
LICCON Error Code Manual

LG1750

073897

19.01.2022

LIEBHERR-WERK EHINGEN GMBH, Postfach 1361, D-89582 Ebingen/Donau
Tel 0049 7391 502-0, Fax 0049 7391 502-3399
www.liebherr.com, E-Mail: info.lwe@liebherr.com

LICCON ERROR CODE (LEC)

Reference	Identification number	Drawing number
Electrics superstructure	98041528	1357-932.87.00.001-
Electrics carrier	98042620	3277-920.13.00.001-
Error list	893609435	9154-700.01.00.000.030

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
000001	ZE 0: system error OS-HC11 (observe parameters) initialising error processor-register erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A420		E	2
000002	ZE 0: system error OS-HC11 (observe parameters) initialising error test total in EPROM/FLASH erroneous no crane operation possible check program memory card or ZE	A420		E	2
000006	ZE 0: system error OS-HC11 (observe parameters) initialising error RAM erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A420		E	2
000007	ZE 0: system error OS-HC11 (observe parameters) UART erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A420		E	2
000010	ZE 0: system error OS-HC11 (observe parameters) system routine inaccessible entry in error memory, all crane movements will be stopped	A420		E	2
000011	ZE 0: system error OS-HC11 (observe parameters) ZE-watchdog expired entry in error memory, all crane movements will be stopped check ZE	A420		E	2
000012	ZE 0: system error OS-HC11 (observe parameters) type-identification in EPROM erroneous entry in error memory, no crane operation possible check program memory card	A420		E	2
000013	ZE 0: system error OS-HC11 (observe parameters) Test sum in FLASH erroneous entry in error memory, all crane movements will be stopped check program memory card	A420		E	2
000014	ZE 0: system error OS-HC11 (observe parameters) program already running entry in error memory, all crane movements will be stopped	A420		E	2
000015	ZE 0: system error OS-HC11 (observe parameters) program not available entry in error memory, all crane movements will be stopped	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
000016	ZE 0: system error OS-HC11 (observe parameters) system-, driver-watchdog expired entry in error memory, all crane movements will be stopped	A420		E	2
000017	ZE 0: system error OS-HC11 (observe parameters) total of CPU-time distribution too great entry in error memory, all crane movements will be stopped	A420		E	2
000018	ZE 0: system error OS-HC11 (observe parameters) arithmetic overflow (16 Bit) entry in error memory, all crane movements will be stopped	A420		E	2
000019	ZE 0: system error OS-HC11 (observe parameters) division through zero (16 Bit) entry in error memory, all crane movements will be stopped	A420		E	2
000020	ZE 0: system error OS-HC11 (observe parameters) task-watchdog expired entry in error memory, all crane movements will be stopped	A420		E	2
000021	ZE 0: system error OS-HC11 (observe parameters) illegal opcode trap entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A420		E	2
000022	ZE 0: system error OS-HC11 (observe parameters) task inactive entry in error memory, all crane movements will be stopped	A420		E	2
000023	ZE 0: system error OS-HC11 (observe parameters) program incapable of running (type identification) entry in error memory, all crane movements will be stopped	A420		E	2
000024	ZE 0: system error OS-HC11 (observe parameters) task already used entry in error memory, all crane movements will be stopped	A420		E	2
000025	ZE 0: system error OS-HC11 (observe parameters) realtime-module already used entry in error memory, all crane movements will be stopped	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
000026	ZE 0: system error OS-HC11 (observe parameters) regulator-module already used entry in error memory, all crane movements will be stopped	A420		E	2
000030	ZE 0: system error OS-HC11 (observe parameters) unacceptable bank address entry in error memory, all crane movements will be stopped	A420		E	2
000041	ZE 0: system error OS-HC11 (observe parameters) arithmetic error entry in error memory, all crane movements will be stopped	A420		E	2
000044	ZE 0: system error OS-HC11 (observe parameters) output parameter without effect, from inactive output entry in error memory, all crane movements will be stopped	A420		E	2
000045	ZE 0: system error OS-HC11 (observe parameters) entry parameter undefined, from inactive input entry in error memory, all crane movements will be stopped	A420		E	2
000046	ZE 0: system error OS-HC11 (observe parameters) impermissible regulator parameter entry in error memory, all crane movements will be stopped	A420		E	2
000047	ZE 0: system error OS-HC11 (observe parameters) realtime-control block not available entry in error memory, all crane movements will be stopped	A420		E	2
000048	ZE 0: system error OS-HC11 (observe parameters) realtime-control block inactive entry in error memory, all crane movements will be stopped	A420		E	2
000049	ZE 0: system error OS-HC11 (observe parameters) urgent modul, ZE not available entry in error memory, no crane operation possible check ZE	A420		E	2
000050	ZE 0: system error OS-HC11 (observe parameters) file not available entry in error memory, all crane movements will be stopped	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
000051	ZE 0: system error OS-HC11 (observe parameters) file already opened entry in error memory, all crane movements will be stopped	A420		E	2
000052	ZE 0: system error OS-HC11 (observe parameters) file not open on close entry in error memory, all crane movements will be stopped	A420		E	2
000053	ZE 0: system error OS-HC11 (observe parameters) system mask not available entry in error memory, all crane movements will be stopped	A420		E	2
000054	ZE 0: system error OS-HC11 (observe parameters) system text not available entry in error memory, all crane movements will be stopped	A420		E	2
000055	ZE 0: system error OS-HC11 (observe parameters) symbol not available entry in error memory, all crane movements will be stopped	A420		E	2
000056	ZE 0: system error OS-HC11 (observe parameters) invalid mark in symbol entry in error memory, all crane movements will be stopped	A420		E	2
000057	ZE 0: system error OS-HC11 (observe parameters) default load chart missing entry in error memory, all crane movements will be stopped	A420		E	2
000058	ZE 0: system error OS-HC11 (observe parameters) amplifier erroneous or return power feed entry in error memory, all crane movements will be stopped check wiring	A420		E	2
000059	ZE 0: system error OS-HC11 (observe parameters) subroutine not reentrant entry in error memory, all crane movements will be stopped	A420		E	2
000060	ZE 0: system error OS-HC11 (observe parameters) transmission error SCI entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
000061	ZE 0: system error OS-HC11 (observe parameters) SCI-BREAK entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A420		E	2
000062	ZE 0: system error OS-HC11 (observe parameters) SCI not connected entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A420		E	2
000063	ZE 0: system error OS-HC11 (observe parameters) monitor error in operation entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A420		E	2
000065	ZE 0: system error OS-HC11 (observe parameters) impermissible bus address entry in error memory, all crane movements will be stopped	A420		E	2
000066	ZE 0: system error OS-HC11 (observe parameters) ADC working outside the permissible tolerance entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A420		E	2
000067	ZE 0: system error OS-HC11 (observe parameters) arithmetic processor not available entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A420		E	2
000068	ZE 0: system error OS-HC11 (observe parameters) impermissible interrupt entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A420		E	2
000070	ZE 0: system error OS-HC11 (observe parameters) various structure versions entry in error memory, no crane operation possible	A420		E	2
000071	ZE 0: system error OS-HC11 (observe parameters) Structure file missing or faulty entry in error memory, no crane operation possible	A420		E	2
000072	ZE 0: system error OS-HC11 (observe parameters) structure entry senseless entry in error memory, no crane operation possible	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
000073	ZE 0: system error OS-HC11 (observe parameters) interpreter error entry in error memory, all crane movements will be stopped	A420		E	2
000074	ZE 0: system error OS-HC11 (observe parameters) transformation ASCII to BIN erroneous entry in error memory, all crane movements will be stopped	A420		E	2
000075	ZE 0: system error OS-HC11 (observe parameters) SPI-error entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A420		E	2
000076	ZE 0: system error OS-HC11 (observe parameters) incorrectly inserted power unit entry in error memory, all crane movements will be stopped check memory card in power supply unit	A420		E	2
000077	ZE 0: system error OS-HC11 (observe parameters) BAF-call-up erroneous entry in error memory, all crane movements will be stopped	A420		E	2
000078	ZE 0: system error OS-HC11 (observe parameters) impermissible parameter entry in error memory, all crane movements will be stopped	A420		E	2
000079	ZE 0: system error OS-HC11 (observe parameters) no right of access entry in error memory, all crane movements will be stopped	A420		E	2
000080	ZE 0: system error OS-HC11 (observe parameters) Fatal internal error entry in error memory, all crane movements will be stopped	A420		E	2
000081	ZE 0: system error OS-HC11 (observe parameters) stack overflow entry in error memory, all crane movements will be stopped	A420		E	2
000082	ZE 0: system error OS-HC11 (observe parameters) hardware-watchdog erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
000094	ZE 0: system error OS-HC11 (observe parameters) transmission error parallel bus entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A420		E	2
000095	ZE 0: system error OS-HC11 (observe parameters) DMA-error entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A420		E	2
000099	ZE 0: system error OS-HC11 (observe parameters) DSP0 erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A420		E	2
002001	ZE 0: system error OS-TMS initialising error processor-register erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A420		E	2
002002	ZE 0: system error OS-TMS initialising error test total in EPROM/FLASH erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A420		E	2
002006	ZE 0: system error OS-TMS initialising error RAM erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A420		E	2
002007	ZE 0: system error OS-TMS UART erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A420		E	2
002020	ZE 0: system error OS-TMS task-watchdog expired entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A420		E	2
002021	ZE 0: system error OS-TMS illegal opcode trap entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A420		E	2
002082	ZE 0: system error OS-TMS hardware-watchdog erroneous entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010012	ZE 0: output 0 short circuit to ground	A420.X1:16		E	1
010013	ZE 0: output 0 open signal circuits	A420.X1:16		E	1
010014	ZE 0: output 0 short circuit to supply voltage	A420.X1:16		E	1
010054	ZE 0: output 0 short circuit to supply voltage	A420.X1:16		E	1
010058	ZE 0: output 0 positive switching transistor: disruption	A420.X1:16		E	1
010070	ZE 0: output 0 measuring system defect no crane operation possible entry in error list	A420.X1:16		E	1
010071	ZE 0: output 0 short circuit to ground or transistor defect	A420.X1:16		E	1
010072	ZE 0: output 0 outside source feeding	A420.X1:16		E	1
010073	ZE 0: output 0 open circuit or short circuit to supply voltage/ground	A420.X1:16		E	1
010112	ZE 0: output 1 short circuit to ground	A420.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010113	ZE 0: output 1 open signal circuits	A420.X1:17		E	1
010114	ZE 0: output 1 short circuit to supply voltage	A420.X1:17		E	1
010154	ZE 0: output 1 short circuit to supply voltage	A420.X1:17		E	1
010158	ZE 0: output 1 positive switching transistor: disruption	A420.X1:17		E	1
010170	ZE 0: output 1 measuring system defect no crane operation possible entry in error list	A420.X1:17		E	1
010171	ZE 0: output 1 short circuit to ground or transistor defect	A420.X1:17		E	1
010172	ZE 0: output 1 outside source feeding	A420.X1:17		E	1
010173	ZE 0: output 1 open circuit or short circuit to supply voltage/ground	A420.X1:17		E	1
010212	ZE 0: output 2 short circuit to ground	A420.X1:18		E	1
010213	ZE 0: output 2 open signal circuits	A420.X1:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010214	ZE 0: output 2 short circuit to supply voltage	A420.X1:18		E	1
010254	ZE 0: output 2 short circuit to supply voltage	A420.X1:18		E	1
010258	ZE 0: output 2 positive switching transistor: disruption	A420.X1:18		E	1
010270	ZE 0: output 2 measuring system defect no crane operation possible entry in error list	A420.X1:18		E	1
010271	ZE 0: output 2 short circuit to ground or transistor defect	A420.X1:18		E	1
010272	ZE 0: output 2 outside source feeding	A420.X1:18		E	1
010273	ZE 0: output 2 open circuit or short circuit to supply voltage/ground	A420.X1:18		E	1
010312	ZE 0: output 3 short circuit to ground	A420.X1:19		E	1
010313	ZE 0: output 3 open signal circuits	A420.X1:19		E	1
010314	ZE 0: output 3 short circuit to supply voltage	A420.X1:19		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010354	ZE 0: output 3 short circuit to supply voltage	A420.X1:19		E	1
010358	ZE 0: output 3 positive switching transistor: disruption	A420.X1:19		E	1
010370	ZE 0: output 3 measuring system defect no crane operation possible entry in error list	A420.X1:19		E	1
010371	ZE 0: output 3 short circuit to ground or transistor defect	A420.X1:19		E	1
010372	ZE 0: output 3 outside source feeding	A420.X1:19		E	1
010373	ZE 0: output 3 open circuit or short circuit to supply voltage/ground	A420.X1:19		E	1
010412	ZE 0: output 4 short circuit to ground	A420.X1:20		E	1
010413	ZE 0: output 4 open signal circuits	A420.X1:20		E	1
010414	ZE 0: output 4 short circuit to supply voltage	A420.X1:20		E	1
010454	ZE 0: output 4 short circuit to supply voltage	A420.X1:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010458	ZE 0: output 4 positive switching transistor: disruption	A420.X1:20		E	1
010460	ZE 0: output 4 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A420.X1:20		E	1
010462	ZE 0: output 4 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A420.X1:20		E	1
010463	ZE 0: output 4 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A420.X1:20		E	1
010470	ZE 0: output 4 measuring system defect no crane operation possible entry in error list	A420.X1:20		E	1
010471	ZE 0: output 4 short circuit to ground or transistor defect	A420.X1:20		E	1
010472	ZE 0: output 4 outside source feeding	A420.X1:20		E	1
010473	ZE 0: output 4 open circuit or short circuit to supply voltage/ground	A420.X1:20		E	1
010512	ZE 0: output 5 short circuit to ground	A420.X1:21		E	1
010513	ZE 0: output 5 open signal circuits	A420.X1:21		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010514	ZE 0: output 5 short circuit to supply voltage	A420.X1:21		E	1
010554	ZE 0: output 5 short circuit to supply voltage	A420.X1:21		E	1
010558	ZE 0: output 5 positive switching transistor: disruption	A420.X1:21		E	1
010560	ZE 0: output 5 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A420.X1:21		E	1
010562	ZE 0: output 5 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A420.X1:21		E	1
010563	ZE 0: output 5 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A420.X1:21		E	1
010570	ZE 0: output 5 measuring system defect no crane operation possible entry in error list	A420.X1:21		E	1
010571	ZE 0: output 5 short circuit to ground or transistor defect	A420.X1:21		E	1
010572	ZE 0: output 5 outside source feeding	A420.X1:21		E	1
010573	ZE 0: output 5 open circuit or short circuit to supply voltage/ground	A420.X1:21		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010612	ZE 0: output 6 short circuit to ground	A420.X1:22		E	1
010613	ZE 0: output 6 open signal circuits	A420.X1:22		E	1
010614	ZE 0: output 6 short circuit to supply voltage	A420.X1:22		E	1
010654	ZE 0: output 6 short circuit to supply voltage	A420.X1:22		E	1
010658	ZE 0: output 6 positive switching transistor: disruption	A420.X1:22		E	1
010660	ZE 0: output 6 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A420.X1:22		E	1
010662	ZE 0: output 6 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A420.X1:22		E	1
010663	ZE 0: output 6 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A420.X1:22		E	1
010670	ZE 0: output 6 measuring system defect no crane operation possible entry in error list	A420.X1:22		E	1
010671	ZE 0: output 6 short circuit to ground or transistor defect	A420.X1:22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010672	ZE 0: output 6 outside source feeding	A420.X1:22		E	1
010673	ZE 0: output 6 open circuit or short circuit to supply voltage/ground	A420.X1:22		E	1
010712	ZE 0: output 7 short circuit to ground	A420.X1:23		E	1
010713	ZE 0: output 7 open signal circuits	A420.X1:23		E	1
010714	ZE 0: output 7 short circuit to supply voltage	A420.X1:23		E	1
010754	ZE 0: output 7 short circuit to supply voltage	A420.X1:23		E	1
010758	ZE 0: output 7 positive switching transistor: disruption	A420.X1:23		E	1
010760	ZE 0: output 7 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A420.X1:23		E	1
010762	ZE 0: output 7 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A420.X1:23		E	1
010763	ZE 0: output 7 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A420.X1:23		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
010770	ZE 0: output 7 measuring system defect no crane operation possible entry in error list	A420.X1:23		E	1
010771	ZE 0: output 7 short circuit to ground or transistor defect	A420.X1:23		E	1
010772	ZE 0: output 7 outside source feeding	A420.X1:23		E	1
010773	ZE 0: output 7 open circuit or short circuit to supply voltage/ground	A420.X1:23		E	1
014959	ZE 0: all output supply voltage missing	A420		E	1
015059	ZE 0: output group 0 supply voltage missing	A420.X1:12		E	1
015159	ZE 0: output group 1 supply voltage missing	A420.X1:24		E	1
015259	ZE 0: output group 2 supply voltage missing	A420		E	1
015359	ZE 0: output group 3 supply voltage missing	A420		E	1
020004	ZE 0: LSB participant address 0 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020005	ZE 0: LSB participant address 0 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020018	ZE 0: LSB participant address 0 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020050	ZE 0: LSB participant address 0 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020051	ZE 0: LSB participant address 0 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020053	ZE 0: LSB participant address 0 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020054	ZE 0: LSB participant address 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020064	ZE 0: LSB participant address 0 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020065	ZE 0: LSB participant address 0 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020066	ZE 0: LSB participant address 0 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020067	ZE 0: LSB participant address 0 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020104	ZE 0: LSB participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020105	ZE 0: LSB participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020118	ZE 0: LSB participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020150	ZE 0: LSB participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020151	ZE 0: LSB participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020153	ZE 0: LSB participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020154	ZE 0: LSB participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020164	ZE 0: LSB participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020165	ZE 0: LSB participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020166	ZE 0: LSB participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020167	ZE 0: LSB participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
020204	ZE 0: LSB participant address 2 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020205	ZE 0: LSB participant address 2 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020218	ZE 0: LSB participant address 2 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020250	ZE 0: LSB participant address 2 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020251	ZE 0: LSB participant address 2 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020253	ZE 0: LSB participant address 2 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020254	ZE 0: LSB participant address 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020264	ZE 0: LSB participant address 2 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020265	ZE 0: LSB participant address 2 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020266	ZE 0: LSB participant address 2 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020267	ZE 0: LSB participant address 2 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
020304	ZE 0: LSB participant address 3 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020305	ZE 0: LSB participant address 3 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020318	ZE 0: LSB participant address 3 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020350	ZE 0: LSB participant address 3 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020351	ZE 0: LSB participant address 3 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020353	ZE 0: LSB participant address 3 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020354	ZE 0: LSB participant address 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020364	ZE 0: LSB participant address 3 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020365	ZE 0: LSB participant address 3 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020366	ZE 0: LSB participant address 3 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020367	ZE 0: LSB participant address 3 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
020404	ZE 0: LSB participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020405	ZE 0: LSB participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020418	ZE 0: LSB participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020450	ZE 0: LSB participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020451	ZE 0: LSB participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020453	ZE 0: LSB participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020454	ZE 0: LSB participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020464	ZE 0: LSB participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020465	ZE 0: LSB participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020466	ZE 0: LSB participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020467	ZE 0: LSB participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
020504	ZE 0: LSB participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020505	ZE 0: LSB participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020518	ZE 0: LSB participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020550	ZE 0: LSB participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020551	ZE 0: LSB participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020553	ZE 0: LSB participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020554	ZE 0: LSB participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020564	ZE 0: LSB participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020565	ZE 0: LSB participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020566	ZE 0: LSB participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020567	ZE 0: LSB participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
020604	ZE 0: LSB participant address 6 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020605	ZE 0: LSB participant address 6 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020618	ZE 0: LSB participant address 6 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020650	ZE 0: LSB participant address 6 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020651	ZE 0: LSB participant address 6 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020653	ZE 0: LSB participant address 6 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020654	ZE 0: LSB participant address 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020664	ZE 0: LSB participant address 6 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020665	ZE 0: LSB participant address 6 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020666	ZE 0: LSB participant address 6 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020667	ZE 0: LSB participant address 6 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
020704	ZE 0: LSB participant address 7 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020705	ZE 0: LSB participant address 7 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020718	ZE 0: LSB participant address 7 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020750	ZE 0: LSB participant address 7 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020751	ZE 0: LSB participant address 7 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020753	ZE 0: LSB participant address 7 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020754	ZE 0: LSB participant address 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020764	ZE 0: LSB participant address 7 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020765	ZE 0: LSB participant address 7 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020766	ZE 0: LSB participant address 7 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020767	ZE 0: LSB participant address 7 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
020804	ZE 0: LSB participant address 8 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020805	ZE 0: LSB participant address 8 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
020818	ZE 0: LSB participant address 8 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020850	ZE 0: LSB participant address 8 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020851	ZE 0: LSB participant address 8 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020853	ZE 0: LSB participant address 8 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020854	ZE 0: LSB participant address 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020864	ZE 0: LSB participant address 8 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020865	ZE 0: LSB participant address 8 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020866	ZE 0: LSB participant address 8 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020867	ZE 0: LSB participant address 8 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
020904	ZE 0: LSB participant address 9 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
020905	ZE 0: LSB participant address 9 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
020918	ZE 0: LSB participant address 9 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
020950	ZE 0: LSB participant address 9 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
020951	ZE 0: LSB participant address 9 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
020953	ZE 0: LSB participant address 9 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
020954	ZE 0: LSB participant address 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
020964	ZE 0: LSB participant address 9 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
020965	ZE 0: LSB participant address 9 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
020966	ZE 0: LSB participant address 9 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
020967	ZE 0: LSB participant address 9 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021004	ZE 0: LSB participant address 10 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021005	ZE 0: LSB participant address 10 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021018	ZE 0: LSB participant address 10 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021050	ZE 0: LSB participant address 10 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021051	ZE 0: LSB participant address 10 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021053	ZE 0: LSB participant address 10 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021054	ZE 0: LSB participant address 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021064	ZE 0: LSB participant address 10 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021065	ZE 0: LSB participant address 10 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021066	ZE 0: LSB participant address 10 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021067	ZE 0: LSB participant address 10 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021104	ZE 0: LSB participant address 11 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021105	ZE 0: LSB participant address 11 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021118	ZE 0: LSB participant address 11 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021150	ZE 0: LSB participant address 11 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021151	ZE 0: LSB participant address 11 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021153	ZE 0: LSB participant address 11 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021154	ZE 0: LSB participant address 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021164	ZE 0: LSB participant address 11 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021165	ZE 0: LSB participant address 11 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021166	ZE 0: LSB participant address 11 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021167	ZE 0: LSB participant address 11 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021204	ZE 0: LSB participant address 12 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021205	ZE 0: LSB participant address 12 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021218	ZE 0: LSB participant address 12 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021250	ZE 0: LSB participant address 12 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021251	ZE 0: LSB participant address 12 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021253	ZE 0: LSB participant address 12 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021254	ZE 0: LSB participant address 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021264	ZE 0: LSB participant address 12 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021265	ZE 0: LSB participant address 12 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021266	ZE 0: LSB participant address 12 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021267	ZE 0: LSB participant address 12 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021304	ZE 0: LSB participant address 13 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021305	ZE 0: LSB participant address 13 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021318	ZE 0: LSB participant address 13 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021350	ZE 0: LSB participant address 13 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021351	ZE 0: LSB participant address 13 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021353	ZE 0: LSB participant address 13 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021354	ZE 0: LSB participant address 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021364	ZE 0: LSB participant address 13 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021365	ZE 0: LSB participant address 13 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021366	ZE 0: LSB participant address 13 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021367	ZE 0: LSB participant address 13 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021404	ZE 0: LSB participant address 14 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021405	ZE 0: LSB participant address 14 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021418	ZE 0: LSB participant address 14 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021450	ZE 0: LSB participant address 14 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021451	ZE 0: LSB participant address 14 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021453	ZE 0: LSB participant address 14 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021454	ZE 0: LSB participant address 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021464	ZE 0: LSB participant address 14 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021465	ZE 0: LSB participant address 14 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021466	ZE 0: LSB participant address 14 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021467	ZE 0: LSB participant address 14 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021504	ZE 0: LSB participant address 15 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021505	ZE 0: LSB participant address 15 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021518	ZE 0: LSB participant address 15 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021550	ZE 0: LSB participant address 15 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021551	ZE 0: LSB participant address 15 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021553	ZE 0: LSB participant address 15 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021554	ZE 0: LSB participant address 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021564	ZE 0: LSB participant address 15 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021565	ZE 0: LSB participant address 15 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021566	ZE 0: LSB participant address 15 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021567	ZE 0: LSB participant address 15 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021604	ZE 0: LSB participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021605	ZE 0: LSB participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021618	ZE 0: LSB participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021650	ZE 0: LSB participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021651	ZE 0: LSB participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021653	ZE 0: LSB participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021654	ZE 0: LSB participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021664	ZE 0: LSB participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021665	ZE 0: LSB participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021666	ZE 0: LSB participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021667	ZE 0: LSB participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021704	ZE 0: LSB participant address 17 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021705	ZE 0: LSB participant address 17 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021718	ZE 0: LSB participant address 17 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021750	ZE 0: LSB participant address 17 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021751	ZE 0: LSB participant address 17 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021753	ZE 0: LSB participant address 17 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021754	ZE 0: LSB participant address 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021764	ZE 0: LSB participant address 17 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021765	ZE 0: LSB participant address 17 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021766	ZE 0: LSB participant address 17 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021767	ZE 0: LSB participant address 17 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021804	ZE 0: LSB participant address 18 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021805	ZE 0: LSB participant address 18 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
021818	ZE 0: LSB participant address 18 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021850	ZE 0: LSB participant address 18 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021851	ZE 0: LSB participant address 18 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021853	ZE 0: LSB participant address 18 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021854	ZE 0: LSB participant address 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021864	ZE 0: LSB participant address 18 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021865	ZE 0: LSB participant address 18 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021866	ZE 0: LSB participant address 18 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021867	ZE 0: LSB participant address 18 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
021904	ZE 0: LSB participant address 19 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
021905	ZE 0: LSB participant address 19 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
021918	ZE 0: LSB participant address 19 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
021950	ZE 0: LSB participant address 19 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
021951	ZE 0: LSB participant address 19 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
021953	ZE 0: LSB participant address 19 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
021954	ZE 0: LSB participant address 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
021964	ZE 0: LSB participant address 19 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
021965	ZE 0: LSB participant address 19 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
021966	ZE 0: LSB participant address 19 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
021967	ZE 0: LSB participant address 19 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022004	ZE 0: LSB participant address 20 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022005	ZE 0: LSB participant address 20 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022018	ZE 0: LSB participant address 20 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022050	ZE 0: LSB participant address 20 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022051	ZE 0: LSB participant address 20 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022053	ZE 0: LSB participant address 20 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022054	ZE 0: LSB participant address 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022064	ZE 0: LSB participant address 20 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022065	ZE 0: LSB participant address 20 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022066	ZE 0: LSB participant address 20 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022067	ZE 0: LSB participant address 20 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022104	ZE 0: LSB participant address 21 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022105	ZE 0: LSB participant address 21 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022118	ZE 0: LSB participant address 21 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022150	ZE 0: LSB participant address 21 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022151	ZE 0: LSB participant address 21 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022153	ZE 0: LSB participant address 21 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022154	ZE 0: LSB participant address 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022164	ZE 0: LSB participant address 21 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022165	ZE 0: LSB participant address 21 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022166	ZE 0: LSB participant address 21 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022167	ZE 0: LSB participant address 21 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022204	ZE 0: LSB participant address 22 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022205	ZE 0: LSB participant address 22 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022218	ZE 0: LSB participant address 22 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022250	ZE 0: LSB participant address 22 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022251	ZE 0: LSB participant address 22 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022253	ZE 0: LSB participant address 22 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022254	ZE 0: LSB participant address 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022264	ZE 0: LSB participant address 22 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022265	ZE 0: LSB participant address 22 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022266	ZE 0: LSB participant address 22 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022267	ZE 0: LSB participant address 22 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022304	ZE 0: LSB participant address 23 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022305	ZE 0: LSB participant address 23 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022318	ZE 0: LSB participant address 23 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022350	ZE 0: LSB participant address 23 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022351	ZE 0: LSB participant address 23 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022353	ZE 0: LSB participant address 23 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022354	ZE 0: LSB participant address 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022364	ZE 0: LSB participant address 23 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022365	ZE 0: LSB participant address 23 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022366	ZE 0: LSB participant address 23 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022367	ZE 0: LSB participant address 23 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022404	ZE 0: LSB participant address 24 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022405	ZE 0: LSB participant address 24 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022418	ZE 0: LSB participant address 24 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022450	ZE 0: LSB participant address 24 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022451	ZE 0: LSB participant address 24 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022453	ZE 0: LSB participant address 24 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022454	ZE 0: LSB participant address 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022464	ZE 0: LSB participant address 24 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022465	ZE 0: LSB participant address 24 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022466	ZE 0: LSB participant address 24 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022467	ZE 0: LSB participant address 24 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022504	ZE 0: LSB participant address 25 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022505	ZE 0: LSB participant address 25 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022518	ZE 0: LSB participant address 25 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022550	ZE 0: LSB participant address 25 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022551	ZE 0: LSB participant address 25 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022553	ZE 0: LSB participant address 25 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022554	ZE 0: LSB participant address 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022564	ZE 0: LSB participant address 25 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022565	ZE 0: LSB participant address 25 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022566	ZE 0: LSB participant address 25 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022567	ZE 0: LSB participant address 25 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022604	ZE 0: LSB participant address 26 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022605	ZE 0: LSB participant address 26 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022618	ZE 0: LSB participant address 26 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022650	ZE 0: LSB participant address 26 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022651	ZE 0: LSB participant address 26 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022653	ZE 0: LSB participant address 26 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022654	ZE 0: LSB participant address 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022664	ZE 0: LSB participant address 26 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022665	ZE 0: LSB participant address 26 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022666	ZE 0: LSB participant address 26 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022667	ZE 0: LSB participant address 26 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022704	ZE 0: LSB participant address 27 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022705	ZE 0: LSB participant address 27 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022718	ZE 0: LSB participant address 27 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022750	ZE 0: LSB participant address 27 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022751	ZE 0: LSB participant address 27 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022753	ZE 0: LSB participant address 27 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022754	ZE 0: LSB participant address 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022764	ZE 0: LSB participant address 27 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022765	ZE 0: LSB participant address 27 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022766	ZE 0: LSB participant address 27 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022767	ZE 0: LSB participant address 27 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022804	ZE 0: LSB participant address 28 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022805	ZE 0: LSB participant address 28 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
022818	ZE 0: LSB participant address 28 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022850	ZE 0: LSB participant address 28 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022851	ZE 0: LSB participant address 28 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022853	ZE 0: LSB participant address 28 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022854	ZE 0: LSB participant address 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022864	ZE 0: LSB participant address 28 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022865	ZE 0: LSB participant address 28 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022866	ZE 0: LSB participant address 28 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022867	ZE 0: LSB participant address 28 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
022904	ZE 0: LSB participant address 29 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1
022905	ZE 0: LSB participant address 29 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
022918	ZE 0: LSB participant address 29 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
022950	ZE 0: LSB participant address 29 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
022951	ZE 0: LSB participant address 29 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
022953	ZE 0: LSB participant address 29 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
022954	ZE 0: LSB participant address 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
022964	ZE 0: LSB participant address 29 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
022965	ZE 0: LSB participant address 29 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
022966	ZE 0: LSB participant address 29 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
022967	ZE 0: LSB participant address 29 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1
023004	ZE 0: LSB participant address 30 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
023005	ZE 0: LSB participant address 30 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A420.X2:z14/z16		E	1
023018	ZE 0: LSB participant address 30 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A420.X2:z14/z16		E	0
023050	ZE 0: LSB participant address 30 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A420.X2:z14/z16		E	2
023051	ZE 0: LSB participant address 30 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A420.X2:z14/z16		E	2
023053	ZE 0: LSB participant address 30 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A420.X2:z14/z16		E	1
023054	ZE 0: LSB participant address 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A420.X2:z14/z16		E	2
023064	ZE 0: LSB participant address 30 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A420.X2:z14/z16		E	1
023065	ZE 0: LSB participant address 30 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A420.X2:z14/z16		E	2
023066	ZE 0: LSB participant address 30 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A420.X2:z14/z16		E	2
023067	ZE 0: LSB participant address 30 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A420.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
023252	ZE 0: Control data transfer LSB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A420.X2:z14/z16		E	0
023255	ZE 0: Control data transfer LSB Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A420.X2:z14/z16		E	2
023256	ZE 0: Control data transfer LSB Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A420.X2:z14/z16		E	2
023257	ZE 0: Control data transfer LSB has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A420.X2:z14/z16		E	1
023258	ZE 0: Control data transfer LSB recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A420.X2:z14/z16		E	0
023259	ZE 0: Control data transfer LSB recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A420.X2:z14/z16		E	0
023260	ZE 0: Control data transfer LSB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A420.X2:z14/z16		E	2
023261	ZE 0: Control data transfer LSB driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A420.X2:z14/z16		E	2
023262	ZE 0: Control data transfer LSB Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A420.X2:z14/z16		E	2
024814	ZE 0: input 0 short circuit to supply voltage report of error, shut-down through application Check sensor line for short-circuit, for faulty sensors by pulling out sensor, connection to input	A420.X2:d2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
024817	ZE 0: input 0 voltage below required value error report only Check sensor and supply line, replace faulty sensor	A420.X2:d2		E	1
024856	ZE 0: input 0 open circuit or short circuit to ground report of error, shut-down through application Check supply voltage, input LICCON, sensor line for interruption, for faulty sensors by pulling out G	A420.X2:d2		E	1
024914	ZE 0: input 1 short circuit to supply voltage report of error, shut-down through application Check sensor line for short-circuit, for faulty sensors by pulling out sensor, connection to input	A420.X2:d4		E	1
024917	ZE 0: input 1 voltage below required value error report only Check sensor and supply line, replace faulty sensor	A420.X2:d4		E	1
024956	ZE 0: input 1 open circuit or short circuit to ground report of error, shut-down through application Check supply voltage, input LICCON, sensor line for interruption, for faulty sensors by pulling out G	A420.X2:d4		E	1
025002	ZE 0: input 2 sensor deficiency data short circuit to supply voltage report of error, otherwise no reaction check supply, LICCON input, sensor lines to short or break, sensor	A420.X2:d6		E	1
025010	ZE 0: input 2 inadmissible signal difference No selection of respective table possible due to faulty feedback signal slewing platform locking check supply, LICCON input, sensor lines to short or break, sensor	A420.X2:d6		E	1
025102	ZE 0: input 3 sensor deficiency data short circuit to supply voltage report of error, otherwise no reaction check supply, LICCON input, sensor lines to short or break, sensor	A420.X2:d8		E	1
026114	ZE 0: input 13 short circuit to supply voltage report of error, shut-down through application Check sensor line for short-circuit, for faulty sensors by pulling out sensor, connection to input	A420.X2:d28		E	1
026156	ZE 0: input 13 open circuit or short circuit to ground report of error, shut-down through application Check supply voltage, input LICCON, sensor line for interruption, for faulty sensors by pulling out G	A420.X2:d28		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
026314	ZE 0: input 15 short circuit to supply voltage operational shut down Spool up - out winch 5 is only permitted with switched on installation switch .	A420.X2:d32		E	
027210	ZE 0: input 24 inadmissible signal difference No selection of respective table possible due to faulty feedback signal slewing platform locking check supply, LICCON input, sensor lines to short or break, sensor	A420.X2:b18		E	1
027365	ZE 0: input 25 Error report, short circuit after supply voltage before start output of error Report check safety chain on short circuit supply voltage and remedy error, possibly external feed	A420.X2:b20		E	2
027366	ZE 0: input 25 Error report, short circuit after supply voltage after end output of error Report check safety chain on short circuit supply voltage and remedy error, possibly external feed	A420.X2:b20		E	2
027514	ZE 0: input 27 short circuit to supply voltage operational shut down Spool up - out winch 5 is only permitted with switched on installation switch .	A420.X2:b24		E	
030000	ZE 0: LMB crane not commissioned or memory error error report only program commissioning data according to commissioning report through after-sales service	A420		B	1
030005	ZE 0: LMB winch 1 not regulated, hook course indicator erroneous imprecise winch control and incorrect hook course indication for winch 1 Start up adjustment switch for range of lift display for winch 1 in lowering direction	A420		E	1
030006	ZE 0: LMB winch 2 not regulated, hook course indicator erroneous imprecise winch control and incorrect hook course indication of winch 2 trigger adjustment switch for hook course indication of winch 2 through lowering	A420		E	1
030016	ZE 0: LMB Pressure transducer overtop guard cyl main boom faulty/not present Load display too great Check sensor and supply line, replace faulty sensor	A420		E	1
030030	ZE 0: LMB One signal draw-meas. conn plate for load weigh faulty/not present Load display if necessary imprecise Check sensor and supply line, replace faulty sensor	A420		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030031	ZE 0: LMB One signal press. tran. for load weigh mast stub faulty/not present Load display if necessary imprecise Check sensor and supply line, replace faulty sensor	A420		E	1
030032	ZE 0: LMB One angle sensor derrick faulty/not present Load display if necessary imprecise Check sensor and supply line, replace faulty sensor	A420		E	1
03003F	ZE 0: LMB F3min undercut, all F3 reducing movements will be stopped Output of error Lower load or lower derrick ballast if possible or spool out retraction gear if possible.	A420		B	1
030040	ZE 0: LMB no standard table defined for this crane program stop Install new program memory card with corrected tables	A420		B	3
030041	ZE 0: LMB all data for actual operation mode not available program stop Install new program memory card with corrected tables	A420		B	3
030042	ZE 0: LMB no valid control word in this table program stop Install new program memory card with corrected tables	A420		B	3
03004A	ZE 0: LMB Pull test bracket 1A left erroneous/missing (not active) F1-Force imprecise, load display possibly imprecise Check sensor and supply line, replace faulty sensor	A420		E	1
03004B	ZE 0: LMB Pull test bracket 1B right erroneous/missing (not active) F1-Force imprecise, load display possibly imprecise Check sensor and supply line, replace faulty sensor	A420		E	1
03004C	ZE 0: LMB Pull test bracket 1A left reports internal error F1-Force imprecise, load display possibly imprecise replace sensor immediately	A420		E	1
03004D	ZE 0: LMB Pull test bracket 1B left reports internal error F1-Force imprecise, load display possibly imprecise replace sensor immediately	A420		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030050	ZE 0: LMB no load chart displayed acoustical signal on actuation of OK-key, no modification in operation program select valid load chart through short-code or function keys F2-F6 and confirm with ENTER	A420		B	1
030051	ZE 0: LMB external information (e.g. slewing platform bolting) missing load chart cannot be entered through OK-key activate slewing platform lock, if necessary check connection to end of stroke switch, or select another load chart	A420		B	1
030052	ZE 0: LMB re-fitting with load more than 0.5t and utilization larger 20% load chart cannot be entered through OK-key put load to ground or switch crane off and on again	A420		B	1
030053	ZE 0: LMB MAN-/AUTO-change-over blocked, unbolt cylinder/tele selected, MS switch-over on manual operation prevented as cylinder or tele not pinned approach pre-selected telescoping target in automatic operation mode (bolt cylinder or tele)	A420		B	1
030054	ZE 0: LMB no new telescoping objective, cylinder/tele unbolting selected, MS modification of telesc. objective prevented- cylinder/tele bolting switch not "0" set or MS "telescoping switch over switch to "0" position and release MS "telescoping"	A420		B	1
03005E	ZE 0: LMB SLGS winch installed but ZM 13 erroneous -> TL is reduced Issuance of error. Load is reduced as if the SLGS rope had been tensioned correctly Check pull test bracket or supply line	A420		E	1
030064	ZE 0: LMB measured overall torque smaller than half torque without charge LMB-Stop: Load torque increasing movements cannot be affected move boom out of danger zone or check sensor (angle-, pressure-, length),if load or radius indication incorrect	A420		B	2
030065	ZE 0: LMB computation-bound program part will no longer run LMB-Stop: Load torque increasing movements cannot be affected on starting, the set-up equipment program key was pressed	A420		B	2
03006B	ZE 0: LMB Boom nose measuring sleeve 6A or 6B not active Output of error. Operation with a sensor is possible Check measuring sleeve as soon as possible.	A420		E	2
030079	ZE 0: LMB STOP, adjusted op. mode and crane configuration not identical LMB-Stop: Load torque increasing movements cannot be affected set up crane according to selected operation mode	A420		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030080	ZE 0: LMB Wind speed transmitter main boom faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	1
030081	ZE 0: LMB Wind speed transmitter accessories faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	1
030082	ZE 0: LMB Wind speed transmitter 3 main boom faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	1
030083	ZE 0: LMB Wind speed transmitter 3 accessories faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	1
030084	ZE 0: LMB Wind speed transmitter 1A reports internal error error report only replace sensor immediately	A420		E	1
030085	ZE 0: LMB Wind speed transmitter 1B reports internal error error report only replace sensor immediately	A420		E	1
030086	ZE 0: LMB Wind speed transmitter 2A reports internal error error report only replace sensor immediately	A420		E	1
030087	ZE 0: LMB Wind speed transmitter 2B reports internal error error report only replace sensor immediately	A420		E	1
030088	ZE 0: LMB Wind speed transmitter 3 main boom reports internal error error report only replace sensor immediately	A420		E	1
030089	ZE 0: LMB Wind speed transmitter 3 accessory reports internal error error report only replace sensor immediately	A420		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030090	ZE 0: LMB Hoist limit switch 1A reports internal error error report only replace sensor immediately	A420		E	1
030091	ZE 0: LMB Hoist limit switch 1B reports internal error error report only replace sensor immediately	A420		E	1
030092	ZE 0: LMB Hoist limit switch 2A reports internal error error report only replace sensor immediately	A420		E	1
030093	ZE 0: LMB Hoist limit switch 2B reports internal error error report only replace sensor immediately	A420		E	1
030094	ZE 0: LMB Hoist limit switch 3 main boom reports internal error error report only replace sensor immediately	A420		E	1
030095	ZE 0: LMB Hoist limit switch 3 accessory reports internal error error report only replace sensor immediately	A420		E	1
030096	ZE 0: LMB Jib, flap and overtopping guard struts in danger of colliding report of error, shut-down through application Luff down jib	A420		B	1
030097	ZE 0: LMB Load utilis >95% and dropping of load when luffing up main boom report of error, shut-down through application Reduce utilisation, if necessary luff up via jib	A420		B	1
030098	ZE 0: LMB 2 front supports are heavily loaded, danger of tipping to the rear error report only Load supports evenly	A420		B	1
030099	ZE 0: LMB 2 supports are heavily loaded, danger of tipping error report only Load supports evenly	A420		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030100	ZE 0: LMB STOP, main boom not mounted LMB-Stop: Load torque increasing movements cannot be affected Mount missing assembly	A420		B	2
030101	ZE 0: LMB STOP, jib not mounted LMB-Stop: Load torque increasing movements cannot be affected Mount missing assembly	A420		B	2
030102	ZE 0: LMB STOP, derrick not mounted LMB-Stop: Load torque increasing movements cannot be affected Mount missing assembly	A420		B	2
030103	ZE 0: LMB STOP, counterweight carriage not mounted LMB-Stop: Load torque increasing movements cannot be affected Mount missing assembly	A420		B	2
030104	ZE 0: LMB STOP, suspended counterweight not mounted LMB-Stop: Load torque increasing movements cannot be affected Mount missing assembly	A420		B	2
030105	ZE 0: LMB Main boom mounted?, pilot contact<>Bus sensor, condition faulty LMB-Stop: Load torque increasing movements cannot be affected Check pilot contact signals and active LSB sensor of mounted assemblies	A420		E	2
030106	ZE 0: LMB Jib mounted?, pilot contact<>Bus sensor, condition faulty LMB-Stop: Load torque increasing movements cannot be affected Check pilot contact signals and active LSB sensor of mounted assemblies	A420		E	2
030107	ZE 0: LMB Derrick mounted?, pilot contact<>Bus sensor, condition faulty LMB-Stop: Load torque increasing movements cannot be affected Check pilot contact signals and active LSB sensor of mounted assemblies	A420		E	2
030108	ZE 0: LMB Hoist limit switch mast stub has incorrect LSB-address LMB-Stop: Load torque increasing movements cannot be affected Connect sensor, or check sensor or supply line	A420		E	2
030109	ZE 0: LMB Mast stub, press. < minimum press., load display incorrect, DANGER! LMB-Stop: Load torque increasing movements cannot be affected Check sensor, measuring cylinder for leaks	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030114	ZE 0: LMB STOP, hoist limit switch 1A faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	2
030115	ZE 0: LMB STOP, hoist limit switch 1B faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	2
030116	ZE 0: LMB STOP, hoist limit switch 2A faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	2
030117	ZE 0: LMB STOP, hoist limit switch 2B faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	2
030118	ZE 0: LMB STOP, hoist limit switch 3 main boom faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	2
030119	ZE 0: LMB STOP, hoist limit switch 3 accessory faulty/not present error report only Connect sensor, or check sensor or supply line	A420		B	2
030133	ZE 0: LMB fly jib retaining cylinder inferior minimal pressure LMB-Stop: Load torque increasing movements cannot be affected Check overtopping guard cylinder for leaks, or check pressure transducer and replace if necessary	A420		B	2
030134	ZE 0: LMB fly jib retaining cylinder exceeds maximum pressure LMB-Stop: Load torque increasing movements cannot be affected Check pressure and position of overtopping guard cylinder, or check pressure transducer and replace if necessary	A420		B	2
030135	ZE 0: LMB permissible deviation of data A/B tension meas. bracket 1 exceeded LMB-Stop: Load torque increasing movements cannot be affected check connecting brackets or power supply, different stress flow into both connecting brackets possible	A420		B	2
030136	ZE 0: LMB permissible deviation of data A/B tension meas. bracket 2 exceeded LMB-Stop: Load torque increasing movements cannot be affected check connecting brackets or power supply, different stress flow into both connecting brackets possible	A420		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030137	ZE 0: LMB permissible deviation of data A/B tension meas. bracket 3 exceeded LMB-Stop: Load torque increasing movements cannot be affected check connecting brackets or power supply, different stress flow into both connecting brackets possible	A420		B	2
030138	ZE 0: LMB STOP, permissible deviation press. tran. mast stub 6 A/B exceeded LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
030139	ZE 0: LMB STOP, permissible deviation pressure transducer jib-RFP exceeded LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
03013B	ZE 0: LMB STOP, permissible deviation measuring sleeve boom nose 6A/B exceeded LMB-Stop: Increased load torque movements and slewing cannot be affected Check measuring sleeve, replace if necessary	A420		E	2
03013C	ZE 0: LMB STOP, measuring sleeve boom nose 6A/B: both sensors not active LMB-Stop: Increased load torque movements and slewing cannot be affected Check measuring sleeve, replace if necessary	A420		E	2
03013D	ZE 0: LMB STOP, load on the boom nose although reeving of boom nose = 0 Output of error with LMB stop Check if the equipped boom nose reeving is correct or if the sensors for load weighing on the boom nose are defective.	A420		B	2
03013F	ZE 0: LMB STOP, pull test bracket 3 defective/missing for F3min monitoring LMB stop and output of error Check sensor, replace if necessary	A420		E	2
030143	ZE 0: LMB and turn STOP, sliding beam angle 1 not as equipped LMB-Stop: Increased load torque movements and slewing cannot be affected Support crane acc. equipment configuration	A420		B	2
030144	ZE 0: LMB and turn STOP, sliding beam angle 2 not as equipped LMB-Stop: Increased load torque movements and slewing cannot be affected Support crane acc. equipment configuration	A420		B	2
030145	ZE 0: LMB and turn STOP, sliding beam angle 3 not as equipped LMB-Stop: Increased load torque movements and slewing cannot be affected Support crane acc. equipment configuration	A420		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030146	ZE 0: LMB and turn STOP, sliding beam angle 4 not as equipped LMB-Stop: Increased load torque movements and slewing cannot be affected Support crane acc. equipment configuration	A420		B	2
030147	ZE 0: LMB working radius list in load chart with incorrect value LMB-Stop: Load torque increasing movements cannot be affected install new data memory card with corrected charts	A420		B	2
030148	ZE 0: LMB actual working radius too small, not in chart LMB-Stop: Load torque increasing movements cannot be affected take care when luffing down to chart area while assembly mode selected	A420		B	2
030149	ZE 0: LMB actual working radius too large, not in chart LMB-Stop: Load torque increasing movements cannot be affected take care with "luffing up when overloaded" when luffing up into chart area	A420		B	2
03014A	ZE 0: LMB STOP, Luff up not possible: upper limit shut off angle reached! Op.shut off, cannot be bypassed. Issue error w.LMB-Stop. Increase radius by spooling out resp. winch	A420		B	1
030150	ZE 0: LMB crane stands in impermissible length-/angle position LMB-Stop: Load torque increasing movements cannot be affected conduct boom in permissible position referred to length, boom angle, bolting condition and fly jib angle	A420		B	2
030151	ZE 0: LMB unknown access type to load chart LMB-Stop: Load torque increasing movements cannot be affected install new data memory card with corrected charts	A420		B	2
030152	ZE 0: LMB no table exists for actual crane configuration LMB-Stop: Load torque increasing movements cannot be affected purchase additional load charts, install new data memory card with corrected charts	A420		B	2
030154	ZE 0: LMB crane improperly supported or support pressure sensor defect LMB-Stop: Increased load torque movements and slewing cannot be affected Support the crane to clear the travel gear or check support pr. sensor or its supply line	A420		B	2
030166	ZE 0: LMB and turn STOP, Sliding beam length 1 not as set up LMB-Stop: Increased load torque movements and slewing cannot be affected Support crane acc. equipment configuration	A420		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030167	ZE 0: LMB and turn STOP, Sliding beam length 2 not as set up LMB-Stop: Increased load torque movements and slewing cannot be affected Support crane acc. equipment configuration	A420		B	2
030168	ZE 0: LMB and turn STOP, Sliding beam length 3 not as set up LMB-Stop: Increased load torque movements and slewing cannot be affected Support crane acc. equipment configuration	A420		B	2
030169	ZE 0: LMB and turn STOP, Sliding beam length 4 not as set up LMB-Stop: Increased load torque movements and slewing cannot be affected Support crane acc. equipment configuration	A420		B	2
03016A	ZE 0: LMB Length sensor sliding beam cyl. 1 (ri/rear) erroneous/missing Output of error Check sensor and supply line, replace defective sensor, if nec.	A420		B	2
03016B	ZE 0: LMB Length sensor sliding beam cyl. 2 (ri/front) erroneous/missing Output of error Check sensor and supply line, replace defective sensor, if nec.	A420		B	2
03016C	ZE 0: LMB Length sensor sliding beam cyl. 3 (le/front) erroneous/missing Output of error Check sensor and supply line, replace defective sensor, if nec.	A420		B	2
03016D	ZE 0: LMB Length sensor sliding beam cyl. 4 (le/rear) erroneous/missing Output of error Check sensor and supply line, replace defective sensor, if nec.	A420		B	2
030170	ZE 0: LMB STOP, Dummy plug/plug mast stub main boom faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Plug in dummy plug mast stub-plug	A420		B	2
030171	ZE 0: LMB STOP, Dummy plug/plug mast stub accessory faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Plug in dummy plug mast stub-plug	A420		B	2
030180	ZE 0: LMB STOP, Difference between angle sensors main boom too great LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030181	ZE 0: LMB STOP, Difference between angle sensors A/B derrick too great LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
030182	ZE 0: LMB difference between angle sensor cylinder lower/upper too great LMB-Stop: Load torque increasing movements cannot be affected retrieve crane deflection through unloading, or check both angle sensors or their lines	A420		B	2
030188	ZE 0: LMB STOP, several angler sensors main boom/jib faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
030189	ZE 0: LMB STOP, both angle sensors derrick faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
030190	ZE 0: LMB angle sensor error: load, reach, pulley head height indication defect LMB-Stop: Load torque increasing movements cannot be affected check LSB-connection, angle sensor	A420		E	2
030191	ZE 0: LMB STOP, both draw-meas. conn plates for load weigh faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
030192	ZE 0: LMB STOP, both press. tran. load weighing mast stub faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
030193	ZE 0: LMB STOP, several press. tran. derrick ballast weigh. faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
030194	ZE 0: LMB STOP, all press. tran. overtop. guard cylinder jib faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
030195	ZE 0: LMB Impermissible angle sensor from main boom or accessory active LMB-Stop: Load torque increasing movements cannot be affected Incorrect boom mounted, incorrect operation type selected or angle sensor has incorrect LSB address	A420		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
03019A	ZE 0: LMB STOP, both pull test brackets 1 A und 1B erroneous/missing LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A420		E	2
0301A1	ZE 0: LMB Length sensor folding beam swing out cyl. 1 erroneous/missing Output of error Check sensor and supply line, replace defective sensor, if nec.	A420		B	2
0301A2	ZE 0: LMB Length sensor folding beam swing out cyl. 2 erroneous/missing Output of error Check sensor and supply line, replace defective sensor, if nec.	A420		B	2
0301A3	ZE 0: LMB Length sensor folding beam swing out cyl. 3 erroneous/missing Output of error Check sensor and supply line, replace defective sensor, if nec.	A420		B	2
0301A4	ZE 0: LMB Length sensor folding beam swing out cyl. 4 erroneous/missing Output of error Check sensor and supply line, replace defective sensor, if nec.	A420		B	2
030200	ZE 0: LMB STOP, crane correspondent table over-equipped control-Stop: even in operation mode crane movements cannot be affected enter chart according to mounted equipment	A420		B	2
030201	ZE 0: LMB All movements STOP, Crawler assembly selected with mounted boom control-Stop: even in operation mode crane movements cannot be affected Select correct switch position	A420		B	2
030202	ZE 0: LMB All movements STOP, jib over-equipped control-Stop: even in operation mode crane movements cannot be affected Disassemble surplus assemblies	A420		B	2
030203	ZE 0: LMB All movements STOP, derrick over equipped control-Stop: even in operation mode crane movements cannot be affected Disassemble surplus assemblies	A420		B	2
030204	ZE 0: LMB STOP, Ballast trailer overequipped LMB-Stop: Load torque increasing movements cannot be affected Disassemble surplus assemblies	A420		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
030205	ZE 0: LMB STOP, susp. ballast overequipped LMB-Stop: Load torque increasing movements cannot be affected Disassemble surplus assemblies	A420		B	2
030206	ZE 0: LMB STOP, LSB-sensor from various mast stubs simultaneously active LMB-Stop: Load torque increasing movements cannot be affected Check affiliated LSB sensor	A420		B	2
030231	ZE 0: LMB STOP, SLK limit switch signal lower Pos. does not match angle sensors LMB-Stop: Load moment increasing movements cannot be run (error is self retaining as long as crane is turned on) Check SLK- limit switch for lower operating range and all angle sensor on boom, replace if necessary	A420		B	2
030241	ZE 0: LMB STOP, overflow with calculation LMB-Stop: Load torque increasing movements cannot be affected Check sensor values, manual adjustments and actual crane condition, if necessary inform after-sales-service	A420		B	3
030245	ZE 0: LMB STOP, internal memory error/program part implausible LMB-Stop: Load torque increasing movements cannot be affected Read error report/display in LICCON test system special diagram "LMB - ERRORS", inform after-sales service	A420		E	3
032800	ZE 0: control slewing No swing movement recognised with selected swing gear Output of error Actuate slewing gear with at least 1/8 init current and check incremental counter (dir. of rotation/function)	A420		E	
032822	ZE 0: control slewing Pressure switch slewing gear brake erroneous/missing	A420		E	
032823	ZE 0: control slewing Pressure switch slewing gear coasting erroneous/missing	A420		E	
033100	ZE 0: Control ballasting / counterweight carriage Limit switch "BW bolted" faulty / not present - Shut-down BW active Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Error remedy see corresponding system error.	A420		E	
033101	ZE 0: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and FB inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following earthing or line interruption, checking of inputs.	A420		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
033102	ZE 0: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted and FB inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A420		E	
033103	ZE 0: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and bolted and FB inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A420		E	
033104	ZE 0: Control ballasting / counterweight carriage Invalid assembly condition - B inserted and FB not inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following supply voltage or earthing or line interruption.	A420		E	
033105	ZE 0: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and B inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following supply voltage or earthing or line interruption.	A420		E	
033106	ZE 0: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A420		E	
033107	ZE 0: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and bolted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A420		E	
033108	ZE 0: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted FB inserted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A420		E	
033943	ZE 0: crane control "Ballast cylinder A not" cont. actuated Output of error Bring button in zero position. If error continued to be active, check electric.	A420		E	
033944	ZE 0: crane control "Ballast cylinder B not" cont. actuated Output of error Bring button in zero position. If error continued to be active, check electric.	A420		E	
03396E	ZE 0: crane control BKE1 Control console crane cab missing Output of error, otherwise no reaction. Check sensor.	A420		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
03396F	ZE 0: crane control BKE1 control console crane cab reports error Output of error, otherwise no reaction. Check sensor, read out any other errors.	A420		E	
033970	ZE 0: crane control BKE1 Control console crane cab defective/missing Output of error, otherwise no reaction. Check sensor.	A420		E	
033971	ZE 0: crane control BTB4_1 defective/missing Output of error, otherwise no reaction. Check sensor.	A420		E	
033972	ZE 0: crane control TE07 TE-module heater defective/missing Output of error, otherwise no reaction. Check sensor.	A420		E	
033973	ZE 0: crane control BTB4_0 defective/missing Output of error, otherwise no reaction. Check sensor.	A420		E	
033974	ZE 0: crane control Pull test bracket F meas. pt. 13F A 500 KN defective/missing Output of error, otherwise no reaction. Check sensor.	A420		E	
033975	ZE 0: crane control BTB6 missing Output of error, otherwise no reaction. Check sensor.	A420		E	
033976	ZE 0: crane control BTB6 reports error Output of error, otherwise no reaction. Check sensor, read out any other errors.	A420		E	
033E41	ZE 0: Switch cabinet LMB-bypass-emerg. or cont. actuation or Short circuit after Ubatt	A420		E	2
034039	ZE 0: instruments crane operators cab Seat contact operated permanently or short circuit after power supply	A420		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
03403C	ZE 0: instruments crane operators cab Assembly continuous actuation or short circuit aft.supply current	A420		E	1
03403D	ZE 0: instruments crane operators cab LMB-bypass cont. actuation or short circuit after Ubatt	A420		E	1
03403F	ZE 0: instruments crane operators cab Deadman switch continuous actuation or short circuit after Ubatt	A420		E	1
034042	ZE 0: instruments crane operators cab Key switch Monitor 2 cont. actuation or short circuit after Ubatt	A420		E	2
034043	ZE 0: instruments crane operators cab Foot button coasting slewing gear cont. actuation Output of error Turn coasting do not actuate - otherwise check switch and wiring for short circuit after VCC	A420		E	2
03433E	ZE 0: instruments armrest left Luffing in with susp. load cont. act. or short circuit after Ubatt	A420		E	1
035802	ZE 0: operation slewing Shut-down counterweight on ground Operation conditional switch off, may not be shunted If possible raise the wheels via lifting the load or reducing the mounted suspended counterweight	A420		B	
035803	ZE 0: operation slewing Shut-down support counterweight carriage is not retracted Operation conditional switch off, may not be shunted Retract support cylinder counterweight carriage completely	A420		B	
035804	ZE 0: operation slewing Shut-down wheels counterweight carriage not in rotary position Operation conditional switch off, may not be shunted With the pre-selection key "Rotary travel BW" turn the wheels of the counterweight carriage (BW) into turning position	A420		B	
035805	ZE 0: operation slewing Shut-down swing with parallel travel count. carriage not possible Operation conditional switch off, may not be shunted With the pre-selection key "Rotary travel BW" turn the wheels of the counterweight carriage (BW) into turning position	A420		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
035808	ZE 0: operation slewing shut-down slewing right working area limitation ABB operational shut down slew left until crane is in working area again - shunting through shut-down of working area limitation	A420		B	
035809	ZE 0: operation slewing shut-down slewing left working area limitation ABB operational shut down slew right until crane is in working area again - shunting through shut-down of working area limitation	A420		B	
035810	ZE 0: operation slewing Shut-down free swing gear working area limitation ABB is active operational shut down slew right until crane is in working area again - shunting through shut-down of working area limitation	A420		B	
035819	ZE 0: operation slewing no or invalid operation mode shut-down Operation conditional switch off, may not be shunted eliminate error see corresponding system error	A420		B	
035820	ZE 0: operation slewing shut-down slewing right LMB operational shut down slew left until crane is within support area again - shut-down can be shunted (danger)	A420		B	
035821	ZE 0: operation slewing shut-down slewing left LMB operational shut down slew right until crane is within support area again - shut-down can be shunted (danger)	A420		B	
035822	ZE 0: operation slewing Shut-down right-hand swing maximum load exceeded operational shut down Turn left until crane once again within the support area or reduce load - shut-down may be shunted (danger)	A420		B	
035823	ZE 0: operation slewing Shut-down left-hand swing maximum load exceeded operational shut down Turn right until crane once again within the support area or reduce load - shut-down may be shunted (danger)	A420		B	
035824	ZE 0: operation slewing Shut-down free swing gear swing area limitation load is on operational shut down Select load chart without swing area monitoring	A420		B	
035825	ZE 0: operation slewing Shut-off free-swing swing gear crane engine not functioning Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate foot switch.	A420		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
03582B	ZE 0: operation slewing Shut off Derrick ballast pulled > Derrick ballast max Operation conditional switch off, may not be shunted Fix cause of "LMB Stop", see error message	A420		B	
035831	ZE 0: operation slewing Master switch 2 faulty/not present Operation conditional switch off, may not be shunted eliminate error see corresponding system error	A420		B	
035839	ZE 0: operation slewing seat contact shut-down operational shut down Sit down or actuate one of the shunting switches for the seat contact in the master switches.	A420		B	
03583E	ZE 0: operation slewing Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A420		B	1
035844	ZE 0: operation slewing Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A420		B	
035854	ZE 0: operation slewing Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted Wind off main boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A420		B	
035855	ZE 0: operation slewing Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Wind off derrick boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A420		B	
03586E	ZE 0: operation slewing Brake slewing gear press switch faulty/missing or foot brake active Output of error, otherwise no reaction. Check function of brake press switch, do not actuate slewing gear foot brake.	A420		B	
035870	ZE 0: operation slewing Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035871	ZE 0: operation slewing Shut-down lim switch "Count. on ground" vo. right faulty/not presen Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
035872	ZE 0: operation slewing Shut-down lim switch "Count. on ground" hi. left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035873	ZE 0: operation slewing Shut-down lim switch "Count. on ground" hi. right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035874	ZE 0: operation slewing Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035875	ZE 0: operation slewing Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035885	ZE 0: operation slewing Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035886	ZE 0: operation slewing Shut-down limit switch "RFP Main boom" links faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035887	ZE 0: operation slewing Shut-down limit switch "Overtop guard cyl D" right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035888	ZE 0: operation slewing Shut-down limit switch "Overtop guard cyl D" left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A420		B	
035890	ZE 0: operation slewing Slewing platform not bolted or impermissible bolting condition report of error, otherwise no reaction Correct bolting position, check position ok: -supply, -input LICCON, -sensor line for short-circuit, -sensor	A420		B	1
0358B4	ZE 0: operation slewing Master switch left BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A420		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
0358BE	ZE 0: operation slewing Shut off upper limit shut off angle main boom (load chart) Operation conditional switch off, may not be shunted Spool main b. contr. winch out until no shut off present - shut off cannot be bypassed	A420		B	
036108	ZE 0: Operation ballasting / counterweight carriage Counterweight carriage (BW) is inserted but not yet bolted report of error, otherwise no reaction Bolt or unplug counterweight carriage.	A420		B	
036109	ZE 0: Operation ballasting / counterweight carriage BW is bolted but not inserted - dummy plug is inserted Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Unbolt or plug in counterweight carriage.	A420		B	
03610B	ZE 0: Operation ballasting / counterweight carriage BW is plugged but not yet pinned and support retracted Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Ballast trailer unpin, plug in or extend support.	A420		B	
036110	ZE 0: Operation ballasting / counterweight carriage No counterweight inserted or dummy plug not inserted report of error, otherwise no reaction Plug in dummy plug.	A420		B	
036111	ZE 0: Operation ballasting / counterweight carriage Counterweight carriage (BW) is bolted but not inserted Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Unbolt or plug in counterweight carriage.	A420		B	
036113	ZE 0: Operation ballasting / counterweight carriage Set B-table does not match the installed entries from B/BW Shut-down due to unclear recognition of assembly condition. Set load chart correctly or mount B/BW in accordance with the table setting.	A420		B	
036114	ZE 0: Operation ballasting / counterweight carriage Suspended counterweight (B) mounted but no B-table set Conversion to control operation type with suspended counterweight - requirements for operation with B must be met. Set load chart correctly or mount B/BW in accordance with the table setting.	A420		B	
036212	ZE 0: Operation crawler Shut off drive crawler - Op. mode parallel operation not active output of error, shut-down through application Activate op. mode parallel operation for driving crawler	A420		B	
036941	ZE 0: Operation crane control Emerg. op. crane control switched on Caution shut-down ineffective All crane functions can be operated unlimited - no switch-offs are any longer effective. Switch off emergency operation - Caution increased risk of accident	A420		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
036942	ZE 0: Operation crane control Emergency op. crane cont. switched on with start test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A420		B	1
036943	ZE 0: Operation crane control Emergency op. crane control switched on during test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A420		B	1
036948	ZE 0: Operation crane control Selection bypass hoist top - not possible - try again operational shut down Bypass is only permitted on limited basis and time controlled, possibly bypass can be reactivated	A420		B	2
036949	ZE 0: Operation crane control Selection bypass LMB - not possible - try again operational shut down Bypass is only permitted on limited basis and time controlled, possibly bypass can be reactivated	A420		B	2
03694A	ZE 0: Operation crane control Selection bypass LMB - not permissible for this utilization Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A420		B	2
03694E	ZE 0: Operation crane control Caution special function for reductions/ bypasses activated Special function as desired issue of op. error Change data word DWx.xxx or turn ignition off / on	A420		B	2
03694F	ZE 0: Operation crane control Caution, Activation EN13000 not possible EN 13000 is deactivated or cannot be activated, since option 85% chart is activated Activation of bypass acc. EN 13000 here not possible.	A420		B	2
03695B	ZE 0: Operation crane control Selection bypass hoist top not possible - no shut off Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A420		B	2
03695C	ZE 0: Operation crane control Selection this bypass not possible - sensor defect Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A420		B	2
03695F	ZE 0: Operation crane control Selection bypass not possible - crane engine still running	A420		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
036960	ZE 0: Operation crane control Selection bypass not possible - seat contact not actuated Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A420		B	2
036962	ZE 0: Operation crane control Selection bypass not possible - zero pos. force required Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A420		B	2
03704C	ZE 0: operation instruments crane operators cab Shut off crane control, preheat hydr. oil actuated Issuance of error at actuation of seat contact, no MS crane movement possible. Poss. additional occurrence Turn off hydraulic oil preheating, MS crane movements running again	A420		B	
037070	ZE 0: operation instruments crane operators cab Master switch 3X has no winch allocated - operation type Output of error, otherwise no reaction. If possible set another operation type.	A420		B	
037071	ZE 0: operation instruments crane operators cab Master switch 3Y has no winch allocated - operation type Output of error, otherwise no reaction. If possible set another operation type.	A420		B	
037072	ZE 0: operation instruments crane operators cab Master switch 3X has no winch allocated - crawler is on Output of error, otherwise no reaction. Switch of crawler travel operation.	A420		B	
037073	ZE 0: operation instruments crane operators cab Master switch 3Y has no winch allocated - crawler is on Output of error, otherwise no reaction. Switch of crawler travel operation.	A420		B	
037074	ZE 0: operation instruments crane operators cab Master switch 3Y has no winch allocated - winch 6 is on Winch 6 continues running until master switch 2Y is no longer defected. Do not modulate master switch 2Y any more.	A420		B	
037080	ZE 0: operation instruments crane operators cab Left-hand foot rocker switch - crawler travel gear is not On Output of error, otherwise no reaction. Switch on crawler travel operation.	A420		B	
037081	ZE 0: operation instruments crane operators cab Right-hand foot rocker switch - crawler travel gear is not On Output of error, otherwise no reaction. Switch on crawler travel operation.	A420		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
037082	ZE 0: operation instruments crane operators cab Master switch MS 3X is disengaged and winch 3 is not mounted Output of error Mount winch 3 or do not defect master switch any more	A420		B	
037083	ZE 0: operation instruments crane operators cab Master switch MS 3X is disengaged and winch 5 is not mounted Output of error Mount winch 5 or do not defect master switch any more	A420		B	
037084	ZE 0: operation instruments crane operators cab Master switch MS 3Y is disengaged and winch 4 is not mounted Output of error Mount winch 4 or do not defect master switch any more	A420		B	
037085	ZE 0: operation instruments crane operators cab Master switch MS 4Y is disengaged and crawler is not mounted Output of error Mount crawler or do not defect master switch any more	A420		B	
037086	ZE 0: operation instruments crane operators cab Master switch MS 5Y is disengaged and crawler is not mounted Output of error Mount crawler or do not defect master switch any more	A420		B	
03714C	ZE 0: operation instruments crane operators cab roof Shut off crane control, preheat hydr. oil actuated Issuance of error at actuation of seat contact, no MS crane movement possible. Poss. additional occurrence Turn off hydraulic oil preheating, MS crane movements running again	A420		B	
037260	ZE 0: operation instruments armrest right Change-over parallel op. On/Off - winches 1-2 with running winches Winches 1 and 2 running on in parallel or single operation, until master switch 1Y is no longer defected. Do not modulate master switch 1Y any more.	A420		B	
037268	ZE 0: operation instruments armrest right Imp oper: Selector switch W1/W2 parallel operation for radio assembly Output of error, the operating mode parallel operation winch 1 and 2 is not executed. Set the winch 1 and 2 selector switch to single operation for the operating mode radio assembly.	A420		B	
037270	ZE 0: operation instruments armrest right Master switch 1Y has no winch allocated - operation type Output of error, otherwise no reaction. If possible set another operation type.	A420		B	
037271	ZE 0: operation instruments armrest right Master switch 1X has no winch allocated - crawler is on Output of error, otherwise no reaction. Switch of crawler travel operation.	A420		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
037272	ZE 0: operation instruments armrest right Master switch 1X has no winch allocated - winch 6 is on Winch 6 continues running until master switch 2Y is no longer defected. Do not modulate master switch 2Y any more.	A420		B	
037280	ZE 0: operation instruments armrest right Master switch MS 1X is disengaged and winch 3 is not mounted Output of error Mount winch 3 or do not defect master switch any more	A420		B	
037281	ZE 0: operation instruments armrest right Master switch MS 1X is disengaged and winch 4 is not mounted Output of error Mount winch 4 or do not defect master switch any more	A420		B	
037282	ZE 0: operation instruments armrest right Master switch MS 1X is disengaged and winch 5 is not mounted Output of error Mount winch 5 or do not defect master switch any more	A420		B	
037283	ZE 0: operation instruments armrest right Master switch MS 1Y is disengaged and winch 1 is not mounted Output of error Winch 1 install or do not deflect master switch	A420		B	
037284	ZE 0: operation instruments armrest right Master switch MS 1Y is disengaged and winch 2 is not mounted Output of error Winch 2 install or do not deflect master switch	A420		B	
037361	ZE 0: operation instruments armrest left Change-over crawler on / off with running winches Winches continue running, until master switches 1X, 2Y, 3X, 3Y are no longer defected. D not modulate master switches 1X, 2Y, 3X, 3Y any more.	A420		B	
037362	ZE 0: operation instruments armrest left Change-over crawler on / off with running crawler Crawler continues travelling, until master switch 4Y and 5Y are no longer defected. Do not modulate master switches 4Y and 5Y any more.	A420		B	
037365	ZE 0: operation instruments armrest left Change over crawler at same time from diff. control points Output of error, otherwise no reaction. Turn selection switch for crawler cab off	A420		B	
037366	ZE 0: operation instruments armrest left Change over crawler actuate selector switch again Output of error, otherwise no reaction. Actuate selection switch for crawler again	A420		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
037373	ZE 0: operation instruments armrest left Master switch 2Y has no winch allocated - crawler is on Output of error, otherwise no reaction. Switch of crawler travel operation.	A420		B	
037374	ZE 0: operation instruments armrest left Master switch 2Y has no winch allocated - winch 4 is on Winch 4 continues running, until master switch 1X or 3Y is no longer defected. Do not modulate master switch 1X or 3Y any more.	A420		B	
037385	ZE 0: operation instruments armrest left Master switch MS 2Y is disengaged and winch 2 is not mounted Output of error Winch 2 install or do not deflect master switch	A420		B	
037386	ZE 0: operation instruments armrest left Master switch MS 2Y is disengaged and winch 5 is not mounted Output of error Mount winch 5 or do not defect master switch any more	A420		B	
037387	ZE 0: operation instruments armrest left Master switch MS 2Y is disengaged and winch 6 is not mounted Output of error Assemble winch 6 or do not deflect master switch	A420		B	
100001	ZE 1: system error OS-HC11 (observe parameters) initialising error processor-register erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A421		E	2
100002	ZE 1: system error OS-HC11 (observe parameters) initialising error test total in EPROM/FLASH erroneous no crane operation possible check program memory card or ZE	A421		E	2
100006	ZE 1: system error OS-HC11 (observe parameters) initialising error RAM erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A421		E	2
100007	ZE 1: system error OS-HC11 (observe parameters) UART erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A421		E	2
100010	ZE 1: system error OS-HC11 (observe parameters) system routine inaccessible entry in error memory, all crane movements will be stopped	A421		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
100011	ZE 1: system error OS-HC11 (observe parameters) ZE-watchdog expired entry in error memory, all crane movements will be stopped check ZE	A421		E	2
100012	ZE 1: system error OS-HC11 (observe parameters) type-identification in EPROM erroneous entry in error memory, no crane operation possible check program memory card	A421		E	2
100013	ZE 1: system error OS-HC11 (observe parameters) Test sum in FLASH erroneous entry in error memory, all crane movements will be stopped check program memory card	A421		E	2
100014	ZE 1: system error OS-HC11 (observe parameters) program already running entry in error memory, all crane movements will be stopped	A421		E	2
100015	ZE 1: system error OS-HC11 (observe parameters) program not available entry in error memory, all crane movements will be stopped	A421		E	2
100016	ZE 1: system error OS-HC11 (observe parameters) system-, driver-watchdog expired entry in error memory, all crane movements will be stopped	A421		E	2
100017	ZE 1: system error OS-HC11 (observe parameters) total of CPU-time distribution too great entry in error memory, all crane movements will be stopped	A421		E	2
100018	ZE 1: system error OS-HC11 (observe parameters) arithmetic overflow (16 Bit) entry in error memory, all crane movements will be stopped	A421		E	2
100019	ZE 1: system error OS-HC11 (observe parameters) division through zero (16 Bit) entry in error memory, all crane movements will be stopped	A421		E	2
100020	ZE 1: system error OS-HC11 (observe parameters) task-watchdog expired entry in error memory, all crane movements will be stopped	A421		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
100021	ZE 1: system error OS-HC11 (observe parameters) illegal opcode trap entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A421		E	2
100022	ZE 1: system error OS-HC11 (observe parameters) task inactive entry in error memory, all crane movements will be stopped	A421		E	2
100023	ZE 1: system error OS-HC11 (observe parameters) program incapable of running (type identification) entry in error memory, all crane movements will be stopped	A421		E	2
100024	ZE 1: system error OS-HC11 (observe parameters) task already used entry in error memory, all crane movements will be stopped	A421		E	2
100025	ZE 1: system error OS-HC11 (observe parameters) realtime-module already used entry in error memory, all crane movements will be stopped	A421		E	2
100026	ZE 1: system error OS-HC11 (observe parameters) regulator-module already used entry in error memory, all crane movements will be stopped	A421		E	2
100030	ZE 1: system error OS-HC11 (observe parameters) unacceptable bank address entry in error memory, all crane movements will be stopped	A421		E	2
100041	ZE 1: system error OS-HC11 (observe parameters) arithmetic error entry in error memory, all crane movements will be stopped	A421		E	2
100044	ZE 1: system error OS-HC11 (observe parameters) output parameter without effect, from inactive output entry in error memory, all crane movements will be stopped	A421		E	2
100045	ZE 1: system error OS-HC11 (observe parameters) entry parameter undefined, from inactive input entry in error memory, all crane movements will be stopped	A421		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
100046	ZE 1: system error OS-HC11 (observe parameters) impermissible regulator parameter entry in error memory, all crane movements will be stopped	A421		E	2
100047	ZE 1: system error OS-HC11 (observe parameters) realtime-control block not available entry in error memory, all crane movements will be stopped	A421		E	2
100048	ZE 1: system error OS-HC11 (observe parameters) realtime-control block inactive entry in error memory, all crane movements will be stopped	A421		E	2
100049	ZE 1: system error OS-HC11 (observe parameters) urgent modul, ZE not available entry in error memory, no crane operation possible check ZE	A421		E	2
100050	ZE 1: system error OS-HC11 (observe parameters) file not available entry in error memory, all crane movements will be stopped	A421		E	2
100051	ZE 1: system error OS-HC11 (observe parameters) file already opened entry in error memory, all crane movements will be stopped	A421		E	2
100052	ZE 1: system error OS-HC11 (observe parameters) file not open on close entry in error memory, all crane movements will be stopped	A421		E	2
100053	ZE 1: system error OS-HC11 (observe parameters) system mask not available entry in error memory, all crane movements will be stopped	A421		E	2
100054	ZE 1: system error OS-HC11 (observe parameters) system text not available entry in error memory, all crane movements will be stopped	A421		E	2
100055	ZE 1: system error OS-HC11 (observe parameters) symbol not available entry in error memory, all crane movements will be stopped	A421		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
100056	ZE 1: system error OS-HC11 (observe parameters) invalid mark in symbol entry in error memory, all crane movements will be stopped	A421		E	2
100057	ZE 1: system error OS-HC11 (observe parameters) default load chart missing entry in error memory, all crane movements will be stopped	A421		E	2
100058	ZE 1: system error OS-HC11 (observe parameters) amplifier erroneous or return power feed entry in error memory, all crane movements will be stopped check wiring	A421		E	2
100059	ZE 1: system error OS-HC11 (observe parameters) subroutine not reentrant entry in error memory, all crane movements will be stopped	A421		E	2
100060	ZE 1: system error OS-HC11 (observe parameters) transmission error SCI entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A421		E	2
100061	ZE 1: system error OS-HC11 (observe parameters) SCI-BREAK entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A421		E	2
100062	ZE 1: system error OS-HC11 (observe parameters) SCI not connected entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A421		E	2
100063	ZE 1: system error OS-HC11 (observe parameters) monitor error in operation entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A421		E	2
100065	ZE 1: system error OS-HC11 (observe parameters) impermissible bus address entry in error memory, all crane movements will be stopped	A421		E	2
100066	ZE 1: system error OS-HC11 (observe parameters) ADC working outside the permissible tolerance entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A421		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
100067	ZE 1: system error OS-HC11 (observe parameters) arithmetic processor not available entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A421		E	2
100068	ZE 1: system error OS-HC11 (observe parameters) impermissible interrupt entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A421		E	2
100070	ZE 1: system error OS-HC11 (observe parameters) various structure versions entry in error memory, no crane operation possible	A421		E	2
100071	ZE 1: system error OS-HC11 (observe parameters) Structure file missing or faulty entry in error memory, no crane operation possible	A421		E	2
100072	ZE 1: system error OS-HC11 (observe parameters) structure entry senseless entry in error memory, no crane operation possible	A421		E	2
100073	ZE 1: system error OS-HC11 (observe parameters) interpreter error entry in error memory, all crane movements will be stopped	A421		E	2
100074	ZE 1: system error OS-HC11 (observe parameters) transformation ASCII to BIN erroneous entry in error memory, all crane movements will be stopped	A421		E	2
100075	ZE 1: system error OS-HC11 (observe parameters) SPI-error entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A421		E	2
100076	ZE 1: system error OS-HC11 (observe parameters) incorrectly inserted power unit entry in error memory, all crane movements will be stopped check memory card in power supply unit	A421		E	2
100077	ZE 1: system error OS-HC11 (observe parameters) BAF-call-up erroneous entry in error memory, all crane movements will be stopped	A421		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
100078	ZE 1: system error OS-HC11 (observe parameters) impermissible parameter entry in error memory, all crane movements will be stopped	A421		E	2
100079	ZE 1: system error OS-HC11 (observe parameters) no right of access entry in error memory, all crane movements will be stopped	A421		E	2
100080	ZE 1: system error OS-HC11 (observe parameters) Fatal internal error entry in error memory, all crane movements will be stopped	A421		E	2
100081	ZE 1: system error OS-HC11 (observe parameters) stack overflow entry in error memory, all crane movements will be stopped	A421		E	2
100082	ZE 1: system error OS-HC11 (observe parameters) hardware-watchdog erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A421		E	2
100094	ZE 1: system error OS-HC11 (observe parameters) transmission error parallel bus entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A421		E	2
100095	ZE 1: system error OS-HC11 (observe parameters) DMA-error entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A421		E	2
100099	ZE 1: system error OS-HC11 (observe parameters) DSP0 erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A421		E	2
102001	ZE 1: system error OS-TMS initialising error processor-register erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A421		E	2
102002	ZE 1: system error OS-TMS initialising error test total in EPROM/FLASH erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A421		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
102006	ZE 1: system error OS-TMS initialising error RAM erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A421		E	2
102007	ZE 1: system error OS-TMS UART erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A421		E	2
102020	ZE 1: system error OS-TMS task-watchdog expired entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A421		E	2
102021	ZE 1: system error OS-TMS illegal opcode trap entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A421		E	2
102082	ZE 1: system error OS-TMS hardware-watchdog erroneous entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A421		E	2
110012	ZE 1: output 0 short circuit to ground	A421.X1:16		E	1
110013	ZE 1: output 0 open signal circuits	A421.X1:16		E	1
110014	ZE 1: output 0 short circuit to supply voltage	A421.X1:16		E	1
110054	ZE 1: output 0 short circuit to supply voltage	A421.X1:16		E	1
110058	ZE 1: output 0 positive switching transistor: disruption	A421.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
110070	ZE 1: output 0 measuring system defect no crane operation possible entry in error list	A421.X1:16		E	1
110071	ZE 1: output 0 short circuit to ground or transistor defect	A421.X1:16		E	1
110072	ZE 1: output 0 outside source feeding	A421.X1:16		E	1
110073	ZE 1: output 0 open circuit or short circuit to supply voltage/ground	A421.X1:16		E	1
110112	ZE 1: output 1 short circuit to ground	A421.X1:17		E	1
110113	ZE 1: output 1 open signal circuits	A421.X1:17		E	1
110114	ZE 1: output 1 short circuit to supply voltage	A421.X1:17		E	1
110154	ZE 1: output 1 short circuit to supply voltage	A421.X1:17		E	1
110158	ZE 1: output 1 positive switching transistor: disruption	A421.X1:17		E	1
110170	ZE 1: output 1 measuring system defect no crane operation possible entry in error list	A421.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
110171	ZE 1: output 1 short circuit to ground or transistor defect	A421.X1:17		E	1
110172	ZE 1: output 1 outside source feeding	A421.X1:17		E	1
110173	ZE 1: output 1 open circuit or short circuit to supply voltage/ground	A421.X1:17		E	1
110212	ZE 1: output 2 short circuit to ground	A421.X1:18		E	1
110213	ZE 1: output 2 open signal circuits	A421.X1:18		E	1
110214	ZE 1: output 2 short circuit to supply voltage	A421.X1:18		E	1
110254	ZE 1: output 2 short circuit to supply voltage	A421.X1:18		E	1
110258	ZE 1: output 2 positive switching transistor: disruption	A421.X1:18		E	1
110270	ZE 1: output 2 measuring system defect no crane operation possible entry in error list	A421.X1:18		E	1
110271	ZE 1: output 2 short circuit to ground or transistor defect	A421.X1:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
110272	ZE 1: output 2 outside source feeding	A421.X1:18		E	1
110273	ZE 1: output 2 open circuit or short circuit to supply voltage/ground	A421.X1:18		E	1
110312	ZE 1: output 3 short circuit to ground	A421.X1:19		E	1
110313	ZE 1: output 3 open signal circuits	A421.X1:19		E	1
110314	ZE 1: output 3 short circuit to supply voltage	A421.X1:19		E	1
110354	ZE 1: output 3 short circuit to supply voltage	A421.X1:19		E	1
110358	ZE 1: output 3 positive switching transistor: disruption	A421.X1:19		E	1
110360	ZE 1: output 3 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A421.X1:19		E	1
110362	ZE 1: output 3 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A421.X1:19		E	1
110363	ZE 1: output 3 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A421.X1:19		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
110370	ZE 1: output 3 measuring system defect no crane operation possible entry in error list	A421.X1:19		E	1
110371	ZE 1: output 3 short circuit to ground or transistor defect	A421.X1:19		E	1
110372	ZE 1: output 3 outside source feeding	A421.X1:19		E	1
110373	ZE 1: output 3 open circuit or short circuit to supply voltage/ground	A421.X1:19		E	1
110412	ZE 1: output 4 short circuit to ground	A421.X1:20		E	1
110413	ZE 1: output 4 open signal circuits	A421.X1:20		E	1
110414	ZE 1: output 4 short circuit to supply voltage	A421.X1:20		E	1
110454	ZE 1: output 4 short circuit to supply voltage	A421.X1:20		E	1
110458	ZE 1: output 4 positive switching transistor: disruption	A421.X1:20		E	1
110460	ZE 1: output 4 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A421.X1:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
110462	ZE 1: output 4 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A421.X1:20		E	1
110463	ZE 1: output 4 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A421.X1:20		E	1
110470	ZE 1: output 4 measuring system defect no crane operation possible entry in error list	A421.X1:20		E	1
110471	ZE 1: output 4 short circuit to ground or transistor defect	A421.X1:20		E	1
110472	ZE 1: output 4 outside source feeding	A421.X1:20		E	1
110473	ZE 1: output 4 open circuit or short circuit to supply voltage/ground	A421.X1:20		E	1
110512	ZE 1: output 5 short circuit to ground	A421.X1:21		E	1
110513	ZE 1: output 5 open signal circuits	A421.X1:21		E	1
110514	ZE 1: output 5 short circuit to supply voltage	A421.X1:21		E	1
110554	ZE 1: output 5 short circuit to supply voltage	A421.X1:21		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
110558	ZE 1: output 5 positive switching transistor: disruption	A421.X1:21		E	1
110570	ZE 1: output 5 measuring system defect no crane operation possible entry in error list	A421.X1:21		E	1
110571	ZE 1: output 5 short circuit to ground or transistor defect	A421.X1:21		E	1
110572	ZE 1: output 5 outside source feeding	A421.X1:21		E	1
110573	ZE 1: output 5 open circuit or short circuit to supply voltage/ground	A421.X1:21		E	1
110612	ZE 1: output 6 short circuit to ground	A421.X1:22		E	1
110613	ZE 1: output 6 open signal circuits	A421.X1:22		E	1
110614	ZE 1: output 6 short circuit to supply voltage	A421.X1:22		E	1
110654	ZE 1: output 6 short circuit to supply voltage	A421.X1:22		E	1
110658	ZE 1: output 6 positive switching transistor: disruption	A421.X1:22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
110670	ZE 1: output 6 measuring system defect no crane operation possible entry in error list	A421.X1:22		E	1
110671	ZE 1: output 6 short circuit to ground or transistor defect	A421.X1:22		E	1
110672	ZE 1: output 6 outside source feeding	A421.X1:22		E	1
110673	ZE 1: output 6 open circuit or short circuit to supply voltage/ground	A421.X1:22		E	1
110712	ZE 1: output 7 short circuit to ground	A421.X1:23		E	1
110713	ZE 1: output 7 open signal circuits	A421.X1:23		E	1
110714	ZE 1: output 7 short circuit to supply voltage	A421.X1:23		E	1
110754	ZE 1: output 7 short circuit to supply voltage	A421.X1:23		E	1
110758	ZE 1: output 7 positive switching transistor: disruption	A421.X1:23		E	1
110770	ZE 1: output 7 measuring system defect no crane operation possible entry in error list	A421.X1:23		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
110771	ZE 1: output 7 short circuit to ground or transistor defect	A421.X1:23		E	1
110772	ZE 1: output 7 outside source feeding	A421.X1:23		E	1
110773	ZE 1: output 7 open circuit or short circuit to supply voltage/ground	A421.X1:23		E	1
114959	ZE 1: all output supply voltage missing	A421		E	1
115059	ZE 1: output group 0 supply voltage missing	A421.X1:12		E	1
115159	ZE 1: output group 1 supply voltage missing	A421.X1:24		E	1
115259	ZE 1: output group 2 supply voltage missing	A421		E	1
115359	ZE 1: output group 3 supply voltage missing	A421		E	1
120004	ZE 1: LSB participant address 0 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
120005	ZE 1: LSB participant address 0 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
120018	ZE 1: LSB participant address 0 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
120050	ZE 1: LSB participant address 0 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
120051	ZE 1: LSB participant address 0 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
120053	ZE 1: LSB participant address 0 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
120054	ZE 1: LSB participant address 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
120064	ZE 1: LSB participant address 0 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
120065	ZE 1: LSB participant address 0 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
120066	ZE 1: LSB participant address 0 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
120067	ZE 1: LSB participant address 0 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
120104	ZE 1: LSB participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
120105	ZE 1: LSB participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
120118	ZE 1: LSB participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
120150	ZE 1: LSB participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
120151	ZE 1: LSB participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
120153	ZE 1: LSB participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
120154	ZE 1: LSB participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
120164	ZE 1: LSB participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
120165	ZE 1: LSB participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
120166	ZE 1: LSB participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
120167	ZE 1: LSB participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
120404	ZE 1: LSB participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
120405	ZE 1: LSB participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
120418	ZE 1: LSB participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
120450	ZE 1: LSB participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
120451	ZE 1: LSB participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
120453	ZE 1: LSB participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
120454	ZE 1: LSB participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
120464	ZE 1: LSB participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
120465	ZE 1: LSB participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
120466	ZE 1: LSB participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
120467	ZE 1: LSB participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
120504	ZE 1: LSB participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
120505	ZE 1: LSB participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
120518	ZE 1: LSB participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
120550	ZE 1: LSB participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
120551	ZE 1: LSB participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
120553	ZE 1: LSB participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
120554	ZE 1: LSB participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
120564	ZE 1: LSB participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
120565	ZE 1: LSB participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
120566	ZE 1: LSB participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
120567	ZE 1: LSB participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
120704	ZE 1: LSB participant address 7 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
120705	ZE 1: LSB participant address 7 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
120718	ZE 1: LSB participant address 7 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
120750	ZE 1: LSB participant address 7 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
120751	ZE 1: LSB participant address 7 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
120753	ZE 1: LSB participant address 7 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
120754	ZE 1: LSB participant address 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
120764	ZE 1: LSB participant address 7 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
120765	ZE 1: LSB participant address 7 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
120766	ZE 1: LSB participant address 7 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
120767	ZE 1: LSB participant address 7 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
121004	ZE 1: LSB participant address 10 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
121005	ZE 1: LSB participant address 10 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
121018	ZE 1: LSB participant address 10 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
121050	ZE 1: LSB participant address 10 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
121051	ZE 1: LSB participant address 10 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
121053	ZE 1: LSB participant address 10 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
121054	ZE 1: LSB participant address 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121064	ZE 1: LSB participant address 10 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
121065	ZE 1: LSB participant address 10 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
121066	ZE 1: LSB participant address 10 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
121067	ZE 1: LSB participant address 10 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
121104	ZE 1: LSB participant address 11 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
121105	ZE 1: LSB participant address 11 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
121118	ZE 1: LSB participant address 11 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
121150	ZE 1: LSB participant address 11 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
121151	ZE 1: LSB participant address 11 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
121153	ZE 1: LSB participant address 11 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121154	ZE 1: LSB participant address 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
121164	ZE 1: LSB participant address 11 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
121165	ZE 1: LSB participant address 11 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
121166	ZE 1: LSB participant address 11 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
121167	ZE 1: LSB participant address 11 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
121204	ZE 1: LSB participant address 12 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
121205	ZE 1: LSB participant address 12 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
121218	ZE 1: LSB participant address 12 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
121250	ZE 1: LSB participant address 12 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
121251	ZE 1: LSB participant address 12 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121253	ZE 1: LSB participant address 12 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
121254	ZE 1: LSB participant address 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
121264	ZE 1: LSB participant address 12 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
121265	ZE 1: LSB participant address 12 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
121266	ZE 1: LSB participant address 12 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
121267	ZE 1: LSB participant address 12 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
121304	ZE 1: LSB participant address 13 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
121305	ZE 1: LSB participant address 13 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
121318	ZE 1: LSB participant address 13 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
121350	ZE 1: LSB participant address 13 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121351	ZE 1: LSB participant address 13 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
121353	ZE 1: LSB participant address 13 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
121354	ZE 1: LSB participant address 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
121364	ZE 1: LSB participant address 13 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
121365	ZE 1: LSB participant address 13 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
121366	ZE 1: LSB participant address 13 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
121367	ZE 1: LSB participant address 13 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
121404	ZE 1: LSB participant address 14 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
121405	ZE 1: LSB participant address 14 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
121418	ZE 1: LSB participant address 14 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121450	ZE 1: LSB participant address 14 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
121451	ZE 1: LSB participant address 14 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
121453	ZE 1: LSB participant address 14 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
121454	ZE 1: LSB participant address 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
121464	ZE 1: LSB participant address 14 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
121465	ZE 1: LSB participant address 14 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
121466	ZE 1: LSB participant address 14 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
121467	ZE 1: LSB participant address 14 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
121504	ZE 1: LSB participant address 15 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
121505	ZE 1: LSB participant address 15 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121518	ZE 1: LSB participant address 15 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
121550	ZE 1: LSB participant address 15 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
121551	ZE 1: LSB participant address 15 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
121553	ZE 1: LSB participant address 15 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
121554	ZE 1: LSB participant address 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
121564	ZE 1: LSB participant address 15 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
121565	ZE 1: LSB participant address 15 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
121566	ZE 1: LSB participant address 15 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
121567	ZE 1: LSB participant address 15 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
121604	ZE 1: LSB participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121605	ZE 1: LSB participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
121618	ZE 1: LSB participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
121650	ZE 1: LSB participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
121651	ZE 1: LSB participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
121653	ZE 1: LSB participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
121654	ZE 1: LSB participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
121664	ZE 1: LSB participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
121665	ZE 1: LSB participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
121666	ZE 1: LSB participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
121667	ZE 1: LSB participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121804	ZE 1: LSB participant address 18 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
121805	ZE 1: LSB participant address 18 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
121818	ZE 1: LSB participant address 18 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
121850	ZE 1: LSB participant address 18 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
121851	ZE 1: LSB participant address 18 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
121853	ZE 1: LSB participant address 18 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
121854	ZE 1: LSB participant address 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
121864	ZE 1: LSB participant address 18 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
121865	ZE 1: LSB participant address 18 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2
121866	ZE 1: LSB participant address 18 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
121867	ZE 1: LSB participant address 18 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
122304	ZE 1: LSB participant address 23 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A421.X2:z14/z16		E	1
122305	ZE 1: LSB participant address 23 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A421.X2:z14/z16		E	1
122318	ZE 1: LSB participant address 23 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A421.X2:z14/z16		E	0
122350	ZE 1: LSB participant address 23 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A421.X2:z14/z16		E	2
122351	ZE 1: LSB participant address 23 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A421.X2:z14/z16		E	2
122353	ZE 1: LSB participant address 23 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A421.X2:z14/z16		E	1
122354	ZE 1: LSB participant address 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A421.X2:z14/z16		E	2
122364	ZE 1: LSB participant address 23 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A421.X2:z14/z16		E	1
122365	ZE 1: LSB participant address 23 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A421.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
122366	ZE 1: LSB participant address 23 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A421.X2:z14/z16		E	2
122367	ZE 1: LSB participant address 23 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A421.X2:z14/z16		E	1
123252	ZE 1: Control data transfer LSB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A421.X2:z14/z16		E	0
123255	ZE 1: Control data transfer LSB Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A421.X2:z14/z16		E	2
123256	ZE 1: Control data transfer LSB Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A421.X2:z14/z16		E	2
123257	ZE 1: Control data transfer LSB has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A421.X2:z14/z16		E	1
123258	ZE 1: Control data transfer LSB recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A421.X2:z14/z16		E	0
123259	ZE 1: Control data transfer LSB recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A421.X2:z14/z16		E	0
123260	ZE 1: Control data transfer LSB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A421.X2:z14/z16		E	2
123261	ZE 1: Control data transfer LSB driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A421.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
123262	ZE 1: Control data transfer LSB Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A421.X2:z14/z16		E	2
124814	ZE 1: input 0 short circuit to supply voltage Output of error Check: the sensor line for short-circuits, faulty sensors by pulling out the sensor, connections to the input plate	A421.X2:d2		E	1
124856	ZE 1: input 0 open circuit or short circuit to ground Output of error Check: Supply voltage, input LICCON, sensor lines for interruptions, faulty sensors by pulling out the sensor	A421.X2:d2		E	1
124914	ZE 1: input 1 short circuit to supply voltage Output of error Check: the sensor line for short-circuits, faulty sensors by pulling out the sensor, connections to the input plate	A421.X2:d4		E	1
124956	ZE 1: input 1 open circuit or short circuit to ground Output of error Check: Supply voltage, input LICCON, sensor lines for interruptions, faulty sensors by pulling out the sensor	A421.X2:d4		E	1
125814	ZE 1: input 10 short circuit to supply voltage report of error, shut-down through application Check sensor line for short-circuit, for faulty sensors by pulling out sensor, connection to input	A421.X2:d22		E	1
125856	ZE 1: input 10 open circuit or short circuit to ground report of error, shut-down through application Check supply voltage, input LICCON, sensor line for interruption, for faulty sensors by pulling out G	A421.X2:d22		E	1
126114	ZE 1: input 13 short circuit to supply voltage report of error, shut-down through application Check sensor line for short-circuit, for faulty sensors by pulling out sensor, connection to input	A421.X2:d28		E	1
126156	ZE 1: input 13 open circuit or short circuit to ground report of error, shut-down through application Check supply voltage, input LICCON, sensor line for interruption, for faulty sensors by pulling out G	A421.X2:d28		E	1
126214	ZE 1: input 14 short circuit to supply voltage report of error, shut-down through application Check sensor line for short-circuit, for faulty sensors by pulling out sensor, connection to input	A421.X2:d30		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
126256	ZE 1: input 14 open circuit or short circuit to ground report of error, shut-down through application Check supply voltage, input LICCON, sensor line for interruption, for faulty sensors by pulling out G	A421.X2:d30		E	1
126314	ZE 1: input 15 short circuit to supply voltage report of error, shut-down through application Check sensor line for short-circuit, for faulty sensors by pulling out sensor, connection to input	A421.X2:d32		E	1
126356	ZE 1: input 15 open circuit or short circuit to ground report of error, shut-down through application Check supply voltage, input LICCON, sensor line for interruption, for faulty sensors by pulling out G	A421.X2:d32		E	1
130008	ZE 1: LMB Winch 3 not adjusted, rope lengths-/range of lift display faulty Imprecise winch control and incorrect rope length display on this winch Readjust rope length display for this winch	A421		E	1
130009	ZE 1: LMB Winch 4 not adjusted, rope lengths-/range of lift display faulty Imprecise winch control and incorrect rope length display on this winch Readjust rope length display for this winch	A421		E	1
130010	ZE 1: LMB Winch 5 not adjusted, rope lengths-/range of lift display faulty Imprecise winch control and incorrect rope length display on this winch Readjust rope length display for this winch	A421		E	1
130011	ZE 1: LMB Winch 6 not adjusted, rope lengths-/range of lift display faulty Imprecise winch control and incorrect rope length display on this winch Readjust rope length display for this winch	A421		E	1
130017	ZE 1: LMB Pressure transducer overtop guard cyl derrick faulty/not present error report only Check sensor and supply line, replace faulty sensor	A421		E	1
130018	ZE 1: LMB Measuring signal derrick implausible (moment to the rear) error report only Check meas. points 1,3,4,5, angle sensor derr, pressure transducer RFP derr, length indic derr count and replace if nec.	A421		B	1
130019	ZE 1: LMB Measuring signal derrick implausible (moment to the front) error report only Check meas. points 1,3,4,5, angle sensor derr, pressure transducer RFP derr, length indic derr count and replace if nec.	A421		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
130020	ZE 1: LMB B-guide frame not definitely bolted front or rear Derrick counterweight radius has poss. been calculated short for front bolting point, load will poss. be reduced Check dummy plug signals	A421		B	1
130021	ZE 1: LMB Derrick ballast input value outside of permissible area error report only Set correct value	A421		B	1
130022	ZE 1: LMB Derrick ballast input not possible, master switch disengaged error report only Put all master switches in zero position	A421		B	1
130065	ZE 1: LMB computation-bound program part will no longer run LMB-Stop: Load torque increasing movements cannot be affected on starting, the set-up equipment program key was pressed	A421		B	2
130126	ZE 1: LMB STOP, press. tran. count. R measuring point 4A faulty/not present Weighed derrick counterweight is imprecise and LMB-Stop: Load moment increased movements not operable Check sensor and supply line, replace faulty sensor	A421		E	2
130127	ZE 1: LMB STOP, press. tran. count. R measuring point 4B faulty/not present Weighed derrick counterweight is imprecise and LMB-Stop: Load moment increased movements not operable Check sensor and supply line, replace faulty sensor	A421		E	2
130128	ZE 1: LMB STOP, press. tran. count. K measuring point 5 faulty/not present Weighed derrick counterweight is imprecise and LMB-Stop: Load moment increased movements not operable Check sensor and supply line, replace faulty sensor	A421		E	2
130129	ZE 1: LMB STOP, length indicator derrick counterweight faulty/not present LMB-Stop: Load torque increasing movements cannot be affected Check sensor and supply line, replace faulty sensor	A421		E	2
130158	ZE 1: LMB Derrick ballast, weighing and entry implausible LMB-Stop: Load torque increasing movements cannot be affected Check derrick counterweight input value, check sensor for derrick counterweight weighing + length indicator	A421		B	2
130159	ZE 1: LMB Derrick angle not in permissible derrick angle window LMB-Stop: Load torque increasing movements cannot be affected Luff derrick into permissible angle area	A421		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
130183	ZE 1: LMB STOP, Difference between derrick ballast force A/B too great LMB-Stop: Load torque increasing movements cannot be affected Load both derrick counterweight tensioners evenly	A421		B	2
130241	ZE 1: LMB STOP, overflow with calculation LMB-Stop: Load torque increasing movements cannot be affected Check sensor values, manual adjustments and actual crane condition, if necessary inform after-sales-service	A421		B	3
130245	ZE 1: LMB STOP, internal memory error/program part implausible LMB-Stop: Load torque increasing movements cannot be affected Read error report/display in LICCON test system special diagram "LMB - ERRORS", inform after-sales service	A421		E	3
130610	ZE 1: Data recorder Start: (still) no valid crane number entered Inspect in 10 sec. cycles Write in coefficients incl. crane number in the NT in "CRANE COMMISSIONING " program (MO > AK)	A421		E	1
130611	ZE 1: Data recorder Start: Crane number faulty (not 9 figures numerically) Data recorder software stops - no documentation possible! Define crane number correctly (Sxxxxxx.yyQ - KNFtt00vrr.Q)	A421		E	1
130612	ZE 1: Data recorder Start: not connected Data recorder software stops - no documentation possible! Connect data logger correctly	A421		E	1
130620	ZE 1: Data recorder Init: Firmware version incorrect/faulty Has not yet been checked!	A421		E	1
130621	ZE 1: Data recorder Init: ATA-card not initialised STATUS-error: Data recorder software stops - no documentation possible! Initialise ATA card with PC-Software "LICCON Manager"	A421		E	1
130622	ZE 1: Data recorder Init: ATA-card contains different crane number STATUS-error: Data recorder software stops - no documentation possible! Use ATA card with correct crane number or newly initialised ATA card	A421		E	1
130623	ZE 1: Data recorder Init: Format-File-Transfer faulty Repeat of Format-File transfers in 1 sec. cycles If necessary correct types and country specific Format-File "Lnnttt01vrr.Q" in EPROM 0	A421		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
130630	ZE 1: Data recorder Transfer: Data transmission faulty Repeat of data transfers in 1 sec. cycles If necessary check connection from LICCON system to data recorder	A421		E	1
130631	ZE 1: Data recorder Transfer: CSM-protocol error Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A421		E	1
130632	ZE 1: Data recorder Transfer: Transmission error (CRC) Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A421		E	1
130633	ZE 1: Data recorder Transfer: STATUS-error Dependent upon STATUS in 1 sec. cycles synchronise anew or stop data recorder software If necessary check connection from LICCON system to data recorder	A421		E	1
130634	ZE 1: Data recorder Transfer: TAN-error Synchronise CSM protocol again completely If necessary check connection from LICCON system to data recorder	A421		E	1
130635	ZE 1: Data recorder Transfer: Writing error Synchronise CSM protocol again completely If necessary check connection from LICCON-System to data recorder and ATA card	A421		E	1
130636	ZE 1: Data recorder Transfer: No recorder data (SPS-Handshake) LICCON-data logger software tries again in 1 sec. cycle Check function of SPS software	A421		E	1
136900	ZE 1: Operation crane control Shut-down assembly cylinder without or with invalid operation type Output of error, shut-down via application. Set correct operation type or disassemble accessory part - shut-down may not be shunted.	A421		B	
136901	ZE 1: Operation crane control Shut-down assembly cylinder master switch 2 faulty / not present Output of error, shut-down via application. Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A421		B	
136903	ZE 1: Operation crane control Shut-off assembly cylinder seating contact	A421		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
13693E	ZE 1: Operation crane control Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A421		B	
136942	ZE 1: Operation crane control Emergency op. crane cont. switched on with start test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A421		B	1
136943	ZE 1: Operation crane control Emergency op. crane control switched on during test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A421		B	1
136944	ZE 1: Operation crane control Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A421		B	
136980	ZE 1: Operation crane control Carry out engine stop w. button, replen. pr. switch no pressure missin Issue of op. error, error display for repl. Pr. switch cont. actuation or short circuit VCC is suppressed Follow instr., turn engine off via engine STOP button or if ign. On, wait until LICCON runs	A421		B	2
1369B4	ZE 1: Operation crane control Master switch left BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A421		B	
137020	ZE 1: operation instruments crane operators cab Shut off buttons assembly winch lift / lower actuate at the same time Output of error, crane function is not selected. Release one of the keys or check the switch and the cabling.	A421		B	
137021	ZE 1: operation instruments crane operators cab Shut off button lift assembly winch stuck or actuated at start Output of error, crane function is not selected. Release "lift" assembly winch key and check key and its wiring for proper function.	A421		B	
137022	ZE 1: operation instruments crane operators cab Shut off button assembly winch down stuck or actuated at start Output of error, crane function is not selected. Release "lower" assembly winch key and check key and its wiring for proper function.	A421		B	
137023	ZE 1: operation instruments crane operators cab Shut-off keys/inputs assembly winch not plausible Output of error, crane function is not selected. Release "lift" or "lower" assembly winch key and check keys and their wiring for proper function.	A421		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
161001	E/A-Modul 1: system error OS-C167 initialising error processor-register erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A11		E	2
161002	E/A-Modul 1: system error OS-C167 initialising error test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A11		E	2
161006	E/A-Modul 1: system error OS-C167 initialising error RAM erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A11		E	2
161013	E/A-Modul 1: system error OS-C167 test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A11		E	2
161016	E/A-Modul 1: system error OS-C167 system-, driver-watchdog expired error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A11		E	2
161068	E/A-Modul 1: system error OS-C167 impermissible interrupt error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A11		E	2
161071	E/A-Modul 1: system error OS-C167 Invalid configuration or Firmware error indication on display re-load Software from ZE	A11		E	2
161080	E/A-Modul 1: system error OS-C167 fatal internal software error error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A11		E	2
161082	E/A-Modul 1: system error OS-C167 hardware-watchdog erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A11		E	2
161088	E/A-Modul 1: system error OS-C167 Configuration does not match software condition error indication on display Comparison SW-condition EAM-SW and configuration LICCON different, check LICCON-configuration, download EAM	A11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
161089	E/A-Modul 1: system error OS-C167 Incorrect version of firmware installed Error output, possible error functions of module Replace module, reload firmware	A11		E	1
161090	E/A-Modul 1: system error OS-C167 Incorrect hardware version recognised Error output, possible error functions of module Replace module	A11		E	1
172052	E/A-Modul 1: input/output DEA0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:17		E	1
172053	E/A-Modul 1: input/output DEA0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:17		E	1
172054	E/A-Modul 1: input/output DEA0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:17		E	1
172055	E/A-Modul 1: input/output DEA0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:17		E	1
172152	E/A-Modul 1: input/output DEA1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:15		E	1
172153	E/A-Modul 1: input/output DEA1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:15		E	1
172154	E/A-Modul 1: input/output DEA1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:15		E	1
172155	E/A-Modul 1: input/output DEA1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
172252	E/A-Modul 1: input/output DEA2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:13		E	1
172253	E/A-Modul 1: input/output DEA2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:13		E	1
172254	E/A-Modul 1: input/output DEA2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:13		E	1
172255	E/A-Modul 1: input/output DEA2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:13		E	1
172352	E/A-Modul 1: input/output DEA3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:11		E	1
172353	E/A-Modul 1: input/output DEA3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:11		E	1
172354	E/A-Modul 1: input/output DEA3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:11		E	1
172355	E/A-Modul 1: input/output DEA3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:11		E	1
172452	E/A-Modul 1: input/output DEA4 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:9		E	1
172453	E/A-Modul 1: input/output DEA4 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
172454	E/A-Modul 1: input/output DEA4 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:9		E	1
172455	E/A-Modul 1: input/output DEA4 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:9		E	1
172552	E/A-Modul 1: input/output DEA5 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:7		E	1
172553	E/A-Modul 1: input/output DEA5 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:7		E	1
172554	E/A-Modul 1: input/output DEA5 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:7		E	1
172555	E/A-Modul 1: input/output DEA5 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:7		E	1
172652	E/A-Modul 1: input/output DEA6 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:5		E	1
172653	E/A-Modul 1: input/output DEA6 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:5		E	1
172654	E/A-Modul 1: input/output DEA6 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:5		E	1
172655	E/A-Modul 1: input/output DEA6 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
172752	E/A-Modul 1: input/output DEA7 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:3		E	1
172753	E/A-Modul 1: input/output DEA7 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:3		E	1
172754	E/A-Modul 1: input/output DEA7 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:3		E	1
172755	E/A-Modul 1: input/output DEA7 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:3		E	1
173681	E/A-Modul 1: voltage input E6 short circuit to supply voltage, open line symbol for brake pressure 1 is flashing on the display unit check input signal on the E/A-Modul or sensor	A11.X2:5		E	1
173781	E/A-Modul 1: voltage input E7 short circuit to supply voltage, open line symbol for brake pressure 2 is flashing on the display unit check input signal on the E/A-Modul or sensor	A11.X2:3		E	1
173782	E/A-Modul 1: voltage input E7 short circuit to ground, open line, constant current 10 mA incorrect no reaction check input signal on the E/A-Modul or sensor	A11.X2:3		E	1
173783	E/A-Modul 1: voltage input E7 short circuit to supply voltage, open line, lack of voltage no reaction check input signal on the E/A-Modul or sensor	A11.X2:3		E	1
179052	E/A-Modul 1: output A0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:18		E	1
179053	E/A-Modul 1: output A0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
179054	E/A-Modul 1: output A0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:18		E	1
179055	E/A-Modul 1: output A0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:18		E	1
179152	E/A-Modul 1: output A1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:16		E	1
179153	E/A-Modul 1: output A1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:16		E	1
179154	E/A-Modul 1: output A1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:16		E	1
179155	E/A-Modul 1: output A1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:16		E	1
179250	E/A-Modul 1: bridge output A2 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A11.X3:14		E	1
179251	E/A-Modul 1: bridge output A2 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A11.X3:14		E	1
179252	E/A-Modul 1: bridge output A2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:14		E	1
179253	E/A-Modul 1: bridge output A2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
179254	E/A-Modul 1: bridge output A2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:14		E	1
179255	E/A-Modul 1: bridge output A2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:14		E	1
179350	E/A-Modul 1: bridge output A3 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A11.X3:12		E	1
179351	E/A-Modul 1: bridge output A3 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A11.X3:12		E	1
179352	E/A-Modul 1: bridge output A3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A11.X3:12		E	1
179353	E/A-Modul 1: bridge output A3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A11.X3:12		E	1
179354	E/A-Modul 1: bridge output A3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A11.X3:12		E	1
179355	E/A-Modul 1: bridge output A3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A11.X3:12		E	1
183401	E/A-Modul 1: SPI-control unit Faulty data transfer E/A-module<->unit (time exceeded) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A11.X4:1/2/3/5/6/7/8		E	1
183402	E/A-Modul 1: SPI-control unit Serious system error to SPI-connection (interface) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A11.X4:1/2/3/5/6/7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
183403	E/A-Modul 1: SPI-control unit break in line or short circuit to supply voltage error indication on display remedy short circuit, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A11.X4:1/2/3/5/6/7/8		E	1
183404	E/A-Modul 1: SPI-control unit break in line or short circuit to ground error indication on display remedy short circuit, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A11.X4:1/2/3/5/6/7/8		E	1
183406	E/A-Modul 1: SPI-control unit Data transfer faulty (faulty check byte) error indication on display suppress EMV- interference	A11.X4:1/2/3/5/6/7/8		E	1
183407	E/A-Modul 1: SPI-control unit Unit faulty/missing, incorrect unit inserted (ID) error indication on display check periphery and replace if necessary, check Software version, check EMV- interference	A11.X4:1/2/3/5/6/7/8		E	1
183408	E/A-Modul 1: SPI-control unit Data transfer faulty (incorrect number of data bytes received) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A11.X4:1/2/3/5/6/7/8		E	1
183900	E/A-Modul 1: Control operating unit (SPI) Faulty initialisation data connection E/A-module<->unit error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A11.X4:1/2/3/5/6/7/8		E	1
183902	E/A-Modul 1: Control operating unit (SPI) Serious system error to SPI-connection (interface) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A11.X4:1/2/3/5/6/7/8		E	1
183905	E/A-Modul 1: Control operating unit (SPI) Initialisation error, resetting inputs/outputs faulty error indication on display check wiring, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A11.X4:1/2/3/5/6/7/8		E	1
183907	E/A-Modul 1: Control operating unit (SPI) Unit faulty/missing, incorrect unit inserted (ID) error indication on display connect functional periphery unit, system then eliminates error independently	A11.X4:1/2/3/5/6/7/8		E	1
183908	E/A-Modul 1: Control operating unit (SPI) Data transfer faulty (incorrect number of data bytes received) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A11.X4:1/2/3/5/6/7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
184104	E/A-Modul 1: LSB-B participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A11.X3:4/6		E	1
184105	E/A-Modul 1: LSB-B participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A11.X3:4/6		E	1
184118	E/A-Modul 1: LSB-B participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A11.X3:4/6		E	0
184150	E/A-Modul 1: LSB-B participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A11.X3:4/6		E	2
184151	E/A-Modul 1: LSB-B participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A11.X3:4/6		E	2
184153	E/A-Modul 1: LSB-B participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A11.X3:4/6		E	1
184154	E/A-Modul 1: LSB-B participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A11.X3:4/6		E	2
184164	E/A-Modul 1: LSB-B participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A11.X3:4/6		E	1
184165	E/A-Modul 1: LSB-B participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A11.X3:4/6		E	2
184166	E/A-Modul 1: LSB-B participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A11.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
184167	E/A-Modul 1: LSB-B participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A11.X3:4/6		E	1
184204	E/A-Modul 1: LSB-B participant address 2 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A11.X3:4/6		E	1
184205	E/A-Modul 1: LSB-B participant address 2 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A11.X3:4/6		E	1
184218	E/A-Modul 1: LSB-B participant address 2 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A11.X3:4/6		E	0
184250	E/A-Modul 1: LSB-B participant address 2 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A11.X3:4/6		E	2
184251	E/A-Modul 1: LSB-B participant address 2 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A11.X3:4/6		E	2
184253	E/A-Modul 1: LSB-B participant address 2 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A11.X3:4/6		E	1
184254	E/A-Modul 1: LSB-B participant address 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A11.X3:4/6		E	2
184264	E/A-Modul 1: LSB-B participant address 2 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A11.X3:4/6		E	1
184265	E/A-Modul 1: LSB-B participant address 2 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A11.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
184266	E/A-Modul 1: LSB-B participant address 2 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A11.X3:4/6		E	2
184267	E/A-Modul 1: LSB-B participant address 2 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A11.X3:4/6		E	1
184304	E/A-Modul 1: LSB-B participant address 3 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A11.X3:4/6		E	1
184305	E/A-Modul 1: LSB-B participant address 3 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A11.X3:4/6		E	1
184318	E/A-Modul 1: LSB-B participant address 3 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A11.X3:4/6		E	0
184350	E/A-Modul 1: LSB-B participant address 3 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A11.X3:4/6		E	2
184351	E/A-Modul 1: LSB-B participant address 3 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A11.X3:4/6		E	2
184353	E/A-Modul 1: LSB-B participant address 3 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A11.X3:4/6		E	1
184354	E/A-Modul 1: LSB-B participant address 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A11.X3:4/6		E	2
184364	E/A-Modul 1: LSB-B participant address 3 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A11.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
184365	E/A-Modul 1: LSB-B participant address 3 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A11.X3:4/6		E	2
184366	E/A-Modul 1: LSB-B participant address 3 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A11.X3:4/6		E	2
184367	E/A-Modul 1: LSB-B participant address 3 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A11.X3:4/6		E	1
184404	E/A-Modul 1: LSB-B participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A11.X3:4/6		E	1
184405	E/A-Modul 1: LSB-B participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A11.X3:4/6		E	1
184418	E/A-Modul 1: LSB-B participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A11.X3:4/6		E	0
184450	E/A-Modul 1: LSB-B participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A11.X3:4/6		E	2
184451	E/A-Modul 1: LSB-B participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A11.X3:4/6		E	2
184453	E/A-Modul 1: LSB-B participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A11.X3:4/6		E	1
184454	E/A-Modul 1: LSB-B participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A11.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
184464	E/A-Modul 1: LSB-B participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A11.X3:4/6		E	1
184465	E/A-Modul 1: LSB-B participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A11.X3:4/6		E	2
184466	E/A-Modul 1: LSB-B participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A11.X3:4/6		E	2
184467	E/A-Modul 1: LSB-B participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A11.X3:4/6		E	1
184504	E/A-Modul 1: LSB-B participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A11.X3:4/6		E	1
184505	E/A-Modul 1: LSB-B participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A11.X3:4/6		E	1
184518	E/A-Modul 1: LSB-B participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A11.X3:4/6		E	0
184550	E/A-Modul 1: LSB-B participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A11.X3:4/6		E	2
184551	E/A-Modul 1: LSB-B participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A11.X3:4/6		E	2
184553	E/A-Modul 1: LSB-B participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A11.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
184554	E/A-Modul 1: LSB-B participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A11.X3:4/6		E	2
184564	E/A-Modul 1: LSB-B participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A11.X3:4/6		E	1
184565	E/A-Modul 1: LSB-B participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A11.X3:4/6		E	2
184566	E/A-Modul 1: LSB-B participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A11.X3:4/6		E	2
184567	E/A-Modul 1: LSB-B participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A11.X3:4/6		E	1
184604	E/A-Modul 1: LSB-B participant address 6 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A11.X3:4/6		E	1
184605	E/A-Modul 1: LSB-B participant address 6 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A11.X3:4/6		E	1
184618	E/A-Modul 1: LSB-B participant address 6 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A11.X3:4/6		E	0
184650	E/A-Modul 1: LSB-B participant address 6 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A11.X3:4/6		E	2
184651	E/A-Modul 1: LSB-B participant address 6 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A11.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
184653	E/A-Modul 1: LSB-B participant address 6 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A11.X3:4/6		E	1
184654	E/A-Modul 1: LSB-B participant address 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A11.X3:4/6		E	2
184664	E/A-Modul 1: LSB-B participant address 6 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A11.X3:4/6		E	1
184665	E/A-Modul 1: LSB-B participant address 6 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A11.X3:4/6		E	2
184666	E/A-Modul 1: LSB-B participant address 6 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A11.X3:4/6		E	2
184667	E/A-Modul 1: LSB-B participant address 6 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A11.X3:4/6		E	1
185604	E/A-Modul 1: LSB-B participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A11.X3:4/6		E	1
185605	E/A-Modul 1: LSB-B participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A11.X3:4/6		E	1
185618	E/A-Modul 1: LSB-B participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A11.X3:4/6		E	0
185650	E/A-Modul 1: LSB-B participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A11.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
185651	E/A-Modul 1: LSB-B participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A11.X3:4/6		E	2
185653	E/A-Modul 1: LSB-B participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A11.X3:4/6		E	1
185654	E/A-Modul 1: LSB-B participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A11.X3:4/6		E	2
185664	E/A-Modul 1: LSB-B participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A11.X3:4/6		E	1
185665	E/A-Modul 1: LSB-B participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A11.X3:4/6		E	2
185666	E/A-Modul 1: LSB-B participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A11.X3:4/6		E	2
185667	E/A-Modul 1: LSB-B participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A11.X3:4/6		E	1
187252	E/A-Modul 1: Control data transfer LSB-B has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A11.X3:4/6		E	0
187255	E/A-Modul 1: Control data transfer LSB-B Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A11.X3:4/6		E	2
187256	E/A-Modul 1: Control data transfer LSB-B Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A11.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
187257	E/A-Modul 1: Control data transfer LSB-B has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A11.X3:4/6		E	1
187258	E/A-Modul 1: Control data transfer LSB-B recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A11.X3:4/6		E	0
187259	E/A-Modul 1: Control data transfer LSB-B recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A11.X3:4/6		E	0
187260	E/A-Modul 1: Control data transfer LSB-B driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A11.X3:4/6		E	2
187261	E/A-Modul 1: Control data transfer LSB-B driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A11.X3:4/6		E	2
187262	E/A-Modul 1: Control data transfer LSB-B Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A11.X3:4/6		E	2
187530	E/A-Modul 1: CAN-participant engine Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A11.X5:5/6		E	1
187531	E/A-Modul 1: CAN-participant engine Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A11.X5:5/6		E	1
187630	E/A-Modul 1: CAN-participant gear Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A11.X5:5/6		E	1
187631	E/A-Modul 1: CAN-participant gear Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A11.X5:5/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
187730	E/A-Modul 1: CAN-participant ABV (ABS/ASR) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A11.X5:5/6		E	1
187731	E/A-Modul 1: CAN-participant ABV (ABS/ASR) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A11.X5:5/6		E	1
187930	E/A-Modul 1: CAN-participant retarder Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A11.X5:5/6		E	1
187931	E/A-Modul 1: CAN-participant retarder Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A11.X5:5/6		E	1
188030	E/A-Modul 1: CAN-user converter clutch unit CCU Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A11.X5:5/6		E	1
188031	E/A-Modul 1: CAN-user converter clutch unit CCU Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A11.X5:5/6		E	1
188530	E/A-Modul 1: CAN-participant E/A-Modul 1 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A11.X5:5/6		E	1
188531	E/A-Modul 1: CAN-participant E/A-Modul 1 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A11.X5:5/6		E	1
188930	E/A-Modul 1: CAN-participant E/A-Modul 5 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A11.X5:5/6		E	1
188931	E/A-Modul 1: CAN-participant E/A-Modul 5 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A11.X5:5/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
189900	E/A-Modul 1: Control data transfer CAN internal error at Register-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A11.X5:5/6		E	2
189901	E/A-Modul 1: Control data transfer CAN internal error at RAM-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A11.X5:5/6		E	2
189902	E/A-Modul 1: Control data transfer CAN Configuration error Software internal error, CAN-transmission will be aborted replace E/A-Modul, check Software (test system ZE)	A11.X5:5/6		E	2
189903	E/A-Modul 1: Control data transfer CAN Transfer interrupted after continuous error CAN-Transmission will be aborted check bus lines/neutral point, replace neutral point or E/A-Modul	A11.X5:5/6		E	1
189910	E/A-Modul 1: Control data transfer CAN short-term error in bus connection re-attachment of Modul to bus transmission check bus lines/neutral point, unplug individual bus participant and check if error has been eliminated	A11.X5:5/6		E	1
189911	E/A-Modul 1: Control data transfer CAN permanent error bus connection cyclic re-attachment of Modul to bus transmission check bus lines/neutral point, unplug individual bus participant and check if error has been eliminated	A11.X5:5/6		E	1
189920	E/A-Modul 1: Control data transfer CAN active participant not responding parameterised substitute values for receiver signals will be used check error report for missing participant(s), test system ZE	A11.X5:5/6		E	1
189921	E/A-Modul 1: Control data transfer CAN No active subscriber responding parameterised substitute values for receiver signals will be used in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A11.X5:5/6		E	1
189950	E/A-Modul 1: Control data transfer CAN erroneous command test system no reaction to unknown test system control command in CAN-System Software check Software (test system)	A11.X5:5/6		E	1
192001	E/A-Modul 1: control engine long-term disruption E/A-Modul <-> engine control engine control and E/A-Modul at emergency speed engine control and E/A-Modul, check CAN-bus-connections	A11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
192110	E/A-Modul 1: control transmission long-term disruption shift selector operation unit <-> gears transmission control and E/A-Modul (operation unit) in emergency drive program check transmission control and E/A-Modul, CAN-bus-connection	A11		E	1
192111	E/A-Modul 1: control transmission long-term disruption shift selector crane op. cab<-> E/A-Modul no shifting possible	A11		B	
192112	E/A-Modul 1: control transmission long-term disruption connection E/A-Modul <-> operation unit transmission control and E/A-Modul (operation unit) in emergency drive program check connection E/A-Modul<->operation unit, power supplies operation unit; replace E/A- Modul or operation unit	A11		E	1
192113	E/A-Modul 1: control transmission error in shift selector keys operation unit: key sticking control system prevents engagement of a gear, check results exclusively after shifting on ignition in case key is activated release (error will be reset), check key or operation unit	A11		E	1
192114	E/A-Modul 1: control transmission shift selector operation unit: D key sticking control system prevents engagement of a gear, check results exclusively after shifting on ignition in case key is activated release (error will be reset), check key or operation unit	A11		E	1
192115	E/A-Modul 1: control transmission shift selector operation unit: N key sticking control system prevents engagement of a gear, check results exclusively after shifting on ignition in case key is activated release (error will be reset), check key or operation unit	A11		E	1
192116	E/A-Modul 1: control transmission shift selector operation unit: R key sticking control system prevents engagement of a gear, check results exclusively after shifting on ignition in case key is activated release (error will be reset), check key or operation unit	A11		E	1
192117	E/A-Modul 1: control transmission shift selector operation unit: gear+ key sticking control system prevents engagement of a gear, check results exclusively after shifting on ignition in case key is activated release (error will be reset), check key or operation unit	A11		E	1
192118	E/A-Modul 1: control transmission shift selector operation unit: gear- key sticking control system prevents engagement of a gear, check results exclusively after shifting on ignition in case key is activated release (error will be reset), check key or operation unit	A11		E	1
192119	E/A-Modul 1: control transmission shift selector operation unit: travel program key 1/2 sticking control system prevents engagement of a gear, check results exclusively after shifting on ignition in case key is activated release (error will be reset), check key or operation unit	A11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
192128	E/A-Modul 1: control transmission feedback of off-road gear simultaneously ON and OFF control system prevents disengagement of the off-road gear ON or OFF, remaining in actual position when ignition ON check sensor for acknowledgement(s), check line connections to the E/A-Modul, replace E/A-Modul	A11		E	1
193455	E/A-Modul 1: control lighting amperage indicator erroneous function is not carried out use original incandescent lamps, check indicator system for short to supply voltage	A11		E	1
193456	E/A-Modul 1: control lighting vehicle indicator defective function is not carried out check indicator system	A11		E	1
194051	E/A-Modul 1: Control active rear axle steering Error in program run Error report, value is zeroed E/A-module 1+3+4, LSB, check system-independent steering	A11		E	1
194052	E/A-Modul 1: Control active rear axle steering Checksum faulty Error report, value is zeroed E/A-module 1+3+4, LSB, check system-independent steering	A11		E	1
194081	E/A-Modul 1: Control active rear axle steering Return report steering status right faulty/missing Error report, value is zeroed E/A-module 1+3+4, LSB, check system-independent steering	A11		E	1
194082	E/A-Modul 1: Control active rear axle steering Return report steering status left faulty/missing Error report, value is zeroed E/A-module 1+3+4, LSB, check system-independent steering	A11		E	1
194083	E/A-Modul 1: Control active rear axle steering Return report steering status right/left implausible Error report, value is zeroed E/A-module 1+3+4, LSB, check system-independent steering	A11		E	1
194190	E/A-Modul 1: LSB-bus participant ZE missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A11		E	1
194192	E/A-Modul 1: LSB-bus participant E/A-Modul 2 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
194193	E/A-Modul 1: LSB-bus participant E/A-Modul 3 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A11		E	1
194194	E/A-Modul 1: LSB-bus participant E/A-Modul 4 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A11		E	1
194195	E/A-Modul 1: LSB-bus participant E/A-Modul 5 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A11		E	1
195010	E/A-Modul 1: operation engine Active DPF regeneration prevented, operating condition not OK Active regeneration prevented, conditions on crane not fulfilled	A11		B	
195011	E/A-Modul 1: operation engine Active DPF regeneration prevented, operating condition not OK Active regeneration prevented, conditions on crane not fulfilled	A11		B	
195012	E/A-Modul 1: operation engine Active DPF regeneration prevented by switch (inhibit) Active regeneration prevented by switch on crane or diagnostics tool	A11		B	
195013	E/A-Modul 1: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A11		B	
195014	E/A-Modul 1: operation engine Active DPF regeneration prevented, error in engine or AGN Active regeneration prevented, engine error condition	A11		B	
195015	E/A-Modul 1: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A11		B	
195016	E/A-Modul 1: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
195017	E/A-Modul 1: operation engine Active DPF regeneration prevented, error in temperature sensors Active regeneration prevented, engine error condition	A11		B	
195018	E/A-Modul 1: operation engine Active DPF regeneration not necessary, loading condition too low Active regeneration prevented/not necessary with current DPF load condition	A11		B	
195019	E/A-Modul 1: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A11		B	
19501A	E/A-Modul 1: operation engine Active DPF regeneration prevented, coolant temperature too low Active regeneration prevented, no release from engine	A11		B	
19501B	E/A-Modul 1: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A11		B	
19501C	E/A-Modul 1: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A11		B	
19501D	E/A-Modul 1: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A11		B	
19501E	E/A-Modul 1: operation engine Active DPF regeneration prevented, engine not idle Active regeneration prevented by current rpm or external specification	A11		B	
19501F	E/A-Modul 1: operation engine Active DPF regeneration prevented, external rpm request active Active regeneration prevented by current rpm or external specification	A11		B	
195040	E/A-Modul 1: operation engine Exhaust aftertreatment (AGN) cleaning proc active - speed increase Active regeneration prevented by current rpm or external specification	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
195041	E/A-Modul 1: operation engine Exhaust/engine temperatures very high - do not turn engine off! Active regeneration prevented by current rpm or external specification	A11		B	
195150	E/A-Modul 1: operation transmission gears in emergency shift selector operation function is not carried out	A11		B	
195151	E/A-Modul 1: operation transmission CAN-connection shift selector <-> gear electronics malfunctioning function is not carried out	A11		B	
195152	E/A-Modul 1: operation transmission connection shift selector <-> keyboard unit malfunctioning function is not carried out	A11		B	
195153	E/A-Modul 1: operation transmission pre-selection not neutral/crane op. cab malfunction <-> E/A-Modul function is not carried out	A11		B	
195154	E/A-Modul 1: operation transmission shift selector out of order: upper-carriage-operation mode function is not carried out	A11		B	
195161	E/A-Modul 1: operation transmission shift selector out of order: key sticking function is not carried out	A11		B	
195172	E/A-Modul 1: operation transmission selection of travel direction prevented, op. type not recognized function is not carried out	A11		B	
195173	E/A-Modul 1: operation transmission selection of travel dir. prevented, multi-shift selector keys activ. function is not carried out	A11		B	
195174	E/A-Modul 1: operation transmission shift selector out of order when engine OFF function is not carried out	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
195175	E/A-Modul 1: operation transmission selection of travel dir. prevented, pre-selection in neutral only function is not carried out	A11		B	
195176	E/A-Modul 1: operation transmission selection of travel direction prevented, operation brake not active function is not carried out	A11		B	
195177	E/A-Modul 1: operation transmission Selection of travel direction hindered, accelerator pedal actuated function is not carried out	A11		B	
195179	E/A-Modul 1: operation transmission pre-selection gear+ prevented, maximum gear attained function is not carried out	A11		B	
195180	E/A-Modul 1: operation transmission pre-selection gear+ prevented, rear axle not locked function is not carried out	A11		B	
195182	E/A-Modul 1: operation transmission pre-selection gear+/- prevented, gear in neutral function is not carried out	A11		B	
195183	E/A-Modul 1: operation transmission pre-selection gear- prevented, minimum gear attained function is not carried out	A11		B	
195184	E/A-Modul 1: operation transmission pre-selection gear+/- prevented, only possible in manual operation function is not carried out	A11		B	
195185	E/A-Modul 1: operation transmission pre-selection gear+/- prevented, both keys simultaneously activated function is not carried out	A11		B	
195191	E/A-Modul 1: operation transmission Change-over travel program only in D possible No change-over of travel program	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
195192	E/A-Modul 1: operation transmission Change-over ranging mode possible in gear area "Ranging" only No change-over in ranging mode	A11		B	
195196	E/A-Modul 1: operation transmission Compressed air deficiency switching Possibly no or limited number of switchings possible	A11		B	
195197	E/A-Modul 1: operation transmission Clutch is overloaded no shifting possible	A11		B	
195500	E/A-Modul 1: operation axle suspension function simultaneously ON and OFF function is not carried out do not simultaneously activate contrasting function keys	A11		B	
195501	E/A-Modul 1: operation axle suspension operation of 2-hand-function without activation of 2-hand-key function is not carried out activate both keys simultaneously or start test program of keyboard unit	A11		B	
195503	E/A-Modul 1: operation axle suspension operation from under-carriage without operation mode function is not carried out check entries (15UW, 15OW, 15UWOW) to E/A-Modul 2, check LSB-connection (see electric circuit diagram)	A11		B	
195505	E/A-Modul 1: operation axle suspension operation from under-carriage with upper-carriage operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A11		B	
195509	E/A-Modul 1: operation axle suspension unauthorised operation from under-carriage function is not carried out start engine and repeat operation	A11		B	
195570	E/A-Modul 1: operation axle suspension undefined condition: neither blocked nor with suspension function is not carried out check blocked limit switch and buffered limit switch	A11		B	
195571	E/A-Modul 1: operation axle suspension undefined condition: blocked and with suspension function is not carried out check blocked limit switch and buffered limit switch	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
195572	E/A-Modul 1: operation axle suspension function only possible on condition "axles with suspension" function is not carried out switch axle suspension to suspended and lower axle, then block axles 5+6 and level axle suspension	A11		B	
195573	E/A-Modul 1: operation axle suspension function only possible on condition "axles blocked" function is not carried out switch on axle blocking	A11		B	
195574	E/A-Modul 1: operation axle suspension unauthorised switch-over in condition "axles with suspension" function is not carried out lift blockage of function	A11		B	
195575	E/A-Modul 1: operation axle suspension unauthorised switch-over in condition "axles blocked" function is not carried out lift blockage of function	A11		B	
195601	E/A-Modul 1: operation level/filling/draining operation of 2-hand-function without activation of 2-hand-key function is not carried out activate both keys simultaneously or start test program of keyboard unit	A11		B	
195603	E/A-Modul 1: operation level/filling/draining operation from under-carriage without operation mode function is not carried out check entries (15UW, 15OW, 15UWOW) to E/A-Modul 2, check LSB-connection (see electric circuit diagram)	A11		B	
195605	E/A-Modul 1: operation level/filling/draining operation from under-carriage with upper-carriage operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A11		B	
195609	E/A-Modul 1: operation level/filling/draining unauthorised operation from under-carriage function is not carried out start engine and repeat operation	A11		B	
195625	E/A-Modul 1: operation level/filling/draining function with actual travel speed blocked function is not carried out Perform function while vehicle at standstill	A11		B	
195640	E/A-Modul 1: operation level/filling/draining level with blocked axle suspension function is not carried out switch axles to suspended condition	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
195641	E/A-Modul 1: operation level/filling/draining simultaneous filling and draining selected function is not carried out select either filling or draining	A11		B	
195642	E/A-Modul 1: operation level/filling/draining no individual operation when level function is active function is not carried out only activate level key	A11		B	
195643	E/A-Modul 1: operation level/filling/draining gears not in neutral function is not carried out switch transmission to neutral (N)	A11		B	
195701	E/A-Modul 1: operation axle compensation operation of 2-hand-function without activation of 2-hand-key function is not carried out	A11		B	
195707	E/A-Modul 1: operation axle compensation operation from under-carriage without initialisation function is not carried out	A11		B	
195709	E/A-Modul 1: operation axle compensation unauthorised operation from under-carriage function is not carried out	A11		B	
195747	E/A-Modul 1: operation axle compensation axle long. compensation switchable only if axle suspens. blocked function is not carried out	A11		B	
195901	E/A-Modul 1: operation longitudinal lock operation of 2-hand-function without activation of 2-hand-key function is not carried out activate both keys simultaneously or start test program of keyboard unit	A11		B	
195902	E/A-Modul 1: operation longitudinal lock operation from upper-carriage without operation mode function is not carried out check entries (15UW, 15OW, 15UWOW) to E/A-Modul 2, check LSB-connection (see electric circuit diagram)	A11		B	
195903	E/A-Modul 1: operation longitudinal lock operation from under-carriage without operation mode function is not carried out check entries (15UW, 15OW, 15UWOW) to E/A-Modul 2, check LSB-connection (see electric circuit diagram)	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
195904	E/A-Modul 1: operation longitudinal lock operation from upper-carriage with under-carriage operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to uppercarriage operation mode	A11		B	
195905	E/A-Modul 1: operation longitudinal lock operation from under-carriage with upper-carriage operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A11		B	
195906	E/A-Modul 1: operation longitudinal lock operation from upper-carriage without initialisation function is not carried out check voltage supply or LSB-connection to E/A-Modul 4	A11		B	
195907	E/A-Modul 1: operation longitudinal lock operation from under-carriage without initialisation function is not carried out check voltage supply or LSB-connection to E/A-Modul 4	A11		B	
195908	E/A-Modul 1: operation longitudinal lock unauthorised operation from upper-carriage function is not carried out start engine and repeat operation	A11		B	
195909	E/A-Modul 1: operation longitudinal lock unauthorised operation from under-carriage function is not carried out start engine and repeat operation	A11		B	
195925	E/A-Modul 1: operation longitudinal lock function with actual travel speed blocked function is not carried out check acknowledgement for off-road gear ON	A11		B	
195948	E/A-Modul 1: operation longitudinal lock rear longitudinal locks with no front longitudinal locks selected function is not carried out check acknowledgement for off-road gear ON	A11		B	
195950	E/A-Modul 1: operation longitudinal lock feedback of off-road gear ON missing function is not carried out check acknowledgement for off-road gear ON	A11		B	
195951	E/A-Modul 1: operation longitudinal lock off-road gear switched off function is not carried out switch on off-road gear	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
195953	E/A-Modul 1: operation longitudinal lock switch-over prevented as axles are raised function is not carried out switch on off-road gear	A11		B	
196001	E/A-Modul 1: operation transversal lock operation of 2-hand-function without activation of 2-hand-key function is not carried out activate both keys simultaneously or start test program of keyboard unit	A11		B	
196003	E/A-Modul 1: operation transversal lock operation from under-carriage without operation mode function is not carried out check entries (15UW, 15OW, 15UWOW) on E/A-Modul 4, check LSB-connection (see electric circuit diagram)	A11		B	
196005	E/A-Modul 1: operation transversal lock operation from under-carriage with upper-carriage operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A11		B	
196007	E/A-Modul 1: operation transversal lock operation from under-carriage without initialisation function is not carried out check voltage supply or LSB-connection to E/A-Modul 4	A11		B	
196009	E/A-Modul 1: operation transversal lock unauthorised operation from under-carriage function is not carried out start engine and repeat operation	A11		B	
196052	E/A-Modul 1: operation transversal lock selection of transversal lock ON with no longitudinal lock selected function is not carried out activate longitudinal locking	A11		B	
196837	E/A-Modul 1: operation instruments operators cab Cross incline larger 1 degree at high pressure and axles blocked	A11		B	
196838	E/A-Modul 1: operation instruments operators cab Maximum flexation at high pressure and axles blocked	A11		B	
197030	E/A-Modul 1: operation heating/air.conditioning switching on air-conditioning only possible with engine running function is not carried out start engine and repeat operation	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
197182	E/A-Modul 1: operation lighting indicator from upper-carriage in under-carriage operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to uppercarriage operation mode	A11		B	
197183	E/A-Modul 1: operation lighting indicator from under-carriage in upper-carriage operation mode function is not carried out switch off undercarriage indicator	A11		B	
197184	E/A-Modul 1: operation lighting simultaneous left and right indicator function is not carried out check steering column switch or wiring	A11		B	
197185	E/A-Modul 1: operation lighting hazard lights from upper-carriage and under-carriage function is not carried out switch off warning light	A11		B	
197186	E/A-Modul 1: operation lighting rear fog lamp only with light function is not carried out switch on full beam, dipped light or fog light	A11		B	
198001	E/A-Modul 1: Operation active rear axle steering 2-Hand-Function without actuation of 2-Hand-Key	A11		B	
198003	E/A-Modul 1: Operation active rear axle steering Prevents: no, or faulty operation type set	A11		B	
198007	E/A-Modul 1: Operation active rear axle steering Prevents: steering/operation type not initialised	A11		B	
198029	E/A-Modul 1: Operation active rear axle steering Change-over operat. type prevented:several keys actuated / key jamming	A11		B	
198032	E/A-Modul 1: Operation active rear axle steering Function prevented with set operation type	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
198033	E/A-Modul 1: Operation active rear axle steering Function prevented: Keyboard blocked in OW-operation	A11		B	
198034	E/A-Modul 1: Operation active rear axle steering Change-over operation type prevented: Operation type UW/OW lacking	A11		B	
198036	E/A-Modul 1: Operation active rear axle steering Operating mode at dolly operation not permissible	A11		B	
198037	E/A-Modul 1: Operation active rear axle steering Impermissible operating mode at high pressure	A11		B	
198038	E/A-Modul 1: Operation active rear axle steering Maximum steering angle at high pressure in op. mode crab walk	A11		B	
199890	E/A-Modul 1: operation diagnosis system test program not executable as engine is not OFF function is not carried out	A11		B	
199892	E/A-Modul 1: operation diagnosis system test program not executable as not in under-carriage op. mode function is not carried out	A11		B	
199895	E/A-Modul 1: operation diagnosis system start not possible as gears not in neutral function is not carried out	A11		B	
199909	E/A-Modul 1: operation optional device unauthorised operation from under-carriage function is not carried out start engine and repeat operation	A11		B	
199922	E/A-Modul 1: operation optional device function not available in under-carriage operation mode function is not carried out on customers request	A11		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
199924	E/A-Modul 1: operation optional device no customized function in under-carriage operation mode function is not carried out on customers request	A11		B	
1A0050	LSB-BSE1: LSBA Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0051	LSB-BSE1: LSBA Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0053	LSB-BSE1: LSBA Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0054	LSB-BSE1: LSBA Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0064	LSB-BSE1: LSBA Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0065	LSB-BSE1: LSBA Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0066	LSB-BSE1: LSBA Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0067	LSB-BSE1: LSBA Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0068	LSB-BSE1: LSBA Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0069	LSB-BSE1: LSBA Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0150	LSB-BSE1: LSBA Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0151	LSB-BSE1: LSBA Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0153	LSB-BSE1: LSBA Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0154	LSB-BSE1: LSBA Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0164	LSB-BSE1: LSBA Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0165	LSB-BSE1: LSBA Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0166	LSB-BSE1: LSBA Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0167	LSB-BSE1: LSBA Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0168	LSB-BSE1: LSBA Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0169	LSB-BSE1: LSBA Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0250	LSB-BSE1: LSBA Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0251	LSB-BSE1: LSBA Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0253	LSB-BSE1: LSBA Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0254	LSB-BSE1: LSBA Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0264	LSB-BSE1: LSBA Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0265	LSB-BSE1: LSBA Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0266	LSB-BSE1: LSBA Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0267	LSB-BSE1: LSBA Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0268	LSB-BSE1: LSBA Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0269	LSB-BSE1: LSBA Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0350	LSB-BSE1: LSBA Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0351	LSB-BSE1: LSBA Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0353	LSB-BSE1: LSBA Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0354	LSB-BSE1: LSBA Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0364	LSB-BSE1: LSBA Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0365	LSB-BSE1: LSBA Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0366	LSB-BSE1: LSBA Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0367	LSB-BSE1: LSBA Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0368	LSB-BSE1: LSBA Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0369	LSB-BSE1: LSBA Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0550	LSB-BSE1: LSBA Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0551	LSB-BSE1: LSBA Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0553	LSB-BSE1: LSBA Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0554	LSB-BSE1: LSBA Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0564	LSB-BSE1: LSBA Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0565	LSB-BSE1: LSBA Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0566	LSB-BSE1: LSBA Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0567	LSB-BSE1: LSBA Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0568	LSB-BSE1: LSBA Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0569	LSB-BSE1: LSBA Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0650	LSB-BSE1: LSBA Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0651	LSB-BSE1: LSBA Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0653	LSB-BSE1: LSBA Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0654	LSB-BSE1: LSBA Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0664	LSB-BSE1: LSBA Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0665	LSB-BSE1: LSBA Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0666	LSB-BSE1: LSBA Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0667	LSB-BSE1: LSBA Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0668	LSB-BSE1: LSBA Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0669	LSB-BSE1: LSBA Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0750	LSB-BSE1: LSBA Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0751	LSB-BSE1: LSBA Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0753	LSB-BSE1: LSBA Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0754	LSB-BSE1: LSBA Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0764	LSB-BSE1: LSBA Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0765	LSB-BSE1: LSBA Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0766	LSB-BSE1: LSBA Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0767	LSB-BSE1: LSBA Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0768	LSB-BSE1: LSBA Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0769	LSB-BSE1: LSBA Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0850	LSB-BSE1: LSBA Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0851	LSB-BSE1: LSBA Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0853	LSB-BSE1: LSBA Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0854	LSB-BSE1: LSBA Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0864	LSB-BSE1: LSBA Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0865	LSB-BSE1: LSBA Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0866	LSB-BSE1: LSBA Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0867	LSB-BSE1: LSBA Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0868	LSB-BSE1: LSBA Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0869	LSB-BSE1: LSBA Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0950	LSB-BSE1: LSBA Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0951	LSB-BSE1: LSBA Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0953	LSB-BSE1: LSBA Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0954	LSB-BSE1: LSBA Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0964	LSB-BSE1: LSBA Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0965	LSB-BSE1: LSBA Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0966	LSB-BSE1: LSBA Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0967	LSB-BSE1: LSBA Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0968	LSB-BSE1: LSBA Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0969	LSB-BSE1: LSBA Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0A50	LSB-BSE1: LSBA Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0A51	LSB-BSE1: LSBA Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0A53	LSB-BSE1: LSBA Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0A54	LSB-BSE1: LSBA Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0A64	LSB-BSE1: LSBA Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0A65	LSB-BSE1: LSBA Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0A66	LSB-BSE1: LSBA Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0A67	LSB-BSE1: LSBA Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0A68	LSB-BSE1: LSBA Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0A69	LSB-BSE1: LSBA Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0B50	LSB-BSE1: LSBA Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0B51	LSB-BSE1: LSBA Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0B53	LSB-BSE1: LSBA Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0B54	LSB-BSE1: LSBA Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0B64	LSB-BSE1: LSBA Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0B65	LSB-BSE1: LSBA Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0B66	LSB-BSE1: LSBA Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0B67	LSB-BSE1: LSBA Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0B68	LSB-BSE1: LSBA Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0B69	LSB-BSE1: LSBA Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0C50	LSB-BSE1: LSBA Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0C51	LSB-BSE1: LSBA Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0C53	LSB-BSE1: LSBA Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0C54	LSB-BSE1: LSBA Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0C64	LSB-BSE1: LSBA Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0C65	LSB-BSE1: LSBA Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0C66	LSB-BSE1: LSBA Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0C67	LSB-BSE1: LSBA Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0C68	LSB-BSE1: LSBA Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0C69	LSB-BSE1: LSBA Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0D50	LSB-BSE1: LSBA Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0D51	LSB-BSE1: LSBA Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0D53	LSB-BSE1: LSBA Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0D54	LSB-BSE1: LSBA Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0D64	LSB-BSE1: LSBA Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0D65	LSB-BSE1: LSBA Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0D66	LSB-BSE1: LSBA Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0D67	LSB-BSE1: LSBA Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0D68	LSB-BSE1: LSBA Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0D69	LSB-BSE1: LSBA Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0E50	LSB-BSE1: LSBA Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0E51	LSB-BSE1: LSBA Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0E53	LSB-BSE1: LSBA Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0E54	LSB-BSE1: LSBA Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0E64	LSB-BSE1: LSBA Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0E65	LSB-BSE1: LSBA Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0E66	LSB-BSE1: LSBA Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0E67	LSB-BSE1: LSBA Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0E68	LSB-BSE1: LSBA Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0E69	LSB-BSE1: LSBA Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0F50	LSB-BSE1: LSBA Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0F51	LSB-BSE1: LSBA Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0F53	LSB-BSE1: LSBA Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0F54	LSB-BSE1: LSBA Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0F64	LSB-BSE1: LSBA Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0F65	LSB-BSE1: LSBA Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0F66	LSB-BSE1: LSBA Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0F67	LSB-BSE1: LSBA Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0F68	LSB-BSE1: LSBA Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0F69	LSB-BSE1: LSBA Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1050	LSB-BSE1: LSBA Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1051	LSB-BSE1: LSBA Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1053	LSB-BSE1: LSBA Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1054	LSB-BSE1: LSBA Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1064	LSB-BSE1: LSBA Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1065	LSB-BSE1: LSBA Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1066	LSB-BSE1: LSBA Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1067	LSB-BSE1: LSBA Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1068	LSB-BSE1: LSBA Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1069	LSB-BSE1: LSBA Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1650	LSB-BSE1: LSBA Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1651	LSB-BSE1: LSBA Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1653	LSB-BSE1: LSBA Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1654	LSB-BSE1: LSBA Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1664	LSB-BSE1: LSBA Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1665	LSB-BSE1: LSBA Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1666	LSB-BSE1: LSBA Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1667	LSB-BSE1: LSBA Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1668	LSB-BSE1: LSBA Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1669	LSB-BSE1: LSBA Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1750	LSB-BSE1: LSBA Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1751	LSB-BSE1: LSBA Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1753	LSB-BSE1: LSBA Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1754	LSB-BSE1: LSBA Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1764	LSB-BSE1: LSBA Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1765	LSB-BSE1: LSBA Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1766	LSB-BSE1: LSBA Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1767	LSB-BSE1: LSBA Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1768	LSB-BSE1: LSBA Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1769	LSB-BSE1: LSBA Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1850	LSB-BSE1: LSBA Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1851	LSB-BSE1: LSBA Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1853	LSB-BSE1: LSBA Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1854	LSB-BSE1: LSBA Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1864	LSB-BSE1: LSBA Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1865	LSB-BSE1: LSBA Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1866	LSB-BSE1: LSBA Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1867	LSB-BSE1: LSBA Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1868	LSB-BSE1: LSBA Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1869	LSB-BSE1: LSBA Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1950	LSB-BSE1: LSBA Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1951	LSB-BSE1: LSBA Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1953	LSB-BSE1: LSBA Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1954	LSB-BSE1: LSBA Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1964	LSB-BSE1: LSBA Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1965	LSB-BSE1: LSBA Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1966	LSB-BSE1: LSBA Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1967	LSB-BSE1: LSBA Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1968	LSB-BSE1: LSBA Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1969	LSB-BSE1: LSBA Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1A50	LSB-BSE1: LSBA Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1A51	LSB-BSE1: LSBA Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1A53	LSB-BSE1: LSBA Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1A54	LSB-BSE1: LSBA Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1A64	LSB-BSE1: LSBA Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1A65	LSB-BSE1: LSBA Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1A66	LSB-BSE1: LSBA Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1A67	LSB-BSE1: LSBA Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1A68	LSB-BSE1: LSBA Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1A69	LSB-BSE1: LSBA Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1B50	LSB-BSE1: LSBA Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1B51	LSB-BSE1: LSBA Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1B53	LSB-BSE1: LSBA Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1B54	LSB-BSE1: LSBA Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1B64	LSB-BSE1: LSBA Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1B65	LSB-BSE1: LSBA Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1B66	LSB-BSE1: LSBA Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1B67	LSB-BSE1: LSBA Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1B68	LSB-BSE1: LSBA Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1B69	LSB-BSE1: LSBA Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1C50	LSB-BSE1: LSBA Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1C51	LSB-BSE1: LSBA Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1C53	LSB-BSE1: LSBA Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1C54	LSB-BSE1: LSBA Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1C64	LSB-BSE1: LSBA Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1C65	LSB-BSE1: LSBA Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1C66	LSB-BSE1: LSBA Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1C67	LSB-BSE1: LSBA Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1C68	LSB-BSE1: LSBA Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1C69	LSB-BSE1: LSBA Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1D50	LSB-BSE1: LSBA Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1D51	LSB-BSE1: LSBA Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1D53	LSB-BSE1: LSBA Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1D54	LSB-BSE1: LSBA Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1D64	LSB-BSE1: LSBA Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1D65	LSB-BSE1: LSBA Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1D66	LSB-BSE1: LSBA Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1D67	LSB-BSE1: LSBA Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1D68	LSB-BSE1: LSBA Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1D69	LSB-BSE1: LSBA Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1E50	LSB-BSE1: LSBA Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1E51	LSB-BSE1: LSBA Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1E53	LSB-BSE1: LSBA Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1E54	LSB-BSE1: LSBA Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1E64	LSB-BSE1: LSBA Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1E65	LSB-BSE1: LSBA Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1E66	LSB-BSE1: LSBA Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1E67	LSB-BSE1: LSBA Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1E68	LSB-BSE1: LSBA Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1E69	LSB-BSE1: LSBA Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A2052	LSB-BSE1: Control data transfer LSBA has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X4:9		E	0
1A2055	LSB-BSE1: Control data transfer LSBA Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:9		E	2
1A2056	LSB-BSE1: Control data transfer LSBA Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:9		E	2
1A2057	LSB-BSE1: Control data transfer LSBA has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X4:9		E	1
1A2058	LSB-BSE1: Control data transfer LSBA recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X4:9		E	0
1A2059	LSB-BSE1: Control data transfer LSBA recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X4:9		E	0
1A2060	LSB-BSE1: Control data transfer LSBA driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361.X4:9		E	2
1A2061	LSB-BSE1: Control data transfer LSBA driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361.X4:9		E	2
1A2062	LSB-BSE1: Control data transfer LSBA Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3050	LSB-BSE1: LSBB Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3051	LSB-BSE1: LSBB Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3053	LSB-BSE1: LSBB Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3054	LSB-BSE1: LSBB Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3064	LSB-BSE1: LSBB Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3065	LSB-BSE1: LSBB Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3066	LSB-BSE1: LSBB Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3067	LSB-BSE1: LSBB Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3068	LSB-BSE1: LSBB Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3069	LSB-BSE1: LSBB Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3250	LSB-BSE1: LSBB Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3251	LSB-BSE1: LSBB Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3253	LSB-BSE1: LSBB Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3254	LSB-BSE1: LSBB Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3264	LSB-BSE1: LSBB Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3265	LSB-BSE1: LSBB Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3266	LSB-BSE1: LSBB Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3267	LSB-BSE1: LSBB Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3268	LSB-BSE1: LSBB Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3269	LSB-BSE1: LSBB Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A5052	LSB-BSE1: Control data transfer LSBB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X4:10		E	0
1A5055	LSB-BSE1: Control data transfer LSBB Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:10		E	2
1A5056	LSB-BSE1: Control data transfer LSBB Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:10		E	2
1A5057	LSB-BSE1: Control data transfer LSBB has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X4:10		E	1
1A5058	LSB-BSE1: Control data transfer LSBB recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X4:10		E	0
1A5059	LSB-BSE1: Control data transfer LSBB recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X4:10		E	0
1A5060	LSB-BSE1: Control data transfer LSBB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361.X4:10		E	2
1A5061	LSB-BSE1: Control data transfer LSBB driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361.X4:10		E	2
1A5062	LSB-BSE1: Control data transfer LSBB Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X4:10		E	2
1A6050	LSB-BSE1: LSBC Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6051	LSB-BSE1: LSBC Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6053	LSB-BSE1: LSBC Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6054	LSB-BSE1: LSBC Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6064	LSB-BSE1: LSBC Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6065	LSB-BSE1: LSBC Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6066	LSB-BSE1: LSBC Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6067	LSB-BSE1: LSBC Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6068	LSB-BSE1: LSBC Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6069	LSB-BSE1: LSBC Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A6250	LSB-BSE1: LSBC Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6251	LSB-BSE1: LSBC Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6253	LSB-BSE1: LSBC Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6254	LSB-BSE1: LSBC Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6264	LSB-BSE1: LSBC Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6265	LSB-BSE1: LSBC Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6266	LSB-BSE1: LSBC Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6267	LSB-BSE1: LSBC Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6268	LSB-BSE1: LSBC Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6269	LSB-BSE1: LSBC Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A8052	LSB-BSE1: Control data transfer LSBC has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X4:11		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A8055	LSB-BSE1: Control data transfer LSBC Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:11		E	2
1A8056	LSB-BSE1: Control data transfer LSBC Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:11		E	2
1A8057	LSB-BSE1: Control data transfer LSBC has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X4:11		E	1
1A8058	LSB-BSE1: Control data transfer LSBC recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X4:11		E	0
1A8059	LSB-BSE1: Control data transfer LSBC recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X4:11		E	0
1A8060	LSB-BSE1: Control data transfer LSBC driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361.X4:11		E	2
1A8061	LSB-BSE1: Control data transfer LSBC driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361.X4:11		E	2
1A8062	LSB-BSE1: Control data transfer LSBC Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X4:11		E	2
1A9050	LSB-BSE1: LSB-D Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9051	LSB-BSE1: LSB-D Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9053	LSB-BSE1: LSB-D Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9054	LSB-BSE1: LSB-D Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9064	LSB-BSE1: LSB-D Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9065	LSB-BSE1: LSB-D Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9066	LSB-BSE1: LSB-D Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9067	LSB-BSE1: LSB-D Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9068	LSB-BSE1: LSB-D Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9069	LSB-BSE1: LSB-D Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A9250	LSB-BSE1: LSB-D Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9251	LSB-BSE1: LSB-D Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9253	LSB-BSE1: LSB-D Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9254	LSB-BSE1: LSB-D Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9264	LSB-BSE1: LSB-D Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9265	LSB-BSE1: LSB-D Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9266	LSB-BSE1: LSB-D Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9267	LSB-BSE1: LSB-D Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9268	LSB-BSE1: LSB-D Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9269	LSB-BSE1: LSB-D Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AB052	LSB-BSE1: Control data transfer LSB-D has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X4:12		E	0
1AB055	LSB-BSE1: Control data transfer LSB-D Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AB056	LSB-BSE1: Control data transfer LSB-D Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:12		E	2
1AB057	LSB-BSE1: Control data transfer LSB-D has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X4:12		E	1
1AB058	LSB-BSE1: Control data transfer LSB-D recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X4:12		E	0
1AB059	LSB-BSE1: Control data transfer LSB-D recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X4:12		E	0
1AB060	LSB-BSE1: Control data transfer LSB-D driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361.X4:12		E	2
1AB061	LSB-BSE1: Control data transfer LSB-D driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361.X4:12		E	2
1AB062	LSB-BSE1: Control data transfer LSB-D Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X4:12		E	2
1B0050	LSB-BSE1: LSBE Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0051	LSB-BSE1: LSBE Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B0053	LSB-BSE1: LSBE Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0054	LSB-BSE1: LSBE Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B0064	LSB-BSE1: LSBE Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0065	LSB-BSE1: LSBE Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B0066	LSB-BSE1: LSBE Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B0067	LSB-BSE1: LSBE Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0068	LSB-BSE1: LSBE Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B0069	LSB-BSE1: LSBE Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B0250	LSB-BSE1: LSBE Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0251	LSB-BSE1: LSBE Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B0253	LSB-BSE1: LSBE Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0254	LSB-BSE1: LSBE Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B0264	LSB-BSE1: LSBE Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0265	LSB-BSE1: LSBE Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B0266	LSB-BSE1: LSBE Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B0267	LSB-BSE1: LSBE Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0268	LSB-BSE1: LSBE Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B0269	LSB-BSE1: LSBE Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B2052	LSB-BSE1: Control data transfer LSBE has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X5:9		E	0
1B2055	LSB-BSE1: Control data transfer LSBE Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:9		E	2
1B2056	LSB-BSE1: Control data transfer LSBE Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B2057	LSB-BSE1: Control data transfer LSBE has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X5:9		E	1
1B2058	LSB-BSE1: Control data transfer LSBE recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X5:9		E	0
1B2059	LSB-BSE1: Control data transfer LSBE recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X5:9		E	0
1B2060	LSB-BSE1: Control data transfer LSBE driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361.X5:9		E	2
1B2061	LSB-BSE1: Control data transfer LSBE driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361.X5:9		E	2
1B2062	LSB-BSE1: Control data transfer LSBE Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X5:9		E	2
1B3050	LSB-BSE1: LSBF Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3051	LSB-BSE1: LSBF Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3053	LSB-BSE1: LSBF Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3054	LSB-BSE1: LSBF Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3064	LSB-BSE1: LSBF Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3065	LSB-BSE1: LSBF Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3066	LSB-BSE1: LSBF Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3067	LSB-BSE1: LSBF Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3068	LSB-BSE1: LSBF Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3069	LSB-BSE1: LSBF Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B3250	LSB-BSE1: LSBF Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3251	LSB-BSE1: LSBF Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3253	LSB-BSE1: LSBF Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3254	LSB-BSE1: LSBF Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3264	LSB-BSE1: LSBF Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3265	LSB-BSE1: LSBF Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3266	LSB-BSE1: LSBF Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3267	LSB-BSE1: LSBF Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3268	LSB-BSE1: LSBF Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3269	LSB-BSE1: LSBF Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B5052	LSB-BSE1: Control data transfer LSBF has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X5:10		E	0
1B5055	LSB-BSE1: Control data transfer LSBF Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:10		E	2
1B5056	LSB-BSE1: Control data transfer LSBF Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:10		E	2
1B5057	LSB-BSE1: Control data transfer LSBF has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B5058	LSB-BSE1: Control data transfer LSBF recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X5:10		E	0
1B5059	LSB-BSE1: Control data transfer LSBF recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X5:10		E	0
1B5060	LSB-BSE1: Control data transfer LSBF driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361.X5:10		E	2
1B5061	LSB-BSE1: Control data transfer LSBF driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361.X5:10		E	2
1B5062	LSB-BSE1: Control data transfer LSBF Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X5:10		E	2
1B6050	LSB-BSE1: LSBG Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6051	LSB-BSE1: LSBG Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6053	LSB-BSE1: LSBG Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6054	LSB-BSE1: LSBG Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6064	LSB-BSE1: LSBG Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6065	LSB-BSE1: LSBG Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6066	LSB-BSE1: LSBG Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6067	LSB-BSE1: LSBG Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6068	LSB-BSE1: LSBG Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6069	LSB-BSE1: LSBG Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B6250	LSB-BSE1: LSBG Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6251	LSB-BSE1: LSBG Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6253	LSB-BSE1: LSBG Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6254	LSB-BSE1: LSBG Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6264	LSB-BSE1: LSBG Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6265	LSB-BSE1: LSBG Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6266	LSB-BSE1: LSBG Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6267	LSB-BSE1: LSBG Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6268	LSB-BSE1: LSBG Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6269	LSB-BSE1: LSBG Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B8052	LSB-BSE1: Control data transfer LSBG has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X5:11		E	0
1B8055	LSB-BSE1: Control data transfer LSBG Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:11		E	2
1B8056	LSB-BSE1: Control data transfer LSBG Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:11		E	2
1B8057	LSB-BSE1: Control data transfer LSBG has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X5:11		E	1
1B8058	LSB-BSE1: Control data transfer LSBG recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X5:11		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B8059	LSB-BSE1: Control data transfer LSBG recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X5:11		E	0
1B8060	LSB-BSE1: Control data transfer LSBG driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361.X5:11		E	2
1B8061	LSB-BSE1: Control data transfer LSBG driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361.X5:11		E	2
1B8062	LSB-BSE1: Control data transfer LSBG Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X5:11		E	2
1B9050	LSB-BSE1: LSBH Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9051	LSB-BSE1: LSBH Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9053	LSB-BSE1: LSBH Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9054	LSB-BSE1: LSBH Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9064	LSB-BSE1: LSBH Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9065	LSB-BSE1: LSBH Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9066	LSB-BSE1: LSBH Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9067	LSB-BSE1: LSBH Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9068	LSB-BSE1: LSBH Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9069	LSB-BSE1: LSBH Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B9250	LSB-BSE1: LSBH Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9251	LSB-BSE1: LSBH Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9253	LSB-BSE1: LSBH Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9254	LSB-BSE1: LSBH Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9264	LSB-BSE1: LSBH Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9265	LSB-BSE1: LSBH Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9266	LSB-BSE1: LSBH Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9267	LSB-BSE1: LSBH Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9268	LSB-BSE1: LSBH Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9269	LSB-BSE1: LSBH Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BB052	LSB-BSE1: Control data transfer LSBH has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X5:12		E	0
1BB055	LSB-BSE1: Control data transfer LSBH Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:12		E	2
1BB056	LSB-BSE1: Control data transfer LSBH Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:12		E	2
1BB057	LSB-BSE1: Control data transfer LSBH has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X5:12		E	1
1BB058	LSB-BSE1: Control data transfer LSBH recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X5:12		E	0
1BB059	LSB-BSE1: Control data transfer LSBH recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X5:12		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BB060	LSB-BSE1: Control data transfer LSBH driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361.X5:12		E	2
1BB061	LSB-BSE1: Control data transfer LSBH driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361.X5:12		E	2
1BB062	LSB-BSE1: Control data transfer LSBH Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X5:12		E	2
1C0050	LSB-BSE1: LSBJ Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0051	LSB-BSE1: LSBJ Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0053	LSB-BSE1: LSBJ Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0054	LSB-BSE1: LSBJ Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0064	LSB-BSE1: LSBJ Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0065	LSB-BSE1: LSBJ Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0066	LSB-BSE1: LSBJ Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0067	LSB-BSE1: LSBJ Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0068	LSB-BSE1: LSBJ Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0069	LSB-BSE1: LSBJ Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C2052	LSB-BSE1: Control data transfer LSBJ has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361		E	0
1C2055	LSB-BSE1: Control data transfer LSBJ Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1C2056	LSB-BSE1: Control data transfer LSBJ Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1C2057	LSB-BSE1: Control data transfer LSBJ has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361		E	1
1C2058	LSB-BSE1: Control data transfer LSBJ recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361		E	0
1C2059	LSB-BSE1: Control data transfer LSBJ recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361		E	0
1C2060	LSB-BSE1: Control data transfer LSBJ driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C2061	LSB-BSE1: Control data transfer LSBJ driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361		E	2
1C2062	LSB-BSE1: Control data transfer LSBJ Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361		E	2
1C3050	LSB-BSE1: LSBK Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C3051	LSB-BSE1: LSBK Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C3053	LSB-BSE1: LSBK Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C3054	LSB-BSE1: LSBK Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C3064	LSB-BSE1: LSBK Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C3065	LSB-BSE1: LSBK Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C3066	LSB-BSE1: LSBK Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C3067	LSB-BSE1: LSBK Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C3068	LSB-BSE1: LSBK Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C3069	LSB-BSE1: LSBK Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C5052	LSB-BSE1: Control data transfer LSBK has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361		E	0
1C5055	LSB-BSE1: Control data transfer LSBK Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1C5056	LSB-BSE1: Control data transfer LSBK Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1C5057	LSB-BSE1: Control data transfer LSBK has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361		E	1
1C5058	LSB-BSE1: Control data transfer LSBK recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361		E	0
1C5059	LSB-BSE1: Control data transfer LSBK recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361		E	0
1C5060	LSB-BSE1: Control data transfer LSBK driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361		E	2
1C5061	LSB-BSE1: Control data transfer LSBK driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C5062	LSB-BSE1: Control data transfer LSBK Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361		E	2
1C6050	LSB-BSE1: LSBL Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C6051	LSB-BSE1: LSBL Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C6053	LSB-BSE1: LSBL Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C6054	LSB-BSE1: LSBL Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C6064	LSB-BSE1: LSBL Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C6065	LSB-BSE1: LSBL Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C6066	LSB-BSE1: LSBL Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C6067	LSB-BSE1: LSBL Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C6068	LSB-BSE1: LSBL Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C6069	LSB-BSE1: LSBL Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C8052	LSB-BSE1: Control data transfer LSBL has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361		E	0
1C8055	LSB-BSE1: Control data transfer LSBL Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1C8056	LSB-BSE1: Control data transfer LSBL Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1C8057	LSB-BSE1: Control data transfer LSBL has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361		E	1
1C8058	LSB-BSE1: Control data transfer LSBL recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361		E	0
1C8059	LSB-BSE1: Control data transfer LSBL recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361		E	0
1C8060	LSB-BSE1: Control data transfer LSBL driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361		E	2
1C8061	LSB-BSE1: Control data transfer LSBL driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361		E	2
1C8062	LSB-BSE1: Control data transfer LSBL Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C9050	LSB-BSE1: LSBM Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C9051	LSB-BSE1: LSBM Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C9053	LSB-BSE1: LSBM Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C9054	LSB-BSE1: LSBM Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C9064	LSB-BSE1: LSBM Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C9065	LSB-BSE1: LSBM Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C9066	LSB-BSE1: LSBM Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C9067	LSB-BSE1: LSBM Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C9068	LSB-BSE1: LSBM Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C9069	LSB-BSE1: LSBM Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1CB052	LSB-BSE1: Control data transfer LSBM has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361		E	0
1CB055	LSB-BSE1: Control data transfer LSBM Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1CB056	LSB-BSE1: Control data transfer LSBM Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1CB057	LSB-BSE1: Control data transfer LSBM has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361		E	1
1CB058	LSB-BSE1: Control data transfer LSBM recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361		E	0
1CB059	LSB-BSE1: Control data transfer LSBM recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361		E	0
1CB060	LSB-BSE1: Control data transfer LSBM driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant In case of temporary problems, the error is fixed by system. For incorrect configuration, new software required	A361		E	2
1CB061	LSB-BSE1: Control data transfer LSBM driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network In case of temp. problems, the error will be fixed by system, otherwise new software required to remedy the error	A361		E	2
1CB062	LSB-BSE1: Control data transfer LSBM Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361		E	2
1D009D	LSB-BSE1: LMB Angle sensor FA-frame def./missing, weighing poss. inaccurate Output of error, operation without sensor is possible. Check angle sensor, replace if necessary.	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D0612	LSB-BSE1: Data recorder Start: not connected No recording possible! Check data logger in 1 sec. interval Connect data logger, if necessary, check connection from LICCON system to data logger	A361		E	1
1D0620	LSB-BSE1: Data recorder Init: Firmware version incorrect/faulty Has not yet been checked!	A361		E	1
1D0621	LSB-BSE1: Data recorder Init: ATA-card not initialised STATUS-error: Data recorder software stops - no documentation possible! Initialize ATA-Card with PC-Software 'LICCON Manager'	A361		E	1
1D0622	LSB-BSE1: Data recorder Init: ATA-card contains different crane number STATUS-error: Data recorder software stops - no documentation possible! Use ATA card with correct crane number or newly initialised ATA card	A361		E	1
1D0623	LSB-BSE1: Data recorder Init: Format-File-Transfer faulty Repeat of Format-File transfers in 1 sec. cycles If necessary, correct type and country specific format file 'Lnnttt01vrrr.Q' in EPROM 0	A361		E	1
1D0630	LSB-BSE1: Data recorder Transfer: Data transmission faulty Repeat of data transfers in 1 sec. cycles If necessary check connection from LICCON system to data recorder	A361		E	1
1D0631	LSB-BSE1: Data recorder Transfer: CSM-protocol error Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A361		E	1
1D0632	LSB-BSE1: Data recorder Transfer: Transmission error (CRC) Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A361		E	1
1D0633	LSB-BSE1: Data recorder Transfer: STATUS-error Resynchronize depending on STATUS in 1 sec.interval If necessary check connection from LICCON system to data recorder	A361		E	1
1D0634	LSB-BSE1: Data recorder Transfer: TAN-error Synchronise CSM protocol again completely If necessary check connection from LICCON system to data recorder	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D0635	LSB-BSE1: Data recorder Transfer: Writing error Synchronise CSM protocol again completely If necessary check connection from LICCON-System to data recorder and ATA card	A361		E	1
1DD01E	LSB-BSE1: Supply voltage 15.3 / CPU0 Voltage outside permissible range error report Check voltage, electr. connections and fuse	A361.X1:1	O-248.A3	E	2
1DD11E	LSB-BSE1: Supply voltage 30.3 / CPU0 Voltage outside permissible range error report Check battery, electr. connections and fuse	A361.X1:2	O-248.A1	E	2
1DDE14	LSB-BSE1: Analog input 0E0 / DSP0 short circuit to supply voltage error report Check DSP0-output A0.0, relay, electr. connections	A361.X4:3		E	2
1DDF14	LSB-BSE1: Analog input 0E1 / DSP0 short circuit to supply voltage error report Check DSP0-output A0.0, relay, electr. connections	A361.X4:4		E	2
1DE012	LSB-BSE1: Analog input 0E2 / DSP0 short circuit to ground error report Check Em. Off switch, voltage, electr. connections	A361.X4:5		E	2
1DE117	LSB-BSE1: Supply voltage 30.1 / DSP0 voltage below required value error indication on display Check battery, voltage, electr. connections and fuse	A361.X4:7		E	2
1DE217	LSB-BSE1: Supply voltage 15.1 / DSP0 voltage below required value error indication on display Check voltage	A361.X4:8		E	2
1DE317	LSB-BSE1: Supply voltage 24V.1 (0A0-1) / DSP0 voltage below required value error indication on display Check voltage, electr. connections and fuse	A361.X4:15		E	2
1DE614	LSB-BSE1: Analog input 1E0 / DSP1 short circuit to supply voltage error report Check DSP1-output A0.0, relay, electr. connections	A361.X5:3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DE714	LSB-BSE1: Analog input 1E1 / DSP1 short circuit to supply voltage error report Check DSP1-output A0.0, relay, electr. connections	A361.X5:4		E	2
1DE812	LSB-BSE1: Analog input 1E2 / DSP1 short circuit to ground error report Check Em. Off switch, voltage, electr. connections	A361.X5:5		E	2
1DE917	LSB-BSE1: Supply voltage 30.2 / DSP1 voltage below required value error indication on display Check battery, voltage, electr. connections and fuse	A361.X5:7		E	2
1DEA17	LSB-BSE1: Supply voltage 15.2 / DSP1 voltage below required value error indication on display Check voltage	A361.X5:8		E	2
1DEB17	LSB-BSE1: Supply voltage 24V.2 (1A0-1) / DSP1 voltage below required value error indication on display Check voltage, electr. connections and fuse	A361.X5:15		E	2
1DEC1B	LSB-BSE1: 2.Shut off channel / DSP0 digital shut off defective Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, fuse, replace module if nec.	A361		E	2
1DEC72	LSB-BSE1: 2.Shut off channel / DSP0 outside source feeding Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, replace module, if nec.	A361		E	2
1DED1B	LSB-BSE1: 2.Shut off channel / DSP1 digital shut off defective Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, fuse, replace module if nec.	A361		E	2
1DED72	LSB-BSE1: 2.Shut off channel / DSP1 outside source feeding Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, replace module, if nec.	A361		E	2
1DF006	LSB-BSE1: System error OS-DSP0 initialising error RAM erroneous Entry in error memory, program is stopped Inform Service of all error parameters and replace module	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DF013	LSB-BSE1: System error OS-DSP0 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A361		E	2
1DF016	LSB-BSE1: System error OS-DSP0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A361		E	2
1DF050	LSB-BSE1: System error OS-DSP0 file not available error report Reload application software	A361		E	3
1DF073	LSB-BSE1: System error OS-DSP0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A361		E	2
1DF082	LSB-BSE1: System error OS-DSP0 hardware-watchdog erroneous Module reset Replace module	A361		E	2
1DF0A1	LSB-BSE1: System error OS-DSP0 System voltage 3V3-Logic outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF0A2	LSB-BSE1: System error OS-DSP0 System voltage 5V-Logic outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF0AD	LSB-BSE1: System error OS-DSP0 System voltage V26-Core outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF0B1	LSB-BSE1: System error OS-DSP0 Power-Fail-Status incorrect error report Check voltage	A361		E	2
1DF0C1	LSB-BSE1: System error OS-DSP0 Incorrect or wrong system version for application error report Reload matching system version	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DF106	LSB-BSE1: System error OS-DSP1 initialising error RAM erroneous Entry in error memory, program is stopped Inform Service of all error parameters and replace module	A361		E	2
1DF113	LSB-BSE1: System error OS-DSP1 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A361		E	2
1DF116	LSB-BSE1: System error OS-DSP1 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A361		E	2
1DF150	LSB-BSE1: System error OS-DSP1 file not available error report Reload application software	A361		E	3
1DF173	LSB-BSE1: System error OS-DSP1 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A361		E	2
1DF182	LSB-BSE1: System error OS-DSP1 hardware-watchdog erroneous Module reset Replace module	A361		E	2
1DF1A1	LSB-BSE1: System error OS-DSP1 System voltage 3V3-Logic outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF1A2	LSB-BSE1: System error OS-DSP1 System voltage 5V-Logic outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF1AD	LSB-BSE1: System error OS-DSP1 System voltage V26-Core outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF1B1	LSB-BSE1: System error OS-DSP1 Power-Fail-Status incorrect error report Check voltage	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DF1C1	LSB-BSE1: System error OS-DSP1 Incorrect or wrong system version for application error report Reload matching system version	A361		E	1
1DF203	LSB-BSE1: System error OS-CPU0 CW Upload to data bank not carried out error report CW Carry out upload in data bank	A361		E	2
1DF280	LSB-BSE1: System error OS-CPU0 Fatal internal error error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF299	LSB-BSE1: System error OS-CPU0 DSP0 erroneous error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF29A	LSB-BSE1: System error OS-CPU0 DSP1 erroneous error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF29B	LSB-BSE1: System error OS-CPU0 dsPIC erroneous error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF2A1	LSB-BSE1: System error OS-CPU0 System voltage 3V3-Logic outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF2A2	LSB-BSE1: System error OS-CPU0 System voltage 5V-Logic outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF2A3	LSB-BSE1: System error OS-CPU0 Board temp. outside permissible range error indication on display Check coolant supply for monitor	A361		E	2
1DF2A4	LSB-BSE1: System error OS-CPU0 Inside temperature outside permissible range error indication on display Check coolant supply for monitor	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DF2A5	LSB-BSE1: System error OS-CPU0 System voltage 12V-CCFL outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF2AB	LSB-BSE1: System error OS-CPU0 System voltage 5V-Standby outside permissible range error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF2AC	LSB-BSE1: System error OS-CPU0 Restoration of CW-operandi failed error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF2AE	LSB-BSE1: System error OS-CPU0 System voltage PCMCIA erroneous error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
1DF2AF	LSB-BSE1: System error OS-CPU0 System voltage 3V- cell-RTC too low error report If time is corrupt, replace battery Type CR1225 in monitor	A361		E	2
1DF2B0	LSB-BSE1: System error OS-CPU0 Time RTC erroneous (Low-Voltage) error report Replace battery Type CR1225 in monitor	A361		E	2
1DF2C0	LSB-BSE1: System error OS-CPU0 Hardware / Software erroneous error report If error repeated, replace component group, inform Service of error parameter	A361		E	2
200001	ZE 2: system error OS-HC11 (observe parameters) initialising error processor-register erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A422		E	2
200002	ZE 2: system error OS-HC11 (observe parameters) initialising error test total in EPROM/FLASH erroneous no crane operation possible check program memory card or ZE	A422		E	2
200006	ZE 2: system error OS-HC11 (observe parameters) initialising error RAM erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A422		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
200007	ZE 2: system error OS-HC11 (observe parameters) UART erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A422		E	2
200010	ZE 2: system error OS-HC11 (observe parameters) system routine inaccessible entry in error memory, all crane movements will be stopped	A422		E	2
200011	ZE 2: system error OS-HC11 (observe parameters) ZE-watchdog expired entry in error memory, all crane movements will be stopped check ZE	A422		E	2
200012	ZE 2: system error OS-HC11 (observe parameters) type-identification in EPROM erroneous entry in error memory, no crane operation possible check program memory card	A422		E	2
200013	ZE 2: system error OS-HC11 (observe parameters) Test sum in FLASH erroneous entry in error memory, all crane movements will be stopped check program memory card	A422		E	2
200014	ZE 2: system error OS-HC11 (observe parameters) program already running entry in error memory, all crane movements will be stopped	A422		E	2
200015	ZE 2: system error OS-HC11 (observe parameters) program not available entry in error memory, all crane movements will be stopped	A422		E	2
200016	ZE 2: system error OS-HC11 (observe parameters) system-, driver-watchdog expired entry in error memory, all crane movements will be stopped	A422		E	2
200017	ZE 2: system error OS-HC11 (observe parameters) total of CPU-time distribution too great entry in error memory, all crane movements will be stopped	A422		E	2
200018	ZE 2: system error OS-HC11 (observe parameters) arithmetic overflow (16 Bit) entry in error memory, all crane movements will be stopped	A422		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
200019	ZE 2: system error OS-HC11 (observe parameters) division through zero (16 Bit) entry in error memory, all crane movements will be stopped	A422		E	2
200020	ZE 2: system error OS-HC11 (observe parameters) task-watchdog expired entry in error memory, all crane movements will be stopped	A422		E	2
200021	ZE 2: system error OS-HC11 (observe parameters) illegal opcode trap entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A422		E	2
200022	ZE 2: system error OS-HC11 (observe parameters) task inactive entry in error memory, all crane movements will be stopped	A422		E	2
200023	ZE 2: system error OS-HC11 (observe parameters) program incapable of running (type identification) entry in error memory, all crane movements will be stopped	A422		E	2
200024	ZE 2: system error OS-HC11 (observe parameters) task already used entry in error memory, all crane movements will be stopped	A422		E	2
200025	ZE 2: system error OS-HC11 (observe parameters) realtime-module already used entry in error memory, all crane movements will be stopped	A422		E	2
200026	ZE 2: system error OS-HC11 (observe parameters) regulator-module already used entry in error memory, all crane movements will be stopped	A422		E	2
200030	ZE 2: system error OS-HC11 (observe parameters) unacceptable bank address entry in error memory, all crane movements will be stopped	A422		E	2
200041	ZE 2: system error OS-HC11 (observe parameters) arithmetic error entry in error memory, all crane movements will be stopped	A422		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
200044	ZE 2: system error OS-HC11 (observe parameters) output parameter without effect, from inactive output entry in error memory, all crane movements will be stopped	A422		E	2
200045	ZE 2: system error OS-HC11 (observe parameters) entry parameter undefined, from inactive input entry in error memory, all crane movements will be stopped	A422		E	2
200046	ZE 2: system error OS-HC11 (observe parameters) impermissible regulator parameter entry in error memory, all crane movements will be stopped	A422		E	2
200047	ZE 2: system error OS-HC11 (observe parameters) realtime-control block not available entry in error memory, all crane movements will be stopped	A422		E	2
200048	ZE 2: system error OS-HC11 (observe parameters) realtime-control block inactive entry in error memory, all crane movements will be stopped	A422		E	2
200049	ZE 2: system error OS-HC11 (observe parameters) urgent modul, ZE not available entry in error memory, no crane operation possible check ZE	A422		E	2
200050	ZE 2: system error OS-HC11 (observe parameters) file not available entry in error memory, all crane movements will be stopped	A422		E	2
200051	ZE 2: system error OS-HC11 (observe parameters) file already opened entry in error memory, all crane movements will be stopped	A422		E	2
200052	ZE 2: system error OS-HC11 (observe parameters) file not open on close entry in error memory, all crane movements will be stopped	A422		E	2
200053	ZE 2: system error OS-HC11 (observe parameters) system mask not available entry in error memory, all crane movements will be stopped	A422		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
200054	ZE 2: system error OS-HC11 (observe parameters) system text not available entry in error memory, all crane movements will be stopped	A422		E	2
200055	ZE 2: system error OS-HC11 (observe parameters) symbol not available entry in error memory, all crane movements will be stopped	A422		E	2
200056	ZE 2: system error OS-HC11 (observe parameters) invalid mark in symbol entry in error memory, all crane movements will be stopped	A422		E	2
200057	ZE 2: system error OS-HC11 (observe parameters) default load chart missing entry in error memory, all crane movements will be stopped	A422		E	2
200058	ZE 2: system error OS-HC11 (observe parameters) amplifier erroneous or return power feed entry in error memory, all crane movements will be stopped check wiring	A422		E	2
200059	ZE 2: system error OS-HC11 (observe parameters) subroutine not reentrant entry in error memory, all crane movements will be stopped	A422		E	2
200060	ZE 2: system error OS-HC11 (observe parameters) transmission error SCI entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A422		E	2
200061	ZE 2: system error OS-HC11 (observe parameters) SCI-BREAK entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A422		E	2
200062	ZE 2: system error OS-HC11 (observe parameters) SCI not connected entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A422		E	2
200063	ZE 2: system error OS-HC11 (observe parameters) monitor error in operation entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A422		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
200065	ZE 2: system error OS-HC11 (observe parameters) impermissible bus address entry in error memory, all crane movements will be stopped	A422		E	2
200066	ZE 2: system error OS-HC11 (observe parameters) ADC working outside the permissible tolerance entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A422		E	2
200067	ZE 2: system error OS-HC11 (observe parameters) arithmetic processor not available entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A422		E	2
200068	ZE 2: system error OS-HC11 (observe parameters) impermissible interrupt entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A422		E	2
200070	ZE 2: system error OS-HC11 (observe parameters) various structure versions entry in error memory, no crane operation possible	A422		E	2
200071	ZE 2: system error OS-HC11 (observe parameters) Structure file missing or faulty entry in error memory, no crane operation possible	A422		E	2
200072	ZE 2: system error OS-HC11 (observe parameters) structure entry senseless entry in error memory, no crane operation possible	A422		E	2
200073	ZE 2: system error OS-HC11 (observe parameters) interpreter error entry in error memory, all crane movements will be stopped	A422		E	2
200074	ZE 2: system error OS-HC11 (observe parameters) transformation ASCII to BIN erroneous entry in error memory, all crane movements will be stopped	A422		E	2
200075	ZE 2: system error OS-HC11 (observe parameters) SPI-error entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A422		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
200076	ZE 2: system error OS-HC11 (observe parameters) incorrectly inserted power unit entry in error memory, all crane movements will be stopped check memory card in power supply unit	A422		E	2
200077	ZE 2: system error OS-HC11 (observe parameters) BAF-call-up erroneous entry in error memory, all crane movements will be stopped	A422		E	2
200078	ZE 2: system error OS-HC11 (observe parameters) impermissible parameter entry in error memory, all crane movements will be stopped	A422		E	2
200079	ZE 2: system error OS-HC11 (observe parameters) no right of access entry in error memory, all crane movements will be stopped	A422		E	2
200080	ZE 2: system error OS-HC11 (observe parameters) Fatal internal error entry in error memory, all crane movements will be stopped	A422		E	2
200081	ZE 2: system error OS-HC11 (observe parameters) stack overflow entry in error memory, all crane movements will be stopped	A422		E	2
200082	ZE 2: system error OS-HC11 (observe parameters) hardware-watchdog erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A422		E	2
200094	ZE 2: system error OS-HC11 (observe parameters) transmission error parallel bus entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A422		E	2
200095	ZE 2: system error OS-HC11 (observe parameters) DMA-error entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A422		E	2
200099	ZE 2: system error OS-HC11 (observe parameters) DSP0 erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A422		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
202001	ZE 2: system error OS-TMS initialising error processor-register erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A422		E	2
202002	ZE 2: system error OS-TMS initialising error test total in EPROM/FLASH erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A422		E	2
202006	ZE 2: system error OS-TMS initialising error RAM erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A422		E	2
202007	ZE 2: system error OS-TMS UART erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A422		E	2
202020	ZE 2: system error OS-TMS task-watchdog expired entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A422		E	2
202021	ZE 2: system error OS-TMS illegal opcode trap entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A422		E	2
202082	ZE 2: system error OS-TMS hardware-watchdog erroneous entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A422		E	2
210012	ZE 2: output 0 short circuit to ground	A422.X1:16		E	1
210013	ZE 2: output 0 open signal circuits	A422.X1:16		E	1
210014	ZE 2: output 0 short circuit to supply voltage	A422.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210054	ZE 2: output 0 short circuit to supply voltage	A422.X1:16		E	1
210058	ZE 2: output 0 positive switching transistor: disruption	A422.X1:16		E	1
210060	ZE 2: output 0 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A422.X1:16		E	1
210062	ZE 2: output 0 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A422.X1:16		E	1
210063	ZE 2: output 0 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A422.X1:16		E	1
210070	ZE 2: output 0 measuring system defect no crane operation possible entry in error list	A422.X1:16		E	1
210071	ZE 2: output 0 short circuit to ground or transistor defect	A422.X1:16		E	1
210072	ZE 2: output 0 outside source feeding	A422.X1:16		E	1
210073	ZE 2: output 0 open circuit or short circuit to supply voltage/ground	A422.X1:16		E	1
210112	ZE 2: output 1 short circuit to ground	A422.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210113	ZE 2: output 1 open signal circuits	A422.X1:17		E	1
210114	ZE 2: output 1 short circuit to supply voltage	A422.X1:17		E	1
210154	ZE 2: output 1 short circuit to supply voltage	A422.X1:17		E	1
210158	ZE 2: output 1 positive switching transistor: disruption	A422.X1:17		E	1
210160	ZE 2: output 1 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A422.X1:17		E	1
210162	ZE 2: output 1 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A422.X1:17		E	1
210163	ZE 2: output 1 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A422.X1:17		E	1
210170	ZE 2: output 1 measuring system defect no crane operation possible entry in error list	A422.X1:17		E	1
210171	ZE 2: output 1 short circuit to ground or transistor defect	A422.X1:17		E	1
210172	ZE 2: output 1 outside source feeding	A422.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210173	ZE 2: output 1 open circuit or short circuit to supply voltage/ground	A422.X1:17		E	1
210212	ZE 2: output 2 short circuit to ground	A422.X1:18		E	1
210213	ZE 2: output 2 open signal circuits	A422.X1:18		E	1
210214	ZE 2: output 2 short circuit to supply voltage	A422.X1:18		E	1
210254	ZE 2: output 2 short circuit to supply voltage	A422.X1:18		E	1
210258	ZE 2: output 2 positive switching transistor: disruption	A422.X1:18		E	1
210270	ZE 2: output 2 measuring system defect no crane operation possible entry in error list	A422.X1:18		E	1
210271	ZE 2: output 2 short circuit to ground or transistor defect	A422.X1:18		E	1
210272	ZE 2: output 2 outside source feeding	A422.X1:18		E	1
210273	ZE 2: output 2 open circuit or short circuit to supply voltage/ground	A422.X1:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210312	ZE 2: output 3 short circuit to ground	A422.X1:19		E	1
210313	ZE 2: output 3 open signal circuits	A422.X1:19		E	1
210314	ZE 2: output 3 short circuit to supply voltage	A422.X1:19		E	1
210354	ZE 2: output 3 short circuit to supply voltage	A422.X1:19		E	1
210358	ZE 2: output 3 positive switching transistor: disruption	A422.X1:19		E	1
210360	ZE 2: output 3 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A422.X1:19		E	1
210362	ZE 2: output 3 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A422.X1:19		E	1
210363	ZE 2: output 3 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A422.X1:19		E	1
210370	ZE 2: output 3 measuring system defect no crane operation possible entry in error list	A422.X1:19		E	1
210371	ZE 2: output 3 short circuit to ground or transistor defect	A422.X1:19		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210372	ZE 2: output 3 outside source feeding	A422.X1:19		E	1
210373	ZE 2: output 3 open circuit or short circuit to supply voltage/ground	A422.X1:19		E	1
210412	ZE 2: output 4 short circuit to ground	A422.X1:20		E	1
210413	ZE 2: output 4 open signal circuits	A422.X1:20		E	1
210414	ZE 2: output 4 short circuit to supply voltage	A422.X1:20		E	1
210454	ZE 2: output 4 short circuit to supply voltage	A422.X1:20		E	1
210458	ZE 2: output 4 positive switching transistor: disruption	A422.X1:20		E	1
210460	ZE 2: output 4 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A422.X1:20		E	1
210462	ZE 2: output 4 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A422.X1:20		E	1
210463	ZE 2: output 4 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A422.X1:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210470	ZE 2: output 4 measuring system defect no crane operation possible entry in error list	A422.X1:20		E	1
210471	ZE 2: output 4 short circuit to ground or transistor defect	A422.X1:20		E	1
210472	ZE 2: output 4 outside source feeding	A422.X1:20		E	1
210473	ZE 2: output 4 open circuit or short circuit to supply voltage/ground	A422.X1:20		E	1
210512	ZE 2: output 5 short circuit to ground	A422.X1:21		E	1
210513	ZE 2: output 5 open signal circuits	A422.X1:21		E	1
210514	ZE 2: output 5 short circuit to supply voltage	A422.X1:21		E	1
210554	ZE 2: output 5 short circuit to supply voltage	A422.X1:21		E	1
210558	ZE 2: output 5 positive switching transistor: disruption	A422.X1:21		E	1
210560	ZE 2: output 5 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A422.X1:21		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210562	ZE 2: output 5 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A422.X1:21		E	1
210563	ZE 2: output 5 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A422.X1:21		E	1
210570	ZE 2: output 5 measuring system defect no crane operation possible entry in error list	A422.X1:21		E	1
210571	ZE 2: output 5 short circuit to ground or transistor defect	A422.X1:21		E	1
210572	ZE 2: output 5 outside source feeding	A422.X1:21		E	1
210573	ZE 2: output 5 open circuit or short circuit to supply voltage/ground	A422.X1:21		E	1
210612	ZE 2: output 6 short circuit to ground	A422.X1:22		E	1
210613	ZE 2: output 6 open signal circuits	A422.X1:22		E	1
210614	ZE 2: output 6 short circuit to supply voltage	A422.X1:22		E	1
210654	ZE 2: output 6 short circuit to supply voltage	A422.X1:22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210658	ZE 2: output 6 positive switching transistor: disruption	A422.X1:22		E	1
210670	ZE 2: output 6 measuring system defect no crane operation possible entry in error list	A422.X1:22		E	1
210671	ZE 2: output 6 short circuit to ground or transistor defect	A422.X1:22		E	1
210672	ZE 2: output 6 outside source feeding	A422.X1:22		E	1
210673	ZE 2: output 6 open circuit or short circuit to supply voltage/ground	A422.X1:22		E	1
210712	ZE 2: output 7 short circuit to ground	A422.X1:23		E	1
210713	ZE 2: output 7 open signal circuits	A422.X1:23		E	1
210714	ZE 2: output 7 short circuit to supply voltage	A422.X1:23		E	1
210754	ZE 2: output 7 short circuit to supply voltage	A422.X1:23		E	1
210758	ZE 2: output 7 positive switching transistor: disruption	A422.X1:23		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
210760	ZE 2: output 7 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A422.X1:23		E	1
210762	ZE 2: output 7 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A422.X1:23		E	1
210763	ZE 2: output 7 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A422.X1:23		E	1
210770	ZE 2: output 7 measuring system defect no crane operation possible entry in error list	A422.X1:23		E	1
210771	ZE 2: output 7 short circuit to ground or transistor defect	A422.X1:23		E	1
210772	ZE 2: output 7 outside source feeding	A422.X1:23		E	1
210773	ZE 2: output 7 open circuit or short circuit to supply voltage/ground	A422.X1:23		E	1
214959	ZE 2: all output supply voltage missing	A422		E	1
215059	ZE 2: output group 0 supply voltage missing	A422.X1:12		E	1
215159	ZE 2: output group 1 supply voltage missing	A422.X1:24		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
215259	ZE 2: output group 2 supply voltage missing	A422		E	1
215359	ZE 2: output group 3 supply voltage missing	A422		E	1
220004	ZE 2: LSB participant address 0 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
220005	ZE 2: LSB participant address 0 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
220018	ZE 2: LSB participant address 0 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
220050	ZE 2: LSB participant address 0 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
220051	ZE 2: LSB participant address 0 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
220053	ZE 2: LSB participant address 0 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
220054	ZE 2: LSB participant address 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
220064	ZE 2: LSB participant address 0 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
220065	ZE 2: LSB participant address 0 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
220066	ZE 2: LSB participant address 0 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
220067	ZE 2: LSB participant address 0 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
220104	ZE 2: LSB participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
220105	ZE 2: LSB participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
220118	ZE 2: LSB participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
220150	ZE 2: LSB participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
220151	ZE 2: LSB participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
220153	ZE 2: LSB participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
220154	ZE 2: LSB participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
220164	ZE 2: LSB participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
220165	ZE 2: LSB participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
220166	ZE 2: LSB participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
220167	ZE 2: LSB participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
220204	ZE 2: LSB participant address 2 level exceeded	A422.X2:z14/z16		E	1
220205	ZE 2: LSB participant address 2 below minimum level	A422.X2:z14/z16		E	1
220218	ZE 2: LSB participant address 2 excess temperature	A422.X2:z14/z16		E	0
220250	ZE 2: LSB participant address 2 reports an incorrect sensor type	A422.X2:z14/z16		E	2
220251	ZE 2: LSB participant address 2 was not configured for the block transfer	A422.X2:z14/z16		E	2
220253	ZE 2: LSB participant address 2 no longer reports or withdrawn during running period	A422.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
220254	ZE 2: LSB participant address 2 Features other settings (parameters) as pre-entered set values	A422.X2:z14/z16		E	2
220264	ZE 2: LSB participant address 2 reports tolerable error in self-test	A422.X2:z14/z16		E	1
220265	ZE 2: LSB participant address 2 reports intolerable error in self-test	A422.X2:z14/z16		E	2
220266	ZE 2: LSB participant address 2 with software version, that is no longer compatible	A422.X2:z14/z16		E	2
220267	ZE 2: LSB participant address 2 supports no download function	A422.X2:z14/z16		E	1
220404	ZE 2: LSB participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
220405	ZE 2: LSB participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
220418	ZE 2: LSB participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
220450	ZE 2: LSB participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
220451	ZE 2: LSB participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
220453	ZE 2: LSB participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
220454	ZE 2: LSB participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
220464	ZE 2: LSB participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
220465	ZE 2: LSB participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
220466	ZE 2: LSB participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
220467	ZE 2: LSB participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
220504	ZE 2: LSB participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
220505	ZE 2: LSB participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
220518	ZE 2: LSB participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
220550	ZE 2: LSB participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
220551	ZE 2: LSB participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
220553	ZE 2: LSB participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
220554	ZE 2: LSB participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
220564	ZE 2: LSB participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
220565	ZE 2: LSB participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
220566	ZE 2: LSB participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
220567	ZE 2: LSB participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
220604	ZE 2: LSB participant address 6 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
220605	ZE 2: LSB participant address 6 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
220618	ZE 2: LSB participant address 6 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
220650	ZE 2: LSB participant address 6 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
220651	ZE 2: LSB participant address 6 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
220653	ZE 2: LSB participant address 6 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
220654	ZE 2: LSB participant address 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
220664	ZE 2: LSB participant address 6 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
220665	ZE 2: LSB participant address 6 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
220666	ZE 2: LSB participant address 6 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
220667	ZE 2: LSB participant address 6 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
220704	ZE 2: LSB participant address 7 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
220705	ZE 2: LSB participant address 7 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
220718	ZE 2: LSB participant address 7 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
220750	ZE 2: LSB participant address 7 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
220751	ZE 2: LSB participant address 7 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
220753	ZE 2: LSB participant address 7 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
220754	ZE 2: LSB participant address 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
220764	ZE 2: LSB participant address 7 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
220765	ZE 2: LSB participant address 7 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
220766	ZE 2: LSB participant address 7 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
220767	ZE 2: LSB participant address 7 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
220904	ZE 2: LSB participant address 9 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
220905	ZE 2: LSB participant address 9 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
220918	ZE 2: LSB participant address 9 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
220950	ZE 2: LSB participant address 9 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
220951	ZE 2: LSB participant address 9 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
220953	ZE 2: LSB participant address 9 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
220954	ZE 2: LSB participant address 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
220964	ZE 2: LSB participant address 9 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
220965	ZE 2: LSB participant address 9 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
220966	ZE 2: LSB participant address 9 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
220967	ZE 2: LSB participant address 9 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
221004	ZE 2: LSB participant address 10 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
221005	ZE 2: LSB participant address 10 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
221018	ZE 2: LSB participant address 10 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
221050	ZE 2: LSB participant address 10 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
221051	ZE 2: LSB participant address 10 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
221053	ZE 2: LSB participant address 10 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
221054	ZE 2: LSB participant address 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
221064	ZE 2: LSB participant address 10 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
221065	ZE 2: LSB participant address 10 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
221066	ZE 2: LSB participant address 10 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
221067	ZE 2: LSB participant address 10 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
221104	ZE 2: LSB participant address 11 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
221105	ZE 2: LSB participant address 11 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
221118	ZE 2: LSB participant address 11 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
221150	ZE 2: LSB participant address 11 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
221151	ZE 2: LSB participant address 11 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
221153	ZE 2: LSB participant address 11 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
221154	ZE 2: LSB participant address 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
221164	ZE 2: LSB participant address 11 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
221165	ZE 2: LSB participant address 11 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
221166	ZE 2: LSB participant address 11 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
221167	ZE 2: LSB participant address 11 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
221204	ZE 2: LSB participant address 12 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
221205	ZE 2: LSB participant address 12 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
221218	ZE 2: LSB participant address 12 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
221250	ZE 2: LSB participant address 12 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
221251	ZE 2: LSB participant address 12 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
221253	ZE 2: LSB participant address 12 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
221254	ZE 2: LSB participant address 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
221264	ZE 2: LSB participant address 12 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
221265	ZE 2: LSB participant address 12 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
221266	ZE 2: LSB participant address 12 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
221267	ZE 2: LSB participant address 12 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
221804	ZE 2: LSB participant address 18 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
221805	ZE 2: LSB participant address 18 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
221818	ZE 2: LSB participant address 18 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
221850	ZE 2: LSB participant address 18 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
221851	ZE 2: LSB participant address 18 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
221853	ZE 2: LSB participant address 18 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1
221854	ZE 2: LSB participant address 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
221864	ZE 2: LSB participant address 18 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
221865	ZE 2: LSB participant address 18 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
221866	ZE 2: LSB participant address 18 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
221867	ZE 2: LSB participant address 18 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
222304	ZE 2: LSB participant address 23 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A422.X2:z14/z16		E	1
222305	ZE 2: LSB participant address 23 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A422.X2:z14/z16		E	1
222318	ZE 2: LSB participant address 23 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A422.X2:z14/z16		E	0
222350	ZE 2: LSB participant address 23 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A422.X2:z14/z16		E	2
222351	ZE 2: LSB participant address 23 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A422.X2:z14/z16		E	2
222353	ZE 2: LSB participant address 23 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A422.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
222354	ZE 2: LSB participant address 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A422.X2:z14/z16		E	2
222364	ZE 2: LSB participant address 23 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A422.X2:z14/z16		E	1
222365	ZE 2: LSB participant address 23 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A422.X2:z14/z16		E	2
222366	ZE 2: LSB participant address 23 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A422.X2:z14/z16		E	2
222367	ZE 2: LSB participant address 23 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A422.X2:z14/z16		E	1
223252	ZE 2: Control data transfer LSB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A422.X2:z14/z16		E	0
223255	ZE 2: Control data transfer LSB Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A422.X2:z14/z16		E	2
223256	ZE 2: Control data transfer LSB Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A422.X2:z14/z16		E	2
223257	ZE 2: Control data transfer LSB has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A422.X2:z14/z16		E	1
223258	ZE 2: Control data transfer LSB recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A422.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
223259	ZE 2: Control data transfer LSB recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A422.X2:z14/z16		E	0
223260	ZE 2: Control data transfer LSB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A422.X2:z14/z16		E	2
223261	ZE 2: Control data transfer LSB driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malfunc. error will be eliminated by system itself otherwise new Software necessary for error elimination	A422.X2:z14/z16		E	2
223262	ZE 2: Control data transfer LSB Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A422.X2:z14/z16		E	2
224814	ZE 2: input 0 short circuit to supply voltage Output of error Check: the sensor line for short-circuits, faulty sensors by pulling out the sensor, connections to the input plate	A422.X2:d2		E	1
224856	ZE 2: input 0 open circuit or short circuit to ground Output of error Check: Supply voltage, input LICCON, sensor lines for interruptions, faulty sensors by pulling out the sensor	A422.X2:d2		E	1
224914	ZE 2: input 1 short circuit to supply voltage Output of error Check: the sensor line for short-circuits, faulty sensors by pulling out the sensor, connections to the input plate	A422.X2:d4		E	1
224956	ZE 2: input 1 open circuit or short circuit to ground Output of error Check: Supply voltage, input LICCON, sensor lines for interruptions, faulty sensors by pulling out the sensor	A422.X2:d4		E	1
230740	ZE 2: Vibrator master switch 1Y not in neutral when starting output of error, shut-down through application release master switch briefly or check LICCON input, gear lines, sensor	A422		B	
230741	ZE 2: Vibrator master switch 1Y both dir. contacts standing by simultaneously output of error, shut-down through application check sensor lines for shorts, defect sensor through unplugging of sensor, connection to circuit board	A422		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
230742	ZE 2: Vibrator master switch 1Y directional contact without zero contact output of error, shut-down through application check supply, LICCON input, sensor lines for breaks , check defect sensor	A422		E	
230743	ZE 2: Vibrator master switch 1Y analogue signal short to supply voltage output of error, shut-down through application check sensor lines for shorts, defect sensor through unplugging of sensor, connection to circuit board	A422		E	
230744	ZE 2: Vibrator master switch 1Y analogue signal erroneous output of error, shut-down through application check sensor lines for shorts, defect sensor through unplugging of sensor, connection to circuit board	A422		E	
230745	ZE 2: Vibrator master switch 1Y analogue sig. open circuit or short circ. to ground output of error, shut-down through application check sensor lines for shorts, defect sensor through unplugging of sensor, connection to circuit board	A422		E	
230746	ZE 2: Vibrator master switch 1Y Zero contact without directional contact output of error, shut-down through application check sensor lines for shorts, defect sensor through unplugging of sensor, connection to circuit board	A422		E	
230747	ZE 2: Vibrator Inputs Vibrator ON / OFF both inputs present at the same time output of error, shut-down through application Check wiring or input LICCON.	A422		E	
230748	ZE 2: Vibrator Op. mode Vibrator selected without Operating mode parallel op. winch 1 output of error, shut-down through application First set winches parallel then switch to parallel op. and then you can switch to vibrator op.	A422		B	
230749	ZE 2: Vibrator seat contact not activated, crane movements blocked output of error, shut-down through application sit down (seat limit switch) or dead man (in master switch) or check LICCON input, sensor lines, sensor	A422		B	
23074A	ZE 2: Vibrator Op. mode Vibrator selected but no release vibrator output of error, shut-down through application In operating mode parallel op., bring all master sw. to zero pos., activate op. mode vibrator again	A422		B	
232000	ZE 2: control winch 1 no slewing movement recognized on actuated winch output of error check LICCON output, lines for short or break, incremental sensor on function, hoisting gear brake	A422		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
232002	ZE 2: control winch 1 hydraulic circuit pressure sensor defective/missing if valid winch torque for LMB is available this will be used, otherwise 0 bar is loaded into pressure value memory check supply, LICCON input, sensor lines to short or break, sensor	A422		E	1
232018	ZE 2: control winch 1 Pressure too high when pump is not actuated Output of error Check pump or pressure sensor	A422		E	
232027	ZE 2: control winch 1 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A422		E	1
23202D	ZE 2: control winch 1 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A422		E	1
23202F	ZE 2: control winch 1 Repl. Pr. Switch continuous actuation or short circuit after VCC output of error Check: - input LICCON, line for short circuit after supply voltage, pressure switch for function	A422		E	1
232041	ZE 2: control winch 1 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A422		E	1
232042	ZE 2: control winch 1 Rotation movement at non-actuated winch brake error report Check winch brake. Check winch turn sensor(installation)	A422		E	1
232100	ZE 2: control winch 2 no slewing movement recognized on actuated winch output of error check LICCON output, lines for short or break, incremental sensor on function, hoisting gear brake	A422		E	1
232102	ZE 2: control winch 2 hydraulic circuit pressure sensor defective/missing if valid winch torque for LMB is available this will be used, otherwise 0 bar is loaded into pressure value memory check supply, LICCON input, sensor lines to short or break, sensor	A422		E	1
232118	ZE 2: control winch 2 Pressure too high when pump is not actuated Output of error Check pump or pressure sensor	A422		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
232127	ZE 2: control winch 2 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A422		E	1
23212D	ZE 2: control winch 2 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A422		E	1
23212F	ZE 2: control winch 2 Repl. Pr. Switch continuous actuation or short circuit after VCC output of error Check: - input LICCON, line for short circuit after supply voltage, pressure switch for function	A422		E	1
232141	ZE 2: control winch 2 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A422		E	1
232142	ZE 2: control winch 2 Rotation movement at non-actuated winch brake error report Check winch brake. Check winch turn sensor(installation)	A422		E	1
235001	ZE 2: operation winch 1 feed pressure supply missing/too low Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A422		B	
235004	ZE 2: operation winch 1 unreeled winch shut-down Operation conditional switch off, may not be shunted reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A422		B	
235005	ZE 2: operation winch 1 reeled winch shut-down Operation conditional switch off, may not be shunted reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A422		B	
235019	ZE 2: operation winch 1 no or invalid operation mode shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A422		B	
235020	ZE 2: operation winch 1 LMB shut-down operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A422		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
235021	ZE 2: operation winch 1 Shut-down measuring point 1 > F max - operation operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A422		B	
235022	ZE 2: operation winch 1 Shut-down measuring point 1 > F max - assembly Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A422		B	
235024	ZE 2: operation winch 1 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A422		B	
235025	ZE 2: operation winch 1 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Set down derrick counterweight on ground, if not possible unload derrick counterweight, until forces in desired range	A422		B	
235026	ZE 2: operation winch 1 Shut-down upper limit angle derrick OGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A422		B	
235027	ZE 2: operation winch 1 Shut-down lower limit angle derrick UGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A422		B	
235029	ZE 2: operation winch 1 winch blocked (C-key monitor) Operation conditional switch off, may not be shunted Authorise winch 1 in control diagram	A422		B	
23502B	ZE 2: operation winch 1 Shut off Derrick ballast pulled > Derrick ballast max Operation conditional switch off, may not be shunted Fix cause of "LMB Stop", see error message	A422		B	
235030	ZE 2: operation winch 1 master switch 1 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A422		B	
235033	ZE 2: operation winch 1 Shut-down parallel op. differential path between winches too great Operation conditional switch off, may not be shunted Operate load hook in single operation winches 1 and 2 horizontally and set winches 1 and 2 in parallel operation.	A422		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
235039	ZE 2: operation winch 1 seat contact shut-down operational shut down Sit down or actuate one of the shunting switches for the seat contact in the master switches.	A422		B	
23503E	ZE 2: operation winch 1 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A422		B	1
235044	ZE 2: operation winch 1 Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A422		B	
235050	ZE 2: operation winch 1 end of stroke switch shut-down 1 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A422		B	
235051	ZE 2: operation winch 1 end of stroke switch shut-down 2 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A422		B	
235052	ZE 2: operation winch 1 end of stroke switch shut-down 3 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A422		B	
235057	ZE 2: operation winch 1 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders SA-frame	A422		B	
235063	ZE 2: operation winch 1 Crane engine in overspeed Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A422		B	
235066	ZE 2: operation winch 1 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A422		B	
235067	ZE 2: operation winch 1 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A422		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
23507A	ZE 2: operation winch 1 Shut off Radio assembly BTT-E Main boom angle exceeded	A422		B	
23507C	ZE 2: operation winch 1 Shut off Radio assembly BTT-E Accessory angle exceeded	A422		B	
235081	ZE 2: operation winch 1 end of stroke switch 1 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A422		B	
235082	ZE 2: operation winch 1 end of stroke switch 2 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A422		B	
235083	ZE 2: operation winch 1 end of stroke switch 3 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A422		B	
23509A	ZE 2: operation winch 1 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders main boom	A422		B	
23509B	ZE 2: operation winch 1 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders Derrick	A422		B	
2350B3	ZE 2: operation winch 1 Shut off Test point 1 < F min and upper limit angle Derrick OGWD operational shut down If possible, move derrick boom in op. position, for that assembly - winch 4 can be lowered	A422		B	
2350B5	ZE 2: operation winch 1 Master switch right BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A422		B	
2350C6	ZE 2: operation winch 1 Shut-off test point 3 < F min Operation conditional switch off, may not be shunted Lower load or lower derrick ballast if possible or spool out retraction gear if possible.	A422		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2350F1	ZE 2: operation winch 1 Shut off lower winch Operation conditional switch off, may not be shunted Spool winch up shut off not bypassable	A422		B	
235101	ZE 2: operation winch 2 feed pressure supply missing/too low Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A422		B	
235104	ZE 2: operation winch 2 unreeled winch shut-down Operation conditional switch off, may not be shunted reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A422		B	
235105	ZE 2: operation winch 2 reeled winch shut-down Operation conditional switch off, may not be shunted reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A422		B	
235119	ZE 2: operation winch 2 no or invalid operation mode shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A422		B	
235120	ZE 2: operation winch 2 LMB shut-down operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A422		B	
235121	ZE 2: operation winch 2 Shut-down measuring point 1 > F max - operation operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A422		B	
235122	ZE 2: operation winch 2 Shut-down measuring point 1 > F max - assembly Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A422		B	
235124	ZE 2: operation winch 2 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A422		B	
235125	ZE 2: operation winch 2 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Set down derrick counterweight on ground, if not possible unload derrick counterweight, until forces in desired range	A422		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
235126	ZE 2: operation winch 2 Shut-down upper limit angle derrick OGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A422		B	
235127	ZE 2: operation winch 2 Shut-down lower limit angle derrick UGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A422		B	
235129	ZE 2: operation winch 2 winch blocked (C-key monitor) Operation conditional switch off, may not be shunted Authorise winch 2 in control diagram.	A422		B	
23512B	ZE 2: operation winch 2 Shut off Derrick ballast pulled > Derrick ballast max Operation conditional switch off, may not be shunted Fix cause of "LMB Stop", see error message	A422		B	
235130	ZE 2: operation winch 2 master switch 1 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A422		B	
235131	ZE 2: operation winch 2 master switch 2 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A422		B	
235133	ZE 2: operation winch 2 Shut-down parallel op. differential path between winches too great Operation conditional switch off, may not be shunted Operate load hook in single operation winches 1 and 2 horizontally and set winches 1 and 2 in parallel operation.	A422		B	
235139	ZE 2: operation winch 2 seat contact shut-down operational shut down Sit down or actuate one of the shunting switches for the seat contact in the master switches.	A422		B	
23513E	ZE 2: operation winch 2 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A422		B	1
235144	ZE 2: operation winch 2 Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A422		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
235150	ZE 2: operation winch 2 end of stroke switch shut-down 1 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A422		B	
235151	ZE 2: operation winch 2 end of stroke switch shut-down 2 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A422		B	
235152	ZE 2: operation winch 2 end of stroke switch shut-down 3 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A422		B	
235157	ZE 2: operation winch 2 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders SA-frame	A422		B	
235163	ZE 2: operation winch 2 Crane engine in overspeed Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A422		B	
235166	ZE 2: operation winch 2 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A422		B	
235167	ZE 2: operation winch 2 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A422		B	
23517A	ZE 2: operation winch 2 Shut off Radio assembly BTT-E Main boom angle exceeded	A422		B	
23517C	ZE 2: operation winch 2 Shut off Radio assembly BTT-E Accessory angle exceeded	A422		B	
235181	ZE 2: operation winch 2 end of stroke switch 1 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A422		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
235182	ZE 2: operation winch 2 end of stroke switch 2 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A422		B	
235183	ZE 2: operation winch 2 end of stroke switch 3 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A422		B	
23519A	ZE 2: operation winch 2 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders main boom	A422		B	
23519B	ZE 2: operation winch 2 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders Derrick	A422		B	
2351B3	ZE 2: operation winch 2 Shut off Test point 1 < F min and upper limit angle Derrick OGWD operational shut down If possible, move derrick boom in op. position, for that assembly - winch 4 can be lowered	A422		B	
2351B5	ZE 2: operation winch 2 Master switch right BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A422		B	
2351C6	ZE 2: operation winch 2 Shut-off test point 3 < F min Operation conditional switch off, may not be shunted Lower load or lower derrick ballast if possible or spool out retraction gear if possible.	A422		B	
2351F1	ZE 2: operation winch 2 Shut off lower winch Operation conditional switch off, may not be shunted Spool winch up shut off not bypassable	A422		B	
236942	ZE 2: Operation crane control Emergency op. crane cont. switched on with start test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A422		B	1
236943	ZE 2: Operation crane control Emergency op. crane control switched on during test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A422		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
261001	E/A-Modul 2: system error OS-C167 initialising error processor-register erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A12		E	2
261002	E/A-Modul 2: system error OS-C167 initialising error test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A12		E	2
261006	E/A-Modul 2: system error OS-C167 initialising error RAM erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A12		E	2
261013	E/A-Modul 2: system error OS-C167 test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A12		E	2
261016	E/A-Modul 2: system error OS-C167 system-, driver-watchdog expired error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A12		E	2
261068	E/A-Modul 2: system error OS-C167 impermissible interrupt error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A12		E	2
261071	E/A-Modul 2: system error OS-C167 Invalid configuration or Firmware error indication on display re-load Software from ZE	A12		E	2
261080	E/A-Modul 2: system error OS-C167 fatal internal software error error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A12		E	2
261082	E/A-Modul 2: system error OS-C167 hardware-watchdog erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A12		E	2
261088	E/A-Modul 2: system error OS-C167 Configuration does not match software condition error indication on display Comparison SW-condition EAM-SW and configuration LICCON different, check LICCON-configuration, download EAM	A12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
261089	E/A-Modul 2: system error OS-C167 Incorrect version of firmware installed Error output, possible error functions of module Replace module, reload firmware	A12		E	1
261090	E/A-Modul 2: system error OS-C167 Incorrect hardware version recognised Error output, possible error functions of module Replace module	A12		E	1
272052	E/A-Modul 2: input/output DEA0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:17		E	1
272053	E/A-Modul 2: input/output DEA0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:17		E	1
272054	E/A-Modul 2: input/output DEA0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:17		E	1
272055	E/A-Modul 2: input/output DEA0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:17		E	1
272152	E/A-Modul 2: input/output DEA1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:15		E	1
272153	E/A-Modul 2: input/output DEA1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:15		E	1
272154	E/A-Modul 2: input/output DEA1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:15		E	1
272155	E/A-Modul 2: input/output DEA1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
272252	E/A-Modul 2: input/output DEA2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:13		E	1
272253	E/A-Modul 2: input/output DEA2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:13		E	1
272254	E/A-Modul 2: input/output DEA2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:13		E	1
272255	E/A-Modul 2: input/output DEA2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:13		E	1
272352	E/A-Modul 2: input/output DEA3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:11		E	1
272353	E/A-Modul 2: input/output DEA3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:11		E	1
272354	E/A-Modul 2: input/output DEA3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:11		E	1
272355	E/A-Modul 2: input/output DEA3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:11		E	1
272452	E/A-Modul 2: input/output DEA4 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:9		E	1
272453	E/A-Modul 2: input/output DEA4 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
272454	E/A-Modul 2: input/output DEA4 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:9		E	1
272455	E/A-Modul 2: input/output DEA4 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:9		E	1
272552	E/A-Modul 2: input/output DEA5 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:7		E	1
272553	E/A-Modul 2: input/output DEA5 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:7		E	1
272554	E/A-Modul 2: input/output DEA5 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:7		E	1
272555	E/A-Modul 2: input/output DEA5 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:7		E	1
272652	E/A-Modul 2: input/output DEA6 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:5		E	1
272653	E/A-Modul 2: input/output DEA6 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:5		E	1
272654	E/A-Modul 2: input/output DEA6 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:5		E	1
272655	E/A-Modul 2: input/output DEA6 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
272752	E/A-Modul 2: input/output DEA7 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:3		E	1
272753	E/A-Modul 2: input/output DEA7 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:3		E	1
272754	E/A-Modul 2: input/output DEA7 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:3		E	1
272755	E/A-Modul 2: input/output DEA7 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:3		E	1
273481	E/A-Modul 2: voltage input E4 short circuit to supply voltage, open line function is not carried out check input signal on the E/A-Modul or sensor	A12.X2:9		E	1
273581	E/A-Modul 2: voltage input E5 short circuit to supply voltage, open line symbol for compressed air supply 1 is flashing on the display unit check input signal on the E/A-Modul or sensor	A12.X2:7		E	1
273681	E/A-Modul 2: voltage input E6 short circuit to supply voltage, open line symbol for compressed air supply 2 is flashing on the display unit check input signal on the E/A-Modul or sensor	A12.X2:5		E	1
273781	E/A-Modul 2: voltage input E7 short circuit to supply voltage, open line symbol for compressed air supply 3 is flashing on the display unit check input signal on the E/A-Modul or sensor	A12.X2:3		E	1
273782	E/A-Modul 2: voltage input E7 short circuit to ground, open line, constant current 10 mA incorrect no reaction check input signal on the E/A-Modul or sensor	A12.X2:3		E	1
273783	E/A-Modul 2: voltage input E7 short circuit to supply voltage, open line, lack of voltage no reaction check input signal on the E/A-Modul or sensor	A12.X2:3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
279052	E/A-Modul 2: output A0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:18		E	1
279053	E/A-Modul 2: output A0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:18		E	1
279054	E/A-Modul 2: output A0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:18		E	1
279055	E/A-Modul 2: output A0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:18		E	1
279152	E/A-Modul 2: output A1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:16		E	1
279153	E/A-Modul 2: output A1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:16		E	1
279154	E/A-Modul 2: output A1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:16		E	1
279155	E/A-Modul 2: output A1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:16		E	1
279250	E/A-Modul 2: bridge output A2 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A12.X3:14		E	1
279251	E/A-Modul 2: bridge output A2 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A12.X3:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
279252	E/A-Modul 2: bridge output A2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:14		E	1
279253	E/A-Modul 2: bridge output A2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:14		E	1
279254	E/A-Modul 2: bridge output A2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:14		E	1
279255	E/A-Modul 2: bridge output A2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:14		E	1
279350	E/A-Modul 2: bridge output A3 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A12.X3:12		E	1
279351	E/A-Modul 2: bridge output A3 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A12.X3:12		E	1
279352	E/A-Modul 2: bridge output A3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A12.X3:12		E	1
279353	E/A-Modul 2: bridge output A3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A12.X3:12		E	1
279354	E/A-Modul 2: bridge output A3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A12.X3:12		E	1
279355	E/A-Modul 2: bridge output A3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A12.X3:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
283301	E/A-Modul 2: SPI-display unit Faulty data transfer E/A-module<>unit (time exceeded) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A12.X4:1/2/3/5/6/7/8		E	1
283302	E/A-Modul 2: SPI-display unit Serious system error to SPI-connection (interface) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A12.X4:1/2/3/5/6/7/8		E	1
283303	E/A-Modul 2: SPI-display unit break in line or short circuit to supply voltage error indication on display remedy short circuit, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A12.X4:1/2/3/5/6/7/8		E	1
283304	E/A-Modul 2: SPI-display unit break in line or short circuit to ground error indication on display remedy short circuit, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A12.X4:1/2/3/5/6/7/8		E	1
283306	E/A-Modul 2: SPI-display unit Data transfer faulty (faulty check byte) error indication on display suppress EMV- interference	A12.X4:1/2/3/5/6/7/8		E	1
283307	E/A-Modul 2: SPI-display unit Unit faulty/missing, incorrect unit inserted (ID) error indication on display check periphery and replace if necessary, check Software version, check EMV- interference	A12.X4:1/2/3/5/6/7/8		E	1
283308	E/A-Modul 2: SPI-display unit Data transfer faulty (incorrect number of data bytes received) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A12.X4:1/2/3/5/6/7/8		E	1
283900	E/A-Modul 2: Control operating unit (SPI) Faulty initialisation data connection E/A-module<>unit error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A12.X4:1/2/3/5/6/7/8		E	1
283902	E/A-Modul 2: Control operating unit (SPI) Serious system error to SPI-connection (interface) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A12.X4:1/2/3/5/6/7/8		E	1
283905	E/A-Modul 2: Control operating unit (SPI) Initialisation error, resetting inputs/outputs faulty error indication on display check wiring, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A12.X4:1/2/3/5/6/7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
283907	E/A-Modul 2: Control operating unit (SPI) Unit faulty/missing, incorrect unit inserted (ID) error indication on display connect functional periphery unit, system then eliminates error independently	A12.X4:1/2/3/5/6/7/8		E	1
283908	E/A-Modul 2: Control operating unit (SPI) Data transfer faulty (incorrect number of data bytes received) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A12.X4:1/2/3/5/6/7/8		E	1
284104	E/A-Modul 2: LSB-B participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
284105	E/A-Modul 2: LSB-B participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
284118	E/A-Modul 2: LSB-B participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
284150	E/A-Modul 2: LSB-B participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
284151	E/A-Modul 2: LSB-B participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
284153	E/A-Modul 2: LSB-B participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
284154	E/A-Modul 2: LSB-B participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
284164	E/A-Modul 2: LSB-B participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
284165	E/A-Modul 2: LSB-B participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
284166	E/A-Modul 2: LSB-B participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
284167	E/A-Modul 2: LSB-B participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
284204	E/A-Modul 2: LSB-B participant address 2 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
284205	E/A-Modul 2: LSB-B participant address 2 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
284218	E/A-Modul 2: LSB-B participant address 2 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
284250	E/A-Modul 2: LSB-B participant address 2 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
284251	E/A-Modul 2: LSB-B participant address 2 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
284253	E/A-Modul 2: LSB-B participant address 2 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
284254	E/A-Modul 2: LSB-B participant address 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
284264	E/A-Modul 2: LSB-B participant address 2 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
284265	E/A-Modul 2: LSB-B participant address 2 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
284266	E/A-Modul 2: LSB-B participant address 2 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
284267	E/A-Modul 2: LSB-B participant address 2 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
284304	E/A-Modul 2: LSB-B participant address 3 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
284305	E/A-Modul 2: LSB-B participant address 3 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
284318	E/A-Modul 2: LSB-B participant address 3 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
284350	E/A-Modul 2: LSB-B participant address 3 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
284351	E/A-Modul 2: LSB-B participant address 3 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
284353	E/A-Modul 2: LSB-B participant address 3 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
284354	E/A-Modul 2: LSB-B participant address 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
284364	E/A-Modul 2: LSB-B participant address 3 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
284365	E/A-Modul 2: LSB-B participant address 3 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
284366	E/A-Modul 2: LSB-B participant address 3 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
284367	E/A-Modul 2: LSB-B participant address 3 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
284404	E/A-Modul 2: LSB-B participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
284405	E/A-Modul 2: LSB-B participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
284418	E/A-Modul 2: LSB-B participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
284450	E/A-Modul 2: LSB-B participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
284451	E/A-Modul 2: LSB-B participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
284453	E/A-Modul 2: LSB-B participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
284454	E/A-Modul 2: LSB-B participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
284464	E/A-Modul 2: LSB-B participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
284465	E/A-Modul 2: LSB-B participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
284466	E/A-Modul 2: LSB-B participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
284467	E/A-Modul 2: LSB-B participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
284504	E/A-Modul 2: LSB-B participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
284505	E/A-Modul 2: LSB-B participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
284518	E/A-Modul 2: LSB-B participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
284550	E/A-Modul 2: LSB-B participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
284551	E/A-Modul 2: LSB-B participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
284553	E/A-Modul 2: LSB-B participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
284554	E/A-Modul 2: LSB-B participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
284564	E/A-Modul 2: LSB-B participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
284565	E/A-Modul 2: LSB-B participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
284566	E/A-Modul 2: LSB-B participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
284567	E/A-Modul 2: LSB-B participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
284604	E/A-Modul 2: LSB-B participant address 6 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
284605	E/A-Modul 2: LSB-B participant address 6 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
284618	E/A-Modul 2: LSB-B participant address 6 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
284650	E/A-Modul 2: LSB-B participant address 6 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
284651	E/A-Modul 2: LSB-B participant address 6 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
284653	E/A-Modul 2: LSB-B participant address 6 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
284654	E/A-Modul 2: LSB-B participant address 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
284664	E/A-Modul 2: LSB-B participant address 6 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
284665	E/A-Modul 2: LSB-B participant address 6 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
284666	E/A-Modul 2: LSB-B participant address 6 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
284667	E/A-Modul 2: LSB-B participant address 6 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
284704	E/A-Modul 2: LSB-B participant address 7 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
284705	E/A-Modul 2: LSB-B participant address 7 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
284718	E/A-Modul 2: LSB-B participant address 7 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
284750	E/A-Modul 2: LSB-B participant address 7 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
284751	E/A-Modul 2: LSB-B participant address 7 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
284753	E/A-Modul 2: LSB-B participant address 7 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
284754	E/A-Modul 2: LSB-B participant address 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
284764	E/A-Modul 2: LSB-B participant address 7 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
284765	E/A-Modul 2: LSB-B participant address 7 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
284766	E/A-Modul 2: LSB-B participant address 7 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
284767	E/A-Modul 2: LSB-B participant address 7 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
284804	E/A-Modul 2: LSB-B participant address 8 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
284805	E/A-Modul 2: LSB-B participant address 8 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
284818	E/A-Modul 2: LSB-B participant address 8 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
284850	E/A-Modul 2: LSB-B participant address 8 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
284851	E/A-Modul 2: LSB-B participant address 8 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
284853	E/A-Modul 2: LSB-B participant address 8 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
284854	E/A-Modul 2: LSB-B participant address 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
284864	E/A-Modul 2: LSB-B participant address 8 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
284865	E/A-Modul 2: LSB-B participant address 8 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
284866	E/A-Modul 2: LSB-B participant address 8 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
284867	E/A-Modul 2: LSB-B participant address 8 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
285004	E/A-Modul 2: LSB-B participant address 10 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
285005	E/A-Modul 2: LSB-B participant address 10 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
285018	E/A-Modul 2: LSB-B participant address 10 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
285050	E/A-Modul 2: LSB-B participant address 10 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
285051	E/A-Modul 2: LSB-B participant address 10 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
285053	E/A-Modul 2: LSB-B participant address 10 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
285054	E/A-Modul 2: LSB-B participant address 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
285064	E/A-Modul 2: LSB-B participant address 10 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
285065	E/A-Modul 2: LSB-B participant address 10 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
285066	E/A-Modul 2: LSB-B participant address 10 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
285067	E/A-Modul 2: LSB-B participant address 10 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
285104	E/A-Modul 2: LSB-B participant address 11 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
285105	E/A-Modul 2: LSB-B participant address 11 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
285118	E/A-Modul 2: LSB-B participant address 11 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
285150	E/A-Modul 2: LSB-B participant address 11 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
285151	E/A-Modul 2: LSB-B participant address 11 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
285153	E/A-Modul 2: LSB-B participant address 11 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
285154	E/A-Modul 2: LSB-B participant address 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
285164	E/A-Modul 2: LSB-B participant address 11 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1
285165	E/A-Modul 2: LSB-B participant address 11 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
285166	E/A-Modul 2: LSB-B participant address 11 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
285167	E/A-Modul 2: LSB-B participant address 11 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
285604	E/A-Modul 2: LSB-B participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A12.X3:4/6		E	1
285605	E/A-Modul 2: LSB-B participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A12.X3:4/6		E	1
285618	E/A-Modul 2: LSB-B participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A12.X3:4/6		E	0
285650	E/A-Modul 2: LSB-B participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A12.X3:4/6		E	2
285651	E/A-Modul 2: LSB-B participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A12.X3:4/6		E	2
285653	E/A-Modul 2: LSB-B participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A12.X3:4/6		E	1
285654	E/A-Modul 2: LSB-B participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A12.X3:4/6		E	2
285664	E/A-Modul 2: LSB-B participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A12.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
285665	E/A-Modul 2: LSB-B participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A12.X3:4/6		E	2
285666	E/A-Modul 2: LSB-B participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A12.X3:4/6		E	2
285667	E/A-Modul 2: LSB-B participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A12.X3:4/6		E	1
287252	E/A-Modul 2: Control data transfer LSB-B has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A12.X3:4/6		E	0
287255	E/A-Modul 2: Control data transfer LSB-B Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A12.X3:4/6		E	2
287256	E/A-Modul 2: Control data transfer LSB-B Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A12.X3:4/6		E	2
287257	E/A-Modul 2: Control data transfer LSB-B has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A12.X3:4/6		E	1
287258	E/A-Modul 2: Control data transfer LSB-B recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A12.X3:4/6		E	0
287259	E/A-Modul 2: Control data transfer LSB-B recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A12.X3:4/6		E	0
287260	E/A-Modul 2: Control data transfer LSB-B driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A12.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
287261	E/A-Modul 2: Control data transfer LSB-B driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A12.X3:4/6		E	2
287262	E/A-Modul 2: Control data transfer LSB-B Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A12.X3:4/6		E	2
287530	E/A-Modul 2: CAN-participant engine Data transfer subscriber transfer cycle exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A12.X5:5/6		E	1
287531	E/A-Modul 2: CAN-participant engine Data transfer faulty/missing, max. cycle time exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A12.X5:5/6		E	1
287630	E/A-Modul 2: CAN-participant gear Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A12.X5:5/6		E	1
287631	E/A-Modul 2: CAN-participant gear Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A12.X5:5/6		E	1
287730	E/A-Modul 2: CAN-participant ABV (ABS/ASR) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A12.X5:5/6		E	1
287731	E/A-Modul 2: CAN-participant ABV (ABS/ASR) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A12.X5:5/6		E	1
287930	E/A-Modul 2: CAN-participant retarder Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A12.X5:5/6		E	1
287931	E/A-Modul 2: CAN-participant retarder Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A12.X5:5/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
288030	E/A-Modul 2: CAN-user converter clutch unit CCU Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A12.X5:5/6		E	1
288031	E/A-Modul 2: CAN-user converter clutch unit CCU Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A12.X5:5/6		E	1
288530	E/A-Modul 2: CAN-participant E/A-Modul 1 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A12.X5:5/6		E	1
288531	E/A-Modul 2: CAN-participant E/A-Modul 1 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A12.X5:5/6		E	1
288630	E/A-Modul 2: CAN-participant E/A-Modul 2 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A12.X5:5/6		E	1
288631	E/A-Modul 2: CAN-participant E/A-Modul 2 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A12.X5:5/6		E	1
288930	E/A-Modul 2: CAN-participant E/A-Modul 5 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A12.X5:5/6		E	1
288931	E/A-Modul 2: CAN-participant E/A-Modul 5 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A12.X5:5/6		E	1
289900	E/A-Modul 2: Control data transfer CAN internal error at Register-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A12.X5:5/6		E	2
289901	E/A-Modul 2: Control data transfer CAN internal error at RAM-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A12.X5:5/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
289902	E/A-Modul 2: Control data transfer CAN Configuration error Software internal error, CAN-transmission will be aborted replace E/A-Modul, check Software (test system ZE)	A12.X5:5/6		E	2
289903	E/A-Modul 2: Control data transfer CAN Transfer interrupted after continuous error CAN-Transmission will be aborted check bus lines/neutral point, replace neutral point or E/A-Modul	A12.X5:5/6		E	1
289910	E/A-Modul 2: Control data transfer CAN short-term error in bus connection re-attachment of Modul to bus transmission check bus lines/neutral point, unplug individual bus participant and check if error has been eliminated	A12.X5:5/6		E	1
289911	E/A-Modul 2: Control data transfer CAN permanent error bus connection cyclic re-attachment of Modul to bus transmission check bus lines/neutral point, unplug individual bus participant and check if error has been eliminated	A12.X5:5/6		E	1
289920	E/A-Modul 2: Control data transfer CAN active participant not responding parameterised substitute values for receiver signals will be used check error report for missing participant(s), test system ZE	A12.X5:5/6		E	1
289921	E/A-Modul 2: Control data transfer CAN No active subscriber responding parameterised substitute values for receiver signals will be used in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A12.X5:5/6		E	1
289950	E/A-Modul 2: Control data transfer CAN erroneous command test system no reaction to unknown test system control command in CAN-System Software check Software (test system)	A12.X5:5/6		E	1
292001	E/A-Modul 2: control engine long-term disruption E/A-Modul <-> engine control engine control and E/A-Modul at emergency speed engine control and E/A-Modul, check CAN-bus-connections	A12		E	1
293500	E/A-Modul 2: control heating/air conditioning servo-motor heating, circulated/fresh air or screen/foot erroneous servo motor relays a high signal to the diagnosis output check water valve and air flaps of the heating or check servo motor	A12		E	1
294190	E/A-Modul 2: LSB-bus participant ZE missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
294191	E/A-Modul 2: LSB-bus participant E/A-Modul 1 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A12		E	1
294193	E/A-Modul 2: LSB-bus participant E/A-Modul 3 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A12		E	1
294194	E/A-Modul 2: LSB-bus participant E/A-Modul 4 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A12		E	1
294195	E/A-Modul 2: LSB-bus participant E/A-Modul 5 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A12		E	1
295050	E/A-Modul 2: operation engine no engine start possible as engine already recognized as ON function is not carried out	A12		B	
295055	E/A-Modul 2: operation engine STOP, ignition operators cab in upper-carriage operation mode function is not carried out	A12		B	
295056	E/A-Modul 2: operation engine STOP, ignition operators cab in under-carriage operation mode function is not carried out	A12		B	
295059	E/A-Modul 2: operation engine no start, CAN-connection E/A-Modul <-> engine elec. malfunc function is not carried out	A12		B	
295060	E/A-Modul 2: operation engine no start, gears not in N function is not carried out	A12		B	
295061	E/A-Modul 2: operation engine no start, no operation mode recognised function is not carried out	A12		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
295062	E/A-Modul 2: operation engine no start, ignition upper/under-carriage switched on function is not carried out	A12		B	
295063	E/A-Modul 2: operation engine no start, engine-STOP-key activated in right support unit function is not carried out	A12		B	
295064	E/A-Modul 2: operation engine no start, engine-STOP-key activated in left support unit function is not carried out	A12		B	
295065	E/A-Modul 2: operation engine no start, key activated in support unit function is not carried out	A12		B	
295079	E/A-Modul 2: operation engine support box-operation mode prevented: gears not in neutral function is not carried out	A12		B	
295080	E/A-Modul 2: operation engine travel operation not possible when key activated on support box function is not carried out	A12		B	
295500	E/A-Modul 2: operation axle suspension function simultaneously ON and OFF function is not carried out do not simultaneously activate contrasting function keys	A12		B	
295511	E/A-Modul 2: operation axle suspension unauthorised switching on of function function is not carried out start engine and repeat operation	A12		B	
295513	E/A-Modul 2: operation axle suspension unauthorised function activation function is not carried out start engine and repeat operation	A12		B	
295900	E/A-Modul 2: operation longitudinal lock function simultaneously ON and OFF function is not carried out do not simultaneously activate contrasting function keys	A12		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
295911	E/A-Modul 2: operation longitudinal lock unauthorised switching on of function function is not carried out start engine and repeat operation	A12		B	
295912	E/A-Modul 2: operation longitudinal lock unauthorised switching off of function function is not carried out start engine and repeat operation	A12		B	
295913	E/A-Modul 2: operation longitudinal lock unauthorised function activation function is not carried out start engine and repeat operation	A12		B	
295914	E/A-Modul 2: operation longitudinal lock activation of function without operation mode function is not carried out start engine and repeat operation	A12		B	
300001	ZE 3: system error OS-HC11 (observe parameters) initialising error processor-register erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A423		E	2
300002	ZE 3: system error OS-HC11 (observe parameters) initialising error test total in EPROM/FLASH erroneous no crane operation possible check program memory card or ZE	A423		E	2
300006	ZE 3: system error OS-HC11 (observe parameters) initialising error RAM erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A423		E	2
300007	ZE 3: system error OS-HC11 (observe parameters) UART erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A423		E	2
300010	ZE 3: system error OS-HC11 (observe parameters) system routine inaccessible entry in error memory, all crane movements will be stopped	A423		E	2
300011	ZE 3: system error OS-HC11 (observe parameters) ZE-watchdog expired entry in error memory, all crane movements will be stopped check ZE	A423		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
300012	ZE 3: system error OS-HC11 (observe parameters) type-identification in EPROM erroneous entry in error memory, no crane operation possible check program memory card	A423		E	2
300013	ZE 3: system error OS-HC11 (observe parameters) Test sum in FLASH erroneous entry in error memory, all crane movements will be stopped check program memory card	A423		E	2
300014	ZE 3: system error OS-HC11 (observe parameters) program already running entry in error memory, all crane movements will be stopped	A423		E	2
300015	ZE 3: system error OS-HC11 (observe parameters) program not available entry in error memory, all crane movements will be stopped	A423		E	2
300016	ZE 3: system error OS-HC11 (observe parameters) system-, driver-watchdog expired entry in error memory, all crane movements will be stopped	A423		E	2
300017	ZE 3: system error OS-HC11 (observe parameters) total of CPU-time distribution too great entry in error memory, all crane movements will be stopped	A423		E	2
300018	ZE 3: system error OS-HC11 (observe parameters) arithmetic overflow (16 Bit) entry in error memory, all crane movements will be stopped	A423		E	2
300019	ZE 3: system error OS-HC11 (observe parameters) division through zero (16 Bit) entry in error memory, all crane movements will be stopped	A423		E	2
300020	ZE 3: system error OS-HC11 (observe parameters) task-watchdog expired entry in error memory, all crane movements will be stopped	A423		E	2
300021	ZE 3: system error OS-HC11 (observe parameters) illegal opcode trap entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A423		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
300022	ZE 3: system error OS-HC11 (observe parameters) task inactive entry in error memory, all crane movements will be stopped	A423		E	2
300023	ZE 3: system error OS-HC11 (observe parameters) program incapable of running (type identification) entry in error memory, all crane movements will be stopped	A423		E	2
300024	ZE 3: system error OS-HC11 (observe parameters) task already used entry in error memory, all crane movements will be stopped	A423		E	2
300025	ZE 3: system error OS-HC11 (observe parameters) realtime-module already used entry in error memory, all crane movements will be stopped	A423		E	2
300026	ZE 3: system error OS-HC11 (observe parameters) regulator-module already used entry in error memory, all crane movements will be stopped	A423		E	2
300030	ZE 3: system error OS-HC11 (observe parameters) unacceptable bank address entry in error memory, all crane movements will be stopped	A423		E	2
300041	ZE 3: system error OS-HC11 (observe parameters) arithmetic error entry in error memory, all crane movements will be stopped	A423		E	2
300044	ZE 3: system error OS-HC11 (observe parameters) output parameter without effect, from inactive output entry in error memory, all crane movements will be stopped	A423		E	2
300045	ZE 3: system error OS-HC11 (observe parameters) entry parameter undefined, from inactive input entry in error memory, all crane movements will be stopped	A423		E	2
300046	ZE 3: system error OS-HC11 (observe parameters) impermissible regulator parameter entry in error memory, all crane movements will be stopped	A423		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
300047	ZE 3: system error OS-HC11 (observe parameters) realtime-control block not available entry in error memory, all crane movements will be stopped	A423		E	2
300048	ZE 3: system error OS-HC11 (observe parameters) realtime-control block inactive entry in error memory, all crane movements will be stopped	A423		E	2
300049	ZE 3: system error OS-HC11 (observe parameters) urgent modul, ZE not available entry in error memory, no crane operation possible check ZE	A423		E	2
300050	ZE 3: system error OS-HC11 (observe parameters) file not available entry in error memory, all crane movements will be stopped	A423		E	2
300051	ZE 3: system error OS-HC11 (observe parameters) file already opened entry in error memory, all crane movements will be stopped	A423		E	2
300052	ZE 3: system error OS-HC11 (observe parameters) file not open on close entry in error memory, all crane movements will be stopped	A423		E	2
300053	ZE 3: system error OS-HC11 (observe parameters) system mask not available entry in error memory, all crane movements will be stopped	A423		E	2
300054	ZE 3: system error OS-HC11 (observe parameters) system text not available entry in error memory, all crane movements will be stopped	A423		E	2
300055	ZE 3: system error OS-HC11 (observe parameters) symbol not available entry in error memory, all crane movements will be stopped	A423		E	2
300056	ZE 3: system error OS-HC11 (observe parameters) invalid mark in symbol entry in error memory, all crane movements will be stopped	A423		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
300057	ZE 3: system error OS-HC11 (observe parameters) default load chart missing entry in error memory, all crane movements will be stopped	A423		E	2
300058	ZE 3: system error OS-HC11 (observe parameters) amplifier erroneous or return power feed entry in error memory, all crane movements will be stopped check wiring	A423		E	2
300059	ZE 3: system error OS-HC11 (observe parameters) subroutine not reentrant entry in error memory, all crane movements will be stopped	A423		E	2
300060	ZE 3: system error OS-HC11 (observe parameters) transmission error SCI entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A423		E	2
300061	ZE 3: system error OS-HC11 (observe parameters) SCI-BREAK entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A423		E	2
300062	ZE 3: system error OS-HC11 (observe parameters) SCI not connected entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A423		E	2
300063	ZE 3: system error OS-HC11 (observe parameters) monitor error in operation entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A423		E	2
300065	ZE 3: system error OS-HC11 (observe parameters) impermissible bus address entry in error memory, all crane movements will be stopped	A423		E	2
300066	ZE 3: system error OS-HC11 (observe parameters) ADC working outside the permissible tolerance entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A423		E	2
300067	ZE 3: system error OS-HC11 (observe parameters) arithmetic processor not available entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A423		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
300068	ZE 3: system error OS-HC11 (observe parameters) impermissible interrupt entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A423		E	2
300070	ZE 3: system error OS-HC11 (observe parameters) various structure versions entry in error memory, no crane operation possible	A423		E	2
300071	ZE 3: system error OS-HC11 (observe parameters) Structure file missing or faulty entry in error memory, no crane operation possible	A423		E	2
300072	ZE 3: system error OS-HC11 (observe parameters) structure entry senseless entry in error memory, no crane operation possible	A423		E	2
300073	ZE 3: system error OS-HC11 (observe parameters) interpreter error entry in error memory, all crane movements will be stopped	A423		E	2
300074	ZE 3: system error OS-HC11 (observe parameters) transformation ASCII to BIN erroneous entry in error memory, all crane movements will be stopped	A423		E	2
300075	ZE 3: system error OS-HC11 (observe parameters) SPI-error entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A423		E	2
300076	ZE 3: system error OS-HC11 (observe parameters) incorrectly inserted power unit entry in error memory, all crane movements will be stopped check memory card in power supply unit	A423		E	2
300077	ZE 3: system error OS-HC11 (observe parameters) BAF-call-up erroneous entry in error memory, all crane movements will be stopped	A423		E	2
300078	ZE 3: system error OS-HC11 (observe parameters) impermissible parameter entry in error memory, all crane movements will be stopped	A423		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
300079	ZE 3: system error OS-HC11 (observe parameters) no right of access entry in error memory, all crane movements will be stopped	A423		E	2
300080	ZE 3: system error OS-HC11 (observe parameters) Fatal internal error entry in error memory, all crane movements will be stopped	A423		E	2
300081	ZE 3: system error OS-HC11 (observe parameters) stack overflow entry in error memory, all crane movements will be stopped	A423		E	2
300082	ZE 3: system error OS-HC11 (observe parameters) hardware-watchdog erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A423		E	2
300094	ZE 3: system error OS-HC11 (observe parameters) transmission error parallel bus entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A423		E	2
300095	ZE 3: system error OS-HC11 (observe parameters) DMA-error entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A423		E	2
300099	ZE 3: system error OS-HC11 (observe parameters) DSP0 erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A423		E	2
302001	ZE 3: system error OS-TMS initialising error processor-register erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A423		E	2
302002	ZE 3: system error OS-TMS initialising error test total in EPROM/FLASH erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A423		E	2
302006	ZE 3: system error OS-TMS initialising error RAM erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A423		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
302007	ZE 3: system error OS-TMS UART erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A423		E	2
302020	ZE 3: system error OS-TMS task-watchdog expired entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A423		E	2
302021	ZE 3: system error OS-TMS illegal opcode trap entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A423		E	2
302082	ZE 3: system error OS-TMS hardware-watchdog erroneous entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A423		E	2
310012	ZE 3: output 0 short circuit to ground	A423.X1:16		E	1
310013	ZE 3: output 0 open signal circuits	A423.X1:16		E	1
310014	ZE 3: output 0 short circuit to supply voltage	A423.X1:16		E	1
310054	ZE 3: output 0 short circuit to supply voltage	A423.X1:16		E	1
310058	ZE 3: output 0 positive switching transistor: disruption	A423.X1:16		E	1
310060	ZE 3: output 0 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A423.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310062	ZE 3: output 0 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A423.X1:16		E	1
310063	ZE 3: output 0 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A423.X1:16		E	1
310070	ZE 3: output 0 measuring system defect no crane operation possible entry in error list	A423.X1:16		E	1
310071	ZE 3: output 0 short circuit to ground or transistor defect	A423.X1:16		E	1
310072	ZE 3: output 0 outside source feeding	A423.X1:16		E	1
310073	ZE 3: output 0 open circuit or short circuit to supply voltage/ground	A423.X1:16		E	1
310112	ZE 3: output 1 short circuit to ground	A423.X1:17		E	1
310113	ZE 3: output 1 open signal circuits	A423.X1:17		E	1
310114	ZE 3: output 1 short circuit to supply voltage	A423.X1:17		E	1
310154	ZE 3: output 1 short circuit to supply voltage	A423.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310158	ZE 3: output 1 positive switching transistor: disruption	A423.X1:17		E	1
310160	ZE 3: output 1 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A423.X1:17		E	1
310162	ZE 3: output 1 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A423.X1:17		E	1
310163	ZE 3: output 1 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A423.X1:17		E	1
310170	ZE 3: output 1 measuring system defect no crane operation possible entry in error list	A423.X1:17		E	1
310171	ZE 3: output 1 short circuit to ground or transistor defect	A423.X1:17		E	1
310172	ZE 3: output 1 outside source feeding	A423.X1:17		E	1
310173	ZE 3: output 1 open circuit or short circuit to supply voltage/ground	A423.X1:17		E	1
310212	ZE 3: output 2 short circuit to ground	A423.X1:18		E	1
310213	ZE 3: output 2 open signal circuits	A423.X1:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310214	ZE 3: output 2 short circuit to supply voltage	A423.X1:18		E	1
310254	ZE 3: output 2 short circuit to supply voltage	A423.X1:18		E	1
310258	ZE 3: output 2 positive switching transistor: disruption	A423.X1:18		E	1
310270	ZE 3: output 2 measuring system defect no crane operation possible entry in error list	A423.X1:18		E	1
310271	ZE 3: output 2 short circuit to ground or transistor defect	A423.X1:18		E	1
310272	ZE 3: output 2 outside source feeding	A423.X1:18		E	1
310273	ZE 3: output 2 open circuit or short circuit to supply voltage/ground	A423.X1:18		E	1
310312	ZE 3: output 3 short circuit to ground	A423.X1:19		E	1
310313	ZE 3: output 3 open signal circuits	A423.X1:19		E	1
310314	ZE 3: output 3 short circuit to supply voltage	A423.X1:19		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310354	ZE 3: output 3 short circuit to supply voltage	A423.X1:19		E	1
310358	ZE 3: output 3 positive switching transistor: disruption	A423.X1:19		E	1
310360	ZE 3: output 3 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A423.X1:19		E	1
310362	ZE 3: output 3 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A423.X1:19		E	1
310363	ZE 3: output 3 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A423.X1:19		E	1
310370	ZE 3: output 3 measuring system defect no crane operation possible entry in error list	A423.X1:19		E	1
310371	ZE 3: output 3 short circuit to ground or transistor defect	A423.X1:19		E	1
310372	ZE 3: output 3 outside source feeding	A423.X1:19		E	1
310373	ZE 3: output 3 open circuit or short circuit to supply voltage/ground	A423.X1:19		E	1
310412	ZE 3: output 4 short circuit to ground	A423.X1:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310413	ZE 3: output 4 open signal circuits	A423.X1:20		E	1
310414	ZE 3: output 4 short circuit to supply voltage	A423.X1:20		E	1
310454	ZE 3: output 4 short circuit to supply voltage	A423.X1:20		E	1
310458	ZE 3: output 4 positive switching transistor: disruption	A423.X1:20		E	1
310460	ZE 3: output 4 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A423.X1:20		E	1
310462	ZE 3: output 4 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A423.X1:20		E	1
310463	ZE 3: output 4 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A423.X1:20		E	1
310470	ZE 3: output 4 measuring system defect no crane operation possible entry in error list	A423.X1:20		E	1
310471	ZE 3: output 4 short circuit to ground or transistor defect	A423.X1:20		E	1
310472	ZE 3: output 4 outside source feeding	A423.X1:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310473	ZE 3: output 4 open circuit or short circuit to supply voltage/ground	A423.X1:20		E	1
310512	ZE 3: output 5 short circuit to ground	A423.X1:21		E	1
310513	ZE 3: output 5 open signal circuits	A423.X1:21		E	1
310514	ZE 3: output 5 short circuit to supply voltage	A423.X1:21		E	1
310554	ZE 3: output 5 short circuit to supply voltage	A423.X1:21		E	1
310558	ZE 3: output 5 positive switching transistor: disruption	A423.X1:21		E	1
310560	ZE 3: output 5 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A423.X1:21		E	1
310562	ZE 3: output 5 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A423.X1:21		E	1
310563	ZE 3: output 5 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A423.X1:21		E	1
310570	ZE 3: output 5 measuring system defect no crane operation possible entry in error list	A423.X1:21		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310571	ZE 3: output 5 short circuit to ground or transistor defect	A423.X1:21		E	1
310572	ZE 3: output 5 outside source feeding	A423.X1:21		E	1
310573	ZE 3: output 5 open circuit or short circuit to supply voltage/ground	A423.X1:21		E	1
310612	ZE 3: output 6 short circuit to ground	A423.X1:22		E	1
310613	ZE 3: output 6 open signal circuits	A423.X1:22		E	1
310614	ZE 3: output 6 short circuit to supply voltage	A423.X1:22		E	1
310654	ZE 3: output 6 short circuit to supply voltage	A423.X1:22		E	1
310658	ZE 3: output 6 positive switching transistor: disruption	A423.X1:22		E	1
310670	ZE 3: output 6 measuring system defect no crane operation possible entry in error list	A423.X1:22		E	1
310671	ZE 3: output 6 short circuit to ground or transistor defect	A423.X1:22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310672	ZE 3: output 6 outside source feeding	A423.X1:22		E	1
310673	ZE 3: output 6 open circuit or short circuit to supply voltage/ground	A423.X1:22		E	1
310712	ZE 3: output 7 short circuit to ground	A423.X1:23		E	1
310713	ZE 3: output 7 open signal circuits	A423.X1:23		E	1
310714	ZE 3: output 7 short circuit to supply voltage	A423.X1:23		E	1
310754	ZE 3: output 7 short circuit to supply voltage	A423.X1:23		E	1
310758	ZE 3: output 7 positive switching transistor: disruption	A423.X1:23		E	1
310760	ZE 3: output 7 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A423.X1:23		E	1
310762	ZE 3: output 7 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A423.X1:23		E	1
310763	ZE 3: output 7 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A423.X1:23		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
310770	ZE 3: output 7 measuring system defect no crane operation possible entry in error list	A423.X1:23		E	1
310771	ZE 3: output 7 short circuit to ground or transistor defect	A423.X1:23		E	1
310772	ZE 3: output 7 outside source feeding	A423.X1:23		E	1
310773	ZE 3: output 7 open circuit or short circuit to supply voltage/ground	A423.X1:23		E	1
314959	ZE 3: all output supply voltage missing	A423		E	1
315059	ZE 3: output group 0 supply voltage missing	A423.X1:12		E	1
315159	ZE 3: output group 1 supply voltage missing	A423.X1:24		E	1
315259	ZE 3: output group 2 supply voltage missing	A423		E	1
315359	ZE 3: output group 3 supply voltage missing	A423		E	1
320004	ZE 3: LSB participant address 0 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
320005	ZE 3: LSB participant address 0 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
320018	ZE 3: LSB participant address 0 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
320050	ZE 3: LSB participant address 0 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
320051	ZE 3: LSB participant address 0 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
320053	ZE 3: LSB participant address 0 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
320054	ZE 3: LSB participant address 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
320064	ZE 3: LSB participant address 0 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
320065	ZE 3: LSB participant address 0 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
320066	ZE 3: LSB participant address 0 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
320067	ZE 3: LSB participant address 0 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
320104	ZE 3: LSB participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
320105	ZE 3: LSB participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
320118	ZE 3: LSB participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
320150	ZE 3: LSB participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
320151	ZE 3: LSB participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
320153	ZE 3: LSB participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
320154	ZE 3: LSB participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
320164	ZE 3: LSB participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
320165	ZE 3: LSB participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
320166	ZE 3: LSB participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
320167	ZE 3: LSB participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
320204	ZE 3: LSB participant address 2 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
320205	ZE 3: LSB participant address 2 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
320218	ZE 3: LSB participant address 2 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
320250	ZE 3: LSB participant address 2 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
320251	ZE 3: LSB participant address 2 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
320253	ZE 3: LSB participant address 2 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
320254	ZE 3: LSB participant address 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
320264	ZE 3: LSB participant address 2 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
320265	ZE 3: LSB participant address 2 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
320266	ZE 3: LSB participant address 2 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
320267	ZE 3: LSB participant address 2 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
320804	ZE 3: LSB participant address 8 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
320805	ZE 3: LSB participant address 8 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
320818	ZE 3: LSB participant address 8 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
320850	ZE 3: LSB participant address 8 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
320851	ZE 3: LSB participant address 8 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
320853	ZE 3: LSB participant address 8 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
320854	ZE 3: LSB participant address 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
320864	ZE 3: LSB participant address 8 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
320865	ZE 3: LSB participant address 8 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
320866	ZE 3: LSB participant address 8 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
320867	ZE 3: LSB participant address 8 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
320904	ZE 3: LSB participant address 9 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
320905	ZE 3: LSB participant address 9 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
320918	ZE 3: LSB participant address 9 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
320950	ZE 3: LSB participant address 9 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
320951	ZE 3: LSB participant address 9 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
320953	ZE 3: LSB participant address 9 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
320954	ZE 3: LSB participant address 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
320964	ZE 3: LSB participant address 9 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
320965	ZE 3: LSB participant address 9 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
320966	ZE 3: LSB participant address 9 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
320967	ZE 3: LSB participant address 9 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321004	ZE 3: LSB participant address 10 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321005	ZE 3: LSB participant address 10 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321018	ZE 3: LSB participant address 10 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321050	ZE 3: LSB participant address 10 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321051	ZE 3: LSB participant address 10 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321053	ZE 3: LSB participant address 10 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321054	ZE 3: LSB participant address 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321064	ZE 3: LSB participant address 10 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321065	ZE 3: LSB participant address 10 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321066	ZE 3: LSB participant address 10 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321067	ZE 3: LSB participant address 10 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321104	ZE 3: LSB participant address 11 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321105	ZE 3: LSB participant address 11 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321118	ZE 3: LSB participant address 11 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321150	ZE 3: LSB participant address 11 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321151	ZE 3: LSB participant address 11 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321153	ZE 3: LSB participant address 11 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321154	ZE 3: LSB participant address 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321164	ZE 3: LSB participant address 11 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321165	ZE 3: LSB participant address 11 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321166	ZE 3: LSB participant address 11 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321167	ZE 3: LSB participant address 11 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321204	ZE 3: LSB participant address 12 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321205	ZE 3: LSB participant address 12 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321218	ZE 3: LSB participant address 12 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321250	ZE 3: LSB participant address 12 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321251	ZE 3: LSB participant address 12 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321253	ZE 3: LSB participant address 12 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321254	ZE 3: LSB participant address 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321264	ZE 3: LSB participant address 12 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321265	ZE 3: LSB participant address 12 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321266	ZE 3: LSB participant address 12 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321267	ZE 3: LSB participant address 12 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321304	ZE 3: LSB participant address 13 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321305	ZE 3: LSB participant address 13 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321318	ZE 3: LSB participant address 13 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321350	ZE 3: LSB participant address 13 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321351	ZE 3: LSB participant address 13 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321353	ZE 3: LSB participant address 13 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321354	ZE 3: LSB participant address 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321364	ZE 3: LSB participant address 13 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321365	ZE 3: LSB participant address 13 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321366	ZE 3: LSB participant address 13 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321367	ZE 3: LSB participant address 13 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321404	ZE 3: LSB participant address 14 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321405	ZE 3: LSB participant address 14 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321418	ZE 3: LSB participant address 14 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321450	ZE 3: LSB participant address 14 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321451	ZE 3: LSB participant address 14 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321453	ZE 3: LSB participant address 14 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321454	ZE 3: LSB participant address 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321464	ZE 3: LSB participant address 14 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321465	ZE 3: LSB participant address 14 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321466	ZE 3: LSB participant address 14 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321467	ZE 3: LSB participant address 14 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321504	ZE 3: LSB participant address 15 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321505	ZE 3: LSB participant address 15 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321518	ZE 3: LSB participant address 15 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321550	ZE 3: LSB participant address 15 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321551	ZE 3: LSB participant address 15 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321553	ZE 3: LSB participant address 15 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321554	ZE 3: LSB participant address 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321564	ZE 3: LSB participant address 15 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321565	ZE 3: LSB participant address 15 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321566	ZE 3: LSB participant address 15 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321567	ZE 3: LSB participant address 15 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321604	ZE 3: LSB participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321605	ZE 3: LSB participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321618	ZE 3: LSB participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321650	ZE 3: LSB participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321651	ZE 3: LSB participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321653	ZE 3: LSB participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321654	ZE 3: LSB participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321664	ZE 3: LSB participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321665	ZE 3: LSB participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321666	ZE 3: LSB participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321667	ZE 3: LSB participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321704	ZE 3: LSB participant address 17 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321705	ZE 3: LSB participant address 17 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321718	ZE 3: LSB participant address 17 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321750	ZE 3: LSB participant address 17 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321751	ZE 3: LSB participant address 17 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321753	ZE 3: LSB participant address 17 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321754	ZE 3: LSB participant address 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321764	ZE 3: LSB participant address 17 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321765	ZE 3: LSB participant address 17 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321766	ZE 3: LSB participant address 17 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321767	ZE 3: LSB participant address 17 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321804	ZE 3: LSB participant address 18 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321805	ZE 3: LSB participant address 18 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321818	ZE 3: LSB participant address 18 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321850	ZE 3: LSB participant address 18 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321851	ZE 3: LSB participant address 18 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321853	ZE 3: LSB participant address 18 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321854	ZE 3: LSB participant address 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
321864	ZE 3: LSB participant address 18 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321865	ZE 3: LSB participant address 18 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321866	ZE 3: LSB participant address 18 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321867	ZE 3: LSB participant address 18 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
321904	ZE 3: LSB participant address 19 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
321905	ZE 3: LSB participant address 19 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
321918	ZE 3: LSB participant address 19 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
321950	ZE 3: LSB participant address 19 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
321951	ZE 3: LSB participant address 19 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
321953	ZE 3: LSB participant address 19 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
321954	ZE 3: LSB participant address 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
321964	ZE 3: LSB participant address 19 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
321965	ZE 3: LSB participant address 19 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
321966	ZE 3: LSB participant address 19 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
321967	ZE 3: LSB participant address 19 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322004	ZE 3: LSB participant address 20 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322005	ZE 3: LSB participant address 20 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322018	ZE 3: LSB participant address 20 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322050	ZE 3: LSB participant address 20 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322051	ZE 3: LSB participant address 20 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322053	ZE 3: LSB participant address 20 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322054	ZE 3: LSB participant address 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322064	ZE 3: LSB participant address 20 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322065	ZE 3: LSB participant address 20 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322066	ZE 3: LSB participant address 20 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322067	ZE 3: LSB participant address 20 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322104	ZE 3: LSB participant address 21 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322105	ZE 3: LSB participant address 21 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322118	ZE 3: LSB participant address 21 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322150	ZE 3: LSB participant address 21 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322151	ZE 3: LSB participant address 21 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322153	ZE 3: LSB participant address 21 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322154	ZE 3: LSB participant address 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322164	ZE 3: LSB participant address 21 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322165	ZE 3: LSB participant address 21 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322166	ZE 3: LSB participant address 21 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322167	ZE 3: LSB participant address 21 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322204	ZE 3: LSB participant address 22 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322205	ZE 3: LSB participant address 22 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322218	ZE 3: LSB participant address 22 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322250	ZE 3: LSB participant address 22 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322251	ZE 3: LSB participant address 22 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322253	ZE 3: LSB participant address 22 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322254	ZE 3: LSB participant address 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322264	ZE 3: LSB participant address 22 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322265	ZE 3: LSB participant address 22 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322266	ZE 3: LSB participant address 22 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322267	ZE 3: LSB participant address 22 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322304	ZE 3: LSB participant address 23 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322305	ZE 3: LSB participant address 23 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322318	ZE 3: LSB participant address 23 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322350	ZE 3: LSB participant address 23 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322351	ZE 3: LSB participant address 23 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322353	ZE 3: LSB participant address 23 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322354	ZE 3: LSB participant address 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322364	ZE 3: LSB participant address 23 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322365	ZE 3: LSB participant address 23 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322366	ZE 3: LSB participant address 23 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322367	ZE 3: LSB participant address 23 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322404	ZE 3: LSB participant address 24 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322405	ZE 3: LSB participant address 24 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322418	ZE 3: LSB participant address 24 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322450	ZE 3: LSB participant address 24 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322451	ZE 3: LSB participant address 24 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322453	ZE 3: LSB participant address 24 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322454	ZE 3: LSB participant address 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322464	ZE 3: LSB participant address 24 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322465	ZE 3: LSB participant address 24 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322466	ZE 3: LSB participant address 24 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322467	ZE 3: LSB participant address 24 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322504	ZE 3: LSB participant address 25 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322505	ZE 3: LSB participant address 25 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322518	ZE 3: LSB participant address 25 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322550	ZE 3: LSB participant address 25 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322551	ZE 3: LSB participant address 25 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322553	ZE 3: LSB participant address 25 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322554	ZE 3: LSB participant address 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322564	ZE 3: LSB participant address 25 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322565	ZE 3: LSB participant address 25 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322566	ZE 3: LSB participant address 25 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322567	ZE 3: LSB participant address 25 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322604	ZE 3: LSB participant address 26 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322605	ZE 3: LSB participant address 26 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322618	ZE 3: LSB participant address 26 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322650	ZE 3: LSB participant address 26 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322651	ZE 3: LSB participant address 26 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322653	ZE 3: LSB participant address 26 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322654	ZE 3: LSB participant address 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322664	ZE 3: LSB participant address 26 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322665	ZE 3: LSB participant address 26 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322666	ZE 3: LSB participant address 26 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322667	ZE 3: LSB participant address 26 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322704	ZE 3: LSB participant address 27 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322705	ZE 3: LSB participant address 27 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322718	ZE 3: LSB participant address 27 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322750	ZE 3: LSB participant address 27 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322751	ZE 3: LSB participant address 27 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322753	ZE 3: LSB participant address 27 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322754	ZE 3: LSB participant address 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322764	ZE 3: LSB participant address 27 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322765	ZE 3: LSB participant address 27 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322766	ZE 3: LSB participant address 27 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322767	ZE 3: LSB participant address 27 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322804	ZE 3: LSB participant address 28 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322805	ZE 3: LSB participant address 28 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322818	ZE 3: LSB participant address 28 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322850	ZE 3: LSB participant address 28 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322851	ZE 3: LSB participant address 28 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322853	ZE 3: LSB participant address 28 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322854	ZE 3: LSB participant address 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
322864	ZE 3: LSB participant address 28 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322865	ZE 3: LSB participant address 28 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322866	ZE 3: LSB participant address 28 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322867	ZE 3: LSB participant address 28 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
322904	ZE 3: LSB participant address 29 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
322905	ZE 3: LSB participant address 29 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
322918	ZE 3: LSB participant address 29 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
322950	ZE 3: LSB participant address 29 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
322951	ZE 3: LSB participant address 29 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
322953	ZE 3: LSB participant address 29 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1
322954	ZE 3: LSB participant address 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
322964	ZE 3: LSB participant address 29 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
322965	ZE 3: LSB participant address 29 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
322966	ZE 3: LSB participant address 29 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
322967	ZE 3: LSB participant address 29 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
323004	ZE 3: LSB participant address 30 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A423.X2:z14/z16		E	1
323005	ZE 3: LSB participant address 30 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A423.X2:z14/z16		E	1
323018	ZE 3: LSB participant address 30 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A423.X2:z14/z16		E	0
323050	ZE 3: LSB participant address 30 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A423.X2:z14/z16		E	2
323051	ZE 3: LSB participant address 30 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A423.X2:z14/z16		E	2
323053	ZE 3: LSB participant address 30 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A423.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
323054	ZE 3: LSB participant address 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A423.X2:z14/z16		E	2
323064	ZE 3: LSB participant address 30 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A423.X2:z14/z16		E	1
323065	ZE 3: LSB participant address 30 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A423.X2:z14/z16		E	2
323066	ZE 3: LSB participant address 30 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A423.X2:z14/z16		E	2
323067	ZE 3: LSB participant address 30 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A423.X2:z14/z16		E	1
323252	ZE 3: Control data transfer LSB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A423.X2:z14/z16		E	0
323255	ZE 3: Control data transfer LSB Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A423.X2:z14/z16		E	2
323256	ZE 3: Control data transfer LSB Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A423.X2:z14/z16		E	2
323257	ZE 3: Control data transfer LSB has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A423.X2:z14/z16		E	1
323258	ZE 3: Control data transfer LSB recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A423.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
323259	ZE 3: Control data transfer LSB recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A423.X2:z14/z16		E	0
323260	ZE 3: Control data transfer LSB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A423.X2:z14/z16		E	2
323261	ZE 3: Control data transfer LSB driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A423.X2:z14/z16		E	2
323262	ZE 3: Control data transfer LSB Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A423.X2:z14/z16		E	2
324814	ZE 3: input 0 short circuit to supply voltage Output of error Check: the sensor line for short-circuits, faulty sensors by pulling out the sensor, connections to the input plate	A423.X2:d2		E	1
324856	ZE 3: input 0 open circuit or short circuit to ground Output of error Check: Supply voltage, input LICCON, sensor lines for interruptions, faulty sensors by pulling out the sensor	A423.X2:d2		E	1
324914	ZE 3: input 1 short circuit to supply voltage Output of error Check: the sensor line for short-circuits, faulty sensors by pulling out the sensor, connections to the input plate	A423.X2:d4		E	1
324956	ZE 3: input 1 open circuit or short circuit to ground Output of error Check: Supply voltage, input LICCON, sensor lines for interruptions, faulty sensors by pulling out the sensor	A423.X2:d4		E	1
332200	ZE 3: control winch 3 no slewing movement recognized on actuated winch output of error check LICCON output, lines for short or break, incremental sensor on function, hoisting gear brake	A423		E	1
332202	ZE 3: control winch 3 hydraulic circuit pressure sensor defective/missing if valid winch torque for LMB is available this will be used, otherwise 0 bar is loaded into pressure value memory check supply, LICCON input, sensor lines to short or break, sensor	A423		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
332218	ZE 3: control winch 3 Pressure too high when pump is not actuated Output of error Check pump or pressure sensor	A423		E	
332227	ZE 3: control winch 3 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A423		E	1
33222D	ZE 3: control winch 3 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A423		E	1
33222F	ZE 3: control winch 3 Repl. Pr. Switch continuous actuation or short circuit after VCC output of error Check: - input LICCON, line for short circuit after supply voltage, pressure switch for function	A423		E	1
332241	ZE 3: control winch 3 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A423		E	1
332242	ZE 3: control winch 3 Rotation movement at non-actuated winch brake error report Check winch brake. Check winch turn sensor(installation)	A423		E	1
332300	ZE 3: control winch 4 no slewing movement recognized on actuated winch output of error check LICCON output, lines for short or break, incremental sensor on function, hoisting gear brake	A423		E	1
332302	ZE 3: control winch 4 hydraulic circuit pressure sensor defective/missing if valid winch torque for LMB is available this will be used, otherwise 0 bar is loaded into pressure value memory check supply, LICCON input, sensor lines to short or break, sensor	A423		E	1
332318	ZE 3: control winch 4 Pressure too high when pump is not actuated Output of error Check pump or pressure sensor	A423		E	
332327	ZE 3: control winch 4 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A423		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
33232D	ZE 3: control winch 4 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A423		E	1
33232F	ZE 3: control winch 4 Repl. Pr. Switch continuous actuation or short circuit after VCC output of error Check: - input LICCON, line for short circuit after supply voltage, pressure switch for function	A423		E	1
332341	ZE 3: control winch 4 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A423		E	1
332342	ZE 3: control winch 4 Rotation movement at non-actuated winch brake error report Check winch brake. Check winch turn sensor(installation)	A423		E	1
332500	ZE 3: control winch 6 no slewing movement recognized on actuated winch output of error check LICCON output, lines for short or break, incremental sensor on function, hoisting gear brake	A423		E	1
332502	ZE 3: control winch 6 hydraulic circuit pressure sensor defective/missing if valid winch torque for LMB is available this will be used, otherwise 0 bar is loaded into pressure value memory check supply, LICCON input, sensor lines to short or break, sensor	A423		E	1
332518	ZE 3: control winch 6 Pressure too high when pump is not actuated Output of error Check pump or pressure sensor	A423		E	
332527	ZE 3: control winch 6 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A423		E	1
33252D	ZE 3: control winch 6 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A423		E	1
33252F	ZE 3: control winch 6 Repl. Pr. Switch continuous actuation or short circuit after VCC output of error Check: - input LICCON, line for short circuit after supply voltage, pressure switch for function	A423		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
332541	ZE 3: control winch 6 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A423		E	1
332542	ZE 3: control winch 6 Rotation movement at non-actuated winch brake error report Check winch brake. Check winch turn sensor(installation)	A423		E	1
335201	ZE 3: operation winch 3 feed pressure supply missing/too low Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A423		B	
335203	ZE 3: operation winch 3 Shut-down jib lower Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335204	ZE 3: operation winch 3 unreeled winch shut-down Operation conditional switch off, may not be shunted reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A423		B	
335205	ZE 3: operation winch 3 reeled winch shut-down Operation conditional switch off, may not be shunted reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A423		B	
335206	ZE 3: operation winch 3 upper angle limit OGW shut-down operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A423		B	
335207	ZE 3: operation winch 3 lower angle limit UGW shut-down operational shut down reel winch in until the radius is within the load chart again - shut-down can be shunted (danger)	A423		B	
335208	ZE 3: operation winch 3 luffing up main boom shut-down working area limitation ABB operational shut down reel winch out until crane in working area again - shunting through shutting down of working area limitation	A423		B	
335209	ZE 3: operation winch 3 luffing down main boom shut-down working area limitation ABB operational shut down reel winch in until crane in working area again - shunting through shutting down of working area limitation	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335210	ZE 3: operation winch 3 fly jib upper stop shut-down Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335211	ZE 3: operation winch 3 fly jib upper flap shut-down Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335213	ZE 3: operation winch 3 shut-down as flap not positioned and angle threshold exceeded Operation conditional switch off, may not be shunted check as to why the flap is not in position - shut-down cannot be shunted	A423		B	
335219	ZE 3: operation winch 3 no or invalid operation mode shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A423		B	
335220	ZE 3: operation winch 3 LMB shut-down operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A423		B	
335221	ZE 3: operation winch 3 Shut-down measuring point 1 > F max - operation operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A423		B	
335222	ZE 3: operation winch 3 Shut-down measuring point 1 > F max - assembly Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A423		B	
335224	ZE 3: operation winch 3 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A423		B	
335226	ZE 3: operation winch 3 Shut-down upper limit angle derrick OGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A423		B	
335227	ZE 3: operation winch 3 Shut-down lower limit angle derrick UGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335228	ZE 3: operation winch 3 Shut-down upper limit angle main boom operational shut down Wind on winch until limit angle is fallen short of - shut-down may be shunted (danger).	A423		B	
335229	ZE 3: operation winch 3 winch blocked (C-key monitor) Operation conditional switch off, may not be shunted Authorise winch 3 in control diagram.	A423		B	
33522B	ZE 3: operation winch 3 Shut off Derrick ballast pulled > Derrick ballast max operational shut down Fix cause of "LMB Stop", see error message. Lift shut off is bypassable with "luff up at overload"	A423		B	
335230	ZE 3: operation winch 3 master switch 1 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
335232	ZE 3: operation winch 3 master switch 3 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
335234	ZE 3: operation winch 3 Shut-down limit angle main boom - derrick Operation conditional switch off, may not be shunted Wind on winch until limit angle is fallen short of - shut-down may be shunted.	A423		B	
335239	ZE 3: operation winch 3 seat contact shut-down operational shut down Sit down or actuate one of the shunting switches for the seat contact in the master switches.	A423		B	
33523E	ZE 3: operation winch 3 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A423		B	1
335244	ZE 3: operation winch 3 Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A423		B	
335250	ZE 3: operation winch 3 end of stroke switch shut-down 1 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335251	ZE 3: operation winch 3 end of stroke switch shut-down 2 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	
335252	ZE 3: operation winch 3 end of stroke switch shut-down 3 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	
335254	ZE 3: operation winch 3 Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335257	ZE 3: operation winch 3 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - luffing down of main boom possible.	A423		B	
335263	ZE 3: operation winch 3 Crane engine in overspeed Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A423		B	
335266	ZE 3: operation winch 3 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335267	ZE 3: operation winch 3 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335270	ZE 3: operation winch 3 shut-down both limit switches "flap in position" defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335272	ZE 3: operation winch 3 shut-down both angle sensors "fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335273	ZE 3: operation winch 3 shut-down both limit switches "lower fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335274	ZE 3: operation winch 3 shut-down both limit switches "upper fly jib flap" defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335275	ZE 3: operation winch 3 shut-down both limit switches "upper fly jib stop"defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
33527A	ZE 3: operation winch 3 Shut off Radio assembly BTT-E Main boom angle exceeded	A423		B	
33527C	ZE 3: operation winch 3 Shut off Radio assembly BTT-E Accessory angle exceeded	A423		B	
335281	ZE 3: operation winch 3 end of stroke switch 1 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
335282	ZE 3: operation winch 3 end of stroke switch 2 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
335283	ZE 3: operation winch 3 end of stroke switch 3 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
335285	ZE 3: operation winch 3 Shut-down limit switch right "RFP main boom" faulty / not present Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335286	ZE 3: operation winch 3 Shut-down limit switch "RFP Main boom" links faulty / not present Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335298	ZE 3: operation winch 3 Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
33529A	ZE 3: operation winch 3 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders main boom	A423		B	
33529B	ZE 3: operation winch 3 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders Derrick	A423		B	
3352B3	ZE 3: operation winch 3 Shut off Test point 1 < F min and upper limit angle Derrick OGWD operational shut down If possible, move derrick boom in op. position, for that assembly - winch 4 can be lowered	A423		B	
3352B5	ZE 3: operation winch 3 Master switch right BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
3352BE	ZE 3: operation winch 3 Shut off upper limit shut off angle main boom (load chart) Operation conditional switch off, may not be shunted Luff main b. down until no shut off - shut off cannot be bypassed	A423		B	
3352C6	ZE 3: operation winch 3 Shut-off test point 3 < F min Operation conditional switch off, may not be shunted Lower load or lower derrick ballast if possible or spool out retraction gear if possible.	A423		B	
335301	ZE 3: operation winch 4 feed pressure supply missing/too low Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A423		B	
335303	ZE 3: operation winch 4 Shut-down jib lower Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335306	ZE 3: operation winch 4 upper angle limit OGW shut-down operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A423		B	
335307	ZE 3: operation winch 4 lower angle limit UGW shut-down operational shut down reel winch in until the radius is within the load chart again - shut-down can be shunted (danger)	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335308	ZE 3: operation winch 4 luffing up main boom shut-down working area limitation ABB operational shut down reel winch out until crane in working area again - shunting through shutting down of working area limitation	A423		B	
335309	ZE 3: operation winch 4 luffing down main boom shut-down working area limitation ABB operational shut down reel winch in until crane in working area again - shunting through shutting down of working area limitation	A423		B	
335310	ZE 3: operation winch 4 fly jib upper stop shut-down Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335311	ZE 3: operation winch 4 fly jib upper flap shut-down Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335313	ZE 3: operation winch 4 shut-down as flap not positioned and angle threshold exceeded Operation conditional switch off, may not be shunted check as to why the flap is not in position - shut-down cannot be shunted	A423		B	
335318	ZE 3: operation winch 4 Shut-down measuring point 1 < F min operational shut down Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A423		B	
335319	ZE 3: operation winch 4 no or invalid operation mode shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A423		B	
335320	ZE 3: operation winch 4 LMB shut-down operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A423		B	
335321	ZE 3: operation winch 4 Shut-down measuring point 1 > F max - operation operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A423		B	
335322	ZE 3: operation winch 4 Shut-down measuring point 1 > F max - assembly Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335324	ZE 3: operation winch 4 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A423		B	
335325	ZE 3: operation winch 4 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Set down derrick counterweight on ground, if not possible unload derrick counterweight, until forces in desired range	A423		B	
335326	ZE 3: operation winch 4 Shut-down upper limit angle derrick OGWD operational shut down Wind on winch until derrick boom is in operating position - shut-down may be shunted (danger).	A423		B	
335327	ZE 3: operation winch 4 Shut-down lower limit angle derrick UGWD operational shut down Wind off winch until derrick boom is in operating position - shut-down may be shunted (danger).	A423		B	
335328	ZE 3: operation winch 4 Shut-down upper limit angle main boom operational shut down Wind on winch until limit angle is fallen short of - shut-down may be shunted (danger).	A423		B	
335329	ZE 3: operation winch 4 winch blocked (C-key monitor) Operation conditional switch off, may not be shunted Authorise winch 4 in control diagram.	A423		B	
33532B	ZE 3: operation winch 4 Shut off Derrick ballast pulled > Derrick ballast max Operation conditional switch off, may not be shunted Fix cause of "LMB Stop", see error message	A423		B	
335330	ZE 3: operation winch 4 master switch 1 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
335332	ZE 3: operation winch 4 master switch 3 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
335339	ZE 3: operation winch 4 seat contact shut-down operational shut down Sit down or actuate one of the shunting switches for the seat contact in the master switches.	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
33533E	ZE 3: operation winch 4 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A423		B	1
335344	ZE 3: operation winch 4 Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A423		B	
335350	ZE 3: operation winch 4 end of stroke switch shut-down 1 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	
335351	ZE 3: operation winch 4 end of stroke switch shut-down 2 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	
335352	ZE 3: operation winch 4 end of stroke switch shut-down 3 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	
335354	ZE 3: operation winch 4 Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335355	ZE 3: operation winch 4 Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Luff down derrick boom until limit switch no longer activated - Shut-down may not be shunted	A423		B	
335356	ZE 3: operation winch 4 Shut-down angle SA-frame < minimal angle Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
335357	ZE 3: operation winch 4 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A423		B	
335363	ZE 3: operation winch 4 Crane engine in overspeed Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335366	ZE 3: operation winch 4 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335367	ZE 3: operation winch 4 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335370	ZE 3: operation winch 4 shut-down both limit switches "flap in position" defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335372	ZE 3: operation winch 4 shut-down both angle sensors "fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335373	ZE 3: operation winch 4 shut-down both limit switches "lower fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335374	ZE 3: operation winch 4 shut-down both limit switches "upper fly jib flap" defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335375	ZE 3: operation winch 4 shut-down both limit switches "upper fly jib stop"defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
33537A	ZE 3: operation winch 4 Shut off Radio assembly BTT-E Main boom angle exceeded	A423		B	
33537B	ZE 3: operation winch 4 Shut off Radio assembly BTT-E Derrick angle exceeded	A423		B	
33537C	ZE 3: operation winch 4 Shut off Radio assembly BTT-E Accessory angle exceeded	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335381	ZE 3: operation winch 4 end of stroke switch 1 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
335382	ZE 3: operation winch 4 end of stroke switch 2 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
335383	ZE 3: operation winch 4 end of stroke switch 3 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
335385	ZE 3: operation winch 4 Shut-down limit switch right "RFP main boom" faulty / not present Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335386	ZE 3: operation winch 4 Shut-down limit switch "RFP Main boom" links faulty / not present Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335387	ZE 3: operation winch 4 Shut-down limit switch right "Overtop guard cyl D" faulty/not pres Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335388	ZE 3: operation winch 4 Shut-down limit switch left "Overtop guard cyl D" faulty/not preS Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335391	ZE 3: operation winch 4 Shut-down limit switch right "Limit angle SA-frame" faulty/not pres Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335392	ZE 3: operation winch 4 Shut-down limit switch left "Limit angle SA-frame" faulty/not prese Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
335398	ZE 3: operation winch 4 Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335399	ZE 3: operation winch 4 Shut off pressure Relapse cyl. derrick outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
33539A	ZE 3: operation winch 4 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders main boom	A423		B	
33539B	ZE 3: operation winch 4 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders Derrick	A423		B	
3353B3	ZE 3: operation winch 4 Shut off Test point 1 < F min and upper limit angle Derrick OGWD operational shut down If possible, move derrick boom in op. position, for that assembly - winch 4 can be lowered	A423		B	
3353B5	ZE 3: operation winch 4 Master switch right BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
3353BE	ZE 3: operation winch 4 Shut off upper limit shut off angle main boom (load chart) Operation conditional switch off, may not be shunted Luff main b. down until no shut off - shut off cannot be bypassed	A423		B	
3353C6	ZE 3: operation winch 4 Shut-off test point 3 < F min Operation conditional switch off, may not be shunted Lower load or lower derrick ballast if possible or spool out retraction gear if possible.	A423		B	
335501	ZE 3: operation winch 6 feed pressure supply missing/too low Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A423		B	
335504	ZE 3: operation winch 6 unreeled winch shut-down Operation conditional switch off, may not be shunted reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A423		B	
335505	ZE 3: operation winch 6 reeled winch shut-down Operation conditional switch off, may not be shunted reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335519	ZE 3: operation winch 6 no or invalid operation mode shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A423		B	
335520	ZE 3: operation winch 6 LMB shut-down operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A423		B	
335521	ZE 3: operation winch 6 Shut-down measuring point 1 > F max - operation operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A423		B	
335522	ZE 3: operation winch 6 Shut-down measuring point 1 > F max - assembly Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A423		B	
335524	ZE 3: operation winch 6 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A423		B	
335525	ZE 3: operation winch 6 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Set down derrick counterweight on ground, if not possible unload derrick counterweight, until forces in desired range	A423		B	
335526	ZE 3: operation winch 6 Shut-down upper limit angle derrick OGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A423		B	
335527	ZE 3: operation winch 6 Shut-down lower limit angle derrick UGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A423		B	
335529	ZE 3: operation winch 6 winch blocked (C-key monitor) Operation conditional switch off, may not be shunted Authorise winch 6 in control diagram.	A423		B	
33552B	ZE 3: operation winch 6 Shut off Derrick ballast pulled > Derrick ballast max Operation conditional switch off, may not be shunted Fix cause of "LMB Stop", see error message	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335531	ZE 3: operation winch 6 master switch 2 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
335539	ZE 3: operation winch 6 seat contact shut-down operational shut down Sit down or actuate one of the shunting switches for the seat contact in the master switches.	A423		B	
33553E	ZE 3: operation winch 6 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A423		B	1
335544	ZE 3: operation winch 6 Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A423		B	
335550	ZE 3: operation winch 6 end of stroke switch shut-down 1 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	
335551	ZE 3: operation winch 6 end of stroke switch shut-down 2 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	
335552	ZE 3: operation winch 6 end of stroke switch shut-down 3 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A423		B	
335557	ZE 3: operation winch 6 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders SA-frame	A423		B	
335563	ZE 3: operation winch 6 Crane engine in overspeed Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A423		B	
335566	ZE 3: operation winch 6 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335567	ZE 3: operation winch 6 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A423		B	
33557A	ZE 3: operation winch 6 Shut off Radio assembly BTT-E Main boom angle exceeded	A423		B	
33557C	ZE 3: operation winch 6 Shut off Radio assembly BTT-E Accessory angle exceeded	A423		B	
335581	ZE 3: operation winch 6 end of stroke switch 1 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
335582	ZE 3: operation winch 6 end of stroke switch 2 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
335583	ZE 3: operation winch 6 end of stroke switch 3 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A423		B	
33559A	ZE 3: operation winch 6 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders main boom	A423		B	
33559B	ZE 3: operation winch 6 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders Derrick	A423		B	
3355B3	ZE 3: operation winch 6 Shut off Test point 1 < F min and upper limit angle Derrick OGWD operational shut down If possible, move derrick boom in op. position, for that assembly - winch 4 can be lowered	A423		B	
3355B5	ZE 3: operation winch 6 Master switch right BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
335506	ZE 3: operation winch 6 Shut-off test point 3 < F min Operation conditional switch off, may not be shunted Lower load or lower derrick ballast if possible or spool out retraction gear if possible.	A423		B	
336202	ZE 3: Operation crawler Shut-down counterweight on ground Operation conditional switch off, may not be shunted Raise suspended counterweight.	A423		B	
336203	ZE 3: Operation crawler Shut-down support counterweight carriage is not retracted Operation conditional switch off, may not be shunted Retract support counterweight carriage completely.	A423		B	
336205	ZE 3: Operation crawler Shut-down swing with parallel travel count. carriage not possible Operation conditional shut-down, shunting via lifting up keyswitch BW - only switch on if BW safely lifted Press tow-travel key until the wheels are in travel direction and the indicator lamp remains on.	A423		B	
336206	ZE 3: Operation crawler Shut-down swing gear brake has not opened with tow-travel BW Operation conditional shut-down, shunting via lifting up keyswitch BW - only switch on if BW safely lifted Check: Brake valve swing gear - electrical selection, short-circuit or interruption, hydraulics.	A423		B	
336207	ZE 3: Operation crawler Shut-down free swing gear is not on with tow-travel BW operational shut down Check: True run or brake swing gear - electrical selection, short-circuit or interruption, hydraulics.	A423		B	
336208	ZE 3: Operation crawler Shut-down swing gear brake has opened with parallel travel BW Operation conditional switch off, may not be shunted Check: Brake valve swing gear - electrical selection, short-circuit following supply voltage, hydraulics.	A423		B	
336209	ZE 3: Operation crawler Shut-down free swing gear is not on with parallel travel BW Operation conditional switch off, may not be shunted Check: True run or brake swing gear - electrical selection, short-circuit or interruption, hydraulics.	A423		B	
336217	ZE 3: Operation crawler Pres. sw. slewing gear brake or slewing gear freewheeling erroneous Operating shut-off and output of error. Check sensor, replace if necessary.	A423		B	
336219	ZE 3: Operation crawler no or invalid operation mode shut-down operational shut down Using the additional error reports determine which error is present with ballast configuration.	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
336220	ZE 3: Operation crawler High-speed gear crawler is not poss. - parallel op. crawler is on High speed crawler is not possible Switch off crawler parallel operation.	A423		B	
33622B	ZE 3: Operation crawler Shut off Derrick ballast pulled > Derrick ballast max Operation conditional switch off, may not be shunted Fix cause of "LMB Stop", see error message	A423		B	
336230	ZE 3: Operation crawler Master switch 4 faulty/not present operational shut down Put foot pedal in zero position. Otherwise note system error for defective or missing sensors.	A423		B	
336231	ZE 3: Operation crawler Master switch 5 faulty/not present operational shut down Put foot pedal in zero position. Otherwise note system error for defective or missing sensors.	A423		B	
336233	ZE 3: Operation crawler Parallel operation differential path between crawlers too great operational shut down Switch off parallel crawler operation and switch on again, parallel operation is thus newly adjusted.	A423		B	
336234	ZE 3: Operation crawler Master switch left BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
336235	ZE 3: Operation crawler Master switch right BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A423		B	
336239	ZE 3: Operation crawler seat contact shut-down operational shut down Sit down or actuate one of the shunting switches for the seat contact in the master switches.	A423		B	
33623E	ZE 3: Operation crawler Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A423		B	1
336244	ZE 3: Operation crawler Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
336254	ZE 3: Operation crawler Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A423		B	
336255	ZE 3: Operation crawler Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Luff down derrick boom until limit switch no longer activated - Shut-down may not be shunted	A423		B	
336270	ZE 3: Operation crawler Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
336271	ZE 3: Operation crawler Shut-down lim switch "Count. on ground" vo. right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
336272	ZE 3: Operation crawler Shut-down lim switch "Count. on ground" hi. left faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
336273	ZE 3: Operation crawler Shut-down lim switch "Count. on ground" hi. right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
336274	ZE 3: Operation crawler Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
336275	ZE 3: Operation crawler Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
336285	ZE 3: Operation crawler Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
336286	ZE 3: Operation crawler Shut-down limit switch "RFP Main boom" links faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
336287	ZE 3: Operation crawler Shut-down limit switch "Overtop guard cyl D" right faulty/not prese Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
336288	ZE 3: Operation crawler Shut-down limit switch "Overtop guard cyl D" left faulty/not presen Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A423		B	
3362BE	ZE 3: Operation crawler Shut off upper limit shut off angle main boom (load chart) Operation conditional switch off, may not be shunted Spool main b. contr. winch out until no shut off present - shut off cannot be bypassed	A423		B	
336923	ZE 3: Operation crane control Shut off, long Derrick, RFP D le/ri - platforms erroneous / missing output of error, shut-down through application Check consoles, either not present or open line or short circuit after supply voltage	A423		B	
336924	ZE 3: Operation crane control Shut-off, longer derrick, RFP D le/ri - consoles set up output of error, shut-down through application Check consoles, either these are still present or short circuit after supply voltage.	A423		B	
336942	ZE 3: Operation crane control Emergency op. crane cont. switched on with start test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A423		B	1
336943	ZE 3: Operation crane control Emergency op. crane control switched on during test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A423		B	1
361001	E/A-Modul 3: system error OS-C167 initialising error processor-register erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A13		E	2
361002	E/A-Modul 3: system error OS-C167 initialising error test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A13		E	2
361006	E/A-Modul 3: system error OS-C167 initialising error RAM erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
361013	E/A-Modul 3: system error OS-C167 test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A13		E	2
361016	E/A-Modul 3: system error OS-C167 system-, driver-watchdog expired error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A13		E	2
361047	E/A-Modul 3: system error OS-C167 No feedback sign. for too long, signalling that sync. was successful Safety measure is initiated Check CAN network, check faulty Bus user.	A13		E	1
361053	E/A-Modul 3: system error OS-C167 User stack too small Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A13		E	1
361068	E/A-Modul 3: system error OS-C167 impermissible interrupt error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A13		E	2
361071	E/A-Modul 3: system error OS-C167 Invalid configuration or Firmware error indication on display re-load Software from ZE	A13		E	2
361080	E/A-Modul 3: system error OS-C167 fatal internal software error error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A13		E	2
361082	E/A-Modul 3: system error OS-C167 hardware-watchdog erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A13		E	2
361088	E/A-Modul 3: system error OS-C167 Configuration does not match software condition error indication on display Comparison SW-condition EAM-SW and configuration LICCON different, check LICCON-configuration, download EAM	A13		E	2
361089	E/A-Modul 3: system error OS-C167 Incorrect version of firmware installed Error output, possible error functions of module Replace module, reload firmware	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
361090	E/A-Modul 3: system error OS-C167 Incorrect hardware version recognised Error output, possible error functions of module Replace module	A13		E	1
372052	E/A-Modul 3: input/output DEA0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:17		E	1
372053	E/A-Modul 3: input/output DEA0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:17		E	1
372054	E/A-Modul 3: input/output DEA0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:17		E	1
372055	E/A-Modul 3: input/output DEA0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:17		E	1
372152	E/A-Modul 3: input/output DEA1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:15		E	1
372153	E/A-Modul 3: input/output DEA1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:15		E	1
372154	E/A-Modul 3: input/output DEA1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:15		E	1
372155	E/A-Modul 3: input/output DEA1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:15		E	1
372252	E/A-Modul 3: input/output DEA2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
372253	E/A-Modul 3: input/output DEA2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:13		E	1
372254	E/A-Modul 3: input/output DEA2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:13		E	1
372255	E/A-Modul 3: input/output DEA2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:13		E	1
372352	E/A-Modul 3: input/output DEA3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:11		E	1
372353	E/A-Modul 3: input/output DEA3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:11		E	1
372354	E/A-Modul 3: input/output DEA3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:11		E	1
372355	E/A-Modul 3: input/output DEA3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:11		E	1
372452	E/A-Modul 3: input/output DEA4 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:9		E	1
372453	E/A-Modul 3: input/output DEA4 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:9		E	1
372454	E/A-Modul 3: input/output DEA4 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
372455	E/A-Modul 3: input/output DEA4 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:9		E	1
372552	E/A-Modul 3: input/output DEA5 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:7		E	1
372553	E/A-Modul 3: input/output DEA5 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:7		E	1
372554	E/A-Modul 3: input/output DEA5 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:7		E	1
372555	E/A-Modul 3: input/output DEA5 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:7		E	1
372652	E/A-Modul 3: input/output DEA6 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:5		E	1
372653	E/A-Modul 3: input/output DEA6 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:5		E	1
372654	E/A-Modul 3: input/output DEA6 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:5		E	1
372655	E/A-Modul 3: input/output DEA6 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:5		E	1
372752	E/A-Modul 3: input/output DEA7 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
372753	E/A-Modul 3: input/output DEA7 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:3		E	1
372754	E/A-Modul 3: input/output DEA7 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:3		E	1
372755	E/A-Modul 3: input/output DEA7 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:3		E	1
373080	E/A-Modul 3: current input E0 short circuit to ground, open line, voltage sensor erroneous Output of error check input signal on the E/A-Modul or sensor	A13.X2:17		E	1
373117	E/A-Modul 3: current input E1 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13.X2:15		E	1
373179	E/A-Modul 3: current input E1 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13.X2:15		E	1
373180	E/A-Modul 3: current input E1 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13.X2:15		E	1
373217	E/A-Modul 3: current input E2 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13.X2:13		E	1
373279	E/A-Modul 3: current input E2 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13.X2:13		E	1
373280	E/A-Modul 3: current input E2 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13.X2:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
373417	E/A-Modul 3: voltage input E4 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:9		E	1
373479	E/A-Modul 3: voltage input E4 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:9		E	1
373480	E/A-Modul 3: voltage input E4 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:9		E	1
373517	E/A-Modul 3: voltage input E5 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:7		E	1
373579	E/A-Modul 3: voltage input E5 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:7		E	1
373580	E/A-Modul 3: voltage input E5 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:7		E	1
373617	E/A-Modul 3: voltage input E6 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:5		E	1
373679	E/A-Modul 3: voltage input E6 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:5		E	1
373680	E/A-Modul 3: voltage input E6 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13.X2:5		E	1
379052	E/A-Modul 3: output A0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
379053	E/A-Modul 3: output A0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:18		E	1
379054	E/A-Modul 3: output A0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:18		E	1
379055	E/A-Modul 3: output A0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:18		E	1
379152	E/A-Modul 3: output A1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:16		E	1
379153	E/A-Modul 3: output A1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:16		E	1
379154	E/A-Modul 3: output A1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:16		E	1
379155	E/A-Modul 3: output A1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:16		E	1
379250	E/A-Modul 3: bridge output A2 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A13.X3:14		E	1
379251	E/A-Modul 3: bridge output A2 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A13.X3:14		E	1
379252	E/A-Modul 3: bridge output A2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
379253	E/A-Modul 3: bridge output A2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:14		E	1
379254	E/A-Modul 3: bridge output A2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:14		E	1
379255	E/A-Modul 3: bridge output A2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:14		E	1
379350	E/A-Modul 3: bridge output A3 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A13.X3:12		E	1
379351	E/A-Modul 3: bridge output A3 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A13.X3:12		E	1
379352	E/A-Modul 3: bridge output A3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A13.X3:12		E	1
379353	E/A-Modul 3: bridge output A3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A13.X3:12		E	1
379354	E/A-Modul 3: bridge output A3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A13.X3:12		E	1
379355	E/A-Modul 3: bridge output A3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A13.X3:12		E	1
383501	E/A-Modul 3: SPI-support unit right Faulty data transfer E/A-module<->unit (time exceeded) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A13.X4:1/2/3/5/6/7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
383502	E/A-Modul 3: SPI-support unit right Serious system error to SPI-connection (interface) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A13.X4:1/2/3/5/6/7/8		E	1
383503	E/A-Modul 3: SPI-support unit right break in line or short circuit to supply voltage error indication on display remedy short circuit, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A13.X4:1/2/3/5/6/7/8		E	1
383504	E/A-Modul 3: SPI-support unit right break in line or short circuit to ground error indication on display remedy short circuit, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A13.X4:1/2/3/5/6/7/8		E	1
383506	E/A-Modul 3: SPI-support unit right Data transfer faulty (faulty check byte) error indication on display suppress EMV- interference	A13.X4:1/2/3/5/6/7/8		E	1
383507	E/A-Modul 3: SPI-support unit right Unit faulty/missing, incorrect unit inserted (ID) error indication on display check periphery and replace if necessary, check Software version, check EMV- interference	A13.X4:1/2/3/5/6/7/8		E	1
383508	E/A-Modul 3: SPI-support unit right Data transfer faulty (incorrect number of data bytes received) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A13.X4:1/2/3/5/6/7/8		E	1
383900	E/A-Modul 3: Control operating unit (SPI) Faulty initialisation data connection E/A-module<->unit error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A13.X4:1/2/3/5/6/7/8		E	1
383902	E/A-Modul 3: Control operating unit (SPI) Serious system error to SPI-connection (interface) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A13.X4:1/2/3/5/6/7/8		E	1
383905	E/A-Modul 3: Control operating unit (SPI) Initialisation error, resetting inputs/outputs faulty error indication on display check wiring, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A13.X4:1/2/3/5/6/7/8		E	1
383907	E/A-Modul 3: Control operating unit (SPI) Unit faulty/missing, incorrect unit inserted (ID) error indication on display connect functional periphery unit, system then eliminates error independently	A13.X4:1/2/3/5/6/7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
383908	E/A-Modul 3: Control operating unit (SPI) Data transfer faulty (incorrect number of data bytes received) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A13.X4:1/2/3/5/6/7/8		E	1
384104	E/A-Modul 3: LSB-B participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
384105	E/A-Modul 3: LSB-B participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
384118	E/A-Modul 3: LSB-B participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
384150	E/A-Modul 3: LSB-B participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
384151	E/A-Modul 3: LSB-B participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
384153	E/A-Modul 3: LSB-B participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
384154	E/A-Modul 3: LSB-B participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
384164	E/A-Modul 3: LSB-B participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
384165	E/A-Modul 3: LSB-B participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
384166	E/A-Modul 3: LSB-B participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
384167	E/A-Modul 3: LSB-B participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
384204	E/A-Modul 3: LSB-B participant address 2 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
384205	E/A-Modul 3: LSB-B participant address 2 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
384218	E/A-Modul 3: LSB-B participant address 2 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
384250	E/A-Modul 3: LSB-B participant address 2 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
384251	E/A-Modul 3: LSB-B participant address 2 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
384253	E/A-Modul 3: LSB-B participant address 2 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
384254	E/A-Modul 3: LSB-B participant address 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
384264	E/A-Modul 3: LSB-B participant address 2 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
384265	E/A-Modul 3: LSB-B participant address 2 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
384266	E/A-Modul 3: LSB-B participant address 2 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
384267	E/A-Modul 3: LSB-B participant address 2 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
384304	E/A-Modul 3: LSB-B participant address 3 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
384305	E/A-Modul 3: LSB-B participant address 3 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
384318	E/A-Modul 3: LSB-B participant address 3 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
384350	E/A-Modul 3: LSB-B participant address 3 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
384351	E/A-Modul 3: LSB-B participant address 3 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
384353	E/A-Modul 3: LSB-B participant address 3 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
384354	E/A-Modul 3: LSB-B participant address 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
384364	E/A-Modul 3: LSB-B participant address 3 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
384365	E/A-Modul 3: LSB-B participant address 3 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
384366	E/A-Modul 3: LSB-B participant address 3 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
384367	E/A-Modul 3: LSB-B participant address 3 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
384404	E/A-Modul 3: LSB-B participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
384405	E/A-Modul 3: LSB-B participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
384418	E/A-Modul 3: LSB-B participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
384450	E/A-Modul 3: LSB-B participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
384451	E/A-Modul 3: LSB-B participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
384453	E/A-Modul 3: LSB-B participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
384454	E/A-Modul 3: LSB-B participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
384464	E/A-Modul 3: LSB-B participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
384465	E/A-Modul 3: LSB-B participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
384466	E/A-Modul 3: LSB-B participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
384467	E/A-Modul 3: LSB-B participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
384504	E/A-Modul 3: LSB-B participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
384505	E/A-Modul 3: LSB-B participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
384518	E/A-Modul 3: LSB-B participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
384550	E/A-Modul 3: LSB-B participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
384551	E/A-Modul 3: LSB-B participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
384553	E/A-Modul 3: LSB-B participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
384554	E/A-Modul 3: LSB-B participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
384564	E/A-Modul 3: LSB-B participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
384565	E/A-Modul 3: LSB-B participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
384566	E/A-Modul 3: LSB-B participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
384567	E/A-Modul 3: LSB-B participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
384604	E/A-Modul 3: LSB-B participant address 6 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
384605	E/A-Modul 3: LSB-B participant address 6 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
384618	E/A-Modul 3: LSB-B participant address 6 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
384650	E/A-Modul 3: LSB-B participant address 6 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
384651	E/A-Modul 3: LSB-B participant address 6 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
384653	E/A-Modul 3: LSB-B participant address 6 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
384654	E/A-Modul 3: LSB-B participant address 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
384664	E/A-Modul 3: LSB-B participant address 6 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
384665	E/A-Modul 3: LSB-B participant address 6 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
384666	E/A-Modul 3: LSB-B participant address 6 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
384667	E/A-Modul 3: LSB-B participant address 6 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
384704	E/A-Modul 3: LSB-B participant address 7 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
384705	E/A-Modul 3: LSB-B participant address 7 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
384718	E/A-Modul 3: LSB-B participant address 7 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
384750	E/A-Modul 3: LSB-B participant address 7 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
384751	E/A-Modul 3: LSB-B participant address 7 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
384753	E/A-Modul 3: LSB-B participant address 7 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
384754	E/A-Modul 3: LSB-B participant address 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
384764	E/A-Modul 3: LSB-B participant address 7 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
384765	E/A-Modul 3: LSB-B participant address 7 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
384766	E/A-Modul 3: LSB-B participant address 7 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
384767	E/A-Modul 3: LSB-B participant address 7 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
384804	E/A-Modul 3: LSB-B participant address 8 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
384805	E/A-Modul 3: LSB-B participant address 8 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
384818	E/A-Modul 3: LSB-B participant address 8 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
384850	E/A-Modul 3: LSB-B participant address 8 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
384851	E/A-Modul 3: LSB-B participant address 8 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
384853	E/A-Modul 3: LSB-B participant address 8 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
384854	E/A-Modul 3: LSB-B participant address 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
384864	E/A-Modul 3: LSB-B participant address 8 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
384865	E/A-Modul 3: LSB-B participant address 8 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
384866	E/A-Modul 3: LSB-B participant address 8 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
384867	E/A-Modul 3: LSB-B participant address 8 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
385004	E/A-Modul 3: LSB-B participant address 10 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
385005	E/A-Modul 3: LSB-B participant address 10 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
385018	E/A-Modul 3: LSB-B participant address 10 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
385050	E/A-Modul 3: LSB-B participant address 10 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
385051	E/A-Modul 3: LSB-B participant address 10 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
385053	E/A-Modul 3: LSB-B participant address 10 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
385054	E/A-Modul 3: LSB-B participant address 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
385064	E/A-Modul 3: LSB-B participant address 10 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
385065	E/A-Modul 3: LSB-B participant address 10 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
385066	E/A-Modul 3: LSB-B participant address 10 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
385067	E/A-Modul 3: LSB-B participant address 10 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
385104	E/A-Modul 3: LSB-B participant address 11 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
385105	E/A-Modul 3: LSB-B participant address 11 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
385118	E/A-Modul 3: LSB-B participant address 11 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
385150	E/A-Modul 3: LSB-B participant address 11 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
385151	E/A-Modul 3: LSB-B participant address 11 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
385153	E/A-Modul 3: LSB-B participant address 11 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
385154	E/A-Modul 3: LSB-B participant address 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
385164	E/A-Modul 3: LSB-B participant address 11 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
385165	E/A-Modul 3: LSB-B participant address 11 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
385166	E/A-Modul 3: LSB-B participant address 11 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
385167	E/A-Modul 3: LSB-B participant address 11 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
385604	E/A-Modul 3: LSB-B participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
385605	E/A-Modul 3: LSB-B participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
385618	E/A-Modul 3: LSB-B participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
385650	E/A-Modul 3: LSB-B participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
385651	E/A-Modul 3: LSB-B participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
385653	E/A-Modul 3: LSB-B participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
385654	E/A-Modul 3: LSB-B participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
385664	E/A-Modul 3: LSB-B participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
385665	E/A-Modul 3: LSB-B participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
385666	E/A-Modul 3: LSB-B participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
385667	E/A-Modul 3: LSB-B participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
385704	E/A-Modul 3: LSB-B participant address 17 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
385705	E/A-Modul 3: LSB-B participant address 17 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
385718	E/A-Modul 3: LSB-B participant address 17 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
385750	E/A-Modul 3: LSB-B participant address 17 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
385751	E/A-Modul 3: LSB-B participant address 17 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
385753	E/A-Modul 3: LSB-B participant address 17 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
385754	E/A-Modul 3: LSB-B participant address 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
385764	E/A-Modul 3: LSB-B participant address 17 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
385765	E/A-Modul 3: LSB-B participant address 17 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
385766	E/A-Modul 3: LSB-B participant address 17 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
385767	E/A-Modul 3: LSB-B participant address 17 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
385804	E/A-Modul 3: LSB-B participant address 18 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
385805	E/A-Modul 3: LSB-B participant address 18 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
385818	E/A-Modul 3: LSB-B participant address 18 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
385850	E/A-Modul 3: LSB-B participant address 18 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
385851	E/A-Modul 3: LSB-B participant address 18 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
385853	E/A-Modul 3: LSB-B participant address 18 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
385854	E/A-Modul 3: LSB-B participant address 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
385864	E/A-Modul 3: LSB-B participant address 18 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
385865	E/A-Modul 3: LSB-B participant address 18 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
385866	E/A-Modul 3: LSB-B participant address 18 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
385867	E/A-Modul 3: LSB-B participant address 18 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
385904	E/A-Modul 3: LSB-B participant address 19 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
385905	E/A-Modul 3: LSB-B participant address 19 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
385918	E/A-Modul 3: LSB-B participant address 19 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
385950	E/A-Modul 3: LSB-B participant address 19 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
385951	E/A-Modul 3: LSB-B participant address 19 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
385953	E/A-Modul 3: LSB-B participant address 19 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
385954	E/A-Modul 3: LSB-B participant address 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
385964	E/A-Modul 3: LSB-B participant address 19 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
385965	E/A-Modul 3: LSB-B participant address 19 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
385966	E/A-Modul 3: LSB-B participant address 19 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
385967	E/A-Modul 3: LSB-B participant address 19 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
386004	E/A-Modul 3: LSB-B participant address 20 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
386005	E/A-Modul 3: LSB-B participant address 20 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
386018	E/A-Modul 3: LSB-B participant address 20 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
386050	E/A-Modul 3: LSB-B participant address 20 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
386051	E/A-Modul 3: LSB-B participant address 20 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
386053	E/A-Modul 3: LSB-B participant address 20 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
386054	E/A-Modul 3: LSB-B participant address 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
386064	E/A-Modul 3: LSB-B participant address 20 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
386065	E/A-Modul 3: LSB-B participant address 20 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
386066	E/A-Modul 3: LSB-B participant address 20 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
386067	E/A-Modul 3: LSB-B participant address 20 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
386604	E/A-Modul 3: LSB-B participant address 26 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
386605	E/A-Modul 3: LSB-B participant address 26 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
386618	E/A-Modul 3: LSB-B participant address 26 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
386650	E/A-Modul 3: LSB-B participant address 26 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
386651	E/A-Modul 3: LSB-B participant address 26 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
386653	E/A-Modul 3: LSB-B participant address 26 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
386654	E/A-Modul 3: LSB-B participant address 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
386664	E/A-Modul 3: LSB-B participant address 26 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
386665	E/A-Modul 3: LSB-B participant address 26 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
386666	E/A-Modul 3: LSB-B participant address 26 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
386667	E/A-Modul 3: LSB-B participant address 26 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
386704	E/A-Modul 3: LSB-B participant address 27 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
386705	E/A-Modul 3: LSB-B participant address 27 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
386718	E/A-Modul 3: LSB-B participant address 27 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
386750	E/A-Modul 3: LSB-B participant address 27 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
386751	E/A-Modul 3: LSB-B participant address 27 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
386753	E/A-Modul 3: LSB-B participant address 27 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
386754	E/A-Modul 3: LSB-B participant address 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
386764	E/A-Modul 3: LSB-B participant address 27 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
386765	E/A-Modul 3: LSB-B participant address 27 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
386766	E/A-Modul 3: LSB-B participant address 27 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
386767	E/A-Modul 3: LSB-B participant address 27 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
386804	E/A-Modul 3: LSB-B participant address 28 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1
386805	E/A-Modul 3: LSB-B participant address 28 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
386818	E/A-Modul 3: LSB-B participant address 28 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
386850	E/A-Modul 3: LSB-B participant address 28 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
386851	E/A-Modul 3: LSB-B participant address 28 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
386853	E/A-Modul 3: LSB-B participant address 28 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
386854	E/A-Modul 3: LSB-B participant address 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
386864	E/A-Modul 3: LSB-B participant address 28 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
386865	E/A-Modul 3: LSB-B participant address 28 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
386866	E/A-Modul 3: LSB-B participant address 28 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
386867	E/A-Modul 3: LSB-B participant address 28 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1
386904	E/A-Modul 3: LSB-B participant address 29 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
386905	E/A-Modul 3: LSB-B participant address 29 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A13.X3:4/6		E	1
386918	E/A-Modul 3: LSB-B participant address 29 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A13.X3:4/6		E	0
386950	E/A-Modul 3: LSB-B participant address 29 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A13.X3:4/6		E	2
386951	E/A-Modul 3: LSB-B participant address 29 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A13.X3:4/6		E	2
386953	E/A-Modul 3: LSB-B participant address 29 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A13.X3:4/6		E	1
386954	E/A-Modul 3: LSB-B participant address 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A13.X3:4/6		E	2
386964	E/A-Modul 3: LSB-B participant address 29 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A13.X3:4/6		E	1
386965	E/A-Modul 3: LSB-B participant address 29 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A13.X3:4/6		E	2
386966	E/A-Modul 3: LSB-B participant address 29 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A13.X3:4/6		E	2
386967	E/A-Modul 3: LSB-B participant address 29 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A13.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
387252	E/A-Modul 3: Control data transfer LSB-B has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A13.X3:4/6		E	0
387255	E/A-Modul 3: Control data transfer LSB-B Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A13.X3:4/6		E	2
387256	E/A-Modul 3: Control data transfer LSB-B Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A13.X3:4/6		E	2
387257	E/A-Modul 3: Control data transfer LSB-B has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A13.X3:4/6		E	1
387258	E/A-Modul 3: Control data transfer LSB-B recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A13.X3:4/6		E	0
387259	E/A-Modul 3: Control data transfer LSB-B recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A13.X3:4/6		E	0
387260	E/A-Modul 3: Control data transfer LSB-B driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A13.X3:4/6		E	2
387261	E/A-Modul 3: Control data transfer LSB-B driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A13.X3:4/6		E	2
387262	E/A-Modul 3: Control data transfer LSB-B Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A13.X3:4/6		E	2
388130	E/A-Modul 3: CAN-subscriber steering valve 1 (EHS1) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A13.X5:5/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
388131	E/A-Modul 3: CAN-subscriber steering valve 1 (EHS1) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1
388230	E/A-Modul 3: CAN-subscriber steering valve 2 (EHS2) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A13.X5:5/6		E	0
388231	E/A-Modul 3: CAN-subscriber steering valve 2 (EHS2) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1
388330	E/A-Modul 3: CAN-subscriber steering valve 3 (EHS3) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A13.X5:5/6		E	0
388331	E/A-Modul 3: CAN-subscriber steering valve 3 (EHS3) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1
388430	E/A-Modul 3: CAN-subscriber steering valve 4 (EHS4) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A13.X5:5/6		E	0
388431	E/A-Modul 3: CAN-subscriber steering valve 4 (EHS4) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1
388730	E/A-Modul 3: CAN-participant E/A-Modul 3 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A13.X5:5/6		E	0
388731	E/A-Modul 3: CAN-participant E/A-Modul 3 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1
388830	E/A-Modul 3: CAN-participant E/A-Modul 4 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
388831	E/A-Modul 3: CAN-participant E/A-Modul 4 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1
389731	E/A-Modul 3: CAN-transmission analogous input values Data transfer faulty/missing, max. cycle time exceeded System message could not be transmitted Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1
389831	E/A-Modul 3: CAN-transmission system time (master) Data transfer faulty/missing, max. cycle time exceeded System message could not be transmitted Check CAN network, check faulty Bus user.	A13.X5:5/6		E	1
389900	E/A-Modul 3: Control data transfer CAN internal error at Register-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A13.X5:5/6		E	2
389901	E/A-Modul 3: Control data transfer CAN internal error at RAM-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A13.X5:5/6		E	2
389902	E/A-Modul 3: Control data transfer CAN Configuration error Software internal error, CAN-transmission will be aborted replace E/A-Modul, check Software (test system ZE)	A13.X5:5/6		E	2
389903	E/A-Modul 3: Control data transfer CAN Transfer interrupted after continuous error CAN-Transmission will be aborted Check CAN network, replace E/A-Modul	A13.X5:5/6		E	1
389910	E/A-Modul 3: Control data transfer CAN short-term error in bus connection re-attachment of Modul to bus transmission Check CAN network, connect individual Bus users and check if error has been remedied	A13.X5:5/6		E	0
389911	E/A-Modul 3: Control data transfer CAN permanent error bus connection cyclic re-attachment of Modul to bus transmission Check CAN network, connect individual Bus users and check if error has been remedied	A13.X5:5/6		E	1
389920	E/A-Modul 3: Control data transfer CAN active participant not responding parameterised substitute values for receiver signals will be used check error report for missing participant(s), test system ZE	A13.X5:5/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
389921	E/A-Modul 3: Control data transfer CAN No active subscriber responding parameterised substitute values for receiver signals will be used in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A13.X5:5/6		E	1
389950	E/A-Modul 3: Control data transfer CAN erroneous command test system no reaction to unknown test system control command in CAN-System Software check Software (test system)	A13.X5:5/6		E	1
391111	E/A-Modul 3: Proportional valve steering axle LA1 CAN-communication with E/A-module faulty/lacking (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A13		E	1
391112	E/A-Modul 3: Proportional valve steering axle LA1 CAN-communication with E/A-module faulty/lacking (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A13		E	1
391113	E/A-Modul 3: Proportional valve steering axle LA1 CAN-communication with E/A-module implausible (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A13		E	1
391114	E/A-Modul 3: Proportional valve steering axle LA1 CAN-communication with E/A-module implausible (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A13		E	1
391115	E/A-Modul 3: Proportional valve steering axle LA1 Voltage supply/PWM-control faulty Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391116	E/A-Modul 3: Proportional valve steering axle LA1 Internal error, EEPROM-memory inconsistent Valve is not controlled (neutral position), secondary measures possibly required Check valve configuration, replace valve	A13		E	1
391117	E/A-Modul 3: Proportional valve steering axle LA1 Reference value valve not neutral due to continuous error Valve is not controlled (neutral position), secondary measures possibly required Remedy fault, activate/deactivate ignition	A13		E	1
391121	E/A-Modul 3: Proportional valve steering axle LA1 Voltage supply below permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
391122	E/A-Modul 3: Proportional valve steering axle LA1 Voltage supply above permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391123	E/A-Modul 3: Proportional valve steering axle LA1 Slide deflected too short; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve; replace valve; errors may be resulted from engine stalling	A13		E	1
391124	E/A-Modul 3: Proportional valve steering axle LA1 Slide deflected too far; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A13		E	1
391125	E/A-Modul 3: Proportional valve steering axle LA1 Valve float position not reached Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A13		E	1
391126	E/A-Modul 3: Proportional valve steering axle LA1 Manual actuation With fault-free valve and neutral set value, error report only No manual operation possible, check valve and replace if necessary; valve shifted mechanically out of neutral?	A13		E	1
391131	E/A-Modul 3: Proportional valve steering axle LA1 Voltage supply below 8V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391132	E/A-Modul 3: Proportional valve steering axle LA1 Voltage supply above 36..45V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391141	E/A-Modul 3: Proportional valve steering axle LA1 Voltage supply above 45V, internal emergency shut-down Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391142	E/A-Modul 3: Proportional valve steering axle LA1 Power amplifier error solenoid valve servo-control Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A13		E	1
391143	E/A-Modul 3: Proportional valve steering axle LA1 Distance converter valve stroke faulty Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
391181	E/A-Modul 3: Proportional valve steering axle LA1 Slide valve can not be shifted into neutral position Internal emergency shut-down, possible valve can not switch to neutral, secondary measures possibly required Check hydraulic supply, valve; replace valve	A13		E	1
391182	E/A-Modul 3: Proportional valve steering axle LA1 Slide valve not in neutral position upon activation Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve and replace if necessary; valve shifted mechanically out of neutral?	A13		E	1
391311	E/A-Modul 3: Proportional valve steering axle LA3 CAN-communication with E/A-module faulty/lacking (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A13		E	1
391312	E/A-Modul 3: Proportional valve steering axle LA3 CAN-communication with E/A-module faulty/lacking (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A13		E	1
391313	E/A-Modul 3: Proportional valve steering axle LA3 CAN-communication with E/A-module implausible (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A13		E	1
391314	E/A-Modul 3: Proportional valve steering axle LA3 CAN-communication with E/A-module implausible (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A13		E	1
391315	E/A-Modul 3: Proportional valve steering axle LA3 Voltage supply/PWM-control faulty Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391316	E/A-Modul 3: Proportional valve steering axle LA3 Internal error, EEPROM-memory inconsistent Valve is not controlled (neutral position), secondary measures possibly required Check valve configuration, replace valve	A13		E	1
391317	E/A-Modul 3: Proportional valve steering axle LA3 Reference value valve not neutral due to continuous error Valve is not controlled (neutral position), secondary measures possibly required Remedy fault, activate/deactivate ignition	A13		E	1
391321	E/A-Modul 3: Proportional valve steering axle LA3 Voltage supply below permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
391322	E/A-Modul 3: Proportional valve steering axle LA3 Voltage supply above permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391323	E/A-Modul 3: Proportional valve steering axle LA3 Slide deflected too short; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve; replace valve; errors may be resulted from engine stalling	A13		E	1
391324	E/A-Modul 3: Proportional valve steering axle LA3 Slide deflected too far; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A13		E	1
391325	E/A-Modul 3: Proportional valve steering axle LA3 Valve float position not reached Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A13		E	1
391326	E/A-Modul 3: Proportional valve steering axle LA3 Manual actuation With fault-free valve and neutral set value, error report only No manual operation possible, check valve and replace if necessary; valve shifted mechanically out of neutral?	A13		E	1
391331	E/A-Modul 3: Proportional valve steering axle LA3 Voltage supply below 8V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391332	E/A-Modul 3: Proportional valve steering axle LA3 Voltage supply above 36..45V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391341	E/A-Modul 3: Proportional valve steering axle LA3 Voltage supply above 45V, internal emergency shut-down Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A13		E	1
391342	E/A-Modul 3: Proportional valve steering axle LA3 Power amplifier error solenoid valve servo-control Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A13		E	1
391343	E/A-Modul 3: Proportional valve steering axle LA3 Distance converter valve stroke faulty Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
391381	E/A-Modul 3: Proportional valve steering axle LA3 Slide valve can not be shifted into neutral position Internal emergency shut-down, possible valve can not switch to neutral, secondary measures possibly required Check hydraulic supply, valve; replace valve	A13		E	1
391382	E/A-Modul 3: Proportional valve steering axle LA3 Slide valve not in neutral position upon activation Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve and replace if necessary; valve shifted mechanically out of neutral?	A13		E	1
392510	E/A-Modul 3: control axle suspension/level signals from transfer contact "axle elevated" simultaneous IN raise axles 3+4 function defective, function can be carried out with defective feedback change-contact pressure switch >120 bar, Check cabling to short against supply voltage	A13		E	1
392511	E/A-Modul 3: control axle suspension/level signals from transfer contact "axle elevated" simultaneous OUT raise axles 3+4 function defective, function can be carried out with defective feedback change-contact pressure switch >120 bar, check cabling for wire break, fuse KI.15	A13		E	1
392830	E/A-Modul 3: control supports location coding for right support unit erroneous (set value = 0) support functions are blocked check line connection to E/A-Modul, check ground connection from signal, replace E/A-Modul	A13		E	2
392832	E/A-Modul 3: control supports right support unit key sticking or activated after switching on right support blocked check/unplug/replace support operating unit release activated key	A13		E	1
394000	E/A-Modul 3: Control active rear axle steering Sensor values channel A/B are not synchronised Safety measure is initiated check cable/plugs for UB- or shorts to ground	A13		E	1
394001	E/A-Modul 3: Control active rear axle steering Local sensor values are not synchronised Safety measure is initiated check cable/plugs for UB- or shorts to ground	A13		E	1
394002	E/A-Modul 3: Control active rear axle steering Low voltage on voltage supply from I / O module Safety measure is initiated Check cable/plug on UB- or short circuit after ground or low voltage at engine ON	A13		E	1
394003	E/A-Modul 3: Control active rear axle steering Signal from angle sensor front axle faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
394004	E/A-Modul 3: Control active rear axle steering Signals from channel A/B angle sensor front axle implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13		E	1
394010	E/A-Modul 3: Control active rear axle steering Signal from angle sensor steering axle 1 faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13		E	1
394011	E/A-Modul 3: Control active rear axle steering Signals from channel A/B angle sensor steering axle 1 implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13		E	1
394017	E/A-Modul 3: Control active rear axle steering Signal from angle sensor steering axle 2 faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13		E	1
394018	E/A-Modul 3: Control active rear axle steering Signals from channel A/B angle sensor steering axle 2 implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13		E	1
394024	E/A-Modul 3: Control active rear axle steering Signal from angle sensor steering axle 3 faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13		E	1
394025	E/A-Modul 3: Control active rear axle steering Signals from channel A/B angle sensor steering axle 3 implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A13		E	1
394031	E/A-Modul 3: Control active rear axle steering Signal from angle sensor steering axle 4 faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13		E	1
394032	E/A-Modul 3: Control active rear axle steering Signals from channel A/B angle sensor steering axle 4 implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A13		E	1
394035	E/A-Modul 3: Control active rear axle steering Steering axle 1 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
394036	E/A-Modul 3: Control active rear axle steering Steering axle 2 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A13		E	1
394037	E/A-Modul 3: Control active rear axle steering Steering axle 3 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A13		E	1
394038	E/A-Modul 3: Control active rear axle steering Steering axle 4 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A13		E	1
394040	E/A-Modul 3: Control active rear axle steering Pressure supply centring circuit too low with speed > 10 km/h Safety measure is initiated Measure input signals on E/A-module, check pressure switch or hydraulic supply	A13		E	1
394041	E/A-Modul 3: Control active rear axle steering Pressure supply centring circuit too high after ignition ON Safety measure is initiated Measure input signals on E/A-module, check pressure switch or hydraulic supply	A13		E	1
394042	E/A-Modul 3: Control active rear axle steering Signals press. switch centr. circuit both ON / short circuit to Vcc Safety measure is initiated Measure input signals on E/A-module or check pressure switch	A13		E	1
394043	E/A-Modul 3: Control active rear axle steering Sig. press. switch centr. circle both OFF/wire break/short circ. earth Safety measure is initiated Measure input signals on E/A-module or check pressure switch	A13		E	1
394051	E/A-Modul 3: Control active rear axle steering Error in program run Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A13		E	1
394052	E/A-Modul 3: Control active rear axle steering Checksum faulty Error report, value is zeroed E/A-module 1+3+4, LSB, check system-independent steering	A13		E	1
394053	E/A-Modul 3: Control active rear axle steering Signal flow sensor pre-tensioning centring cyl.: Oil supply too low Safety measure is initiated Check input signals on E/A-module, flow switch or hydraulic supply	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
394054	E/A-Modul 3: Control active rear axle steering Signal flow sensor pre-tensioning centring cyl.: Sensor faulty/missing Safety measure is initiated Check input signals on E/A-module, flow switch or hydraulic supply	A13		E	1
394056	E/A-Modul 3: Control active rear axle steering Signal flow sensor pretension centring cylinder: line break Safety measure is initiated Check input signals on E/A-module, flow switch or hydraulic supply	A13		E	1
394058	E/A-Modul 3: Control active rear axle steering Actuator values from opposite side are too old Safety measure is initiated Check CAN network, check faulty Bus user.	A13		E	1
394059	E/A-Modul 3: Control active rear axle steering Actuator values difference with opposite side too great Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A13		E	1
394060	E/A-Modul 3: Control active rear axle steering CAN- values from I / O module 3 are not plausible Safety measure is initiated Check cable/plug on UB- or short circuit after ground or low voltage at engine Start	A13		E	1
394061	E/A-Modul 3: Control active rear axle steering CAN- values from I / O module 4 are not plausible Safety measure is initiated Check cable/plug on UB- or short circuit after ground or low voltage at engine Start	A13		E	1
394062	E/A-Modul 3: Control active rear axle steering Outlet centring valves trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on E/A-module	A13		E	1
394064	E/A-Modul 3: Control active rear axle steering Outlet locking valve 1 trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on E/A-module	A13		E	1
394066	E/A-Modul 3: Control active rear axle steering Outlet locking valve 2 trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on E/A-module	A13		E	1
394067	E/A-Modul 3: Control active rear axle steering Power feedback measuring determines too great a difference in current error report on display Check outlet switching on E/A-module	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
394070	E/A-Modul 3: Control active rear axle steering Signal Travel speed tachograph faulty/missing Error report, replacement value 100 km/h, axles are reset depending on operation type Speed signal tacho, check CAN1, EAM1, EAM5, ECU, LSB	A13		E	1
394071	E/A-Modul 3: Control active rear axle steering Signal travel speed output gear sensor faulty/lacking Error report, replacement value 100 km/h, axles are reset depending on operation type Output gear speed, gear control unit, output sensor, check CAN	A13		E	1
394072	E/A-Modul 3: Control active rear axle steering Signal travel speed tacho<->gear impl./outside tolerance Error report, replacement value 100 km/h, axles are reset depending on operation type Speed signal tacho, check output gear speed	A13		E	1
394073	E/A-Modul 3: Control active rear axle steering Signal engine speed diesel engine faulty/missing Error report, value is zeroed Speed signal ECU, check CAN1, ECU, EAM5, LSB	A13		E	1
394075	E/A-Modul 3: Control active rear axle steering Steering axle 1 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A13		E	1
394076	E/A-Modul 3: Control active rear axle steering Steering axle 2 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A13		E	1
394077	E/A-Modul 3: Control active rear axle steering Steering axle 3 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A13		E	1
394078	E/A-Modul 3: Control active rear axle steering Steering axle 4 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A13		E	1
394080	E/A-Modul 3: Control active rear axle steering Set value specifica. operation type from operating unit faulty/missing Steering becomes faulty following time-out EAM1, operating unit, check LSB	A13		E	1
394082	E/A-Modul 3: Control active rear axle steering Return report steering status left faulty/missing Steering becomes faulty following time-out Steering, check LSB	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
394085	E/A-Modul 3: Control active rear axle steering Error in computer at opposite side Safety measure is initiated Read error code on other module and remedy error	A13		E	1
394090	E/A-Modul 3: Control active rear axle steering Diagnosis centring valve: steering axle 1 not centring error report on display	A13		E	1
394091	E/A-Modul 3: Control active rear axle steering Diagnosis centring valve: steering axle 2 not centring error report on display Check whether valve is mechanically jammed	A13		E	1
394092	E/A-Modul 3: Control active rear axle steering Diagnosis centring valve: steering axle 3 not centring error report on display Check whether valve is mechanically jammed	A13		E	1
394093	E/A-Modul 3: Control active rear axle steering Diagnosis freewheel valve: steering axle 4 not freewheeling error report on display Check whether valve is mechanically jammed	A13		E	1
394094	E/A-Modul 3: Control active rear axle steering Diagnosis locking valve: steering axle 1 not locking error report on display Check whether valve is mechanically jammed	A13		E	1
394095	E/A-Modul 3: Control active rear axle steering Diagnosis locking valve: steering axle 2 not locking error report on display Check whether valve is mechanically jammed	A13		E	1
394096	E/A-Modul 3: Control active rear axle steering Diagnosis locking valve: steering axle 3 not locking error report on display Check whether valve is mechanically jammed	A13		E	1
394185	E/A-Modul 3: LSB-bus participant Support pressure transducer front right faulty/not present communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394186	E/A-Modul 3: LSB-bus participant Support pressure transducer front left faulty/not present communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
394187	E/A-Modul 3: LSB-bus participant Support pressure transducer rear right faulty/not present communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394188	E/A-Modul 3: LSB-bus participant Support pressure transducer rear left faulty/not present communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394189	E/A-Modul 3: LSB-bus participant Incline sensor erroneous/ missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394190	E/A-Modul 3: LSB-bus participant ZE missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394191	E/A-Modul 3: LSB-bus participant E/A-Modul 1 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394192	E/A-Modul 3: LSB-bus participant E/A-Modul 2 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394194	E/A-Modul 3: LSB-bus participant E/A-Modul 4 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394195	E/A-Modul 3: LSB-bus participant E/A-Modul 5 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
394196	E/A-Modul 3: LSB-bus participant E/A-Modul 6 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A13		E	1
396408	E/A-Modul 3: operation supports unauthorised operation from upper-carriage function is not carried out check coding of E/A-Modul 3 and E/A-Modul 4 (see electric circuit diagram)	A13		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
396409	E/A-Modul 3: operation supports unauthorised operation from under-carriage function is not carried out check coding of E/A-Modul 3 and E/A-Modul 4 (see electric circuit diagram)	A13		B	
396440	E/A-Modul 3: operation supports simultaneous UP and DOWN operation of support control unit function is not carried out actuate UP key or DOWN key of the respective support operating unit, start test program support service unit	A13		B	
396441	E/A-Modul 3: operation supports simultaneous IN and OUT operation of support control unit function is not carried out actuate OFF key or ON key of the respective support operating unit, start test program support operating unit	A13		B	
396442	E/A-Modul 3: operation supports simultaneous UP and DOWN operation on upper-carriage monitor function is not carried out actuate UP key or DOWN key of the respective support operating unit, start test program support service unit	A13		B	
396443	E/A-Modul 3: operation supports simultaneous IN and OUT operation on upper-carriage monitor function is not carried out actuate OFF key or ON key of the respective support operating unit, start test program support operating unit	A13		B	
396444	E/A-Modul 3: operation supports simultaneous left and right operation of support control unit function is not carried out actuate support from only one operating position, start test program support operating unit	A13		B	
396445	E/A-Modul 3: operation supports simultaneous operation of support control unit and upper-carriage function is not carried out actuate support from only one operating position, start test program support operating unit	A13		B	
396446	E/A-Modul 3: operation supports simultaneous operation of support control unit and upper-carriage function is not carried out actuate support from only one operating position, start test program support operating unit	A13		B	
396447	E/A-Modul 3: operation supports operation of support control unit with travel direction D engaged function is not carried out switch transmission to neutral (N)	A13		B	
396448	E/A-Modul 3: operation supports operation of support control unit with travel direction R engaged function is not carried out switch transmission to neutral (N)	A13		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
396449	E/A-Modul 3: operation supports op. of upper-carriage monitor with travel direction D engaged function is not carried out switch transmission to neutral (N)	A13		B	
396450	E/A-Modul 3: operation supports operation of upper-carriage-monitor R function is not carried out switch transmission to neutral (N)	A13		B	
396451	E/A-Modul 3: operation supports unauthorised activation of right support control unit key right support blocked release activated key after having authorized function through hand- key	A13		B	
398028	E/A-Modul 3: Operation active rear axle steering Wheel collision last mech. steered and 1st electr. steered axle Output of error Turn the steering wheel in the other direction	A13		B	
398030	E/A-Modul 3: Operation active rear axle steering Switch-over operation type prevented: Travel speed too high	A13		B	
398031	E/A-Modul 3: Operation active rear axle steering Change-over operation type prevented: Adjust axles manually	A13		B	
399890	E/A-Modul 3: operation diagnosis system test program not executable as engine is not OFF function is not carried out shut down engine	A13		B	
399892	E/A-Modul 3: operation diagnosis system test program not executable as not in under-carriage op. mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A13		B	
400001	ZE 4: system error OS-HC11 (observe parameters) initialising error processor-register erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A424		E	2
400002	ZE 4: system error OS-HC11 (observe parameters) initialising error test total in EPROM/FLASH erroneous no crane operation possible check program memory card or ZE	A424		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
400006	ZE 4: system error OS-HC11 (observe parameters) initialising error RAM erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A424		E	2
400007	ZE 4: system error OS-HC11 (observe parameters) UART erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A424		E	2
400010	ZE 4: system error OS-HC11 (observe parameters) system routine inaccessible entry in error memory, all crane movements will be stopped	A424		E	2
400011	ZE 4: system error OS-HC11 (observe parameters) ZE-watchdog expired entry in error memory, all crane movements will be stopped check ZE	A424		E	2
400012	ZE 4: system error OS-HC11 (observe parameters) type-identification in EPROM erroneous entry in error memory, no crane operation possible check program memory card	A424		E	2
400013	ZE 4: system error OS-HC11 (observe parameters) Test sum in FLASH erroneous entry in error memory, all crane movements will be stopped check program memory card	A424		E	2
400014	ZE 4: system error OS-HC11 (observe parameters) program already running entry in error memory, all crane movements will be stopped	A424		E	2
400015	ZE 4: system error OS-HC11 (observe parameters) program not available entry in error memory, all crane movements will be stopped	A424		E	2
400016	ZE 4: system error OS-HC11 (observe parameters) system-, driver-watchdog expired entry in error memory, all crane movements will be stopped	A424		E	2
400017	ZE 4: system error OS-HC11 (observe parameters) total of CPU-time distribution too great entry in error memory, all crane movements will be stopped	A424		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
400018	ZE 4: system error OS-HC11 (observe parameters) arithmetic overflow (16 Bit) entry in error memory, all crane movements will be stopped	A424		E	2
400019	ZE 4: system error OS-HC11 (observe parameters) division through zero (16 Bit) entry in error memory, all crane movements will be stopped	A424		E	2
400020	ZE 4: system error OS-HC11 (observe parameters) task-watchdog expired entry in error memory, all crane movements will be stopped	A424		E	2
400021	ZE 4: system error OS-HC11 (observe parameters) illegal opcode trap entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A424		E	2
400022	ZE 4: system error OS-HC11 (observe parameters) task inactive entry in error memory, all crane movements will be stopped	A424		E	2
400023	ZE 4: system error OS-HC11 (observe parameters) program incapable of running (type identification) entry in error memory, all crane movements will be stopped	A424		E	2
400024	ZE 4: system error OS-HC11 (observe parameters) task already used entry in error memory, all crane movements will be stopped	A424		E	2
400025	ZE 4: system error OS-HC11 (observe parameters) realtime-module already used entry in error memory, all crane movements will be stopped	A424		E	2
400026	ZE 4: system error OS-HC11 (observe parameters) regulator-module already used entry in error memory, all crane movements will be stopped	A424		E	2
400030	ZE 4: system error OS-HC11 (observe parameters) unacceptable bank address entry in error memory, all crane movements will be stopped	A424		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
400041	ZE 4: system error OS-HC11 (observe parameters) arithmetic error entry in error memory, all crane movements will be stopped	A424		E	2
400044	ZE 4: system error OS-HC11 (observe parameters) output parameter without effect, from inactive output entry in error memory, all crane movements will be stopped	A424		E	2
400045	ZE 4: system error OS-HC11 (observe parameters) entry parameter undefined, from inactive input entry in error memory, all crane movements will be stopped	A424		E	2
400046	ZE 4: system error OS-HC11 (observe parameters) impermissible regulator parameter entry in error memory, all crane movements will be stopped	A424		E	2
400047	ZE 4: system error OS-HC11 (observe parameters) realtime-control block not available entry in error memory, all crane movements will be stopped	A424		E	2
400048	ZE 4: system error OS-HC11 (observe parameters) realtime-control block inactive entry in error memory, all crane movements will be stopped	A424		E	2
400049	ZE 4: system error OS-HC11 (observe parameters) urgent modul, ZE not available entry in error memory, no crane operation possible check ZE	A424		E	2
400050	ZE 4: system error OS-HC11 (observe parameters) file not available entry in error memory, all crane movements will be stopped	A424		E	2
400051	ZE 4: system error OS-HC11 (observe parameters) file already opened entry in error memory, all crane movements will be stopped	A424		E	2
400052	ZE 4: system error OS-HC11 (observe parameters) file not open on close entry in error memory, all crane movements will be stopped	A424		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
400053	ZE 4: system error OS-HC11 (observe parameters) system mask not available entry in error memory, all crane movements will be stopped	A424		E	2
400054	ZE 4: system error OS-HC11 (observe parameters) system text not available entry in error memory, all crane movements will be stopped	A424		E	2
400055	ZE 4: system error OS-HC11 (observe parameters) symbol not available entry in error memory, all crane movements will be stopped	A424		E	2
400056	ZE 4: system error OS-HC11 (observe parameters) invalid mark in symbol entry in error memory, all crane movements will be stopped	A424		E	2
400057	ZE 4: system error OS-HC11 (observe parameters) default load chart missing entry in error memory, all crane movements will be stopped	A424		E	2
400058	ZE 4: system error OS-HC11 (observe parameters) amplifier erroneous or return power feed entry in error memory, all crane movements will be stopped check wiring	A424		E	2
400059	ZE 4: system error OS-HC11 (observe parameters) subroutine not reentrant entry in error memory, all crane movements will be stopped	A424		E	2
400060	ZE 4: system error OS-HC11 (observe parameters) transmission error SCI entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A424		E	2
400061	ZE 4: system error OS-HC11 (observe parameters) SCI-BREAK entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A424		E	2
400062	ZE 4: system error OS-HC11 (observe parameters) SCI not connected entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A424		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
400063	ZE 4: system error OS-HC11 (observe parameters) monitor error in operation entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A424		E	2
400065	ZE 4: system error OS-HC11 (observe parameters) impermissible bus address entry in error memory, all crane movements will be stopped	A424		E	2
400066	ZE 4: system error OS-HC11 (observe parameters) ADC working outside the permissible tolerance entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A424		E	2
400067	ZE 4: system error OS-HC11 (observe parameters) arithmetic processor not available entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A424		E	2
400068	ZE 4: system error OS-HC11 (observe parameters) impermissible interrupt entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A424		E	2
400070	ZE 4: system error OS-HC11 (observe parameters) various structure versions entry in error memory, no crane operation possible	A424		E	2
400071	ZE 4: system error OS-HC11 (observe parameters) Structure file missing or faulty entry in error memory, no crane operation possible	A424		E	2
400072	ZE 4: system error OS-HC11 (observe parameters) structure entry senseless entry in error memory, no crane operation possible	A424		E	2
400073	ZE 4: system error OS-HC11 (observe parameters) interpreter error entry in error memory, all crane movements will be stopped	A424		E	2
400074	ZE 4: system error OS-HC11 (observe parameters) transformation ASCII to BIN erroneous entry in error memory, all crane movements will be stopped	A424		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
400075	ZE 4: system error OS-HC11 (observe parameters) SPI-error entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A424		E	2
400076	ZE 4: system error OS-HC11 (observe parameters) incorrectly inserted power unit entry in error memory, all crane movements will be stopped check memory card in power supply unit	A424		E	2
400077	ZE 4: system error OS-HC11 (observe parameters) BAF-call-up erroneous entry in error memory, all crane movements will be stopped	A424		E	2
400078	ZE 4: system error OS-HC11 (observe parameters) impermissible parameter entry in error memory, all crane movements will be stopped	A424		E	2
400079	ZE 4: system error OS-HC11 (observe parameters) no right of access entry in error memory, all crane movements will be stopped	A424		E	2
400080	ZE 4: system error OS-HC11 (observe parameters) Fatal internal error entry in error memory, all crane movements will be stopped	A424		E	2
400081	ZE 4: system error OS-HC11 (observe parameters) stack overflow entry in error memory, all crane movements will be stopped	A424		E	2
400082	ZE 4: system error OS-HC11 (observe parameters) hardware-watchdog erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A424		E	2
400094	ZE 4: system error OS-HC11 (observe parameters) transmission error parallel bus entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A424		E	2
400095	ZE 4: system error OS-HC11 (observe parameters) DMA-error entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A424		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
400099	ZE 4: system error OS-HC11 (observe parameters) DSP0 erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A424		E	2
402001	ZE 4: system error OS-TMS initialising error processor-register erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A424		E	2
402002	ZE 4: system error OS-TMS initialising error test total in EPROM/FLASH erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A424		E	2
402006	ZE 4: system error OS-TMS initialising error RAM erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A424		E	2
402007	ZE 4: system error OS-TMS UART erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A424		E	2
402020	ZE 4: system error OS-TMS task-watchdog expired entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A424		E	2
402021	ZE 4: system error OS-TMS illegal opcode trap entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A424		E	2
402082	ZE 4: system error OS-TMS hardware-watchdog erroneous entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A424		E	2
410012	ZE 4: output 0 short circuit to ground	A424.X1:16		E	1
410013	ZE 4: output 0 open signal circuits	A424.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410014	ZE 4: output 0 short circuit to supply voltage	A424.X1:16		E	1
410054	ZE 4: output 0 short circuit to supply voltage	A424.X1:16		E	1
410058	ZE 4: output 0 positive switching transistor: disruption	A424.X1:16		E	1
410060	ZE 4: output 0 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A424.X1:16		E	1
410062	ZE 4: output 0 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A424.X1:16		E	1
410063	ZE 4: output 0 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A424.X1:16		E	1
410070	ZE 4: output 0 measuring system defect no crane operation possible entry in error list	A424.X1:16		E	1
410071	ZE 4: output 0 short circuit to ground or transistor defect	A424.X1:16		E	1
410072	ZE 4: output 0 outside source feeding	A424.X1:16		E	1
410073	ZE 4: output 0 open circuit or short circuit to supply voltage/ground	A424.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410112	ZE 4: output 1 short circuit to ground	A424.X1:17		E	1
410113	ZE 4: output 1 open signal circuits	A424.X1:17		E	1
410114	ZE 4: output 1 short circuit to supply voltage	A424.X1:17		E	1
410154	ZE 4: output 1 short circuit to supply voltage	A424.X1:17		E	1
410158	ZE 4: output 1 positive switching transistor: disruption	A424.X1:17		E	1
410160	ZE 4: output 1 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A424.X1:17		E	1
410162	ZE 4: output 1 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A424.X1:17		E	1
410163	ZE 4: output 1 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A424.X1:17		E	1
410170	ZE 4: output 1 measuring system defect no crane operation possible entry in error list	A424.X1:17		E	1
410171	ZE 4: output 1 short circuit to ground or transistor defect	A424.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410172	ZE 4: output 1 outside source feeding	A424.X1:17		E	1
410173	ZE 4: output 1 open circuit or short circuit to supply voltage/ground	A424.X1:17		E	1
410212	ZE 4: output 2 short circuit to ground	A424.X1:18		E	1
410213	ZE 4: output 2 open signal circuits	A424.X1:18		E	1
410214	ZE 4: output 2 short circuit to supply voltage	A424.X1:18		E	1
410254	ZE 4: output 2 short circuit to supply voltage	A424.X1:18		E	1
410258	ZE 4: output 2 positive switching transistor: disruption	A424.X1:18		E	1
410270	ZE 4: output 2 measuring system defect no crane operation possible entry in error list	A424.X1:18		E	1
410271	ZE 4: output 2 short circuit to ground or transistor defect	A424.X1:18		E	1
410272	ZE 4: output 2 outside source feeding	A424.X1:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410273	ZE 4: output 2 open circuit or short circuit to supply voltage/ground	A424.X1:18		E	1
410312	ZE 4: output 3 short circuit to ground	A424.X1:19		E	1
410313	ZE 4: output 3 open signal circuits	A424.X1:19		E	1
410314	ZE 4: output 3 short circuit to supply voltage	A424.X1:19		E	1
410354	ZE 4: output 3 short circuit to supply voltage	A424.X1:19		E	1
410358	ZE 4: output 3 positive switching transistor: disruption	A424.X1:19		E	1
410360	ZE 4: output 3 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A424.X1:19		E	1
410362	ZE 4: output 3 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A424.X1:19		E	1
410363	ZE 4: output 3 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A424.X1:19		E	1
410370	ZE 4: output 3 measuring system defect no crane operation possible entry in error list	A424.X1:19		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410371	ZE 4: output 3 short circuit to ground or transistor defect	A424.X1:19		E	1
410372	ZE 4: output 3 outside source feeding	A424.X1:19		E	1
410373	ZE 4: output 3 open circuit or short circuit to supply voltage/ground	A424.X1:19		E	1
410412	ZE 4: output 4 short circuit to ground	A424.X1:20		E	1
410413	ZE 4: output 4 open signal circuits	A424.X1:20		E	1
410414	ZE 4: output 4 short circuit to supply voltage	A424.X1:20		E	1
410454	ZE 4: output 4 short circuit to supply voltage	A424.X1:20		E	1
410458	ZE 4: output 4 positive switching transistor: disruption	A424.X1:20		E	1
410470	ZE 4: output 4 measuring system defect no crane operation possible entry in error list	A424.X1:20		E	1
410471	ZE 4: output 4 short circuit to ground or transistor defect	A424.X1:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410472	ZE 4: output 4 outside source feeding	A424.X1:20		E	1
410473	ZE 4: output 4 open circuit or short circuit to supply voltage/ground	A424.X1:20		E	1
410512	ZE 4: output 5 short circuit to ground	A424.X1:21		E	1
410513	ZE 4: output 5 open signal circuits	A424.X1:21		E	1
410514	ZE 4: output 5 short circuit to supply voltage	A424.X1:21		E	1
410554	ZE 4: output 5 short circuit to supply voltage	A424.X1:21		E	1
410558	ZE 4: output 5 positive switching transistor: disruption	A424.X1:21		E	1
410570	ZE 4: output 5 measuring system defect no crane operation possible entry in error list	A424.X1:21		E	1
410571	ZE 4: output 5 short circuit to ground or transistor defect	A424.X1:21		E	1
410572	ZE 4: output 5 outside source feeding	A424.X1:21		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410573	ZE 4: output 5 open circuit or short circuit to supply voltage/ground	A424.X1:21		E	1
410612	ZE 4: output 6 short circuit to ground	A424.X1:22		E	1
410613	ZE 4: output 6 open signal circuits	A424.X1:22		E	1
410614	ZE 4: output 6 short circuit to supply voltage	A424.X1:22		E	1
410654	ZE 4: output 6 short circuit to supply voltage	A424.X1:22		E	1
410658	ZE 4: output 6 positive switching transistor: disruption	A424.X1:22		E	1
410660	ZE 4: output 6 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A424.X1:22		E	1
410662	ZE 4: output 6 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A424.X1:22		E	1
410663	ZE 4: output 6 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A424.X1:22		E	1
410670	ZE 4: output 6 measuring system defect no crane operation possible entry in error list	A424.X1:22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410671	ZE 4: output 6 short circuit to ground or transistor defect	A424.X1:22		E	1
410672	ZE 4: output 6 outside source feeding	A424.X1:22		E	1
410673	ZE 4: output 6 open circuit or short circuit to supply voltage/ground	A424.X1:22		E	1
410712	ZE 4: output 7 short circuit to ground	A424.X1:23		E	1
410713	ZE 4: output 7 open signal circuits	A424.X1:23		E	1
410714	ZE 4: output 7 short circuit to supply voltage	A424.X1:23		E	1
410754	ZE 4: output 7 short circuit to supply voltage	A424.X1:23		E	1
410758	ZE 4: output 7 positive switching transistor: disruption	A424.X1:23		E	1
410770	ZE 4: output 7 measuring system defect no crane operation possible entry in error list	A424.X1:23		E	1
410771	ZE 4: output 7 short circuit to ground or transistor defect	A424.X1:23		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
410772	ZE 4: output 7 outside source feeding	A424.X1:23		E	1
410773	ZE 4: output 7 open circuit or short circuit to supply voltage/ground	A424.X1:23		E	1
414959	ZE 4: all output supply voltage missing	A424		E	1
415059	ZE 4: output group 0 supply voltage missing	A424.X1:12		E	1
415159	ZE 4: output group 1 supply voltage missing	A424.X1:24		E	1
415259	ZE 4: output group 2 supply voltage missing	A424		E	1
415359	ZE 4: output group 3 supply voltage missing	A424		E	1
420004	ZE 4: LSB participant address 0 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
420005	ZE 4: LSB participant address 0 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
420018	ZE 4: LSB participant address 0 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
420050	ZE 4: LSB participant address 0 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
420051	ZE 4: LSB participant address 0 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
420053	ZE 4: LSB participant address 0 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
420054	ZE 4: LSB participant address 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
420064	ZE 4: LSB participant address 0 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
420065	ZE 4: LSB participant address 0 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
420066	ZE 4: LSB participant address 0 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
420067	ZE 4: LSB participant address 0 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
420104	ZE 4: LSB participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
420105	ZE 4: LSB participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
420118	ZE 4: LSB participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
420150	ZE 4: LSB participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
420151	ZE 4: LSB participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
420153	ZE 4: LSB participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
420154	ZE 4: LSB participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
420164	ZE 4: LSB participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
420165	ZE 4: LSB participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
420166	ZE 4: LSB participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
420167	ZE 4: LSB participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
420304	ZE 4: LSB participant address 3 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
420305	ZE 4: LSB participant address 3 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
420318	ZE 4: LSB participant address 3 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
420350	ZE 4: LSB participant address 3 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
420351	ZE 4: LSB participant address 3 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
420353	ZE 4: LSB participant address 3 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
420354	ZE 4: LSB participant address 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
420364	ZE 4: LSB participant address 3 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
420365	ZE 4: LSB participant address 3 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
420366	ZE 4: LSB participant address 3 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
420367	ZE 4: LSB participant address 3 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
420404	ZE 4: LSB participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
420405	ZE 4: LSB participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
420418	ZE 4: LSB participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
420450	ZE 4: LSB participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
420451	ZE 4: LSB participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
420453	ZE 4: LSB participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
420454	ZE 4: LSB participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
420464	ZE 4: LSB participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
420465	ZE 4: LSB participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
420466	ZE 4: LSB participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
420467	ZE 4: LSB participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
420704	ZE 4: LSB participant address 7 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
420705	ZE 4: LSB participant address 7 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
420718	ZE 4: LSB participant address 7 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
420750	ZE 4: LSB participant address 7 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
420751	ZE 4: LSB participant address 7 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
420753	ZE 4: LSB participant address 7 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
420754	ZE 4: LSB participant address 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
420764	ZE 4: LSB participant address 7 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
420765	ZE 4: LSB participant address 7 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
420766	ZE 4: LSB participant address 7 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
420767	ZE 4: LSB participant address 7 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
420804	ZE 4: LSB participant address 8 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
420805	ZE 4: LSB participant address 8 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
420818	ZE 4: LSB participant address 8 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
420850	ZE 4: LSB participant address 8 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
420851	ZE 4: LSB participant address 8 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
420853	ZE 4: LSB participant address 8 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
420854	ZE 4: LSB participant address 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
420864	ZE 4: LSB participant address 8 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
420865	ZE 4: LSB participant address 8 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
420866	ZE 4: LSB participant address 8 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
420867	ZE 4: LSB participant address 8 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
420904	ZE 4: LSB participant address 9 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
420905	ZE 4: LSB participant address 9 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
420918	ZE 4: LSB participant address 9 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
420950	ZE 4: LSB participant address 9 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
420951	ZE 4: LSB participant address 9 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
420953	ZE 4: LSB participant address 9 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
420954	ZE 4: LSB participant address 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
420964	ZE 4: LSB participant address 9 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
420965	ZE 4: LSB participant address 9 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
420966	ZE 4: LSB participant address 9 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
420967	ZE 4: LSB participant address 9 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421004	ZE 4: LSB participant address 10 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421005	ZE 4: LSB participant address 10 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421018	ZE 4: LSB participant address 10 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421050	ZE 4: LSB participant address 10 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421051	ZE 4: LSB participant address 10 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421053	ZE 4: LSB participant address 10 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421054	ZE 4: LSB participant address 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421064	ZE 4: LSB participant address 10 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421065	ZE 4: LSB participant address 10 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421066	ZE 4: LSB participant address 10 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421067	ZE 4: LSB participant address 10 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421104	ZE 4: LSB participant address 11 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421105	ZE 4: LSB participant address 11 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421118	ZE 4: LSB participant address 11 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421150	ZE 4: LSB participant address 11 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421151	ZE 4: LSB participant address 11 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421153	ZE 4: LSB participant address 11 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421154	ZE 4: LSB participant address 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421164	ZE 4: LSB participant address 11 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421165	ZE 4: LSB participant address 11 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421166	ZE 4: LSB participant address 11 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421167	ZE 4: LSB participant address 11 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421204	ZE 4: LSB participant address 12 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421205	ZE 4: LSB participant address 12 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421218	ZE 4: LSB participant address 12 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421250	ZE 4: LSB participant address 12 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421251	ZE 4: LSB participant address 12 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421253	ZE 4: LSB participant address 12 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421254	ZE 4: LSB participant address 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421264	ZE 4: LSB participant address 12 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421265	ZE 4: LSB participant address 12 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421266	ZE 4: LSB participant address 12 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421267	ZE 4: LSB participant address 12 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421304	ZE 4: LSB participant address 13 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421305	ZE 4: LSB participant address 13 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421318	ZE 4: LSB participant address 13 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421350	ZE 4: LSB participant address 13 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421351	ZE 4: LSB participant address 13 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421353	ZE 4: LSB participant address 13 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421354	ZE 4: LSB participant address 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421364	ZE 4: LSB participant address 13 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421365	ZE 4: LSB participant address 13 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421366	ZE 4: LSB participant address 13 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421367	ZE 4: LSB participant address 13 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421404	ZE 4: LSB participant address 14 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421405	ZE 4: LSB participant address 14 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421418	ZE 4: LSB participant address 14 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421450	ZE 4: LSB participant address 14 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421451	ZE 4: LSB participant address 14 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421453	ZE 4: LSB participant address 14 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421454	ZE 4: LSB participant address 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421464	ZE 4: LSB participant address 14 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421465	ZE 4: LSB participant address 14 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421466	ZE 4: LSB participant address 14 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421467	ZE 4: LSB participant address 14 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421504	ZE 4: LSB participant address 15 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421505	ZE 4: LSB participant address 15 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421518	ZE 4: LSB participant address 15 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421550	ZE 4: LSB participant address 15 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421551	ZE 4: LSB participant address 15 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421553	ZE 4: LSB participant address 15 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421554	ZE 4: LSB participant address 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421564	ZE 4: LSB participant address 15 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421565	ZE 4: LSB participant address 15 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421566	ZE 4: LSB participant address 15 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421567	ZE 4: LSB participant address 15 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421604	ZE 4: LSB participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421605	ZE 4: LSB participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421618	ZE 4: LSB participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421650	ZE 4: LSB participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421651	ZE 4: LSB participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421653	ZE 4: LSB participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421654	ZE 4: LSB participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421664	ZE 4: LSB participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421665	ZE 4: LSB participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421666	ZE 4: LSB participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421667	ZE 4: LSB participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421704	ZE 4: LSB participant address 17 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421705	ZE 4: LSB participant address 17 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421718	ZE 4: LSB participant address 17 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421750	ZE 4: LSB participant address 17 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421751	ZE 4: LSB participant address 17 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421753	ZE 4: LSB participant address 17 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421754	ZE 4: LSB participant address 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421764	ZE 4: LSB participant address 17 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421765	ZE 4: LSB participant address 17 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421766	ZE 4: LSB participant address 17 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421767	ZE 4: LSB participant address 17 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421804	ZE 4: LSB participant address 18 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421805	ZE 4: LSB participant address 18 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421818	ZE 4: LSB participant address 18 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421850	ZE 4: LSB participant address 18 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421851	ZE 4: LSB participant address 18 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421853	ZE 4: LSB participant address 18 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421854	ZE 4: LSB participant address 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
421864	ZE 4: LSB participant address 18 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421865	ZE 4: LSB participant address 18 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421866	ZE 4: LSB participant address 18 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421867	ZE 4: LSB participant address 18 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
421904	ZE 4: LSB participant address 19 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
421905	ZE 4: LSB participant address 19 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
421918	ZE 4: LSB participant address 19 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
421950	ZE 4: LSB participant address 19 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
421951	ZE 4: LSB participant address 19 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
421953	ZE 4: LSB participant address 19 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
421954	ZE 4: LSB participant address 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
421964	ZE 4: LSB participant address 19 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
421965	ZE 4: LSB participant address 19 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
421966	ZE 4: LSB participant address 19 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
421967	ZE 4: LSB participant address 19 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422004	ZE 4: LSB participant address 20 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422005	ZE 4: LSB participant address 20 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422018	ZE 4: LSB participant address 20 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422050	ZE 4: LSB participant address 20 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422051	ZE 4: LSB participant address 20 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422053	ZE 4: LSB participant address 20 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422054	ZE 4: LSB participant address 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422064	ZE 4: LSB participant address 20 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422065	ZE 4: LSB participant address 20 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422066	ZE 4: LSB participant address 20 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422067	ZE 4: LSB participant address 20 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422104	ZE 4: LSB participant address 21 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422105	ZE 4: LSB participant address 21 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422118	ZE 4: LSB participant address 21 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422150	ZE 4: LSB participant address 21 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422151	ZE 4: LSB participant address 21 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422153	ZE 4: LSB participant address 21 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422154	ZE 4: LSB participant address 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422164	ZE 4: LSB participant address 21 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422165	ZE 4: LSB participant address 21 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422166	ZE 4: LSB participant address 21 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422167	ZE 4: LSB participant address 21 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422204	ZE 4: LSB participant address 22 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422205	ZE 4: LSB participant address 22 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422218	ZE 4: LSB participant address 22 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422250	ZE 4: LSB participant address 22 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422251	ZE 4: LSB participant address 22 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422253	ZE 4: LSB participant address 22 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422254	ZE 4: LSB participant address 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422264	ZE 4: LSB participant address 22 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422265	ZE 4: LSB participant address 22 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422266	ZE 4: LSB participant address 22 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422267	ZE 4: LSB participant address 22 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422304	ZE 4: LSB participant address 23 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422305	ZE 4: LSB participant address 23 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422318	ZE 4: LSB participant address 23 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422350	ZE 4: LSB participant address 23 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422351	ZE 4: LSB participant address 23 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422353	ZE 4: LSB participant address 23 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422354	ZE 4: LSB participant address 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422364	ZE 4: LSB participant address 23 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422365	ZE 4: LSB participant address 23 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422366	ZE 4: LSB participant address 23 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422367	ZE 4: LSB participant address 23 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422404	ZE 4: LSB participant address 24 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422405	ZE 4: LSB participant address 24 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422418	ZE 4: LSB participant address 24 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422450	ZE 4: LSB participant address 24 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422451	ZE 4: LSB participant address 24 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422453	ZE 4: LSB participant address 24 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422454	ZE 4: LSB participant address 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422464	ZE 4: LSB participant address 24 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422465	ZE 4: LSB participant address 24 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422466	ZE 4: LSB participant address 24 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422467	ZE 4: LSB participant address 24 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422504	ZE 4: LSB participant address 25 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422505	ZE 4: LSB participant address 25 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422518	ZE 4: LSB participant address 25 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422550	ZE 4: LSB participant address 25 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422551	ZE 4: LSB participant address 25 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422553	ZE 4: LSB participant address 25 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422554	ZE 4: LSB participant address 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422564	ZE 4: LSB participant address 25 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422565	ZE 4: LSB participant address 25 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422566	ZE 4: LSB participant address 25 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422567	ZE 4: LSB participant address 25 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422604	ZE 4: LSB participant address 26 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422605	ZE 4: LSB participant address 26 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422618	ZE 4: LSB participant address 26 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422650	ZE 4: LSB participant address 26 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422651	ZE 4: LSB participant address 26 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422653	ZE 4: LSB participant address 26 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422654	ZE 4: LSB participant address 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422664	ZE 4: LSB participant address 26 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422665	ZE 4: LSB participant address 26 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422666	ZE 4: LSB participant address 26 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422667	ZE 4: LSB participant address 26 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422704	ZE 4: LSB participant address 27 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422705	ZE 4: LSB participant address 27 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422718	ZE 4: LSB participant address 27 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422750	ZE 4: LSB participant address 27 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422751	ZE 4: LSB participant address 27 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422753	ZE 4: LSB participant address 27 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422754	ZE 4: LSB participant address 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422764	ZE 4: LSB participant address 27 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422765	ZE 4: LSB participant address 27 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422766	ZE 4: LSB participant address 27 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422767	ZE 4: LSB participant address 27 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422804	ZE 4: LSB participant address 28 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422805	ZE 4: LSB participant address 28 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422818	ZE 4: LSB participant address 28 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422850	ZE 4: LSB participant address 28 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422851	ZE 4: LSB participant address 28 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422853	ZE 4: LSB participant address 28 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422854	ZE 4: LSB participant address 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
422864	ZE 4: LSB participant address 28 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422865	ZE 4: LSB participant address 28 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422866	ZE 4: LSB participant address 28 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422867	ZE 4: LSB participant address 28 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
422904	ZE 4: LSB participant address 29 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
422905	ZE 4: LSB participant address 29 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
422918	ZE 4: LSB participant address 29 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
422950	ZE 4: LSB participant address 29 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
422951	ZE 4: LSB participant address 29 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
422953	ZE 4: LSB participant address 29 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1
422954	ZE 4: LSB participant address 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
422964	ZE 4: LSB participant address 29 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
422965	ZE 4: LSB participant address 29 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
422966	ZE 4: LSB participant address 29 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
422967	ZE 4: LSB participant address 29 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
423004	ZE 4: LSB participant address 30 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A424.X2:z14/z16		E	1
423005	ZE 4: LSB participant address 30 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A424.X2:z14/z16		E	1
423018	ZE 4: LSB participant address 30 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A424.X2:z14/z16		E	0
423050	ZE 4: LSB participant address 30 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A424.X2:z14/z16		E	2
423051	ZE 4: LSB participant address 30 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A424.X2:z14/z16		E	2
423053	ZE 4: LSB participant address 30 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A424.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
423054	ZE 4: LSB participant address 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A424.X2:z14/z16		E	2
423064	ZE 4: LSB participant address 30 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A424.X2:z14/z16		E	1
423065	ZE 4: LSB participant address 30 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A424.X2:z14/z16		E	2
423066	ZE 4: LSB participant address 30 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A424.X2:z14/z16		E	2
423067	ZE 4: LSB participant address 30 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A424.X2:z14/z16		E	1
423252	ZE 4: Control data transfer LSB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A424.X2:z14/z16		E	0
423255	ZE 4: Control data transfer LSB Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A424.X2:z14/z16		E	2
423256	ZE 4: Control data transfer LSB Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A424.X2:z14/z16		E	2
423257	ZE 4: Control data transfer LSB has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A424.X2:z14/z16		E	1
423258	ZE 4: Control data transfer LSB recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A424.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
423259	ZE 4: Control data transfer LSB recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A424.X2:z14/z16		E	0
423260	ZE 4: Control data transfer LSB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A424.X2:z14/z16		E	2
423261	ZE 4: Control data transfer LSB driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A424.X2:z14/z16		E	2
423262	ZE 4: Control data transfer LSB Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A424.X2:z14/z16		E	2
424814	ZE 4: input 0 short circuit to supply voltage Output of error Check: the sensor line for short-circuits, faulty sensors by pulling out the sensor, connections to the input plate	A424.X2:d2		E	1
424856	ZE 4: input 0 open circuit or short circuit to ground Output of error Check: Supply voltage, input LICCON, sensor lines for interruptions, faulty sensors by pulling out the sensor	A424.X2:d2		E	1
425614	ZE 4: input 8 short circuit to supply voltage Issuance of error at safety chain test. Possibly additional error messages after start Check of supply voltage and corresponding wiring, remedy/rule out damage and/or short circuit	A424.X2:d18		E	2
425714	ZE 4: input 9 short circuit to supply voltage Issuance of error at safety chain test. Possibly additional error messages after start Check of supply voltage and corresponding wiring, remedy/rule out damage and/or short circuit	A424.X2:d20		E	2
426214	ZE 4: input 14 short circuit to supply voltage Issuance of error at safety chain test. Possibly additional error messages after start Check of supply voltage and corresponding wiring, remedy/rule out damage and/or short circuit	A424.X2:d30		E	2
426314	ZE 4: input 15 short circuit to supply voltage Issuance of error at safety chain test. Possibly additional error messages after start Check of supply voltage and corresponding wiring, remedy/rule out damage and/or short circuit	A424.X2:d32		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
430610	ZE 4: Data recorder Start: (still) no valid crane number entered Inspect in 10 sec. cycles Write in coefficients incl. crane number in the NT in "CRANE COMMISSIONING " program (MO > AK)	A424		E	1
430611	ZE 4: Data recorder Start: Crane number faulty (not 9 figures numerically) Data recorder software stops - no documentation possible! Define crane number correctly (Sxxxxxx.yyQ - KNFttt00vrr.Q)	A424		E	1
430612	ZE 4: Data recorder Start: not connected Data recorder software stops - no documentation possible! Connect data logger correctly	A424		E	1
430620	ZE 4: Data recorder Init: Firmware version incorrect/faulty Has not yet been checked!	A424		E	1
430621	ZE 4: Data recorder Init: ATA-card not initialised STATUS-error: Data recorder software stops - no documentation possible! Initialise ATA card with PC-Software "LICCON Manager"	A424		E	1
430622	ZE 4: Data recorder Init: ATA-card contains different crane number STATUS-error: Data recorder software stops - no documentation possible! Use ATA card with correct crane number or newly initialised ATA card	A424		E	1
430623	ZE 4: Data recorder Init: Format-File-Transfer faulty Repeat of Format-File transfers in 1 sec. cycles If necessary correct types and country specific Format-File "Lnnttt01vrr.Q" in EPROM 0	A424		E	1
430630	ZE 4: Data recorder Transfer: Data transmission faulty Repeat of data transfers in 1 sec. cycles If necessary check connection from LICCON system to data recorder	A424		E	1
430631	ZE 4: Data recorder Transfer: CSM-protocol error Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A424		E	1
430632	ZE 4: Data recorder Transfer: Transmission error (CRC) Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A424		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
430633	ZE 4: Data recorder Transfer: STATUS-error Dependent upon STATUS in 1 sec. cycles synchronise anew or stop data recorder software If necessary check connection from LICCON system to data recorder	A424		E	1
430634	ZE 4: Data recorder Transfer: TAN-error Synchronise CSM protocol again completely If necessary check connection from LICCON system to data recorder	A424		E	1
430635	ZE 4: Data recorder Transfer: Writing error Synchronise CSM protocol again completely If necessary check connection from LICCON-System to data recorder and ATA card	A424		E	1
430636	ZE 4: Data recorder Transfer: No recorder data (SPS-Handshake) LICCON-data logger software tries again in 1 sec. cycle Check function of SPS software	A424		E	1
432400	ZE 4: control winch 5 no slewing movement recognized on actuated winch output of error check LICCON output, lines for short or break, incremental sensor on function, hoisting gear brake	A424		E	1
432402	ZE 4: control winch 5 hydraulic circuit pressure sensor defective/missing if valid winch torque for LMB is available this will be used, otherwise 0 bar is loaded into pressure value memory check supply, LICCON input, sensor lines to short or break, sensor	A424		E	1
432418	ZE 4: control winch 5 Pressure too high when pump is not actuated Output of error Check pump or pressure sensor	A424		E	
432427	ZE 4: control winch 5 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A424		E	1
43242D	ZE 4: control winch 5 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A424		E	1
43242F	ZE 4: control winch 5 Repl. Pr. Switch continuous actuation or short circuit after VCC output of error Check: - input LICCON, line for short circuit after supply voltage, pressure switch for function	A424		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
432441	ZE 4: control winch 5 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A424		E	1
432442	ZE 4: control winch 5 Rotation movement at non-actuated winch brake error report Check winch brake. Check winch turn sensor(installation)	A424		E	1
435401	ZE 4: operation winch 5 feed pressure supply missing/too low Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A424		B	
435403	ZE 4: operation winch 5 Shut-down jib lower Operation conditional switch off, may not be shunted Luff up jib until limit switch no longer activated - shut-down may not be shunted	A424		B	
435404	ZE 4: operation winch 5 unreeled winch shut-down Operation conditional switch off, may not be shunted reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A424		B	
435405	ZE 4: operation winch 5 reeled winch shut-down Operation conditional switch off, may not be shunted Wind off winch until switch "Winch wound on" is no longer activated - shut-down may not be shunted	A424		B	
435406	ZE 4: operation winch 5 upper angle limit OGW shut-down operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A424		B	
435407	ZE 4: operation winch 5 lower angle limit UGW shut-down operational shut down reel winch in until the radius is within the load chart again - shut-down can be shunted (danger)	A424		B	
435410	ZE 4: operation winch 5 fly jib upper stop shut-down Operation conditional switch off, may not be shunted Luff down jib until limit switch no longer activated - shut-down may not be activated	A424		B	
435411	ZE 4: operation winch 5 fly jib upper flap shut-down Operation conditional switch off, may not be shunted Luff down jib until limit switch no longer activated - shut-down may not be activated	A424		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
435413	ZE 4: operation winch 5 shut-down as flap not positioned and angle threshold exceeded Operation conditional switch off, may not be shunted check as to why the flap is not in position - shut-down cannot be shunted	A424		B	
435414	ZE 4: operation winch 5 pressure retaining cylinder RFP N shut-down outside set range Operation conditional switch off, may not be shunted Wind off winch until pressure is once again within the desired range - shut-down may not be shunted .	A424		B	
435416	ZE 4: operation winch 5 luffing up accessory shut-down working area limitation ABB operational shut down reel winch out until crane in working area again - shunting through shutting down of working area limitation	A424		B	
435417	ZE 4: operation winch 5 luffing down accessory shut-down working area limitation ABB operational shut down reel winch in until crane in working area again - shunting through shutting down of working area limitation	A424		B	
435419	ZE 4: operation winch 5 no or invalid operation mode shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A424		B	
435420	ZE 4: operation winch 5 LMB shut-down operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A424		B	
435421	ZE 4: operation winch 5 Shut-down measuring point 1 > F max - operation Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A424		B	
435422	ZE 4: operation winch 5 Shut-down measuring point 1 > F max - assembly operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A424		B	
435424	ZE 4: operation winch 5 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A424		B	
435425	ZE 4: operation winch 5 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A424		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
435426	ZE 4: operation winch 5 Shut-down upper limit angle derrick OGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A424		B	
435427	ZE 4: operation winch 5 Shut-down lower limit angle derrick UGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A424		B	
435428	ZE 4: operation winch 5 Shut-down upper limit angle main boom Operation conditional switch off, may not be shunted Spool up - out winch 5 is only permitted at main boom positions small limit angle	A424		B	
435429	ZE 4: operation winch 5 winch blocked (C-key monitor) Operation conditional switch off, may not be shunted Authorise winch 5 in control diagram.	A424		B	
43542B	ZE 4: operation winch 5 Shut off Derrick ballast pulled > Derrick ballast max Operation conditional switch off, may not be shunted Fix cause of "LMB Stop", see error message	A424		B	
435430	ZE 4: operation winch 5 master switch 1 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A424		B	
435431	ZE 4: operation winch 5 master switch 2 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A424		B	
435432	ZE 4: operation winch 5 master switch 3 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A424		B	
435438	ZE 4: operation winch 5 Shut-down upper limit angle accessory Operation conditional switch off, may not be shunted Luff up main boom during erection procedure, luff down main boom or accessory during setting down procedure.	A424		B	
435439	ZE 4: operation winch 5 seat contact shut-down operational shut down Sit down or actuate one of the shunting switches for the seat contact in the master switches.	A424		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
43543E	ZE 4: operation winch 5 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A424		B	1
435444	ZE 4: operation winch 5 Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A424		B	
435446	ZE 4: operation winch 5 Shut off control panel plugged in operational shut down Spool up - out winch 5 is only permitted with switched on installation switch .	A424		B	
435450	ZE 4: operation winch 5 end of stroke switch shut-down 1 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A424		B	
435451	ZE 4: operation winch 5 end of stroke switch shut-down 2 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A424		B	
435452	ZE 4: operation winch 5 end of stroke switch shut-down 3 operational shut down control winch in opposite direction until end stroke switch no longer active - shut-down can be shunted (danger)	A424		B	
435457	ZE 4: operation winch 5 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders SA-frame	A424		B	
435463	ZE 4: operation winch 5 Crane engine in overspeed Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A424		B	
435465	ZE 4: operation winch 5 Assembly switch is not turned on operational shut down Spool up - out winch 5 is only permitted with switched on installation switch .	A424		B	
435466	ZE 4: operation winch 5 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A424		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
435467	ZE 4: operation winch 5 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A424		B	
435470	ZE 4: operation winch 5 shut-down both limit switches "flap in position" defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A424		B	
435472	ZE 4: operation winch 5 shut-down both angle sensors "fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A424		B	
435473	ZE 4: operation winch 5 shut-down both limit switches "lower fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A424		B	
435474	ZE 4: operation winch 5 shut-down both limit switches "upper fly jib flap" defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A424		B	
435475	ZE 4: operation winch 5 shut-down both limit switches "upper fly jib stop"defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A424		B	
43547A	ZE 4: operation winch 5 Shut off Radio assembly BTT-E Main boom angle exceeded	A424		B	
43547C	ZE 4: operation winch 5 Shut off Radio assembly BTT-E Accessory angle exceeded	A424		B	
435481	ZE 4: operation winch 5 end of stroke switch 1 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A424		B	
435482	ZE 4: operation winch 5 end of stroke switch 2 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A424		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
435483	ZE 4: operation winch 5 end of stroke switch 3 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A424		B	
43549A	ZE 4: operation winch 5 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders main boom	A424		B	
43549B	ZE 4: operation winch 5 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted Check pressure supply Relapse cylinders Derrick	A424		B	
4354B3	ZE 4: operation winch 5 Shut off Test point 1 < F min and upper limit angle Derrick OGWD operational shut down If possible, move derrick boom in op. position, for that assembly - winch 4 can be lowered	A424		B	
4354B5	ZE 4: operation winch 5 Master switch right BTTE erroneous/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A424		B	
4354C6	ZE 4: operation winch 5 Shut-off test point 3 < F min Operation conditional switch off, may not be shunted Lower load or lower derrick ballast if possible or spool out retraction gear if possible.	A424		B	
4354D3	ZE 4: operation winch 5 Shut off since SLGS-Winch, press deadman longer output of error, shut-down through application First press Deadman MS2 for 1.5 sec, then deflect MS2Y, then release Deadman button	A424		B	
436942	ZE 4: Operation crane control Emergency op. crane cont. switched on with start test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A424		B	1
436943	ZE 4: Operation crane control Emergency op. crane control switched on during test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A424		B	1
436948	ZE 4: Operation crane control Selection bypass hoist top - not possible - try again operational shut down Bypass is only permitted on limited basis and time controlled, possibly bypass can be reactivated	A424		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
436949	ZE 4: Operation crane control Selection bypass LMB - not possible - try again operational shut down Bypass is only permitted on limited basis and time controlled, possibly bypass can be reactivated	A424		B	2
43694A	ZE 4: Operation crane control Selection bypass LMB - not permissible for this utilization Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A424		B	2
43694E	ZE 4: Operation crane control Caution special function for reductions/ bypasses activated Special function as desired issue of op. error Change data word DWx.xxx or turn ignition off / on	A424		B	2
43694F	ZE 4: Operation crane control Caution, Activation EN13000 not possible EN 13000 is deactivated or cannot be activated, since option 85% chart is activated Activcation of bypass acc. EN 13000 here not possible.	A424		B	2
436955	ZE 4: Operation crane control Selection bypass LMB not permissible for this F1-utilization	A424		B	2
43695B	ZE 4: Operation crane control Selection bypass hoist top not possible - no shut off Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A424		B	2
43695C	ZE 4: Operation crane control Selection this bypass not possible - sensor defect Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A424		B	2
43695F	ZE 4: Operation crane control Selection bypass not possible - crane engine still running	A424		B	2
436960	ZE 4: Operation crane control Selection bypass not possible - seat contact not actuated Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A424		B	2
436962	ZE 4: Operation crane control Selection bypass not possible - zero pos. force required Slewing brake applied or cannot be opened + LMB-Stop since no load chart present Pin turntable or luff up boom to valid load chart	A424		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
461001	E/A-Modul 4: system error OS-C167 initialising error processor-register erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A14		E	2
461002	E/A-Modul 4: system error OS-C167 initialising error test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A14		E	2
461006	E/A-Modul 4: system error OS-C167 initialising error RAM erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A14		E	2
461013	E/A-Modul 4: system error OS-C167 test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A14		E	2
461016	E/A-Modul 4: system error OS-C167 system-, driver-watchdog expired error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A14		E	2
461048	E/A-Modul 4: system error OS-C167 Synchronisation not successful due to read time several times 0 Safety measure is initiated Check CAN network, check faulty Bus user.	A14		E	1
461049	E/A-Modul 4: system error OS-C167 Error in order: Strobe-Signal, Sync-Signal Safety measure is initiated Check CAN network, check faulty Bus user.	A14		E	1
461050	E/A-Modul 4: system error OS-C167 Correction with synchronisation > 1ms, although already synchronised Safety measure is initiated Check CAN network, check faulty Bus user.	A14		E	1
461053	E/A-Modul 4: system error OS-C167 User stack too small Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A14		E	1
461068	E/A-Modul 4: system error OS-C167 impermissible interrupt error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A14		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
461071	E/A-Modul 4: system error OS-C167 Invalid configuration or Firmware error indication on display re-load Software from ZE	A14		E	2
461080	E/A-Modul 4: system error OS-C167 fatal internal software error error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A14		E	2
461082	E/A-Modul 4: system error OS-C167 hardware-watchdog erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A14		E	2
461088	E/A-Modul 4: system error OS-C167 Configuration does not match software condition error indication on display Comparison SW-condition EAM-SW and configuration LICCON different, check LICCON-configuration, download EAM	A14		E	2
461089	E/A-Modul 4: system error OS-C167 Incorrect version of firmware installed Error output, possible error functions of module Replace module, reload firmware	A14		E	1
461090	E/A-Modul 4: system error OS-C167 Incorrect hardware version recognised Error output, possible error functions of module Replace module	A14		E	1
472052	E/A-Modul 4: input/output DEA0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:17		E	1
472053	E/A-Modul 4: input/output DEA0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:17		E	1
472054	E/A-Modul 4: input/output DEA0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:17		E	1
472055	E/A-Modul 4: input/output DEA0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
472152	E/A-Modul 4: input/output DEA1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:15		E	1
472153	E/A-Modul 4: input/output DEA1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:15		E	1
472154	E/A-Modul 4: input/output DEA1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:15		E	1
472155	E/A-Modul 4: input/output DEA1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:15		E	1
472252	E/A-Modul 4: input/output DEA2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:13		E	1
472253	E/A-Modul 4: input/output DEA2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:13		E	1
472254	E/A-Modul 4: input/output DEA2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:13		E	1
472255	E/A-Modul 4: input/output DEA2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:13		E	1
472352	E/A-Modul 4: input/output DEA3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:11		E	1
472353	E/A-Modul 4: input/output DEA3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
472354	E/A-Modul 4: input/output DEA3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:11		E	1
472355	E/A-Modul 4: input/output DEA3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:11		E	1
472452	E/A-Modul 4: input/output DEA4 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:9		E	1
472453	E/A-Modul 4: input/output DEA4 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:9		E	1
472454	E/A-Modul 4: input/output DEA4 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:9		E	1
472455	E/A-Modul 4: input/output DEA4 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:9		E	1
472552	E/A-Modul 4: input/output DEA5 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:7		E	1
472553	E/A-Modul 4: input/output DEA5 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:7		E	1
472554	E/A-Modul 4: input/output DEA5 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:7		E	1
472555	E/A-Modul 4: input/output DEA5 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
472652	E/A-Modul 4: input/output DEA6 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:5		E	1
472653	E/A-Modul 4: input/output DEA6 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:5		E	1
472654	E/A-Modul 4: input/output DEA6 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:5		E	1
472655	E/A-Modul 4: input/output DEA6 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:5		E	1
472752	E/A-Modul 4: input/output DEA7 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:3		E	1
472753	E/A-Modul 4: input/output DEA7 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:3		E	1
472754	E/A-Modul 4: input/output DEA7 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:3		E	1
472755	E/A-Modul 4: input/output DEA7 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:3		E	1
473080	E/A-Modul 4: current input E0 short circuit to ground, open line, voltage sensor erroneous Output of error check input signal on the E/A-Modul or sensor	A14.X2:17		E	1
473117	E/A-Modul 4: current input E1 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14.X2:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
473179	E/A-Modul 4: current input E1 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14.X2:15		E	1
473180	E/A-Modul 4: current input E1 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14.X2:15		E	1
473217	E/A-Modul 4: current input E2 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14.X2:13		E	1
473279	E/A-Modul 4: current input E2 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14.X2:13		E	1
473280	E/A-Modul 4: current input E2 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14.X2:13		E	1
473517	E/A-Modul 4: voltage input E5 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:7		E	1
473579	E/A-Modul 4: voltage input E5 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:7		E	1
473580	E/A-Modul 4: voltage input E5 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:7		E	1
473617	E/A-Modul 4: voltage input E6 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:5		E	1
473679	E/A-Modul 4: voltage input E6 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
473680	E/A-Modul 4: voltage input E6 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:5		E	1
473717	E/A-Modul 4: voltage input E7 voltage below required value Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:3		E	1
473779	E/A-Modul 4: voltage input E7 Short circuit after supply voltage, over-tension Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:3		E	1
473780	E/A-Modul 4: voltage input E7 short circuit to ground, open line, voltage sensor erroneous Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14.X2:3		E	1
479052	E/A-Modul 4: output A0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:18		E	1
479053	E/A-Modul 4: output A0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:18		E	1
479054	E/A-Modul 4: output A0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:18		E	1
479055	E/A-Modul 4: output A0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:18		E	1
479152	E/A-Modul 4: output A1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:16		E	1
479153	E/A-Modul 4: output A1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
479154	E/A-Modul 4: output A1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:16		E	1
479155	E/A-Modul 4: output A1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:16		E	1
479250	E/A-Modul 4: bridge output A2 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A14.X3:14		E	1
479251	E/A-Modul 4: bridge output A2 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A14.X3:14		E	1
479252	E/A-Modul 4: bridge output A2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:14		E	1
479253	E/A-Modul 4: bridge output A2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:14		E	1
479254	E/A-Modul 4: bridge output A2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:14		E	1
479255	E/A-Modul 4: bridge output A2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:14		E	1
479350	E/A-Modul 4: bridge output A3 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A14.X3:12		E	1
479351	E/A-Modul 4: bridge output A3 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A14.X3:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
479352	E/A-Modul 4: bridge output A3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A14.X3:12		E	1
479353	E/A-Modul 4: bridge output A3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A14.X3:12		E	1
479354	E/A-Modul 4: bridge output A3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A14.X3:12		E	1
479355	E/A-Modul 4: bridge output A3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A14.X3:12		E	1
483601	E/A-Modul 4: SPI-support unit left Faulty data transfer E/A-module<->unit (time exceeded) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A14.X4:1/2/3/5/6/7/8		E	1
483602	E/A-Modul 4: SPI-support unit left Serious system error to SPI-connection (interface) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A14.X4:1/2/3/5/6/7/8		E	1
483603	E/A-Modul 4: SPI-support unit left break in line or short circuit to supply voltage error indication on display remedy short circuit, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A14.X4:1/2/3/5/6/7/8		E	1
483604	E/A-Modul 4: SPI-support unit left break in line or short circuit to ground error indication on display remedy short circuit, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A14.X4:1/2/3/5/6/7/8		E	1
483606	E/A-Modul 4: SPI-support unit left Data transfer faulty (faulty check byte) error indication on display suppress EMV- interference	A14.X4:1/2/3/5/6/7/8		E	1
483607	E/A-Modul 4: SPI-support unit left Unit faulty/missing, incorrect unit inserted (ID) error indication on display check periphery and replace if necessary, check Software version, check EMV- interference	A14.X4:1/2/3/5/6/7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
483608	E/A-Modul 4: SPI-support unit left Data transfer faulty (incorrect number of data bytes received) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A14.X4:1/2/3/5/6/7/8		E	1
483900	E/A-Modul 4: Control operating unit (SPI) Faulty initialisation data connection E/A-module<->unit error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A14.X4:1/2/3/5/6/7/8		E	1
483902	E/A-Modul 4: Control operating unit (SPI) Serious system error to SPI-connection (interface) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A14.X4:1/2/3/5/6/7/8		E	1
483905	E/A-Modul 4: Control operating unit (SPI) Initialisation error, resetting inputs/outputs faulty error indication on display check wiring, check periphery and replace if necessary, check E/A-Modul and replace if necessary	A14.X4:1/2/3/5/6/7/8		E	1
483907	E/A-Modul 4: Control operating unit (SPI) Unit faulty/missing, incorrect unit inserted (ID) error indication on display connect functional periphery unit, system then eliminates error independently	A14.X4:1/2/3/5/6/7/8		E	1
483908	E/A-Modul 4: Control operating unit (SPI) Data transfer faulty (incorrect number of data bytes received) error indication on display system re-starts SPI-driver and eliminates error independently, with repeated occurrence replace E/A-Modul	A14.X4:1/2/3/5/6/7/8		E	1
484104	E/A-Modul 4: LSB-B participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
484105	E/A-Modul 4: LSB-B participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
484118	E/A-Modul 4: LSB-B participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
484150	E/A-Modul 4: LSB-B participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484151	E/A-Modul 4: LSB-B participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
484153	E/A-Modul 4: LSB-B participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
484154	E/A-Modul 4: LSB-B participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
484164	E/A-Modul 4: LSB-B participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
484165	E/A-Modul 4: LSB-B participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
484166	E/A-Modul 4: LSB-B participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
484167	E/A-Modul 4: LSB-B participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
484204	E/A-Modul 4: LSB-B participant address 2 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
484205	E/A-Modul 4: LSB-B participant address 2 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
484218	E/A-Modul 4: LSB-B participant address 2 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484250	E/A-Modul 4: LSB-B participant address 2 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
484251	E/A-Modul 4: LSB-B participant address 2 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
484253	E/A-Modul 4: LSB-B participant address 2 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
484254	E/A-Modul 4: LSB-B participant address 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
484264	E/A-Modul 4: LSB-B participant address 2 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
484265	E/A-Modul 4: LSB-B participant address 2 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
484266	E/A-Modul 4: LSB-B participant address 2 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
484267	E/A-Modul 4: LSB-B participant address 2 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
484304	E/A-Modul 4: LSB-B participant address 3 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
484305	E/A-Modul 4: LSB-B participant address 3 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484318	E/A-Modul 4: LSB-B participant address 3 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
484350	E/A-Modul 4: LSB-B participant address 3 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
484351	E/A-Modul 4: LSB-B participant address 3 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
484353	E/A-Modul 4: LSB-B participant address 3 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
484354	E/A-Modul 4: LSB-B participant address 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
484364	E/A-Modul 4: LSB-B participant address 3 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
484365	E/A-Modul 4: LSB-B participant address 3 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
484366	E/A-Modul 4: LSB-B participant address 3 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
484367	E/A-Modul 4: LSB-B participant address 3 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
484404	E/A-Modul 4: LSB-B participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484405	E/A-Modul 4: LSB-B participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
484418	E/A-Modul 4: LSB-B participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
484450	E/A-Modul 4: LSB-B participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
484451	E/A-Modul 4: LSB-B participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
484453	E/A-Modul 4: LSB-B participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
484454	E/A-Modul 4: LSB-B participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
484464	E/A-Modul 4: LSB-B participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
484465	E/A-Modul 4: LSB-B participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
484466	E/A-Modul 4: LSB-B participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
484467	E/A-Modul 4: LSB-B participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484504	E/A-Modul 4: LSB-B participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
484505	E/A-Modul 4: LSB-B participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
484518	E/A-Modul 4: LSB-B participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
484550	E/A-Modul 4: LSB-B participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
484551	E/A-Modul 4: LSB-B participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
484553	E/A-Modul 4: LSB-B participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
484554	E/A-Modul 4: LSB-B participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
484564	E/A-Modul 4: LSB-B participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
484565	E/A-Modul 4: LSB-B participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
484566	E/A-Modul 4: LSB-B participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484567	E/A-Modul 4: LSB-B participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
484604	E/A-Modul 4: LSB-B participant address 6 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
484605	E/A-Modul 4: LSB-B participant address 6 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
484618	E/A-Modul 4: LSB-B participant address 6 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
484650	E/A-Modul 4: LSB-B participant address 6 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
484651	E/A-Modul 4: LSB-B participant address 6 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
484653	E/A-Modul 4: LSB-B participant address 6 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
484654	E/A-Modul 4: LSB-B participant address 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
484664	E/A-Modul 4: LSB-B participant address 6 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
484665	E/A-Modul 4: LSB-B participant address 6 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484666	E/A-Modul 4: LSB-B participant address 6 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
484667	E/A-Modul 4: LSB-B participant address 6 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
484704	E/A-Modul 4: LSB-B participant address 7 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
484705	E/A-Modul 4: LSB-B participant address 7 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
484718	E/A-Modul 4: LSB-B participant address 7 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
484750	E/A-Modul 4: LSB-B participant address 7 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
484751	E/A-Modul 4: LSB-B participant address 7 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
484753	E/A-Modul 4: LSB-B participant address 7 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
484754	E/A-Modul 4: LSB-B participant address 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
484764	E/A-Modul 4: LSB-B participant address 7 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484765	E/A-Modul 4: LSB-B participant address 7 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
484766	E/A-Modul 4: LSB-B participant address 7 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
484767	E/A-Modul 4: LSB-B participant address 7 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
484804	E/A-Modul 4: LSB-B participant address 8 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
484805	E/A-Modul 4: LSB-B participant address 8 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
484818	E/A-Modul 4: LSB-B participant address 8 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
484850	E/A-Modul 4: LSB-B participant address 8 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
484851	E/A-Modul 4: LSB-B participant address 8 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
484853	E/A-Modul 4: LSB-B participant address 8 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
484854	E/A-Modul 4: LSB-B participant address 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
484864	E/A-Modul 4: LSB-B participant address 8 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
484865	E/A-Modul 4: LSB-B participant address 8 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
484866	E/A-Modul 4: LSB-B participant address 8 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
484867	E/A-Modul 4: LSB-B participant address 8 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
485004	E/A-Modul 4: LSB-B participant address 10 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
485005	E/A-Modul 4: LSB-B participant address 10 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
485018	E/A-Modul 4: LSB-B participant address 10 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
485050	E/A-Modul 4: LSB-B participant address 10 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
485051	E/A-Modul 4: LSB-B participant address 10 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
485053	E/A-Modul 4: LSB-B participant address 10 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
485054	E/A-Modul 4: LSB-B participant address 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
485064	E/A-Modul 4: LSB-B participant address 10 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
485065	E/A-Modul 4: LSB-B participant address 10 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
485066	E/A-Modul 4: LSB-B participant address 10 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
485067	E/A-Modul 4: LSB-B participant address 10 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
485104	E/A-Modul 4: LSB-B participant address 11 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
485105	E/A-Modul 4: LSB-B participant address 11 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
485118	E/A-Modul 4: LSB-B participant address 11 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
485150	E/A-Modul 4: LSB-B participant address 11 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
485151	E/A-Modul 4: LSB-B participant address 11 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
485153	E/A-Modul 4: LSB-B participant address 11 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
485154	E/A-Modul 4: LSB-B participant address 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
485164	E/A-Modul 4: LSB-B participant address 11 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
485165	E/A-Modul 4: LSB-B participant address 11 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
485166	E/A-Modul 4: LSB-B participant address 11 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
485167	E/A-Modul 4: LSB-B participant address 11 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
485604	E/A-Modul 4: LSB-B participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
485605	E/A-Modul 4: LSB-B participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
485618	E/A-Modul 4: LSB-B participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
485650	E/A-Modul 4: LSB-B participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
485651	E/A-Modul 4: LSB-B participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
485653	E/A-Modul 4: LSB-B participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
485654	E/A-Modul 4: LSB-B participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
485664	E/A-Modul 4: LSB-B participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
485665	E/A-Modul 4: LSB-B participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
485666	E/A-Modul 4: LSB-B participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
485667	E/A-Modul 4: LSB-B participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
485704	E/A-Modul 4: LSB-B participant address 17 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
485705	E/A-Modul 4: LSB-B participant address 17 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
485718	E/A-Modul 4: LSB-B participant address 17 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
485750	E/A-Modul 4: LSB-B participant address 17 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
485751	E/A-Modul 4: LSB-B participant address 17 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
485753	E/A-Modul 4: LSB-B participant address 17 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
485754	E/A-Modul 4: LSB-B participant address 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
485764	E/A-Modul 4: LSB-B participant address 17 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
485765	E/A-Modul 4: LSB-B participant address 17 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
485766	E/A-Modul 4: LSB-B participant address 17 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
485767	E/A-Modul 4: LSB-B participant address 17 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
485804	E/A-Modul 4: LSB-B participant address 18 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
485805	E/A-Modul 4: LSB-B participant address 18 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
485818	E/A-Modul 4: LSB-B participant address 18 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
485850	E/A-Modul 4: LSB-B participant address 18 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
485851	E/A-Modul 4: LSB-B participant address 18 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
485853	E/A-Modul 4: LSB-B participant address 18 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
485854	E/A-Modul 4: LSB-B participant address 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
485864	E/A-Modul 4: LSB-B participant address 18 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
485865	E/A-Modul 4: LSB-B participant address 18 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
485866	E/A-Modul 4: LSB-B participant address 18 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
485867	E/A-Modul 4: LSB-B participant address 18 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
485904	E/A-Modul 4: LSB-B participant address 19 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
485905	E/A-Modul 4: LSB-B participant address 19 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
485918	E/A-Modul 4: LSB-B participant address 19 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
485950	E/A-Modul 4: LSB-B participant address 19 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
485951	E/A-Modul 4: LSB-B participant address 19 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
485953	E/A-Modul 4: LSB-B participant address 19 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
485954	E/A-Modul 4: LSB-B participant address 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
485964	E/A-Modul 4: LSB-B participant address 19 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
485965	E/A-Modul 4: LSB-B participant address 19 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
485966	E/A-Modul 4: LSB-B participant address 19 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
485967	E/A-Modul 4: LSB-B participant address 19 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
486004	E/A-Modul 4: LSB-B participant address 20 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
486005	E/A-Modul 4: LSB-B participant address 20 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
486018	E/A-Modul 4: LSB-B participant address 20 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
486050	E/A-Modul 4: LSB-B participant address 20 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
486051	E/A-Modul 4: LSB-B participant address 20 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
486053	E/A-Modul 4: LSB-B participant address 20 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
486054	E/A-Modul 4: LSB-B participant address 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
486064	E/A-Modul 4: LSB-B participant address 20 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
486065	E/A-Modul 4: LSB-B participant address 20 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
486066	E/A-Modul 4: LSB-B participant address 20 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
486067	E/A-Modul 4: LSB-B participant address 20 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
486604	E/A-Modul 4: LSB-B participant address 26 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
486605	E/A-Modul 4: LSB-B participant address 26 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
486618	E/A-Modul 4: LSB-B participant address 26 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
486650	E/A-Modul 4: LSB-B participant address 26 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
486651	E/A-Modul 4: LSB-B participant address 26 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
486653	E/A-Modul 4: LSB-B participant address 26 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
486654	E/A-Modul 4: LSB-B participant address 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
486664	E/A-Modul 4: LSB-B participant address 26 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
486665	E/A-Modul 4: LSB-B participant address 26 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
486666	E/A-Modul 4: LSB-B participant address 26 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
486667	E/A-Modul 4: LSB-B participant address 26 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
486704	E/A-Modul 4: LSB-B participant address 27 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
486705	E/A-Modul 4: LSB-B participant address 27 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
486718	E/A-Modul 4: LSB-B participant address 27 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
486750	E/A-Modul 4: LSB-B participant address 27 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
486751	E/A-Modul 4: LSB-B participant address 27 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
486753	E/A-Modul 4: LSB-B participant address 27 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
486754	E/A-Modul 4: LSB-B participant address 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
486764	E/A-Modul 4: LSB-B participant address 27 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
486765	E/A-Modul 4: LSB-B participant address 27 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
486766	E/A-Modul 4: LSB-B participant address 27 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
486767	E/A-Modul 4: LSB-B participant address 27 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
486804	E/A-Modul 4: LSB-B participant address 28 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
486805	E/A-Modul 4: LSB-B participant address 28 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
486818	E/A-Modul 4: LSB-B participant address 28 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
486850	E/A-Modul 4: LSB-B participant address 28 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
486851	E/A-Modul 4: LSB-B participant address 28 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
486853	E/A-Modul 4: LSB-B participant address 28 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1
486854	E/A-Modul 4: LSB-B participant address 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
486864	E/A-Modul 4: LSB-B participant address 28 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
486865	E/A-Modul 4: LSB-B participant address 28 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
486866	E/A-Modul 4: LSB-B participant address 28 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
486867	E/A-Modul 4: LSB-B participant address 28 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
486904	E/A-Modul 4: LSB-B participant address 29 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A14.X3:4/6		E	1
486905	E/A-Modul 4: LSB-B participant address 29 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A14.X3:4/6		E	1
486918	E/A-Modul 4: LSB-B participant address 29 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A14.X3:4/6		E	0
486950	E/A-Modul 4: LSB-B participant address 29 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A14.X3:4/6		E	2
486951	E/A-Modul 4: LSB-B participant address 29 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A14.X3:4/6		E	2
486953	E/A-Modul 4: LSB-B participant address 29 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A14.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
486954	E/A-Modul 4: LSB-B participant address 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A14.X3:4/6		E	2
486964	E/A-Modul 4: LSB-B participant address 29 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A14.X3:4/6		E	1
486965	E/A-Modul 4: LSB-B participant address 29 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A14.X3:4/6		E	2
486966	E/A-Modul 4: LSB-B participant address 29 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A14.X3:4/6		E	2
486967	E/A-Modul 4: LSB-B participant address 29 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A14.X3:4/6		E	1
487252	E/A-Modul 4: Control data transfer LSB-B has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A14.X3:4/6		E	0
487255	E/A-Modul 4: Control data transfer LSB-B Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A14.X3:4/6		E	2
487256	E/A-Modul 4: Control data transfer LSB-B Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A14.X3:4/6		E	2
487257	E/A-Modul 4: Control data transfer LSB-B has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A14.X3:4/6		E	1
487258	E/A-Modul 4: Control data transfer LSB-B recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A14.X3:4/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
487259	E/A-Modul 4: Control data transfer LSB-B recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A14.X3:4/6		E	0
487260	E/A-Modul 4: Control data transfer LSB-B driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A14.X3:4/6		E	2
487261	E/A-Modul 4: Control data transfer LSB-B driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A14.X3:4/6		E	2
487262	E/A-Modul 4: Control data transfer LSB-B Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A14.X3:4/6		E	2
488130	E/A-Modul 4: CAN-subscriber steering valve 1 (EHS1) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A14.X5:5/6		E	0
488131	E/A-Modul 4: CAN-subscriber steering valve 1 (EHS1) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1
488230	E/A-Modul 4: CAN-subscriber steering valve 2 (EHS2) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A14.X5:5/6		E	0
488231	E/A-Modul 4: CAN-subscriber steering valve 2 (EHS2) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1
488330	E/A-Modul 4: CAN-subscriber steering valve 3 (EHS3) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A14.X5:5/6		E	0
488331	E/A-Modul 4: CAN-subscriber steering valve 3 (EHS3) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
488430	E/A-Modul 4: CAN-subscriber steering valve 4 (EHS4) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A14.X5:5/6		E	0
488431	E/A-Modul 4: CAN-subscriber steering valve 4 (EHS4) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1
488730	E/A-Modul 4: CAN-participant E/A-Modul 3 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A14.X5:5/6		E	0
488731	E/A-Modul 4: CAN-participant E/A-Modul 3 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1
488830	E/A-Modul 4: CAN-participant E/A-Modul 4 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1
488831	E/A-Modul 4: CAN-participant E/A-Modul 4 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1
489731	E/A-Modul 4: CAN-transmission analogous input values Data transfer faulty/missing, max. cycle time exceeded System message could not be transmitted Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1
489831	E/A-Modul 4: CAN-transmission system time (master) Data transfer faulty/missing, max. cycle time exceeded System message could not be transmitted Check CAN network, check faulty Bus user.	A14.X5:5/6		E	1
489900	E/A-Modul 4: Control data transfer CAN internal error at Register-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A14.X5:5/6		E	2
489901	E/A-Modul 4: Control data transfer CAN internal error at RAM-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A14.X5:5/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
489902	E/A-Modul 4: Control data transfer CAN Configuration error Software internal error, CAN-transmission will be aborted replace E/A-Modul, check Software (test system ZE)	A14.X5:5/6		E	2
489903	E/A-Modul 4: Control data transfer CAN Transfer interrupted after continuous error CAN-Transmission will be aborted Check CAN network, replace E/A-Modul	A14.X5:5/6		E	1
489910	E/A-Modul 4: Control data transfer CAN short-term error in bus connection re-attachment of Modul to bus transmission Check CAN network, connect individual Bus users and check if error has been remedied	A14.X5:5/6		E	0
489911	E/A-Modul 4: Control data transfer CAN permanent error bus connection cyclic re-attachment of Modul to bus transmission Check CAN network, connect individual Bus users and check if error has been remedied	A14.X5:5/6		E	1
489920	E/A-Modul 4: Control data transfer CAN active participant not responding parameterised substitute values for receiver signals will be used check error report for missing participant(s), test system ZE	A14.X5:5/6		E	0
489921	E/A-Modul 4: Control data transfer CAN No active subscriber responding parameterised substitute values for receiver signals will be used in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A14.X5:5/6		E	1
489950	E/A-Modul 4: Control data transfer CAN erroneous command test system no reaction to unknown test system control command in CAN-System Software check Software (test system)	A14.X5:5/6		E	1
491211	E/A-Modul 4: Proportional valve steering axle LA2 CAN-communication with E/A-module faulty/lacking (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A14		E	1
491212	E/A-Modul 4: Proportional valve steering axle LA2 CAN-communication with E/A-module faulty/lacking (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A14		E	1
491213	E/A-Modul 4: Proportional valve steering axle LA2 CAN-communication with E/A-module implausible (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
491214	E/A-Modul 4: Proportional valve steering axle LA2 CAN-communication with E/A-module implausible (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A14		E	1
491215	E/A-Modul 4: Proportional valve steering axle LA2 Voltage supply/PWM-control faulty Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491216	E/A-Modul 4: Proportional valve steering axle LA2 Internal error, EEPROM-memory inconsistent Valve is not controlled (neutral position), secondary measures possibly required Check valve configuration, replace valve	A14		E	1
491217	E/A-Modul 4: Proportional valve steering axle LA2 Reference value valve not neutral due to continuous error Valve is not controlled (neutral position), secondary measures possibly required Remedy fault, activate/deactivate ignition	A14		E	1
491221	E/A-Modul 4: Proportional valve steering axle LA2 Voltage supply below permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491222	E/A-Modul 4: Proportional valve steering axle LA2 Voltage supply above permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491223	E/A-Modul 4: Proportional valve steering axle LA2 Slide deflected too short; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve; replace valve; errors may be resulted from engine stalling	A14		E	1
491224	E/A-Modul 4: Proportional valve steering axle LA2 Slide deflected too far; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A14		E	1
491225	E/A-Modul 4: Proportional valve steering axle LA2 Valve float position not reached Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A14		E	1
491226	E/A-Modul 4: Proportional valve steering axle LA2 Manual actuation With fault-free valve and neutral set value, error report only No manual operation possible, check valve and replace if necessary; valve shifted mechanically out of neutral?	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
491231	E/A-Modul 4: Proportional valve steering axle LA2 Voltage supply below 8V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491232	E/A-Modul 4: Proportional valve steering axle LA2 Voltage supply above 36..45V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491241	E/A-Modul 4: Proportional valve steering axle LA2 Voltage supply above 45V, internal emergency shut-down Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491242	E/A-Modul 4: Proportional valve steering axle LA2 Power amplifier error solenoid valve servo-control Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A14		E	1
491243	E/A-Modul 4: Proportional valve steering axle LA2 Distance converter valve stroke faulty Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A14		E	1
491281	E/A-Modul 4: Proportional valve steering axle LA2 Slide valve can not be shifted into neutral position Internal emergency shut-down, possible valve can not switch to neutral, secondary measures possibly required Check hydraulic supply, valve; replace valve	A14		E	1
491282	E/A-Modul 4: Proportional valve steering axle LA2 Slide valve not in neutral position upon activation Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve and replace if necessary; valve shifted mechanically out of neutral?	A14		E	1
491411	E/A-Modul 4: Proportional valve steering axle LA4 CAN-communication with E/A-module faulty/lacking (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A14		E	1
491412	E/A-Modul 4: Proportional valve steering axle LA4 CAN-communication with E/A-module faulty/lacking (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A14		E	1
491413	E/A-Modul 4: Proportional valve steering axle LA4 CAN-communication with E/A-module implausible (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
491414	E/A-Modul 4: Proportional valve steering axle LA4 CAN-communication with E/A-module implausible (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A14		E	1
491415	E/A-Modul 4: Proportional valve steering axle LA4 Voltage supply/PWM-control faulty Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491416	E/A-Modul 4: Proportional valve steering axle LA4 Internal error, EEPROM-memory inconsistent Valve is not controlled (neutral position), secondary measures possibly required Check valve configuration, replace valve	A14		E	1
491417	E/A-Modul 4: Proportional valve steering axle LA4 Reference value valve not neutral due to continuous error Valve is not controlled (neutral position), secondary measures possibly required Remedy fault, activate/deactivate ignition	A14		E	1
491421	E/A-Modul 4: Proportional valve steering axle LA4 Voltage supply below permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491422	E/A-Modul 4: Proportional valve steering axle LA4 Voltage supply above permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491423	E/A-Modul 4: Proportional valve steering axle LA4 Slide deflected too short; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve; replace valve; errors may be resulted from engine stalling	A14		E	1
491424	E/A-Modul 4: Proportional valve steering axle LA4 Slide deflected too far; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A14		E	1
491425	E/A-Modul 4: Proportional valve steering axle LA4 Valve float position not reached Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A14		E	1
491426	E/A-Modul 4: Proportional valve steering axle LA4 Manual actuation With fault-free valve and neutral set value, error report only No manual operation possible, check valve and replace if necessary; valve shifted mechanically out of neutral?	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
491431	E/A-Modul 4: Proportional valve steering axle LA4 Voltage supply below 8V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491432	E/A-Modul 4: Proportional valve steering axle LA4 Voltage supply above 36..45V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491441	E/A-Modul 4: Proportional valve steering axle LA4 Voltage supply above 45V, internal emergency shut-down Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A14		E	1
491442	E/A-Modul 4: Proportional valve steering axle LA4 Power amplifier error solenoid valve servo-control Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A14		E	1
491443	E/A-Modul 4: Proportional valve steering axle LA4 Distance converter valve stroke faulty Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A14		E	1
491481	E/A-Modul 4: Proportional valve steering axle LA4 Slide valve can not be shifted into neutral position Internal emergency shut-down, possible valve can not switch to neutral, secondary measures possibly required Check hydraulic supply, valve; replace valve	A14		E	1
491482	E/A-Modul 4: Proportional valve steering axle LA4 Slide valve not in neutral position upon activation Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve and replace if necessary; valve shifted mechanically out of neutral?	A14		E	1
492747	E/A-Modul 4: control steering signal from steering pump flow switch erroneous control indicator for steering pump flashing check line connections, power supply 10 mA from E/A-Modul; replace sensor or E/A-Modul	A14		E	1
492748	E/A-Modul 4: control steering signal from auxiliary steering pump flow switch erroneous control indicator for auxiliary steering pump flashing check line connections, power supply 10 mA from E/A-Modul; replace sensor or E/A-Modul	A14		E	1
492831	E/A-Modul 4: control supports location coding for left support unit erroneous (set value = 1) support functions are blocked check line connection to E/A-Modul, check power supply from signal, replace E/A-Modul	A14		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
492833	E/A-Modul 4: control supports left support unit key sticking or activated after switching on left support blocked check/unplug/replace support operating unit release activated key	A14		E	1
494000	E/A-Modul 4: Control active rear axle steering Sensor values channel A/B are not synchronised Safety measure is initiated check cable/plugs for UB- or shorts to ground	A14		E	1
494001	E/A-Modul 4: Control active rear axle steering Local sensor values are not synchronised Safety measure is initiated check cable/plugs for UB- or shorts to ground	A14		E	1
494002	E/A-Modul 4: Control active rear axle steering Low voltage on voltage supply from I / O module Safety measure is initiated Check cable/plug on UB- or short circuit after ground or low voltage at engine ON	A14		E	1
494003	E/A-Modul 4: Control active rear axle steering Signal from angle sensor front axle faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14		E	1
494004	E/A-Modul 4: Control active rear axle steering Signals from channel A/B angle sensor front axle implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14		E	1
494010	E/A-Modul 4: Control active rear axle steering Signal from angle sensor steering axle 1 faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14		E	1
494011	E/A-Modul 4: Control active rear axle steering Signals from channel A/B angle sensor steering axle 1 implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14		E	1
494017	E/A-Modul 4: Control active rear axle steering Signal from angle sensor steering axle 2 faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14		E	1
494018	E/A-Modul 4: Control active rear axle steering Signals from channel A/B angle sensor steering axle 2 implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
494024	E/A-Modul 4: Control active rear axle steering Signal from angle sensor steering axle 3 faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14		E	1
494025	E/A-Modul 4: Control active rear axle steering Signals from channel A/B angle sensor steering axle 3 implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel), check parallel resistance connection	A14		E	1
494031	E/A-Modul 4: Control active rear axle steering Signal from angle sensor steering axle 4 faulty, tolerance too great Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14		E	1
494032	E/A-Modul 4: Control active rear axle steering Signals from channel A/B angle sensor steering axle 4 implausible Safety measure is initiated Measure input current on E/A-module (approx.10 mA with straight-line travel)	A14		E	1
494035	E/A-Modul 4: Control active rear axle steering Steering axle 1 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A14		E	1
494036	E/A-Modul 4: Control active rear axle steering Steering axle 2 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A14		E	1
494037	E/A-Modul 4: Control active rear axle steering Steering axle 3 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A14		E	1
494038	E/A-Modul 4: Control active rear axle steering Steering axle 4 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A14		E	1
494040	E/A-Modul 4: Control active rear axle steering Pressure supply centring circuit too low with speed > 10 km/h Safety measure is initiated Measure input signals on E/A-module, check pressure switch or hydraulic supply	A14		E	1
494041	E/A-Modul 4: Control active rear axle steering Pressure supply centring circuit too high after ignition ON Safety measure is initiated Measure input signals on E/A-module, check pressure switch or hydraulic supply	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
494042	E/A-Modul 4: Control active rear axle steering Signals press. switch centr. circuit both ON / short circuit to Vcc Safety measure is initiated Measure input signals on E/A-module or check pressure switch	A14		E	1
494043	E/A-Modul 4: Control active rear axle steering Sig. press. switch centr. circle both OFF/wire break/short circ. earth Safety measure is initiated Measure input signals on E/A-module or check pressure switch	A14		E	1
494045	E/A-Modul 4: Control active rear axle steering Signal flow sensor steering pump: Oil supply too low error report on display Check input signals on E/A-module, flow switch or hydraulic supply	A14		E	1
494046	E/A-Modul 4: Control active rear axle steering Signal flow sensor steering pump: Sensor faulty/missing error report on display Check input signals on E/A-module, flow switch or hydraulic supply	A14		E	1
494049	E/A-Modul 4: Control active rear axle steering Signal flow sensor auxiliary steering pump: Oil supply too low error report on display Check input signals on E/A-module, flow switch or hydraulic supply	A14		E	1
494050	E/A-Modul 4: Control active rear axle steering Signal flow sensor auxiliary steering pump: Sensor faulty/missing error report on display Check input signals on E/A-module, flow switch or hydraulic supply	A14		E	1
494051	E/A-Modul 4: Control active rear axle steering Error in program run Error report, value is zeroed E/A-module 1+3+4, LSB, check system-independent steering	A14		E	1
494052	E/A-Modul 4: Control active rear axle steering Checksum faulty Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A14		E	1
494058	E/A-Modul 4: Control active rear axle steering Actuator values from opposite side are too old Safety measure is initiated Check CAN network, check faulty Bus user.	A14		E	1
494059	E/A-Modul 4: Control active rear axle steering Actuator values difference with opposite side too great Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
494060	E/A-Modul 4: Control active rear axle steering CAN- values from I / O module 3 are not plausible Safety measure is initiated Check cable/plug on UB- or short circuit after ground or low voltage at engine Start	A14		E	1
494061	E/A-Modul 4: Control active rear axle steering CAN- values from I / O module 4 are not plausible Safety measure is initiated Check cable/plug on UB- or short circuit after ground or low voltage at engine Start	A14		E	1
494062	E/A-Modul 4: Control active rear axle steering Outlet centring valves trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on E/A-module	A14		E	1
494063	E/A-Modul 4: Control active rear axle steering Pressure supply emergency supply centering circuit too low error report on display Check input signals or initial actuation on I/O module	A14		E	1
494064	E/A-Modul 4: Control active rear axle steering Outlet locking valve 1 trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on E/A-module	A14		E	1
494066	E/A-Modul 4: Control active rear axle steering Outlet locking valve 2 trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on E/A-module	A14		E	1
494067	E/A-Modul 4: Control active rear axle steering Power feedback measuring determines too great a difference in current error report on display Check outlet switching on E/A-module	A14		E	1
494070	E/A-Modul 4: Control active rear axle steering Signal Travel speed tachograph faulty/missing Error report, replacement value 100 km/h, axles are reset depending on operation type Speed signal tacho, check CAN1, EAM1, EAM5, ECU, LSB	A14		E	1
494071	E/A-Modul 4: Control active rear axle steering Signal travel speed output gear sensor faulty/lacking Error report, replacement value 100 km/h, axles are reset depending on operation type Speed signal tacho, check output gear speed	A14		E	1
494072	E/A-Modul 4: Control active rear axle steering Signal travel speed tacho<->gear impl./outside tolerance Error report, replacement value 100 km/h, axles are reset depending on operation type Output gear speed, gear control unit, output sensor, check CAN	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
494073	E/A-Modul 4: Control active rear axle steering Signal engine speed diesel engine faulty/missing Error report, value is zeroed Speed signal ECU, check CAN1, ECU, EAM5, LSB	A14		E	1
494075	E/A-Modul 4: Control active rear axle steering Steering axle 1 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A14		E	1
494076	E/A-Modul 4: Control active rear axle steering Steering axle 2 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A14		E	1
494077	E/A-Modul 4: Control active rear axle steering Steering axle 3 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A14		E	1
494078	E/A-Modul 4: Control active rear axle steering Steering axle 4 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A14		E	1
494080	E/A-Modul 4: Control active rear axle steering Set value specifica. operation type from operating unit faulty/missing Steering becomes faulty following time-out EAM1, operating unit, check LSB	A14		E	1
494081	E/A-Modul 4: Control active rear axle steering Return report steering status right faulty/missing Steering becomes faulty following time-out Steering, check LSB	A14		E	1
494085	E/A-Modul 4: Control active rear axle steering Error in computer at opposite side Safety measure is initiated Read error code on other module and remedy error	A14		E	1
494090	E/A-Modul 4: Control active rear axle steering Diagnosis centring valve: steering axle 1 not centring error report on display Check whether valve is mechanically jammed	A14		E	1
494091	E/A-Modul 4: Control active rear axle steering Diagnosis centring valve: steering axle 2 not centring error report on display Check whether valve is mechanically jammed	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
494092	E/A-Modul 4: Control active rear axle steering Diagnosis centring valve: steering axle 3 not centring error report on display Check whether valve is mechanically jammed	A14		E	1
494093	E/A-Modul 4: Control active rear axle steering Diagnosis freewheel valve: steering axle 4 not freewheeling error report on display Check whether valve is mechanically jammed	A14		E	1
494094	E/A-Modul 4: Control active rear axle steering Diagnosis locking valve: steering axle 1 not locking error report on display Check whether valve is mechanically jammed	A14		E	1
494095	E/A-Modul 4: Control active rear axle steering Diagnosis locking valve: steering axle 2 not locking error report on display Check whether valve is mechanically jammed	A14		E	1
494096	E/A-Modul 4: Control active rear axle steering Diagnosis locking valve: steering axle 3 not locking error report on display Check whether valve is mechanically jammed	A14		E	1
494185	E/A-Modul 4: LSB-bus participant Support pressure transducer front right faulty/not present communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494186	E/A-Modul 4: LSB-bus participant Support pressure transducer front left faulty/not present communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494187	E/A-Modul 4: LSB-bus participant Support pressure transducer rear right faulty/not present communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494188	E/A-Modul 4: LSB-bus participant Support pressure transducer rear left faulty/not present communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494189	E/A-Modul 4: LSB-bus participant Incline sensor erroneous/ missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
494190	E/A-Modul 4: LSB-bus participant ZE missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494191	E/A-Modul 4: LSB-bus participant E/A-Modul 1 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494192	E/A-Modul 4: LSB-bus participant E/A-Modul 2 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494193	E/A-Modul 4: LSB-bus participant E/A-Modul 3 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494195	E/A-Modul 4: LSB-bus participant E/A-Modul 5 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
494196	E/A-Modul 4: LSB-bus participant E/A-Modul 6 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A14		E	1
496000	E/A-Modul 4: operation transversal lock function simultaneously ON and OFF function is not carried out do not simultaneously activate contrasting function keys	A14		B	
496011	E/A-Modul 4: operation transversal lock unauthorised switching on of function function is not carried out start engine and repeat operation	A14		B	
496012	E/A-Modul 4: operation transversal lock unauthorised switching off of function function is not carried out start engine and repeat operation	A14		B	
496013	E/A-Modul 4: operation transversal lock unauthorised function activation function is not carried out start engine and repeat operation	A14		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
496014	E/A-Modul 4: operation transversal lock activation of function without operation mode function is not carried out start engine and repeat operation	A14		B	
496408	E/A-Modul 4: operation supports unauthorised operation from upper-carriage function is not carried out check coding of E/A-Modul 3 and E/A-Modul 4 (see electric circuit diagram)	A14		B	
496409	E/A-Modul 4: operation supports unauthorised operation from under-carriage function is not carried out check coding of E/A-Modul 3 and E/A-Modul 4 (see electric circuit diagram)	A14		B	
496440	E/A-Modul 4: operation supports simultaneous UP and DOWN operation of support control unit function is not carried out actuate UP key or DOWN key of the respective support operating unit, start test program support service unit	A14		B	
496441	E/A-Modul 4: operation supports simultaneous IN and OUT operation of support control unit function is not carried out actuate OFF key or ON key of the respective support operating unit, start test program support operating unit	A14		B	
496442	E/A-Modul 4: operation supports simultaneous UP and DOWN operation on upper-carriage monitor function is not carried out actuate UP key or DOWN key of the respective support operating unit, start test program support service unit	A14		B	
496443	E/A-Modul 4: operation supports simultaneous IN and OUT operation on upper-carriage monitor function is not carried out actuate OFF key or ON key of the respective support operating unit, start test program support operating unit	A14		B	
496444	E/A-Modul 4: operation supports simultaneous left and right operation of support control unit function is not carried out activate support from only one operating position or start test program support operating unit	A14		B	
496445	E/A-Modul 4: operation supports simultaneous operation of support control unit and upper-carriage function is not carried out activate support from only one operating position or start test program support operating unit	A14		B	
496446	E/A-Modul 4: operation supports simultaneous operation of support control unit and upper-carriage function is not carried out activate support from only one operating position or start test program support operating unit	A14		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
496447	E/A-Modul 4: operation supports operation of support control unit with travel direction D engaged function is not carried out switch transmission to neutral (N)	A14		B	
496448	E/A-Modul 4: operation supports operation of support control unit with travel direction R engaged function is not carried out switch transmission to neutral (N)	A14		B	
496449	E/A-Modul 4: operation supports op. of upper-carriage monitor with travel direction D engaged function is not carried out switch transmission to neutral (N)	A14		B	
496450	E/A-Modul 4: operation supports operation of upper-carriage-monitor R function is not carried out switch transmission to neutral (N)	A14		B	
496452	E/A-Modul 4: operation supports unauthorised activation of left support control unit key left support blocked release activated key after having authorized function through hand- key	A14		B	
498028	E/A-Modul 4: Operation active rear axle steering Wheel collision last mech. steered and 1st electr. steered axle Output of error Turn the steering wheel in the other direction	A14		B	
498030	E/A-Modul 4: Operation active rear axle steering Switch-over operation type prevented: Travel speed too high	A14		B	
498031	E/A-Modul 4: Operation active rear axle steering Change-over operation type prevented: Adjust axles manually	A14		B	
499890	E/A-Modul 4: operation diagnosis system test program not executable as engine is not OFF function is not carried out shut down engine	A14		B	
499892	E/A-Modul 4: operation diagnosis system test program not executable as not in under-carriage op. mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A14		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
4C4F43	LSB-BSE0: Job planner This is a non-relevant Service note Issue Service notice! No remedy required!			S	
500001	ZE 5: system error OS-HC11 (observe parameters) initialising error processor-register erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A425		E	2
500002	ZE 5: system error OS-HC11 (observe parameters) initialising error test total in EPROM/FLASH erroneous no crane operation possible check program memory card or ZE	A425		E	2
500006	ZE 5: system error OS-HC11 (observe parameters) initialising error RAM erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A425		E	2
500007	ZE 5: system error OS-HC11 (observe parameters) UART erroneous no crane operation possible if error re-occurs, then ZE should be replaced	A425		E	2
500010	ZE 5: system error OS-HC11 (observe parameters) system routine inaccessible entry in error memory, all crane movements will be stopped	A425		E	2
500011	ZE 5: system error OS-HC11 (observe parameters) ZE-watchdog expired entry in error memory, all crane movements will be stopped check ZE	A425		E	2
500012	ZE 5: system error OS-HC11 (observe parameters) type-identification in EPROM erroneous entry in error memory, no crane operation possible check program memory card	A425		E	2
500013	ZE 5: system error OS-HC11 (observe parameters) Test sum in FLASH erroneous entry in error memory, all crane movements will be stopped check program memory card	A425		E	2
500014	ZE 5: system error OS-HC11 (observe parameters) program already running entry in error memory, all crane movements will be stopped	A425		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
500015	ZE 5: system error OS-HC11 (observe parameters) program not available entry in error memory, all crane movements will be stopped	A425		E	2
500016	ZE 5: system error OS-HC11 (observe parameters) system-, driver-watchdog expired entry in error memory, all crane movements will be stopped	A425		E	2
500017	ZE 5: system error OS-HC11 (observe parameters) total of CPU-time distribution too great entry in error memory, all crane movements will be stopped	A425		E	2
500018	ZE 5: system error OS-HC11 (observe parameters) arithmetic overflow (16 Bit) entry in error memory, all crane movements will be stopped	A425		E	2
500019	ZE 5: system error OS-HC11 (observe parameters) division through zero (16 Bit) entry in error memory, all crane movements will be stopped	A425		E	2
500020	ZE 5: system error OS-HC11 (observe parameters) task-watchdog expired entry in error memory, all crane movements will be stopped	A425		E	2
500021	ZE 5: system error OS-HC11 (observe parameters) illegal opcode trap entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A425		E	2
500022	ZE 5: system error OS-HC11 (observe parameters) task inactive entry in error memory, all crane movements will be stopped	A425		E	2
500023	ZE 5: system error OS-HC11 (observe parameters) program incapable of running (type identification) entry in error memory, all crane movements will be stopped	A425		E	2
500024	ZE 5: system error OS-HC11 (observe parameters) task already used entry in error memory, all crane movements will be stopped	A425		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
500025	ZE 5: system error OS-HC11 (observe parameters) realtime-module already used entry in error memory, all crane movements will be stopped	A425		E	2
500026	ZE 5: system error OS-HC11 (observe parameters) regulator-module already used entry in error memory, all crane movements will be stopped	A425		E	2
500030	ZE 5: system error OS-HC11 (observe parameters) unacceptable bank address entry in error memory, all crane movements will be stopped	A425		E	2
500041	ZE 5: system error OS-HC11 (observe parameters) arithmetic error entry in error memory, all crane movements will be stopped	A425		E	2
500044	ZE 5: system error OS-HC11 (observe parameters) output parameter without effect, from inactive output entry in error memory, all crane movements will be stopped	A425		E	2
500045	ZE 5: system error OS-HC11 (observe parameters) entry parameter undefined, from inactive input entry in error memory, all crane movements will be stopped	A425		E	2
500046	ZE 5: system error OS-HC11 (observe parameters) impermissible regulator parameter entry in error memory, all crane movements will be stopped	A425		E	2
500047	ZE 5: system error OS-HC11 (observe parameters) realtime-control block not available entry in error memory, all crane movements will be stopped	A425		E	2
500048	ZE 5: system error OS-HC11 (observe parameters) realtime-control block inactive entry in error memory, all crane movements will be stopped	A425		E	2
500049	ZE 5: system error OS-HC11 (observe parameters) urgent modul, ZE not available entry in error memory, no crane operation possible check ZE	A425		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
500050	ZE 5: system error OS-HC11 (observe parameters) file not available entry in error memory, all crane movements will be stopped	A425		E	2
500051	ZE 5: system error OS-HC11 (observe parameters) file already opened entry in error memory, all crane movements will be stopped	A425		E	2
500052	ZE 5: system error OS-HC11 (observe parameters) file not open on close entry in error memory, all crane movements will be stopped	A425		E	2
500053	ZE 5: system error OS-HC11 (observe parameters) system mask not available entry in error memory, all crane movements will be stopped	A425		E	2
500054	ZE 5: system error OS-HC11 (observe parameters) system text not available entry in error memory, all crane movements will be stopped	A425		E	2
500055	ZE 5: system error OS-HC11 (observe parameters) symbol not available entry in error memory, all crane movements will be stopped	A425		E	2
500056	ZE 5: system error OS-HC11 (observe parameters) invalid mark in symbol entry in error memory, all crane movements will be stopped	A425		E	2
500057	ZE 5: system error OS-HC11 (observe parameters) default load chart missing entry in error memory, all crane movements will be stopped	A425		E	2
500058	ZE 5: system error OS-HC11 (observe parameters) amplifier erroneous or return power feed entry in error memory, all crane movements will be stopped check wiring	A425		E	2
500059	ZE 5: system error OS-HC11 (observe parameters) subroutine not reentrant entry in error memory, all crane movements will be stopped	A425		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
500060	ZE 5: system error OS-HC11 (observe parameters) transmission error SCI entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A425		E	2
500061	ZE 5: system error OS-HC11 (observe parameters) SCI-BREAK entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A425		E	2
500062	ZE 5: system error OS-HC11 (observe parameters) SCI not connected entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A425		E	2
500063	ZE 5: system error OS-HC11 (observe parameters) monitor error in operation entry in error memory, all crane movements will be stopped check monitor ZE and connection cable	A425		E	2
500065	ZE 5: system error OS-HC11 (observe parameters) impermissible bus address entry in error memory, all crane movements will be stopped	A425		E	2
500066	ZE 5: system error OS-HC11 (observe parameters) ADC working outside the permissible tolerance entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A425		E	2
500067	ZE 5: system error OS-HC11 (observe parameters) arithmetic processor not available entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A425		E	2
500068	ZE 5: system error OS-HC11 (observe parameters) impermissible interrupt entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A425		E	2
500070	ZE 5: system error OS-HC11 (observe parameters) various structure versions entry in error memory, no crane operation possible	A425		E	2
500071	ZE 5: system error OS-HC11 (observe parameters) Structure file missing or faulty entry in error memory, no crane operation possible	A425		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
500072	ZE 5: system error OS-HC11 (observe parameters) structure entry senseless entry in error memory, no crane operation possible	A425		E	2
500073	ZE 5: system error OS-HC11 (observe parameters) interpreter error entry in error memory, all crane movements will be stopped	A425		E	2
500074	ZE 5: system error OS-HC11 (observe parameters) transformation ASCII to BIN erroneous entry in error memory, all crane movements will be stopped	A425		E	2
500075	ZE 5: system error OS-HC11 (observe parameters) SPI-error entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A425		E	2
500076	ZE 5: system error OS-HC11 (observe parameters) incorrectly inserted power unit entry in error memory, all crane movements will be stopped check memory card in power supply unit	A425		E	2
500077	ZE 5: system error OS-HC11 (observe parameters) BAF-call-up erroneous entry in error memory, all crane movements will be stopped	A425		E	2
500078	ZE 5: system error OS-HC11 (observe parameters) impermissible parameter entry in error memory, all crane movements will be stopped	A425		E	2
500079	ZE 5: system error OS-HC11 (observe parameters) no right of access entry in error memory, all crane movements will be stopped	A425		E	2
500080	ZE 5: system error OS-HC11 (observe parameters) Fatal internal error entry in error memory, all crane movements will be stopped	A425		E	2
500081	ZE 5: system error OS-HC11 (observe parameters) stack overflow entry in error memory, all crane movements will be stopped	A425		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
500082	ZE 5: system error OS-HC11 (observe parameters) hardware-watchdog erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A425		E	2
500094	ZE 5: system error OS-HC11 (observe parameters) transmission error parallel bus entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A425		E	2
500095	ZE 5: system error OS-HC11 (observe parameters) DMA-error entry in error memory, all crane movements will be stopped check ZE, bus circuit board, power supply unit	A425		E	2
500099	ZE 5: system error OS-HC11 (observe parameters) DSP0 erroneous entry in error memory, all crane movements will be stopped if error re-occurs, then ZE should be replaced	A425		E	2
502001	ZE 5: system error OS-TMS initialising error processor-register erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A425		E	2
502002	ZE 5: system error OS-TMS initialising error test total in EPROM/FLASH erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A425		E	2
502006	ZE 5: system error OS-TMS initialising error RAM erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A425		E	2
502007	ZE 5: system error OS-TMS UART erroneous entry of error in error memory, all crane movements will be stopped replace ZE	A425		E	2
502020	ZE 5: system error OS-TMS task-watchdog expired entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A425		E	2
502021	ZE 5: system error OS-TMS illegal opcode trap entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A425		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
502082	ZE 5: system error OS-TMS hardware-watchdog erroneous entry of error in error memory, all crane movements will be stopped elimination only possible through after-sales service	A425		E	2
510012	ZE 5: output 0 short circuit to ground	A425.X1:16		E	1
510013	ZE 5: output 0 open signal circuits	A425.X1:16		E	1
510014	ZE 5: output 0 short circuit to supply voltage	A425.X1:16		E	1
510054	ZE 5: output 0 short circuit to supply voltage	A425.X1:16		E	1
510058	ZE 5: output 0 positive switching transistor: disruption	A425.X1:16		E	1
510060	ZE 5: output 0 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A425.X1:16		E	1
510062	ZE 5: output 0 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A425.X1:16		E	1
510063	ZE 5: output 0 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A425.X1:16		E	1
510070	ZE 5: output 0 measuring system defect no crane operation possible entry in error list	A425.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
510071	ZE 5: output 0 short circuit to ground or transistor defect	A425.X1:16		E	1
510072	ZE 5: output 0 outside source feeding	A425.X1:16		E	1
510073	ZE 5: output 0 open circuit or short circuit to supply voltage/ground	A425.X1:16		E	1
510112	ZE 5: output 1 short circuit to ground	A425.X1:17		E	1
510113	ZE 5: output 1 open signal circuits	A425.X1:17		E	1
510114	ZE 5: output 1 short circuit to supply voltage	A425.X1:17		E	1
510154	ZE 5: output 1 short circuit to supply voltage	A425.X1:17		E	1
510158	ZE 5: output 1 positive switching transistor: disruption	A425.X1:17		E	1
510160	ZE 5: output 1 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A425.X1:17		E	1
510162	ZE 5: output 1 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A425.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
510163	ZE 5: output 1 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A425.X1:17		E	1
510170	ZE 5: output 1 measuring system defect no crane operation possible entry in error list	A425.X1:17		E	1
510171	ZE 5: output 1 short circuit to ground or transistor defect	A425.X1:17		E	1
510172	ZE 5: output 1 outside source feeding	A425.X1:17		E	1
510173	ZE 5: output 1 open circuit or short circuit to supply voltage/ground	A425.X1:17		E	1
510212	ZE 5: output 2 short circuit to ground	A425.X1:18		E	1
510213	ZE 5: output 2 open signal circuits	A425.X1:18		E	1
510214	ZE 5: output 2 short circuit to supply voltage	A425.X1:18		E	1
510254	ZE 5: output 2 short circuit to supply voltage	A425.X1:18		E	1
510258	ZE 5: output 2 positive switching transistor: disruption	A425.X1:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
510270	ZE 5: output 2 measuring system defect no crane operation possible entry in error list	A425.X1:18		E	1
510271	ZE 5: output 2 short circuit to ground or transistor defect	A425.X1:18		E	1
510272	ZE 5: output 2 outside source feeding	A425.X1:18		E	1
510273	ZE 5: output 2 open circuit or short circuit to supply voltage/ground	A425.X1:18		E	1
510312	ZE 5: output 3 short circuit to ground	A425.X1:19		E	1
510313	ZE 5: output 3 open signal circuits	A425.X1:19		E	1
510314	ZE 5: output 3 short circuit to supply voltage	A425.X1:19		E	1
510354	ZE 5: output 3 short circuit to supply voltage	A425.X1:19		E	1
510358	ZE 5: output 3 positive switching transistor: disruption	A425.X1:19		E	1
510370	ZE 5: output 3 measuring system defect no crane operation possible entry in error list	A425.X1:19		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
510371	ZE 5: output 3 short circuit to ground or transistor defect	A425.X1:19		E	1
510372	ZE 5: output 3 outside source feeding	A425.X1:19		E	1
510373	ZE 5: output 3 open circuit or short circuit to supply voltage/ground	A425.X1:19		E	1
510412	ZE 5: output 4 short circuit to ground	A425.X1:20		E	1
510413	ZE 5: output 4 open signal circuits	A425.X1:20		E	1
510414	ZE 5: output 4 short circuit to supply voltage	A425.X1:20		E	1
510454	ZE 5: output 4 short circuit to supply voltage	A425.X1:20		E	1
510458	ZE 5: output 4 positive switching transistor: disruption	A425.X1:20		E	1
510460	ZE 5: output 4 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A425.X1:20		E	1
510462	ZE 5: output 4 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A425.X1:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
510463	ZE 5: output 4 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A425.X1:20		E	1
510470	ZE 5: output 4 measuring system defect no crane operation possible entry in error list	A425.X1:20		E	1
510471	ZE 5: output 4 short circuit to ground or transistor defect	A425.X1:20		E	1
510472	ZE 5: output 4 outside source feeding	A425.X1:20		E	1
510473	ZE 5: output 4 open circuit or short circuit to supply voltage/ground	A425.X1:20		E	1
510512	ZE 5: output 5 short circuit to ground	A425.X1:21		E	1
510513	ZE 5: output 5 open signal circuits	A425.X1:21		E	1
510514	ZE 5: output 5 short circuit to supply voltage	A425.X1:21		E	1
510554	ZE 5: output 5 short circuit to supply voltage	A425.X1:21		E	1
510558	ZE 5: output 5 positive switching transistor: disruption	A425.X1:21		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
510560	ZE 5: output 5 safety chain error, diode defect or safety contact sticking report of error, otherwise no reaction checking of safety contact and diode	A425.X1:21		E	1
510562	ZE 5: output 5 Error safety chain, contact "ZE OK" sticking report of error, otherwise no reaction Check of ZE OK relay / contact	A425.X1:21		E	1
510563	ZE 5: output 5 Error safety chain, output error report of error, otherwise no reaction Check of output/ ZE/ switching	A425.X1:21		E	1
510570	ZE 5: output 5 measuring system defect no crane operation possible entry in error list	A425.X1:21		E	1
510571	ZE 5: output 5 short circuit to ground or transistor defect	A425.X1:21		E	1
510572	ZE 5: output 5 outside source feeding	A425.X1:21		E	1
510573	ZE 5: output 5 open circuit or short circuit to supply voltage/ground	A425.X1:21		E	1
510612	ZE 5: output 6 short circuit to ground	A425.X1:22		E	1
510613	ZE 5: output 6 open signal circuits	A425.X1:22		E	1
510614	ZE 5: output 6 short circuit to supply voltage	A425.X1:22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
510654	ZE 5: output 6 short circuit to supply voltage	A425.X1:22		E	1
510658	ZE 5: output 6 positive switching transistor: disruption	A425.X1:22		E	1
510670	ZE 5: output 6 measuring system defect no crane operation possible entry in error list	A425.X1:22		E	1
510671	ZE 5: output 6 short circuit to ground or transistor defect	A425.X1:22		E	1
510672	ZE 5: output 6 outside source feeding	A425.X1:22		E	1
510673	ZE 5: output 6 open circuit or short circuit to supply voltage/ground	A425.X1:22		E	1
510712	ZE 5: output 7 short circuit to ground	A425.X1:23		E	1
510713	ZE 5: output 7 open signal circuits	A425.X1:23		E	1
510714	ZE 5: output 7 short circuit to supply voltage	A425.X1:23		E	1
510754	ZE 5: output 7 short circuit to supply voltage	A425.X1:23		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
510758	ZE 5: output 7 positive switching transistor: disruption	A425.X1:23		E	1
510770	ZE 5: output 7 measuring system defect no crane operation possible entry in error list	A425.X1:23		E	1
510771	ZE 5: output 7 short circuit to ground or transistor defect	A425.X1:23		E	1
510772	ZE 5: output 7 outside source feeding	A425.X1:23		E	1
510773	ZE 5: output 7 open circuit or short circuit to supply voltage/ground	A425.X1:23		E	1
514959	ZE 5: all output supply voltage missing	A425		E	1
515059	ZE 5: output group 0 supply voltage missing	A425.X1:12		E	1
515159	ZE 5: output group 1 supply voltage missing	A425.X1:24		E	1
515259	ZE 5: output group 2 supply voltage missing	A425		E	1
515359	ZE 5: output group 3 supply voltage missing	A425		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
520004	ZE 5: LSB participant address 0 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
520005	ZE 5: LSB participant address 0 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
520018	ZE 5: LSB participant address 0 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
520050	ZE 5: LSB participant address 0 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
520051	ZE 5: LSB participant address 0 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
520053	ZE 5: LSB participant address 0 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
520054	ZE 5: LSB participant address 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
520064	ZE 5: LSB participant address 0 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
520065	ZE 5: LSB participant address 0 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
520066	ZE 5: LSB participant address 0 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
520067	ZE 5: LSB participant address 0 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
520104	ZE 5: LSB participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
520105	ZE 5: LSB participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
520118	ZE 5: LSB participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
520150	ZE 5: LSB participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
520151	ZE 5: LSB participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
520153	ZE 5: LSB participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
520154	ZE 5: LSB participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
520164	ZE 5: LSB participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
520165	ZE 5: LSB participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
520166	ZE 5: LSB participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
520167	ZE 5: LSB participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
520204	ZE 5: LSB participant address 2 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
520205	ZE 5: LSB participant address 2 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
520218	ZE 5: LSB participant address 2 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
520250	ZE 5: LSB participant address 2 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
520251	ZE 5: LSB participant address 2 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
520253	ZE 5: LSB participant address 2 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
520254	ZE 5: LSB participant address 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
520264	ZE 5: LSB participant address 2 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
520265	ZE 5: LSB participant address 2 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
520266	ZE 5: LSB participant address 2 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
520267	ZE 5: LSB participant address 2 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
520904	ZE 5: LSB participant address 9 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
520905	ZE 5: LSB participant address 9 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
520918	ZE 5: LSB participant address 9 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
520950	ZE 5: LSB participant address 9 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
520951	ZE 5: LSB participant address 9 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
520953	ZE 5: LSB participant address 9 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
520954	ZE 5: LSB participant address 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
520964	ZE 5: LSB participant address 9 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
520965	ZE 5: LSB participant address 9 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
520966	ZE 5: LSB participant address 9 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
520967	ZE 5: LSB participant address 9 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
521404	ZE 5: LSB participant address 14 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
521405	ZE 5: LSB participant address 14 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
521418	ZE 5: LSB participant address 14 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
521450	ZE 5: LSB participant address 14 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
521451	ZE 5: LSB participant address 14 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
521453	ZE 5: LSB participant address 14 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
521454	ZE 5: LSB participant address 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
521464	ZE 5: LSB participant address 14 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
521465	ZE 5: LSB participant address 14 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
521466	ZE 5: LSB participant address 14 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
521467	ZE 5: LSB participant address 14 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
521504	ZE 5: LSB participant address 15 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
521505	ZE 5: LSB participant address 15 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
521518	ZE 5: LSB participant address 15 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
521550	ZE 5: LSB participant address 15 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
521551	ZE 5: LSB participant address 15 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
521553	ZE 5: LSB participant address 15 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
521554	ZE 5: LSB participant address 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
521564	ZE 5: LSB participant address 15 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
521565	ZE 5: LSB participant address 15 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
521566	ZE 5: LSB participant address 15 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
521567	ZE 5: LSB participant address 15 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
521604	ZE 5: LSB participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
521605	ZE 5: LSB participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
521618	ZE 5: LSB participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
521650	ZE 5: LSB participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
521651	ZE 5: LSB participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
521653	ZE 5: LSB participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
521654	ZE 5: LSB participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
521664	ZE 5: LSB participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
521665	ZE 5: LSB participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
521666	ZE 5: LSB participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
521667	ZE 5: LSB participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
521704	ZE 5: LSB participant address 17 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
521705	ZE 5: LSB participant address 17 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
521718	ZE 5: LSB participant address 17 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
521750	ZE 5: LSB participant address 17 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
521751	ZE 5: LSB participant address 17 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
521753	ZE 5: LSB participant address 17 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
521754	ZE 5: LSB participant address 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
521764	ZE 5: LSB participant address 17 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
521765	ZE 5: LSB participant address 17 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
521766	ZE 5: LSB participant address 17 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
521767	ZE 5: LSB participant address 17 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
521804	ZE 5: LSB participant address 18 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
521805	ZE 5: LSB participant address 18 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
521818	ZE 5: LSB participant address 18 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
521850	ZE 5: LSB participant address 18 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
521851	ZE 5: LSB participant address 18 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
521853	ZE 5: LSB participant address 18 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
521854	ZE 5: LSB participant address 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
521864	ZE 5: LSB participant address 18 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
521865	ZE 5: LSB participant address 18 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
521866	ZE 5: LSB participant address 18 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
521867	ZE 5: LSB participant address 18 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
521904	ZE 5: LSB participant address 19 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
521905	ZE 5: LSB participant address 19 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
521918	ZE 5: LSB participant address 19 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
521950	ZE 5: LSB participant address 19 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
521951	ZE 5: LSB participant address 19 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
521953	ZE 5: LSB participant address 19 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
521954	ZE 5: LSB participant address 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
521964	ZE 5: LSB participant address 19 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
521965	ZE 5: LSB participant address 19 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
521966	ZE 5: LSB participant address 19 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
521967	ZE 5: LSB participant address 19 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
522004	ZE 5: LSB participant address 20 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
522005	ZE 5: LSB participant address 20 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
522018	ZE 5: LSB participant address 20 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
522050	ZE 5: LSB participant address 20 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
522051	ZE 5: LSB participant address 20 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
522053	ZE 5: LSB participant address 20 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
522054	ZE 5: LSB participant address 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
522064	ZE 5: LSB participant address 20 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
522065	ZE 5: LSB participant address 20 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
522066	ZE 5: LSB participant address 20 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
522067	ZE 5: LSB participant address 20 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
522104	ZE 5: LSB participant address 21 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
522105	ZE 5: LSB participant address 21 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
522118	ZE 5: LSB participant address 21 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
522150	ZE 5: LSB participant address 21 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
522151	ZE 5: LSB participant address 21 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
522153	ZE 5: LSB participant address 21 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
522154	ZE 5: LSB participant address 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
522164	ZE 5: LSB participant address 21 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
522165	ZE 5: LSB participant address 21 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
522166	ZE 5: LSB participant address 21 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
522167	ZE 5: LSB participant address 21 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
522504	ZE 5: LSB participant address 25 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
522505	ZE 5: LSB participant address 25 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
522518	ZE 5: LSB participant address 25 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
522550	ZE 5: LSB participant address 25 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
522551	ZE 5: LSB participant address 25 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
522553	ZE 5: LSB participant address 25 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
522554	ZE 5: LSB participant address 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
522564	ZE 5: LSB participant address 25 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
522565	ZE 5: LSB participant address 25 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
522566	ZE 5: LSB participant address 25 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
522567	ZE 5: LSB participant address 25 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
522604	ZE 5: LSB participant address 26 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
522605	ZE 5: LSB participant address 26 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
522618	ZE 5: LSB participant address 26 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
522650	ZE 5: LSB participant address 26 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
522651	ZE 5: LSB participant address 26 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
522653	ZE 5: LSB participant address 26 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
522654	ZE 5: LSB participant address 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
522664	ZE 5: LSB participant address 26 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
522665	ZE 5: LSB participant address 26 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
522666	ZE 5: LSB participant address 26 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
522667	ZE 5: LSB participant address 26 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
522704	ZE 5: LSB participant address 27 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
522705	ZE 5: LSB participant address 27 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
522718	ZE 5: LSB participant address 27 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
522750	ZE 5: LSB participant address 27 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
522751	ZE 5: LSB participant address 27 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
522753	ZE 5: LSB participant address 27 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
522754	ZE 5: LSB participant address 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
522764	ZE 5: LSB participant address 27 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
522765	ZE 5: LSB participant address 27 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
522766	ZE 5: LSB participant address 27 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
522767	ZE 5: LSB participant address 27 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
522904	ZE 5: LSB participant address 29 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
522905	ZE 5: LSB participant address 29 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
522918	ZE 5: LSB participant address 29 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
522950	ZE 5: LSB participant address 29 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2
522951	ZE 5: LSB participant address 29 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
522953	ZE 5: LSB participant address 29 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
522954	ZE 5: LSB participant address 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
522964	ZE 5: LSB participant address 29 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
522965	ZE 5: LSB participant address 29 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
522966	ZE 5: LSB participant address 29 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
522967	ZE 5: LSB participant address 29 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
523004	ZE 5: LSB participant address 30 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A425.X2:z14/z16		E	1
523005	ZE 5: LSB participant address 30 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A425.X2:z14/z16		E	1
523018	ZE 5: LSB participant address 30 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A425.X2:z14/z16		E	0
523050	ZE 5: LSB participant address 30 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
523051	ZE 5: LSB participant address 30 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A425.X2:z14/z16		E	2
523053	ZE 5: LSB participant address 30 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A425.X2:z14/z16		E	1
523054	ZE 5: LSB participant address 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A425.X2:z14/z16		E	2
523064	ZE 5: LSB participant address 30 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A425.X2:z14/z16		E	1
523065	ZE 5: LSB participant address 30 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A425.X2:z14/z16		E	2
523066	ZE 5: LSB participant address 30 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A425.X2:z14/z16		E	2
523067	ZE 5: LSB participant address 30 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A425.X2:z14/z16		E	1
523252	ZE 5: Control data transfer LSB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A425.X2:z14/z16		E	0
523255	ZE 5: Control data transfer LSB Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A425.X2:z14/z16		E	2
523256	ZE 5: Control data transfer LSB Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A425.X2:z14/z16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
523257	ZE 5: Control data transfer LSB has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A425.X2:z14/z16		E	1
523258	ZE 5: Control data transfer LSB recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A425.X2:z14/z16		E	0
523259	ZE 5: Control data transfer LSB recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A425.X2:z14/z16		E	0
523260	ZE 5: Control data transfer LSB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A425.X2:z14/z16		E	2
523261	ZE 5: Control data transfer LSB driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A425.X2:z14/z16		E	2
523262	ZE 5: Control data transfer LSB Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A425.X2:z14/z16		E	2
533100	ZE 5: Control ballasting / counterweight carriage Limit switch "BW bolted" faulty / not present - Shut-down BW active Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Error remedy see corresponding system error.	A425		E	
533101	ZE 5: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and FB inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following earthing or line interruption, checking of inputs.	A425		E	
533102	ZE 5: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted and FB inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A425		E	
533103	ZE 5: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and bolted and FB inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A425		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
533104	ZE 5: Control ballasting / counterweight carriage Invalid assembly condition - B inserted and FB not inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following supply voltage or earthing or line interruption.	A425		E	
533105	ZE 5: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and B inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following supply voltage or earthing or line interruption.	A425		E	
533106	ZE 5: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A425		E	
533107	ZE 5: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and bolted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A425		E	
533108	ZE 5: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted FB inserted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A425		E	
533112	ZE 5: Control ballasting / counterweight carriage Safety test counterweight carriage reports error - check control BW Cont. carries on running, however poss. error function as faulty recognised system component during safety test Switch over derr. monitor to count. carriage and read error reports in error diagnosis system of counterweight carriage.	A425		E	
533113	ZE 5: Control ballasting / counterweight carriage Control of axles without func., relevant sensor faulty/not present Control of the axles is switched off, axles remain in the last set condition Reestablish function of the respective sensor - error remedy see corresponding system error.	A425		E	
533114	ZE 5: Control ballasting / counterweight carriage Data trans (LSB) between crane and counte. carriage interrupted Functions affected by the transmission fault will not be carried out. Error remedy see corresponding system error or operating error.	A425		E	
533155	ZE 5: Control ballasting / counterweight carriage "Two inputs ""suspended ballast radius"" are active simultaneously" report of error, otherwise no reaction Check of wiring - short circuit after supply voltage, check of inputs.	A425		E	
533156	ZE 5: Control ballasting / counterweight carriage "Three inputs ""suspended ballast radius"" are active simultaneously" report of error, otherwise no reaction Check of wiring - short circuit after supply voltage, check of inputs.	A425		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
533157	ZE 5: Control ballasting / counterweight carriage Guide frames and suspended ballast are installed - without radius report of error, otherwise no reaction Check of wiring - length sensor not plugged in or short circuit after ground or line interruption	A425		E	
533158	ZE 5: Control ballasting / counterweight carriage Guide frames and suspended ballast are not installed - with radius report of error, otherwise no reaction Check of wiring - short circuit after supply voltage, check of inputs.	A425		E	
533159	ZE 5: Control ballasting / counterweight carriage Guide frames installed and susp. ballast not installed - w/o radius report of error, otherwise no reaction Check of wiring - length sensor not plugged in or short circuit after ground or line interruption	A425		E	
53315A	ZE 5: Control ballasting / counterweight carriage A susp.ballast radius is active without length sensor sliding cylinder report of error, otherwise no reaction Check of wiring - length sensor defective or missing.	A425		E	
53315B	ZE 5: Control ballasting / counterweight carriage Length sensor sliding cyl. is active and multiple susp. ballast radii report of error, otherwise no reaction Check of wiring - short circuit after supply voltage, check of inputs.	A425		E	
53315C	ZE 5: Control ballasting / counterweight carriage Length sensor sliding cyl. is active and no suspended ballast radius report of error, otherwise no reaction Check of wiring - short circuit after ground or line interruption.	A425		E	
533284	ZE 5: Control crawler No travel movement detected with controlled crawler left Output of error Actuate crawler travel gear with at least 1/8 init current and check incremental counter (dir. of rotation/function)	A425		E	
533285	ZE 5: Control crawler No travel movement detected with controlled crawler right Output of error Actuate crawler travel gear with at least 1/8 init current and check incremental counter (dir. of rotation/function)	A425		E	
533900	ZE 5: crane control signal engine speed defective/missing output of error, rated speed will now be adjusted for the power limitation check engine electronics, with permanent error contact after-sales service	A425		E	1
533901	ZE 5: crane control Signal current engine momentum - Maximum erroneous / missing output of error, rated speed will now be adjusted for the power limitation check engine electronics, with permanent error contact after-sales service	A425		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
536102	ZE 5: Operation ballasting / counterweight carriage Shut-down counterweight on ground Operation conditional shut-down, may not be shunted. If possible raise the wheels via lifting the load or reducing the mounted suspended counterweight	A425		B	
536103	ZE 5: Operation ballasting / counterweight carriage Shut-down support counterweight carriage is not retracted Operation conditional shut-down, may not be shunted. Retract support cylinder counterweight carriage completely.	A425		B	
536104	ZE 5: Operation ballasting / counterweight carriage Shut-down counterweight carriage telescoping blocked Operation conditional shut-down, shunting via lifting up keyswitch BW - only switch on if BW safely lifted Press "Tow-travel on" key until the wheels are in the travel direction and the indicator lamp remains lit.	A425		B	
536105	ZE 5: Operation ballasting / counterweight carriage Shut-down keys counterweight "Up" / "Down" actuated simultaneously Operation conditional shut-down, may not be shunted. Release one of the keys or check the switch and the cabling.	A425		B	
536106	ZE 5: Operation ballasting / counterweight carriage Shut-down keys counterweight "In" / "Out" actuated simultaneously Operation conditional shut-down, may not be shunted. Release one of the keys or check the switch and the cabling.	A425		B	
536107	ZE 5: Operation ballasting / counterweight carriage Shut-down keys support BW "Up" / "Down" actuated simultaneously Operation conditional shut-down, may not be shunted. Release one of the keys or check the switch and the cabling.	A425		B	
536108	ZE 5: Operation ballasting / counterweight carriage Counterweight carriage (BW) is inserted but not yet bolted report of error, otherwise no reaction Bolt or unplug counterweight carriage.	A425		B	
536109	ZE 5: Operation ballasting / counterweight carriage BW is bolted but not inserted - dummy plug is inserted Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Unbolt or plug in counterweight carriage.	A425		B	
536110	ZE 5: Operation ballasting / counterweight carriage No counterweight inserted or dummy plug not inserted report of error, otherwise no reaction Plug in dummy plug.	A425		B	
536111	ZE 5: Operation ballasting / counterweight carriage Counterweight carriage (BW) is bolted but not inserted Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Unbolt or plug in counterweight carriage.	A425		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
536112	ZE 5: Operation ballasting / counterweight carriage Leveling (B/BW)without function level sensor(B/BW) erroneous/missing Levelling is switched off, switches for cylinder A - Stop and cylinder B - Stop however carry on functioning. Check defective or missing level sensor. See also corresponding system error.	A425		B	
536118	ZE 5: Operation ballasting / counterweight carriage Shut-down measuring point 1 < F min Operation conditional shut-down, may not be shunted. Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A425		B	
536119	ZE 5: Operation ballasting / counterweight carriage no or invalid operation mode shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A425		B	
536120	ZE 5: Operation ballasting / counterweight carriage LMB shut-down operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A425		B	
536121	ZE 5: Operation ballasting / counterweight carriage Shut-down measuring point 1 > F max - operation operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A425		B	
536122	ZE 5: Operation ballasting / counterweight carriage Shut-down measuring point 1 > F max - assembly Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A425		B	
536124	ZE 5: Operation ballasting / counterweight carriage Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A425		B	
53612B	ZE 5: Operation ballasting / counterweight carriage Shut off Derrick ballast pulled > Derrick ballast max Operation conditional switch off, may not be shunted Lower load or derrick ballast	A425		B	
53612F	ZE 5: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E max pulled Ballast exceeded	A425		B	
536130	ZE 5: Operation ballasting / counterweight carriage Switch-off key ballast "Up" clamping or actuated with start Output of error, crane function is not selected. Release counterweight "Up" key or check key and its cabling for correct functioning	A425		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
536131	ZE 5: Operation ballasting / counterweight carriage Switch-off key ballast "Down" clamping or actuated with start Output of error, crane function is not selected. Release counterweight "Down" key or check key and its cabling for correct functioning	A425		B	
536132	ZE 5: Operation ballasting / counterweight carriage Switch-off key ballast "On" clamping or actuated with start Output of error, crane function is not selected. Release counterweight "On" key or check key and its cabling for correct functioning	A425		B	
536133	ZE 5: Operation ballasting / counterweight carriage Switch-off key ballast "Off" clamping or actuated with start Output of error, crane function is not selected. Release counterweight "Off" key or Taste check key and its cabling for correct functioning	A425		B	
536134	ZE 5: Operation ballasting / counterweight carriage Switch-off key support "Up" clamping or actuated with start Output of error, crane function is not selected. Release support "Up" key or check key and its cabling for correct functioning	A425		B	
536135	ZE 5: Operation ballasting / counterweight carriage Switch-off key support "Down" clamping or actuated with start Output of error, crane function is not selected. Release support "Down" key or check key and its cabling for correct functioning	A425		B	
536136	ZE 5: Operation ballasting / counterweight carriage Switch-off key BW steering system clamping or actuated with start Output of error, crane function is not selected. Release keys for steering programs and after steering or check key and its cabling for correct functioning	A425		B	
53613F	ZE 5: Operation ballasting / counterweight carriage Wheel drive "On" blocked - rot. speed too high (C-key) Issue of error, function not actuated Set slewing speed (C-Button) acc. to specifications in load charts or operating instructions	A425		B	
536140	ZE 5: Operation ballasting / counterweight carriage Wheel drive "On" blocked - turning or parallel travel not "On" Issue of error, function not actuated Turn switch wheel drive off or pre-selection ballast trailer circular or parallel travel	A425		B	
536141	ZE 5: Operation ballasting / counterweight carriage Wheel drive "On" blocked - Ballast trailer lifted off is turned on Issue of error, function not actuated Turn switch wheel drive off or lower ballast onto wheels if possible and turn switch "BT lifted off" off	A425		B	
536144	ZE 5: Operation ballasting / counterweight carriage Shut-off crane engine not running Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A425		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
536154	ZE 5: Operation ballasting / counterweight carriage Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted Wind off main boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A425		B	
536155	ZE 5: Operation ballasting / counterweight carriage Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Wind off derrick boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A425		B	
536166	ZE 5: Operation ballasting / counterweight carriage Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted Release button Error remedy, see resp. system error	A425		B	
536167	ZE 5: Operation ballasting / counterweight carriage Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted Release button Error remedy, see resp. system error	A425		B	
536170	ZE 5: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536171	ZE 5: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" vo. right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536172	ZE 5: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" hi. left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536173	ZE 5: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" hi. right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536174	ZE 5: Operation ballasting / counterweight carriage Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536175	ZE 5: Operation ballasting / counterweight carriage Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
536185	ZE 5: Operation ballasting / counterweight carriage Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536186	ZE 5: Operation ballasting / counterweight carriage Shut-down limit switch "RFP Main boom" links faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536187	ZE 5: Operation ballasting / counterweight carriage Shut-down limit switch "Overtop guard cyl D" right faulty/not prese Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536188	ZE 5: Operation ballasting / counterweight carriage Shut-down limit switch "Overtop guard cyl D" left faulty/not presen Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A425		B	
536191	ZE 5: Operation ballasting / counterweight carriage Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted Release button Error remedy, see resp. system error	A425		B	
536192	ZE 5: Operation ballasting / counterweight carriage Shut off pressure Relapse cyl. derrick outside nom. range Operation conditional switch off, may not be shunted Release button Error remedy, see resp. system error	A425		B	
53619C	ZE 5: Operation ballasting / counterweight carriage Shut-off test point 3 < F min Operation conditional switch off, may not be shunted Lower load or lower or retract derrick ballast if possible or spool out retraction gear if possible.	A425		B	
5361BE	ZE 5: Operation ballasting / counterweight carriage Shut off upper limit shut off angle main boom (load chart) Operation conditional switch off, may not be shunted Spool main b. contr. winch out until no shut off present - shut off cannot be bypassed	A425		B	
5361F1	ZE 5: Operation ballasting / counterweight carriage Shut off Test point 1 < F min and upper limit angle Derrick OGWD operational shut down If possible, move derrick boom in op. position, for that assembly - winch 4 can be lowered	A425		B	
536942	ZE 5: Operation crane control Emergency op. crane cont. switched on with start test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A425		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
536943	ZE 5: Operation crane control Emergency op. crane control switched on during test-safety chain report of error, otherwise no reaction Switch off emergency operation, restart LICCON, test safety chain will then be carried out	A425		B	1
561001	E/A-Modul 5: system error OS-C167 initialising error processor-register erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A15		E	2
561002	E/A-Modul 5: system error OS-C167 initialising error test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A15		E	2
561006	E/A-Modul 5: system error OS-C167 initialising error RAM erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A15		E	2
561013	E/A-Modul 5: system error OS-C167 test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A15		E	2
561016	E/A-Modul 5: system error OS-C167 system-, driver-watchdog expired error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A15		E	2
561068	E/A-Modul 5: system error OS-C167 impermissible interrupt error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A15		E	2
561071	E/A-Modul 5: system error OS-C167 Invalid configuration or Firmware error indication on display re-load Software from ZE	A15		E	2
561080	E/A-Modul 5: system error OS-C167 fatal internal software error error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A15		E	2
561082	E/A-Modul 5: system error OS-C167 hardware-watchdog erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
561088	E/A-Modul 5: system error OS-C167 Configuration does not match software condition error indication on display Comparison SW-condition EAM-SW and configuration LICCON different, check LICCON-configuration, download EAM	A15		E	2
561089	E/A-Modul 5: system error OS-C167 Incorrect version of firmware installed Error output, possible error functions of module Replace module, reload firmware	A15		E	1
561090	E/A-Modul 5: system error OS-C167 Incorrect hardware version recognised Error output, possible error functions of module Replace module	A15		E	1
572052	E/A-Modul 5: input/output DEA0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:17		E	1
572053	E/A-Modul 5: input/output DEA0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:17		E	1
572054	E/A-Modul 5: input/output DEA0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:17		E	1
572055	E/A-Modul 5: input/output DEA0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:17		E	1
572152	E/A-Modul 5: input/output DEA1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:15		E	1
572153	E/A-Modul 5: input/output DEA1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:15		E	1
572154	E/A-Modul 5: input/output DEA1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
572155	E/A-Modul 5: input/output DEA1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:15		E	1
572252	E/A-Modul 5: input/output DEA2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:13		E	1
572253	E/A-Modul 5: input/output DEA2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:13		E	1
572254	E/A-Modul 5: input/output DEA2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:13		E	1
572255	E/A-Modul 5: input/output DEA2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:13		E	1
572352	E/A-Modul 5: input/output DEA3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:11		E	1
572353	E/A-Modul 5: input/output DEA3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:11		E	1
572354	E/A-Modul 5: input/output DEA3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:11		E	1
572355	E/A-Modul 5: input/output DEA3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:11		E	1
572452	E/A-Modul 5: input/output DEA4 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
572453	E/A-Modul 5: input/output DEA4 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:9		E	1
572454	E/A-Modul 5: input/output DEA4 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:9		E	1
572455	E/A-Modul 5: input/output DEA4 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:9		E	1
572552	E/A-Modul 5: input/output DEA5 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:7		E	1
572553	E/A-Modul 5: input/output DEA5 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:7		E	1
572554	E/A-Modul 5: input/output DEA5 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:7		E	1
572555	E/A-Modul 5: input/output DEA5 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:7		E	1
572652	E/A-Modul 5: input/output DEA6 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:5		E	1
572653	E/A-Modul 5: input/output DEA6 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:5		E	1
572654	E/A-Modul 5: input/output DEA6 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
572655	E/A-Modul 5: input/output DEA6 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:5		E	1
572752	E/A-Modul 5: input/output DEA7 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:3		E	1
572753	E/A-Modul 5: input/output DEA7 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:3		E	1
572754	E/A-Modul 5: input/output DEA7 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:3		E	1
572755	E/A-Modul 5: input/output DEA7 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:3		E	1
573782	E/A-Modul 5: voltage input E7 short circuit to ground, open line, constant current 10 mA incorrect On the indicator unit, the symbol blinks for the Diesel tank check input signal on the E/A-Modul or sensor	A15.X2:3		E	1
573783	E/A-Modul 5: voltage input E7 short circuit to supply voltage, open line, lack of voltage On the indicator unit, the symbol blinks for the Diesel tank check input signal on the E/A-Modul or sensor	A15.X2:3		E	1
579052	E/A-Modul 5: output A0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:18		E	1
579053	E/A-Modul 5: output A0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:18		E	1
579054	E/A-Modul 5: output A0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
579055	E/A-Modul 5: output A0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:18		E	1
579152	E/A-Modul 5: output A1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:16		E	1
579153	E/A-Modul 5: output A1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:16		E	1
579154	E/A-Modul 5: output A1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:16		E	1
579155	E/A-Modul 5: output A1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:16		E	1
579250	E/A-Modul 5: bridge output A2 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A15.X3:14		E	1
579251	E/A-Modul 5: bridge output A2 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A15.X3:14		E	1
579252	E/A-Modul 5: bridge output A2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:14		E	1
579253	E/A-Modul 5: bridge output A2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:14		E	1
579254	E/A-Modul 5: bridge output A2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
579255	E/A-Modul 5: bridge output A2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:14		E	1
579350	E/A-Modul 5: bridge output A3 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A15.X3:12		E	1
579351	E/A-Modul 5: bridge output A3 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A15.X3:12		E	1
579352	E/A-Modul 5: bridge output A3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A15.X3:12		E	1
579353	E/A-Modul 5: bridge output A3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A15.X3:12		E	1
579354	E/A-Modul 5: bridge output A3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A15.X3:12		E	1
579355	E/A-Modul 5: bridge output A3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A15.X3:12		E	1
584104	E/A-Modul 5: LSB-B participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A15.X3:4/6		E	1
584105	E/A-Modul 5: LSB-B participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A15.X3:4/6		E	1
584118	E/A-Modul 5: LSB-B participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A15.X3:4/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
584150	E/A-Modul 5: LSB-B participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A15.X3:4/6		E	2
584151	E/A-Modul 5: LSB-B participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A15.X3:4/6		E	2
584153	E/A-Modul 5: LSB-B participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A15.X3:4/6		E	1
584154	E/A-Modul 5: LSB-B participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A15.X3:4/6		E	2
584164	E/A-Modul 5: LSB-B participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A15.X3:4/6		E	1
584165	E/A-Modul 5: LSB-B participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A15.X3:4/6		E	2
584166	E/A-Modul 5: LSB-B participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A15.X3:4/6		E	2
584167	E/A-Modul 5: LSB-B participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A15.X3:4/6		E	1
584204	E/A-Modul 5: LSB-B participant address 2 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A15.X3:4/6		E	1
584205	E/A-Modul 5: LSB-B participant address 2 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A15.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
584218	E/A-Modul 5: LSB-B participant address 2 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A15.X3:4/6		E	0
584250	E/A-Modul 5: LSB-B participant address 2 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A15.X3:4/6		E	2
584251	E/A-Modul 5: LSB-B participant address 2 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A15.X3:4/6		E	2
584253	E/A-Modul 5: LSB-B participant address 2 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A15.X3:4/6		E	1
584254	E/A-Modul 5: LSB-B participant address 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A15.X3:4/6		E	2
584264	E/A-Modul 5: LSB-B participant address 2 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A15.X3:4/6		E	1
584265	E/A-Modul 5: LSB-B participant address 2 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A15.X3:4/6		E	2
584266	E/A-Modul 5: LSB-B participant address 2 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A15.X3:4/6		E	2
584267	E/A-Modul 5: LSB-B participant address 2 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A15.X3:4/6		E	1
584304	E/A-Modul 5: LSB-B participant address 3 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A15.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
584305	E/A-Modul 5: LSB-B participant address 3 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A15.X3:4/6		E	1
584318	E/A-Modul 5: LSB-B participant address 3 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A15.X3:4/6		E	0
584350	E/A-Modul 5: LSB-B participant address 3 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A15.X3:4/6		E	2
584351	E/A-Modul 5: LSB-B participant address 3 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A15.X3:4/6		E	2
584353	E/A-Modul 5: LSB-B participant address 3 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A15.X3:4/6		E	1
584354	E/A-Modul 5: LSB-B participant address 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A15.X3:4/6		E	2
584364	E/A-Modul 5: LSB-B participant address 3 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A15.X3:4/6		E	1
584365	E/A-Modul 5: LSB-B participant address 3 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A15.X3:4/6		E	2
584366	E/A-Modul 5: LSB-B participant address 3 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A15.X3:4/6		E	2
584367	E/A-Modul 5: LSB-B participant address 3 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A15.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
584404	E/A-Modul 5: LSB-B participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A15.X3:4/6		E	1
584405	E/A-Modul 5: LSB-B participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A15.X3:4/6		E	1
584418	E/A-Modul 5: LSB-B participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A15.X3:4/6		E	0
584450	E/A-Modul 5: LSB-B participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A15.X3:4/6		E	2
584451	E/A-Modul 5: LSB-B participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A15.X3:4/6		E	2
584453	E/A-Modul 5: LSB-B participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A15.X3:4/6		E	1
584454	E/A-Modul 5: LSB-B participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A15.X3:4/6		E	2
584464	E/A-Modul 5: LSB-B participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A15.X3:4/6		E	1
584465	E/A-Modul 5: LSB-B participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A15.X3:4/6		E	2
584466	E/A-Modul 5: LSB-B participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A15.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
584467	E/A-Modul 5: LSB-B participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A15.X3:4/6		E	1
584504	E/A-Modul 5: LSB-B participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A15.X3:4/6		E	1
584505	E/A-Modul 5: LSB-B participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A15.X3:4/6		E	1
584518	E/A-Modul 5: LSB-B participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A15.X3:4/6		E	0
584550	E/A-Modul 5: LSB-B participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A15.X3:4/6		E	2
584551	E/A-Modul 5: LSB-B participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A15.X3:4/6		E	2
584553	E/A-Modul 5: LSB-B participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A15.X3:4/6		E	1
584554	E/A-Modul 5: LSB-B participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A15.X3:4/6		E	2
584564	E/A-Modul 5: LSB-B participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A15.X3:4/6		E	1
584565	E/A-Modul 5: LSB-B participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A15.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
584566	E/A-Modul 5: LSB-B participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A15.X3:4/6		E	2
584567	E/A-Modul 5: LSB-B participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A15.X3:4/6		E	1
584604	E/A-Modul 5: LSB-B participant address 6 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A15.X3:4/6		E	1
584605	E/A-Modul 5: LSB-B participant address 6 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A15.X3:4/6		E	1
584618	E/A-Modul 5: LSB-B participant address 6 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A15.X3:4/6		E	0
584650	E/A-Modul 5: LSB-B participant address 6 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A15.X3:4/6		E	2
584651	E/A-Modul 5: LSB-B participant address 6 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A15.X3:4/6		E	2
584653	E/A-Modul 5: LSB-B participant address 6 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A15.X3:4/6		E	1
584654	E/A-Modul 5: LSB-B participant address 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A15.X3:4/6		E	2
584664	E/A-Modul 5: LSB-B participant address 6 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A15.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
584665	E/A-Modul 5: LSB-B participant address 6 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A15.X3:4/6		E	2
584666	E/A-Modul 5: LSB-B participant address 6 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A15.X3:4/6		E	2
584667	E/A-Modul 5: LSB-B participant address 6 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A15.X3:4/6		E	1
585604	E/A-Modul 5: LSB-B participant address 16 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A15.X3:4/6		E	1
585605	E/A-Modul 5: LSB-B participant address 16 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A15.X3:4/6		E	1
585618	E/A-Modul 5: LSB-B participant address 16 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A15.X3:4/6		E	0
585650	E/A-Modul 5: LSB-B participant address 16 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A15.X3:4/6		E	2
585651	E/A-Modul 5: LSB-B participant address 16 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A15.X3:4/6		E	2
585653	E/A-Modul 5: LSB-B participant address 16 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A15.X3:4/6		E	1
585654	E/A-Modul 5: LSB-B participant address 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A15.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
585664	E/A-Modul 5: LSB-B participant address 16 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A15.X3:4/6		E	1
585665	E/A-Modul 5: LSB-B participant address 16 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A15.X3:4/6		E	2
585666	E/A-Modul 5: LSB-B participant address 16 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A15.X3:4/6		E	2
585667	E/A-Modul 5: LSB-B participant address 16 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A15.X3:4/6		E	1
587252	E/A-Modul 5: Control data transfer LSB-B has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A15.X3:4/6		E	0
587255	E/A-Modul 5: Control data transfer LSB-B Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A15.X3:4/6		E	2
587256	E/A-Modul 5: Control data transfer LSB-B Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A15.X3:4/6		E	2
587257	E/A-Modul 5: Control data transfer LSB-B has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A15.X3:4/6		E	1
587258	E/A-Modul 5: Control data transfer LSB-B recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A15.X3:4/6		E	0
587259	E/A-Modul 5: Control data transfer LSB-B recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A15.X3:4/6		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
587260	E/A-Modul 5: Control data transfer LSB-B driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A15.X3:4/6		E	2
587261	E/A-Modul 5: Control data transfer LSB-B driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A15.X3:4/6		E	2
587262	E/A-Modul 5: Control data transfer LSB-B Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A15.X3:4/6		E	2
587530	E/A-Modul 5: CAN-participant engine Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A15.X5:5/6		E	1
587531	E/A-Modul 5: CAN-participant engine Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A15.X5:5/6		E	1
587630	E/A-Modul 5: CAN-participant gear Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A15.X5:5/6		E	1
587631	E/A-Modul 5: CAN-participant gear Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A15.X5:5/6		E	1
587730	E/A-Modul 5: CAN-participant ABV (ABS/ASR) Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A15.X5:5/6		E	1
587731	E/A-Modul 5: CAN-participant ABV (ABS/ASR) Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A15.X5:5/6		E	1
587930	E/A-Modul 5: CAN-participant retarder Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A15.X5:5/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
587931	E/A-Modul 5: CAN-participant retarder Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A15.X5:5/6		E	1
588030	E/A-Modul 5: CAN-user converter clutch unit CCU Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A15.X5:5/6		E	1
588031	E/A-Modul 5: CAN-user converter clutch unit CCU Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A15.X5:5/6		E	1
588530	E/A-Modul 5: CAN-participant E/A-Modul 1 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A15.X5:5/6		E	1
588531	E/A-Modul 5: CAN-participant E/A-Modul 1 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A15.X5:5/6		E	1
588930	E/A-Modul 5: CAN-participant E/A-Modul 5 Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time check bus lines/neutral point, check defective bus participant	A15.X5:5/6		E	1
588931	E/A-Modul 5: CAN-participant E/A-Modul 5 Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used check bus lines/neutral point, check defective bus participant	A15.X5:5/6		E	1
589900	E/A-Modul 5: Control data transfer CAN internal error at Register-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A15.X5:5/6		E	2
589901	E/A-Modul 5: Control data transfer CAN internal error at RAM-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A15.X5:5/6		E	2
589902	E/A-Modul 5: Control data transfer CAN Configuration error Software internal error, CAN-transmission will be aborted replace E/A-Modul, check Software (test system ZE)	A15.X5:5/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
589903	E/A-Modul 5: Control data transfer CAN Transfer interrupted after continuous error CAN-Transmission will be aborted check bus lines/neutral point, replace neutral point or E/A-Modul	A15.X5:5/6		E	1
589910	E/A-Modul 5: Control data transfer CAN short-term error in bus connection re-attachment of Modul to bus transmission check bus lines/neutral point, unplug individual bus participant and check if error has been eliminated	A15.X5:5/6		E	1
589911	E/A-Modul 5: Control data transfer CAN permanent error bus connection cyclic re-attachment of Modul to bus transmission check bus lines/neutral point, unplug individual bus participant and check if error has been eliminated	A15.X5:5/6		E	1
589920	E/A-Modul 5: Control data transfer CAN active participant not responding parameterised substitute values for receiver signals will be used check error report for missing participant(s), test system ZE	A15.X5:5/6		E	1
589921	E/A-Modul 5: Control data transfer CAN No active subscriber responding parameterised substitute values for receiver signals will be used in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A15.X5:5/6		E	1
589950	E/A-Modul 5: Control data transfer CAN erroneous command test system no reaction to unknown test system control command in CAN-System Software check Software (test system)	A15.X5:5/6		E	1
592001	E/A-Modul 5: control engine long-term disruption E/A-Modul <-> engine control engine control and E/A-Modul at emergency speed engine control and E/A-Modul, check CAN-bus-connections	A15		E	1
592005	E/A-Modul 5: control engine condition erroneous: CAN-signal engine ON <-> load ctrl. D+ OFF identification engine ON/OFF possibly erroneous check alternator line connection to display unit, check alternator signal	A15		E	1
592006	E/A-Modul 5: control engine condition erroneous: CAN-signal engine OFF <-> load ctrl. D+ ON identification engine ON/OFF possibly erroneous check alternator line connection to display unit, check alternator signal	A15		E	1
592034	E/A-Modul 5: control engine Travel speed Tachograph missing Tempomat/Tempo-set-function blocked, engine will be limited in the torque output Tachograph connection <->E/A-Modul, check signals to inputs from E/A-Modul; replace E/A-Modul Taco	A15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
592035	E/A-Modul 5: control engine Travel speed Tachograph incorrect Tempomat/Tempo-set-function blocked, engine will be limited in the torque output Tachograph connection <->E/A-Modul, check signals to inputs from E/A-Modul; replace E/A-Modul Taco	A15		E	1
592036	E/A-Modul 5: control engine Travel speed Tachograph <-> Gear output RPM not plausible Tempomat/Tempo-set-function blocked, engine will be limited in the torque output Tachograph connection <->E/A-Modul, signals to inputs from E/A-Modul, check gear speed; replace E/A-Modul Taco	A15		E	1
592102	E/A-Modul 5: control transmission permanent malfunction E/A-Modul 1 <-> E/A-Modul 5 travel switch signals will be switched off, emergency operation check CAN-bus system, E/A-Module 1 and 5	A15		E	1
592121	E/A-Modul 5: control transmission shift selector-specified gear range/travel direction erroneous travel switch signals will be switched off, emergency operation check CAN-bus system, Check Software in E/A-Modules (test system)	A15		E	1
592957	E/A-Modul 5: control brakes/pneumatic system brake pressure switch 0.5 bar signal "op. brakes active" missing operation brake signal activated if circle 1+2 > 1,5 bar, stronger application of the brake necessary check connection from brake pressure switch to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593160	E/A-Modul 5: instruments operators cab auxiliary brakes signal level 1 missing auxiliary brake(s) is/are not actuated check connection from brake lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593161	E/A-Modul 5: instruments operators cab auxiliary brakes signal level 2 missing auxiliary brake(s) is/are not actuated check connection from brake lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593162	E/A-Modul 5: instruments operators cab auxiliary brakes signal level 3 missing auxiliary brake(s) is/are not actuated check connection from brake lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593165	E/A-Modul 5: instruments operators cab auxiliary brakes signal level 1 short to supply voltage auxiliary brake(s) is/are not actuated check connection from brake lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593166	E/A-Modul 5: instruments operators cab auxiliary brakes signal level 2 short to supply voltage auxiliary brake(s) is/are not actuated check connection from brake lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
593167	E/A-Modul 5: instruments operators cab auxiliary brakes signal level 3 short to supply voltage auxiliary brake(s) is/are not actuated check connection from brake lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593175	E/A-Modul 5: instruments operators cab Tempomat lever no signal or supply voltage missing auxiliary brake(s) is/are not actuated check connection from brake lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593176	E/A-Modul 5: instruments operators cab Tempomat lever signal SET+ no signal or short to ground Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593177	E/A-Modul 5: instruments operators cab Tempomat lever signal SET- no signal or short to ground Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593178	E/A-Modul 5: instruments operators cab Tempomat lever signal OFF no signal or short to ground Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593179	E/A-Modul 5: instruments operators cab Tempomat lever signal QUIT short to supply voltage Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593180	E/A-Modul 5: instruments operators cab Tempomat lever signal TEMPOSET short to supply voltage Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593181	E/A-Modul 5: instruments operators cab Tempomat lever signal TEMPOMAT SET+ without returning (QUIT) Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593182	E/A-Modul 5: instruments operators cab Tempomat lever signal TEMPOMAT SET- without returning (QUIT) Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
593183	E/A-Modul 5: instruments operators cab Tempomat lever signal OFF without returning (QUIT) Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
593184	E/A-Modul 5: instruments operators cab Tempomat lever signals SET+, SET-, OFF erroneous combination Tempomat/Temposet-functions blocked check connection from Tempomat lever to E/A-Modul, check signals to entries from E/A-Modul, replace E/A-Modul	A15		E	1
594081	E/A-Modul 5: Control active rear axle steering Return report steering status right faulty/missing Steering becomes faulty following time-out, speed becomes limited Steering, check LSB	A15		E	1
594082	E/A-Modul 5: Control active rear axle steering Return report steering status left faulty/missing Steering becomes faulty following time-out, speed becomes limited Steering, check LSB	A15		E	1
594083	E/A-Modul 5: Control active rear axle steering Return report steering status right/left implausible Steering becomes faulty following time-out, speed becomes limited Steering, check LSB	A15		E	1
594190	E/A-Modul 5: LSB-bus participant ZE missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A15		E	1
594191	E/A-Modul 5: LSB-bus participant E/A-Modul 1 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A15		E	1
594192	E/A-Modul 5: LSB-bus participant E/A-Modul 2 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A15		E	1
594193	E/A-Modul 5: LSB-bus participant E/A-Modul 3 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A15		E	1
594194	E/A-Modul 5: LSB-bus participant E/A-Modul 4 missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A15		E	1
595074	E/A-Modul 5: operation engine accelerator operators cab blocked in upper-carriage operation mode function is not carried out	A15		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
595075	E/A-Modul 5: operation engine accelerator operators cab blocked in support operation mode function is not carried out	A15		B	
595076	E/A-Modul 5: operation engine accelerator op. cab blocked when auxiliary brake active or selected function is not carried out	A15		B	
595077	E/A-Modul 5: operation engine accelerator upper-carr. activated on malf. of GAS <-> E/A-Modul function is not carried out	A15		B	
596885	E/A-Modul 5: operation instruments operators cab Tempomat lever blocked in upper-carriage operation mode function is not carried out	A15		B	
596886	E/A-Modul 5: operation instruments operators cab Tempomat lever blocked in support operation mode function is not carried out	A15		B	
661001	E/A-Modul 6: system error OS-C167 initialising error processor-register erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A16		E	2
661002	E/A-Modul 6: system error OS-C167 initialising error test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A16		E	2
661006	E/A-Modul 6: system error OS-C167 initialising error RAM erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A16		E	2
661013	E/A-Modul 6: system error OS-C167 test total in EPROM/FLASH erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A16		E	2
661016	E/A-Modul 6: system error OS-C167 system-, driver-watchdog expired error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
661068	E/A-Modul 6: system error OS-C167 impermissible interrupt error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A16		E	2
661071	E/A-Modul 6: system error OS-C167 Invalid configuration or Firmware error indication on display re-load Software from ZE	A16		E	2
661080	E/A-Modul 6: system error OS-C167 fatal internal software error error indication on display note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A16		E	2
661082	E/A-Modul 6: system error OS-C167 hardware-watchdog erroneous error indication on display ignition ON/OFF, with repeated occurrence --> replace E/A-Modul	A16		E	2
661088	E/A-Modul 6: system error OS-C167 Configuration does not match software condition error indication on display Comparison SW-condition EAM-SW and configuration LICCON different, check LICCON-configuration, download EAM	A16		E	2
661089	E/A-Modul 6: system error OS-C167 Incorrect version of firmware installed Error output, possible error functions of module Replace module, reload firmware	A16		E	1
661090	E/A-Modul 6: system error OS-C167 Incorrect hardware version recognised Error output, possible error functions of module Replace module	A16		E	1
672052	E/A-Modul 6: input/output DEA0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:17		E	1
672053	E/A-Modul 6: input/output DEA0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:17		E	1
672054	E/A-Modul 6: input/output DEA0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
672055	E/A-Modul 6: input/output DEA0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:17		E	1
672152	E/A-Modul 6: input/output DEA1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:15		E	1
672153	E/A-Modul 6: input/output DEA1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:15		E	1
672154	E/A-Modul 6: input/output DEA1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:15		E	1
672155	E/A-Modul 6: input/output DEA1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:15		E	1
672252	E/A-Modul 6: input/output DEA2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:13		E	1
672253	E/A-Modul 6: input/output DEA2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:13		E	1
672254	E/A-Modul 6: input/output DEA2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:13		E	1
672255	E/A-Modul 6: input/output DEA2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:13		E	1
672352	E/A-Modul 6: input/output DEA3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
672353	E/A-Modul 6: input/output DEA3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:11		E	1
672354	E/A-Modul 6: input/output DEA3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:11		E	1
672355	E/A-Modul 6: input/output DEA3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:11		E	1
672452	E/A-Modul 6: input/output DEA4 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:9		E	1
672453	E/A-Modul 6: input/output DEA4 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:9		E	1
672454	E/A-Modul 6: input/output DEA4 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:9		E	1
672455	E/A-Modul 6: input/output DEA4 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:9		E	1
672552	E/A-Modul 6: input/output DEA5 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:7		E	1
672553	E/A-Modul 6: input/output DEA5 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:7		E	1
672554	E/A-Modul 6: input/output DEA5 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
672555	E/A-Modul 6: input/output DEA5 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:7		E	1
672652	E/A-Modul 6: input/output DEA6 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:5		E	1
672653	E/A-Modul 6: input/output DEA6 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:5		E	1
672654	E/A-Modul 6: input/output DEA6 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:5		E	1
672655	E/A-Modul 6: input/output DEA6 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:5		E	1
672752	E/A-Modul 6: input/output DEA7 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:3		E	1
672753	E/A-Modul 6: input/output DEA7 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:3		E	1
672754	E/A-Modul 6: input/output DEA7 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:3		E	1
672755	E/A-Modul 6: input/output DEA7 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:3		E	1
673482	E/A-Modul 6: voltage input E4 short circuit to ground, open line, constant current 10 mA incorrect Display LICCON: ?? °C check input signal on the E/A-Modul or sensor	A16.X2:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
673483	E/A-Modul 6: voltage input E4 short circuit to supply voltage, open line, lack of voltage Display LICCON: ?? °C check input signal on the E/A-Modul or sensor	A16.X2:9		E	1
673782	E/A-Modul 6: voltage input E7 short circuit to ground, open line, constant current 10 mA incorrect display Liccon:??? % check input signal on the E/A-Modul or sensor	A16.X2:3		E	1
673783	E/A-Modul 6: voltage input E7 short circuit to supply voltage, open line, lack of voltage display Liccon:??? % check input signal on the E/A-Modul or sensor	A16.X2:3		E	1
679052	E/A-Modul 6: output A0 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:18		E	1
679053	E/A-Modul 6: output A0 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:18		E	1
679054	E/A-Modul 6: output A0 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:18		E	1
679055	E/A-Modul 6: output A0 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:18		E	1
679152	E/A-Modul 6: output A1 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:16		E	1
679153	E/A-Modul 6: output A1 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:16		E	1
679154	E/A-Modul 6: output A1 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
679155	E/A-Modul 6: output A1 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:16		E	1
679250	E/A-Modul 6: bridge output A2 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A16.X3:14		E	1
679251	E/A-Modul 6: bridge output A2 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A16.X3:14		E	1
679252	E/A-Modul 6: bridge output A2 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:14		E	1
679253	E/A-Modul 6: bridge output A2 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:14		E	1
679254	E/A-Modul 6: bridge output A2 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:14		E	1
679255	E/A-Modul 6: bridge output A2 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:14		E	1
679350	E/A-Modul 6: bridge output A3 short circuit to ground, junction not supplied error report on display check output for short, check current supply of load, if necessary replace E/A-Modul	A16.X3:12		E	1
679351	E/A-Modul 6: bridge output A3 short circuit to supply voltage, excessive temperature error report on display check output for short, check output load (measure load current), if necessary replace E/A-Modul	A16.X3:12		E	1
679352	E/A-Modul 6: bridge output A3 output open, to low load, short circuit to supply voltage error report on display check output for broken wire, check load on output (measure load current), if necessary replace E/A-Modul	A16.X3:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
679353	E/A-Modul 6: bridge output A3 transistor current supply insufficient or missing error report on display check current supply and fuse E/A-Modul, if necessary replace E/A-Modul	A16.X3:12		E	1
679354	E/A-Modul 6: bridge output A3 short circuit to supply voltage error report on display check output for short, if necessary replace E/A-Modul	A16.X3:12		E	1
679355	E/A-Modul 6: bridge output A3 excessive temperature, short circuit to ground or overload error report on display check output for short, current supply, check fuse of E/A-Modul, if necessary replace E/A-Modul	A16.X3:12		E	1
684104	E/A-Modul 6: LSB-B participant address 1 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A16.X3:4/6		E	1
684105	E/A-Modul 6: LSB-B participant address 1 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A16.X3:4/6		E	1
684118	E/A-Modul 6: LSB-B participant address 1 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A16.X3:4/6		E	0
684150	E/A-Modul 6: LSB-B participant address 1 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A16.X3:4/6		E	2
684151	E/A-Modul 6: LSB-B participant address 1 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A16.X3:4/6		E	2
684153	E/A-Modul 6: LSB-B participant address 1 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A16.X3:4/6		E	1
684154	E/A-Modul 6: LSB-B participant address 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A16.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
684164	E/A-Modul 6: LSB-B participant address 1 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A16.X3:4/6		E	1
684165	E/A-Modul 6: LSB-B participant address 1 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A16.X3:4/6		E	2
684166	E/A-Modul 6: LSB-B participant address 1 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A16.X3:4/6		E	2
684167	E/A-Modul 6: LSB-B participant address 1 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A16.X3:4/6		E	1
684404	E/A-Modul 6: LSB-B participant address 4 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A16.X3:4/6		E	1
684405	E/A-Modul 6: LSB-B participant address 4 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A16.X3:4/6		E	1
684418	E/A-Modul 6: LSB-B participant address 4 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A16.X3:4/6		E	0
684450	E/A-Modul 6: LSB-B participant address 4 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A16.X3:4/6		E	2
684451	E/A-Modul 6: LSB-B participant address 4 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A16.X3:4/6		E	2
684453	E/A-Modul 6: LSB-B participant address 4 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A16.X3:4/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
684454	E/A-Modul 6: LSB-B participant address 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A16.X3:4/6		E	2
684464	E/A-Modul 6: LSB-B participant address 4 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A16.X3:4/6		E	1
684465	E/A-Modul 6: LSB-B participant address 4 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A16.X3:4/6		E	2
684466	E/A-Modul 6: LSB-B participant address 4 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A16.X3:4/6		E	2
684467	E/A-Modul 6: LSB-B participant address 4 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A16.X3:4/6		E	1
684504	E/A-Modul 6: LSB-B participant address 5 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A16.X3:4/6		E	1
684505	E/A-Modul 6: LSB-B participant address 5 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A16.X3:4/6		E	1
684518	E/A-Modul 6: LSB-B participant address 5 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A16.X3:4/6		E	0
684550	E/A-Modul 6: LSB-B participant address 5 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A16.X3:4/6		E	2
684551	E/A-Modul 6: LSB-B participant address 5 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A16.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
684553	E/A-Modul 6: LSB-B participant address 5 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A16.X3:4/6		E	1
684554	E/A-Modul 6: LSB-B participant address 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A16.X3:4/6		E	2
684564	E/A-Modul 6: LSB-B participant address 5 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A16.X3:4/6		E	1
684565	E/A-Modul 6: LSB-B participant address 5 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A16.X3:4/6		E	2
684566	E/A-Modul 6: LSB-B participant address 5 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A16.X3:4/6		E	2
684567	E/A-Modul 6: LSB-B participant address 5 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A16.X3:4/6		E	1
684704	E/A-Modul 6: LSB-B participant address 7 level exceeded report of error, otherwise no reaction check sensor installation, check pre-attenuation of sensor, clean dirt from sensor, replace sensor when defect	A16.X3:4/6		E	1
684705	E/A-Modul 6: LSB-B participant address 7 below minimum level report of error, otherwise no reaction check sensor installation, eliminate clogging or damage to sensor, if defect replace sensor	A16.X3:4/6		E	1
684718	E/A-Modul 6: LSB-B participant address 7 excess temperature report of error, otherwise no reaction operate sensor in permitted temperature range, check sensor heat supply and carry off	A16.X3:4/6		E	0
684750	E/A-Modul 6: LSB-B participant address 7 reports an incorrect sensor type entry in error memory, otherwise no reaction, the answer will be interpreted according to the set type characteristics check address assignment over test system (LSB-screen), install correct sensor	A16.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
684751	E/A-Modul 6: LSB-B participant address 7 was not configured for the block transfer entry in error memory, otherwise no reaction, no block transfer will be carried out configuration problem, load new Software	A16.X3:4/6		E	2
684753	E/A-Modul 6: LSB-B participant address 7 no longer reports or withdrawn during running period entry in error memory, participant will be deactivated, data buffer to the application will be set to 0 check connection, if connection OK then replace sensor	A16.X3:4/6		E	1
684754	E/A-Modul 6: LSB-B participant address 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A16.X3:4/6		E	2
684764	E/A-Modul 6: LSB-B participant address 7 reports tolerable error in self-test entry in error memory, otherwise no reaction; note only: sensor still functions correctly check sensor, clean if necessary, with repeated occurrence replace sensor	A16.X3:4/6		E	1
684765	E/A-Modul 6: LSB-B participant address 7 reports intolerable error in self-test entry in error memory, otherwise no reaction, the error free operation is no longer guaranteed replace sensor immediately	A16.X3:4/6		E	2
684766	E/A-Modul 6: LSB-B participant address 7 with software version, that is no longer compatible entry in error memory, otherwise no reaction, it will be tried as far as possible to work with the sensor replace sensor through new part	A16.X3:4/6		E	2
684767	E/A-Modul 6: LSB-B participant address 7 supports no download function entry in error memory, otherwise no reaction, no download can be carried out no download to be carried out	A16.X3:4/6		E	1
687252	E/A-Modul 6: Control data transfer LSB-B has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A16.X3:4/6		E	0
687255	E/A-Modul 6: Control data transfer LSB-B Bus connection faulty/defect, short circuit to supply voltage entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A16.X3:4/6		E	2
687256	E/A-Modul 6: Control data transfer LSB-B Bus connection faulty/defect, no supply/short circuit to earth entry in error memory, driver tries permanently to re-boot bus, bus boots as soon as error is eliminated check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A16.X3:4/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
687257	E/A-Modul 6: Control data transfer LSB-B has recognised network re-set (data transfer starts again) entry in error memory, driver re-starts and runs re-booting of network check bus lines, withdraw sensors successively from bus until malfunction source recognised, replace defective part	A16.X3:4/6		E	1
687258	E/A-Modul 6: Control data transfer LSB-B recognised participant with incorrect baud rate in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated from system itself, check address assignment of sensors	A16.X3:4/6		E	0
687259	E/A-Modul 6: Control data transfer LSB-B recognised communication breakdown in bus entry in error memory, driver re-starts and runs re-booting of network will be eliminated by driver through re-booting of network	A16.X3:4/6		E	0
687260	E/A-Modul 6: Control data transfer LSB-B driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant with temporary malfunctions error will be eliminated by system itself, with incorrect configuration install new software	A16.X3:4/6		E	2
687261	E/A-Modul 6: Control data transfer LSB-B driver error: undefined message appears entry in error memory, driver re-starts and runs re-booting of network with temporary malf. error will be eliminated by system itself otherwise new Software necessary for error elimination	A16.X3:4/6		E	2
687262	E/A-Modul 6: Control data transfer LSB-B Driver error: Initialization error entry in error memory, driver re-starts and runs re-booting of network new Software is necessary for error elimination	A16.X3:4/6		E	2
687530	E/A-Modul 6: CAN-participant engine Data transfer subscriber transfer cycle exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A16.X5:5/6		E	0
687531	E/A-Modul 6: CAN-participant engine Data transfer faulty/missing, max. cycle time exceeded parameterised substitute values for receiver signals will be used Check CAN network, check faulty Bus user.	A16.X5:5/6		E	1
689030	E/A-Modul 6: CAN-participant E/A-Modul 6 Data transfer subscriber transfer cycle exceeded CAN-Transmission will be aborted Check CAN network, replace E/A-Modul	A16.X5:5/6		E	0
689031	E/A-Modul 6: CAN-participant E/A-Modul 6 Data transfer faulty/missing, max. cycle time exceeded CAN-Information from participant has exceeded the defined cycle time Check CAN network, check faulty Bus user.	A16.X5:5/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
689900	E/A-Modul 6: Control data transfer CAN internal error at Register-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A16.X5:5/6		E	2
689901	E/A-Modul 6: Control data transfer CAN internal error at RAM-check Controller internal error, CAN-transmission will be aborted replace E/A-Modul	A16.X5:5/6		E	2
689902	E/A-Modul 6: Control data transfer CAN Configuration error Software internal error, CAN-transmission will be aborted replace E/A-Modul, check Software (test system ZE)	A16.X5:5/6		E	2
689903	E/A-Modul 6: Control data transfer CAN Transfer interrupted after continuous error CAN-Transmission will be aborted Check CAN network, replace E/A-Modul	A16.X5:5/6		E	1
689910	E/A-Modul 6: Control data transfer CAN short-term error in bus connection re-attachment of Modul to bus transmission Check CAN network, connect individual Bus users and check if error has been remedied	A16.X5:5/6		E	0
689911	E/A-Modul 6: Control data transfer CAN permanent error bus connection cyclic re-attachment of Modul to bus transmission Check CAN network, connect individual Bus users and check if error has been remedied	A16.X5:5/6		E	1
689920	E/A-Modul 6: Control data transfer CAN active participant not responding parameterised substitute values for receiver signals will be used check error report for missing participant(s), test system ZE	A16.X5:5/6		E	0
689921	E/A-Modul 6: Control data transfer CAN No active subscriber responding parameterised substitute values for receiver signals will be used in case bus system is error free, check connection of E/A-Modul to CAN-network, replace E/A-Modul	A16.X5:5/6		E	1
689950	E/A-Modul 6: Control data transfer CAN erroneous command test system no reaction to unknown test system control command in CAN-System Software check Software (test system)	A16.X5:5/6		E	1
692001	E/A-Modul 6: control engine long-term disruption E/A-Modul <-> engine control Continuous CAN-interruption: Engine control in emergency speed After restoring the CAN-communication, the engine electronics remain in emergency speed --> ignition OFF/ON	A16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
692005	E/A-Modul 6: control engine condition erroneous: CAN-signal engine ON <-> load ctrl. D+ OFF check alternator line connection to display unit, check alternator signal	A16		E	1
692006	E/A-Modul 6: control engine condition erroneous: CAN-signal engine OFF <-> load ctrl. D+ ON check alternator line connection to display unit, check alternator signal	A16		E	1
6920D0	E/A-Modul 6: control engine Emerg. off active, connection interruption at active radio remote cont Em. Off reaction is initiated Emerg. off open, reestablish connection	A16		E	1
6920D1	E/A-Modul 6: control engine Emerg. off active, connection interruption at active radio remote cont Em. Off reaction is initiated Emerg. off open, reestablish connection	A16		E	1
6920D2	E/A-Modul 6: control engine Emerg. off active from radio remote control Shut off of releases (Shut off diagram), and control by radio remote control Possibly emerg. off actuated or no radio conn. present	A16		E	1
694190	E/A-Modul 6: LSB-bus participant ZE missing communication with participant not possible, after re-starting of bus communication error will be reset check LSB-network, check participant	A16		E	1
695010	E/A-Modul 6: operation engine Active DPF regeneration prevented, operating condition not OK Active regeneration prevented, conditions on crane not fulfilled	A16		B	
695011	E/A-Modul 6: operation engine Active DPF regeneration prevented, operating condition not OK Active regeneration prevented, conditions on crane not fulfilled	A16		B	
695012	E/A-Modul 6: operation engine Active DPF regeneration prevented by switch (inhibit) Active regeneration prevented by switch on crane or diagnostics tool	A16		B	
695013	E/A-Modul 6: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A16		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
695014	E/A-Modul 6: operation engine Active DPF regeneration prevented, error in engine or AGN Active regeneration prevented, engine error condition	A16		B	
695015	E/A-Modul 6: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A16		B	
695016	E/A-Modul 6: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A16		B	
695017	E/A-Modul 6: operation engine Active DPF regeneration prevented, error in temperature sensors Active regeneration prevented, engine error condition	A16		B	
695018	E/A-Modul 6: operation engine Active DPF regeneration not necessary, loading condition too low Active regeneration prevented/not necessary with current DPF load condition	A16		B	
695019	E/A-Modul 6: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A16		B	
69501A	E/A-Modul 6: operation engine Active DPF regeneration prevented, coolant temperature too low Active regeneration prevented, no release from engine	A16		B	
69501B	E/A-Modul 6: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A16		B	
69501C	E/A-Modul 6: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A16		B	
69501D	E/A-Modul 6: operation engine Active DPF regeneration prevented, no release from engine Active regeneration prevented, no release from engine	A16		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
69501E	E/A-Modul 6: operation engine Active DPF regeneration prevented, engine not idle Active regeneration prevented by current rpm or external specification	A16		B	
69501F	E/A-Modul 6: operation engine Active DPF regeneration prevented, external rpm request active Active regeneration prevented by current rpm or external specification	A16		B	
695040	E/A-Modul 6: operation engine Exhaust aftertreatment (AGN) cleaning proc active - speed increase Active regeneration prevented by current rpm or external specification	A16		B	
695041	E/A-Modul 6: operation engine Exhaust/engine temperatures very high - do not turn engine off! Active regeneration prevented by current rpm or external specification	A16		B	
695050	E/A-Modul 6: operation engine no engine start possible as engine already recognized as ON no start signal on engine check signals KI50 ignition start switch and D+ alternator	A16		B	
695059	E/A-Modul 6: operation engine no start, CAN-connection E/A-Modul <-> engine elec. malfunc no engine start possible from crane operators cab eliminate error in CAN-bus system	A16		B	
695061	E/A-Modul 6: operation engine no start, no operation mode recognised engine start not possible check key	A16		B	
695063	E/A-Modul 6: operation engine no start, engine-STOP-key activated in right support unit engine start not possible check key	A16		B	
695064	E/A-Modul 6: operation engine no start, engine-STOP-key activated in left support unit engine start not possible check key	A16		B	
695065	E/A-Modul 6: operation engine no start, key activated in support unit engine start not possible check key	A16		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
696953	E/A-Modul 6: operation instruments crane operators cab Engine-Stop UC actuated/sticking/short circuit to supply upon start	A16		B	
701000	Power supply unit: Memory card faulty, transmission error, addressing error Shut-down Replace slide-in card			E	2
702100	Power supply unit: RAM-memory faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
702101	Power supply unit: RAM-memory faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
702200	Power supply unit: FLASH- memory faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
702201	Power supply unit: FLASH- memory faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
702300	Power supply unit: EEPROM- memory faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
702301	Power supply unit: EEPROM- memory faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
702400	Power supply unit: Globalbus-/QW-transmission faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
702401	Power supply unit: Globalbus-/QW-transmission faulty, transmission error, addressing error Shut-down Check ZE/bus motherboard/power supply unit connections			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
702500	Power supply unit: FLASH- memory, - module faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
703000	Power supply unit: FPGA faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
703001	Power supply unit: FPGA faulty, transmission error, addressing error Shut-down Replace slide-in card, check connections ZE/bus motherboard/power supply unit			E	2
709002	Power supply unit: internal error Checksum (CRC) incorrect Shut-down Replace power supply unit			E	2
709003	Power supply unit: internal error ADC-conversion faulty, processor error, time exceeded Shut-down Replace power supply unit			E	2
709004	Power supply unit: internal error faulty/incorrect slide-in card Shut-down Replace slide-in card			E	2
70900A	Power supply unit: internal error Signal to Done-Pin incorrect (0) Shut-down Check ZE/bus motherboard/power supply unit			E	2
70900B	Power supply unit: internal error Signal to Done-Pin incorrect (1) Shut-down Check ZE/bus motherboard/power supply unit			E	2
70900D	Power supply unit: internal error Register fault FPGA Shut-down Check ZE/bus motherboard/power supply unit			E	2
709010	Power supply unit: internal error Signal to Done-Pin incorrect (0) Shut-down Check ZE/bus motherboard/power supply unit			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
709011	Power supply unit: internal error Signal to Done-Pin incorrect (1) Shut-down Check ZE/bus motherboard/power supply unit			E	2
709013	Power supply unit: internal error Register fault FPGA Shut-down Check ZE/bus motherboard/power supply unit			E	2
709014	Power supply unit: internal error SCI transmission error, time exceeded (overrun) Shut-down Replace power supply unit			E	2
70901E	Power supply unit: internal error LCA-design time exceeded (ZE 0 faulty/missing) Shut-down Check ZE/bus motherboard/power supply unit			E	2
709020	Power supply unit: internal error SCI transmission error, time exceeded (overrun) Shut-down Replace power supply unit			E	2
709028	Power supply unit: internal error PIC time exceeded Shut-down Replace power supply unit			E	2
709030	Power supply unit: internal error LCA-design time exceeded (ZE 0 faulty/missing) Shut-down Check ZE/bus motherboard/power supply unit			E	2
709032	Power supply unit: internal error Bus controller addressing/time exceeded/data transmission (P1) Shut-down Replace power supply unit			E	2
70903C	Power supply unit: internal error Signal error "Control on" different 0, relay contact sticking Shut-down Check plug/connections/relay			E	2
709040	Power supply unit: internal error PIC time exceeded Shut-down Replace power supply unit			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
709050	Power supply unit: internal error Initialising error excess/lack of voltage Shut-down Replace power supply unit			E	2
709051	Power supply unit: internal error Lack of voltage (P0 = channel, P1 = value) Shut-down Check voltage supply, replace power supply unit			E	2
709052	Power supply unit: internal error Excess voltage (P0 = channel, P1 = value) Shut-down Check voltage supply, replace power supply unit			E	2
709060	Power supply unit: internal error Signal error "Control on" different 0, relay contact sticking Shut-down Check plug/connections/relay			E	2
709063	Power supply unit: internal error Power supply unit off, power supply unit shut-down (note parameter) Shut-down Replace power supply unit			E	2
709080	Power supply unit: internal error Initialising error excess/lack of voltage Shut-down Check voltage supply, replace power supply unit			E	2
709081	Power supply unit: internal error Lack of voltage (P0 = channel, P1 = value) Shut-down Check voltage supply, replace power supply unit			E	2
709082	Power supply unit: internal error Excess voltage (P0 = channel, P1 = value) Shut-down Check voltage supply, replace power supply unit			E	2
709099	Power supply unit: internal error Power supply unit off, power supply unit shut-down (note parameter) Shut-down Replace power supply unit			E	2
810160	ABV: CAN-bus system disrupted data communication ABV function not restricted check CAN-network, check/replace ABV-control device	A60.X1:1/2/3		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
810162	ABV: CAN-bus system Speed signal Tachograph to CAN faulty/missing/implausible ABV function not restricted check CAN-network, ABV-control device, speed signal C3, E/A-Modul 5	A60.X1:1/2/3		E	1
810163	ABV: CAN-bus system Interruption/continuous control line(s) ABV function not restricted check CAN-network, check/replace ABV-control device	A60.X1:1/2/3		E	0
810167	ABV: CAN-bus system CAN-communication gears faulty/not present ABV function not restricted check CAN-network, check/replace ABV-control device	A60.X1:1/2/3		E	0
810168	ABV: CAN-bus system CAN-communication engine erroneous/missing (ID 592) ABV function not restricted check CAN-network, check/replace ABV-control device	A60.X1:1/2/3		E	0
810169	ABV: CAN-bus system CAN-communication E/A-Module erroneous/missing (INS) ABV function not restricted check CAN-network, check/replace ABV-control device	A60.X1:1/2/3		E	0
811001	ABV: control device error or power supply Kl.15/30 excess voltage ABS: inactive check net supply control device	A60.X1:7/9		E	1
811002	ABV: control device error or power supply Kl.15/30 voltage below required value ABS: inactive check net supply control device	A60.X1:7/9		E	1
811010	ABV: control device error or power supply Kl.15/30 defect ABS: inactive, ASR: inactive replace control device	A60.X1:7/9		E	1
811012	ABV: control device error or power supply Kl.15/30 incorrect parameters ABS: inactive, ASR: inactive replace control device	A60.X1:7/9		E	1
811029	ABV: control device error or power supply Kl.15/30 monitor switch time for solenoid valve actuated ABS: inactive, ASR: inactive check solenoid valve, control device	A60.X1:7/9		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
811094	ABV: control device error or power supply Kl.15/30 Wheel speeds/tyre dimensions implausible, incorrect parameterisation ABS: wheel not regulated, ASR: inactive check tires, magnet wheels, sensors	A60.X1:7/9		E	1
811102	ABV: control device error or power supply Kl.15/30 voltage below required value ABS: inactive check net supply control device	A60.X1:7/9		E	1
811103	ABV: control device error or power supply Kl.15/30 interruption ABS: inactive check net supply control device	A60.X1:7/9		E	1
811202	ABV: control device error or power supply Kl.15/30 voltage below required value ABS: inactive check net supply control device	A60.X1:7/9		E	1
811203	ABV: control device error or power supply Kl.15/30 interruption ABS: inactive check net supply control device	A60.X1:7/9		E	1
811602	ABV: control device error, power supply Kl.31 voltage below required value ABS: inactive check net supply control device	A60.X1:10/12		E	1
811609	ABV: control device error, power supply Kl.31 interruption ABS: inactive check net supply control device	A60.X1:10/12		E	1
811702	ABV: control device error, power supply Kl.31 voltage below required value ABS: inactive check net supply control device	A60.X1:10/12		E	1
811709	ABV: control device error, power supply Kl.31 interruption ABS: inactive check net supply control device	A60.X1:10/12		E	1
812004	ABV: output longitudinal lock short circuit to ground check output, output is not connected!	A60		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
812005	ABV: output longitudinal lock short circuit to supply voltage check output, output is not connected!	A60		E	1
812103	ABV: output trailer shut-down interruption check output, output is not connected!	A60		E	1
812104	ABV: output trailer shut-down short circuit to ground check output, output is not connected!	A60		E	1
812105	ABV: output trailer shut-down short circuit to supply voltage check output, output is not connected!	A60		E	1
812112	ABV: output trailer shut-down incorrect parameters check output, output is not connected!, replace control device	A60		E	0
813020	ABV: ABS-solenoid valve front axle right interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3:7/8/9		E	1
813021	ABV: ABS-solenoid valve front axle right short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3:7/8/9		E	1
813022	ABV: ABS-solenoid valve front axle right short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3:7/8/9		E	1
813023	ABV: ABS-solenoid valve front axle right interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3:7/8/9		E	1
813026	ABV: ABS-solenoid valve front axle right interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3:7/8/9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
813027	ABV: ABS-solenoid valve front axle right short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3:7/8/9		E	1
813028	ABV: ABS-solenoid valve front axle right short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3:7/8/9		E	1
813030	ABV: ABS-solenoid valve front axle right external control ABS: front/rear diagonal and differential brakes inactive check cabling, valve (ohm resistance), control device	A60.X3:7/8/9		E	2
813120	ABV: ABS-solenoid valve front axle left interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X2:1/2/3		E	1
813121	ABV: ABS-solenoid valve front axle left short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X2:1/2/3		E	1
813122	ABV: ABS-solenoid valve front axle left short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X2:1/2/3		E	1
813123	ABV: ABS-solenoid valve front axle left interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X2:1/2/3		E	1
813126	ABV: ABS-solenoid valve front axle left interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X2:1/2/3		E	1
813127	ABV: ABS-solenoid valve front axle left short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X2:1/2/3		E	1
813128	ABV: ABS-solenoid valve front axle left short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X2:1/2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
813130	ABV: ABS-solenoid valve front axle left external control ABS: front/rear diagonal and differential brakes inactive check cabling, valve (ohm resistance), control device	A60.X2:1/2/3		E	2
813220	ABV: ABS-solenoid valve rear axle right interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:10/11/12		E	1
813221	ABV: ABS-solenoid valve rear axle right short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:10/11/12		E	1
813222	ABV: ABS-solenoid valve rear axle right short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:10/11/12		E	1
813223	ABV: ABS-solenoid valve rear axle right interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:10/11/12		E	1
813226	ABV: ABS-solenoid valve rear axle right interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:10/11/12		E	1
813227	ABV: ABS-solenoid valve rear axle right short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:10/11/12		E	1
813228	ABV: ABS-solenoid valve rear axle right short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:10/11/12		E	1
813230	ABV: ABS-solenoid valve rear axle right external control ABS: front/rear diagonal and differential brakes inactive check cabling, valve (ohm resistance), control device	A60.X4:10/11/12		E	2
813320	ABV: ABS-solenoid valve rear axle left interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:1/2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
813321	ABV: ABS-solenoid valve rear axle left short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:1/2/3		E	1
813322	ABV: ABS-solenoid valve rear axle left short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:1/2/3		E	1
813323	ABV: ABS-solenoid valve rear axle left interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:1/2/3		E	1
813326	ABV: ABS-solenoid valve rear axle left interruption ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:1/2/3		E	1
813327	ABV: ABS-solenoid valve rear axle left short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:1/2/3		E	1
813328	ABV: ABS-solenoid valve rear axle left short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X4:1/2/3		E	1
813330	ABV: ABS-solenoid valve rear axle left external control ABS: front/rear diagonal and differential brakes inactive check cabling, valve (ohm resistance), control device	A60.X4:1/2/3		E	2
813604	ABV: valve front axle right and rear axle left short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3/.X4		E	1
813605	ABV: valve front axle right and rear axle left short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3/.X4		E	1
813704	ABV: valve front axle left and rear axle right short circuit to ground ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3/X98		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
813705	ABV: valve front axle left and rear axle right short circuit to supply voltage ABS: wheel not regulated check cabling, valve (ohm resistance), control device	A60.X3/X98		E	1
813804	ABV: ASR, DIF-valve short circuit to ground ASR: inactive check cabling, valve (ohm resistance), control device	A60.X4:4/7		E	1
813805	ABV: ASR, DIF-valve short circuit to supply voltage ASR: inactive check cabling, valve (ohm resistance), control device	A60.X4:4/7		E	1
813809	ABV: ASR, DIF-valve interruption ASR: inactive check cabling, valve (ohm resistance), control device	A60.X4:4/7		E	1
813812	ABV: ASR, DIF-valve incorrect parameters ASR: inactive replace control device	A60.X4:4/7		E	0
814040	ABV: speed sensor front axle right interruption ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X3:4/5		E	1
814041	ABV: speed sensor front axle right short circuit to ground ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X3:4/5		E	1
814042	ABV: speed sensor front axle right short circuit to supply voltage ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X3:4/5		E	1
814044	ABV: speed sensor front axle right winding short ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X3:4/5		E	1
814045	ABV: speed sensor front axle right magnet wheel defect ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling, magnet wheel	A60.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
814046	ABV: speed sensor front axle right sensor vibration ABS: partly inactive, ASR: inactive check sensor voltage, Ohm resistance of cabling, magnet wheel	A60.X3:4/5		E	0
814047	ABV: speed sensor front axle right shimmed magnet wheel check magnet wheel for shimmy	A60.X3:4/5		E	0
814048	ABV: speed sensor front axle right Air gap, clearance sensor<>magnet wheel too large ABS: wheel not regulated, ASR: inactive check play in wheel bearing, sensor voltage, ohm resistance of cabling; push sensor on magnet wheel	A60.X3:4/5		E	1
814140	ABV: speed sensor front axle left interruption ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X2:4/5		E	1
814141	ABV: speed sensor front axle left short circuit to ground ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X2:4/5		E	1
814142	ABV: speed sensor front axle left short circuit to supply voltage ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X2:4/5		E	1
814144	ABV: speed sensor front axle left winding short ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X2:4/5		E	1
814145	ABV: speed sensor front axle left magnet wheel defect ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling, magnet wheel	A60.X2:4/5		E	1
814146	ABV: speed sensor front axle left sensor vibration ABS: partly inactive, ASR: inactive check sensor voltage, Ohm resistance of cabling, magnet wheel	A60.X2:4/5		E	0
814147	ABV: speed sensor front axle left shimmed magnet wheel check magnet wheel for shimmy	A60.X2:4/5		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
814148	ABV: speed sensor front axle left Air gap, clearance sensor<>magnet wheel too large ABS: wheel not regulated, ASR: inactive check play in wheel bearing, sensor voltage, ohm resistance of cabling; push sensor on magnet wheel	A60.X2:4/5		E	1
814240	ABV: speed sensor rear axle right interruption ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X4:8/9		E	1
814241	ABV: speed sensor rear axle right short circuit to ground ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X4:8/9		E	1
814242	ABV: speed sensor rear axle right short circuit to supply voltage ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X4:8/9		E	1
814244	ABV: speed sensor rear axle right winding short ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X4:8/9		E	1
814245	ABV: speed sensor rear axle right magnet wheel defect ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling, magnet wheel	A60.X4:8/9		E	1
814246	ABV: speed sensor rear axle right sensor vibration ABS: partly inactive, ASR: inactive check sensor voltage, Ohm resistance of cabling, magnet wheel	A60.X4:8/9		E	0
814247	ABV: speed sensor rear axle right shimmed magnet wheel check magnet wheel for shimmy	A60.X4:8/9		E	0
814248	ABV: speed sensor rear axle right Air gap, clearance sensor<>magnet wheel too large ABS: wheel not regulated, ASR: inactive check play in wheel bearing, sensor voltage, ohm resistance of cabling; push sensor on magnet wheel	A60.X4:8/9		E	1
814340	ABV: speed sensor rear axle left interruption ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X4:5/6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
814341	ABV: speed sensor rear axle left short circuit to ground ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X4:5/6		E	1
814342	ABV: speed sensor rear axle left short circuit to supply voltage ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X4:5/6		E	1
814344	ABV: speed sensor rear axle left winding short ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling	A60.X4:5/6		E	1
814345	ABV: speed sensor rear axle left magnet wheel defect ABS: wheel not regulated, ASR: inactive check sensor voltage, Ohm resistance of cabling, magnet wheel	A60.X4:5/6		E	1
814346	ABV: speed sensor rear axle left sensor vibration ABS: partly inactive, ASR: inactive check sensor voltage, Ohm resistance of cabling, magnet wheel	A60.X4:5/6		E	0
814347	ABV: speed sensor rear axle left shimmed magnet wheel check magnet wheel for shimmy	A60.X4:5/6		E	0
814348	ABV: speed sensor rear axle left Air gap, clearance sensor<>magnet wheel too large ABS: wheel not regulated, ASR: inactive check play in wheel bearing, sensor voltage, ohm resistance of cabling; push sensor on magnet wheel	A60.X4:5/6		E	1
821111	retarder: Output AD1 - re-circulation valve short circuit to ground ECU no longer selects recirculation valve, response time becomes longer RESET - otherwise check cables between ECU and recirculation valve, check recirculation valve (inner resistance)	A62.X1:1		E	1
821112	retarder: Output AD1 - re-circulation valve short circuit to supply voltage ECU no longer selects recirculation valve, response time becomes longer INT OFF/ON - check cables between ECU and recirculation valve, ZF 02	A62.X1:1		E	1
821113	retarder: Output AD1 - re-circulation valve interruption ECU no longer selects recirculation valve, response time becomes longer INT OFF/ON - check cables between ECU and recirculation valve, check recirculation valve (inner resistance)	A62.X1:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
821911	retarder: Output AIP- proportional-flow valve short circuit to ground ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, check proportional valve (inner resistance), ZF 25	A62.X1:4		E	1
821912	retarder: Output AIP- proportional-flow valve short circuit to supply voltage ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, ZF 26	A62.X1:4		E	1
821913	retarder: Output AIP- proportional-flow valve interruption ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, check proportional valve (inner resistance), ZF 27	A62.X1:4		E	1
821914	retarder: Output AIP- proportional-flow valve Resistance incorrect ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, check proportional valve (inner resistance), ZF 28	A62.X1:4		E	1
822111	retarder: Output ADM1 - Dimensions proportional-flow valve short circuit to ground ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, ZF 29	A62.X1:3		E	1
822112	retarder: Output ADM1 - Dimensions proportional-flow valve short circuit to supply voltage ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, check proportional valve (inner resistance), ZF 30	A62.X1:3		E	1
822316	retarder: Amperemeter channel proportional-flow valve Malfunction limit fallen short of ECU switches off the intarder; Intarder no longer available RESET - replace ECU, ZF 39	A62.X1:3/4		E	1
822317	retarder: Amperemeter channel proportional-flow valve Malfunction limit exceeded ECU switches off the intarder; Intarder no longer available RESET - replace ECU, ZF 40	A62.X1:3/4		E	1
823211	retarder: Input ER1 - temperature sensor short circuit to ground ECU limits the braking action to 100 kW INT OFF/ON - check cables between ECU and temperature sensor, temperature sensor (resistance), ZF 38	A62.X1:9		E	1
823213	retarder: Input ER1 - temperature sensor interruption ECU limits the braking action to 100 kW INT OFF/ON - check cables between ECU and temperature sensor, check temperature sensor (resistance), ZF 37	A62.X1:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
823318	retarder: Inputs ED1..ED5 - brake stage switch Check sum / signal(s) implausible ECU reduces the set braking level under certain circumstances INT OFF/ON - check cables between ECU and brake range switch, check brake range switch, ZF 44	A62.X1:15/16/17/42/43		E	1
824319	retarder: CAN transmission malfunction Data transfer faulty/missing, signal error no reaction RESET - check CAN-Bus line, check terminal resistance, ZF 53	A62.X1:22/49/21/48		E	1
824415	retarder: CAN-Bus Data transfer faulty/missing, max. cycle time exceeded ECU switches off the intarder; Intarder no longer available RESET - check CAN-Bus line, ZF 54	A62.X1:22/49/21/48		E	1
824615	retarder: CAN-Bus data transfer Data transfer faulty/missing, max. cycle time exceeded no reaction RESET - check CAN-Bus line, check terminal resistance, ZF 56	A62.X1:22/49/21/48		E	1
825819	retarder: CAN-data transfer ABS/ASR (ID 512) Data transfer faulty/missing, signal error ECU switches off the intarder; Intarder no longer available INT OFF/ON - check ABS-ECU, check CAN-Bus line, check terminal resistance, ZF 74	A62.X1:22/49		E	1
825919	retarder: CAN-data transfer engine (ID 592) Data transfer faulty/missing, signal error ECU limits the braking action to 350 kW INT OFF/ON - check FMR-ECU, check CAN-Bus line, check terminal resistance, ZF 75	A62.X1:22/49		E	1
826119	retarder: CAN-data transfer engine (ID 593) Data transfer faulty/missing, signal error ECU limits the braking action to 350 kW INT OFF/ON - check FMR-ECU, check CAN-Bus line, check terminal resistance, ZF 75	A62.X1:22/49		E	1
826219	retarder: CAN-data transfer gears (ID 556) Data transfer faulty/missing, signal error ECU limits the power to 250 mA, the automatic brake (Bremsomat) is not available INT OFF/ON - check TCU-ECU, check CAN-Bus line, check terminal resistance, ZF 80	A62.X1:22/49		E	1
827113	retarder: Supply VPE1/VPE2 KI.30 interruption no reaction RESET - check supply of ECU (cables), ZF 41	A62.X1:54/55		E	1
827216	retarder: Supply VPI1/VPI2 KI.15 Malfunction limit fallen short of ECU switches off the intarder; Intarder no longer available RESET - check on-board supply voltage (battery, alternator), ZF 43	A62.X1:53/31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
827217	retarder: Supply VPI1/VPI2 Kl.15 Malfunction limit exceeded ECU switches off the intarder; Intarder no longer available RESET - check on-board supply voltage (battery, alternator), ZF 42	A62.X1:53/31		E	1
828218	retarder: Operating hours counter Check sum / signal(s) implausible ECU resets the operating hour counter back to 0 Replace ECU, ZF 46	A62.X1		E	0
828318	retarder: Error memory Check sum / signal(s) implausible ECU rejects the error memory content Replace ECU, ZF 47	A62.X1		E	0
828415	retarder: System error Data transfer faulty/missing, max. cycle time exceeded ECU switches off the intarder; Intarder no longer available Replace ECU, ZF 51	A62.X1		E	1
843300	heating, air cond.: Aux. heater chassis No function, control unit error / heater lock	A130		E	1
843301	heating, air cond.: Aux. heater chassis no start	A130		E	1
843302	heating, air cond.: Aux. heater chassis repeated glow interruption	A130		E	1
843303	heating, air cond.: Aux. heater chassis lack of voltage/excess voltage	A130.X8:12		E	1
843304	heating, air cond.: Aux. heater chassis premature glow identification	A130		E	1
843305	heating, air cond.: Aux. heater chassis Flame sensor/flame monitor interruption / short circuit	A130.X6:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
843306	heating, air cond.: Aux. heater chassis Temperature sensor interruption / short circuit (coolant- for Pro)	A130.X5:1		E	1
843307	heating, air cond.: Aux. heater chassis Metering pump/ solenoid valve interruption / short circuit/ defect	A130.X3:1		E	1
843308	heating, air cond.: Aux. heater chassis blower motor interruption/short circuit/erroneous speed	A130.X1:1		E	1
843309	heating, air cond.: Aux. heater chassis Glow plug interruption / short circuit/ defective (circulation pump Th	A130.X2:1		E	1
843310	heating, air cond.: Aux. heater chassis overheating	A130		E	1
843311	heating, air cond.: Aux. heater chassis Circulation pump interruption / short circuit (ignition spark sensor T	A130.X4.1		E	1
843312	heating, air cond.: Aux. heater chassis Battery disconnect switch short circuit,(heater lock ThermoS)	A130		E	1
843600	heating, air cond.: Aux. heater Superstr. No function, control unit error / heater lock no reaction check fuses, check battery terminals, replace control device	A330		E	1
843601	heating, air cond.: Aux. heater Superstr. no start Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A330		E	1
843602	heating, air cond.: Aux. heater Superstr. repeated glow interruption Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A330		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
843603	heating, air cond.: Aux. heater Superstr. lack of voltage/excess voltage Error message, function of auxiliary heater is problematic check battery, check electrical connections	A330.X8:12		E	1
843604	heating, air cond.: Aux. heater Superstr. premature glow identification Error message, function of auxiliary heater is problematic replace flame detector	A330		E	1
843605	heating, air cond.: Aux. heater Superstr. Flame sensor/flame monitor interruption / short circuit Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace flame detector	A330.X6:1		E	1
843606	heating, air cond.: Aux. heater Superstr. Temperature sensor interruption / short circuit (coolant- for Pro) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace temperature sensor	A330.X5:1		E	1
843607	heating, air cond.: Aux. heater Superstr. Metering pump/ solenoid valve interruption / short circuit/ defect Error message, function of auxiliary heater is problematic check coolant level, bleed coolant circuit, reset temperature limitation, examine cabling	A330.X3:1		E	1
843608	heating, air cond.: Aux. heater Superstr. blower motor interruption/short circuit/erroneous speed Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace combustion air ventilator	A330.X1:1		E	1
843609	heating, air cond.: Aux. heater Superstr. Glow plug interruption / short circuit/ defective (circulation pump Th Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace heater plug	A330.X2:1		E	1
843610	heating, air cond.: Aux. heater Superstr. overheating Error message, function of auxiliary heater is problematic re-fill coolant, press temperature limitation button before switching on, replace temperature limitation	A330		E	1
843611	heating, air cond.: Aux. heater Superstr. Circulation pump interruption / short circuit (ignition spark sensor T Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace water pump	A330.X4.1		E	1
843612	heating, air cond.: Aux. heater Superstr. Battery disconnect switch short circuit,(heater lock ThermoS) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace set value transmitter	A330		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880100	Engine chassis: Control Travel pedal actuated at selected / active engine brake No acceptance of gases at active engine brake Deactivation of engine brake	A700.X2:34/.X2:48		E	1
880101	Engine chassis: Control Travel pedal actuated at support / superstructure operation No acceptance of gases at active support operation Deactivation of support operation	A700.X2:34/.X2:48		E	1
880102	Engine chassis: Control Function "bleeding fuel supply" activated (gas pedal) Breather function of fuel pump and lines to engine on active Engine RPM > 800 1/min or turn ignition off / on	A700.X2:34/.X2:48		B	
880400	Engine chassis: CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded Emerg. op.: Momentum and RPM limitation of engine Check cable / plug / I/O-Module(s)	A700.X2:		E	1
880401	Engine chassis: CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / coupling module	A700.X2:		E	1
880402	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A700.X2:		E	1
880403	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A700.X2:		E	1
880404	Engine chassis: CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A700.X2:		E	1
880405	Engine chassis: CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module1	A700.X2:		E	1
880406	Engine chassis: CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module1	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880407	Engine chassis: CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module2	A700.X2:		E	1
880408	Engine chassis: CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module2	A700.X2:		E	1
880409	Engine chassis: CAN-Data transfer Retarder (ID 772) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / retarder module	A700.X2:		E	1
880410	Engine chassis: CAN-Data transfer WSK (ID 776) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / converter module	A700.X2:		E	1
880411	Engine chassis: CAN-Data transfer Overrun of receiving buffer last received value or replacement value Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700.X2:		E	1
880500	Engine chassis: CAN-engine control unit Time exceeded request global process view internal error, replace control unit	A700.X2:			
880501	Engine chassis: CAN-engine control unit Time exceeded at receipt of complete output data last received value or replacement value Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700.X2:		E	1
880502	Engine chassis: CAN-engine control unit Data communication failed / interrupted (Sending timeout) last received value or replacement value Check cable / plug / CAN-participant	A700.X2:		E	1
880503	Engine chassis: CAN-engine control unit Data communication interrupted (Passive error) last received value or replacement value Check cable / plug / CAN-participant	A700.X2:		E	1
880504	Engine chassis: CAN-engine control unit Data communication interrupted (BusOff) last received value or replacement value Check cable / plug / CAN-participant	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880600	Engine chassis: CAN constr. machinery Time exceeded request global process view Check cable / plug / CAN-participant	A700.X2:		E	1
880601	Engine chassis: CAN constr. machinery Time exceeded at receipt of complete output data Check cable / plug / CAN-participant	A700.X2:		E	1
880602	Engine chassis: CAN constr. machinery Data communication failed / interrupted (Sending timeout) Check cable / plug / CAN-participant	A700.X2:		E	1
880603	Engine chassis: CAN constr. machinery Data communication interrupted (Passive error) Check cable / plug / CAN-participant	A700.X2:		E	1
880604	Engine chassis: CAN constr. machinery Data communication interrupted (BusOff) Check cable / plug / CAN-participant	A700.X2:		E	1
880605	Engine chassis: CAN constr. machinery Data communication malfunctioning (warning) Check cable / plug / CAN-participant	A700.X2:		E	1
880606	Engine chassis: CAN constr. machinery Data communication was malfunctioning (timeout) Check cable / plug / CAN-participant	A700.X2:		E	1
880700	Engine chassis: CAN AMET Time exceeded request global process view Check cable / plug / CAN-participant	A700.X2:		E	1
880701	Engine chassis: CAN AMET Time exceeded at receipt of complete output data Check cable / plug / CAN-participant	A700.X2:		E	1
880702	Engine chassis: CAN AMET Data communication failed / interrupted (Sending timeout) Check cable / plug / CAN-participant	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880703	Engine chassis: CAN AMET Data communication interrupted (Passive error) Check cable / plug / CAN-participant	A700.X2:		E	1
880704	Engine chassis: CAN AMET Data communication interrupted (BusOff) Check cable / plug / CAN-participant	A700.X2:		E	1
880705	Engine chassis: CAN AMET Data communication malfunctioning (warning) Check cable / plug / CAN-participant	A700.X2:		E	1
880706	Engine chassis: CAN AMET Data communication was malfunctioning (timeout) Check cable / plug / CAN-participant	A700.X2:		E	1
880800	Engine chassis: CAN-Data transfer Data communication Tachograph problem Change over to plausible speed source Check cable / plug / tachograph	A700.X2:		E	1
880801	Engine chassis: CAN-Data transfer Data communication TSC1 problem No Check cable / plug / CAN-participant	A700.X2:		E	1
880802	Engine chassis: CAN-Data transfer Data communication failed / interrupted (Sending timeout) Change over to plausible speed source Check cable / plug / CAN-participant	A700.X2:		E	1
880803	Engine chassis: CAN-Data transfer Data communication interrupted (Passive error) Change over to plausible speed source Check cable / plug / CAN-participant	A700.X2:		E	1
880804	Engine chassis: CAN-Data transfer Data communication interrupted (BusOff) Change over to plausible speed source Check cable / plug / CAN-participant	A700.X2:		E	1
880900	Engine chassis: CAN-communication status CAN A - Setting Transfer rate 125 Kbaud possible No	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880901	Engine chassis: CAN-communication status CAN A - Setting Transfer rate 250 KBaud possible No	A700.X2:		E	1
880902	Engine chassis: CAN-communication status CAN A - Setting Transfer rate 500 KBaud possible No	A700.X2:		E	1
880903	Engine chassis: CAN-communication status CAN A - Setting Transfer rate 1 MBaud possible No	A700.X2:		E	1
880904	Engine chassis: CAN-communication status CAN B - Setting Transfer rate 125 KBaud possible No	A700.X2:		E	1
880905	Engine chassis: CAN-communication status CAN B - Setting Transfer rate 250 KBaud possible No	A700.X2:		E	1
880906	Engine chassis: CAN-communication status CAN B - Setting Transfer rate 500 KBaud possible No	A700.X2:		E	1
880907	Engine chassis: CAN-communication status CAN B - Setting Transfer rate 1 MBaud possible No	A700.X2:		E	1
880908	Engine chassis: CAN-communication status CAN-connection after problem new synchronized No	A700.X2:		E	1
880909	Engine chassis: CAN-communication status Transfer error stored on CAN No	A700.X2:		E	1
880910	Engine chassis: CAN-communication status CAN-transfer rate not recognized / is detected No	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880911	Engine chassis: CAN-communication status CAN-transfer rate not recognized / is detected No	A700.X2:		E	1
880912	Engine chassis: CAN-communication status CAN-transfer rate not recognized / is detected	A700.X2:		E	1
881000	Engine chassis: Internal error Stack-overflow Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881001	Engine chassis: Internal error Exception Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881002	Engine chassis: Internal error Program test Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881003	Engine chassis: Internal error RAM-Test Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881004	Engine chassis: Internal error Overflow in error stack No Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	0
881005	Engine chassis: Internal error Comp. time error No Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881006	Engine chassis: Internal error Error-Index too large The error cannot be shown Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	0
881100	Engine chassis: Memory error EEPROM Error at EEPROM-access Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
881101	Engine chassis: Memory error EEPROM Check sum via parameter memory is erroneous Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	2
881102	Engine chassis: Memory error EEPROM Parameter memory in EEPROM is invalid Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	2
881103	Engine chassis: Memory error EEPROM Check sum via ECU-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881104	Engine chassis: Memory error EEPROM Check sum via NMI-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881105	Engine chassis: Memory error EEPROM Check sum via Work data-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881106	Engine chassis: Memory error EEPROM Check sum via load collective is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881107	Engine chassis: Memory error EEPROM Structure size of load collective has changed No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881108	Engine chassis: Memory error EEPROM EEPROM has insufficient memory for load collective free No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881109	Engine chassis: Memory error EEPROM Check sum via permanent data is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881200	Engine chassis: Power supply Supply voltage too low Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug).	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
881201	Engine chassis: Power supply Supply voltage too high Engine cannot be started or engine shut off; only communication with diagnostics tool Check power supply (battery, alternator, wiring, plug)	A700.X2:		E	1
881202	Engine chassis: Power supply Digital output short circuit after supply voltage Engine shut off; only communication with diagnostics tool Wiring, check engine control unit; replace engine control unit if nec.	A700.X2:		E	1
881203	Engine chassis: Power supply Error at release of power outputs Engine shut off; shut off of all digital outlets Wiring, check engine control unit; replace engine control unit if nec.	A700.X2:		E	1
881204	Engine chassis: Power supply Current supply PS1 erroneous/missing Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A700.X2:		E	1
881205	Engine chassis: Power supply Error on 12V-Reference: Voltage too low (<10V) Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A700.X2:		E	1
881206	Engine chassis: Power supply Error on 12V-Reference: Voltage too high (>14V) Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A700.X2:		E	1
881500	Engine chassis: Configuration error Fan control The fan control is deactivated. Resulting in maximum vent position New data set, or replace engine control unit	A700		E	1
881501	Engine chassis: Configuration error Full load curve (incorrect Offset) The matching of the performance curve is internally limited New data set, or replace engine control unit	A700		E	1
881502	Engine chassis: Configuration error Monitoring Travel pedal Pedal unit is not monitored New data set, or replace engine control unit	A700		E	1
881503	Engine chassis: Configuration error Incorrect pump code Injector class 3 is used as replacement value Check pump coding and change (via diagnostics or corr. diagnostics tool)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
881504	Engine chassis: Configuration error Assignment error at high pressure sensors Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A700		E	1
881505	Engine chassis: Configuration error No high pressure pump active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A700		E	1
881506	Engine chassis: Configuration error Current output for high pressure pump 1 not active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A700		E	1
881507	Engine chassis: Configuration error Current output for high pressure pump 2 not active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A700		E	1
881800	Engine chassis: Active engine protection functions Excess temperature on exhaust turbine Power reduction 304700: WG/EGR-controller, check load pressure sensor	A700		E	1
881900	Engine chassis: Speed recording Maximum difference travel speed Tacho<->Gear exceeded The larger speed value is used Check Wiring engine control unit to speed sensor or check speed sensor.	A700		E	1
882000	Engine chassis: Alternator Undervoltage at engine start No Check wiring engine control unit to alternator and alternator.	A700.X2:		E	1
882001	Engine chassis: Alternator Undervoltage at engine on No Check wiring engine control unit to alternator and alternator.	A700.X2:		E	1
882002	Engine chassis: Alternator Undervoltage at engine on No Check wiring engine control unit to alternator and alternator.	A700.X2:		E	1
882003	Engine chassis: Alternator Overvoltage at engine on No Check wiring engine control unit to alternator and alternator.	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
882004	Engine chassis: Alternator Voltage deviation to supply voltage too low No Check wiring engine control unit to alternator and alternator.	A700.X2:		E	1
882005	Engine chassis: Alternator Voltage deviation to supply voltage too high No Check wiring engine control unit to alternator and alternator.	A700.X2:		E	1
882100	Engine chassis: Travel pedal No gas switch erroneous Use low value Check wiring engine control unit to travel pedal. Check travel pedal / replace	A700		E	1
882101	Engine chassis: Travel pedal maximum signal difference channel 1 and 2 exceeded Use low value Check wiring engine control unit to travel pedal. Check travel pedal / replace	A700		E	1
882800	Engine chassis: Exhaust return (AGR2) Short circuit after ground or broken wire External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882801	Engine chassis: Exhaust return (AGR2) short circuit to supply voltage External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882802	Engine chassis: Exhaust return (AGR2) Hardware error (Transistor defective) External AGR2 is not actuated Check engine control unit	A700.X1:		E	1
882803	Engine chassis: Exhaust return (AGR2) Rule deviation negative External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882804	Engine chassis: Exhaust return (AGR2) Rule deviation positive External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882805	Engine chassis: Exhaust return (AGR2) Logic threshold breach in shut off condition External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
882806	Engine chassis: Exhaust return (AGR2) Logic threshold breach (Current less than perm. minimum value) External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882807	Engine chassis: Exhaust return (AGR2) Logic threshold breach (Current more than perm. maximum value) External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882811	Engine chassis: Exhaust return (AGR2) open without actuation External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882812	Engine chassis: Exhaust return (AGR2) closed despite actuation External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882900	Engine chassis: Air flap Short circuit after ground or broken wire Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882901	Engine chassis: Air flap short circuit to supply voltage Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882902	Engine chassis: Air flap Hardware error (Transistor defective) Air vent is not actuated Check engine control unit	A700.X2:12/13		E	1
882903	Engine chassis: Air flap Rule deviation negative Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882904	Engine chassis: Air flap Rule deviation positive Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882905	Engine chassis: Air flap Logic threshold breach in shut off condition Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
882906	Engine chassis: Air flap Logic threshold breach (Current less than perm. minimum value) Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882907	Engine chassis: Air flap Logic threshold breach (Current more than perm. maximum value) Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882908	Engine chassis: Air flap Over current LowSide Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882909	Engine chassis: Air flap Over current HighSide Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882910	Engine chassis: Air flap PWM on maximum Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
883003	Engine chassis: High pressure pump 1 Rule deviation negative Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883004	Engine chassis: High pressure pump 1 Rule deviation positive Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883005	Engine chassis: High pressure pump 1 Current to high in shut off condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883006	Engine chassis: High pressure pump 1 Current to low in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883007	Engine chassis: High pressure pump 1 Current to high in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883008	Engine chassis: High pressure pump 1 UeberCurrent LowSide (ground switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883009	Engine chassis: High pressure pump 1 UeberCurrent HighSide (Plus-switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883010	Engine chassis: High pressure pump 1 PWM on maximum Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883103	Engine chassis: High pressure pump 2 Rule deviation negative Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883104	Engine chassis: High pressure pump 2 Rule deviation positive Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883105	Engine chassis: High pressure pump 2 Current to high in shut off condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883106	Engine chassis: High pressure pump 2 Current to low in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883107	Engine chassis: High pressure pump 2 Current to high in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883108	Engine chassis: High pressure pump 2 UeberCurrent LowSide (ground switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883109	Engine chassis: High pressure pump 2 UeberCurrent HighSide (Plus-switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883110	Engine chassis: High pressure pump 2 PWM on maximum Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883200	Engine chassis: Starter short circuit to ground Engine start not possible Check cable harness / plug / Starter / engine control unit	A700.X1:29		E	1
883201	Engine chassis: Starter short circuit to supply voltage Engine start not possible Check cable harness / plug / Starter / engine control unit	A700.X1:29		E	1
883300	Engine chassis: Fan control Short circuit after ground or broken wire The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883301	Engine chassis: Fan control short circuit to supply voltage The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883302	Engine chassis: Fan control Hardware error (Transistor defective) The fan control is deactivated. Resulting in maximum vent position Check engine control unit	A700.X2:26/27		E	1
883303	Engine chassis: Fan control Rule deviation negative The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883304	Engine chassis: Fan control Rule deviation positive The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883305	Engine chassis: Fan control Logic threshold breach in shut off condition The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883306	Engine chassis: Fan control Logic threshold breach (Current less than perm. minimum value) The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883307	Engine chassis: Fan control Logic threshold breach (Current more than perm. maximum value) The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883400	Engine chassis: Engine brake Short circuit after ground or broken wire Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883401	Engine chassis: Engine brake short circuit to supply voltage Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883402	Engine chassis: Engine brake Hardware error (Transistor defective) Engine brake flap is not actuated Check engine control unit	A700.X2:11		E	1
883403	Engine chassis: Engine brake Rule deviation negative Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883404	Engine chassis: Engine brake Rule deviation positive Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883405	Engine chassis: Engine brake Logic threshold breach in shut off condition Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883406	Engine chassis: Engine brake Logic threshold breach (Current less than perm. minimum value) Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883407	Engine chassis: Engine brake Logic threshold breach (Current more than perm. maximum value) Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883500	Engine chassis: Heater flange unit 1 Short circuit after ground or broken wire Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883501	Engine chassis: Heater flange unit 1 short circuit to supply voltage Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883502	Engine chassis: Heater flange unit 1 Hardware error (Transistor defective) Failure of pre- and afterheat phase Check engine control unit	A700.X2:39/64		E	1
883503	Engine chassis: Heater flange unit 1 Rule deviation negative Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883504	Engine chassis: Heater flange unit 1 Rule deviation positive Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883505	Engine chassis: Heater flange unit 1 Logic threshold breach in shut off condition Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883506	Engine chassis: Heater flange unit 1 Logic threshold breach (Current less than perm. minimum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883507	Engine chassis: Heater flange unit 1 Logic threshold breach (Current more than perm. maximum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883511	Engine chassis: Heater flange unit 1 No voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883512	Engine chassis: Heater flange unit 1 Voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883600	Engine chassis: Heater flange unit 2 Short circuit after ground or broken wire Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883601	Engine chassis: Heater flange unit 2 short circuit to supply voltage Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883602	Engine chassis: Heater flange unit 2 Hardware error (Transistor defective) Failure of pre- and afterheat phase Check engine control unit	A700.X2:25/65		E	1
883603	Engine chassis: Heater flange unit 2 Rule deviation negative Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883604	Engine chassis: Heater flange unit 2 Rule deviation positive Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883605	Engine chassis: Heater flange unit 2 Logic threshold breach in shut off condition Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883606	Engine chassis: Heater flange unit 2 Logic threshold breach (Current less than perm. minimum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883607	Engine chassis: Heater flange unit 2 Logic threshold breach (Current more than perm. maximum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883611	Engine chassis: Heater flange unit 2 No voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883612	Engine chassis: Heater flange unit 2 Voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883700	Engine chassis: Solenoid valves Short circuit after ground or broken wire Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883701	Engine chassis: Solenoid valves short circuit to supply voltage Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883702	Engine chassis: Solenoid valves Hardware error (Transistor defective) Failure of after heat phase Check engine control unit	A700.X2:25/65		E	1
883703	Engine chassis: Solenoid valves Rule deviation negative Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883704	Engine chassis: Solenoid valves Rule deviation positive Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883705	Engine chassis: Solenoid valves Logic threshold breach in shut off condition Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883706	Engine chassis: Solenoid valves Logic threshold breach (Current less than perm. minimum value) Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883707	Engine chassis: Solenoid valves Logic threshold breach (Current more than perm. maximum value) Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883800	Engine chassis: Turbo charger Short circuit after ground or broken wire Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883801	Engine chassis: Turbo charger short circuit to supply voltage Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883802	Engine chassis: Turbo charger Hardware error (Transistor defective) Turbocharger is not actuated Check engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883803	Engine chassis: Turbo charger Rule deviation negative Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883804	Engine chassis: Turbo charger Rule deviation positive Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883805	Engine chassis: Turbo charger Logic threshold breach in shut off condition Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883806	Engine chassis: Turbo charger Logic threshold breach (Current less than perm. minimum value) Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883807	Engine chassis: Turbo charger Logic threshold breach (Current more than perm. maximum value) Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883900	Engine chassis: Exhaust return (AGR) Short circuit after ground or broken wire External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883901	Engine chassis: Exhaust return (AGR) short circuit to supply voltage External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883902	Engine chassis: Exhaust return (AGR) Hardware error (Transistor defective) External AGR is not actuated Check engine control unit	A700.X1:		E	1
883903	Engine chassis: Exhaust return (AGR) Rule deviation negative External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883904	Engine chassis: Exhaust return (AGR) Rule deviation positive External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883905	Engine chassis: Exhaust return (AGR) Logic threshold breach (Current higher than perm. min. value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883906	Engine chassis: Exhaust return (AGR) Logic threshold breach (Current less than perm. minimum value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883907	Engine chassis: Exhaust return (AGR) Logic threshold breach (Current more than perm. maximum value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883911	Engine chassis: Exhaust return (AGR) open without actuation External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883912	Engine chassis: Exhaust return (AGR) closed despite actuation External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
884000	Engine chassis: Emerg. Op. indicator Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A700.X2:42		E	1
884001	Engine chassis: Emerg. Op. indicator short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A700.X2:42		E	1
884002	Engine chassis: Emerg. Op. indicator Hardware error (Transistor defective) None Check engine control unit	A700.X2:42		E	1
884100	Engine chassis: Indicator light preglow / start readiness Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A700.X2:28		E	1
884101	Engine chassis: Indicator light preglow / start readiness short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A700.X2:28		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
884102	Engine chassis: Indicator light preglow / start readiness Hardware error (Transistor defective) None Check engine control unit	A700.X2:28		E	1
884200	Engine chassis: Charge indicator Alternator Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A700.X2:14		E	1
884201	Engine chassis: Charge indicator Alternator short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A700.X2:14		E	1
884202	Engine chassis: Charge indicator Alternator Hardware error (Transistor defective) None Check engine control unit	A700.X2:14		E	1
884300	Engine chassis: fan control 1 (reversible) Short circuit after ground or broken wire	A700.X2:26/27		E	1
884301	Engine chassis: fan control 1 (reversible) short circuit to supply voltage	A700.X2:26/27		E	1
884302	Engine chassis: fan control 1 (reversible) Hardware error (Transistor defective)	A700.X2:26/27		E	1
884303	Engine chassis: fan control 1 (reversible) Rule deviation negative	A700.X2:26/27		E	1
884304	Engine chassis: fan control 1 (reversible) Rule deviation positive	A700.X2:26/27		E	1
884305	Engine chassis: fan control 1 (reversible) Logic threshold breach in shut off condition	A700.X2:26/27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
884306	Engine chassis: fan control 1 (reversible) Logic threshold breach (Current less than perm. minimum value)	A700.X2:26/27		E	1
884307	Engine chassis: fan control 1 (reversible) Logic threshold breach (Current more than perm. maximum value)	A700.X2:26/27		E	1
884400	Engine chassis: fan control 2 (reversible) Short circuit after ground or broken wire	A700.X2:26/27		E	1
884401	Engine chassis: fan control 2 (reversible) short circuit to supply voltage	A700.X2:26/27		E	1
884402	Engine chassis: fan control 2 (reversible) Hardware error (Transistor defective)	A700.X2:26/27		E	1
884403	Engine chassis: fan control 2 (reversible) Rule deviation negative	A700.X2:26/27		E	1
884404	Engine chassis: fan control 2 (reversible) Rule deviation positive	A700.X2:26/27		E	1
884405	Engine chassis: fan control 2 (reversible) Logic threshold breach in shut off condition	A700.X2:26/27		E	1
884406	Engine chassis: fan control 2 (reversible) Logic threshold breach (Current less than perm. minimum value)	A700.X2:26/27		E	1
884407	Engine chassis: fan control 2 (reversible) Logic threshold breach (Current more than perm. maximum value)	A700.X2:26/27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
884500	Engine chassis: Rail pressure system Pressure relief valve 1 open High pressure regulation emergency operation activated Test Rail circuit 1	A700		E	1
884501	Engine chassis: Rail pressure system Pressure relief valve 2 open High pressure regulation emergency operation activated Test Rail circuit 2	A700		E	1
884502	Engine chassis: Rail pressure system Emergency operation high pressure regulation active Power reduction, high pressure pump control turned off Test Rail circuit 1/2 / wiring harness / plug	A700		E	1
884503	Engine chassis: Rail pressure system Pressure difference between high pressure sensor 1 and 2 No reaction on engine, the higher sensor value is used Test wiring harness/ plug / rail pressure sensors / rail circuit 1/2	A700		E	1
884504	Engine chassis: Rail pressure system Regulation deviation in CR-regulating circuit 1 None Test Rail circuit 1	A700		E	1
884505	Engine chassis: Rail pressure system Regulation deviation in CR-regulating circuit 2 None Test Rail circuit 2	A700		E	1
884700	Engine chassis: Error on air path components Maximum charge pressure exceeded (P3-protection) Power reduction 301800:Check intake system for leaks	A700		E	1
884900	Engine chassis: RPM signal output Short circuit after ground or broken wire No Check wiring harness / plug / connected modules	A700		E	1
884901	Engine chassis: RPM signal output short circuit to supply voltage No Check wiring harness / plug / connected modules	A700		E	1
885000	Engine chassis: Cylinder A1 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885001	Engine chassis: Cylinder A1 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	2
885002	Engine chassis: Cylinder A1 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	2
885003	Engine chassis: Cylinder A1 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	2
885005	Engine chassis: Cylinder A1 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	
885006	Engine chassis: Cylinder A1 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	0
885007	Engine chassis: Cylinder A1 No increase time measured No Replace engine control unit	A700.X1:22/8		E	2
885008	Engine chassis: Cylinder A1 Increase time too large No New data set, or replace engine control unit	A700.X1:22/8		E	
885100	Engine chassis: Cylinder A2 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	2
885101	Engine chassis: Cylinder A2 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	2
885102	Engine chassis: Cylinder A2 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885103	Engine chassis: Cylinder A2 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	2
885104	Engine chassis: Cylinder A2 No fly time measured No Replace engine control unit	A700.X1:21/7		E	2
885105	Engine chassis: Cylinder A2 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	
885106	Engine chassis: Cylinder A2 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	0
885107	Engine chassis: Cylinder A2 No increase time measured No Replace engine control unit	A700.X1:21/7		E	2
885108	Engine chassis: Cylinder A2 Increase time too large No New data set, or replace engine control unit	A700.X1:21/7		E	
885200	Engine chassis: Cylinder A3 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2
885201	Engine chassis: Cylinder A3 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2
885202	Engine chassis: Cylinder A3 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2
885203	Engine chassis: Cylinder A3 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885204	Engine chassis: Cylinder A3 No fly time measured No Replace engine control unit	A700.X1:20/6		E	2
885205	Engine chassis: Cylinder A3 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	
885206	Engine chassis: Cylinder A3 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	0
885207	Engine chassis: Cylinder A3 No increase time measured No Replace engine control unit	A700.X1:20/6		E	2
885208	Engine chassis: Cylinder A3 Increase time too large No New data set, or replace engine control unit	A700.X1:20/6		E	
885300	Engine chassis: Cylinder A4 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	2
885301	Engine chassis: Cylinder A4 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	2
885302	Engine chassis: Cylinder A4 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	2
885303	Engine chassis: Cylinder A4 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	2
885304	Engine chassis: Cylinder A4 No fly time measured No Replace engine control unit	A700.X1:19/5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885305	Engine chassis: Cylinder A4 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	
885306	Engine chassis: Cylinder A4 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	0
885307	Engine chassis: Cylinder A4 No increase time measured No Replace engine control unit	A700.X1:19/5		E	2
885308	Engine chassis: Cylinder A4 Increase time too large No New data set, or replace engine control unit	A700.X1:19/5		E	
885800	Engine chassis: Cylinder B1 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	2
885801	Engine chassis: Cylinder B1 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	2
885802	Engine chassis: Cylinder B1 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	2
885803	Engine chassis: Cylinder B1 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	2
885804	Engine chassis: Cylinder B1 No fly time measured No Replace engine control unit	A700.X1:18/4		E	2
885805	Engine chassis: Cylinder B1 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885806	Engine chassis: Cylinder B1 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	0
885807	Engine chassis: Cylinder B1 No increase time measured No Replace engine control unit	A700.X1:18/4		E	2
885808	Engine chassis: Cylinder B1 Increase time too large No New data set, or replace engine control unit	A700.X1:18/4		E	
885900	Engine chassis: Cylinder B2 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	2
885901	Engine chassis: Cylinder B2 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	2
885902	Engine chassis: Cylinder B2 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	2
885903	Engine chassis: Cylinder B2 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	2
885904	Engine chassis: Cylinder B2 No fly time measured No Replace engine control unit	A700.X1:17/3		E	2
885905	Engine chassis: Cylinder B2 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	
885906	Engine chassis: Cylinder B2 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885907	Engine chassis: Cylinder B2 No increase time measured No Replace engine control unit	A700.X1:17/3		E	2
885908	Engine chassis: Cylinder B2 Increase time too large No New data set, or replace engine control unit	A700.X1:17/3		E	
886000	Engine chassis: Cylinder B3 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	2
886001	Engine chassis: Cylinder B3 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	2
886002	Engine chassis: Cylinder B3 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	2
886003	Engine chassis: Cylinder B3 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	2
886004	Engine chassis: Cylinder B3 No fly time measured No Replace engine control unit	A700.X1:16/2		E	2
886005	Engine chassis: Cylinder B3 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	
886006	Engine chassis: Cylinder B3 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	0
886007	Engine chassis: Cylinder B3 No increase time measured No Replace engine control unit	A700.X1:16/2		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
886008	Engine chassis: Cylinder B3 Increase time too large No New data set, or replace engine control unit	A700.X1:16/2		E	
886100	Engine chassis: Cylinder B4 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	2
886101	Engine chassis: Cylinder B4 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	2
886102	Engine chassis: Cylinder B4 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	2
886103	Engine chassis: Cylinder B4 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	2
886104	Engine chassis: Cylinder B4 No fly time measured No Replace engine control unit	A700.X1:15/1		E	2
886105	Engine chassis: Cylinder B4 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	
886106	Engine chassis: Cylinder B4 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	0
886107	Engine chassis: Cylinder B4 No increase time measured No Replace engine control unit	A700.X1:15/1		E	2
886108	Engine chassis: Cylinder B4 Increase time too large No New data set, or replace engine control unit	A700.X1:15/1		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
886900	Engine chassis: Injection system Cylinder error Engine shut off Check cable / plug / solenoid valve / engine control unit	A700		E	2
886901	Engine chassis: Injection system Overlap of injection on bank A Engine shut off New data set, or replace engine control unit	A700		E	2
886902	Engine chassis: Injection system Overlap of injection on bank B Engine shut off New data set, or replace engine control unit	A700		E	2
886903	Engine chassis: Injection system Short circuit Plus switch after ground on bank A No Check cable / plug / solenoid valve / engine control unit	A700		E	2
886904	Engine chassis: Injection system Short circuit Plus switch after ground on bank B No Check cable / plug / solenoid valve / engine control unit	A700		E	2
886905	Engine chassis: Injection system Short circuit Plus switch after supply voltage on bank A No Check cable / plug / solenoid valve / engine control unit	A700		E	2
886906	Engine chassis: Injection system Short circuit Plus switch after supply voltage on bank B No Check cable / plug / solenoid valve / engine control unit	A700		E	2
886907	Engine chassis: Injection system Short circuit Ground switch after ground on bank A at CR-Motor occurs shut off of bank A Check cable / plug / solenoid valve / engine control unit	A700		E	2
886908	Engine chassis: Injection system Short circuit Ground switch after ground on bank B at CR-Motor occurs shut off of bank B Check cable / plug / solenoid valve / engine control unit	A700		E	2
886909	Engine chassis: Injection system Short circuit Ground switch after supply voltage on bank A No Check cable / plug / solenoid valve / engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
886910	Engine chassis: Injection system Short circuit Ground switch after supply voltage on bank B No Check cable / plug / solenoid valve / engine control unit	A700		E	2
887000	Engine chassis: Overspeed RPM sensor 1 Warning threshold exceeded None Check engine op. (excess. speed due to push op.); engine control unit	A700		E	1
887001	Engine chassis: Overspeed RPM sensor 2 Warning threshold exceeded None Check engine op. (excess. speed due to push op.); engine control unit	A700		E	1
887002	Engine chassis: Overspeed RPM sensor 1 Safety threshold exceeded Engine shut off Check engine op. (excess. speed due to push op.); engine control unit	A700		E	1
887003	Engine chassis: Overspeed RPM sensor 2 Safety threshold exceeded Engine shut off Check engine op. (excess. speed due to push op.); engine control unit	A700		E	1
887100	Engine chassis: Synchronization defective Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1
887101	Engine chassis: Synchronization incorrect distance gap<>Phase sensor Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1
887102	Engine chassis: Synchronization Tooth number not correct Engine start not possible Turn ign. on / off; check RPM sensor	A700		E	1
887103	Engine chassis: Synchronization not possible, RPM is too low Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1
887104	Engine chassis: Synchronization Index counter camshaft gear erroneous Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887200	Engine chassis: RPM sensor 1 failed Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A700.X1:69/55/41		E	1
887201	Engine chassis: RPM sensor 1 does not start Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A700.X1:69/55/41		E	1
887202	Engine chassis: RPM sensor 1 impermissible signal difference (Gradient breach) Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A700.X1:69/55/41		E	1
887203	Engine chassis: RPM sensor 1 Frequency too high Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A700.X1:69/55/41		E	1
887204	Engine chassis: RPM sensor 1 poled Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Check RPM sensor inst., engine control unit.	A700.X1:69/55/41		E	1
887205	Engine chassis: RPM sensor 1 Value implausible/erroneous Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Check RPM sensor inst., engine control unit.	A700.X1:69/55/41		E	1
887300	Engine chassis: RPM sensor 2 failed Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A700.X1:68/54/40		E	1
887302	Engine chassis: RPM sensor 2 impermissible signal difference (Gradient breach) Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A700.X1:68/54/40		E	1
887303	Engine chassis: RPM sensor 2 Frequency too high Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A700.X1:68/54/40		E	1
887304	Engine chassis: RPM sensor 2 poled Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Check RPM sensor inst., engine control unit.	A700.X1:68/54/40		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887305	Engine chassis: RPM sensor 2 Value implausible/erroneous Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Check RPM sensor inst., engine control unit.	A700.X1:68/54/40		E	1
887400	Engine chassis: Sensor Position camshaft failed Engine start, dep. on configuration, not possible. No effect with engine running Check distance of phase sensor to camshaft gear (0.5-2.0 mm); wiring to phase sensor, phase sensor	A700.X1:70/56/42		E	1
887404	Engine chassis: Sensor Position camshaft poled Engine start, dep. on configuration, not possible. No effect with engine running Check: Phase sensor installation, engine control unit	A700.X1:70/56/42		E	1
887405	Engine chassis: Sensor Position camshaft Value implausible/erroneous Emergency shut off at simultaneous failure of redundant sensor (1 or 2). Otherwise RPM reg. via red. sensor Check: Phase sensor installation, engine control unit	A700.X1:70/56/42		E	1
887500	Engine chassis: Travel pedal channel 1 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X2:33/34/35		E	1
887501	Engine chassis: Travel pedal channel 1 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:33/34/35		E	1
887502	Engine chassis: Travel pedal channel 1 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:33/34/35		E	1
887503	Engine chassis: Travel pedal channel 1 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:33/34/35		E	1
887504	Engine chassis: Travel pedal channel 1 Signal outside permissible range (Limit 1) remains in low idle when both travel pedal sensors have failed Check travel pedal sensor 1 for operating range injury. Fix possible mechanical problem	A700.X2:33/34/35		E	1
887505	Engine chassis: Travel pedal channel 1 Signal outside permissible range (Limit 2) remains in low idle when both travel pedal sensors have failed Check travel pedal sensor 1 for operating range injury. Fix possible mechanical problem	A700.X2:33/34/35		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887506	Engine chassis: Travel pedal channel 1 signal implausible Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A700.X2:33/34/35		E	1
887600	Engine chassis: Travel pedal channel 2 Short circuit after ground or line interruption Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A700.X2:47/48/49		E	1
887602	Engine chassis: Travel pedal channel 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:47/48/49		E	1
887603	Engine chassis: Travel pedal channel 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:47/48/49		E	1
887604	Engine chassis: Travel pedal channel 2 Signal outside permissible range (Limit 1) remains in low idle when both travel pedal sensors have failed Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A700.X2:47/48/49		E	1
887605	Engine chassis: Travel pedal channel 2 Signal outside permissible range (Limit 2) remains in low idle when both travel pedal sensors have failed Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A700.X2:47/48/49		E	1
887606	Engine chassis: Travel pedal channel 2 signal implausible Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A700.X2:47/48/49		E	1
887700	Engine chassis: Sensor coolant level Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X2:19/20/21		E	2
887701	Engine chassis: Sensor coolant level short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:19/20/21		E	2
887702	Engine chassis: Sensor coolant level Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:19/20/21		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887703	Engine chassis: Sensor coolant level Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:19/20/21		E	2
887704	Engine chassis: Sensor coolant level Signal outside permissible range (Limit 1) no reaction Check coolant level for operating range injury. Fix possible mechanical problem	A700.X2:19/20/21		E	0
887705	Engine chassis: Sensor coolant level Signal outside permissible range (Limit 2) no reaction Check coolant level for operating range injury. Fix possible mechanical problem	A700.X2:19/20/21		E	0
887706	Engine chassis: Sensor coolant level signal implausible Check sensor, wiring, input on control unit	A700.X2:19/20/21		E	2
887800	Engine chassis: Sensor oil level Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700		E	1
887801	Engine chassis: Sensor oil level short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
887802	Engine chassis: Sensor oil level Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
887803	Engine chassis: Sensor oil level Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
887804	Engine chassis: Sensor oil level Signal outside permissible range (Limit 1) no reaction Check oil level for operating range injury. Fix possible mechanical problem	A700		E	1
887805	Engine chassis: Sensor oil level Signal outside permissible range (Limit 2) no reaction Check oil level for operating range injury. Fix possible mechanical problem	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887806	Engine chassis: Sensor oil level signal implausible Check sensor, wiring, input on control unit	A700		E	1
888300	Engine chassis: Sensor air filter contamination 2 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:30/44/58		E	1
888301	Engine chassis: Sensor air filter contamination 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:30/44/58		E	1
888302	Engine chassis: Sensor air filter contamination 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:30/44/58		E	1
888303	Engine chassis: Sensor air filter contamination 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:30/44/58		E	1
888304	Engine chassis: Sensor air filter contamination 2 Signal outside permissible range (Limit 1) no reaction Check air filter pressure sensor 1 for operating range injury. Fix possible mechanical problem	A700.X1:30/44/58		E	0
888305	Engine chassis: Sensor air filter contamination 2 Signal outside permissible range (Limit 2) no reaction Check air filter pressure sensor 1 for operating range injury. Fix possible mechanical problem	A700.X1:30/44/58		E	0
888306	Engine chassis: Sensor air filter contamination 2 signal implausible Check sensor, wiring, input on control unit	A700.X1:30/44/58		E	1
888400	Engine chassis: Sensor charge air pr, Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:61/47/33		E	1
888401	Engine chassis: Sensor charge air pr, short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:61/47/33		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888402	Engine chassis: Sensor charge air pr, Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:61/47/33		E	1
888403	Engine chassis: Sensor charge air pr, Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:61/47/33		E	1
888404	Engine chassis: Sensor charge air pr, Signal outside permissible range (Limit 1) no reaction Check charge air pressure sensor 2 for operating range injury. Fix possible mechanical problem	A700.X1:61/47/33		E	1
888405	Engine chassis: Sensor charge air pr, Signal outside permissible range (Limit 2) no reaction Check charge air pressure sensor 2 for operating range injury. Fix possible mechanical problem	A700.X1:61/47/33		E	1
888406	Engine chassis: Sensor charge air pr, signal implausible Check sensor, wiring, input on control unit	A700.X1:61/47/33		E	1
888500	Engine chassis: Sensor oil pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:63/49/35		E	2
888501	Engine chassis: Sensor oil pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:63/49/35		E	2
888502	Engine chassis: Sensor oil pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:63/49/35		E	2
888503	Engine chassis: Sensor oil pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:63/49/35		E	2
888504	Engine chassis: Sensor oil pr. Signal outside permissible range (Limit 1) no reaction Check oil pressure for operating range injury. Fix possible mechanical problem	A700.X1:63/49/35		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888505	Engine chassis: Sensor oil pr. Signal outside permissible range (Limit 2) no reaction Check oil pressure for operating range injury. Fix possible mechanical problem	A700.X1:63/49/35		E	0
888506	Engine chassis: Sensor oil pr. signal implausible Check sensor, wiring, input on control unit	A700.X1:63/49/35		E	2
888600	Engine chassis: Sensor fuel pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:62/48/34		E	1
888601	Engine chassis: Sensor fuel pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:62/48/34		E	1
888602	Engine chassis: Sensor fuel pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:62/48/34		E	1
888603	Engine chassis: Sensor fuel pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:62/48/34		E	1
888604	Engine chassis: Sensor fuel pr. Signal outside permissible range (Limit 1) no reaction Check medium for fuel pressure injury. Fix possible mechanical problem	A700.X1:62/48/34		E	1
888605	Engine chassis: Sensor fuel pr. Signal outside permissible range (Limit 2) no reaction Check medium for fuel pressure injury. Fix possible mechanical problem	A700.X1:62/48/34		E	1
888606	Engine chassis: Sensor fuel pr. signal implausible Check sensor, wiring, input on control unit	A700.X1:62/48/34		E	1
888700	Engine chassis: Sensor Air filter contamination Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X2:5/6/7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888701	Engine chassis: Sensor Air filter contamination short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:5/6/7		E	1
888702	Engine chassis: Sensor Air filter contamination Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:5/6/7		E	1
888703	Engine chassis: Sensor Air filter contamination Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:5/6/7		E	1
888704	Engine chassis: Sensor Air filter contamination Signal outside permissible range (Limit 1) no reaction Check air filter pressure sensor 1 for operating range injury. Fix possible mechanical problem	A700.X2:5/6/7		E	0
888705	Engine chassis: Sensor Air filter contamination Signal outside permissible range (Limit 2) no reaction Check air filter pressure sensor 1 for operating range injury. Fix possible mechanical problem	A700.X2:5/6/7		E	0
888706	Engine chassis: Sensor Air filter contamination signal implausible Check sensor, wiring, input on control unit	A700.X2:5/6/7		E	1
888800	Engine chassis: Common Rail Pr. sensor 1 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:60/46/32		E	1
888801	Engine chassis: Common Rail Pr. sensor 1 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:60/46/32		E	1
888802	Engine chassis: Common Rail Pr. sensor 1 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:60/46/32		E	1
888803	Engine chassis: Common Rail Pr. sensor 1 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:60/46/32		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888804	Engine chassis: Common Rail Pr. sensor 1 Signal outside permissible range (Limit 1) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check Common rail pressure sensor 1 for operating range injury. Fix possible mechanical problem	A700.X1:60/46/32		E	1
888805	Engine chassis: Common Rail Pr. sensor 1 Signal outside permissible range (Limit 2) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check Common rail pressure sensor 1 for operating range injury. Fix possible mechanical problem	A700.X1:60/46/32		E	1
888806	Engine chassis: Common Rail Pr. sensor 1 signal implausible Check sensor, wiring, input on control unit	A700.X1:60/46/32		E	1
888900	Engine chassis: Common Rail Pr. sensor 2 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:59/45/31		E	1
888901	Engine chassis: Common Rail Pr. sensor 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:59/45/31		E	1
888902	Engine chassis: Common Rail Pr. sensor 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:59/45/31		E	1
888903	Engine chassis: Common Rail Pr. sensor 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:59/45/31		E	1
888904	Engine chassis: Common Rail Pr. sensor 2 Signal outside permissible range (Limit 1) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check Common rail pressure sensor 2 for operating range injury. Fix possible mechanical problem	A700.X1:59/45/31		E	1
888905	Engine chassis: Common Rail Pr. sensor 2 Signal outside permissible range (Limit 2) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check Common rail pressure sensor 2 for operating range injury. Fix possible mechanical problem	A700.X1:59/45/31		E	1
888906	Engine chassis: Common Rail Pr. sensor 2 signal implausible Check sensor, wiring, input on control unit	A700.X1:59/45/31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889000	Engine chassis: Sensor ambient pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700		E	1
889001	Engine chassis: Sensor ambient pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
889002	Engine chassis: Sensor ambient pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889003	Engine chassis: Sensor ambient pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
889004	Engine chassis: Sensor ambient pr. Signal outside permissible range (Limit 1) Check sensor, wiring, input on control unit	A700		E	1
889005	Engine chassis: Sensor ambient pr. Signal outside permissible range (Limit 2) Check sensor, wiring, input on control unit	A700		E	1
889006	Engine chassis: Sensor ambient pr. signal implausible Check sensor, wiring, input on control unit	A700		E	1
889100	Engine chassis: Sensor air filter vacuum pressure status 2 short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889101	Engine chassis: Sensor air filter vacuum pressure status 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700		E	1
889102	Engine chassis: Sensor air filter vacuum pressure status 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889103	Engine chassis: Sensor air filter vacuum pressure status 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
889104	Engine chassis: Sensor air filter vacuum pressure status 2 Signal outside permissible range (Limit 1) no reaction Check air filter pressure switch 2 for operating range injury. Fix possible mechanical problem	A700		E	1
889105	Engine chassis: Sensor air filter vacuum pressure status 2 Signal outside permissible range (Limit 2) no reaction Check air filter pressure switch 2 for operating range injury. Fix possible mechanical problem	A700		E	1
889106	Engine chassis: Sensor air filter vacuum pressure status 2 Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700		E	1
889200	Engine chassis: Sensor air filter sub pressure status short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:46/60		E	1
889201	Engine chassis: Sensor air filter sub pressure status short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X2:46/60		E	1
889202	Engine chassis: Sensor air filter sub pressure status Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:46/60		E	1
889203	Engine chassis: Sensor air filter sub pressure status Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:46/60		E	1
889204	Engine chassis: Sensor air filter sub pressure status Signal outside permissible range (Limit 1) no reaction Check air filter pressure switch 1 for operating range injury. Fix possible mechanical problem	A700.X2:46/60		E	1
889205	Engine chassis: Sensor air filter sub pressure status Signal outside permissible range (Limit 2) no reaction Check air filter pressure switch 1 for operating range injury. Fix possible mechanical problem	A700.X2:46/60		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889206	Engine chassis: Sensor air filter sub pressure status Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700.X2:46/60		E	1
889300	Engine chassis: Sensor Water in fuel short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:		E	1
889301	Engine chassis: Sensor Water in fuel short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X2:		E	1
889302	Engine chassis: Sensor Water in fuel Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:		E	1
889303	Engine chassis: Sensor Water in fuel Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:		E	1
889304	Engine chassis: Sensor Water in fuel Signal outside permissible range (Limit 1) no reaction Check water level sensor for operating range injury. Fix possible mechanical problem	A700.X2:		E	1
889305	Engine chassis: Sensor Water in fuel Signal outside permissible range (Limit 2) no reaction Check water level sensor for operating range injury. Fix possible mechanical problem	A700.X2:		E	1
889306	Engine chassis: Sensor Water in fuel Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700.X2:		E	1
889400	Engine chassis: Sensor Intercooler-Temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:		E	1
889401	Engine chassis: Sensor Intercooler-Temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889402	Engine chassis: Sensor Intercooler-Temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:		E	1
889403	Engine chassis: Sensor Intercooler-Temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:		E	1
889404	Engine chassis: Sensor Intercooler-Temperature Signal outside permissible range (Limit 1) no reaction Check exhaust temperature sensor for operating range injury. Fix possible mechanical problem	A700.X2:		E	1
889405	Engine chassis: Sensor Intercooler-Temperature Signal outside permissible range (Limit 2) no reaction Check exhaust temperature sensor for operating range injury. Fix possible mechanical problem	A700.X2:		E	1
889406	Engine chassis: Sensor Intercooler-Temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700.X2:		E	1
889500	Engine chassis: Oil temperature sensor short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:46/60		E	1
889501	Engine chassis: Oil temperature sensor short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X2:46/60		E	1
889502	Engine chassis: Oil temperature sensor Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:46/60		E	1
889503	Engine chassis: Oil temperature sensor Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:46/60		E	1
889504	Engine chassis: Oil temperature sensor Signal outside permissible range (Limit 1) no reaction Check oil temperature sensor for operating range injury. Fix possible mechanical problem	A700.X2:46/60		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889505	Engine chassis: Oil temperature sensor Signal outside permissible range (Limit 2) no reaction Check oil temperature sensor for operating range injury. Fix possible mechanical problem	A700.X2:46/60		E	1
889506	Engine chassis: Oil temperature sensor Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700.X2:46/60		E	1
889600	Engine chassis: Sensor fuel temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:38/52		E	1
889601	Engine chassis: Sensor fuel temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X1:38/52		E	1
889602	Engine chassis: Sensor fuel temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:38/52		E	1
889603	Engine chassis: Sensor fuel temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:38/52		E	1
889604	Engine chassis: Sensor fuel temperature Signal outside permissible range (Limit 1) Performance reduction Check fuel temperature sensor for operating range injury. Fix possible mechanical problem	A700.X1:38/52		E	1
889605	Engine chassis: Sensor fuel temperature Signal outside permissible range (Limit 2) Performance reduction Check fuel temperature sensor for operating range injury. Fix possible mechanical problem	A700.X1:38/52		E	1
889606	Engine chassis: Sensor fuel temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700.X1:38/52		E	1
889700	Engine chassis: Sensor charge air temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889701	Engine chassis: Sensor charge air temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X1:		E	1
889702	Engine chassis: Sensor charge air temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:		E	1
889703	Engine chassis: Sensor charge air temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:		E	1
889704	Engine chassis: Sensor charge air temperature Signal outside permissible range (Limit 1) Performance reduction Check charge air temperature sensor for operating range injury. Fix possible mechanical problem	A700.X1:		E	0
889705	Engine chassis: Sensor charge air temperature Signal outside permissible range (Limit 2) Performance reduction Check charge air temperature sensor for operating range injury. Fix possible mechanical problem	A700.X1:		E	0
889706	Engine chassis: Sensor charge air temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700.X1:		E	1
889800	Engine chassis: Sensor coolant temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:51/37		E	2
889801	Engine chassis: Sensor coolant temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X1:51/37		E	2
889802	Engine chassis: Sensor coolant temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:51/37		E	2
889803	Engine chassis: Sensor coolant temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:51/37		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889804	Engine chassis: Sensor coolant temperature Signal outside permissible range (Limit 1) Performance reduction Check coolant temperature sensor for operating range injury. Fix possible mechanical problem.	A700.X1:51/37		E	0
889805	Engine chassis: Sensor coolant temperature Signal outside permissible range (Limit 2) Performance reduction Check coolant temperature sensor for operating range injury. Fix possible mechanical problem.	A700.X1:51/37		E	0
889806	Engine chassis: Sensor coolant temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700.X1:51/37		E	1
889900	Engine chassis: Sensor internal temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889901	Engine chassis: Sensor internal temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700		E	1
889902	Engine chassis: Sensor internal temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889903	Engine chassis: Sensor internal temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
889904	Engine chassis: Sensor internal temperature Signal outside permissible range (Limit 1) no reaction Check internal temperature for operating range injury. Fix possible mechanical problem	A700		E	1
889905	Engine chassis: Sensor internal temperature Signal outside permissible range (Limit 2) no reaction Check internal temperature for operating range injury. Fix possible mechanical problem	A700		E	1
889906	Engine chassis: Sensor internal temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
890100	Engine uppercarr. Control Travel pedal actuated at selected / active engine brake No acceptance of gases at active engine brake Deactivation of engine brake	A750.X2:34/.X2:48	/@	E	1
890101	Engine uppercarr. Control Travel pedal actuated at support / superstructure operation No acceptance of gases at active support operation Deactivation of support operation	A750.X2:34/.X2:48	/@	E	1
890102	Engine uppercarr. Control Function "bleeding fuel supply" activated (gas pedal) Breather function of fuel pump and lines to engine on active Engine RPM > 800 1/min or turn ignition off / on	A750.X2:34/.X2:48	/@	B	
890400	Engine uppercarr. CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded Emerg. op.: Momentum and RPM limitation of engine Check cable / plug / I/O-Module(s)	A750.X2:		E	1
890401	Engine uppercarr. CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / coupling module	A750.X2:		E	1
890402	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A750.X2:		E	1
890403	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A750.X2:		E	1
890404	Engine uppercarr. CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A750.X2:		E	1
890405	Engine uppercarr. CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module1	A750.X2:		E	1
890406	Engine uppercarr. CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module1	A750.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
890407	Engine uppercarr. CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module2	A750.X2:		E	1
890408	Engine uppercarr. CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module2	A750.X2:		E	1
890409	Engine uppercarr. CAN-Data transfer Retarder (ID 772) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / retarder module	A750.X2:		E	1
890410	Engine uppercarr. CAN-Data transfer WSK (ID 776) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / converter module	A750.X2:		E	1
890411	Engine uppercarr. CAN-Data transfer Overrun of receiving buffer last received value or replacement value Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750.X2:		E	1
890500	Engine uppercarr. CAN-engine control unit Time exceeded request global process view internal error, replace control unit	A750.X2:			
890501	Engine uppercarr. CAN-engine control unit Time exceeded at receipt of complete output data last received value or replacement value Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750.X2:		E	1
890502	Engine uppercarr. CAN-engine control unit Data communication failed / interrupted (Sending timeout) last received value or replacement value Check cable / plug / CAN-participant	A750.X2:		E	1
890503	Engine uppercarr. CAN-engine control unit Data communication interrupted (Passive error) last received value or replacement value Check cable / plug / CAN-participant	A750.X2:		E	1
890504	Engine uppercarr. CAN-engine control unit Data communication interrupted (BusOff) last received value or replacement value Check cable / plug / CAN-participant	A750.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
890600	Engine uppercarr. CAN constr. machinery Time exceeded request global process view Check cable / plug / CAN-participant	A750.X2:		E	1
890601	Engine uppercarr. CAN constr. machinery Time exceeded at receipt of complete output data Check cable / plug / CAN-participant	A750.X2:		E	1
890602	Engine uppercarr. CAN constr. machinery Data communication failed / interrupted (Sending timeout) Check cable / plug / CAN-participant	A750.X2:		E	1
890603	Engine uppercarr. CAN constr. machinery Data communication interrupted (Passive error) Check cable / plug / CAN-participant	A750.X2:		E	1
890604	Engine uppercarr. CAN constr. machinery Data communication interrupted (BusOff) Check cable / plug / CAN-participant	A750.X2:		E	1
890605	Engine uppercarr. CAN constr. machinery Data communication malfunctioning (warning) Check cable / plug / CAN-participant	A750.X2:		E	1
890606	Engine uppercarr. CAN constr. machinery Data communication was malfunctioning (timeout) Check cable / plug / CAN-participant	A750.X2:		E	1
890700	Engine uppercarr. CAN AMET Time exceeded request global process view Check cable / plug / CAN-participant	A750.X2:		E	1
890701	Engine uppercarr. CAN AMET Time exceeded at receipt of complete output data Check cable / plug / CAN-participant	A750.X2:		E	1
890702	Engine uppercarr. CAN AMET Data communication failed / interrupted (Sending timeout) Check cable / plug / CAN-participant	A750.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
890703	Engine uppercarr. CAN AMET Data communication interrupted (Passive error) Check cable / plug / CAN-participant	A750.X2:		E	1
890704	Engine uppercarr. CAN AMET Data communication interrupted (BusOff) Check cable / plug / CAN-participant	A750.X2:		E	1
890705	Engine uppercarr. CAN AMET Data communication malfunctioning (warning) Check cable / plug / CAN-participant	A750.X2:		E	1
890706	Engine uppercarr. CAN AMET Data communication was malfunctioning (timeout) Check cable / plug / CAN-participant	A750.X2:		E	1
890800	Engine uppercarr. CAN-Data transfer Data communication Tachograph problem Change over to plausible speed source Check cable / plug / tachograph	A750.X2:		E	1
890801	Engine uppercarr. CAN-Data transfer Data communication TSC1 problem No Check cable / plug / CAN-participant	A750.X2:		E	1
890802	Engine uppercarr. CAN-Data transfer Data communication failed / interrupted (Sending timeout) Change over to plausible speed source Check cable / plug / CAN-participant	A750.X2:		E	1
890803	Engine uppercarr. CAN-Data transfer Data communication interrupted (Passive error) Change over to plausible speed source Check cable / plug / CAN-participant	A750.X2:		E	1
890804	Engine uppercarr. CAN-Data transfer Data communication interrupted (BusOff) Change over to plausible speed source Check cable / plug / CAN-participant	A750.X2:		E	1
890900	Engine uppercarr. CAN-communication status CAN A - Setting Transfer rate 125 Kbaud possible No	A750.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
890901	Engine uppercarr. CAN-communication status CAN A - Setting Transfer rate 250 KBaud possible No	A750.X2:		E	1
890902	Engine uppercarr. CAN-communication status CAN A - Setting Transfer rate 500 KBaud possible No	A750.X2:		E	1
890903	Engine uppercarr. CAN-communication status CAN A - Setting Transfer rate 1 MBaud possible No	A750.X2:		E	1
890904	Engine uppercarr. CAN-communication status CAN B - Setting Transfer rate 125 KBaud possible No	A750.X2:		E	1
890905	Engine uppercarr. CAN-communication status CAN B - Setting Transfer rate 250 KBaud possible No	A750.X2:		E	1
890906	Engine uppercarr. CAN-communication status CAN B - Setting Transfer rate 500 KBaud possible No	A750.X2:		E	1
890907	Engine uppercarr. CAN-communication status CAN B - Setting Transfer rate 1 MBaud possible No	A750.X2:		E	1
890908	Engine uppercarr. CAN-communication status CAN-connection after problem new synchronized No	A750.X2:		E	1
890909	Engine uppercarr. CAN-communication status Transfer error stored on CAN No	A750.X2:		E	1
890910	Engine uppercarr. CAN-communication status CAN-transfer rate not recognized / is detected No	A750.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
890911	Engine uppercarr. CAN-communication status CAN-transfer rate not recognized / is detected No	A750.X2:		E	1
890912	Engine uppercarr. CAN-communication status CAN-transfer rate not recognized / is detected	A750.X2:		E	1
891000	Engine uppercarr. Internal error Stack-overflow Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750		E	2
891001	Engine uppercarr. Internal error Exception Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750		E	2
891002	Engine uppercarr. Internal error Program test Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750		E	2
891003	Engine uppercarr. Internal error RAM-Test Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750		E	2
891004	Engine uppercarr. Internal error Overflow in error stack No Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750		E	0
891005	Engine uppercarr. Internal error Comp. time error No Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750		E	2
891006	Engine uppercarr. Internal error Error-Index too large The error cannot be shown Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A750		E	0
891100	Engine uppercarr. Memory error EEPROM Error at EEPROM-access Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
891101	Engine uppercarr. Memory error EEPROM Check sum via parameter memory is erroneous Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	2
891102	Engine uppercarr. Memory error EEPROM Parameter memory in EEPROM is invalid Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	2
891103	Engine uppercarr. Memory error EEPROM Check sum via ECU-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	0
891104	Engine uppercarr. Memory error EEPROM Check sum via NMI-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	0
891105	Engine uppercarr. Memory error EEPROM Check sum via Work data-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	0
891106	Engine uppercarr. Memory error EEPROM Check sum via load collective is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	0
891107	Engine uppercarr. Memory error EEPROM Structure size of load collective has changed No Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	0
891108	Engine uppercarr. Memory error EEPROM EEPROM has insufficient memory for load collective free No Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	0
891109	Engine uppercarr. Memory error EEPROM Check sum via permanent data is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A750		E	0
891200	Engine uppercarr. Power supply Supply voltage too low Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug).	A750.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
891201	Engine uppercarr. Power supply Supply voltage too high Engine cannot be started or engine shut off; only communication with diagnostics tool Check power supply (battery, alternator, wiring, plug)	A750.X2:		E	1
891202	Engine uppercarr. Power supply Digital output short circuit after supply voltage Engine shut off; only communication with diagnostics tool Wiring, check engine control unit; replace engine control unit if nec.	A750.X2:		E	1
891203	Engine uppercarr. Power supply Error at release of power outputs Engine shut off; shut off of all digital outlets Wiring, check engine control unit; replace engine control unit if nec.	A750.X2:		E	1
891204	Engine uppercarr. Power supply Current supply PS1 erroneous/missing Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A750.X2:		E	1
891205	Engine uppercarr. Power supply Error on 12V-Reference: Voltage too low (<10V) Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A750.X2:		E	1
891206	Engine uppercarr. Power supply Error on 12V-Reference: Voltage too high (>14V) Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A750.X2:		E	1
891500	Engine uppercarr. Configuration error Fan control The fan control is deactivated. Resulting in maximum vent position New data set, or replace engine control unit	A750		E	1
891501	Engine uppercarr. Configuration error Full load curve (incorrect Offset) The matching of the performance curve is internally limited New data set, or replace engine control unit	A750		E	1
891502	Engine uppercarr. Configuration error Monitoring Travel pedal Pedal unit is not monitored New data set, or replace engine control unit	A750		E	1
891503	Engine uppercarr. Configuration error Incorrect pump code Injector class 3 is used as replacement value Check pump coding and change (via diagnostics or corr. diagnostics tool)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
891504	Engine uppercarr. Configuration error Assignment error at high pressure sensors Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A750		E	1
891505	Engine uppercarr. Configuration error No high pressure pump active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A750		E	1
891506	Engine uppercarr. Configuration error Current output for high pressure pump 1 not active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A750		E	1
891507	Engine uppercarr. Configuration error Current output for high pressure pump 2 not active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A750		E	1
891800	Engine uppercarr. Active engine protection functions Excess temperature on exhaust turbine Power reduction 304700: WG/EGR-controller, check load pressure sensor	A750		E	1
891900	Engine uppercarr. Speed recording Maximum difference travel speed Tacho<->Gear exceeded The larger speed value is used Check Wiring engine control unit to speed sensor or check speed sensor.	A750		E	1
892000	Engine uppercarr. Alternator Undervoltage at engine start No Check wiring engine control unit to alternator and alternator.	A750.X2:		E	1
892001	Engine uppercarr. Alternator Undervoltage at engine on No Check wiring engine control unit to alternator and alternator.	A750.X2:		E	1
892002	Engine uppercarr. Alternator Undervoltage at engine on No Check wiring engine control unit to alternator and alternator.	A750.X2:		E	1
892003	Engine uppercarr. Alternator Overvoltage at engine on No Check wiring engine control unit to alternator and alternator.	A750.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
892004	Engine uppercarr. Alternator Voltage deviation to supply voltage too low No Check wiring engine control unit to alternator and alternator.	A750.X2:		E	1
892005	Engine uppercarr. Alternator Voltage deviation to supply voltage too high No Check wiring engine control unit to alternator and alternator.	A750.X2:		E	1
892100	Engine uppercarr. Travel pedal No gas switch erroneous Use low value Check wiring engine control unit to travel pedal. Check travel pedal / replace	A750		E	1
892101	Engine uppercarr. Travel pedal maximum signal difference channel 1 and 2 exceeded Use low value Check wiring engine control unit to travel pedal. Check travel pedal / replace	A750		E	1
892800	Engine uppercarr. Exhaust return (AGR2) Short circuit after ground or broken wire External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1
892801	Engine uppercarr. Exhaust return (AGR2) short circuit to supply voltage External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1
892802	Engine uppercarr. Exhaust return (AGR2) Hardware error (Transistor defective) External AGR2 is not actuated Check engine control unit	A750.X1:		E	1
892803	Engine uppercarr. Exhaust return (AGR2) Rule deviation negative External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1
892804	Engine uppercarr. Exhaust return (AGR2) Rule deviation positive External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1
892805	Engine uppercarr. Exhaust return (AGR2) Logic threshold breach in shut off condition External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
892806	Engine uppercarr. Exhaust return (AGR2) Logic threshold breach (Current less than perm. minimum value) External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1
892807	Engine uppercarr. Exhaust return (AGR2) Logic threshold breach (Current more than perm. maximum value) External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1
892811	Engine uppercarr. Exhaust return (AGR2) open without actuation External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1
892812	Engine uppercarr. Exhaust return (AGR2) closed despite actuation External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A750.X1:		E	1
892900	Engine uppercarr. Air flap Short circuit after ground or broken wire Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
892901	Engine uppercarr. Air flap short circuit to supply voltage Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
892902	Engine uppercarr. Air flap Hardware error (Transistor defective) Air vent is not actuated Check engine control unit	A750.X2:12/13	/@	E	1
892903	Engine uppercarr. Air flap Rule deviation negative Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
892904	Engine uppercarr. Air flap Rule deviation positive Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
892905	Engine uppercarr. Air flap Logic threshold breach in shut off condition Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
892906	Engine uppercarr. Air flap Logic threshold breach (Current less than perm. minimum value) Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
892907	Engine uppercarr. Air flap Logic threshold breach (Current more than perm. maximum value) Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
892908	Engine uppercarr. Air flap Over current LowSide Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
892909	Engine uppercarr. Air flap Over current HighSide Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
892910	Engine uppercarr. Air flap PWM on maximum Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A750.X2:12/13	/@	E	1
893003	Engine uppercarr. High pressure pump 1 Rule deviation negative Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893004	Engine uppercarr. High pressure pump 1 Rule deviation positive Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893005	Engine uppercarr. High pressure pump 1 Current to high in shut off condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893006	Engine uppercarr. High pressure pump 1 Current to low in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893007	Engine uppercarr. High pressure pump 1 Current to high in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
893008	Engine uppercarr. High pressure pump 1 UeberCurrent LowSide (ground switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893009	Engine uppercarr. High pressure pump 1 UeberCurrent HighSide (Plus-switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893010	Engine uppercarr. High pressure pump 1 PWM on maximum Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893103	Engine uppercarr. High pressure pump 2 Rule deviation negative Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893104	Engine uppercarr. High pressure pump 2 Rule deviation positive Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893105	Engine uppercarr. High pressure pump 2 Current to high in shut off condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893106	Engine uppercarr. High pressure pump 2 Current to low in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893107	Engine uppercarr. High pressure pump 2 Current to high in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893108	Engine uppercarr. High pressure pump 2 UeberCurrent LowSide (ground switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893109	Engine uppercarr. High pressure pump 2 UeberCurrent HighSide (Plus-switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
893110	Engine uppercarr. High pressure pump 2 PWM on maximum Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A750.X1:		E	1
893200	Engine uppercarr. Starter short circuit to ground Engine start not possible Check cable harness / plug / Starter / engine control unit	A750.X1:29	O-227.F2	E	1
893201	Engine uppercarr. Starter short circuit to supply voltage Engine start not possible Check cable harness / plug / Starter / engine control unit	A750.X1:29	O-227.F2	E	1
893300	Engine uppercarr. Fan control Short circuit after ground or broken wire The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A750.X2:26/27	O-211.F8/@	E	1
893301	Engine uppercarr. Fan control short circuit to supply voltage The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A750.X2:26/27	O-211.F8/@	E	1
893302	Engine uppercarr. Fan control Hardware error (Transistor defective) The fan control is deactivated. Resulting in maximum vent position Check engine control unit	A750.X2:26/27	O-211.F8/@	E	1
893303	Engine uppercarr. Fan control Rule deviation negative The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A750.X2:26/27	O-211.F8/@	E	1
893304	Engine uppercarr. Fan control Rule deviation positive The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A750.X2:26/27	O-211.F8/@	E	1
893305	Engine uppercarr. Fan control Logic threshold breach in shut off condition The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A750.X2:26/27	O-211.F8/@	E	1
893306	Engine uppercarr. Fan control Logic threshold breach (Current less than perm. minimum value) The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A750.X2:26/27	O-211.F8/@	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
893307	Engine uppercarr. Fan control Logic threshold breach (Current more than perm. maximum value) The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A750.X2:26/27	O-211.F8/@	E	1
893400	Engine uppercarr. Engine brake Short circuit after ground or broken wire Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A750.X2:11	/@	E	1
893401	Engine uppercarr. Engine brake short circuit to supply voltage Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A750.X2:11	/@	E	1
893402	Engine uppercarr. Engine brake Hardware error (Transistor defective) Engine brake flap is not actuated Check engine control unit	A750.X2:11	/@	E	1
893403	Engine uppercarr. Engine brake Rule deviation negative Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A750.X2:11	/@	E	1
893404	Engine uppercarr. Engine brake Rule deviation positive Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A750.X2:11	/@	E	1
893405	Engine uppercarr. Engine brake Logic threshold breach in shut off condition Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A750.X2:11	/@	E	1
893406	Engine uppercarr. Engine brake Logic threshold breach (Current less than perm. minimum value) Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A750.X2:11	/@	E	1
893407	Engine uppercarr. Engine brake Logic threshold breach (Current more than perm. maximum value) Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A750.X2:11	/@	E	1
893500	Engine uppercarr. Heater flange unit 1 Short circuit after ground or broken wire Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
893501	Engine uppercarr. Heater flange unit 1 short circuit to supply voltage Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893502	Engine uppercarr. Heater flange unit 1 Hardware error (Transistor defective) Failure of pre- and afterheat phase Check engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893503	Engine uppercarr. Heater flange unit 1 Rule deviation negative Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893504	Engine uppercarr. Heater flange unit 1 Rule deviation positive Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893505	Engine uppercarr. Heater flange unit 1 Logic threshold breach in shut off condition Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893506	Engine uppercarr. Heater flange unit 1 Logic threshold breach (Current less than perm. minimum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893507	Engine uppercarr. Heater flange unit 1 Logic threshold breach (Current more than perm. maximum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893511	Engine uppercarr. Heater flange unit 1 No voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893512	Engine uppercarr. Heater flange unit 1 Voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:39/64	O-231.E3/221.F7	E	1
893600	Engine uppercarr. Heater flange unit 2 Short circuit after ground or broken wire Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
893601	Engine uppercarr. Heater flange unit 2 short circuit to supply voltage Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893602	Engine uppercarr. Heater flange unit 2 Hardware error (Transistor defective) Failure of pre- and afterheat phase Check engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893603	Engine uppercarr. Heater flange unit 2 Rule deviation negative Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893604	Engine uppercarr. Heater flange unit 2 Rule deviation positive Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893605	Engine uppercarr. Heater flange unit 2 Logic threshold breach in shut off condition Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893606	Engine uppercarr. Heater flange unit 2 Logic threshold breach (Current less than perm. minimum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893607	Engine uppercarr. Heater flange unit 2 Logic threshold breach (Current more than perm. maximum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893611	Engine uppercarr. Heater flange unit 2 No voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893612	Engine uppercarr. Heater flange unit 2 Voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893700	Engine uppercarr. Solenoid valves Short circuit after ground or broken wire Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
893701	Engine uppercarr. Solenoid valves short circuit to supply voltage Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893702	Engine uppercarr. Solenoid valves Hardware error (Transistor defective) Failure of after heat phase Check engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893703	Engine uppercarr. Solenoid valves Rule deviation negative Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893704	Engine uppercarr. Solenoid valves Rule deviation positive Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893705	Engine uppercarr. Solenoid valves Logic threshold breach in shut off condition Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893706	Engine uppercarr. Solenoid valves Logic threshold breach (Current less than perm. minimum value) Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893707	Engine uppercarr. Solenoid valves Logic threshold breach (Current more than perm. maximum value) Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A750.X2:25/65	O-224.E1/221.F7	E	1
893800	Engine uppercarr. Turbo charger Short circuit after ground or broken wire Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A750		E	1
893801	Engine uppercarr. Turbo charger short circuit to supply voltage Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A750		E	1
893802	Engine uppercarr. Turbo charger Hardware error (Transistor defective) Turbocharger is not actuated Check engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
893803	Engine uppercarr. Turbo charger Rule deviation negative Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A750		E	1
893804	Engine uppercarr. Turbo charger Rule deviation positive Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A750		E	1
893805	Engine uppercarr. Turbo charger Logic threshold breach in shut off condition Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A750		E	1
893806	Engine uppercarr. Turbo charger Logic threshold breach (Current less than perm. minimum value) Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A750		E	1
893807	Engine uppercarr. Turbo charger Logic threshold breach (Current more than perm. maximum value) Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A750		E	1
893900	Engine uppercarr. Exhaust return (AGR) Short circuit after ground or broken wire External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1
893901	Engine uppercarr. Exhaust return (AGR) short circuit to supply voltage External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1
893902	Engine uppercarr. Exhaust return (AGR) Hardware error (Transistor defective) External AGR is not actuated Check engine control unit	A750.X1:		E	1
893903	Engine uppercarr. Exhaust return (AGR) Rule deviation negative External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1
893904	Engine uppercarr. Exhaust return (AGR) Rule deviation positive External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
893905	Engine uppercarr. Exhaust return (AGR) Logic threshold breach (Current higher than perm. min. value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1
893906	Engine uppercarr. Exhaust return (AGR) Logic threshold breach (Current less than perm. minimum value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1
893907	Engine uppercarr. Exhaust return (AGR) Logic threshold breach (Current more than perm. maximum value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1
893911	Engine uppercarr. Exhaust return (AGR) open without actuation External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1
893912	Engine uppercarr. Exhaust return (AGR) closed despite actuation External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A750.X1:		E	1
894000	Engine uppercarr. Emerg. Op. indicator Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A750.X2:42	O-200.E4	E	1
894001	Engine uppercarr. Emerg. Op. indicator short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A750.X2:42	O-200.E4	E	1
894002	Engine uppercarr. Emerg. Op. indicator Hardware error (Transistor defective) None Check engine control unit	A750.X2:42	O-200.E4	E	1
894100	Engine uppercarr. Indicator light preglow / start readiness Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A750.X2:28	/@	E	1
894101	Engine uppercarr. Indicator light preglow / start readiness short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A750.X2:28	/@	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
894102	Engine uppercarr. Indicator light preglow / start readiness Hardware error (Transistor defective) None Check engine control unit	A750.X2:28	/@	E	1
894200	Engine uppercarr. Charge indicator Alternator Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A750.X2:14	/@	E	1
894201	Engine uppercarr. Charge indicator Alternator short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A750.X2:14	/@	E	1
894202	Engine uppercarr. Charge indicator Alternator Hardware error (Transistor defective) None Check engine control unit	A750.X2:14	/@	E	1
894300	Engine uppercarr. fan control 1 (reversible) Short circuit after ground or broken wire	A750.X2:26/27	O-211.F8/@	E	1
894301	Engine uppercarr. fan control 1 (reversible) short circuit to supply voltage	A750.X2:26/27	O-211.F8/@	E	1
894302	Engine uppercarr. fan control 1 (reversible) Hardware error (Transistor defective)	A750.X2:26/27	O-211.F8/@	E	1
894303	Engine uppercarr. fan control 1 (reversible) Rule deviation negative	A750.X2:26/27	O-211.F8/@	E	1
894304	Engine uppercarr. fan control 1 (reversible) Rule deviation positive	A750.X2:26/27	O-211.F8/@	E	1
894305	Engine uppercarr. fan control 1 (reversible) Logic threshold breach in shut off condition	A750.X2:26/27	O-211.F8/@	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
894306	Engine uppercarr. fan control 1 (reversible) Logic threshold breach (Current less than perm. minimum value)	A750.X2:26/27	O-211.F8/@	E	1
894307	Engine uppercarr. fan control 1 (reversible) Logic threshold breach (Current more than perm. maximum value)	A750.X2:26/27	O-211.F8/@	E	1
894400	Engine uppercarr. fan control 2 (reversible) Short circuit after ground or broken wire	A750.X2:26/27	O-211.F8/@	E	1
894401	Engine uppercarr. fan control 2 (reversible) short circuit to supply voltage	A750.X2:26/27	O-211.F8/@	E	1
894402	Engine uppercarr. fan control 2 (reversible) Hardware error (Transistor defective)	A750.X2:26/27	O-211.F8/@	E	1
894403	Engine uppercarr. fan control 2 (reversible) Rule deviation negative	A750.X2:26/27	O-211.F8/@	E	1
894404	Engine uppercarr. fan control 2 (reversible) Rule deviation positive	A750.X2:26/27	O-211.F8/@	E	1
894405	Engine uppercarr. fan control 2 (reversible) Logic threshold breach in shut off condition	A750.X2:26/27	O-211.F8/@	E	1
894406	Engine uppercarr. fan control 2 (reversible) Logic threshold breach (Current less than perm. minimum value)	A750.X2:26/27	O-211.F8/@	E	1
894407	Engine uppercarr. fan control 2 (reversible) Logic threshold breach (Current more than perm. maximum value)	A750.X2:26/27	O-211.F8/@	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
894500	Engine uppercarr. Rail pressure system Pressure relief valve 1 open High pressure regulation emergency operation activated Test Rail circuit 1	A750		E	1
894501	Engine uppercarr. Rail pressure system Pressure relief valve 2 open High pressure regulation emergency operation activated Test Rail circuit 2	A750		E	1
894502	Engine uppercarr. Rail pressure system Emergency operation high pressure regulation active Power reduction, high pressure pump control turned off Test Rail circuit 1/2 / wiring harness / plug	A750		E	1
894503	Engine uppercarr. Rail pressure system Pressure difference between high pressure sensor 1 and 2 No reaction on engine, the higher sensor value is used Test wiring harness/ plug / rail pressure sensors / rail circuit 1/2	A750		E	1
894504	Engine uppercarr. Rail pressure system Regulation deviation in CR-regulating circuit 1 None Test Rail circuit 1	A750		E	1
894505	Engine uppercarr. Rail pressure system Regulation deviation in CR-regulating circuit 2 None Test Rail circuit 2	A750		E	1
894700	Engine uppercarr. Error on air path components Maximum charge pressure exceeded (P3-protection) Power reduction 301800:Check intake system for leaks	A750		E	1
894900	Engine uppercarr. RPM signal output Short circuit after ground or broken wire No Check wiring harness / plug / connected modules	A750		E	1
894901	Engine uppercarr. RPM signal output short circuit to supply voltage No Check wiring harness / plug / connected modules	A750		E	1
895000	Engine uppercarr. Cylinder A1 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A750.X1:22/8	/225.E7	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
895001	Engine uppercarr. Cylinder A1 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:22/8	/225.E7	E	2
895002	Engine uppercarr. Cylinder A1 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:22/8	/225.E7	E	2
895003	Engine uppercarr. Cylinder A1 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A750.X1:22/8	/225.E7	E	2
895005	Engine uppercarr. Cylinder A1 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A750.X1:22/8	/225.E7	E	
895006	Engine uppercarr. Cylinder A1 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A750.X1:22/8	/225.E7	E	0
895007	Engine uppercarr. Cylinder A1 No increase time measured No Replace engine control unit	A750.X1:22/8	/225.E7	E	2
895008	Engine uppercarr. Cylinder A1 Increase time too large No New data set, or replace engine control unit	A750.X1:22/8	/225.E7	E	
895100	Engine uppercarr. Cylinder A2 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A750.X1:21/7	/227.F4	E	2
895101	Engine uppercarr. Cylinder A2 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:21/7	/227.F4	E	2
895102	Engine uppercarr. Cylinder A2 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:21/7	/227.F4	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
895103	Engine uppercarr. Cylinder A2 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A750.X1:21/7	/227.F4	E	2
895104	Engine uppercarr. Cylinder A2 No fly time measured No Replace engine control unit	A750.X1:21/7	/227.F4	E	2
895105	Engine uppercarr. Cylinder A2 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A750.X1:21/7	/227.F4	E	
895106	Engine uppercarr. Cylinder A2 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A750.X1:21/7	/227.F4	E	0
895107	Engine uppercarr. Cylinder A2 No increase time measured No Replace engine control unit	A750.X1:21/7	/227.F4	E	2
895108	Engine uppercarr. Cylinder A2 Increase time too large No New data set, or replace engine control unit	A750.X1:21/7	/227.F4	E	
895200	Engine uppercarr. Cylinder A3 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	2
895201	Engine uppercarr. Cylinder A3 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	2
895202	Engine uppercarr. Cylinder A3 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	2
895203	Engine uppercarr. Cylinder A3 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
895204	Engine uppercarr. Cylinder A3 No fly time measured No Replace engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	2
895205	Engine uppercarr. Cylinder A3 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	
895206	Engine uppercarr. Cylinder A3 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	0
895207	Engine uppercarr. Cylinder A3 No increase time measured No Replace engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	2
895208	Engine uppercarr. Cylinder A3 Increase time too large No New data set, or replace engine control unit	A750.X1:20/6	O-225.E5/227.F5	E	
895300	Engine uppercarr. Cylinder A4 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A750.X1:19/5	/227.F5	E	2
895301	Engine uppercarr. Cylinder A4 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:19/5	/227.F5	E	2
895302	Engine uppercarr. Cylinder A4 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:19/5	/227.F5	E	2
895303	Engine uppercarr. Cylinder A4 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A750.X1:19/5	/227.F5	E	2
895304	Engine uppercarr. Cylinder A4 No fly time measured No Replace engine control unit	A750.X1:19/5	/227.F5	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
895305	Engine uppercarr. Cylinder A4 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A750.X1:19/5	/227.F5	E	
895306	Engine uppercarr. Cylinder A4 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A750.X1:19/5	/227.F5	E	0
895307	Engine uppercarr. Cylinder A4 No increase time measured No Replace engine control unit	A750.X1:19/5	/227.F5	E	2
895308	Engine uppercarr. Cylinder A4 Increase time too large No New data set, or replace engine control unit	A750.X1:19/5	/227.F5	E	
895800	Engine uppercarr. Cylinder B1 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	2
895801	Engine uppercarr. Cylinder B1 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	2
895802	Engine uppercarr. Cylinder B1 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	2
895803	Engine uppercarr. Cylinder B1 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	2
895804	Engine uppercarr. Cylinder B1 No fly time measured No Replace engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	2
895805	Engine uppercarr. Cylinder B1 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
895806	Engine uppercarr. Cylinder B1 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	0
895807	Engine uppercarr. Cylinder B1 No increase time measured No Replace engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	2
895808	Engine uppercarr. Cylinder B1 Increase time too large No New data set, or replace engine control unit	A750.X1:18/4	O-219.E5/225.E8	E	
895900	Engine uppercarr. Cylinder B2 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	2
895901	Engine uppercarr. Cylinder B2 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	2
895902	Engine uppercarr. Cylinder B2 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	2
895903	Engine uppercarr. Cylinder B2 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	2
895904	Engine uppercarr. Cylinder B2 No fly time measured No Replace engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	2
895905	Engine uppercarr. Cylinder B2 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	
895906	Engine uppercarr. Cylinder B2 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
895907	Engine uppercarr. Cylinder B2 No increase time measured No Replace engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	2
895908	Engine uppercarr. Cylinder B2 Increase time too large No New data set, or replace engine control unit	A750.X1:17/3	O-219.E4/229.F5	E	
896000	Engine uppercarr. Cylinder B3 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	2
896001	Engine uppercarr. Cylinder B3 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	2
896002	Engine uppercarr. Cylinder B3 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	2
896003	Engine uppercarr. Cylinder B3 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	2
896004	Engine uppercarr. Cylinder B3 No fly time measured No Replace engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	2
896005	Engine uppercarr. Cylinder B3 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	
896006	Engine uppercarr. Cylinder B3 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	0
896007	Engine uppercarr. Cylinder B3 No increase time measured No Replace engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
896008	Engine uppercarr. Cylinder B3 Increase time too large No New data set, or replace engine control unit	A750.X1:16/2	O-225.E5/229.F5	E	
896100	Engine uppercarr. Cylinder B4 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A750.X1:15/1	/229.F6	E	2
896101	Engine uppercarr. Cylinder B4 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:15/1	/229.F6	E	2
896102	Engine uppercarr. Cylinder B4 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A750.X1:15/1	/229.F6	E	2
896103	Engine uppercarr. Cylinder B4 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A750.X1:15/1	/229.F6	E	2
896104	Engine uppercarr. Cylinder B4 No fly time measured No Replace engine control unit	A750.X1:15/1	/229.F6	E	2
896105	Engine uppercarr. Cylinder B4 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A750.X1:15/1	/229.F6	E	
896106	Engine uppercarr. Cylinder B4 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A750.X1:15/1	/229.F6	E	0
896107	Engine uppercarr. Cylinder B4 No increase time measured No Replace engine control unit	A750.X1:15/1	/229.F6	E	2
896108	Engine uppercarr. Cylinder B4 Increase time too large No New data set, or replace engine control unit	A750.X1:15/1	/229.F6	E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
896900	Engine uppercarr. Injection system Cylinder error Engine shut off Check cable / plug / solenoid valve / engine control unit	A750		E	2
896901	Engine uppercarr. Injection system Overlap of injection on bank A Engine shut off New data set, or replace engine control unit	A750		E	2
896902	Engine uppercarr. Injection system Overlap of injection on bank B Engine shut off New data set, or replace engine control unit	A750		E	2
896903	Engine uppercarr. Injection system Short circuit Plus switch after ground on bank A No Check cable / plug / solenoid valve / engine control unit	A750		E	2
896904	Engine uppercarr. Injection system Short circuit Plus switch after ground on bank B No Check cable / plug / solenoid valve / engine control unit	A750		E	2
896905	Engine uppercarr. Injection system Short circuit Plus switch after supply voltage on bank A No Check cable / plug / solenoid valve / engine control unit	A750		E	2
896906	Engine uppercarr. Injection system Short circuit Plus switch after supply voltage on bank B No Check cable / plug / solenoid valve / engine control unit	A750		E	2
896907	Engine uppercarr. Injection system Short circuit Ground switch after ground on bank A at CR-Motor occurs shut off of bank A Check cable / plug / solenoid valve / engine control unit	A750		E	2
896908	Engine uppercarr. Injection system Short circuit Ground switch after ground on bank B at CR-Motor occurs shut off of bank B Check cable / plug / solenoid valve / engine control unit	A750		E	2
896909	Engine uppercarr. Injection system Short circuit Ground switch after supply voltage on bank A No Check cable / plug / solenoid valve / engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
896910	Engine uppercarr. Injection system Short circuit Ground switch after supply voltage on bank B No Check cable / plug / solenoid valve / engine control unit	A750		E	2
897000	Engine uppercarr. Overspeed RPM sensor 1 Warning threshold exceeded None Check engine op. (excess. speed due to push op.); engine control unit	A750		E	1
897001	Engine uppercarr. Overspeed RPM sensor 2 Warning threshold exceeded None Check engine op. (excess. speed due to push op.); engine control unit	A750		E	1
897002	Engine uppercarr. Overspeed RPM sensor 1 Safety threshold exceeded Engine shut off Check engine op. (excess. speed due to push op.); engine control unit	A750		E	1
897003	Engine uppercarr. Overspeed RPM sensor 2 Safety threshold exceeded Engine shut off Check engine op. (excess. speed due to push op.); engine control unit	A750		E	1
897100	Engine uppercarr. Synchronization defective Engine start not possible Turn ign. on / off; check RPM and phase sensor	A750		E	1
897101	Engine uppercarr. Synchronization incorrect distance gap<->Phase sensor Engine start not possible Turn ign. on / off; check RPM and phase sensor	A750		E	1
897102	Engine uppercarr. Synchronization Tooth number not correct Engine start not possible Turn ign. on / off; check RPM sensor	A750		E	1
897103	Engine uppercarr. Synchronization not possible, RPM is too low Engine start not possible Turn ign. on / off; check RPM and phase sensor	A750		E	1
897104	Engine uppercarr. Synchronization Index counter camshaft gear erroneous Engine start not possible Turn ign. on / off; check RPM and phase sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
897200	Engine uppercarr. RPM sensor 1 failed Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A750.X1:69/55/41		E	1
897201	Engine uppercarr. RPM sensor 1 does not start Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A750.X1:69/55/41		E	1
897202	Engine uppercarr. RPM sensor 1 impermissible signal difference (Gradient breach) Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A750.X1:69/55/41		E	1
897203	Engine uppercarr. RPM sensor 1 Frequency too high Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A750.X1:69/55/41		E	1
897204	Engine uppercarr. RPM sensor 1 poled Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Check RPM sensor inst., engine control unit.	A750.X1:69/55/41		E	1
897205	Engine uppercarr. RPM sensor 1 Value implausible/erroneous Emergency shut off at simultaneous failure of redundant sensor 2. Otherwise RPM registration via redundant sensor Check RPM sensor inst., engine control unit.	A750.X1:69/55/41		E	1
897300	Engine uppercarr. RPM sensor 2 failed Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A750.X1:68/54/40		E	1
897302	Engine uppercarr. RPM sensor 2 impermissible signal difference (Gradient breach) Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A750.X1:68/54/40		E	1
897303	Engine uppercarr. RPM sensor 2 Frequency too high Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A750.X1:68/54/40		E	1
897304	Engine uppercarr. RPM sensor 2 poled Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Check RPM sensor inst., engine control unit.	A750.X1:68/54/40		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
897305	Engine uppercarr. RPM sensor 2 Value implausible/erroneous Emergency shut off at simultaneous failure of redundant sensor 1. otherwise RPM registration via redundant sensor. Check RPM sensor inst., engine control unit.	A750.X1:68/54/40		E	1
897400	Engine uppercarr. Sensor Position camshaft failed Engine start, dep. on configuration, not possible. No effect with engine running Check distance of phase sensor to camshaft gear (0.5-2.0 mm); wiring to phase sensor, phase sensor	A750.X1:70/56/42		E	1
897404	Engine uppercarr. Sensor Position camshaft poled Engine start, dep. on configuration, not possible. No effect with engine running Check: Phase sensor installation, engine control unit	A750.X1:70/56/42		E	1
897405	Engine uppercarr. Sensor Position camshaft Value implausible/erroneous Emergency shut off at simultaneous failure of redundant sensor (1 or 2). Otherwise RPM reg. via red. sensor Check: Phase sensor installation, engine control unit	A750.X1:70/56/42		E	1
897500	Engine uppercarr. Travel pedal channel 1 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X2:33/34/35	O-226.F4/@	E	1
897501	Engine uppercarr. Travel pedal channel 1 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:33/34/35	O-226.F4/@	E	1
897502	Engine uppercarr. Travel pedal channel 1 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:33/34/35	O-226.F4/@	E	1
897503	Engine uppercarr. Travel pedal channel 1 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:33/34/35	O-226.F4/@	E	1
897504	Engine uppercarr. Travel pedal channel 1 Signal outside permissible range (Limit 1) remains in low idle when both travel pedal sensors have failed Check travel pedal sensor 1 for operating range injury. Fix possible mechanical problem	A750.X2:33/34/35	O-226.F4/@	E	1
897505	Engine uppercarr. Travel pedal channel 1 Signal outside permissible range (Limit 2) remains in low idle when both travel pedal sensors have failed Check travel pedal sensor 1 for operating range injury. Fix possible mechanical problem	A750.X2:33/34/35	O-226.F4/@	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
897506	Engine uppercarr. Travel pedal channel 1 signal implausible Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A750.X2:33/34/35	O-226.F4/@	E	1
897600	Engine uppercarr. Travel pedal channel 2 Short circuit after ground or line interruption Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A750.X2:47/48/49	O-220.E4/231.E4/226.F8	E	1
897602	Engine uppercarr. Travel pedal channel 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:47/48/49	O-220.E4/231.E4/226.F8	E	1
897603	Engine uppercarr. Travel pedal channel 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:47/48/49	O-220.E4/231.E4/226.F8	E	1
897604	Engine uppercarr. Travel pedal channel 2 Signal outside permissible range (Limit 1) remains in low idle when both travel pedal sensors have failed Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A750.X2:47/48/49	O-220.E4/231.E4/226.F8	E	1
897605	Engine uppercarr. Travel pedal channel 2 Signal outside permissible range (Limit 2) remains in low idle when both travel pedal sensors have failed Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A750.X2:47/48/49	O-220.E4/231.E4/226.F8	E	1
897606	Engine uppercarr. Travel pedal channel 2 signal implausible Check travel pedal sensor 2 for operating range injury. Fix possible mechanical problem	A750.X2:47/48/49	O-220.E4/231.E4/226.F8	E	1
897700	Engine uppercarr. Sensor coolant level Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X2:19/20/21	O-219.E1/219.E3/200.A2	E	2
897701	Engine uppercarr. Sensor coolant level short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:19/20/21	O-219.E1/219.E3/200.A2	E	2
897702	Engine uppercarr. Sensor coolant level Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:19/20/21	O-219.E1/219.E3/200.A2	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
897703	Engine uppercarr. Sensor coolant level Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:19/20/21	O- 219.E1/219.E3/200.A2	E	2
897704	Engine uppercarr. Sensor coolant level Signal outside permissible range (Limit 1) no reaction Check coolant level for operating range injury. Fix possible mechanical problem	A750.X2:19/20/21	O- 219.E1/219.E3/200.A2	E	0
897705	Engine uppercarr. Sensor coolant level Signal outside permissible range (Limit 2) no reaction Check coolant level for operating range injury. Fix possible mechanical problem	A750.X2:19/20/21	O- 219.E1/219.E3/200.A2	E	0
897706	Engine uppercarr. Sensor coolant level signal implausible Check sensor, wiring, input on control unit	A750.X2:19/20/21	O- 219.E1/219.E3/200.A2	E	2
897800	Engine uppercarr. Sensor oil level Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750		E	1
897801	Engine uppercarr. Sensor oil level short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750		E	1
897802	Engine uppercarr. Sensor oil level Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750		E	1
897803	Engine uppercarr. Sensor oil level Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750		E	1
897804	Engine uppercarr. Sensor oil level Signal outside permissible range (Limit 1) no reaction Check oil level for operating range injury. Fix possible mechanical problem	A750		E	1
897805	Engine uppercarr. Sensor oil level Signal outside permissible range (Limit 2) no reaction Check oil level for operating range injury. Fix possible mechanical problem	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
897806	Engine uppercarr. Sensor oil level signal implausible Check sensor, wiring, input on control unit	A750		E	1
898300	Engine uppercarr. Sensor air filter contamination 2 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X1:30/44/58	O-222.F8/@	E	1
898301	Engine uppercarr. Sensor air filter contamination 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:30/44/58	O-222.F8/@	E	1
898302	Engine uppercarr. Sensor air filter contamination 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:30/44/58	O-222.F8/@	E	1
898303	Engine uppercarr. Sensor air filter contamination 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:30/44/58	O-222.F8/@	E	1
898304	Engine uppercarr. Sensor air filter contamination 2 Signal outside permissible range (Limit 1) no reaction Check air filter pressure sensor 1 for operating range injury. Fix possible mechanical problem	A750.X1:30/44/58	O-222.F8/@	E	0
898305	Engine uppercarr. Sensor air filter contamination 2 Signal outside permissible range (Limit 2) no reaction Check air filter pressure sensor 1 for operating range injury. Fix possible mechanical problem	A750.X1:30/44/58	O-222.F8/@	E	0
898306	Engine uppercarr. Sensor air filter contamination 2 signal implausible Check sensor, wiring, input on control unit	A750.X1:30/44/58	O-222.F8/@	E	1
898400	Engine uppercarr. Sensor charge air pr, Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X1:61/47/33	O-219.E6/@	E	1
898401	Engine uppercarr. Sensor charge air pr, short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:61/47/33	O-219.E6/@	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
898402	Engine uppercarr. Sensor charge air pr, Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:61/47/33	O-219.E6/@	E	1
898403	Engine uppercarr. Sensor charge air pr, Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:61/47/33	O-219.E6/@	E	1
898404	Engine uppercarr. Sensor charge air pr, Signal outside permissible range (Limit 1) no reaction Check charge air pressure sensor 2 for operating range injury. Fix possible mechanical problem	A750.X1:61/47/33	O-219.E6/@	E	1
898405	Engine uppercarr. Sensor charge air pr, Signal outside permissible range (Limit 2) no reaction Check charge air pressure sensor 2 for operating range injury. Fix possible mechanical problem	A750.X1:61/47/33	O-219.E6/@	E	1
898406	Engine uppercarr. Sensor charge air pr, signal implausible Check sensor, wiring, input on control unit	A750.X1:61/47/33	O-219.E6/@	E	1
898500	Engine uppercarr. Sensor oil pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X1:63/49/35		E	2
898501	Engine uppercarr. Sensor oil pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:63/49/35		E	2
898502	Engine uppercarr. Sensor oil pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:63/49/35		E	2
898503	Engine uppercarr. Sensor oil pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:63/49/35		E	2
898504	Engine uppercarr. Sensor oil pr. Signal outside permissible range (Limit 1) no reaction Check oil pressure for operating range injury. Fix possible mechanical problem	A750.X1:63/49/35		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
898505	Engine uppercarr. Sensor oil pr. Signal outside permissible range (Limit 2) no reaction Check oil pressure for operating range injury. Fix possible mechanical problem	A750.X1:63/49/35		E	0
898506	Engine uppercarr. Sensor oil pr. signal implausible Check sensor, wiring, input on control unit	A750.X1:63/49/35		E	2
898600	Engine uppercarr. Sensor fuel pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X1:62/48/34	O-227.F3/219.E6/@	E	1
898601	Engine uppercarr. Sensor fuel pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:62/48/34	O-227.F3/219.E6/@	E	1
898602	Engine uppercarr. Sensor fuel pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:62/48/34	O-227.F3/219.E6/@	E	1
898603	Engine uppercarr. Sensor fuel pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:62/48/34	O-227.F3/219.E6/@	E	1
898604	Engine uppercarr. Sensor fuel pr. Signal outside permissible range (Limit 1) no reaction Check medium for fuel pressure injury. Fix possible mechanical problem	A750.X1:62/48/34	O-227.F3/219.E6/@	E	1
898605	Engine uppercarr. Sensor fuel pr. Signal outside permissible range (Limit 2) no reaction Check medium for fuel pressure injury. Fix possible mechanical problem	A750.X1:62/48/34	O-227.F3/219.E6/@	E	1
898606	Engine uppercarr. Sensor fuel pr. signal implausible Check sensor, wiring, input on control unit	A750.X1:62/48/34	O-227.F3/219.E6/@	E	1
898700	Engine uppercarr. Sensor Air filter contamination Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X2:5/6/7	O-232.F2/221.F7	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
898701	Engine uppercarr. Sensor Air filter contamination short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:5/6/7	O-232.F2/221.F7	E	1
898702	Engine uppercarr. Sensor Air filter contamination Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:5/6/7	O-232.F2/221.F7	E	1
898703	Engine uppercarr. Sensor Air filter contamination Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:5/6/7	O-232.F2/221.F7	E	1
898704	Engine uppercarr. Sensor Air filter contamination Signal outside permissible range (Limit 1) no reaction Check air filter pressure sensor 1 for operating range injury. Fix possible mechanical problem	A750.X2:5/6/7	O-232.F2/221.F7	E	0
898705	Engine uppercarr. Sensor Air filter contamination Signal outside permissible range (Limit 2) no reaction Check air filter pressure sensor 1 for operating range injury. Fix possible mechanical problem	A750.X2:5/6/7	O-232.F2/221.F7	E	0
898706	Engine uppercarr. Sensor Air filter contamination signal implausible Check sensor, wiring, input on control unit	A750.X2:5/6/7	O-232.F2/221.F7	E	1
898800	Engine uppercarr. Common Rail Pr. sensor 1 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X1:60/46/32	O-223.B4/228.F5	E	1
898801	Engine uppercarr. Common Rail Pr. sensor 1 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:60/46/32	O-223.B4/228.F5	E	1
898802	Engine uppercarr. Common Rail Pr. sensor 1 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:60/46/32	O-223.B4/228.F5	E	1
898803	Engine uppercarr. Common Rail Pr. sensor 1 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:60/46/32	O-223.B4/228.F5	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
898804	Engine uppercarr. Common Rail Pr. sensor 1 Signal outside permissible range (Limit 1) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check Common rail pressure sensor 1 for operating range injury. Fix possible mechanical problem	A750.X1:60/46/32	O-223.B4/228.F5	E	1
898805	Engine uppercarr. Common Rail Pr. sensor 1 Signal outside permissible range (Limit 2) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check Common rail pressure sensor 1 for operating range injury. Fix possible mechanical problem	A750.X1:60/46/32	O-223.B4/228.F5	E	1
898806	Engine uppercarr. Common Rail Pr. sensor 1 signal implausible Check sensor, wiring, input on control unit	A750.X1:60/46/32	O-223.B4/228.F5	E	1
898900	Engine uppercarr. Common Rail Pr. sensor 2 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750.X1:59/45/31	O-227.F3/223.B2/228.F5	E	1
898901	Engine uppercarr. Common Rail Pr. sensor 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:59/45/31	O-227.F3/223.B2/228.F5	E	1
898902	Engine uppercarr. Common Rail Pr. sensor 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:59/45/31	O-227.F3/223.B2/228.F5	E	1
898903	Engine uppercarr. Common Rail Pr. sensor 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:59/45/31	O-227.F3/223.B2/228.F5	E	1
898904	Engine uppercarr. Common Rail Pr. sensor 2 Signal outside permissible range (Limit 1) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check Common rail pressure sensor 2 for operating range injury. Fix possible mechanical problem	A750.X1:59/45/31	O-227.F3/223.B2/228.F5	E	1
898905	Engine uppercarr. Common Rail Pr. sensor 2 Signal outside permissible range (Limit 2) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check Common rail pressure sensor 2 for operating range injury. Fix possible mechanical problem	A750.X1:59/45/31	O-227.F3/223.B2/228.F5	E	1
898906	Engine uppercarr. Common Rail Pr. sensor 2 signal implausible Check sensor, wiring, input on control unit	A750.X1:59/45/31	O-227.F3/223.B2/228.F5	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
899000	Engine uppercarr. Sensor ambient pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A750		E	1
899001	Engine uppercarr. Sensor ambient pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750		E	1
899002	Engine uppercarr. Sensor ambient pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750		E	1
899003	Engine uppercarr. Sensor ambient pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750		E	1
899004	Engine uppercarr. Sensor ambient pr. Signal outside permissible range (Limit 1) Check sensor, wiring, input on control unit	A750		E	1
899005	Engine uppercarr. Sensor ambient pr. Signal outside permissible range (Limit 2) Check sensor, wiring, input on control unit	A750		E	1
899006	Engine uppercarr. Sensor ambient pr. signal implausible Check sensor, wiring, input on control unit	A750		E	1
899100	Engine uppercarr. Sensor air filter vacuum pressure status 2 short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750		E	1
899101	Engine uppercarr. Sensor air filter vacuum pressure status 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750		E	1
899102	Engine uppercarr. Sensor air filter vacuum pressure status 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
899103	Engine uppercarr. Sensor air filter vacuum pressure status 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750		E	1
899104	Engine uppercarr. Sensor air filter vacuum pressure status 2 Signal outside permissible range (Limit 1) no reaction Check air filter pressure switch 2 for operating range injury. Fix possible mechanical problem	A750		E	1
899105	Engine uppercarr. Sensor air filter vacuum pressure status 2 Signal outside permissible range (Limit 2) no reaction Check air filter pressure switch 2 for operating range injury. Fix possible mechanical problem	A750		E	1
899106	Engine uppercarr. Sensor air filter vacuum pressure status 2 Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750		E	1
899200	Engine uppercarr. Sensor air filter sub pressure status short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:46/60	/211.F2	E	1
899201	Engine uppercarr. Sensor air filter sub pressure status short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750.X2:46/60	/211.F2	E	1
899202	Engine uppercarr. Sensor air filter sub pressure status Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:46/60	/211.F2	E	1
899203	Engine uppercarr. Sensor air filter sub pressure status Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:46/60	/211.F2	E	1
899204	Engine uppercarr. Sensor air filter sub pressure status Signal outside permissible range (Limit 1) no reaction Check air filter pressure switch 1 for operating range injury. Fix possible mechanical problem	A750.X2:46/60	/211.F2	E	1
899205	Engine uppercarr. Sensor air filter sub pressure status Signal outside permissible range (Limit 2) no reaction Check air filter pressure switch 1 for operating range injury. Fix possible mechanical problem	A750.X2:46/60	/211.F2	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
899206	Engine uppercarr. Sensor air filter sub pressure status Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750.X2:46/60	/211.F2	E	1
899300	Engine uppercarr. Sensor Water in fuel short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:		E	1
899301	Engine uppercarr. Sensor Water in fuel short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750.X2:		E	1
899302	Engine uppercarr. Sensor Water in fuel Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:		E	1
899303	Engine uppercarr. Sensor Water in fuel Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:		E	1
899304	Engine uppercarr. Sensor Water in fuel Signal outside permissible range (Limit 1) no reaction Check water level sensor for operating range injury. Fix possible mechanical problem	A750.X2:		E	1
899305	Engine uppercarr. Sensor Water in fuel Signal outside permissible range (Limit 2) no reaction Check water level sensor for operating range injury. Fix possible mechanical problem	A750.X2:		E	1
899306	Engine uppercarr. Sensor Water in fuel Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750.X2:		E	1
899400	Engine uppercarr. Sensor Intercooler-Temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:		E	1
899401	Engine uppercarr. Sensor Intercooler-Temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
899402	Engine uppercarr. Sensor Intercooler-Temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:		E	1
899403	Engine uppercarr. Sensor Intercooler-Temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:		E	1
899404	Engine uppercarr. Sensor Intercooler-Temperature Signal outside permissible range (Limit 1) no reaction Check exhaust temperature sensor for operating range injury. Fix possible mechanical problem	A750.X2:		E	1
899405	Engine uppercarr. Sensor Intercooler-Temperature Signal outside permissible range (Limit 2) no reaction Check exhaust temperature sensor for operating range injury. Fix possible mechanical problem	A750.X2:		E	1
899406	Engine uppercarr. Sensor Intercooler-Temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750.X2:		E	1
899500	Engine uppercarr. Oil temperature sensor short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:46/60	/211.F2	E	1
899501	Engine uppercarr. Oil temperature sensor short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750.X2:46/60	/211.F2	E	1
899502	Engine uppercarr. Oil temperature sensor Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X2:46/60	/211.F2	E	1
899503	Engine uppercarr. Oil temperature sensor Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X2:46/60	/211.F2	E	1
899504	Engine uppercarr. Oil temperature sensor Signal outside permissible range (Limit 1) no reaction Check oil temperature sensor for operating range injury. Fix possible mechanical problem	A750.X2:46/60	/211.F2	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
899505	Engine uppercarr. Oil temperature sensor Signal outside permissible range (Limit 2) no reaction Check oil temperature sensor for operating range injury. Fix possible mechanical problem	A750.X2:46/60	/211.F2	E	1
899506	Engine uppercarr. Oil temperature sensor Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750.X2:46/60	/211.F2	E	1
899600	Engine uppercarr. Sensor fuel temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:38/52	/227.F8	E	1
899601	Engine uppercarr. Sensor fuel temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750.X1:38/52	/227.F8	E	1
899602	Engine uppercarr. Sensor fuel temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:38/52	/227.F8	E	1
899603	Engine uppercarr. Sensor fuel temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:38/52	/227.F8	E	1
899604	Engine uppercarr. Sensor fuel temperature Signal outside permissible range (Limit 1) Performance reduction Check fuel temperature sensor for operating range injury. Fix possible mechanical problem	A750.X1:38/52	/227.F8	E	1
899605	Engine uppercarr. Sensor fuel temperature Signal outside permissible range (Limit 2) Performance reduction Check fuel temperature sensor for operating range injury. Fix possible mechanical problem	A750.X1:38/52	/227.F8	E	1
899606	Engine uppercarr. Sensor fuel temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750.X1:38/52	/227.F8	E	1
899700	Engine uppercarr. Sensor charge air temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
899701	Engine uppercarr. Sensor charge air temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750.X1:		E	1
899702	Engine uppercarr. Sensor charge air temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:		E	1
899703	Engine uppercarr. Sensor charge air temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:		E	1
899704	Engine uppercarr. Sensor charge air temperature Signal outside permissible range (Limit 1) Performance reduction Check charge air temperature sensor for operating range injury. Fix possible mechanical problem	A750.X1:		E	0
899705	Engine uppercarr. Sensor charge air temperature Signal outside permissible range (Limit 2) Performance reduction Check charge air temperature sensor for operating range injury. Fix possible mechanical problem	A750.X1:		E	0
899706	Engine uppercarr. Sensor charge air temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750.X1:		E	1
899800	Engine uppercarr. Sensor coolant temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:51/37	/@	E	2
899801	Engine uppercarr. Sensor coolant temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750.X1:51/37	/@	E	2
899802	Engine uppercarr. Sensor coolant temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750.X1:51/37	/@	E	2
899803	Engine uppercarr. Sensor coolant temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750.X1:51/37	/@	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
899804	Engine uppercarr. Sensor coolant temperature Signal outside permissible range (Limit 1) Performance reduction Check coolant temperature sensor for operating range injury. Fix possible mechanical problem.	A750.X1:51/37	/@	E	0
899805	Engine uppercarr. Sensor coolant temperature Signal outside permissible range (Limit 2) Performance reduction Check coolant temperature sensor for operating range injury. Fix possible mechanical problem.	A750.X1:51/37	/@	E	0
899806	Engine uppercarr. Sensor coolant temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750.X1:51/37	/@	E	1
899900	Engine uppercarr. Sensor internal temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750		E	1
899901	Engine uppercarr. Sensor internal temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A750		E	1
899902	Engine uppercarr. Sensor internal temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A750		E	1
899903	Engine uppercarr. Sensor internal temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A750		E	1
899904	Engine uppercarr. Sensor internal temperature Signal outside permissible range (Limit 1) no reaction Check internal temperature for operating range injury. Fix possible mechanical problem	A750		E	1
899905	Engine uppercarr. Sensor internal temperature Signal outside permissible range (Limit 2) no reaction Check internal temperature for operating range injury. Fix possible mechanical problem	A750		E	1
899906	Engine uppercarr. Sensor internal temperature Test value not plausible at Motor off Check sensor, wiring, input on control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0100	Engine chassis: Operating note Travel pedal actuated at selected / active engine brake No acceptance of gases at active engine brake 300100: Deactivation of engine brake	A700		B	0
8A0101	Engine chassis: Operating note Travel pedal actuated at support / superstructure operation No acceptance of gases at active engine brake 300101: Deactivation of support operation	A700		B	0
8A0102	Engine chassis: Operating note Service function "Vent fuel supply" activated (Gaspedal Increase of injection amount in starting phase 300102: Deactivate after reaching rpm limit or after initialization of engine control unit	A700		B	0
8A0103	Engine chassis: Operating note Engine Start prevented, ignition switch actuated after ignition on No engine start until Signal terminal 50 on input was recognized as low 300103: Release ignition switch Kl.50 or check signal for short circuit after Ubatt	A700		B	0
8A0104	Engine chassis: Operating note Engine Start prevented, Ignition switch to short in zero No engine start until Signal terminal 50 on input was recognized as low 300104: Release ignition switch T.50 or check signal for short circuit after Ubatt	A700		B	0
8A0105	Engine chassis: Operating note Engine Start prevented, Ignition switch actuated in Init phase No engine start until Signal terminal 50 on input was recognized as low 300105: Release ignition switch T.50 or check signal for short circuit after Ubatt	A700		B	0
8A0106	Engine chassis: Operating note Engine running for long time without load in idling Filter load increases significantly 300106: Increase load/engine rpm	A700		B	0
8A0107	Engine chassis: Operating note manual DPF regeneration not possible, charge status too low no reaction 300107: Deactivate manual DPF Regeneration	A700		B	1
8A0108	Engine chassis: Operating note manual DPF regeneration not possible, time blockage no reaction 300107: Deactivate manual DPF Regeneration	A700		B	1
8A0109	Engine chassis: Operating note Start prevented, no release of emerg. stop function engine start not possible 300109: Release ignition switch, check emerg. stop signal for short circuit after Ubatt	A700		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A010A	Engine chassis: Operating note Time conditions for monitoring test values not met engine start not possible 300110: Check / replace machine control Master 4	A700		B	0
8A010B	Engine chassis: Operating note Emerg. op after problem of data transfer on CAN-Bus active engine start not possible 300111: Stop engine and restart, check CAN-wiring	A700		B	0
8A0200	Engine chassis: Operating note Travel pedal actuated at selected / active engine brake 300200:	A700		B	0
8A0400	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit(meter Sensor 1) faulty Possibly power reduction 300400: Check wiring CAN-Buses, control units	A700		E	1
8A0401	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit(meter Sensor 2) faulty Possibly power reduction 300401: Check wiring CAN-Buses, control units	A700		E	1
8A0402	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit 2 (Sensors SCR cat.) faulty Possibly power reduction 300402: Check wiring CAN-Buses, control units	A700		E	1
8A0403	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit 2(urea tank sensors) faulty Possibly power reduction 300403: Check wiring CAN-Buses, control units	A700		E	1
8A0404	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit 2(SCR metering status) faulty Possibly power reduction 300404: Check wiring CAN-Buses, control units	A700		E	1
8A0405	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit 2(SCR metering info) faulty Possibly power reduction 300405: Check wiring CAN-Buses, control units	A700		E	1
8A0406	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit 2(NoxUp2 dew-point) faulty Possibly power reduction 300406: Check wiring CAN-Buses, control units	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0407	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit 2(NoxDown2 dew-point) faulty Possibly power reduction 300407: Check wiring CAN-Buses, control units	A700		E	1
8A0408	Engine chassis: CAN-Data transfer engine CAN 4 Diagnostics of SCR-metering unit 2 erroneous no reaction 300408: Check wiring CAN-Buses, control units	A700		E	1
8A0409	Engine chassis: CAN-Data transfer engine CAN 4 Data transfer SCR Service diagnostics faulty, 2. Pump no reaction 300409: Check wiring CAN-Buses, control units	A700		E	1
8A040A	Engine chassis: CAN-Data transfer engine CAN 4 Service diagnostics function SCR 2 not properly completed no reaction 300410: Check wiring CAN-Buses, control units	A700		E	1
8A040B	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit 2(meter Sensor 1) faulty Possibly power reduction 300411: Check wiring CAN-Buses, control units	A700		E	1
8A040C	Engine chassis: CAN-Data transfer engine CAN 4 SCR-unit 2(meter Sensor 2) faulty Possibly power reduction 300412: Check wiring CAN-Buses, control units	A700		E	1
8A040D	Engine chassis: CAN-Data transfer engine CAN 4 Humidity sensor faulty Possibly power reduction 300413: Check wiring CAN-Buses, control units	A700		E	1
8A0500	Engine chassis: CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded Emerg. op.: Momentum and RPM limitation of engine 300500: Check cable / plug / I/O-module(s)	A700		E	1
8A0501	Engine chassis: CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded Last received value or replacement value 300501: Check cable / plug / Coupling module	A700		E	1
8A0502	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded Last received value or replacement value 300502: Check cable / plug / Gear module	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0503	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded Last received value or replacement value 300503: Check cable / plug / Gear module	A700		E	1
8A0504	Engine chassis: CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded Last received value or replacement value 300504: Check cable / plug / Gear module	A700		E	1
8A0505	Engine chassis: CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded Last received value or replacement value 300505: Check cable / plug / ABS/ASR-Module1	A700		E	1
8A0506	Engine chassis: CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded Last received value or replacement value 300506: Check cable / plug / ABS/ASR-Module1	A700		E	1
8A0507	Engine chassis: CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded Last received value or replacement value 300507: Check cable / plug / ABS/ASR-Module2	A700		E	1
8A0508	Engine chassis: CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded Last received value or replacement value 300508: Check cable / plug / ABS/ASR-Module2	A700		E	1
8A0509	Engine chassis: CAN-Data transfer Retarder (ID 772) erroneous/maximum cycle time exceeded Last received value or replacement value 300509: Check cable / plug / Retarder module	A700		E	1
8A050A	Engine chassis: CAN-Data transfer WSK (ID 776) erroneous/maximum cycle time exceeded Last received value or replacement value 300510: Check cable / plug / converter module	A700		E	1
8A050B	Engine chassis: CAN-Data transfer Overrun of receiving buffer Last received value or replacement value 300511: Turn ignition off/on, load new software in engine control unit or replace control unit	A700		E	1
8A0600	Engine chassis: CAN-Data transfer engine control unit Aborted (Passive error) Last received value or replacement value 300600: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0601	Engine chassis: CAN-Data transfer engine control unit Aborted (BusOff) Last received value or replacement value 300601: Check cable / plug / CAN-participant	A700		E	1
8A0602	Engine chassis: CAN-Data transfer engine control unit Faulty / interrupted (Rx-warning) Last received value or replacement value 300602: Check cable / plug / CAN-participant	A700		E	1
8A0603	Engine chassis: CAN-Data transfer engine control unit Faulty / interrupted (Tx-warning) Last received value or replacement value 300603: Check cable / plug / CAN-participant	A700		E	1
8A0604	Engine chassis: CAN-Data transfer engine control unit Faulty / interrupted (send -timeout) Last received value or replacement value 300604: Check cable / plug / CAN-participant	A700		E	1
8A0606	Engine chassis: CAN-Data transfer engine control unit Faulty / interrupted (complete transmission data) Last received value or replacement value 300606: Turn ignition off/on, Load new software in engine control unit or replace control unit	A700		E	1
8A0700	Engine chassis: CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded no reaction 300700: Check cable / plug / CAN-participant	A700		E	1
8A0701	Engine chassis: CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded no reaction 300701: Check cable / plug / CAN-participant	A700		E	1
8A0702	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300702: Check cable / plug / CAN-participant	A700		E	1
8A0703	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300703: Check cable / plug / CAN-participant	A700		E	1
8A0704	Engine chassis: CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded no reaction 300704: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0705	Engine chassis: CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded 300705:	A700		E	1
8A0706	Engine chassis: CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded 300706:	A700		E	1
8A0707	Engine chassis: CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded 300707:	A700		E	1
8A0708	Engine chassis: CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded 300708:	A700		E	1
8A0800	Engine chassis: CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded emergency operation 300800: Check cable / plug / CAN-participant	A700		E	1
8A0801	Engine chassis: CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded emergency operation 300801: Check cable / plug / CAN-participant	A700		E	1
8A0802	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300802: Check cable / plug / CAN-participant	A700		E	1
8A0803	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300803: Check cable / plug / CAN-participant	A700		E	1
8A0804	Engine chassis: CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded emergency operation 300804: Check cable / plug / Master	A700		E	1
8A0900	Engine chassis: CAN-Data transfer Aborted (Passive error) Change over to plausible speed source 300900: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0901	Engine chassis: CAN-Data transfer Aborted (BusOff) Change over to plausible speed source 300901: Check cable / plug / CAN-participant	A700		E	1
8A0902	Engine chassis: CAN-Data transfer Faulty / interrupted (Rx-warning) no reaction 300902: Check cable / plug / CAN-participant	A700		E	1
8A0903	Engine chassis: CAN-Data transfer Faulty / interrupted (Tx-warning) no reaction 300903: Check cable / plug / CAN-participant	A700		E	1
8A0904	Engine chassis: CAN-Data transfer Faulty / interrupted (send -timeout) Change over to plausible speed source 300904: Check cable / plug / CAN-participant	A700		E	1
8A0905	Engine chassis: CAN-Data transfer Faulty / interrupted (TSC1) no reaction 300905: Check cable / plug / CAN-participant	A700		E	1
8A0A00	Engine chassis: CAN-Data transfer Aborted (Passive error) Change over to plausible speed source 301000: Check cable / plug / CAN-participant	A700		E	1
8A0A01	Engine chassis: CAN-Data transfer Aborted (BusOff) Change over to plausible speed source 301001: Check cable / plug / CAN-participant	A700		E	1
8A0A02	Engine chassis: CAN-Data transfer Faulty / interrupted (Rx-warning) no reaction 301002: Check cable / plug / CAN-participant	A700		E	1
8A0A03	Engine chassis: CAN-Data transfer Faulty / interrupted (Tx-warning) no reaction 301003: Check cable / plug / CAN-participant	A700		E	1
8A0A04	Engine chassis: CAN-Data transfer Faulty / interrupted (send -timeout) Possibly power reduction 301004: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0A05	Engine chassis: CAN-Data transfer AGR-Module 1 erroneous/maximum cycle time exceeded Possibly power reduction 301005: Check cable / plug / CAN-participant	A700		E	1
8A0A06	Engine chassis: CAN-Data transfer AGR-Module 2 erroneous/maximum cycle time exceeded Possibly power reduction 301006: Check cable / plug / CAN-participant	A700		E	1
8A0A07	Engine chassis: CAN-Data transfer WasteGate-Module 1 erroneous/maximum cycle time exceeded Possibly power reduction 301007: Check cable / plug / CAN-participant	A700		E	1
8A0A08	Engine chassis: CAN-Data transfer WasteGate-Module 2 erroneous/maximum cycle time exceeded Possibly power reduction 301008: Check cable / plug / CAN-participant	A700		E	1
8A0A09	Engine chassis: CAN-Data transfer Restrictor flap module erroneous/maximum cycle time exceeded Possibly power reduction 301009: Check cable / plug / CAN-participant	A700		E	1
8A0A0A	Engine chassis: CAN-Data transfer Tachograph erroneous/maximum cycle time exceeded Change over to plausible speed source 301010: Check cable / plug / CAN-participant	A700		E	1
8A0A0B	Engine chassis: CAN-Data transfer NOx-Lambda sensor up1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301011: Check cable / plug / CAN-participant	A700		E	1
8A0A0C	Engine chassis: CAN-Data transfer NOx-Lambda sensor down1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301012: Check cable / plug / CAN-participant	A700		E	1
8A0A0D	Engine chassis: CAN-Data transfer Mass flow sensor 1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301013: Check cable / plug / CAN-participant	A700		E	1
8A0B00	Engine chassis: CAN-Data transfer Aborted (Passive error) no reaction 301100: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0B01	Engine chassis: CAN-Data transfer Aborted (BusOff) no reaction 301101: Check cable / plug / CAN-participant	A700		E	1
8A0B02	Engine chassis: CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301102: Check cable / plug / CAN-participant	A700		E	1
8A0B03	Engine chassis: CAN-Data transfer Faulty / interrupted (Tx warning) no reaction 301103: Check cable / plug / CAN-participant	A700		E	1
8A0B04	Engine chassis: CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301104: Check cable / plug / CAN-participant check Master-Slave recognition-Pin	A700		E	1
8A0B05	Engine chassis: CAN-Data transfer Faulty / interrupted (Rx timeout) No injection on slave modules will occur 301105: Check cable / plug / CAN-participant / Slave recognition Pin	A700		E	1
8A0B06	Engine chassis: CAN-Data transfer Faulty / interrupted (Tx Send buffer overflow) 301106: Check cable / plug / CAN-participant	A700		E	1
8A0B07	Engine chassis: CAN-Data transfer Internal error, Software slave Module incompatible to master No injection on slave modules will occur 301107: Update slave and master module	A700		E	1
8A0B08	Engine chassis: CAN-Data transfer Internal error, calibration slave Module incompatible to master No injection on slave modules will occur 301108: Update slave and master module	A700		E	1
8A0C00	Engine chassis: CAN-Data transfer Motor CAN 2 HC-dosing unit (PRODPM2) faulty / interrupted Warning light on in operation no regeneration permitted 301200: Check cable / plug / CAN-participant	A700		E	1
8A0C01	Engine chassis: CAN-Data transfer Motor CAN 2 HC-dosing unit (HCDI1) faulty / interrupted Warning light on in operation no regeneration permitted 301201: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0C02	Engine chassis: CAN-Data transfer Motor CAN 2 Mass flow sensor 2 faulty / interrupted Possibly power reduction 301202: Check cable / plug / CAN-participant	A700		E	1
8A0C03	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of mass flow sensor 1 failed Possibly power reduction 301203: Check cable / plug / CAN-participant	A700		E	1
8A0C04	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of mass flow sensor 2 failed Possibly power reduction 301204: Check cable / plug / CAN-participant	A700		E	1
8A0C05	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of Nox-sensors "Up1" failed Possibly power reduction 301205: Check cable / plug / CAN-participant	A700		E	1
8A0C06	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of Nox-sensors "Down1" failed Possibly power reduction 301206: Check cable / plug / CAN-participant	A700		E	1
8A0C07	Engine chassis: CAN-Data transfer Motor CAN 2 Tachograph (Date, time) faulty / interrupted Change over to plausible speed source 301207: Check cable / plug / CAN-participant	A700		E	1
8A0C08	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of "Egr1" failed Power reduction of Diesel engine 301208: Check cable / plug / CAN-participant	A700		E	1
8A0C09	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of "Egr2" failed Power reduction of Diesel engine 301209: Check cable / plug / CAN-participant	A700		E	1
8A0C0A	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of "WG1" failed Power reduction of Diesel engine 301210: Check cable / plug / CAN-participant	A700		E	1
8A0C0B	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of "WG2" failed Power reduction of Diesel engine 301211: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0C0C	Engine chassis: CAN-Data transfer Motor CAN 2 SCR-unit (SCR Sensors) faulty / interrupted Possibly power reduction 301212: Check cable / plug / CAN-participant	A700		E	1
8A0C0D	Engine chassis: CAN-Data transfer Motor CAN 2 Diagnostics of HC-dosing unit failed no reaction 301213: Check cable / plug / CAN-participant	A700		E	1
8A0D00	Engine chassis: CAN-Data transfer Aborted (Passive error) no reaction 301300: Check cable / plug / CAN-participant	A700		E	1
8A0D01	Engine chassis: CAN-Data transfer Aborted (BusOff) no reaction 301301: Check cable / plug / CAN-participant	A700		E	1
8A0D02	Engine chassis: CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301302: Check cable / plug / CAN-participant	A700		E	1
8A0D03	Engine chassis: CAN-Data transfer Faulty / interrupted (Tx warning) no reaction 301303: Check cable / plug / CAN-participant	A700		E	1
8A0D04	Engine chassis: CAN-Data transfer Faulty / interrupted (Rx warning) No injection on Slave modules 301304: Check cable / plug / CAN-participant	A700		E	1
8A0D05	Engine chassis: CAN-Data transfer Incorrect transfer rate recognized No injection on Slave modules 301305: Check cable / plug / CAN-participant / Slave recognition Pin	A700		E	1
8A0D06	Engine chassis: CAN-Data transfer Unexpected messages recognized No injection on Slave modules 301306: Check cable / plug / CAN-participant / Slave recognition Pin	A700		E	1
8A0E00	Engine chassis: CAN-Data transfer Motor CAN 3 SCR-unit (Tank sensors) faulty / interrupted Possibly power reduction 301400: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0E01	Engine chassis: CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, metering status Possibly power reduction 301401: Check cable / plug / CAN-participant	A700		E	1
8A0E02	Engine chassis: CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, metering information Possibly power reduction 301402: Check cable / plug / CAN-participant	A700		E	1
8A0E03	Engine chassis: CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, dew-point recognition "NOxUp1" Possibly power reduction 301403: Check cable / plug / CAN-participant	A700		E	1
8A0E04	Engine chassis: CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, dew-point recognition "NOxDown1" Possibly power reduction 301404: Check cable / plug / CAN-participant	A700		E	1
8A0E05	Engine chassis: CAN-Data transfer Motor CAN 3 Water pump faulty / interrupted (Status report) no reaction 301405: Check cable / plug / CAN-participant	A700		E	1
8A0E06	Engine chassis: CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, diagnostics not possible no reaction 301406: Check cable / plug / CAN-participant	A700		E	1
8A0E07	Engine chassis: CAN-Data transfer Motor CAN 3 Restrictor flap module faulty / interrupted, diagnostics not possible Possibly power reduction 301407: Check cable / plug / CAN-participant	A700		E	1
8A0E08	Engine chassis: CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, Service diagnostics not possible no reaction 301408: Check cable / plug / CAN-participant	A700		E	1
8A0E09	Engine chassis: CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, Service diagnostics not completed 301409:	A700		E	1
8A0E0A	Engine chassis: CAN-Data transfer Motor CAN 3 Nox-Lambda sensor "Up 2" faulty 301410: Check cable / plug / CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A0E0B	Engine chassis: CAN-Data transfer Motor CAN 3 Nox-Lambda sensor "Down 2" faulty 301411: Check cable / plug / CAN-participant	A700		E	1
8A0E0C	Engine chassis: CAN-Data transfer Motor CAN 3 Diagnostics of NOx-Sensor "Up 2" failed 301412: Check cable / plug / CAN-participant	A700		E	1
8A0E0D	Engine chassis: CAN-Data transfer Motor CAN 3 Diagnostics of NOx-Sensor "Down 2" failed 301413: Check cable / plug / CAN-participant	A700		E	1
8A1000	Engine chassis: Engine protection function Excess temperature on exhaust turbine active Performance reduction 301600: Check exhaust system for leaks	A700		E	1
8A1200	Engine chassis: CAN constr. machines, download Memory error flash 0 301800:	A700		E	1
8A1201	Engine chassis: CAN constr. machines, download Memory error flash 0 301801:	A700		E	1
8A1202	Engine chassis: CAN constr. machines, download Memory error flash 0 301802:	A700		E	1
8A1203	Engine chassis: CAN constr. machines, download memory error EEPROM 0 301803:	A700		E	1
8A1204	Engine chassis: CAN constr. machines, download Check sum error 0 301804:	A700		E	1
8A1205	Engine chassis: CAN constr. machines, download Incorrect number of data 0 301805:	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A1206	Engine chassis: CAN constr. machines, download Receive buffer overflow 0 301806:	A700		E	1
8A1207	Engine chassis: CAN constr. machines, download download active 0 301807:	A700		E	1
8A1208	Engine chassis: CAN constr. machines, download unknown area 0 301808:	A700		E	1
8A1300	Engine chassis: Internal error control equipment Stack-overflow Engine cannot be started or engine shut off 301900: Load new software in engine control unit or replace engine control unit	A700		E	1
8A1301	Engine chassis: Internal error control equipment Exception error Engine cannot be started or engine shut off 301901: Load new software in engine control unit or replace engine control unit	A700		E	2
8A1302	Engine chassis: Internal error control equipment Program test Engine cannot be started or engine shut off 301902: Load new software in engine control unit or replace engine control unit	A700		E	2
8A1303	Engine chassis: Internal error control equipment RAM-Test Engine cannot be started or engine shut off 301903: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1304	Engine chassis: Internal error control equipment Overflow in error stack no reaction 301904: Load new software in engine control unit or replace engine control unit	A700		E	1
8A1305	Engine chassis: Internal error control equipment Comp. time error no reaction 301905: Load new software in engine control unit or replace engine control unit	A700		E	2
8A1306	Engine chassis: Internal error control equipment Error-Index too large The error cannot be saved 301906: Load new software in engine control unit or replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A1400	Engine chassis: Control unit defective (memory EEPROM) Error at EEPROM-access Engine cannot be started or engine shut off 302000: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1401	Engine chassis: Control unit defective (memory EEPROM) Check sum error Parameter memory Engine cannot be started or engine shut off 302001: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1402	Engine chassis: Control unit defective (memory EEPROM) Parameter memory in EEPROM is invalid Engine cannot be started or engine shut off 302002: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1403	Engine chassis: Control unit defective (memory EEPROM) Check sum error ECU-Page No reaction - possibly data sets or operating conditions could not be saved 302003: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A1404	Engine chassis: Control unit defective (memory EEPROM) Check sum error NMI-Page No reaction - possibly data sets or operating conditions could not be saved 302004: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A1405	Engine chassis: Control unit defective (memory EEPROM) Check sum error Workdata-Page No reaction - possibly data sets or operating conditions could not be saved 302005: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A1406	Engine chassis: Control unit defective (memory EEPROM) Check sum error load collective No reaction - possibly load collective data could not be saved 302006: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A1407	Engine chassis: Control unit defective (memory EEPROM) Structure size of load collective has changed No reaction - possibly load collective data could not be saved 302007: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A1408	Engine chassis: Control unit defective (memory EEPROM) EEPROM-Memory full (load collective) No reaction - possibly load collective data could not be saved 302008: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A1409	Engine chassis: Control unit defective (memory EEPROM) Check sum error permanent Data No reaction - possibly data sets or operating conditions could not be saved 302009: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A140A	Engine chassis: Control unit defective (memory EEPROM) EEPROM Data inconsistent No reaction - possibly data sets or operating conditions could not be saved 302010: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A140B	Engine chassis: Control unit defective (memory EEPROM) Check sum error OBD-Page No reaction - possibly data sets or operating conditions could not be saved 302011: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A140C	Engine chassis: Control unit defective (memory EEPROM) Check sum error EEPROM-areas No reaction - possibly data sets or operating conditions could not be saved 302012: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8A1500	Engine chassis: Power supply voltage below required value Engine cannot be started or engine shut off 302100: Check on board network (battery, alternator, wiring, plug)	A700		E	2
8A1501	Engine chassis: Power supply excess voltage Engine cannot be started or engine shut off 302101: Check on board network (battery, alternator, wiring, plug)	A700		E	2
8A1502	Engine chassis: Power supply Digital outlet short circuit after supply voltage Engine shut off 302102: Check wiring, engine control unit, possibly replace engine control unit	A700		E	2
8A1503	Engine chassis: Power supply Error release output outlets Engine shut off, shut off of all digital outlets 302103: Check wiring, engine control unit, possibly replace engine control unit	A700		E	2
8A1504	Engine chassis: Power supply PS1-Pin erroneous/missing Engine cannot be started or engine shut off 302104: Check on board network in ref. to PS1 (terminal 30/31), engine control unit	A700		E	2
8A1505	Engine chassis: Power supply Reference voltage 12V below permissible range Engine shut off 302105: Check supply voltage Rpm sensors, on board network, engine control unit	A700		E	2
8A1506	Engine chassis: Power supply Reference voltage 12V above permissible range Engine shut off 302106: Check supply voltage Rpm sensors, on board network, engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A1600	Engine chassis: Configuration error Fan control cooler The fan control is deactivated. Resulting in maximum vent position 302200: Load new software in engine control unit	A700		E	2
8A1601	Engine chassis: Configuration error Offset to full load curve The matching of the performance curve is internally limited 302201: Load new software in engine control unit	A700		E	2
8A1602	Engine chassis: Configuration error Monitoring Pedal unit Pedal unit is not monitored 302202: Load new software in engine control unit	A700		E	2
8A1603	Engine chassis: Configuration error Incorrect pump code Replacement value is used 302203: Check pump coding and change (via diagnostics or resp. diagnostics tool)	A700		E	2
8A1604	Engine chassis: Configuration error Incorrect assignment of high pressure sensors no reaction 302204: Load new software in engine control unit	A700		E	2
8A1605	Engine chassis: Configuration error No high pr. pump activated no reaction 302205: Load new software in engine control unit	A700		E	2
8A1606	Engine chassis: Configuration error Current output for VCV 1 not active no reaction 302206: Load new software in engine control unit	A700		E	2
8A1607	Engine chassis: Configuration error Current output for VCV 2 not active no reaction 302207: Load new software in engine control unit	A700		E	2
8A1608	Engine chassis: Configuration error CAN-messages no reaction 302208: Load new software in engine control unit	A700		E	2
8A1609	Engine chassis: Configuration error CAN-transfer rate no reaction 302209: Load new software in engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A160A	Engine chassis: Configuration error Incorrect assignment of analog sensor no reaction 302210: Load new software in engine control unit	A700		E	2
8A160B	Engine chassis: Configuration error Incorrect assignment switch no reaction 302211:	A700		E	2
8A160C	Engine chassis: Configuration error Motor configuration erroneous/missing Engine cannot be started or engine shut off 302212: Load new software in engine control unit	A700		E	2
8A160D	Engine chassis: Configuration error Parameterization actuator invalid Power reduction of Diesel engine 302213: Load new software in engine control unit	A700		E	2
8A1700	Engine chassis: Configuration error Component ID of SCR-unit incorrect 302300:	A700		E	2
8A1701	Engine chassis: Configuration error Component ID of HC-metering unit incorrect The matching of the performance curve is internally limited 302201: Load new software in engine control unit	A700		E	1
8A1702	Engine chassis: Configuration error Component ID of restrictor flap incorrect Pedal unit is not monitored 302202: Load new software in engine control unit	A700		E	1
8A1703	Engine chassis: Configuration error Current output for PCV1 not active Replacement value is used 302203: Check pump coding and change (via diagnostics or resp. diagnostics tool)	A700		E	1
8A1704	Engine chassis: Configuration error Current output for PCV2 not active no reaction 302204: Load new software in engine control unit	A700		E	1
8A1800	Engine chassis: Configuration error Fan control cooler 302400:	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A1900	Engine chassis: Control unit defective (FLASH-memory) Check sum error Parameter memory Engine cannot be started or engine shut off 302500: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1901	Engine chassis: Control unit defective (FLASH-memory) Invalid data, default values are used Engine cannot be started or engine shut off 302501: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1902	Engine chassis: Control unit defective (FLASH-memory) Error during delete Engine cannot be started or engine shut off 302502: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1903	Engine chassis: Control unit defective (FLASH-memory) Error during programming Engine cannot be started or engine shut off 302503: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1904	Engine chassis: Control unit defective (FLASH-memory) Error during check Engine cannot be started or engine shut off 302504: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1905	Engine chassis: Control unit defective (FLASH-memory) Data inconsistent Engine cannot be started or engine shut off 302505: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	2
8A1A00	Engine chassis: Internal error control equipment Program error Engine shut off 302600: Program update to newest software version	A700		E	2
8A1A01	Engine chassis: Internal error control equipment Program error Engine shut off 302601: Program update to newest software version	A700		E	2
8A1A02	Engine chassis: Internal error control equipment Program error Engine shut off 302602: Program update to newest software version	A700		E	2
8A1A03	Engine chassis: Internal error control equipment Program error Engine shut off 302603: Program update to newest software version	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A1A04	Engine chassis: Internal error control equipment Program error Engine shut off 302604: Program update to newest software version	A700		E	2
8A1A05	Engine chassis: Internal error control equipment Program error Engine shut off 302605: Program update to newest software version	A700		E	2
8A1A06	Engine chassis: Internal error control equipment Program error Engine shut off 302606: Program Update to newest software bersion	A700		E	2
8A1B00	Engine chassis: Speed recording Maximum difference travel speed Tacho<->Gear exceeded The larger speed value is used 302700: Check gear and tachograph	A700		E	1
8A1C00	Engine chassis: Actuation engine brake Broken wire or Short circuit after ground Engine brake flap is not actuated 302800: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C01	Engine chassis: Actuation engine brake Broken wire or short circuit after supply voltage Engine brake flap is not actuated 302801: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C02	Engine chassis: Actuation engine brake Hardware error (control unit defective) Engine brake flap is not actuated 302802: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C03	Engine chassis: Actuation engine brake Maximum signal difference to actuation exceeded Engine brake flap is not actuated 302803: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C04	Engine chassis: Actuation engine brake Maximum signal difference to actuation exceeded Engine brake flap is not actuated 302804: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C05	Engine chassis: Actuation engine brake Current measured without actuation Engine brake flap is not actuated 302805: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A1C06	Engine chassis: Actuation engine brake Current too low in actuated state Engine brake flap is not actuated 302806: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C07	Engine chassis: Actuation engine brake Current too high in actuated state Engine brake flap is not actuated 302807: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C08	Engine chassis: Actuation engine brake Ground switch overcurrent Engine brake flap is not actuated 302808: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C09	Engine chassis: Actuation engine brake Plus switch overcurrent Engine brake flap is not actuated 302809: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1C0A	Engine chassis: Actuation engine brake Maximum analog value exceeded (PWM) Engine brake flap is not actuated 302810: Check wiring harness, plug, engine brake flap, engine control unit	A700		E	1
8A1D00	Engine chassis: Alternator Charge control D+ of mass flow sensor no reaction 302900: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A700		E	1
8A1D01	Engine chassis: Alternator Charge control D+ Overvoltage at engine off no reaction 302901: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A700		E	1
8A1D02	Engine chassis: Alternator Charge control D+ undervoltage at engine on no reaction 302902: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A700		E	1
8A1D03	Engine chassis: Alternator Charge control D+ overvoltage at engine on no reaction 302903: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A700		E	1
8A1D04	Engine chassis: Alternator Charge control D+ voltage deviation to on board current too low no reaction 302904: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A1D05	Engine chassis: Alternator Charge control D+ voltage deviation to on board current too high no reaction 302905: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A700		E	1
8A1D06	Engine chassis: Alternator Implausibility at test of on board voltage Battery charge voltage regulated to 28.5V 302906: Check inputs of alternator	A700		E	0
8A1E00	Engine chassis: Alternator 2 Charge control D+ of mass flow sensor no reaction 303000: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A700		E	1
8A1E01	Engine chassis: Alternator 2 Charge control D+ Overvoltage at engine off no reaction 303001: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A700		E	1
8A1E02	Engine chassis: Alternator 2 Charge control D+ undervoltage at engine on no reaction 303002: wiring engine control unit to alternator (D+), check alternator and V-belt	A700		E	1
8A1E03	Engine chassis: Alternator 2 Charge control D+ overvoltage at engine on no reaction 303003: Check wiring engine control unit to alternator (D+), alternator and V-belt	A700		E	1
8A1E04	Engine chassis: Alternator 2 Charge control D+ voltage deviation to on board current too low no reaction 303004: Check wiring alternator (D+) to battery or to engine control unit, alternator	A700		E	1
8A1E05	Engine chassis: Alternator 2 Charge control D+ voltage deviation to on board current too high no reaction 303005: Check wiring alternator (D+) to battery or to engine control unit , alternator	A700		E	1
8A1F00	Engine chassis: Travel pedal No gas switch erroneous Use low value 303100: Check wiring engine control unit to travel pedal, check travel pedal, replace	A700		E	1
8A1F01	Engine chassis: Travel pedal maximum signal difference channel 1 and 2 exceeded Use low value 303101: Check wiring engine control unit to travel pedal, check travel pedal, replace	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2000	Engine chassis: Plausibility error Charge pressure to atmospheric pressure no reaction 303200: Replace sensor, check intake system for leaks	A700		E	0
8A2100	Engine chassis: Error in Rail pr. system Pressure relief valve 1 has been actuated High pressure regulation emergency operation activated 303300: Check engine Stop/start, Rail circuit, Test unit, wiring Test unit, Rail pr. sensor	A700		E	2
8A2101	Engine chassis: Error in Rail pr. system Pressure relief valve 2 has been actuated High pressure regulation emergency operation activated 303301: Check engine Stop/start, Rail circuit, Test unit, wiring Test unit, Rail pr. sensor	A700		E	2
8A2102	Engine chassis: Error in Rail pr. system Emerg. op. high pr. regulation activated Power reduction, high pressure pump control turned off 303302: Check rail circuit 1/2, Check wiring harness, plug	A700		E	2
8A2103	Engine chassis: Error in Rail pr. system Maximum pressure deviation high pr. sensor 1 and 2 exceeded No reaction on engine, the larger of the high pressure sensor values is used 303303: Check wiring harness, plug, rail pr. sensors, check rail circuit 1/2	A700		E	1
8A2104	Engine chassis: Error in Rail pr. system CR-regulating circuit 1 too large deviation (positive) no reaction 303304: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	2
8A2105	Engine chassis: Error in Rail pr. system CR-regulating circuit 2 too large deviation (positive) no reaction 303305: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	2
8A2106	Engine chassis: Error in Rail pr. system CR-regulating circuit 1 too large deviation (negative) no reaction 303306: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	2
8A2107	Engine chassis: Error in Rail pr. system CR-regulating circuit 2 too large deviation (negative) no reaction 303307: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	2
8A2108	Engine chassis: Error in Rail pr. system CR-regulating circuit 1 has leakage no reaction 303308: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2109	Engine chassis: Error in Rail pr. system CR-regulating circuit 2 has leakage no reaction 303309: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	2
8A210A	Engine chassis: Error in Rail pr. system VCV Plausibility error Pump 1 High pressure regulation emergency operation activated 303310: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	1
8A210B	Engine chassis: Error in Rail pr. system VCV Plausibility error Pump 2 303311: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	0
8A210C	Engine chassis: Error in Rail pr. system common-rail regulating circuit 1 has leakage (CRS-System) no reaction 303312: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	1
8A210D	Engine chassis: Error in Rail pr. system common-rail regulating circuit 2 has leakage (CRS-System) no reaction 303313: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	1
8A2200	Engine chassis: Current outlet 1 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303400: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2201	Engine chassis: Current outlet 1 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303401: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2202	Engine chassis: Current outlet 1 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303402: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2203	Engine chassis: Current outlet 1 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303403: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2204	Engine chassis: Current outlet 1 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303404: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2205	Engine chassis: Current outlet 1 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303405: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2206	Engine chassis: Current outlet 1 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303406: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2207	Engine chassis: Current outlet 1 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303407: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2208	Engine chassis: Current outlet 1 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303408: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2209	Engine chassis: Current outlet 1 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303409: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A220A	Engine chassis: Current outlet 1 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303410: Check wiring harness, plug, CR-components1, engine control unit	A700		E	2
8A2300	Engine chassis: Current outlet 2 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303500: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2301	Engine chassis: Current outlet 2 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303501: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2302	Engine chassis: Current outlet 2 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303502: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2303	Engine chassis: Current outlet 2 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303503: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2304	Engine chassis: Current outlet 2 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303504: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2305	Engine chassis: Current outlet 2 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303505: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2306	Engine chassis: Current outlet 2 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303506: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2307	Engine chassis: Current outlet 2 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303507: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2308	Engine chassis: Current outlet 2 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303508: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2309	Engine chassis: Current outlet 2 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303509: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A230A	Engine chassis: Current outlet 2 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303510: Check wiring harness, plug, CR-components2, engine control unit	A700		E	2
8A2400	Engine chassis: Current outlet 3 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303600: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2
8A2401	Engine chassis: Current outlet 3 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303601: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2
8A2402	Engine chassis: Current outlet 3 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303602: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2403	Engine chassis: Current outlet 3 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303603: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2
8A2404	Engine chassis: Current outlet 3 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303604: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2
8A2405	Engine chassis: Current outlet 3 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303605: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2
8A2406	Engine chassis: Current outlet 3 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303606: Check wiring harness, plug, CR-comp.3, engine control unit	A700		E	2
8A2407	Engine chassis: Current outlet 3 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303607: Check wiring harness, plug, CR-comp.3, engine control unit	A700		E	2
8A2408	Engine chassis: Current outlet 3 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303608: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2
8A2409	Engine chassis: Current outlet 3 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303609: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2
8A240A	Engine chassis: Current outlet 3 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303610: Check wiring harness, plug, CR-components3, engine control unit	A700		E	2
8A2500	Engine chassis: Current outlet 4 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303700: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2501	Engine chassis: Current outlet 4 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303701: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2502	Engine chassis: Current outlet 4 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303702: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2503	Engine chassis: Current outlet 4 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303703: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2504	Engine chassis: Current outlet 4 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303704: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2505	Engine chassis: Current outlet 4 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303705: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2506	Engine chassis: Current outlet 4 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303706: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2507	Engine chassis: Current outlet 4 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303707: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2508	Engine chassis: Current outlet 4 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303708: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2509	Engine chassis: Current outlet 4 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303709: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A250A	Engine chassis: Current outlet 4 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303710: Check wiring harness, plug, CR-components4, engine control unit	A700		E	2
8A2600	Engine chassis: Actuation Starter Broken wire or Short circuit after ground Engine start not possible 303800: Check wiring harness, plug, Starter, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2601	Engine chassis: Actuation Starter Broken wire or short circuit after supply voltage Engine start not possible 303801: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A2602	Engine chassis: Actuation Starter Hardware error (control unit defective) Engine start not possible 303802: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A2603	Engine chassis: Actuation Starter Maximum signal difference to actuation exceeded no reaction 303803: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A2604	Engine chassis: Actuation Starter Maximum signal difference to actuation exceeded no reaction 303804: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A2605	Engine chassis: Actuation Starter Current measured without actuation no reaction 303805: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A2606	Engine chassis: Actuation Starter Current too low in actuated state no reaction 303806: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A2607	Engine chassis: Actuation Starter Current too high in actuated state no reaction 303807: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A2608	Engine chassis: Actuation Starter Ground switch overcurrent no reaction 303808: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A2609	Engine chassis: Actuation Starter Plus switch overcurrent no reaction 303809: Check wiring harness, plug, Starter, engine control unit	A700		E	1
8A260A	Engine chassis: Actuation Starter Maximum analog value exceeded (PWM) no reaction 303810: Check wiring harness, plug, Starter, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2700	Engine chassis: Actuation fan 1 cooling Broken wire or Short circuit after ground no reaction 303900: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2701	Engine chassis: Actuation fan 1 cooling Broken wire or short circuit after supply voltage no reaction 303901: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2702	Engine chassis: Actuation fan 1 cooling Hardware error (control unit defective) no reaction 303902: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2703	Engine chassis: Actuation fan 1 cooling Maximum signal difference to actuation exceeded no reaction 303903: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2704	Engine chassis: Actuation fan 1 cooling Maximum signal difference to actuation exceeded no reaction 303904: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2705	Engine chassis: Actuation fan 1 cooling Current measured without actuation no reaction 303905: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2706	Engine chassis: Actuation fan 1 cooling Current too low in actuated state no reaction 303906: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2707	Engine chassis: Actuation fan 1 cooling Current too high in actuated state no reaction 303907: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2708	Engine chassis: Actuation fan 1 cooling Ground switch overcurrent no reaction 303908: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2709	Engine chassis: Actuation fan 1 cooling Plus switch overcurrent no reaction 303909: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A270A	Engine chassis: Actuation fan 1 cooling Maximum analog value exceeded (PWM) no reaction 303910: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2800	Engine chassis: Actuation fan 2 cooling Broken wire or Short circuit after ground no reaction 304000: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2801	Engine chassis: Actuation fan 2 cooling Broken wire or short circuit after supply voltage no reaction 304001: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2802	Engine chassis: Actuation fan 2 cooling Hardware error (control unit defective) no reaction 304002: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2803	Engine chassis: Actuation fan 2 cooling Maximum signal difference to actuation exceeded no reaction 304003: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2804	Engine chassis: Actuation fan 2 cooling Maximum signal difference to actuation exceeded no reaction 304004: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2805	Engine chassis: Actuation fan 2 cooling Current measured without actuation no reaction 304005: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2806	Engine chassis: Actuation fan 2 cooling Current too low in actuated state no reaction 304006: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2807	Engine chassis: Actuation fan 2 cooling Current too high in actuated state no reaction 304007: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2808	Engine chassis: Actuation fan 2 cooling Ground switch overcurrent no reaction 304008: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2809	Engine chassis: Actuation fan 2 cooling Plus switch overcurrent no reaction 304009: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A280A	Engine chassis: Actuation fan 2 cooling Maximum analog value exceeded (PWM) no reaction 304010: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2900	Engine chassis: Actuation fan 1 inverted cooling Broken wire or Short circuit after ground no reaction 304100: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2901	Engine chassis: Actuation fan 1 inverted cooling Broken wire or short circuit after supply voltage no reaction 304101: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2902	Engine chassis: Actuation fan 1 inverted cooling Hardware error (control unit defective) no reaction 304102: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2903	Engine chassis: Actuation fan 1 inverted cooling Maximum signal difference to actuation exceeded no reaction 304103: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2904	Engine chassis: Actuation fan 1 inverted cooling Maximum signal difference to actuation exceeded no reaction 304104: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2905	Engine chassis: Actuation fan 1 inverted cooling Current measured without actuation no reaction 304105: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2906	Engine chassis: Actuation fan 1 inverted cooling Current too low in actuated state no reaction 304106: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2907	Engine chassis: Actuation fan 1 inverted cooling Current too high in actuated state no reaction 304107: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2908	Engine chassis: Actuation fan 1 inverted cooling Ground switch overcurrent no reaction 304108: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2909	Engine chassis: Actuation fan 1 inverted cooling Plus switch overcurrent no reaction 304109: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A290A	Engine chassis: Actuation fan 1 inverted cooling Maximum analog value exceeded (PWM) no reaction 304110: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A00	Engine chassis: Actuation fan 2 inverted cooling Broken wire or Short circuit after ground no reaction 304200: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A01	Engine chassis: Actuation fan 2 inverted cooling Broken wire or short circuit after supply voltage no reaction 304201: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A02	Engine chassis: Actuation fan 2 inverted cooling Hardware error (control unit defective) no reaction 304202: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A03	Engine chassis: Actuation fan 2 inverted cooling Maximum signal difference to actuation exceeded no reaction 304203: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A04	Engine chassis: Actuation fan 2 inverted cooling Maximum signal difference to actuation exceeded no reaction 304204: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A05	Engine chassis: Actuation fan 2 inverted cooling Current measured without actuation no reaction 304205: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A06	Engine chassis: Actuation fan 2 inverted cooling Current too low in actuated state no reaction 304206: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2A07	Engine chassis: Actuation fan 2 inverted cooling Current too high in actuated state no reaction 304207: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A08	Engine chassis: Actuation fan 2 inverted cooling Ground switch overcurrent no reaction 304208: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A09	Engine chassis: Actuation fan 2 inverted cooling Plus switch overcurrent no reaction 304209: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2A0A	Engine chassis: Actuation fan 2 inverted cooling Maximum analog value exceeded (PWM) no reaction 304210: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A2B00	Engine chassis: Actuation Heat flange / Flame start Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304300: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B01	Engine chassis: Actuation Heat flange / Flame start Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304301: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B02	Engine chassis: Actuation Heat flange / Flame start Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304302: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B03	Engine chassis: Actuation Heat flange / Flame start Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304303: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B04	Engine chassis: Actuation Heat flange / Flame start Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304304: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B05	Engine chassis: Actuation Heat flange / Flame start Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304305: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2B06	Engine chassis: Actuation Heat flange / Flame start Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304306: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B07	Engine chassis: Actuation Heat flange / Flame start Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304307: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B08	Engine chassis: Actuation Heat flange / Flame start Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304308: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B09	Engine chassis: Actuation Heat flange / Flame start Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304309: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B0A	Engine chassis: Actuation Heat flange / Flame start Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304310: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B0B	Engine chassis: Actuation Heat flange / Flame start No voltage measured on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304311: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2B0C	Engine chassis: Actuation Heat flange / Flame start Voltage error on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304312: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C00	Engine chassis: Actuation Heat flange / Flame start 2 Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304400: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C01	Engine chassis: Actuation Heat flange / Flame start 2 Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304401: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C02	Engine chassis: Actuation Heat flange / Flame start 2 Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304402: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2C03	Engine chassis: Actuation Heat flange / Flame start 2 Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304403: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C04	Engine chassis: Actuation Heat flange / Flame start 2 Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304404: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C05	Engine chassis: Actuation Heat flange / Flame start 2 Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304405: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C06	Engine chassis: Actuation Heat flange / Flame start 2 Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304406: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C07	Engine chassis: Actuation Heat flange / Flame start 2 Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304407: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C08	Engine chassis: Actuation Heat flange / Flame start 2 Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304408: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C09	Engine chassis: Actuation Heat flange / Flame start 2 Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304409: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C0A	Engine chassis: Actuation Heat flange / Flame start 2 Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304410: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C0B	Engine chassis: Actuation Heat flange / Flame start 2 No voltage measured on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304411: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2C0C	Engine chassis: Actuation Heat flange / Flame start 2 Voltage error on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304412: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2D00	Engine chassis: Actuation Solenoid valve Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304500: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D01	Engine chassis: Actuation Solenoid valve Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304501: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D02	Engine chassis: Actuation Solenoid valve Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304502: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D03	Engine chassis: Actuation Solenoid valve Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304503: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D04	Engine chassis: Actuation Solenoid valve Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304504: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D05	Engine chassis: Actuation Solenoid valve Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304505: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D06	Engine chassis: Actuation Solenoid valve Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304506: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D07	Engine chassis: Actuation Solenoid valve Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304507: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D08	Engine chassis: Actuation Solenoid valve Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304508: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2D09	Engine chassis: Actuation Solenoid valve Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304509: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2D0A	Engine chassis: Actuation Solenoid valve Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304510: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A700		E	1
8A2E00	Engine chassis: Actuation Air flap Broken wire or Short circuit after ground no reaction 304600: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E01	Engine chassis: Actuation Air flap Broken wire or short circuit after supply voltage no reaction 304601: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E02	Engine chassis: Actuation Air flap Hardware error (control unit defective) no reaction 304602: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E03	Engine chassis: Actuation Air flap Maximum signal difference to actuation exceeded no reaction 304603: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E04	Engine chassis: Actuation Air flap Maximum signal difference to actuation exceeded no reaction 304604: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E05	Engine chassis: Actuation Air flap Current measured without actuation no reaction 304605: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E06	Engine chassis: Actuation Air flap Current too low in actuated state no reaction 304606: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E07	Engine chassis: Actuation Air flap Current too high in actuated state no reaction 304607: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E08	Engine chassis: Actuation Air flap Ground switch overcurrent no reaction 304608: Check wiring harness, plug, air flap, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2E09	Engine chassis: Actuation Air flap Plus switch overcurrent no reaction 304609: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2E0A	Engine chassis: Actuation Air flap Maximum analog value exceeded (PWM) no reaction 304610: Check wiring harness, plug, air flap, engine control unit	A700		E	1
8A2F00	Engine chassis: Actuation Turbocharger Broken wire or Short circuit after ground No reaction, change over to OL 304700: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F01	Engine chassis: Actuation Turbocharger Broken wire or short circuit after supply voltage No reaction, change over to OL 304701: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F02	Engine chassis: Actuation Turbocharger Hardware error (control unit defective) No reaction, change over to OL 304702: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F03	Engine chassis: Actuation Turbocharger Maximum signal difference to actuation exceeded No reaction, change over to OL 304703: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F04	Engine chassis: Actuation Turbocharger Maximum signal difference to actuation exceeded No reaction, change over to OL 304704: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F05	Engine chassis: Actuation Turbocharger Current measured without actuation No reaction, change over to OL 304705: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F06	Engine chassis: Actuation Turbocharger Current too low in actuated state No reaction, change over to OL 304706: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F07	Engine chassis: Actuation Turbocharger Current too high in actuated state No reaction, change over to OL 304707: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A2F08	Engine chassis: Actuation Turbocharger Ground switch overcurrent No reaction, change over to OL 304708: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F09	Engine chassis: Actuation Turbocharger Plus switch overcurrent No reaction, change over to OL 304709: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A2F0A	Engine chassis: Actuation Turbocharger Maximum analog value exceeded (PWM) No reaction, change over to OL 304710: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3000	Engine chassis: Actuation Turbocharger 2 Broken wire or Short circuit after ground No reaction, change over to OL 304800: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3001	Engine chassis: Actuation Turbocharger 2 Broken wire or short circuit after supply voltage No reaction, change over to OL 304801: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3002	Engine chassis: Actuation Turbocharger 2 Hardware error (control unit defective) No reaction, change over to OL 304802: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3003	Engine chassis: Actuation Turbocharger 2 Maximum signal difference to actuation exceeded No reaction, change over to OL 304803: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3004	Engine chassis: Actuation Turbocharger 2 Maximum signal difference to actuation exceeded No reaction, change over to OL 304804: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3005	Engine chassis: Actuation Turbocharger 2 Current measured without actuation No reaction, change over to OL 304805: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3006	Engine chassis: Actuation Turbocharger 2 Current too low in actuated state No reaction, change over to OL 304806: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3007	Engine chassis: Actuation Turbocharger 2 Current too high in actuated state No reaction, change over to OL 304807: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3008	Engine chassis: Actuation Turbocharger 2 Ground switch overcurrent No reaction, change over to OL 304808: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3009	Engine chassis: Actuation Turbocharger 2 Plus switch overcurrent No reaction, change over to OL 304809: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A300A	Engine chassis: Actuation Turbocharger 2 Maximum analog value exceeded (PWM) No reaction, change over to OL 304810: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A700		E	1
8A3100	Engine chassis: Actuation AGR 1 Broken wire or Short circuit after ground Function engine brake flap deactivated 304900: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A3101	Engine chassis: Actuation AGR 1 Broken wire or short circuit after supply voltage Function engine brake flap deactivated 304901: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A3102	Engine chassis: Actuation AGR 1 Hardware error (control unit defective) Function engine brake flap deactivated 304902: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A3103	Engine chassis: Actuation AGR 1 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 304903: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A3104	Engine chassis: Actuation AGR 1 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 304904: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A3105	Engine chassis: Actuation AGR 1 Current measured without actuation Function engine brake flap deactivated 304905: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3106	Engine chassis: Actuation AGR 1 Current too low in actuated state Function engine brake flap deactivated 304906: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A3107	Engine chassis: Actuation AGR 1 Current too high in actuated state Function engine brake flap deactivated 304907: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A310B	Engine chassis: Actuation AGR 1 Deviation error, AGR open too wide Function engine brake flap deactivated 304911: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A310C	Engine chassis: Actuation AGR 1 Deviation error, AGR open too little Function engine brake flap deactivated 304912: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A310D	Engine chassis: Actuation AGR 1 Error in CAN-Module AGR Function engine brake flap deactivated 304913: Check wiring harness, plug, AGR1-valve, engine control unit	A700		E	1
8A3200	Engine chassis: Actuation AGR 2 Broken wire or Short circuit after ground Function engine brake flap deactivated 305000: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A3201	Engine chassis: Actuation AGR 2 Broken wire or short circuit after supply voltage Function engine brake flap deactivated 305001: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A3202	Engine chassis: Actuation AGR 2 Hardware error (control unit defective) Function engine brake flap deactivated 305002: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A3203	Engine chassis: Actuation AGR 2 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 305003: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A3204	Engine chassis: Actuation AGR 2 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 305004: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3205	Engine chassis: Actuation AGR 2 Current measured without actuation Function engine brake flap deactivated 305005: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A3206	Engine chassis: Actuation AGR 2 Current too low in actuated state Function engine brake flap deactivated 305006: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A3207	Engine chassis: Actuation AGR 2 Current too high in actuated state Function engine brake flap deactivated 305007: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A320B	Engine chassis: Actuation AGR 2 Deviation error, AGR open too wide Function engine brake flap deactivated 305011: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A320C	Engine chassis: Actuation AGR 2 Deviation error, AGR open too little Function engine brake flap deactivated 305012: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A320D	Engine chassis: Actuation AGR 2 Error in CAN-Module AGR Function engine brake flap deactivated 305013: Check wiring harness, plug, AGR2-valve, engine control unit	A700		E	1
8A3300	Engine chassis: Lamp emerg. oper Broken wire or Short circuit after ground No reaction, status is not shown 305100: Check wiring	A700		E	1
8A3301	Engine chassis: Lamp emerg. oper Broken wire or short circuit after supply voltage No reaction, status is not shown 305101: Check wiring	A700		E	1
8A3302	Engine chassis: Lamp emerg. oper Hardware error (control unit defective) No reaction, status is not shown 305102: Check wiring	A700		E	1
8A3303	Engine chassis: Lamp emerg. oper Maximum signal difference to actuation exceeded No reaction, status is not shown 305103: Check wiring	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3304	Engine chassis: Lamp emerg. oper Maximum signal difference to actuation exceeded No reaction, status is not shown 305104: Check wiring	A700		E	1
8A3305	Engine chassis: Lamp emerg. oper Current measured without actuation No reaction, status is not shown 305105: Check wiring	A700		E	1
8A3306	Engine chassis: Lamp emerg. oper Current too low in actuated state No reaction, status is not shown 305106: Check wiring	A700		E	1
8A3307	Engine chassis: Lamp emerg. oper Current too high in actuated state No reaction, status is not shown 305107: Check wiring	A700		E	1
8A3308	Engine chassis: Lamp emerg. oper Ground switch overcurrent No reaction, status is not shown 305108: Check wiring	A700		E	1
8A3309	Engine chassis: Lamp emerg. oper Plus switch overcurrent No reaction, status is not shown 305109: Check wiring	A700		E	1
8A330A	Engine chassis: Lamp emerg. oper Maximum analog value exceeded (PWM) No reaction, status is not shown 305110: Check wiring	A700		E	1
8A3400	Engine chassis: Lamp cold start / Start readiness Broken wire or Short circuit after ground No reaction, status is not shown 305200: Check wiring	A700		E	1
8A3401	Engine chassis: Lamp cold start / Start readiness Broken wire or short circuit after supply voltage No reaction, status is not shown 305201: Check wiring	A700		E	1
8A3402	Engine chassis: Lamp cold start / Start readiness Hardware error (control unit defective) No reaction, status is not shown 305202: Check wiring	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3403	Engine chassis: Lamp cold start / Start readiness Maximum signal difference to actuation exceeded No reaction, status is not shown 305203: Check wiring	A700		E	1
8A3404	Engine chassis: Lamp cold start / Start readiness Maximum signal difference to actuation exceeded No reaction, status is not shown 305204: Check wiring	A700		E	1
8A3405	Engine chassis: Lamp cold start / Start readiness Current measured without actuation No reaction, status is not shown 305205: Check wiring	A700		E	1
8A3406	Engine chassis: Lamp cold start / Start readiness Current too low in actuated state No reaction, status is not shown 305206: Check wiring	A700		E	1
8A3407	Engine chassis: Lamp cold start / Start readiness Current too high in actuated state No reaction, status is not shown 305207: Check wiring	A700		E	1
8A3408	Engine chassis: Lamp cold start / Start readiness Ground switch overcurrent No reaction, status is not shown 305208: Check wiring	A700		E	1
8A3409	Engine chassis: Lamp cold start / Start readiness Plus switch overcurrent No reaction, status is not shown 305209: Check wiring	A700		E	1
8A340A	Engine chassis: Lamp cold start / Start readiness Maximum analog value exceeded (PWM) No reaction, status is not shown 305210: Check wiring	A700		E	1
8A3500	Engine chassis: Request engine stop Broken wire or Short circuit after ground No reaction, status is not shown 305300: Check wiring	A700		E	1
8A3501	Engine chassis: Request engine stop Broken wire or short circuit after supply voltage No reaction, status is not shown 305301: Check wiring	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3502	Engine chassis: Request engine stop Hardware error (control unit defective) No reaction, status is not shown 305302: Check wiring	A700		E	1
8A3503	Engine chassis: Request engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305303: Check wiring	A700		E	1
8A3504	Engine chassis: Request engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305304: Check wiring	A700		E	1
8A3505	Engine chassis: Request engine stop Current measured without actuation 305305: Check wiring	A700		E	1
8A3506	Engine chassis: Request engine stop Current too low in actuated state No reaction, status is not shown 305306: Check wiring	A700		E	1
8A3507	Engine chassis: Request engine stop Current too high in actuated state No reaction, status is not shown 305307: Check wiring	A700		E	1
8A3508	Engine chassis: Request engine stop Ground switch overcurrent No reaction, status is not shown 305308: Check wiring	A700		E	1
8A3509	Engine chassis: Request engine stop Plus switch overcurrent No reaction, status is not shown 305309: Check wiring	A700		E	1
8A350A	Engine chassis: Request engine stop Maximum analog value exceeded (PWM) No reaction, status is not shown 305310: Check wiring	A700		E	1
8A3600	Engine chassis: Outlet engine running Broken wire or Short circuit after ground No reaction, status is not shown 305400: Check wiring	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3601	Engine chassis: Outlet engine running Broken wire or short circuit after supply voltage No reaction, status is not shown 305401: Check wiring	A700		E	1
8A3602	Engine chassis: Outlet engine running Hardware error (control unit defective) No reaction, status is not shown 305402: Check wiring	A700		E	1
8A3603	Engine chassis: Outlet engine running Maximum signal difference to actuation exceeded No reaction, status is not shown 305403: Check wiring	A700		E	1
8A3604	Engine chassis: Outlet engine running Maximum signal difference to actuation exceeded No reaction, status is not shown 305404: Check wiring	A700		E	1
8A3605	Engine chassis: Outlet engine running Current measured without actuation No reaction, status is not shown 305405: Check wiring	A700		E	1
8A3606	Engine chassis: Outlet engine running Current too low in actuated state No reaction, status is not shown 305406: Check wiring	A700		E	1
8A3607	Engine chassis: Outlet engine running Current too high in actuated state No reaction, status is not shown 305407: Check wiring	A700		E	1
8A3608	Engine chassis: Outlet engine running Ground switch overcurrent No reaction, status is not shown 305408: Check wiring	A700		E	1
8A3609	Engine chassis: Outlet engine running Plus switch overcurrent No reaction, status is not shown 305409: Check wiring	A700		E	1
8A360A	Engine chassis: Outlet engine running Maximum analog value exceeded (PWM) No reaction, status is not shown 305410: Check wiring	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3700	Engine chassis: Display engine stop Broken wire or Short circuit after ground No reaction, status is not shown 305500: Check wiring	A700		E	1
8A3701	Engine chassis: Display engine stop Broken wire or short circuit after supply voltage No reaction, status is not shown 305501: Check wiring	A700		E	1
8A3702	Engine chassis: Display engine stop Hardware error (control unit defective) No reaction, status is not shown 305502: Check wiring	A700		E	1
8A3703	Engine chassis: Display engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305503: Check wiring	A700		E	1
8A3704	Engine chassis: Display engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305504: Check wiring	A700		E	1
8A3705	Engine chassis: Display engine stop Current measured without actuation No reaction, status is not shown 305505: Check wiring	A700		E	1
8A3706	Engine chassis: Display engine stop Current too low in actuated state No reaction, status is not shown 305506: Check wiring	A700		E	1
8A3707	Engine chassis: Display engine stop Current too high in actuated state No reaction, status is not shown 305507: Check wiring	A700		E	1
8A3708	Engine chassis: Display engine stop Ground switch overcurrent No reaction, status is not shown 305508: Check wiring	A700		E	1
8A3709	Engine chassis: Display engine stop Plus switch overcurrent No reaction, status is not shown 305509: Check wiring	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A370A	Engine chassis: Display engine stop Maximum analog value exceeded (PWM) No reaction, status is not shown 305510: Check wiring	A700		E	1
8A3800	Engine chassis: DAReversible fan Broken wire or Short circuit after ground The reversible fan control 1 is not actuated 305600: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A3801	Engine chassis: DAReversible fan Broken wire or short circuit after supply voltage The reversible fan control 1 is not actuated 305601: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A3802	Engine chassis: DAReversible fan Hardware error (control unit defective) The reversible fan control 1 is not actuated 305602: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A3803	Engine chassis: DAReversible fan Maximum signal difference to actuation exceeded The reversible fan control 1 is not actuated 305603: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A3804	Engine chassis: DAReversible fan Maximum signal difference to actuation exceeded The reversible fan control 1 is not actuated 305604: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A3805	Engine chassis: DAReversible fan Current measured without actuation The reversible fan control 1 is not actuated 305605: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A3806	Engine chassis: DAReversible fan Current too low in actuated state The reversible fan control 1 is not actuated 305606: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A3807	Engine chassis: DAReversible fan Current too high in actuated state The reversible fan control 1 is not actuated 305607: Check wiring harness, plug, fan prop. valve, engine control unit	A700		E	1
8A3900	Engine chassis: Outlet engine rpm Broken wire or Short circuit after ground 305700:	A700		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3901	Engine chassis: Outlet engine rpm Broken wire or short circuit after supply voltage 305701:	A700		E	0
8A3A00	Engine chassis: Outlet engine off Broken wire or Short circuit after ground no reaction 305800: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A01	Engine chassis: Outlet engine off Broken wire or short circuit after supply voltage no reaction 305801: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A02	Engine chassis: Outlet engine off Error on hardware recognized no reaction 305802: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A03	Engine chassis: Outlet engine off Regulating deviation negative too high no reaction 305803: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A04	Engine chassis: Outlet engine off Regulating deviation positive too high no reaction 305804: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A05	Engine chassis: Outlet engine off Current in shut off status too high no reaction 305805: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A06	Engine chassis: Outlet engine off Current too low no reaction 305806: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A07	Engine chassis: Outlet engine off Current too high no reaction 305807: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A08	Engine chassis: Outlet engine off Current on ground switch too high no reaction 305808: Check wiring, engine control unit and unit connected to this unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3A09	Engine chassis: Outlet engine off Current on plus switch too high no reaction 305809: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3A0A	Engine chassis: Outlet engine off Pulse width (PWM) on maximum no reaction 305810: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B00	Engine chassis: Output warning signal (Amber Warning) Broken wire or Short circuit after ground no reaction 305900: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B01	Engine chassis: Output warning signal (Amber Warning) Broken wire or short circuit after supply voltage no reaction 305901: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B02	Engine chassis: Output warning signal (Amber Warning) Error on hardware recognized no reaction 305902: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B03	Engine chassis: Output warning signal (Amber Warning) Regulating deviation negative too high no reaction 305903: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B04	Engine chassis: Output warning signal (Amber Warning) Regulating deviation positive too high no reaction 305904: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B05	Engine chassis: Output warning signal (Amber Warning) Current in shut off status too high no reaction 305905: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B06	Engine chassis: Output warning signal (Amber Warning) Current too low no reaction 305906: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B07	Engine chassis: Output warning signal (Amber Warning) Current too high no reaction 305907: Check wiring, engine control unit and unit connected to this unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3B08	Engine chassis: Output warning signal (Amber Warning) Current on ground switch too high no reaction 305908: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3B09	Engine chassis: Output warning signal (Amber Warning) Current on plus switch too high no reaction 305909: Check wiring, engine control unit and unit connected to this unit	A700		E	1
8A3C00	Engine chassis: Mass flow sensor 1 Temperature sensor erroneous Possibly power reduction 306000: Replace sensor	A700		E	1
8A3C01	Engine chassis: Mass flow sensor 1 Absolute pressure sensor erroneous Possibly power reduction 306001: Replace sensor	A700		E	1
8A3C02	Engine chassis: Mass flow sensor 1 Differential pressure sensor erroneous Possibly power reduction 306002: Replace sensor	A700		E	1
8A3C03	Engine chassis: Mass flow sensor 1 excess temperature Change over to 2nd Lambda Signal 306003: Replace sensor	A700		E	1
8A3C0A	Engine chassis: Mass flow sensor 1 Ground current signal 1 implausible, detection at high ground current Warning light on 306010: Clean sensor or replace	A700		E	1
8A3C0B	Engine chassis: Mass flow sensor 1 Ground current signal 1 implausible, detection at low ground current Warning light on 306011: Clean sensor or replace	A700		E	1
8A3D00	Engine chassis: Mass flow sensor 2 Temperature sensor erroneous Possibly power reduction 306100: Replace sensor	A700		E	1
8A3D01	Engine chassis: Mass flow sensor 2 Absolute pressure sensor erroneous Possibly power reduction 306101: Replace sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A3D02	Engine chassis: Mass flow sensor 2 Differential pressure sensor erroneous Possibly power reduction 306102: Replace sensor	A700		E	1
8A3D03	Engine chassis: Mass flow sensor 2 excess temperature Change over to 2nd Lambda Signal 306103: Replace sensor	A700		E	1
8A3D0A	Engine chassis: Mass flow sensor 2 Ground current signal 1 implausible, detection at high ground current Warning light on 306110: Clean sensor or replace	A700		E	1
8A3D0B	Engine chassis: Mass flow sensor 2 Ground current signal 1 implausible, detection at low ground current Warning light on 306111: Clean sensor or replace	A700		E	1
8A3E00	Engine chassis: NOx sensor "Up 1" Open line No Lambda correction - possibly power reduction 306200: Replace sensor	A700		E	1
8A3E01	Engine chassis: NOx sensor "Up 1" Short circuit No Lambda correction - possibly power reduction 306201: Replace sensor	A700		E	1
8A3E0A	Engine chassis: NOx sensor "Up 1" Value implausible Warning light on 306210: Replace sensor	A700		E	1
8A3F00	Engine chassis: NOx sensor "Down 1" Open line No Lambda correction - possibly power reduction 306300: Replace sensor	A700		E	1
8A3F01	Engine chassis: NOx sensor "Down 1" Short circuit No Lambda correction - possibly power reduction 306301: Replace sensor	A700		E	1
8A4000	Engine chassis: NOx sensor "Up 2" Open line No Lambda correction - possibly power reduction 306400: Replace sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4001	Engine chassis: NOx sensor "Up 2" Short circuit No Lambda correction - possibly power reduction 306401: Replace sensor	A700		E	1
8A4100	Engine chassis: NOx sensor "Down 2" Open line No Lambda correction - possibly power reduction 306500: Replace sensor	A700		E	1
8A4101	Engine chassis: NOx sensor "Down 2" Short circuit No Lambda correction - possibly power reduction 306501: Replace sensor	A700		E	1
8A4200	Engine chassis: Water pump maximum rpm deviation exceeded no reaction 306600: Check wiring harness, plug, conn. Modul	A700		E	1
8A4300	Engine chassis: EGR-valve 1 excess temperature Power reduction of Diesel engine 306700: Check cooling module	A700		E	1
8A4301	Engine chassis: EGR-valve 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 306701: Check module: linkage, flap	A700		E	1
8A4302	Engine chassis: EGR-valve 1 Data communication CAN faulty Power reduction of Diesel engine 306702: Check wiring, Module	A700		E	1
8A4303	Engine chassis: EGR-valve 1 Data communication CAN interrupted Power reduction of Diesel engine 306703: Check wiring, Module	A700		E	1
8A4304	Engine chassis: EGR-valve 1 Spring erroneous Power reduction of Diesel engine 306704: Replace module	A700		E	1
8A4305	Engine chassis: EGR-valve 1 Gear erroneous Power reduction of Diesel engine 306705: Replace module	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4306	Engine chassis: EGR-valve 1 steering device error Power reduction of Diesel engine 306706: Replace module	A700		E	1
8A4307	Engine chassis: EGR-valve 1 Absolute position sensor erroneous Power reduction of Diesel engine 306707: Replace module	A700		E	1
8A4309	Engine chassis: EGR-valve 1 Calibration procedure erroneous Power reduction of Diesel engine 306709: Check module: linkage, flap	A700		E	1
8A430A	Engine chassis: EGR-valve 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306710: Check module: linkage, flap	A700		E	1
8A430B	Engine chassis: EGR-valve 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306711: Check wiring alternator (D+) to battery or to engine control unit , alternator	A700		E	1
8A430C	Engine chassis: EGR-valve 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306712: Check module: linkage, flap	A700		E	1
8A430D	Engine chassis: EGR-valve 1 Reference to zero point erroneous Power reduction of Diesel engine 306713: Check module: linkage, flap	A700		E	1
8A4400	Engine chassis: EGR-valve 2 excess temperature Power reduction of Diesel engine 306800: Check cooling module	A700		E	1
8A4401	Engine chassis: EGR-valve 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 306801: Check module: linkage, flap	A700		E	1
8A4402	Engine chassis: EGR-valve 2 Data communication CAN faulty Power reduction of Diesel engine 306802: Check wiring, Module	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4403	Engine chassis: EGR-valve 2 Data communication CAN interrupted Power reduction of Diesel engine 306803: Check wiring, Module pruefen	A700		E	1
8A4404	Engine chassis: EGR-valve 2 Spring erroneous Power reduction of Diesel engine 306804: Replace module	A700		E	1
8A4405	Engine chassis: EGR-valve 2 Gear erroneous Power reduction of Diesel engine 306805: Replace module	A700		E	1
8A4406	Engine chassis: EGR-valve 2 steering device error Power reduction of Diesel engine 306806: Replace module	A700		E	1
8A4407	Engine chassis: EGR-valve 2 Absolute position sensor erroneous Power reduction of Diesel engine 306807: Replace module	A700		E	1
8A4409	Engine chassis: EGR-valve 2 Calibration procedure erroneous Power reduction of Diesel engine 306809: Check module: linkage, flap	A700		E	1
8A440A	Engine chassis: EGR-valve 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306810: Check module: linkage, flap	A700		E	1
8A440B	Engine chassis: EGR-valve 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306811: Check wiring alternator (D+) to battery or to engine control unit, alternator	A700		E	1
8A440C	Engine chassis: EGR-valve 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306812: Check module: linkage, flap	A700		E	1
8A440D	Engine chassis: EGR-valve 2 Reference to zero point erroneous Power reduction of Diesel engine 306813: Check module: linkage, flap	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4500	Engine chassis: WG-valve 1 excess temperature Power reduction of Diesel engine 306900: Check cooling module	A700		E	1
8A4501	Engine chassis: WG-valve 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 306901: Check module: linkage, flap	A700		E	1
8A4502	Engine chassis: WG-valve 1 Data communication CAN faulty Power reduction of Diesel engine 306902: Check wiring, Module pruefen	A700		E	1
8A4503	Engine chassis: WG-valve 1 Data communication CAN interrupted Power reduction of Diesel engine 306903: Check wiring, Module pruefen	A700		E	1
8A4504	Engine chassis: WG-valve 1 Spring erroneous Power reduction of Diesel engine 306904: Replace module	A700		E	1
8A4505	Engine chassis: WG-valve 1 Gear erroneous Power reduction of Diesel engine 306905: Replace module	A700		E	1
8A4506	Engine chassis: WG-valve 1 steering device error Power reduction of Diesel engine 306906: Replace module	A700		E	1
8A4507	Engine chassis: WG-valve 1 Absolute position sensor erroneous Power reduction of Diesel engine 306907: Replace module	A700		E	1
8A4509	Engine chassis: WG-valve 1 Calibration procedure erroneous Power reduction of Diesel engine 306909: Check module: linkage, flap	A700		E	1
8A450A	Engine chassis: WG-valve 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306910: Check module: linkage, flap	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A450B	Engine chassis: WG-valve 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306911: Check wiring alternator (D+) to battery or to engine control unit, alternator	A700		E	1
8A450C	Engine chassis: WG-valve 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306912: Check module: linkage, flap	A700		E	1
8A450D	Engine chassis: WG-valve 1 Reference to zero point erroneous Power reduction of Diesel engine 306913: Check module: linkage, flap	A700		E	1
8A4600	Engine chassis: WG-valve 2 excess temperature Power reduction of Diesel engine 307000: Check cooling module	A700		E	1
8A4601	Engine chassis: WG-valve 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 307001: Check module: linkage, flap	A700		E	1
8A4602	Engine chassis: WG-valve 2 Data communication CAN faulty Power reduction of Diesel engine 307002: Check wiring, module	A700		E	1
8A4603	Engine chassis: WG-valve 2 Data communication CAN interrupted Power reduction of Diesel engine 307003: Check wiring, Module pruefen	A700		E	1
8A4604	Engine chassis: WG-valve 2 Spring erroneous Power reduction of Diesel engine 307004: Replace module	A700		E	1
8A4605	Engine chassis: WG-valve 2 Gear erroneous Power reduction of Diesel engine 307005: Replace module	A700		E	1
8A4606	Engine chassis: WG-valve 2 steering device error Power reduction of Diesel engine 307006: Replace module	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4607	Engine chassis: WG-valve 2 Absolute position sensor erroneous Power reduction of Diesel engine 307007: Replace module	A700		E	1
8A4609	Engine chassis: WG-valve 2 Calibration procedure erroneous Power reduction of Diesel engine 307009: Check module: linkage, flap	A700		E	1
8A460A	Engine chassis: WG-valve 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307010: Check module: linkage, flap	A700		E	1
8A460B	Engine chassis: WG-valve 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307011: Check wiring alternator (D+) to battery or to engine control unit , alternator	A700		E	1
8A460C	Engine chassis: WG-valve 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307012: Check module: linkage, flap	A700		E	1
8A460D	Engine chassis: WG-valve 2 Reference to zero point erroneous Power reduction of Diesel engine 307013: Check module: linkage, flap	A700		E	1
8A4700	Engine chassis: Restrictor flap 1 excess temperature Power reduction of Diesel engine 307100: Check cooling module	A700		E	1
8A4701	Engine chassis: Restrictor flap 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 307101: Check module: linkage, flap	A700		E	1
8A4702	Engine chassis: Restrictor flap 1 Data communication CAN faulty Power reduction of Diesel engine 307102: Check wiring, Module pruefen	A700		E	1
8A4703	Engine chassis: Restrictor flap 1 Data communication CAN interrupted Power reduction of Diesel engine 307103: Check wiring, Module pruefen	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4704	Engine chassis: Restrictor flap 1 Spring erroneous Power reduction of Diesel engine 307104: Replace module	A700		E	1
8A4705	Engine chassis: Restrictor flap 1 Gear erroneous Power reduction of Diesel engine 307105: Replace module	A700		E	1
8A4706	Engine chassis: Restrictor flap 1 steering device error Power reduction of Diesel engine 307106: Replace module	A700		E	1
8A4707	Engine chassis: Restrictor flap 1 Absolute position sensor erroneous Power reduction of Diesel engine 307107: Replace module	A700		E	1
8A4709	Engine chassis: Restrictor flap 1 Calibration procedure erroneous Power reduction of Diesel engine 307109: Check module: linkage, flap	A700		E	1
8A470A	Engine chassis: Restrictor flap 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307110: Check module: linkage, flap	A700		E	1
8A470B	Engine chassis: Restrictor flap 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307111: Check wiring alternator (D+) to battery or to engine control unit , alternator	A700		E	1
8A470C	Engine chassis: Restrictor flap 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307112: Check module: linkage, flap	A700		E	1
8A470D	Engine chassis: Restrictor flap 1 Reference to zero point erroneous Power reduction of Diesel engine 307113: Check module: linkage, flap	A700		E	1
8A4800	Engine chassis: Restrictor flap 2 excess temperature Power reduction of Diesel engine 307200: Check cooling module	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4801	Engine chassis: Restrictor flap 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 307201: Check module: linkage, flap	A700		E	1
8A4802	Engine chassis: Restrictor flap 2 Data communication CAN faulty Power reduction of Diesel engine 307202: Check wiring, modules	A700		E	1
8A4803	Engine chassis: Restrictor flap 2 Data communication CAN interrupted Power reduction of Diesel engine 307203: Check wiring, Module pruefen	A700		E	1
8A4804	Engine chassis: Restrictor flap 2 Spring erroneous Power reduction of Diesel engine 307204: Replace module	A700		E	1
8A4805	Engine chassis: Restrictor flap 2 Gear erroneous Power reduction of Diesel engine 307205: Replace module	A700		E	1
8A4806	Engine chassis: Restrictor flap 2 steering device error Power reduction of Diesel engine 307206: Replace module	A700		E	1
8A4807	Engine chassis: Restrictor flap 2 Absolute position sensor erroneous Power reduction of Diesel engine 307207: Replace module	A700		E	1
8A4809	Engine chassis: Restrictor flap 2 Calibration procedure erroneous Power reduction of Diesel engine 307209: Check module: linkage, flap	A700		E	1
8A480A	Engine chassis: Restrictor flap 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307210: Check module: linkage, flap	A700		E	1
8A480B	Engine chassis: Restrictor flap 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307211: Check wiring alternator (D+) to batter or engine control unit , alternator	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A480C	Engine chassis: Restrictor flap 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307212: Check module: linkage, flap	A700		E	1
8A480D	Engine chassis: Restrictor flap 2 Reference to zero point erroneous Power reduction of Diesel engine 307213: Check module: linkage, flap	A700		E	1
8A4900	Engine chassis: Relay outlet, sensors, actuators Line interruption or short circuit after ground 307300: Check wiring and control units	A700		E	1
8A4901	Engine chassis: Relay outlet, sensors, actuators Line interruption or short circuit after supply voltage 307301: Check wiring and control units	A700		E	1
8A4905	Engine chassis: Relay outlet, sensors, actuators Current too high in turned off status 307305: Check wiring and control units	A700		E	1
8A4906	Engine chassis: Relay outlet, sensors, actuators Current too low in turned off status 307306: Check wiring and control units	A700		E	1
8A4907	Engine chassis: Relay outlet, sensors, actuators Current too high in actuated status 307307: Check wiring and control units	A700		E	1
8A4A00	Engine chassis: Error machine Emerg. stop actuated, line interruption or short circuit after ground Engine stop 307400: Emerg. stop actuated, check wiring and emerg. stop button	A700		E	1
8A4B00	Engine chassis: Travel pedal Short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307500: Check wiring engine control unit/travel pedal sensor 1 (broken wire or short circuit after ground)	A700		E	1
8A4B01	Engine chassis: Travel pedal Sensor signal short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307501: Check wiring engine control unit/travel pedal sensor 1 (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4B02	Engine chassis: Travel pedal Sensor supply voltage short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307502: Check wiring engine control unit/travel pedal sensor 1 (short circuit after ground)	A700		E	1
8A4B03	Engine chassis: Travel pedal Sensor supply voltage short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307503: Check wiring engine control unit/travel pedal sensor 1 (short circuit after batt. volt.)	A700		E	1
8A4B04	Engine chassis: Travel pedal Sensor signal outside permissible range 1 Remains at low idle when both travel pedal sensors failed 307504: Check operational status of engine	A700		E	1
8A4B05	Engine chassis: Travel pedal Sensor signal outside permissible range 2 Remains at low idle when both travel pedal sensors failed 307505: Check operational status of engine	A700		E	1
8A4B06	Engine chassis: Travel pedal Plausibility error at engine off no reaction 307506: Check wiring engine control unit/sensor	A700		E	1
8A4C00	Engine chassis: accelerator 2 Short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307600: Check wiring engine control unit/travel pedal sensor 2 (broken wire or short circuit after ground)	A700		E	1
8A4C01	Engine chassis: accelerator 2 Sensor signal short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307601: Check wiring engine control unit/travel pedal sensor 2 (short circuit after batt. volt.)	A700		E	1
8A4C02	Engine chassis: accelerator 2 Sensor supply voltage short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307602: Check wiring engine control unit/travel pedal sensor 2 (short circuit after ground)	A700		E	1
8A4C03	Engine chassis: accelerator 2 Sensor supply voltage short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307603: Check wiring engine control unit/travel pedal sensor 2 (short circuit after batt. volt.)	A700		E	1
8A4C04	Engine chassis: accelerator 2 Sensor signal outside permissible range 1 Remains at low idle when both travel pedal sensors failed 307604: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4C05	Engine chassis: accelerator 2 Sensor signal outside permissible range 2 Remains at low idle when both travel pedal sensors failed 307605: Check operational status of engine	A700		E	1
8A4C06	Engine chassis: accelerator 2 Plausibility error at engine off no reaction 307606: Check wiring engine control unit/sensor	A700		E	1
8A4D00	Engine chassis: Fill level sensor Urea tank Short circuit after ground or broken wire Benutzung des Ersatzwertes. 307700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A4D01	Engine chassis: Fill level sensor Urea tank Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 307701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A4D02	Engine chassis: Fill level sensor Urea tank Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 307702: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A4D03	Engine chassis: Fill level sensor Urea tank Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 307703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A4D04	Engine chassis: Fill level sensor Urea tank Sensor signal outside permissible range 1 no reaction 307704: Ureastand	A700		E	1
8A4D05	Engine chassis: Fill level sensor Urea tank Sensor signal outside permissible range 2 no reaction 307705: Ureastand	A700		E	1
8A4D06	Engine chassis: Fill level sensor Urea tank Plausibility error at engine off no reaction 307706: Check wiring engine control unit/sensor	A700		E	1
8A4E00	Engine chassis: Fill level sensor engine oil Short circuit after ground or broken wire Benutzung des Ersatzwertes. 307800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4E01	Engine chassis: Fill level sensor engine oil Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 307801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A4E02	Engine chassis: Fill level sensor engine oil Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 307802: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A4E03	Engine chassis: Fill level sensor engine oil Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 307803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A4E04	Engine chassis: Fill level sensor engine oil Sensor signal outside permissible range 1 no reaction 307804: Oil level, oil level sensor	A700		E	1
8A4E05	Engine chassis: Fill level sensor engine oil Sensor signal outside permissible range 2 no reaction 307805: Oil level, oil level sensor	A700		E	1
8A4E06	Engine chassis: Fill level sensor engine oil Plausibility error at engine off no reaction 307806: Check wiring engine control unit/sensor	A700		E	1
8A4F00	Engine chassis: AGR Position sensor 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 307900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A4F01	Engine chassis: AGR Position sensor 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 307901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A4F02	Engine chassis: AGR Position sensor 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 307902: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A4F03	Engine chassis: AGR Position sensor 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 307903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A4F04	Engine chassis: AGR Position sensor 1 Sensor signal outside permissible range 1 no reaction 307904: AGR 1 Position sensor	A700		E	1
8A4F05	Engine chassis: AGR Position sensor 1 Sensor signal outside permissible range 2 no reaction 307905: AGR 1 Position sensor	A700		E	1
8A4F06	Engine chassis: AGR Position sensor 1 Plausibility error at engine off no reaction 307906: Check wiring engine control unit/sensor	A700		E	1
8A5000	Engine chassis: AGR Position sensor 2 Short circuit after ground or broken wire Use replacement value. Output red. in case of failure of both Commonrail pr. sensor, otherwise no reaction 308000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5001	Engine chassis: AGR Position sensor 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5002	Engine chassis: AGR Position sensor 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308002: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A5003	Engine chassis: AGR Position sensor 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5004	Engine chassis: AGR Position sensor 2 Sensor signal outside permissible range 1 no reaction 308004: AGR 2 Position sensor	A700		E	1
8A5005	Engine chassis: AGR Position sensor 2 Sensor signal outside permissible range 2 no reaction 308005: AGR 2 Position sensor	A700		E	1
8A5006	Engine chassis: AGR Position sensor 2 Plausibility error at engine off no reaction 308006: Check wiring engine control unit/sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5200	Engine chassis: Charge air pr. sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5201	Engine chassis: Charge air pr. sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5202	Engine chassis: Charge air pr. sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308202: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A5203	Engine chassis: Charge air pr. sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5204	Engine chassis: Charge air pr. sensor Sensor signal outside permissible range 1 no reaction 308204: Check operational status of engine	A700		E	1
8A5205	Engine chassis: Charge air pr. sensor Sensor signal outside permissible range 2 no reaction 308205: Check operational status of engine	A700		E	1
8A5206	Engine chassis: Charge air pr. sensor Plausibility error at engine off no reaction 308206: Check wiring engine control unit/sensor	A700		E	1
8A5207	Engine chassis: Charge air pr. sensor Value implausible Warning light on, replace sensor 308207: Check wiring engine control unit/sensor	A700		E	1
8A5300	Engine chassis: Oil pressure sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5301	Engine chassis: Oil pressure sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5302	Engine chassis: Oil pressure sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308302: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A5303	Engine chassis: Oil pressure sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5304	Engine chassis: Oil pressure sensor Sensor signal outside permissible range 1 no reaction 308304: Check operational status of engine	A700		E	1
8A5305	Engine chassis: Oil pressure sensor Sensor signal outside permissible range 2 no reaction 308305: Check operational status of engine	A700		E	1
8A5306	Engine chassis: Oil pressure sensor Plausibility error at engine off no reaction 308306: Check wiring engine control unit/sensor	A700		E	1
8A5400	Engine chassis: Fuel pressure sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5401	Engine chassis: Fuel pressure sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5402	Engine chassis: Fuel pressure sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308402: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A5403	Engine chassis: Fuel pressure sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5404	Engine chassis: Fuel pressure sensor Sensor signal outside permissible range 1 no reaction 308404: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5405	Engine chassis: Fuel pressure sensor Sensor signal outside permissible range 2 no reaction 308405: Check operational status of engine	A700		E	1
8A5406	Engine chassis: Fuel pressure sensor Plausibility error at engine off no reaction 308406: Check wiring engine control unit/sensor	A700		E	1
8A5500	Engine chassis: Fuel pr. sensor 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5501	Engine chassis: Fuel pr. sensor 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5502	Engine chassis: Fuel pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308502: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A5503	Engine chassis: Fuel pr. sensor 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5504	Engine chassis: Fuel pr. sensor 2 Sensor signal outside permissible range 1 no reaction 308504: Check operational status of engine	A700		E	1
8A5505	Engine chassis: Fuel pr. sensor 2 Sensor signal outside permissible range 2 no reaction 308505: Check operational status of engine	A700		E	1
8A5506	Engine chassis: Fuel pr. sensor 2 Plausibility error at engine off no reaction 308506: Check wiring engine control unit/sensor	A700		E	1
8A5600	Engine chassis: Air filter vacuum pr. sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5601	Engine chassis: Air filter vacuum pr. sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5602	Engine chassis: Air filter vacuum pr. sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308602: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A5603	Engine chassis: Air filter vacuum pr. sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5604	Engine chassis: Air filter vacuum pr. sensor Sensor signal outside permissible range 1 no reaction 308604: Air filter 1, air pr. sensor 1	A700		E	1
8A5605	Engine chassis: Air filter vacuum pr. sensor Sensor signal outside permissible range 2 no reaction 308605: Air filter 1, air pr. sensor 1	A700		E	1
8A5606	Engine chassis: Air filter vacuum pr. sensor Plausibility error at engine off no reaction 308606: Check wiring engine control unit/sensor	A700		E	1
8A5700	Engine chassis: Air filter vacuum pr. sensor 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5701	Engine chassis: Air filter vacuum pr. sensor 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A5702	Engine chassis: Air filter vacuum pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308702: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A5703	Engine chassis: Air filter vacuum pr. sensor 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5704	Engine chassis: Air filter vacuum pr. sensor 2 Sensor signal outside permissible range 1 no reaction 308704: Air filter 2, air pr. sensor 2	A700		E	1
8A5705	Engine chassis: Air filter vacuum pr. sensor 2 Sensor signal outside permissible range 2 no reaction 308705: Air filter 2, air pr. sensor 2	A700		E	1
8A5706	Engine chassis: Air filter vacuum pr. sensor 2 Plausibility error at engine off no reaction 308706: Check wiring engine control unit/sensor	A700		E	1
8A5800	Engine chassis: Rail pr. sensor 1 Short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	2
8A5801	Engine chassis: Rail pr. sensor 1 Sensor signal short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	2
8A5802	Engine chassis: Rail pr. sensor 1 Sensor supply voltage short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308802: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	2
8A5803	Engine chassis: Rail pr. sensor 1 Sensor supply voltage short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	2
8A5804	Engine chassis: Rail pr. sensor 1 Sensor signal outside permissible range 1 no reaction 308804: Check operational status of engine	A700		E	2
8A5805	Engine chassis: Rail pr. sensor 1 Sensor signal outside permissible range 2 Engine standstill after delay 308805: Check operational status of engine	A700		E	2
8A5806	Engine chassis: Rail pr. sensor 1 Plausibility error at engine off no reaction 308806: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5807	Engine chassis: Rail pr. sensor 1 Value implausible High pressure regulation emergency operation activated 308807: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	2
8A5808	Engine chassis: Rail pr. sensor 1 Pressure run implausible (Gradient) High pressure regulation emergency operation activated 308808: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	2
8A5809	Engine chassis: Rail pr. sensor 1 Pressure value implausible to constant no reaction 308809: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A700		E	1
8A5900	Engine chassis: Rail pr. sensor 2 Short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	2
8A5901	Engine chassis: Rail pr. sensor 2 Sensor signal short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	2
8A5902	Engine chassis: Rail pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308902: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	2
8A5903	Engine chassis: Rail pr. sensor 2 Sensor supply voltage short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	2
8A5904	Engine chassis: Rail pr. sensor 2 Sensor signal outside permissible range 1 Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308904: Check operational status of engine	A700		E	2
8A5905	Engine chassis: Rail pr. sensor 2 Sensor signal outside permissible range 2 Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308905: Check operational status of engine	A700		E	2
8A5906	Engine chassis: Rail pr. sensor 2 Plausibility error at engine off no reaction 308906: Check wiring engine control unit/sensor	A700		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5907	Engine chassis: Rail pr. sensor 2 Value implausible High pressure regulation emergency operation activated 308907: Check wiring harness, plug, rail pr. sensors, check rail circuit 1/2	A700		E	2
8A5908	Engine chassis: Rail pr. sensor 2 Pressure run implausible (Gradient) High pressure regulation emergency operation activated 308908: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	2
8A5909	Engine chassis: Rail pr. sensor 2 Pressure value implausible to constant no reaction 308909: Nitrogen circuit, Rail sensor 2, pr. relief valve 2, high pr. pump 2, Cable conn. engine control unit	A700		E	1
8A5A00	Engine chassis: Atmospheric pressure sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309000: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A5A01	Engine chassis: Atmospheric pressure sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309001: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A5A02	Engine chassis: Atmospheric pressure sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309002: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A5A03	Engine chassis: Atmospheric pressure sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309003: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A5A04	Engine chassis: Atmospheric pressure sensor Sensor signal outside permissible range 1 no reaction 309004: Check operational status of engine	A700		E	1
8A5A05	Engine chassis: Atmospheric pressure sensor Sensor signal outside permissible range 2 no reaction 309005: Check operational status of engine	A700		E	1
8A5A06	Engine chassis: Atmospheric pressure sensor Plausibility error at engine off no reaction 309006: Check wiring engine control unit/sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5A07	Engine chassis: Atmospheric pressure sensor Value implausible Warning light on, replace sensor 309007: Replace ECU	A700		E	1
8A5C00	Engine chassis: Exhaust pr. difference sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5C01	Engine chassis: Exhaust pr. difference sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309201: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5C02	Engine chassis: Exhaust pr. difference sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309202: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5C03	Engine chassis: Exhaust pr. difference sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309203: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5C04	Engine chassis: Exhaust pr. difference sensor Sensor signal outside permissible range 1 no reaction 309204: Check operational status of engine	A700		E	1
8A5C05	Engine chassis: Exhaust pr. difference sensor Sensor signal outside permissible range 2 no reaction 309205: Check operational status of engine	A700		E	1
8A5C06	Engine chassis: Exhaust pr. difference sensor Plausibility error at engine off no reaction 309206: Check wiring engine control unit/sensor	A700		E	1
8A5C07	Engine chassis: Exhaust pr. difference sensor Value implausible Warning light on 309207: Replace sensor	A700		E	1
8A5D00	Engine chassis: Battery voltage measuring Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5D01	Engine chassis: Battery voltage measuring Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309301: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5D02	Engine chassis: Battery voltage measuring Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309302: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5D03	Engine chassis: Battery voltage measuring Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309303: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5D04	Engine chassis: Battery voltage measuring Sensor signal outside permissible range 1 no reaction 309304: Check operational status of engine	A700		E	1
8A5D05	Engine chassis: Battery voltage measuring Sensor signal outside permissible range 2 no reaction 309305: Check operational status of engine	A700		E	1
8A5D06	Engine chassis: Battery voltage measuring Plausibility error at engine off no reaction 309306: Check wiring engine control unit/sensor	A700		E	1
8A5E00	Engine chassis: Pressure sensor InterChargerUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5E01	Engine chassis: Pressure sensor InterChargerUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309401: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5E02	Engine chassis: Pressure sensor InterChargerUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309402: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5E03	Engine chassis: Pressure sensor InterChargerUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309403: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5E04	Engine chassis: Pressure sensor InterChargerUp 1 Sensor signal outside permissible range 1 no reaction 309404: Check operational status of engine	A700		E	1
8A5E05	Engine chassis: Pressure sensor InterChargerUp 1 Sensor signal outside permissible range 2 no reaction 309405: Check operational status of engine	A700		E	1
8A5E06	Engine chassis: Pressure sensor InterChargerUp 1 Plausibility error at engine off no reaction 309406: Check wiring engine control unit/sensor	A700		E	1
8A5E07	Engine chassis: Pressure sensor InterChargerUp 1 Value implausible Warning light on, replace sensor 309407: Check wiring engine control unit/sensor	A700		E	1
8A5F00	Engine chassis: Pressure sensor InterChargerDown 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5F01	Engine chassis: Pressure sensor InterChargerDown 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309501: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5F02	Engine chassis: Pressure sensor InterChargerDown 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309502: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5F03	Engine chassis: Pressure sensor InterChargerDown 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309503: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A5F04	Engine chassis: Pressure sensor InterChargerDown 1 Sensor signal outside permissible range 1 no reaction 309504: Check operational status of engine	A700		E	1
8A5F05	Engine chassis: Pressure sensor InterChargerDown 1 Sensor signal outside permissible range 2 no reaction 309505: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A5F06	Engine chassis: Pressure sensor InterChargerDown 1 Plausibility error at engine off no reaction 309506: Check wiring engine control unit/sensor	A700		E	1
8A5F07	Engine chassis: Pressure sensor InterChargerDown 1 Value implausible Warning light on, replace sensor 309507: Check wiring engine control unit/sensor	A700		E	1
8A6000	Engine chassis: Pressure sensor InterChargerUp 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6001	Engine chassis: Pressure sensor InterChargerUp 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309601: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6002	Engine chassis: Pressure sensor InterChargerUp 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309602: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6003	Engine chassis: Pressure sensor InterChargerUp 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309603: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6004	Engine chassis: Pressure sensor InterChargerUp 2 Sensor signal outside permissible range 1 no reaction 309604: Check operational status of engine	A700		E	1
8A6005	Engine chassis: Pressure sensor InterChargerUp 2 Sensor signal outside permissible range 2 no reaction 309605: Check operational status of engine	A700		E	1
8A6006	Engine chassis: Pressure sensor InterChargerUp 2 Plausibility error at engine off no reaction 309606: Check wiring engine control unit/sensor	A700		E	1
8A6100	Engine chassis: Pressure sensor InterChargerDown 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A6101	Engine chassis: Pressure sensor InterChargerDown 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309701: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6102	Engine chassis: Pressure sensor InterChargerDown 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309702: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6103	Engine chassis: Pressure sensor InterChargerDown 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309703: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6104	Engine chassis: Pressure sensor InterChargerDown 2 Sensor signal outside permissible range 1 no reaction 309704: Check operational status of engine	A700		E	1
8A6105	Engine chassis: Pressure sensor InterChargerDown 2 Sensor signal outside permissible range 2 no reaction 309705: Check operational status of engine	A700		E	1
8A6106	Engine chassis: Pressure sensor InterChargerDown 2 Plausibility error at engine off no reaction 309706: Check wiring engine control unit/sensor	A700		E	1
8A6107	Engine chassis: Pressure sensor InterChargerDown 2 Value implausible 309707:	A700		E	1
8A6200	Engine chassis: Pressure sensor InterCoolerUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6201	Engine chassis: Pressure sensor InterCoolerUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309801: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6202	Engine chassis: Pressure sensor InterCoolerUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309802: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A6203	Engine chassis: Pressure sensor InterCoolerUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309803: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6204	Engine chassis: Pressure sensor InterCoolerUp 1 Sensor signal outside permissible range 1 no reaction 309804: Check operational status of engine	A700		E	1
8A6205	Engine chassis: Pressure sensor InterCoolerUp 1 Sensor signal outside permissible range 2 no reaction 309805: Check operational status of engine	A700		E	1
8A6206	Engine chassis: Pressure sensor InterCoolerUp 1 Plausibility error at engine off no reaction 309806: Check wiring engine control unit/sensor	A700		E	1
8A6207	Engine chassis: Pressure sensor InterCoolerUp 1 Value implausible Warning light on, replace sensor 309807: Check wiring engine control unit/sensor	A700		E	1
8A6900	Engine chassis: Exhaust temperature sensor 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6901	Engine chassis: Exhaust temperature sensor 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6902	Engine chassis: Exhaust temperature sensor 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310502: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A6903	Engine chassis: Exhaust temperature sensor 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6904	Engine chassis: Exhaust temperature sensor 1 Sensor signal outside permissible range 1 no reaction 310504: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A6905	Engine chassis: Exhaust temperature sensor 1 Sensor signal outside permissible range 2 no reaction 310505: Check operational status of engine	A700		E	1
8A6906	Engine chassis: Exhaust temperature sensor 1 Plausibility error at engine off no reaction 310506: Check wiring engine control unit/sensor	A700		E	1
8A6A00	Engine chassis: Exhaust temperature sensor 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6A01	Engine chassis: Exhaust temperature sensor 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6A02	Engine chassis: Exhaust temperature sensor 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310602: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A6A03	Engine chassis: Exhaust temperature sensor 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6A04	Engine chassis: Exhaust temperature sensor 2 Sensor signal outside permissible range 1 no reaction 310604: Check operational status of engine	A700		E	1
8A6A05	Engine chassis: Exhaust temperature sensor 2 Sensor signal outside permissible range 2 no reaction 310605: Check operational status of engine	A700		E	1
8A6A06	Engine chassis: Exhaust temperature sensor 2 Plausibility error at engine off no reaction 310606: Check wiring engine control unit/sensor	A700		E	1
8A6B00	Engine chassis: Temperature sensor DOCUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A6B01	Engine chassis: Temperature sensor DOCUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6B02	Engine chassis: Temperature sensor DOCUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310702: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A6B03	Engine chassis: Temperature sensor DOCUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6B04	Engine chassis: Temperature sensor DOCUp 1 Sensor signal outside permissible range 1 no reaction 310704: Check operational status of engine	A700		E	1
8A6B05	Engine chassis: Temperature sensor DOCUp 1 Sensor signal outside permissible range 2 no reaction 310705: Check operational status of engine	A700		E	1
8A6B06	Engine chassis: Temperature sensor DOCUp 1 Plausibility error at engine off no reaction 310706: Check wiring engine control unit/sensor	A700		E	1
8A6B07	Engine chassis: Temperature sensor DOCUp 1 Value implausible Warning light on 310707: Check wiring engine control unit/sensor	A700		E	1
8A6B0A	Engine chassis: Temperature sensor DOCUp 1 Pressure value at engine start too low Warning light on 310710: Check wiring engine control unit/sensor	A700		E	1
8A6C00	Engine chassis: Temperature sensor DPFUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6C01	Engine chassis: Temperature sensor DPFUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A6C02	Engine chassis: Temperature sensor DPFU1 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310802: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A6C03	Engine chassis: Temperature sensor DPFU1 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6C04	Engine chassis: Temperature sensor DPFU1 1 Sensor signal outside permissible range 1 no reaction 310804: Check operational status of engine	A700		E	1
8A6C05	Engine chassis: Temperature sensor DPFU1 1 Sensor signal outside permissible range 2 no reaction 310805: Check operational status of engine	A700		E	1
8A6C06	Engine chassis: Temperature sensor DPFU1 1 Plausibility error at engine off no reaction 310806: Check wiring engine control unit/sensor	A700		E	1
8A6C07	Engine chassis: Temperature sensor DPFU1 1 Value implausible Warning light on 310807: Replace sensor	A700		E	1
8A6C0A	Engine chassis: Temperature sensor DPFU1 1 Pressure value at engine start too low Warning light on 310810: Check wiring engine control unit/sensor	A700		E	1
8A6D00	Engine chassis: Temperature sensor DPFD1 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6D01	Engine chassis: Temperature sensor DPFD1 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6D02	Engine chassis: Temperature sensor DPFD1 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310902: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A6D03	Engine chassis: Temperature sensor DPFDOWN 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6D04	Engine chassis: Temperature sensor DPFDOWN 1 Sensor signal outside permissible range 1 no reaction 310904: Check operational status of engine	A700		E	1
8A6D05	Engine chassis: Temperature sensor DPFDOWN 1 Sensor signal outside permissible range 2 no reaction 310905: Check operational status of engine	A700		E	1
8A6D06	Engine chassis: Temperature sensor DPFDOWN 1 Plausibility error at engine off no reaction 310906: Check wiring engine control unit/sensor	A700		E	1
8A6D07	Engine chassis: Temperature sensor DPFDOWN 1 Value implausible Warning light on 310907: Replace sensor	A700		E	1
8A6D0A	Engine chassis: Temperature sensor DPFDOWN 1 Pressure value at engine start too low Warning light on 310910: Check wiring engine control unit/sensor	A700		E	1
8A6E00	Engine chassis: Temperature sensor charge air cooler Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6E01	Engine chassis: Temperature sensor charge air cooler Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6E02	Engine chassis: Temperature sensor charge air cooler Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311002: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A6E03	Engine chassis: Temperature sensor charge air cooler Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A6E04	Engine chassis: Temperature sensor charge air cooler Sensor signal outside permissible range 1 no reaction 311004: Check operational status of engine	A700		E	1
8A6E05	Engine chassis: Temperature sensor charge air cooler Sensor signal outside permissible range 2 no reaction 311005: Check operational status of engine	A700		E	1
8A6E06	Engine chassis: Temperature sensor charge air cooler Plausibility error at engine off no reaction 311006: Check wiring engine control unit/sensor	A700		E	1
8A6E07	Engine chassis: Temperature sensor charge air cooler Value implausible Warning light on, replace sensor 311007: Check wiring engine control unit-Sensor check charge air cooler	A700		E	1
8A6F00	Engine chassis: Hydraulic oil temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311100: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A6F01	Engine chassis: Hydraulic oil temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311101: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6F02	Engine chassis: Hydraulic oil temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311102: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A6F03	Engine chassis: Hydraulic oil temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311103: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A6F04	Engine chassis: Hydraulic oil temperature sensor Sensor signal outside permissible range 1 no reaction 311104: Check operational status of engine	A700		E	1
8A6F05	Engine chassis: Hydraulic oil temperature sensor Sensor signal outside permissible range 2 no reaction 311105: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A6F06	Engine chassis: Hydraulic oil temperature sensor Plausibility error at engine off no reaction 311106: Check wiring engine control unit/sensor	A700		E	1
8A7000	Engine chassis: Fuel temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7001	Engine chassis: Fuel temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7002	Engine chassis: Fuel temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311202: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7003	Engine chassis: Fuel temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7004	Engine chassis: Fuel temperature sensor Sensor signal outside permissible range 1 no reaction 311204: Check operational status of engine	A700		E	1
8A7005	Engine chassis: Fuel temperature sensor Sensor signal outside permissible range 2 no reaction 311205: Check operational status of engine	A700		E	1
8A7006	Engine chassis: Fuel temperature sensor Plausibility error at engine off no reaction 311206: Check wiring engine control unit/sensor	A700		E	1
8A7100	Engine chassis: Charge air temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7101	Engine chassis: Charge air temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7102	Engine chassis: Charge air temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311302: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7103	Engine chassis: Charge air temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7104	Engine chassis: Charge air temperature sensor Sensor signal outside permissible range 1 no reaction 311304: Check operational status of engine	A700		E	1
8A7105	Engine chassis: Charge air temperature sensor Sensor signal outside permissible range 2 no reaction 311305: Check operational status of engine	A700		E	1
8A7106	Engine chassis: Charge air temperature sensor Plausibility error at engine off no reaction 311306: Check wiring engine control unit/sensor	A700		E	1
8A7107	Engine chassis: Charge air temperature sensor Value implausible Warning light on 311307: Replace sensor	A700		E	1
8A7200	Engine chassis: Coolant temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7201	Engine chassis: Coolant temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7202	Engine chassis: Coolant temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311402: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7203	Engine chassis: Coolant temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7204	Engine chassis: Coolant temperature sensor Sensor signal outside permissible range 1 no reaction 311404: Check operational status of engine	A700		E	1
8A7205	Engine chassis: Coolant temperature sensor Sensor signal outside permissible range 2 no reaction 311405: Check operational status of engine	A700		E	1
8A7206	Engine chassis: Coolant temperature sensor Plausibility error at engine off no reaction 311406: Check wiring engine control unit/sensor	A700		E	1
8A7207	Engine chassis: Coolant temperature sensor Value implausible Warning light on 311407: Replace sensor	A700		E	1
8A7300	Engine chassis: Atmospheric temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7301	Engine chassis: Atmospheric temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7302	Engine chassis: Atmospheric temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311502: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7303	Engine chassis: Atmospheric temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7304	Engine chassis: Atmospheric temperature sensor Sensor signal outside permissible range 1 no reaction 311504: Check operational status of engine	A700		E	1
8A7305	Engine chassis: Atmospheric temperature sensor Sensor signal outside permissible range 2 no reaction 311505: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7306	Engine chassis: Atmospheric temperature sensor Plausibility error at engine off no reaction 311506: Check wiring engine control unit/sensor	A700		E	1
8A7400	Engine chassis: Battery temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7401	Engine chassis: Battery temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7402	Engine chassis: Battery temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311602: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7403	Engine chassis: Battery temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7404	Engine chassis: Battery temperature sensor Sensor signal outside permissible range 1 no reaction 311604: Check operational status of engine	A700		E	1
8A7405	Engine chassis: Battery temperature sensor Sensor signal outside permissible range 2 no reaction 311605: Check operational status of engine	A700		E	1
8A7406	Engine chassis: Battery temperature sensor Plausibility error at engine off no reaction 311606: Check wiring engine control unit/sensor	A700		E	1
8A7500	Engine chassis: Temperature sensor TransfCasePump Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7501	Engine chassis: Temperature sensor TransfCasePump Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7502	Engine chassis: Temperature sensor TransfCasePump Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311702: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7503	Engine chassis: Temperature sensor TransfCasePump Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7504	Engine chassis: Temperature sensor TransfCasePump Sensor signal outside permissible range 1 no reaction 311704: Check operational status of engine	A700		E	1
8A7505	Engine chassis: Temperature sensor TransfCasePump Sensor signal outside permissible range 2 no reaction 311705: Check operational status of engine	A700		E	1
8A7506	Engine chassis: Temperature sensor TransfCasePump Plausibility error at engine off no reaction 311706: Check wiring engine control unit/sensor	A700		E	1
8A7600	Engine chassis: Temperature sensor SCRUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7601	Engine chassis: Temperature sensor SCRUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7602	Engine chassis: Temperature sensor SCRUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311802: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7603	Engine chassis: Temperature sensor SCRUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7604	Engine chassis: Temperature sensor SCRUp 1 Sensor signal outside permissible range 1 no reaction 311804: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7605	Engine chassis: Temperature sensor SCRUp 1 Sensor signal outside permissible range 2 no reaction 311805: Check operational status of engine	A700		E	1
8A7606	Engine chassis: Temperature sensor SCRUp 1 Plausibility error at engine off no reaction 311806: Check wiring engine control unit/sensor	A700		E	1
8A7700	Engine chassis: Temperature sensor SCRDown 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7701	Engine chassis: Temperature sensor SCRDown 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7702	Engine chassis: Temperature sensor SCRDown 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311902: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7703	Engine chassis: Temperature sensor SCRDown 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7704	Engine chassis: Temperature sensor SCRDown 1 Sensor signal outside permissible range 1 no reaction 311904: Check operational status of engine	A700		E	1
8A7705	Engine chassis: Temperature sensor SCRDown 1 Sensor signal outside permissible range 2 no reaction 311905: Check operational status of engine	A700		E	1
8A7706	Engine chassis: Temperature sensor SCRDown 1 Plausibility error at engine off no reaction 311906: Check wiring engine control unit/sensor	A700		E	1
8A7800	Engine chassis: oil temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7801	Engine chassis: oil temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7802	Engine chassis: oil temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312002: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7803	Engine chassis: oil temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7804	Engine chassis: oil temperature sensor Sensor signal outside permissible range 1 no reaction 312004: Check operational status of engine	A700		E	1
8A7805	Engine chassis: oil temperature sensor Sensor signal outside permissible range 2 no reaction 312005: Check operational status of engine	A700		E	1
8A7806	Engine chassis: oil temperature sensor Plausibility error at engine off no reaction 312006: Check wiring engine control unit/sensor	A700		E	1
8A7900	Engine chassis: Temperature sensor InterChargerUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312100: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7901	Engine chassis: Temperature sensor InterChargerUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312101: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7902	Engine chassis: Temperature sensor InterChargerUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312102: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7903	Engine chassis: Temperature sensor InterChargerUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312103: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7904	Engine chassis: Temperature sensor InterChargerUp 1 Sensor signal outside permissible range 1 no reaction 312104: Check operational status of engine	A700		E	1
8A7905	Engine chassis: Temperature sensor InterChargerUp 1 Sensor signal outside permissible range 2 no reaction 312105: Check operational status of engine	A700		E	1
8A7906	Engine chassis: Temperature sensor InterChargerUp 1 Plausibility error at engine off no reaction 312106: Check wiring engine control unit/sensor	A700		E	1
8A7907	Engine chassis: Temperature sensor InterChargerUp 1 Value implausible 312107:	A700		E	1
8A7A00	Engine chassis: Temperature sensor InterChargerDown 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7A01	Engine chassis: Temperature sensor InterChargerDown 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7A02	Engine chassis: Temperature sensor InterChargerDown 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312202: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7A03	Engine chassis: Temperature sensor InterChargerDown 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7A04	Engine chassis: Temperature sensor InterChargerDown 1 Sensor signal outside permissible range 1 no reaction 312204: Check operational status of engine	A700		E	1
8A7A05	Engine chassis: Temperature sensor InterChargerDown 1 Sensor signal outside permissible range 2 no reaction 312205: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7A06	Engine chassis: Temperature sensor InterChargerDown 1 Plausibility error at engine off no reaction 312206: Check wiring engine control unit/sensor	A700		E	1
8A7A07	Engine chassis: Temperature sensor InterChargerDown 1 Value implausible Warning light on 312207: Replace sensor	A700		E	1
8A7B00	Engine chassis: Temperature sensor InterChargerUp 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7B01	Engine chassis: Temperature sensor InterChargerUp 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7B02	Engine chassis: Temperature sensor InterChargerUp 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312302: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7B03	Engine chassis: Temperature sensor InterChargerUp 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7B04	Engine chassis: Temperature sensor InterChargerUp 2 Sensor signal outside permissible range 1 no reaction 312304: Check operational status of engine	A700		E	1
8A7B05	Engine chassis: Temperature sensor InterChargerUp 2 Sensor signal outside permissible range 2 no reaction 312305: Check operational status of engine	A700		E	1
8A7B06	Engine chassis: Temperature sensor InterChargerUp 2 Plausibility error at engine off no reaction 312306: Check wiring engine control unit/sensor	A700		E	1
8A7C00	Engine chassis: Temperature sensor InterChargerDown 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7C01	Engine chassis: Temperature sensor InterChargerDown 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7C02	Engine chassis: Temperature sensor InterChargerDown 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312402: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7C03	Engine chassis: Temperature sensor InterChargerDown 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7C04	Engine chassis: Temperature sensor InterChargerDown 2 Sensor signal outside permissible range 1 no reaction 312404: Check operational status of engine	A700		E	1
8A7C05	Engine chassis: Temperature sensor InterChargerDown 2 Sensor signal outside permissible range 2 no reaction 312405: Check operational status of engine	A700		E	1
8A7C06	Engine chassis: Temperature sensor InterChargerDown 2 Plausibility error at engine off no reaction 312406: Check wiring engine control unit/sensor	A700		E	1
8A7C07	Engine chassis: Temperature sensor InterChargerDown 2 Value implausible Warning light on 312407: Replace sensor	A700		E	1
8A7D00	Engine chassis: Temperature sensor InterCoolerUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7D01	Engine chassis: Temperature sensor InterCoolerUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7D02	Engine chassis: Temperature sensor InterCoolerUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312502: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7D03	Engine chassis: Temperature sensor InterCoolerUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7D04	Engine chassis: Temperature sensor InterCoolerUp 1 Sensor signal outside permissible range 1 no reaction 312504: Check operational status of engine	A700		E	1
8A7D05	Engine chassis: Temperature sensor InterCoolerUp 1 Sensor signal outside permissible range 2 no reaction 312505: Check operational status of engine	A700		E	1
8A7D06	Engine chassis: Temperature sensor InterCoolerUp 1 Plausibility error at engine off no reaction 312506: Check wiring engine control unit/sensor	A700		E	1
8A7D07	Engine chassis: Temperature sensor InterCoolerUp 1 Value implausible Warning light on, replace sensor 312507: Check wiring engine control unit/sensor	A700		E	1
8A7E00	Engine chassis: Temperature sensor SCRUp 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7E01	Engine chassis: Temperature sensor SCRUp 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7E02	Engine chassis: Temperature sensor SCRUp 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312602: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7E03	Engine chassis: Temperature sensor SCRUp 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7E04	Engine chassis: Temperature sensor SCRUp 2 Sensor signal outside permissible range 1 no reaction 312604: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A7E05	Engine chassis: Temperature sensor SCRUp 2 Sensor signal outside permissible range 2 no reaction 312605: Check operational status of engine	A700		E	1
8A7E06	Engine chassis: Temperature sensor SCRUp 2 Plausibility error at engine off no reaction 312606: Check wiring engine control unit/sensor	A700		E	1
8A7F00	Engine chassis: Temperature sensor SCRDown 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A7F01	Engine chassis: Temperature sensor SCRDown 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7F02	Engine chassis: Temperature sensor SCRDown 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312702: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A7F03	Engine chassis: Temperature sensor SCRDown 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A7F04	Engine chassis: Temperature sensor SCRDown 2 Sensor signal outside permissible range 1 no reaction 312704: Check operational status of engine	A700		E	1
8A7F05	Engine chassis: Temperature sensor SCRDown 2 Sensor signal outside permissible range 2 no reaction 312705: Check operational status of engine	A700		E	1
8A7F06	Engine chassis: Temperature sensor SCRDown 2 Plausibility error at engine off no reaction 312706: Check wiring engine control unit/sensor	A700		E	1
8A8500	Engine chassis: Hardware temperature sensor control unit Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A8501	Engine chassis: Hardware temperature sensor control unit Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 313301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A8502	Engine chassis: Hardware temperature sensor control unit Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 313302: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A8503	Engine chassis: Hardware temperature sensor control unit Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 313303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A8504	Engine chassis: Hardware temperature sensor control unit Sensor signal outside permissible range 1 no reaction 313304: Check operational status of engine	A700		E	1
8A8505	Engine chassis: Hardware temperature sensor control unit Sensor signal outside permissible range 2 no reaction 313305: Check operational status of engine	A700		E	1
8A8506	Engine chassis: Hardware temperature sensor control unit Plausibility error at engine off no reaction 313306: Check wiring engine control unit/sensor	A700		E	1
8A8600	Engine chassis: Hardware temperature sensor control unit CPU Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A700		E	1
8A8601	Engine chassis: Hardware temperature sensor control unit CPU Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 313401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1
8A8602	Engine chassis: Hardware temperature sensor control unit CPU Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 313402: Check wiring engine control unit/sensor (short circuit after ground)	A700		E	1
8A8603	Engine chassis: Hardware temperature sensor control unit CPU Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 313403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A8604	Engine chassis: Hardware temperature sensor control unit CPU Sensor signal outside permissible range 1 no reaction 313404: Check operational status of engine	A700		E	1
8A8605	Engine chassis: Hardware temperature sensor control unit CPU Sensor signal outside permissible range 2 no reaction 313405: Check operational status of engine	A700		E	1
8A8606	Engine chassis: Hardware temperature sensor control unit CPU Plausibility error at engine off no reaction 313406: Check wiring engine control unit/sensor	A700		E	1
8A8800	Engine chassis: Switch signal 1 Alternator short circuit to ground Benutzung des Ersatzwertes. 313600: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8801	Engine chassis: Switch signal 1 Alternator Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 313601: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8802	Engine chassis: Switch signal 1 Alternator Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313602: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8803	Engine chassis: Switch signal 1 Alternator short circuit to supply voltage Benutzung des Ersatzwertes. 313603:	A700		E	1
8A8804	Engine chassis: Switch signal 1 Alternator Operating status outside permissible range Benutzung des Ersatzwertes. 313604: Check operational status of engine	A700		E	1
8A8806	Engine chassis: Switch signal 1 Alternator Value implausible at engine standstill no reaction 313606: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8900	Engine chassis: Switch signal 2 Alternator short circuit to ground Benutzung des Ersatzwertes. 313700: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A8901	Engine chassis: Switch signal 2 Alternator Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 313701: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8902	Engine chassis: Switch signal 2 Alternator Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313702: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8903	Engine chassis: Switch signal 2 Alternator short circuit to supply voltage Benutzung des Ersatzwertes. 313703:	A700		E	1
8A8904	Engine chassis: Switch signal 2 Alternator Operating status outside permissible range Benutzung des Ersatzwertes. 313704: Check operational status of engine	A700		E	1
8A8906	Engine chassis: Switch signal 2 Alternator Value implausible at engine standstill no reaction 313706: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8A00	Engine chassis: Switch signal Heater unit "SupV" 1 short circuit to ground Benutzung des Ersatzwertes. 313800: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8A01	Engine chassis: Switch signal Heater unit "SupV" 1 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 313801: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8A02	Engine chassis: Switch signal Heater unit "SupV" 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313802: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8A03	Engine chassis: Switch signal Heater unit "SupV" 1 short circuit to supply voltage Benutzung des Ersatzwertes. 313803: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8A04	Engine chassis: Switch signal Heater unit "SupV" 1 Operating status outside permissible range Benutzung des Ersatzwertes. 313804: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A8A06	Engine chassis: Switch signal Heater unit "SupV" 1 Value implausible at engine standstill no reaction 313806: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8B00	Engine chassis: Switch signal Heater unit "SupV" 2 short circuit to ground Benutzung des Ersatzwertes. 313900: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8B01	Engine chassis: Switch signal Heater unit "SupV" 2 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 313901: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8B02	Engine chassis: Switch signal Heater unit "SupV" 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313902: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8B03	Engine chassis: Switch signal Heater unit "SupV" 2 short circuit to supply voltage Benutzung des Ersatzwertes. 313903: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8B04	Engine chassis: Switch signal Heater unit "SupV" 2 Operating status outside permissible range Benutzung des Ersatzwertes. 313904: Check operational status of engine	A700		E	1
8A8B06	Engine chassis: Switch signal Heater unit "SupV" 2 Value implausible at engine standstill no reaction 313906: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8C00	Engine chassis: Switch signal Starter short circuit to ground Benutzung des Ersatzwertes. 314000: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8C01	Engine chassis: Switch signal Starter Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314001: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8C02	Engine chassis: Switch signal Starter Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314002: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A8C03	Engine chassis: Switch signal Starter short circuit to supply voltage Benutzung des Ersatzwertes. 314003: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8C04	Engine chassis: Switch signal Starter Operating status outside permissible range Benutzung des Ersatzwertes. 314004: Check operational status of engine	A700		E	1
8A8C06	Engine chassis: Switch signal Starter Value implausible at engine standstill no reaction 314006: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8D00	Engine chassis: Idle switch signal short circuit to ground Benutzung des Ersatzwertes. 314100: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8D01	Engine chassis: Idle switch signal Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314101: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8D02	Engine chassis: Idle switch signal Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314102: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8D03	Engine chassis: Idle switch signal short circuit to supply voltage Benutzung des Ersatzwertes. 314103: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8D04	Engine chassis: Idle switch signal Operating status outside permissible range Benutzung des Ersatzwertes. 314104: Check operational status of engine	A700		E	1
8A8D06	Engine chassis: Idle switch signal Value implausible at engine standstill no reaction 314106: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8E00	Engine chassis: Switch signal Test op. short circuit to ground Benutzung des Ersatzwertes. 314200: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A8E01	Engine chassis: Switch signal Test op. Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314201: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8E02	Engine chassis: Switch signal Test op. Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314202: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8E03	Engine chassis: Switch signal Test op. short circuit to supply voltage Benutzung des Ersatzwertes. 314203: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8E04	Engine chassis: Switch signal Test op. Operating status outside permissible range Benutzung des Ersatzwertes. 314204: Check operational status of engine	A700		E	1
8A8E06	Engine chassis: Switch signal Test op. Value implausible at engine standstill no reaction 314206: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8F00	Engine chassis: Switch signal "SupvEgr" 1 short circuit to ground Benutzung des Ersatzwertes. 314300: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8F01	Engine chassis: Switch signal "SupvEgr" 1 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314301: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8F02	Engine chassis: Switch signal "SupvEgr" 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314302: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8F03	Engine chassis: Switch signal "SupvEgr" 1 short circuit to supply voltage Benutzung des Ersatzwertes. 314303: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A8F04	Engine chassis: Switch signal "SupvEgr" 1 Operating status outside permissible range Benutzung des Ersatzwertes. 314304: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A8F06	Engine chassis: Switch signal "SupvEgr" 1 Value implausible at engine standstill no reaction 314306: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9000	Engine chassis: Switch signal "SupvEgr" 2 short circuit to ground Benutzung des Ersatzwertes. 314400: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9001	Engine chassis: Switch signal "SupvEgr" 2 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314401: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9002	Engine chassis: Switch signal "SupvEgr" 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314402: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9003	Engine chassis: Switch signal "SupvEgr" 2 short circuit to supply voltage Benutzung des Ersatzwertes. 314403: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9004	Engine chassis: Switch signal "SupvEgr" 2 Operating status outside permissible range Benutzung des Ersatzwertes. 314404: Check operational status of engine	A700		E	1
8A9006	Engine chassis: Switch signal "SupvEgr" 2 Value implausible at engine standstill no reaction 314406: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9100	Engine chassis: Switch signal Fixed rpm short circuit to ground Benutzung des Ersatzwertes. 314500: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9101	Engine chassis: Switch signal Fixed rpm Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314501: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9102	Engine chassis: Switch signal Fixed rpm Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314502: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9103	Engine chassis: Switch signal Fixed rpm short circuit to supply voltage Benutzung des Ersatzwertes. 314503: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9104	Engine chassis: Switch signal Fixed rpm Operating status outside permissible range Benutzung des Ersatzwertes. 314504: Check operational status of engine	A700		E	1
8A9106	Engine chassis: Switch signal Fixed rpm Value implausible at engine standstill no reaction 314506: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9200	Engine chassis: Empty gas switch signal short circuit to ground Benutzung des Ersatzwertes. 314600: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9201	Engine chassis: Empty gas switch signal Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314601: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9202	Engine chassis: Empty gas switch signal Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314602: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9203	Engine chassis: Empty gas switch signal short circuit to supply voltage Benutzung des Ersatzwertes. 314603: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9204	Engine chassis: Empty gas switch signal Operating status outside permissible range Benutzung des Ersatzwertes. 314604: Check operational status of engine	A700		E	1
8A9206	Engine chassis: Empty gas switch signal Value implausible at engine standstill no reaction 314606: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9300	Engine chassis: Switch signal "EcyStart" short circuit to ground Benutzung des Ersatzwertes. 314700: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9301	Engine chassis: Switch signal "EcyStart" Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314701: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9302	Engine chassis: Switch signal "EcyStart" Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314702: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9303	Engine chassis: Switch signal "EcyStart" short circuit to supply voltage Benutzung des Ersatzwertes. 314703: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9304	Engine chassis: Switch signal "EcyStart" Operating status outside permissible range Benutzung des Ersatzwertes. 314704: Check operational status of engine	A700		E	1
8A9306	Engine chassis: Switch signal "EcyStart" Value implausible at engine standstill no reaction 314706: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9400	Engine chassis: Switch signal "DelayEcyStart" short circuit to ground Benutzung des Ersatzwertes. 314800: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9401	Engine chassis: Switch signal "DelayEcyStart" Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314801: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9402	Engine chassis: Switch signal "DelayEcyStart" Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314802: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9403	Engine chassis: Switch signal "DelayEcyStart" short circuit to supply voltage Benutzung des Ersatzwertes. 314803: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9404	Engine chassis: Switch signal "DelayEcyStart" Operating status outside permissible range Benutzung des Ersatzwertes. 314804: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9406	Engine chassis: Switch signal "DelayEcyStart" Value implausible at engine standstill no reaction 314806: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9500	Engine chassis: Switch signal Notstopp short circuit to ground Benutzung des Ersatzwertes. 314900: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9501	Engine chassis: Switch signal Notstopp Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314901: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9502	Engine chassis: Switch signal Notstopp Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314902: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9503	Engine chassis: Switch signal Notstopp short circuit to supply voltage Benutzung des Ersatzwertes. 314903: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9504	Engine chassis: Switch signal Notstopp Operating status outside permissible range Benutzung des Ersatzwertes. 314904: Check operational status of engine	A700		E	1
8A9506	Engine chassis: Switch signal Notstopp Value implausible at engine standstill no reaction 314906: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9600	Engine chassis: Switch signal "Slave on" short circuit to ground Benutzung des Ersatzwertes. 315000: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9601	Engine chassis: Switch signal "Slave on" Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315001: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9602	Engine chassis: Switch signal "Slave on" Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315002: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9603	Engine chassis: Switch signal "Slave on" short circuit to supply voltage Benutzung des Ersatzwertes. 315003: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9604	Engine chassis: Switch signal "Slave on" Operating status outside permissible range Benutzung des Ersatzwertes. 315004: Check operational status of engine	A700		E	1
8A9606	Engine chassis: Switch signal "Slave on" Value implausible at engine standstill no reaction 315006: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9700	Engine chassis: Switch signal fan reversed short circuit to ground Benutzung des Ersatzwertes. 315100: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9701	Engine chassis: Switch signal fan reversed Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315101: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9702	Engine chassis: Switch signal fan reversed Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315102: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9703	Engine chassis: Switch signal fan reversed short circuit to supply voltage Benutzung des Ersatzwertes. 315103: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9704	Engine chassis: Switch signal fan reversed Operating status outside permissible range Benutzung des Ersatzwertes. 315104: Check operational status of engine	A700		E	1
8A9706	Engine chassis: Switch signal fan reversed Value implausible at engine standstill no reaction 315106: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9800	Engine chassis: Switch signal fan reversed manual short circuit to ground Benutzung des Ersatzwertes. 315200: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9801	Engine chassis: Switch signal fan reversed manual Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315201: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9802	Engine chassis: Switch signal fan reversed manual Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315202: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9803	Engine chassis: Switch signal fan reversed manual short circuit to supply voltage Benutzung des Ersatzwertes. 315203: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9804	Engine chassis: Switch signal fan reversed manual Operating status outside permissible range Benutzung des Ersatzwertes. 315204: Check operational status of engine	A700		E	1
8A9806	Engine chassis: Switch signal fan reversed manual Value implausible at engine standstill no reaction 315206: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9900	Engine chassis: Air filter vacuum pr. switch 1 short circuit to ground Benutzung des Ersatzwertes. 315300: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9901	Engine chassis: Air filter vacuum pr. switch 1 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315301: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9902	Engine chassis: Air filter vacuum pr. switch 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315302: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9903	Engine chassis: Air filter vacuum pr. switch 1 short circuit to supply voltage Benutzung des Ersatzwertes. 315303: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9904	Engine chassis: Air filter vacuum pr. switch 1 Operating status outside permissible range Benutzung des Ersatzwertes. 315304: Check operational status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9906	Engine chassis: Air filter vacuum pr. switch 1 Value implausible at engine standstill no reaction 315306: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9A00	Engine chassis: Air filter vacuum pr. switch 2 short circuit to ground Benutzung des Ersatzwertes. 315400: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9A01	Engine chassis: Air filter vacuum pr. switch 2 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315401: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9A02	Engine chassis: Air filter vacuum pr. switch 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315402: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9A03	Engine chassis: Air filter vacuum pr. switch 2 short circuit to supply voltage Benutzung des Ersatzwertes. 315403: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9A04	Engine chassis: Air filter vacuum pr. switch 2 Operating status outside permissible range Benutzung des Ersatzwertes. 315404: Check operational status of engine	A700		E	1
8A9A06	Engine chassis: Air filter vacuum pr. switch 2 Value implausible at engine standstill no reaction 315406: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9B00	Engine chassis: Sensor Water in fuel short circuit to ground Benutzung des Ersatzwertes. 315500: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9B01	Engine chassis: Sensor Water in fuel Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315501: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9B02	Engine chassis: Sensor Water in fuel Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315502: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9B03	Engine chassis: Sensor Water in fuel short circuit to supply voltage Benutzung des Ersatzwertes. 315503: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9B04	Engine chassis: Sensor Water in fuel Operating status outside permissible range Benutzung des Ersatzwertes. 315504: Check operational status of engine	A700		E	1
8A9B06	Engine chassis: Sensor Water in fuel Value implausible at engine standstill no reaction 315506: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9C00	Engine chassis: Coolant level sensor short circuit to ground Benutzung des Ersatzwertes. 315600: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9C01	Engine chassis: Coolant level sensor Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315601: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9C02	Engine chassis: Coolant level sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315602: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9C03	Engine chassis: Coolant level sensor short circuit to supply voltage Benutzung des Ersatzwertes. 315603: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9C04	Engine chassis: Coolant level sensor Operating status outside permissible range Benutzung des Ersatzwertes. 315604: Check operational status of engine	A700		E	1
8A9C06	Engine chassis: Coolant level sensor Value implausible at engine standstill no reaction 315606: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8A9D00	Engine chassis: Flame start system short circuit to ground Benutzung des Ersatzwertes. 315700: Turn ignition off/on, possibly change engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9D01	Engine chassis: Flame start system Line interruption or short circuit after supply voltage Benutzung des Ersatzwertes. 315701: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9D02	Engine chassis: Flame start system Line interruption or short circuit after ground Benutzung des Ersatzwertes. 315702: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9D03	Engine chassis: Flame start system short circuit to supply voltage Benutzung des Ersatzwertes. 315703: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9D04	Engine chassis: Flame start system Operating data outside permissible range Benutzung des Ersatzwertes. 315704: Check op. status of engine	A700		E	1
8A9D06	Engine chassis: Flame start system Test values implausible at engine standstill no reaction 315706: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9E00	Engine chassis: Flame start system 2 short circuit to ground Benutzung des Ersatzwertes. 315800: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9E01	Engine chassis: Flame start system 2 Line interruption or short circuit after supply voltage Benutzung des Ersatzwertes. 315801: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9E02	Engine chassis: Flame start system 2 Line interruption or short circuit after ground Benutzung des Ersatzwertes. 315802: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9E03	Engine chassis: Flame start system 2 short circuit to supply voltage Benutzung des Ersatzwertes. 315803: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9E04	Engine chassis: Flame start system 2 Operating data outside permissible range Benutzung des Ersatzwertes. 315804: Check op. status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8A9E06	Engine chassis: Flame start system 2 Test values implausible at engine standstill no reaction 315806: Turn ignition off/on, possibly change engine control unit	A700		E	1
8A9F00	Engine chassis: Input signal request engine brake short circuit to ground Benutzung des Ersatzwertes. 315900: Check wiring, control unit	A700		E	1
8A9F01	Engine chassis: Input signal request engine brake Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315901: Check wiring, control unit	A700		E	1
8A9F02	Engine chassis: Input signal request engine brake Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315902: Check wiring, control unit	A700		E	1
8A9F03	Engine chassis: Input signal request engine brake short circuit to supply voltage Benutzung des Ersatzwertes. 315903: Check wiring, control unit	A700		E	1
8A9F04	Engine chassis: Input signal request engine brake Operating status outside permissible range Benutzung des Ersatzwertes. 315904: Check wiring, control unit	A700		E	1
8A9F06	Engine chassis: Input signal request engine brake Value implausible at engine standstill no reaction 315906: Check wiring, control unit	A700		E	1
8AA000	Engine chassis: Input signal water in fuel 2 short circuit to ground Benutzung des Ersatzwertes. 315900: Check wiring, control unit	A700		E	1
8AA001	Engine chassis: Input signal water in fuel 2 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315901: Check wiring, control unit	A700		E	1
8AA002	Engine chassis: Input signal water in fuel 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 316000: Check wiring, control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AA003	Engine chassis: Input signal water in fuel 2 short circuit to supply voltage Benutzung des Ersatzwertes. 316001: Check wiring, control unit	A700		E	1
8AA004	Engine chassis: Input signal water in fuel 2 Operating status outside permissible range Benutzung des Ersatzwertes. 316002: Check wiring, control unit	A700		E	1
8AA006	Engine chassis: Input signal water in fuel 2 Value implausible at engine standstill no reaction 316004: Check wiring, control unit	A700		E	1
8AA100	Engine chassis: Input signal rpm increase short circuit to ground Benutzung des Ersatzwertes. 316005: Check wiring, control unit	A700		E	1
8AA101	Engine chassis: Input signal rpm increase Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 316006: Check wiring, control unit	A700		E	1
8AA102	Engine chassis: Input signal rpm increase Short circuit after ground or broken wire Benutzung des Ersatzwertes. 316100: Check wiring, control unit	A700		E	1
8AA103	Engine chassis: Input signal rpm increase short circuit to supply voltage Benutzung des Ersatzwertes. 316101: Check wiring, control unit	A700		E	1
8AA104	Engine chassis: Input signal rpm increase Operating status outside permissible range Benutzung des Ersatzwertes. 316102: Check wiring, control unit	A700		E	1
8AA106	Engine chassis: Input signal rpm increase Value implausible at engine standstill no reaction 316103: Check wiring, control unit	A700		E	1
8AA200	Engine chassis: Input signal rpm decrease short circuit to ground Benutzung des Ersatzwertes. 316106: Check wiring, control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AA201	Engine chassis: Input signal rpm decrease Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 316200: Check wiring, control unit	A700		E	1
8AA202	Engine chassis: Input signal rpm decrease Short circuit after ground or broken wire Benutzung des Ersatzwertes. 316201: Check wiring, control unit	A700		E	1
8AA203	Engine chassis: Input signal rpm decrease short circuit to supply voltage Benutzung des Ersatzwertes. 316202: Check wiring, control unit	A700		E	1
8AA204	Engine chassis: Input signal rpm decrease Operating status outside permissible range Benutzung des Ersatzwertes. 316203: Check wiring, control unit	A700		E	1
8AA206	Engine chassis: Input signal rpm decrease Value implausible at engine standstill no reaction 316206: Check wiring, control unit	A700		E	1
8AA300	Engine chassis: Input signal fixed rpm short circuit to ground 319500	A700		E	1
8AA301	Engine chassis: Input signal fixed rpm Line interruption or short circuit after supply voltage 319501	A700		E	1
8AA302	Engine chassis: Input signal fixed rpm Line interruption or short circuit after ground 319502	A700		E	1
8AA303	Engine chassis: Input signal fixed rpm short circuit to supply voltage 319503	A700		E	1
8AA306	Engine chassis: Input signal fixed rpm Test values implausible at engine standstill 319504	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AC300	Engine chassis: Actuation Injection Cyl. 1 Interruption or current remeasuring erroneous no reaction 319500: Check cable, plug, injector, engine control unit	A700		E	1
8AC301	Engine chassis: Actuation Injection Cyl. 1 Maximum current ground switch exceeded Injector unit is not energized 319501: Check cable, plug, injector, engine control unit	A700		E	1
8AC302	Engine chassis: Actuation Injection Cyl. 1 Maximum current Plus switch exceeded Injector unit is not energized 319502: Check cable, plug, injector, engine control unit	A700		E	1
8AC303	Engine chassis: Actuation Injection Cyl. 1 No increase time measured no reaction 319503: Check cable, plug, injector, engine control unit	A700		E	1
8AC304	Engine chassis: Actuation Injection Cyl. 1 Increase time too large no reaction 319504: Check cable, plug, injector, engine control unit	A700		E	1
8AC305	Engine chassis: Actuation Injection Cyl. 1 Cyl. Overlap Engine shut off 319505: Load new software in engine control unit	A700		E	1
8AC306	Engine chassis: Actuation Injection Cyl. 1 No fly time measured no reaction 319506: Check cable, plug, injector, engine control unit	A700		E	1
8AC307	Engine chassis: Actuation Injection Cyl. 1 Fly time too small no reaction 319507: Check cable, plug, injector, engine control unit	A700		E	1
8AC308	Engine chassis: Actuation Injection Cyl. 1 Fly time too large no reaction 319508: Check cable, plug, injector, engine control unit	A700		E	1
8AC400	Engine chassis: Actuation Injection Cyl. 2 Interruption or current remeasuring erroneous no reaction 319600: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AC401	Engine chassis: Actuation Injection Cyl. 2 Maximum current ground switch exceeded Injector unit is not energized 319601: Check cable, plug, injector, engine control unit	A700		E	1
8AC402	Engine chassis: Actuation Injection Cyl. 2 Maximum current Plus switch exceeded Injector unit is not energized 319602: Check cable, plug, injector, engine control unit	A700		E	1
8AC403	Engine chassis: Actuation Injection Cyl. 2 No increase time measured no reaction 319603: Check cable, plug, injector, engine control unit	A700		E	1
8AC404	Engine chassis: Actuation Injection Cyl. 2 Increase time too large no reaction 319604: Check cable, plug, injector, engine control unit	A700		E	1
8AC405	Engine chassis: Actuation Injection Cyl. 2 Cyl. Overlap Engine shut off 319605: Load new software in engine control unit	A700		E	1
8AC406	Engine chassis: Actuation Injection Cyl. 2 No fly time measured no reaction 319606: Check cable, plug, injector, engine control unit	A700		E	1
8AC407	Engine chassis: Actuation Injection Cyl. 2 Fly time too small no reaction 319607: Check cable, plug, injector, engine control unit	A700		E	1
8AC408	Engine chassis: Actuation Injection Cyl. 2 Fly time too large no reaction 319608: Check cable, plug, injector, engine control unit	A700		E	1
8AC500	Engine chassis: Actuation Injection Cyl. 3 Interruption or current remeasuring erroneous no reaction 319700: Check cable, plug, injector, engine control unit	A700		E	1
8AC501	Engine chassis: Actuation Injection Cyl. 3 Maximum current ground switch exceeded Injector unit is not energized 319701: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AC502	Engine chassis: Actuation Injection Cyl. 3 Maximum current Plus switch exceeded Injector unit is not energized 319702: Check cable, plug, injector, engine control unit	A700		E	1
8AC503	Engine chassis: Actuation Injection Cyl. 3 No increase time measured no reaction 319703: Check cable, plug, injector, engine control unit	A700		E	1
8AC504	Engine chassis: Actuation Injection Cyl. 3 Increase time too large no reaction 319704: Check cable, plug, injector, engine control unit	A700		E	1
8AC505	Engine chassis: Actuation Injection Cyl. 3 Cyl. Overlap Engine shut off 319705: Load new software in engine control unit	A700		E	1
8AC506	Engine chassis: Actuation Injection Cyl. 3 No fly time measured no reaction 319706: Check cable, plug, injector, engine control unit	A700		E	1
8AC507	Engine chassis: Actuation Injection Cyl. 3 Fly time too small no reaction 319707: Check cable, plug, injector, engine control unit	A700		E	1
8AC508	Engine chassis: Actuation Injection Cyl. 3 Fly time too large no reaction 319708: Check cable, plug, injector, engine control unit	A700		E	1
8AC600	Engine chassis: Actuation Injection Cyl. 4 Interruption or current remeasuring erroneous no reaction 319800: Check cable, plug, injector, engine control unit	A700		E	1
8AC601	Engine chassis: Actuation Injection Cyl. 4 Maximum current ground switch exceeded Injector unit is not energized 319801: Check cable, plug, injector, engine control unit	A700		E	1
8AC602	Engine chassis: Actuation Injection Cyl. 4 Maximum current Plus switch exceeded Injector unit is not energized 319802: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AC603	Engine chassis: Actuation Injection Cyl. 4 No increase time measured no reaction 319803: Check cable, plug, injector, engine control unit	A700		E	1
8AC604	Engine chassis: Actuation Injection Cyl. 4 Increase time too large no reaction 319804: Check cable, plug, injector, engine control unit	A700		E	1
8AC605	Engine chassis: Actuation Injection Cyl. 4 Cyl. Overlap Engine shut off 319805: Load new software in engine control unit	A700		E	1
8AC606	Engine chassis: Actuation Injection Cyl. 4 No fly time measured no reaction 319806: Check cable, plug, injector, engine control unit	A700		E	1
8AC607	Engine chassis: Actuation Injection Cyl. 4 Fly time too small no reaction 319807: Check cable, plug, injector, engine control unit	A700		E	1
8AC608	Engine chassis: Actuation Injection Cyl. 4 Fly time too large no reaction 319808: Check cable, plug, injector, engine control unit	A700		E	1
8AC700	Engine chassis: Actuation Injection Cyl. 5 Interruption or current remeasuring erroneous no reaction 319900: Check cable, plug, injector, engine control unit	A700		E	1
8AC701	Engine chassis: Actuation Injection Cyl. 5 Maximum current ground switch exceeded Injector unit is not energized 319901: Check cable, plug, injector, engine control unit	A700		E	1
8AC702	Engine chassis: Actuation Injection Cyl. 5 Maximum current Plus switch exceeded Injector unit is not energized 319902: Check cable, plug, injector, engine control unit	A700		E	1
8AC703	Engine chassis: Actuation Injection Cyl. 5 No increase time measured no reaction 319903: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AC704	Engine chassis: Actuation Injection Cyl. 5 Increase time too large no reaction 319904: Check cable, plug, injector, engine control unit	A700		E	1
8AC705	Engine chassis: Actuation Injection Cyl. 5 Cyl. Overlap Engine shut off 319905: Load new software in engine control unit	A700		E	1
8AC706	Engine chassis: Actuation Injection Cyl. 5 No fly time measured no reaction 319906: Check cable, plug, injector, engine control unit	A700		E	1
8AC707	Engine chassis: Actuation Injection Cyl. 5 Fly time too small no reaction 319907: Check cable, plug, injector, engine control unit	A700		E	1
8AC708	Engine chassis: Actuation Injection Cyl. 5 Fly time too large no reaction 319908: Check cable, plug, injector, engine control unit	A700		E	1
8AC800	Engine chassis: Actuation Injection Cyl. 6 Interruption or current remeasuring erroneous no reaction 320000: Check cable, plug, injector, engine control unit	A700		E	1
8AC801	Engine chassis: Actuation Injection Cyl. 6 Maximum current ground switch exceeded Injector unit is not energized 320001: Check cable, plug, injector, engine control unit	A700		E	1
8AC802	Engine chassis: Actuation Injection Cyl. 6 Maximum current Plus switch exceeded Injector unit is not energized 320002: Check cable, plug, injector, engine control unit	A700		E	1
8AC803	Engine chassis: Actuation Injection Cyl. 6 No increase time measured no reaction 320003: Check cable, plug, injector, engine control unit	A700		E	1
8AC804	Engine chassis: Actuation Injection Cyl. 6 Increase time too large no reaction 320004: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AC805	Engine chassis: Actuation Injection Cyl. 6 Cyl. Overlap Engine shut off 320005: Load new software in engine control unit	A700		E	1
8AC806	Engine chassis: Actuation Injection Cyl. 6 No fly time measured no reaction 320006: Check cable, plug, injector, engine control unit	A700		E	1
8AC807	Engine chassis: Actuation Injection Cyl. 6 Fly time too small no reaction 320007: Check cable, plug, injector, engine control unit	A700		E	1
8AC808	Engine chassis: Actuation Injection Cyl. 6 Fly time too large no reaction 320008: Check cable, plug, injector, engine control unit	A700		E	1
8AC900	Engine chassis: Actuation Injection Cyl. 7 Interruption or current remeasuring erroneous no reaction 320100: Check cable, plug, injector, engine control unit	A700		E	1
8AC901	Engine chassis: Actuation Injection Cyl. 7 Maximum current ground switch exceeded Injector unit is not energized 320101: Check cable, plug, injector, engine control unit	A700		E	1
8AC902	Engine chassis: Actuation Injection Cyl. 7 Maximum current Plus switch exceeded Injector unit is not energized 320102: Check cable, plug, injector, engine control unit	A700		E	1
8AC903	Engine chassis: Actuation Injection Cyl. 7 No increase time measured no reaction 320103: Check cable, plug, injector, engine control unit	A700		E	1
8AC904	Engine chassis: Actuation Injection Cyl. 7 Increase time too large no reaction 320104: Check cable, plug, injector, engine control unit	A700		E	1
8AC905	Engine chassis: Actuation Injection Cyl. 7 Cyl. Overlap Engine shut off 320105: Load new software in engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AC906	Engine chassis: Actuation Injection Cyl. 7 No fly time measured no reaction 320106: Check cable, plug, injector, engine control unit	A700		E	1
8AC907	Engine chassis: Actuation Injection Cyl. 7 Fly time too small no reaction 320107: Check cable, plug, injector, engine control unit	A700		E	1
8AC908	Engine chassis: Actuation Injection Cyl. 7 Fly time too large no reaction 320108: Check cable, plug, injector, engine control unit	A700		E	1
8ACA00	Engine chassis: Actuation Injection Cyl. 8 Interruption or current remeasuring erroneous no reaction 320200: Check cable, plug, injector, engine control unit	A700		E	1
8ACA01	Engine chassis: Actuation Injection Cyl. 8 Maximum current ground switch exceeded Injector unit is not energized 320201: Check cable, plug, injector, engine control unit	A700		E	1
8ACA02	Engine chassis: Actuation Injection Cyl. 8 Maximum current Plus switch exceeded Injector unit is not energized 320202: Check cable, plug, injector, engine control unit	A700		E	1
8ACA03	Engine chassis: Actuation Injection Cyl. 8 No increase time measured no reaction 320203: Check cable, plug, injector, engine control unit	A700		E	1
8ACA04	Engine chassis: Actuation Injection Cyl. 8 Increase time too large no reaction 320204: Check cable, plug, injector, engine control unit	A700		E	1
8ACA05	Engine chassis: Actuation Injection Cyl. 8 Cyl. Overlap Engine shut off 320205: Load new software in engine control unit	A700		E	1
8ACA06	Engine chassis: Actuation Injection Cyl. 8 No fly time measured no reaction 320206: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8ACA07	Engine chassis: Actuation Injection Cyl. 8 Fly time too small no reaction 320207: Check cable, plug, injector, engine control unit	A700		E	1
8ACA08	Engine chassis: Actuation Injection Cyl. 8 Fly time too large no reaction 320208: Check cable, plug, injector, engine control unit	A700		E	1
8ACB00	Engine chassis: Actuation Injection Cyl. 9 Interruption or current remeasuring erroneous no reaction 320300: Check cable, plug, injector, engine control unit	A700		E	1
8ACB01	Engine chassis: Actuation Injection Cyl. 9 Maximum current ground switch exceeded Injector unit is not energized 320301: Check cable, plug, injector, engine control unit	A700		E	1
8ACB02	Engine chassis: Actuation Injection Cyl. 9 Maximum current Plus switch exceeded Injector unit is not energized 320302: Check cable, plug, injector, engine control unit	A700		E	1
8ACB03	Engine chassis: Actuation Injection Cyl. 9 No increase time measured no reaction 320303: Check cable, plug, injector, engine control unit	A700		E	1
8ACB04	Engine chassis: Actuation Injection Cyl. 9 Increase time too large no reaction 320304: Check cable, plug, injector, engine control unit	A700		E	1
8ACB05	Engine chassis: Actuation Injection Cyl. 9 Cyl. Overlap Engine shut off 320305: Load new software in engine control unit	A700		E	1
8ACB06	Engine chassis: Actuation Injection Cyl. 9 No fly time measured no reaction 320306: Check cable, plug, injector, engine control unit	A700		E	1
8ACB07	Engine chassis: Actuation Injection Cyl. 9 Fly time too small no reaction 320307: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8ACB08	Engine chassis: Actuation Injection Cyl. 9 Fly time too large no reaction 320308: Check cable, plug, injector, engine control unit	A700		E	1
8ACC00	Engine chassis: Actuation Injection Cyl. 10 Interruption or current remeasuring erroneous no reaction 320400: Check cable, plug, injector, engine control unit	A700		E	1
8ACC01	Engine chassis: Actuation Injection Cyl. 10 Maximum current ground switch exceeded Injector unit is not energized 320401: Check cable, plug, injector, engine control unit	A700		E	1
8ACC02	Engine chassis: Actuation Injection Cyl. 10 Maximum current Plus switch exceeded Injector unit is not energized 320402: Check cable, plug, injector, engine control unit	A700		E	1
8ACC03	Engine chassis: Actuation Injection Cyl. 10 No increase time measured no reaction 320403: Check cable, plug, injector, engine control unit	A700		E	1
8ACC04	Engine chassis: Actuation Injection Cyl. 10 Increase time too large no reaction 320404: Check cable, plug, injector, engine control unit	A700		E	1
8ACC05	Engine chassis: Actuation Injection Cyl. 10 Cyl. Overlap Engine shut off 320405: Load new software in engine control unit	A700		E	1
8ACC06	Engine chassis: Actuation Injection Cyl. 10 No fly time measured no reaction 320406: Check cable, plug, injector, engine control unit	A700		E	1
8ACC07	Engine chassis: Actuation Injection Cyl. 10 Fly time too small no reaction 320407: Check cable, plug, injector, engine control unit	A700		E	1
8ACC08	Engine chassis: Actuation Injection Cyl. 10 Fly time too large no reaction 320408: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8ACD00	Engine chassis: Actuation Injection Cyl. 11 Interruption or current remeasuring erroneous no reaction 320500: Check cable, plug, injector, engine control unit	A700		E	1
8ACD01	Engine chassis: Actuation Injection Cyl. 11 Maximum current ground switch exceeded Injector unit is not energized 320501: Check cable, plug, injector, engine control unit	A700		E	1
8ACD02	Engine chassis: Actuation Injection Cyl. 11 Maximum current Plus switch exceeded Injector unit is not energized 320502: Check cable, plug, injector, engine control unit	A700		E	1
8ACD03	Engine chassis: Actuation Injection Cyl. 11 No increase time measured no reaction 320503: Check cable, plug, injector, engine control unit	A700		E	1
8ACD04	Engine chassis: Actuation Injection Cyl. 11 Increase time too large no reaction 320504: Check cable, plug, injector, engine control unit	A700		E	1
8ACD05	Engine chassis: Actuation Injection Cyl. 11 Cyl. Overlap Engine shut off 320505: Load new software in engine control unit	A700		E	1
8ACD06	Engine chassis: Actuation Injection Cyl. 11 No fly time measured no reaction 320506: Check cable, plug, injector, engine control unit	A700		E	1
8ACD07	Engine chassis: Actuation Injection Cyl. 11 Fly time too small no reaction 320507: Check cable, plug, injector, engine control unit	A700		E	1
8ACD08	Engine chassis: Actuation Injection Cyl. 11 Fly time too large no reaction 320508: Check cable, plug, injector, engine control unit	A700		E	1
8ACE00	Engine chassis: Actuation Injection Cyl. 12 Interruption or current remeasuring erroneous no reaction 320600: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8ACE01	Engine chassis: Actuation Injection Cyl. 12 Maximum current ground switch exceeded Injector unit is not energized 320601: Check cable, plug, injector, engine control unit	A700		E	1
8ACE02	Engine chassis: Actuation Injection Cyl. 12 Maximum current Plus switch exceeded Injector unit is not energized 320602: Check cable, plug, injector, engine control unit	A700		E	1
8ACE03	Engine chassis: Actuation Injection Cyl. 12 No increase time measured no reaction 320603: Check cable, plug, injector, engine control unit	A700		E	1
8ACE04	Engine chassis: Actuation Injection Cyl. 12 Increase time too large no reaction 320604: Check cable, plug, injector, engine control unit	A700		E	1
8ACE05	Engine chassis: Actuation Injection Cyl. 12 Cyl. Overlap Engine shut off 320605: Load new software in engine control unit	A700		E	1
8ACE06	Engine chassis: Actuation Injection Cyl. 12 No fly time measured no reaction 320606: Check cable, plug, injector, engine control unit	A700		E	1
8ACE07	Engine chassis: Actuation Injection Cyl. 12 Fly time too small no reaction 320607: Check cable, plug, injector, engine control unit	A700		E	1
8ACE08	Engine chassis: Actuation Injection Cyl. 12 Fly time too large no reaction 320608: Check cable, plug, injector, engine control unit	A700		E	1
8ACF00	Engine chassis: Actuation injection cylinder 13 Interruption or current remeasuring erroneous no reaction 320700: Check cable, plug, injector, engine control unit	A700		E	1
8ACF01	Engine chassis: Actuation injection cylinder 13 Maximum current ground switch exceeded Injector unit is not energized 320701: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8ACF02	Engine chassis: Actuation injection cylinder 13 Maximum current Plus switch exceeded Injector unit is not energized 320702: Check cable, plug, injector, engine control unit	A700		E	1
8ACF03	Engine chassis: Actuation injection cylinder 13 No increase time measured no reaction 320703: Check cable, plug, injector, engine control unit	A700		E	1
8ACF04	Engine chassis: Actuation injection cylinder 13 Increase time too large no reaction 320704: Check cable, plug, injector, engine control unit	A700		E	1
8ACF05	Engine chassis: Actuation injection cylinder 13 Cyl. Overlap Engine shut off 320705: Load new software in engine control unit	A700		E	1
8ACF06	Engine chassis: Actuation injection cylinder 13 No fly time measured no reaction 320706: Check cable, plug, injector, engine control unit	A700		E	1
8ACF07	Engine chassis: Actuation injection cylinder 13 Fly time too small no reaction 320707: Check cable, plug, injector, engine control unit	A700		E	1
8ACF08	Engine chassis: Actuation injection cylinder 13 Fly time too large no reaction 320708: Check cable, plug, injector, engine control unit	A700		E	1
8AD000	Engine chassis: Actuation injection cylinder 14 Interruption or current remeasuring erroneous no reaction 320800: Check cable, plug, injector, engine control unit	A700		E	1
8AD001	Engine chassis: Actuation injection cylinder 14 Maximum current ground switch exceeded Injector unit is not energized 320801: Check cable, plug, injector, engine control unit	A700		E	1
8AD002	Engine chassis: Actuation injection cylinder 14 Maximum current Plus switch exceeded Injector unit is not energized 320802: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AD003	Engine chassis: Actuation injection cylinder 14 No increase time measured no reaction 320803: Check cable, plug, injector, engine control unit	A700		E	1
8AD004	Engine chassis: Actuation injection cylinder 14 Increase time too large no reaction 320804: Check cable, plug, injector, engine control unit	A700		E	1
8AD005	Engine chassis: Actuation injection cylinder 14 Cyl. Overlap Engine shut off 320805: Load new software in engine control unit	A700		E	1
8AD006	Engine chassis: Actuation injection cylinder 14 No fly time measured no reaction 320806: Check cable, plug, injector, engine control unit	A700		E	1
8AD007	Engine chassis: Actuation injection cylinder 14 Fly time too small no reaction 320807: Check cable, plug, injector, engine control unit	A700		E	1
8AD008	Engine chassis: Actuation injection cylinder 14 Fly time too large no reaction 320808: Check cable, plug, injector, engine control unit	A700		E	1
8AD100	Engine chassis: Actuation injection cylinder 15 Interruption or current remeasuring erroneous no reaction 320900: Check cable, plug, injector, engine control unit	A700		E	1
8AD101	Engine chassis: Actuation injection cylinder 15 Maximum current ground switch exceeded Injector unit is not energized 320901: Check cable, plug, injector, engine control unit	A700		E	1
8AD102	Engine chassis: Actuation injection cylinder 15 Maximum current Plus switch exceeded Injector unit is not energized 320902: Check cable, plug, injector, engine control unit	A700		E	1
8AD103	Engine chassis: Actuation injection cylinder 15 No increase time measured no reaction 320903: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AD104	Engine chassis: Actuation injection cylinder 15 Increase time too large no reaction 320904: Check cable, plug, injector, engine control unit	A700		E	1
8AD105	Engine chassis: Actuation injection cylinder 15 Cyl. Overlap Engine shut off 320905: Load new software in engine control unit	A700		E	1
8AD106	Engine chassis: Actuation injection cylinder 15 No fly time measured no reaction 320906: Check cable, plug, injector, engine control unit	A700		E	1
8AD107	Engine chassis: Actuation injection cylinder 15 Fly time too small no reaction 320907: Check cable, plug, injector, engine control unit	A700		E	1
8AD108	Engine chassis: Actuation injection cylinder 15 Fly time too large no reaction 320908: Check cable, plug, injector, engine control unit	A700		E	1
8AD200	Engine chassis: Actuation injection cylinder 16 Interruption or current remeasuring erroneous no reaction 321000: Check cable, plug, injector, engine control unit	A700		E	1
8AD201	Engine chassis: Actuation injection cylinder 16 Maximum current ground switch exceeded Injector unit is not energized 321001: Check cable, plug, injector, engine control unit	A700		E	1
8AD202	Engine chassis: Actuation injection cylinder 16 Maximum current Plus switch exceeded Injector unit is not energized 321002: Check cable, plug, injector, engine control unit	A700		E	1
8AD203	Engine chassis: Actuation injection cylinder 16 No increase time measured no reaction 321003: Check cable, plug, injector, engine control unit	A700		E	1
8AD204	Engine chassis: Actuation injection cylinder 16 Increase time too large no reaction 321004: Check cable, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AD205	Engine chassis: Actuation injection cylinder 16 Cyl. Overlap Engine shut off 321005: Load new software in engine control unit	A700		E	1
8AD206	Engine chassis: Actuation injection cylinder 16 No fly time measured no reaction 321006: Check cable, plug, injector, engine control unit	A700		E	1
8AD207	Engine chassis: Actuation injection cylinder 16 Fly time too small no reaction 321007: Check cable, plug, injector, engine control unit	A700		E	1
8AD208	Engine chassis: Actuation injection cylinder 16 Fly time too large no reaction 321008: Check cable, plug, injector, engine control unit	A700		E	1
8AD400	Engine chassis: Injection system Cylinder error Engine shut off 321200: Check cable, plug, injector, engine control unit	A700		E	1
8AD401	Engine chassis: Injection system Overlap of injection on cyl. bank A Engine shut off 321201: Load new software in engine control unit	A700		E	1
8AD402	Engine chassis: Injection system Overlap of injection on cyl. bank B Engine shut off 321202: Load new software in engine control unit	A700		E	1
8AD403	Engine chassis: Injection system Overlap of injection on cyl. bank C Engine shut off 321203: Load new software in engine control unit	A700		E	1
8AD404	Engine chassis: Injection system Overlap of injection on cyl. bank D Engine shut off 321204: Load new software in engine control unit	A700		E	1
8AD500	Engine chassis: Rpm monitoring Rpm sensor 1 has warning threshold exceeded no reaction 321300: Check engine op.(overspeed due to push op.)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AD501	Engine chassis: Rpm monitoring Rpm sensor 2 has warning threshold exceeded no reaction 321301: Check engine op.(overspeed due to push op.)	A700		E	1
8AD502	Engine chassis: Rpm monitoring Rpm sensor 1 has safety threshold exceeded Engine shut off 321302: Check engine op.(overspeed due to push op.)	A700		E	1
8AD503	Engine chassis: Rpm monitoring Rpm sensor 2 has safety threshold exceeded Engine shut off 321303: Check engine op.(overspeed due to push op.)	A700		E	1
8AD504	Engine chassis: Rpm monitoring Warning threshold exceeded no reaction 321304: Check engine op.(overspeed due to push op.)	A700		E	2
8AD505	Engine chassis: Rpm monitoring Safety threshold exceeded Engine shut off 321305: Check engine op.(overspeed due to push op.)	A700		E	2
8AD600	Engine chassis: Synchronization Rpm signals No synchronization no reaction 321400: Turn ignition off/on, check rpm and camshaft sensor	A700		E	1
8AD601	Engine chassis: Synchronization Rpm signals Incorrect distance gap <> Phase sensor no reaction 321401: Turn ignition off/on, check rpm and camshaft sensor	A700		E	1
8AD602	Engine chassis: Synchronization Rpm signals Tooth number (Impulse number) wrong Engine start not possible 321402: Turn ignition off/on, check teeth on flywheel, check rpm sensor	A700		E	1
8AD603	Engine chassis: Synchronization Rpm signals not possible, Rpm too low no reaction 321403: Turn ignition off/on, check rpm and camshaft sensor	A700		E	1
8AD604	Engine chassis: Synchronization Rpm signals Index counter cam shaft gear erroneous no reaction 321404: Turn ignition off/on, check rpm and camshaft sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AD700	Engine chassis: RPM sensor 1 Signal lost Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321500: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AD701	Engine chassis: RPM sensor 1 No signal Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321501: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AD702	Engine chassis: RPM sensor 1 Permissible signal difference within test interval exceeded Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321502: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AD703	Engine chassis: RPM sensor 1 Limit frequency exceeded Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321503: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AD704	Engine chassis: RPM sensor 1 Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321504: Check rpm sensor inst., engine control unit	A700		E	1
8AD705	Engine chassis: RPM sensor 1 Measurement erroneous Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321505: Check rpm sensor inst., engine control unit	A700		E	1
8AD800	Engine chassis: RPM sensor 2 Signal lost Em. Shut off at simult. failure of both Rpm sensors 321600: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AD801	Engine chassis: RPM sensor 2 No signal Em. Shut off at simult. failure of both Rpm sensors 321601: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AD802	Engine chassis: RPM sensor 2 Permissible signal difference within test interval exceeded Em. Shut off at simult. failure of both Rpm sensors 321602: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AD803	Engine chassis: RPM sensor 2 Limit frequency exceeded Em. Shut off at simult. failure of both Rpm sensors 321603: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AD804	Engine chassis: RPM sensor 2 Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321604: Check rpm sensor inst., sensor.	A700		E	1
8AD805	Engine chassis: RPM sensor 2 Measurement erroneous RPM determination via functioning sensor. 321605: Check rpm sensor inst., sensor.	A700		E	1
8AD900	Engine chassis: Index sensor Signal lost Em. Shut off at simult. failure of both Rpm sensors 321700: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AD901	Engine chassis: Index sensor No signal Em. Shut off at simult. failure of both Rpm sensors 321701: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AD902	Engine chassis: Index sensor Permissible signal difference within test interval exceeded Em. Shut off at simult. failure of both Rpm sensors 321702: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AD903	Engine chassis: Index sensor Limit frequency exceeded Em. Shut off at simult. failure of both Rpm sensors 321703: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AD904	Engine chassis: Index sensor Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321704: Check rpm sensor inst., sensor.	A700		E	1
8AD905	Engine chassis: Index sensor Measurement erroneous RPM determination via functioning sensor. 321705: Check rpm sensor inst., sensor.	A700		E	1
8ADA04	Engine chassis: Lambda-Measurement Regulation deviation, Lambda value too low Warning light on 321804: - Ground current sensor - Lambda Sensor - exhaust return	A700		E	1
8ADA05	Engine chassis: Lambda-Measurement Regulation deviation, Lambda value too high Warning light on 321805: - Ground current sensor - Lambda Sensor - exhaust return	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8ADA07	Engine chassis: Lambda-Measurement EGR Flow between Bank 1 and Bank 2 very asymmetric Warning light on 321807: Clean / replace actuator, check lines/linkage	A700		E	1
8ADB04	Engine chassis: Lambda-Measurement Permanent regulation deviation, Lambda value too low Warning light on 321904: - Ground current sensor - Lambda Sensor - exhaust return	A700		E	1
8ADB05	Engine chassis: Lambda-Measurement Permanent regulation deviation, Lambda value too high Warning light on 321905: - Ground current sensor - Lambda Sensor - exhaust return	A700		E	1
8ADC04	Engine chassis: charge air pressure minimum limit value fallen below Warning light on 322004: Check intake system for leaks	A700		E	1
8ADC05	Engine chassis: charge air pressure maximum limit value exceeded Warning light on 322005: Check for stuck Wastegate	A700		E	1
8AE200	Engine chassis: Injection system 2 Cylinder error Slave Modules not running (there will be no injection on this module) 322600: Check cable, plug, injector, engine control unit	A700		E	1
8AE201	Engine chassis: Injection system 2 Overlap of injection on cyl. bank A Slave Modules not running (there will be no injection on this module) 322601: Load new software in engine control unit	A700		E	1
8AE202	Engine chassis: Injection system 2 Overlap of injection on cyl. bank B Slave Modules not running (there will be no injection on this module) 322602: Load new software in engine control unit	A700		E	1
8AE203	Engine chassis: Injection system 2 Overlap of injection on cyl. bank C Slave Modules not running (there will be no injection on this module) 322603: Load new software in engine control unit	A700		E	1
8AE204	Engine chassis: Injection system 2 Overlap of injection on cyl. bank D Slave Modules not running (there will be no injection on this module) 322604: Load new software in engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AE205	Engine chassis: Injection system 2 Plus switch cyl. bank A Short circuit after ground no reaction 322605: Check cable, plug, injector, engine control unit	A700		E	1
8AE206	Engine chassis: Injection system 2 Plus switch cyl. bank B Short circuit after ground no reaction 322606: Check cable, plug, injector, engine control unit	A700		E	1
8AE207	Engine chassis: Injection system 2 Plus switch cyl. bank A short circuit after supply voltage no reaction 322607: Check cable, plug, injector, engine control unit	A700		E	1
8AE208	Engine chassis: Injection system 2 Plus switch cyl. bank B short circuit after supply voltage no reaction 322608: Check cable, plug, injector, engine control unit	A700		E	1
8AE209	Engine chassis: Injection system 2 Ground switch cyl. bank A Short circuit after ground At CR-Motor Shut off of Bank A on Slave Module 322609: Check cable, plug, injector, engine control unit	A700		E	1
8AE20A	Engine chassis: Injection system 2 Ground switch cyl. bank B Short circuit after ground At CR-Motor Shut off of Bank B on Slave Module 322610: Check cable, plug, injector, engine control unit	A700		E	1
8AE20B	Engine chassis: Injection system 2 Ground switch cyl. bank A short circuit after supply voltage no reaction 322611: Check cable, plug, injector, engine control unit	A700		E	1
8AE20C	Engine chassis: Injection system 2 Ground switch cyl. bank B short circuit after supply voltage no reaction 322612: Check cable, plug, injector, engine control unit	A700		E	1
8AE300	Engine chassis: Synchronization Rpm signals System 2 No synchronization no reaction 322700: Turn ignition off/on, check rpm and camshaft sensor	A700		E	1
8AE301	Engine chassis: Synchronization Rpm signals System 2 Incorrect distance gap <> Phase sensor no reaction 322701: Turn ignition off/on, check rpm and camshaft sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AE302	Engine chassis: Synchronization Rpm signals System 2 Tooth number (Impulse number) wrong Slave Modules not running (there will be no injection on this module) 322702: Turn ignition off/on, check teeth on flywheel, rpm sensor	A700		E	1
8AE303	Engine chassis: Synchronization Rpm signals System 2 not possible, Rpm too low no reaction 322703: Turn ignition off/on, check rpm and camshaft sensor	A700		E	1
8AE304	Engine chassis: Synchronization Rpm signals System 2 Index counter cam shaft gear erroneous no reaction 322704: Turn ignition off/on, check rpm and camshaft sensor	A700		E	1
8AE400	Engine chassis: Rpm sensor 1 System 2 Signal lost Engine output reduced. Rpm recording via camshaft sensor if o.k. 322800: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AE401	Engine chassis: Rpm sensor 1 System 2 No signal Engine output reduced. Rpm recording via camshaft sensor if o.k. 322801: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AE402	Engine chassis: Rpm sensor 1 System 2 Permissible signal difference within test interval exceeded Engine output reduced. Rpm recording via camshaft sensor if o.k. 322802: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AE403	Engine chassis: Rpm sensor 1 System 2 Limit frequency exceeded Engine output reduced. Rpm recording via camshaft sensor if o.k. 322803: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AE404	Engine chassis: Rpm sensor 1 System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322804: Check rpm sensor inst., engine control unit	A700		E	1
8AE405	Engine chassis: Rpm sensor 1 System 2 Measurement erroneous Engine output reduced. Rpm recording via camshaft sensor if o.k. 322805: Check rpm sensor inst., engine control unit	A700		E	1
8AE500	Engine chassis: Rpm sensor 2 System 2 Signal lost Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322900: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AE501	Engine chassis: Rpm sensor 2 System 2 No signal Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322901: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AE502	Engine chassis: Rpm sensor 2 System 2 Permissible signal difference within test interval exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322902: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AE503	Engine chassis: Rpm sensor 2 System 2 Limit frequency exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322903: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AE504	Engine chassis: Rpm sensor 2 System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322904: Check rpm sensor inst., sensor.	A700		E	1
8AE505	Engine chassis: Rpm sensor 2 System 2 Measurement erroneous RPM determination via functioning sensor. 322905: Check rpm sensor inst., sensor.	A700		E	1
8AE600	Engine chassis: Index sensor System 2 Signal lost Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323000: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AE601	Engine chassis: Index sensor System 2 No signal Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323001: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A700		E	1
8AE602	Engine chassis: Index sensor System 2 Permissible signal difference within test interval exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323002: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AE603	Engine chassis: Index sensor System 2 Limit frequency exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323003: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A700		E	1
8AE604	Engine chassis: Index sensor System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323004: Check rpm sensor inst., sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AE605	Engine chassis: Index sensor System 2 Measurement erroneous RPM determination via functioning sensor. 323005: Check rpm sensor inst., sensor.	A700		E	1
8AE700	Engine chassis: Hardware temperature sensor control unit 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 323100: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8AE701	Engine chassis: Hardware temperature sensor control unit 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 323101: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8AE702	Engine chassis: Hardware temperature sensor control unit 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 323102: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8AE703	Engine chassis: Hardware temperature sensor control unit 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 323103: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8AE704	Engine chassis: Hardware temperature sensor control unit 2 Sensor signal outside permissible range 1 Benutzung des Ersatzwertes. 323104: Check operational status of engine	A700		E	1
8AE705	Engine chassis: Hardware temperature sensor control unit 2 Sensor signal outside permissible range 2 Benutzung des Ersatzwertes. 323105: Check operational status of engine	A700		E	1
8AE706	Engine chassis: Hardware temperature sensor control unit 2 Plausibility error at engine off no reaction 323106: Check operational status of engine	A700		E	1
8AE800	Engine chassis: Hardware temperature sensor control unit 2 CPU Short circuit after ground or broken wire Benutzung des Ersatzwertes. 323200: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8AE801	Engine chassis: Hardware temperature sensor control unit 2 CPU Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 323201: Turn ignition off/on, possibly replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AE802	Engine chassis: Hardware temperature sensor control unit 2 CPU Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 323202: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8AE803	Engine chassis: Hardware temperature sensor control unit 2 CPU Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 323203: Turn ignition off/on, possibly replace engine control unit	A700		E	1
8AE804	Engine chassis: Hardware temperature sensor control unit 2 CPU Sensor signal outside permissible range 1 Benutzung des Ersatzwertes. 323204: Check operational status of engine	A700		E	1
8AE805	Engine chassis: Hardware temperature sensor control unit 2 CPU Sensor signal outside permissible range 2 Benutzung des Ersatzwertes. 323205: Check operational status of engine	A700		E	1
8AE806	Engine chassis: Hardware temperature sensor control unit 2 CPU Plausibility error at engine off no reaction 323206: Check operational status of engine	A700		E	1
8AE900	Engine chassis: Internal error control unit 2 Stack-overflow Slave Modules not running (there will be no injection on this module) 323300: Load new software in engine control unit or replace engine control unit	A700		E	1
8AE901	Engine chassis: Internal error control unit 2 Exception error Slave Modules not running (there will be no injection on this module) 323301: Load new software in engine control unit or replace engine control unit	A700		E	1
8AE902	Engine chassis: Internal error control unit 2 Program test Slave Modules not running (there will be no injection on this module) 323302: Load new software in engine control unit or replace engine control unit	A700		E	1
8AE903	Engine chassis: Internal error control unit 2 RAM-Test Slave Modules not running (there will be no injection on this module) 323303: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AE904	Engine chassis: Internal error control unit 2 Overflow in error stack no reaction 323304: Load new software in engine control unit or replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AE905	Engine chassis: Internal error control unit 2 Comp. time error no reaction 323305: Load new software in engine control unit or replace engine control unit	A700		E	1
8AE906	Engine chassis: Internal error control unit 2 Error-Index too large The error cannot be saved 323306: Load new software in engine control unit or replace engine control unit	A700		E	1
8AEA00	Engine chassis: Control unit 2 defective (Memory EEPROM) Error at EEPROM-access Slave Modules not running (there will be no injection on this module) 323400: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEA01	Engine chassis: Control unit 2 defective (Memory EEPROM) Check sum error Parameter memory Slave Modules not running (there will be no injection on this module) 323401: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEA02	Engine chassis: Control unit 2 defective (Memory EEPROM) Parameter memory in EEPROM is invalid Slave Modules not running (there will be no injection on this module) 323402: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEA03	Engine chassis: Control unit 2 defective (Memory EEPROM) Check sum error ECU-Page No reaction - possibly data sets or operating conditions could not be saved 323403: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEA04	Engine chassis: Control unit 2 defective (Memory EEPROM) Check sum error NMI-Page No reaction - possibly data sets or operating conditions could not be saved 323404: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEA05	Engine chassis: Control unit 2 defective (Memory EEPROM) Check sum error Workdata-Page No reaction - possibly data sets or operating conditions could not be saved 323405: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEA06	Engine chassis: Control unit 2 defective (Memory EEPROM) Check sum error load collective No reaction - possibly load collective data could not be saved 323406: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEA07	Engine chassis: Control unit 2 defective (Memory EEPROM) Structure size of load collective has changed No reaction - possibly load collective data could not be saved 323407: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AEA08	Engine chassis: Control unit 2 defective (Memory EEPROM) EEPROM-Memory full (load collective) No reaction - possibly load collective data could not be saved 323408: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEA09	Engine chassis: Control unit 2 defective (Memory EEPROM) Check sum error permanent Data No reaction - possibly data sets or operating conditions could not be saved 323409: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEB00	Engine chassis: Voltage supply System 2 voltage below required value Slave Modules not running (there will be no injection on this module) 323500: Check on board network(battery, alternator, wiring, plug).	A700		E	1
8AEB01	Engine chassis: Voltage supply System 2 excess voltage Slave Modules not running (there will be no injection on this module) 323501: Check on board network (battery, alternator, wiring, plug)	A700		E	1
8AEB02	Engine chassis: Voltage supply System 2 Digital outlet short circuit after supply voltage Slave Modules not running (there will be no injection on this module) 323502: Check wiring, engine control unit, possibly replace engine control unit	A700		E	1
8AEB03	Engine chassis: Voltage supply System 2 Error release output outlets Slave Modules not running (there will be no injection on this module) 323503: Check wiring, engine control unit, possibly replace engine control unit	A700		E	1
8AEB04	Engine chassis: Voltage supply System 2 PS1-Pin erroneous/missing Slave Modules not running (there will be no injection on this module) 323504: Check on board network in ref. to PS1 (terminal 30/31), engine control unit	A700		E	1
8AEB05	Engine chassis: Voltage supply System 2 Reference voltage 12V below permissible range Slave Modules not running (there will be no injection on this module) 323505: Check supply voltage Rpm sensors, on board network, engine control unit	A700		E	1
8AEB06	Engine chassis: Voltage supply System 2 Reference voltage 12V above permissible range Slave Modules not running (there will be no injection on this module) 323506: Check supply voltage Rpm sensors, on board network, engine control unit	A700		E	1
8AEC00	Engine chassis: Control unit 2 defective (FLASH-Memory) Check sum error Parameter memory Slave Modules not running (there will be no injection on this module) 323600: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AEC01	Engine chassis: Control unit 2 defective (FLASH-Memory) Invalid data, default values are used Slave Modules not running (there will be no injection on this module) 323601: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEC02	Engine chassis: Control unit 2 defective (FLASH-Memory) Error during delete Slave Modules not running (there will be no injection on this module) 323602: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEC03	Engine chassis: Control unit 2 defective (FLASH-Memory) Error during programming Slave Modules not running (there will be no injection on this module) 323603: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEC04	Engine chassis: Control unit 2 defective (FLASH-Memory) Error during check Slave Modules not running (there will be no injection on this module) 323604: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AEC05	Engine chassis: Control unit 2 defective (FLASH-Memory) Data inconsistent Slave Modules not running (there will be no injection on this module) 323605: Turn ignition off/on, if error not remedied, replace engine control unit	A700		E	1
8AED00	Engine chassis: Outlet engine rpm System 2 Broken wire or Short circuit after ground 323700: Check wiring harness, plug, conn. Modul	A700		E	1
8AED01	Engine chassis: Outlet engine rpm System 2 Broken wire or short circuit after supply voltage 323701: Check wiring harness, plug, conn. Modul	A700		E	1
8AEE00	Engine chassis: Safety checks (SIL) Access error Data memory Engine stop, Start lock 323800: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE01	Engine chassis: Safety checks (SIL) Access error Data memory Engine stop, Start lock 323801: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE02	Engine chassis: Safety checks (SIL) Access error Data memory Engine stop, Start lock 323802: Turn ignition on / off, Update or replace engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AEE03	Engine chassis: Safety checks (SIL) Emerg. shut off (DI6) Engine stop, Start lock 323803: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE04	Engine chassis: Safety checks (SIL) Emerg. shut off (Level DI6) Engine stop, Start lock 323804: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE05	Engine chassis: Safety checks (SIL) Plausibility error status Kl.15 <=> emerg. stop Engine stop, Start lock 323805: Deactivate emerg. stop and turn ignition on / off	A700		E	2
8AEE06	Engine chassis: Safety checks (SIL) Plausibility error Monitoring Kl.15 Engine stop, Start lock 323806: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE07	Engine chassis: Safety checks (SIL) Plausibility error Monitoring Kl.15 Engine stop, Start lock 323807: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE08	Engine chassis: Safety checks (SIL) Reference voltage 1.5 V ADC/DMA erroneous Engine stop, Start lock 323808: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE09	Engine chassis: Safety checks (SIL) Error in program run control Engine stop, Start lock 323809: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE0A	Engine chassis: Safety checks (SIL) Error in program run control Engine stop, Start lock 323810: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE0B	Engine chassis: Safety checks (SIL) Error in program run control Engine stop, Start lock 323811: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEE0D	Engine chassis: Safety checks (SIL) Internal error data memory (checksum flash) Engine stop, Start lock 323813: Turn ignition on / off, Update or replace engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AEF00	Engine chassis: Safety checks (SIL) Internal error data memory (checksum Parameter) Engine stop, Start lock 323900: Load valid data set	A700		E	2
8AEF01	Engine chassis: Safety checks (SIL) Internal error data memory (Safety buffer) Engine stop, Start lock 323901: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF02	Engine chassis: Safety checks (SIL) Plausibility error Monitoring PS1-Pin Engine stop, Start lock 323902: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF03	Engine chassis: Safety checks (SIL) Plausibility error Monitoring PS1-Pin Engine stop, Start lock 323903: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF04	Engine chassis: Safety checks (SIL) Plausibility error Monitoring KI.50 Engine stop, Start lock 323904: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF05	Engine chassis: Safety checks (SIL) Plausibility error Monitoring air flap Engine stop, Start lock 323905: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF06	Engine chassis: Safety checks (SIL) Injector Bank A permanently energized Engine stop, Start lock 323906: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF07	Engine chassis: Safety checks (SIL) Injector Bank B permanently energized Engine stop, Start lock 323907: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF08	Engine chassis: Safety checks (SIL) Injector Bank C permanently energized Engine stop, Start lock 323908: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF09	Engine chassis: Safety checks (SIL) Injector Bank D permanently energized Engine stop, Start lock 323909: Turn ignition on / off, Update or replace engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AEF0A	Engine chassis: Safety checks (SIL) Injector excessive current Engine stop, Start lock 323910: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF0B	Engine chassis: Safety checks (SIL) Plausibility error Monitoring PS2-Pin Engine stop, Start lock 323911: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF0C	Engine chassis: Safety checks (SIL) Max. temperature injector exceeded Engine stop, Start lock 323912: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AEF0D	Engine chassis: Safety checks (SIL) Internal error CPU (excessive temperature) Engine stop, Start lock 323913: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF000	Engine chassis: Safety checks (SIL) Plausibility error rpm monitoring Engine stop, Start lock 324000: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF001	Engine chassis: Safety checks (SIL) all rpm signals erroneous/missing Engine stop, Start lock 324001: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF002	Engine chassis: Safety checks (SIL) Crankshaft signals erroneous/implausible (Signal sample) Engine stop, Start lock 324002: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF003	Engine chassis: Safety checks (SIL) Crankshaft signals erroneous/implausible (failure) Engine stop, Start lock 324003: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF004	Engine chassis: Safety checks (SIL) Crankshaft signals erroneous/implausible (difference) Engine stop, Start lock 324004: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF005	Engine chassis: Safety checks (SIL) Nockenwellensignale erroneous/implausible (Signal sample) Engine stop, Start lock 324005: Turn ignition on / off, Update or replace engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF006	Engine chassis: Safety checks (SIL) Nockenwellensignale erroneous/implausible (failure) Engine stop, Start lock 324006: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF007	Engine chassis: Safety checks (SIL) Nockenwellensignale erroneous/implausible (difference) Engine stop, Start lock 324007: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF008	Engine chassis: Safety checks (SIL) Reference voltage 12V outside permissible range Engine stop, Start lock 324008: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF009	Engine chassis: Safety checks (SIL) Incorrect software or hardware version (not SIL-able) Engine stop, Start lock 324009: Replace control unit	A700		E	2
8AF00A	Engine chassis: Safety checks (SIL) Incorrect hardware version (not SIL-able) Engine stop, Start lock 324010: Replace control unit	A700		E	2
8AF00B	Engine chassis: Safety checks (SIL) Temperature difference between injector / end stage too high Engine stop, Start lock 324011: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF100	Engine chassis: Safety checks (SIL) Internal software error (incorrect Parameter) Engine stop, Start lock 324100: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF105	Engine chassis: Safety checks (SIL) Starter turns without actuation Engine stop, Start lock 324105: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF106	Engine chassis: Safety checks (SIL) Injectors do not turn off Engine stop, Start lock 324106: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF107	Engine chassis: Safety checks (SIL) Fatal internal error (Monitoring Status machine) Engine stop, Start lock 324107: Turn ignition on / off, Update or replace engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF108	Engine chassis: Safety checks (SIL) Configuration error Vehicle-CAN Engine stop, Start lock 324108: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF109	Engine chassis: Safety checks (SIL) Datenuebertragung Vehicle -CAN gestoert Engine stop, Start lock 324109: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF10A	Engine chassis: Safety checks (SIL) Plausibility error Signals Vehicle -CAN Engine stop, Start lock 324110: Turn ignition on / off, Update or replace engine control unit	A700		E	2
8AF200	Engine chassis: SCR-control unit Hardware error metering unit No measures or pump is in off mode 324200:	A700		E	1
8AF201	Engine chassis: SCR-control unit Metering unit outside permissible limits Pump is in off mode 324201: No measures, error due to environmental cond.	A700		E	1
8AF202	Engine chassis: SCR-control unit mechanical error metering unit Pump is in off mode 324202: Check meter	A700		E	1
8AF203	Engine chassis: SCR-control unit Memory error metering unit Pump is in off mode 324203: Calibrate meter, if error present always, flash meters	A700		E	1
8AF204	Engine chassis: SCR-control unit Urea pressure, output line no reaction 324204: Check outgoing line and its conn.	A700		E	1
8AF205	Engine chassis: SCR-control unit Urea pressure, input line No measures or pump is in off mode 324205: Check input line and its connections	A700		E	1
8AF206	Engine chassis: SCR-control unit Urea pressure, nozzle no reaction 324206: Check the spray on nozzle	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF207	Engine chassis: SCR-control unit Urea pressure, injector Pump is in off mode 324207: Check both pins of plugs, if not short circuited, replace bad units	A700		E	1
8AF208	Engine chassis: SCR-control unit Control unit error, CAN-communication, display No measures or pump is in off mode 324208: Check CAN-connections	A700		E	1
8AF209	Engine chassis: SCR-control unit Battery voltage outside permissible limits Pump is in off mode 324209: Check supply voltage	A700		E	1
8AF20A	Engine chassis: SCR-control unit Temperature CAT, Sensor inflow outside permissible limits Pump is in off mode 324210: No measures, error due to environmental cond.	A700		E	1
8AF20B	Engine chassis: SCR-control unit Temperature CAT, Sensor inflow erroneous Pump is in off mode 324211: Check both pins of plugs, if not short circuited, replace bad units	A700		E	1
8AF20C	Engine chassis: SCR-control unit TemperatureCAT, Sensor outflow outside permissible limits Pump is in off mode 324212: No measures, error due to environmental cond.	A700		E	1
8AF20D	Engine chassis: SCR-control unit Temperature CAT, Sensor outflow erroneous Pump is in off mode 324213: Check both pins of plugs, if not short circuited, replace bad units	A700		E	1
8AF300	Engine chassis: SCR-control unit Tank sensor erroneous No measures or pump is in off mode 324300: Check both pins of plugs, if not short circuited, replace bad units	A700		E	1
8AF301	Engine chassis: SCR-control unit Tank sensor outside permissible range 324301: No measures, error due to environmental cond.	A700		E	1
8AF302	Engine chassis: SCR-control unit Line heating erroneous No measures, error due to environmental cond. 324302: Check both pins of plugs, if not short circuited, replace bad units	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF303	Engine chassis: SCR-control unit Line heating, temperature outside permissible range Pump is in off mode 324303: No measures, error due to environmental cond.	A700		E	1
8AF304	Engine chassis: SCR-control unit Valve heat pump erroneous Pump is in off mode 324304: Defrost system	A700		E	1
8AF305	Engine chassis: SCR-control unit Communcation error NOx-Sensor inflow Pump is in off mode 324305: Check electr. conn. of SCR System	A700		E	1
8AF306	Engine chassis: SCR-control unit Heater and O2 NOx-Sensor inflow erroneous No measures or pump is in off mode 324306: Replace Upstream NOx Sensor	A700		E	1
8AF307	Engine chassis: SCR-control unit NOx-Sensor inflow erroneous No measures or pump is in off mode 324307: Check both pins of plugs, if not short circuited, replace bad units	A700		E	1
8AF308	Engine chassis: SCR-control unit Communcation error NOx-Sensor outflow Pump is in off mode 324308: Check electr. conn. of SCR System	A700		E	1
8AF309	Engine chassis: SCR-control unit Heater and O2 NOx-Sensor outflow erroneous No measures or pump is in off mode 324309: Replace downstream NOx Sensor	A700		E	1
8AF30A	Engine chassis: SCR-control unit NOx-Sensor outflow erroneous No measures or pump is in off mode 324310: Check both pins of plugs, if not short circuited, replace bad units	A700		E	1
8AF500	Engine chassis: Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324500: Check for plugged/ damaged nitrogen line or IV is closed blocked	A700		E	1
8AF501	Engine chassis: Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324501: Check nitrogen line for leaks or IV in open position blocked.	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF502	Engine chassis: Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324502: Check nitrogen supply	A700		E	1
8AF503	Engine chassis: Dosing unit 1 Urea "DEF" Data transfer on CAN erroneous/missing Possibly regeneration not possible 324503: Check nitrogen supply line for leaks or plugs, check pump nitrogen supply	A700		E	1
8AF504	Engine chassis: Dosing unit 1 Urea "DEF" Electric defect on shut off valve Possibly regeneration not possible 324504: Broken line DCU 17 to test unit, visual check, moisture, wiring	A700		E	1
8AF505	Engine chassis: Dosing unit 1 Urea "DEF" System error control shut off valve Possibly regeneration not possible 324505: Shut off valve plugged: - replace MU, bleed system.	A700		E	1
8AF506	Engine chassis: Dosing unit 1 Urea "DEF" Back flow error on sensor pressure+temperature Possibly regeneration not possible 324506: Check nitrogen line for leaks or IV in open position blocked.	A700		E	1
8AF507	Engine chassis: Dosing unit 1 Urea "DEF" Back flow error on sensor pressure+temperature Possibly regeneration not possible 324507: Broken line DCU 17 to test unit, visual check, moisture, wiring	A700		E	1
8AF508	Engine chassis: Dosing unit 1 Urea "DEF" Electric defect on Dosing valve Possibly regeneration not possible 324508: Broken line DCU 17 to test unit, visual check, moisture, wiring	A700		E	1
8AF509	Engine chassis: Dosing unit 1 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324509: Changer MU, System Entlueften	A700		E	1
8AF50A	Engine chassis: Dosing unit 1 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324510: Metering valve opens too slow: - check power supply, - start system again change MU, bleed system	A700		E	1
8AF50B	Engine chassis: Dosing unit 1 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324511: Broken line DCU 17 to pressure sensor, visual check, moisture, wiring	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF50C	Engine chassis: Dosing unit 1 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324512: Downstream pressure sensor signal not plausible: - change MU, bleed system	A700		E	1
8AF50D	Engine chassis: Dosing unit 1 Urea "DEF" Control unit injection system erroneous Possibly regeneration not possible 324513: Change U, bleed system	A700		E	1
8AF600	Engine chassis: Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324600: DCU17 wechseln	A700		E	1
8AF601	Engine chassis: Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324601: Check power supply of DCU17, replace control unit	A700		E	1
8AF602	Engine chassis: Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324602: Check Can connection lines incl. connections of connections	A700		E	1
8AF603	Engine chassis: Dosing unit 2 Urea "DEF" Data transfer on CAN erroneous/missing Possibly regeneration not possible 324603: Data from LIDEC incorrect, not present or not correct. Check LIDEC error stack.	A700		E	1
8AF604	Engine chassis: Dosing unit 2 Urea "DEF" Electric defect on shut off valve Possibly regeneration not possible 324604: Voltage supply of DCU17 is too high, check electr. Lines of DCU17 for short circuit	A700		E	1
8AF605	Engine chassis: Dosing unit 2 Urea "DEF" System error control shut off valve Possibly regeneration not possible 324605: Problem during System, check DCU17 error stack trouble shooting dep. failure	A700		E	1
8AF60A	Engine chassis: Dosing unit 2 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324610: Reset des HC-meters (KeyOff- wait 5 sec. - KeyOn)	A700		E	1
8AF60B	Engine chassis: Dosing unit 2 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324611: Check application dating - check Software Version of HC-meter	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF60C	Engine chassis: Dosing unit 2 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324612: Turn HC-meter off (wait 5 sec.), turn on, check Software version, replace HC-meter	A700		E	1
8AF60D	Engine chassis: Dosing unit 2 Urea "DEF" Control unit injection system erroneous Possibly regeneration not possible 324613:	A700		E	1
8AF704	Engine chassis: Temperature monitoring "DOC" Minimum temperature fallen below Warning light on in operation no regeneration permitted 324704: Check HC meter, DOC, then carry out Service Regeneration	A700		E	1
8AF705	Engine chassis: Temperature monitoring "DOC" Maximum temperature exceeded Warning light on - in operation no regeneration permitted - power reduction 324705: Check HC meter, DOC, then carry out Service Regeneration	A700		E	1
8AF800	Engine chassis: Monitoring Particle filter "DPF" Oil in exhaust system Warning light on in operation no regeneration permitted 324800: Check: - DOC (possibly replace or turn over and service regeneration)	A700		E	1
8AF801	Engine chassis: Monitoring Particle filter "DPF" Maximum ash load reached Warning light on in operation no regeneration permitted 324801: Clean DPF or replace	A700		E	1
8AF802	Engine chassis: Monitoring Particle filter "DPF" Difference pressure filter too high Warning light on- in operation no regeneration permitted possible power reduction 324802: Clean DPF or replace	A700		E	1
8AF803	Engine chassis: Monitoring Particle filter "DPF" Difference pressure filter too low Warning light on - in operation no regeneration permitted - power reduction 324803: Replace DPF	A700		E	1
8AF804	Engine chassis: Monitoring Particle filter "DPF" Maximum number aborted heat phases exceeded Warning light on- in operation no regeneration permitted possible power reduction 324804: Request Service regeneration	A700		E	1
8AF805	Engine chassis: Monitoring Particle filter "DPF" Maximum number aborted regeneration phases exceeded Warning light on- in operation no regeneration permitted possible power reduction 324805: Request Service regeneration	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF806	Engine chassis: Monitoring Particle filter "DPF" Maximum temperature increase and max. temperature exceeded Warning light on 324806: Replace DPF	A700		E	1
8AF807	Engine chassis: Monitoring Particle filter "DPF" Maximum temperature limit exceeded Warning light on 324807: Replace DPF	A700		E	1
8AF900	Engine chassis: OBD Error Ambient pressure sensor Error Use replacement value, no reaction 324900: Check op. status of engine, replace engine control unit	A700		E	1
8AF901	Engine chassis: OBD Error Ambient temperature sensor Error Use replacement value, no reaction 324901: Check wiring, control units, sensors	A700		E	1
8AF902	Engine chassis: OBD Error ChargeAir Temperature sensor Error Use replacement value, no reaction 324902: Check wiring, control units, sensors	A700		E	1
8AF903	Engine chassis: OBD Error Charge air pressure sensor error Use replacement value, no reaction 324903: Check wiring, control units, sensors	A700		E	1
8AF904	Engine chassis: OBD Error Error Pressure deviation charge air pr. regulator Warning light on 324904: Check intake system for leaks, Wastegate	A700		E	1
8AF905	Engine chassis: OBD Error Error restrictor flap Power reduction of Diesel engine 324905: Check wiring, control units, sensors	A700		E	1
8AF906	Engine chassis: OBD Error Rail pressure sensor 1 Error Power red. in case of failure of both Commonrail pr.sensors, otherwise no reaction, engine standstill after delay 324906: Check wiring, control units, sensors	A700		E	1
8AF907	Engine chassis: OBD Error Rail pressure sensor 2 Error Power red. in case of failure of both Commonrail pr.sensors, otherwise no reaction, engine standstill after delay 324907: Check wiring, control units, sensors	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AF908	Engine chassis: OBD Error Pressure reg. valve (PCV) Error Possibly high pr. reg/ emerg. op. activated 324908: Check wiring harness, plug, CR-components2, engine control unit	A700		E	1
8AF909	Engine chassis: OBD Error Rail pressure reg. 1 Error no reaction 324909: Nitrogen circuit,Rail sensor,DBV,high pr. pump,wiring	A700		E	1
8AF90A	Engine chassis: OBD Error Rail pressure reg. 2 Error no reaction 324910: Nitrogen circuit,Rail sensor,DBV,high pr. pump,wiring	A700		E	1
8AF90B	Engine chassis: OBD Error Metering unit (VCV) Error Possibly high pr. reg/ emerg. op. activated 324911: Check wiring harness, plug, CR-components1, engine control unit	A700		E	1
8AF90C	Engine chassis: OBD Error Error Injector 1 Injector is not energized, no reaction 324912: Check wiring, plug, injector, engine control unit	A700		E	1
8AF90D	Engine chassis: OBD Error Error Injector 2 Injector is not energized, no reaction 324913: Check wiring, plug, injector, engine control unit	A700		E	1
8AFA00	Engine chassis: OBD Error Error Injector 3 Injector is not energized, no reaction 325000: Check wiring, plug, injector, engine control unit	A700		E	1
8AFA01	Engine chassis: OBD Error Error Injector 4 Injector is not energized, no reaction 325001: Check wiring, plug, injector, engine control unit	A700		E	1
8AFA02	Engine chassis: OBD Error Error Injector 5 Injector is not energized, no reaction 325002: Check wiring, plug, injector, engine control unit	A700		E	1
8AFA03	Engine chassis: OBD Error Error Injector 6 Injector is not energized, no reaction 325003: Check wiring, plug, injector, engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AFA04	Engine chassis: OBD Error Error Injector 7 Injector is not energized, no reaction 325004: Check wiring, plug, injector, engine control unit	A700		E	1
8AFA05	Engine chassis: OBD Error Error Injector 8 Injector is not energized, no reaction 325005: Check wiring, plug, injector, engine control unit	A700		E	1
8AFA06	Engine chassis: OBD Error Error fuel temperature sensor Use replacement value, no reaction 325006: Check wiring, plug, injector, engine control unit	A700		E	1
8AFA07	Engine chassis: OBD Error Error coolant temperature sensor Use replacement value, no reaction 325007: Check wiring, plug, injector, engine control unit	A700		E	1
8AFA08	Engine chassis: OBD Error Error crankshaft rpm sensor Emerg. shut off only at sim. Failure of both Rpm sensors 325008: Check rpm sensor, distance sensor to flywheel	A700		E	1
8AFA09	Engine chassis: OBD Error Error Index sensor camshaft Emerg. shut off only at sim. Failure of both Rpm sensors 325009: Check rpm sensor, distance sensor to flywheel	A700		E	1
8AFA0A	Engine chassis: OBD Error SCR catalytic converter inflow temp. sensor error Pump is in off mode 325010: No measures, error due to environmental conditions	A700		E	1
8AFA0B	Engine chassis: OBD Error SCR catalytic converter inflow temp. sensor error - OOR MIN Pump is in off mode 325011: No measures, error due to environmental cond.	A700		E	1
8AFA0C	Engine chassis: OBD Error SCR catalytic converter outflow temp. sensor error Pump is in off mode 325012: No measures, error due to environmental cond.	A700		E	1
8AFA0D	Engine chassis: OBD Error SCR catalytic converter Efficiency error (DEF-Quality, defective cat.) Actuation error lights, possible momentum reduction 325013: Check SCR-control unit, System for leaks, DEF-Quality	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AFB00	Engine chassis: OBD Error SCR catalytic converter Efficiency error (Monitor 2) Actuation warning lights, possible momentum limitation 325100: Check SCR-control unit, System for leaks, DEF-Quality	A700		E	1
8AFB01	Engine chassis: OBD Error SCR catalytic converter Efficiency error (incorrect medium, Monitor 2) Actuation warning lights, possible momentum limitation 325101: Check SCR-control unit, System for leaks, DEF-Quality	A700		E	1
8AFB02	Engine chassis: OBD Error NOx (Upstream) - Error Sensor communication Pump is in off mode 325102: Check electr. conn. from SCR System	A700		E	1
8AFB03	Engine chassis: OBD Error NOx (Upstream) - Error Sensor No measures or pump is in off mode 325103: Check plug, wiring, control units	A700		E	1
8AFB04	Engine chassis: OBD Error NOx (Downstream) - Error Sensor communication Pump is in off mode 325104: Check electr. conn. from SCR System	A700		E	1
8AFB05	Engine chassis: OBD Error NOx (Downstream) - Error Sensor No measures or pump is in off mode 325105: Check plug, wiring, control units	A700		E	1
8AFB06	Engine chassis: OBD Error Urea Injector Error - short circuit Pump is in off mode 325106: Check plug, wiring, control units	A700		E	1
8AFB07	Engine chassis: OBD Error Urea Injector Error open line Pump is in off mode 325107: Check plug, wiring, control units	A700		E	1
8AFB08	Engine chassis: OBD Error Urea pressure Error Pump is in Off mode, no measures or pump is in Off mode 325108: Check plug, wiring, control units	A700		E	1
8AFB09	Engine chassis: OBD Error Urea pressure Error - OOR MIN No measures or pump is in off mode 325109:	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AFB0A	Engine chassis: OBD Error Urea pressure mechanical error 1 no reaction 325110: Check the spray on nozzle	A700		E	1
8AFB0B	Engine chassis: OBD Error Urea pressure mechanical error 3 no reaction 325111: Check the spray on nozzle	A700		E	1
8AFB0C	Engine chassis: OBD Error Metering error Pump is in off mode 325112: check meter, replace if nec.	A700		E	1
8AFB0D	Engine chassis: OBD Error Pump temperature and heater error Pump is in Off mode, no measures or pump is in Off mode 325113: No measures, error due to environmental cond.	A700		E	1
8AFC00	Engine chassis: OBD Error Urea tank Heater erroneous (driver) No measures or pump is in off mode 325200: Check plug, wiring, control units	A700		E	1
8AFC01	Engine chassis: OBD Error Line heating Urea erroneous (driver) No measures, error due to environmental cond. 325201: Check plug, wiring, control units	A700		E	1
8AFC02	Engine chassis: OBD Error Pump heater Urea erroneous (driver) No measures or pump is in off mode 325202:	A700		E	1
8AFC03	Engine chassis: OBD Error Urea tank Temperature sensor erroneous No measures, error due to environmental cond. 325203: No measures, error due to environmental cond.	A700		E	1
8AFC04	Engine chassis: OBD Error Urea tank Temperature sensor erroneous (OOR MIN) 325204: No measures, error due to environmental cond.	A700		E	1
8AFC05	Engine chassis: OBD Error Urea tank fill level sensor erroneous No measures or pump is in off mode 325205: Check plug, wiring, control units	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AFC06	Engine chassis: OBD Error Urea tank fill level sensor erroneous no reaction 325206: No measure	A700		E	1
8AFC07	Engine chassis: OBD Error Fill level urea tank threshold 3 Actuation warning lights, possible momentum limitation 325207: Refill urea tank	A700		E	1
8AFC08	Engine chassis: OBD Error Fill level urea tank threshold 2 Actuation warning lights, possible momentum limitation 325208: Refill urea tank	A700		E	1
8AFC09	Engine chassis: OBD Error Fill level urea tank threshold 1 Actuation warning lights, possible momentum limitation 325209: Refill urea tank	A700		E	1
8AFC0A	Engine chassis: OBD Error Fill level urea tank threshold 0 Actuation warning lights, possible momentum limitation 325210: Refill urea tank	A700		E	1
8AFC0B	Engine chassis: OBD Error SCR ECM Error power supply Pump is in Off mode, no measures or pump is in Off mode 325211: Check supply voltage	A700		E	1
8AFC0C	Engine chassis: OBD Error SCR ECM Error Temperature Pump is in off mode 325212: No measures, error due to environmental cond.	A700		E	1
8AFC0D	Engine chassis: OBD Error SCR ECM CAN communication erroneous No measures or pump is in off mode 325213: Check CAN-connections	A700		E	1
8AFD00	Engine chassis: Error Exhaust treatment "AGN" Particle filter "DPF" load status threshold 4 reached Exhaust back pressure/DPF Temperature high 325300: Activate manual regeneration	A700		E	1
8AFD01	Engine chassis: Error Exhaust treatment "AGN" Particle filter "DPF" load status threshold 5 reached Exhaust back pressure/DPF Temperature high 325301: Activate Service Regeneration	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8AFE00	Engine chassis: OBD Error SCR power supply, Sensor error Engine cannot be started or engine shut off 325400: Check on board network	A700		E	1
8AFE01	Engine chassis: OBD Error ECM internal error control unit Engine cannot be started or engine shut off 325401: Load current software, replace engine control unit	A700		E	1
8AFE02	Engine chassis: OBD Error CAN-communication (J1939) interrupted Change over to plausible speed source 325402: Check cable / plug / CAN-participant	A700		E	1
8AFE03	Engine chassis: OBD Error CAN-communication (J1939) maximum transmission cycle exceeded Possibly power reduction 325403: Check cable / plug / CAN-participant	A700		E	1
8AFE04	Engine chassis: OBD Error Injector 9 erroneous Injector unit is not energized 325404: Check cable, plug, injection unit, engine control unit	A700		E	1
8AFE0D	Engine chassis: OBD Error Start block, problem exhaust aftertreatment/fill level urea tank Start lock 325413: Check wiring, exhaust system; check fill level urea, add urea	A700		E	1
8B0100	Engine uppercarr. Operating note Travel pedal actuated at selected / active engine brake No acceptance of gases at active engine brake 300100: Deactivation of engine brake	A750		B	0
8B0101	Engine uppercarr. Operating note Travel pedal actuated at support / superstructure operation No acceptance of gases at active engine brake 300101: Deactivation of support operation	A750		B	0
8B0102	Engine uppercarr. Operating note Service function "Vent fuel supply" activated (Gaspedal Increase of injection amount in starting phase 300102: Deactivate after reaching rpm limit or after initialization of engine control unit	A750		B	0
8B0103	Engine uppercarr. Operating note Engine Start prevented, ignition switch actuated after ignition on No engine start until Signal terminal 50 on input was recognized as low 300103: Release ignition switch KI.50 or check signal for short circuit after Ubatt	A750		B	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0104	Engine uppercarr. Operating note Engine Start prevented, Ignition switch to short in zero No engine start until Signal terminal 50 on input was recognized as low 300104: Release ignition switch T.50 or check signal for short circuit after Ubatt	A750		B	0
8B0105	Engine uppercarr. Operating note Engine Start prevented, Ignition switch actuated in Init phase No engine start until Signal terminal 50 on input was recognized as low 300105: Release ignition switch T.50 or check signal for short circuit after Ubatt	A750		B	0
8B0106	Engine uppercarr. Operating note Engine running for long time without load in idling Filter load increases significantly 300106: Increase load/engine rpm	A750		B	0
8B0107	Engine uppercarr. Operating note manual DPF regeneration not possible, charge status too low no reaction 300107: Deactivate manual DPF Regeneration	A750		B	1
8B0108	Engine uppercarr. Operating note manual DPF regeneration not possible, time blockage no reaction 300107: Deactivate manual DPF Regeneration	A750		B	1
8B0109	Engine uppercarr. Operating note Start prevented, no release of emerg. stop function engine start not possible 300109: Release ignition switch, check emerg. stop signal for short circuit after Ubatt	A750		B	1
8B010A	Engine uppercarr. Operating note Time conditions for monitoring test values not met engine start not possible 300110: Check / replace machine control Master 4	A750		B	0
8B010B	Engine uppercarr. Operating note Emerg. op after problem of data transfer on CAN-Bus active engine start not possible 300111: Stop engine and restart, check CAN-wiring	A750		B	0
8B0200	Engine uppercarr. Operating note Travel pedal actuated at selected / active engine brake 300200:	A750		B	0
8B0400	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit(meter Sensor 1) faulty Possibly power reduction 300400: Check wiring CAN-Buses, control units	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0401	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit(meter Sensor 2) faulty Possibly power reduction 300401: Check wiring CAN-Buses, control units	A750		E	1
8B0402	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2 (Sensors SCR cat.) faulty Possibly power reduction 300402: Check wiring CAN-Buses, control units	A750		E	1
8B0403	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(urea tank sensors) faulty Possibly power reduction 300403: Check wiring CAN-Buses, control units	A750		E	1
8B0404	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(SCR metering status) faulty Possibly power reduction 300404: Check wiring CAN-Buses, control units	A750		E	1
8B0405	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(SCR metering info) faulty Possibly power reduction 300405: Check wiring CAN-Buses, control units	A750		E	1
8B0406	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(NoxUp2 dew-point) faulty Possibly power reduction 300406: Check wiring CAN-Buses, control units	A750		E	1
8B0407	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(NoxDown2 dew-point) faulty Possibly power reduction 300407: Check wiring CAN-Buses, control units	A750		E	1
8B0408	Engine uppercarr. CAN-Data transfer engine CAN 4 Diagnostics of SCR-metering unit 2 erroneous no reaction 300408: Check wiring CAN-Buses, control units	A750		E	1
8B0409	Engine uppercarr. CAN-Data transfer engine CAN 4 Data transfer SCR Service diagnostics faulty, 2. Pump no reaction 300409: Check wiring CAN-Buses, control units	A750		E	1
8B040A	Engine uppercarr. CAN-Data transfer engine CAN 4 Service diagnostics function SCR 2 not properly completed no reaction 300410: Check wiring CAN-Buses, control units	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B040B	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(meter Sensor 1) faulty Possibly power reduction 300411: Check wiring CAN-Buses, control units	A750		E	1
8B040C	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(meter Sensor 2) faulty Possibly power reduction 300412: Check wiring CAN-Buses, control units	A750		E	1
8B040D	Engine uppercarr. CAN-Data transfer engine CAN 4 Humidity sensor faulty Possibly power reduction 300413: Check wiring CAN-Buses, control units	A750		E	1
8B0500	Engine uppercarr. CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded Emerg. op.: Momentum and RPM limitation of engine 300500: Check cable / plug / I/O-module(s)	A750		E	1
8B0501	Engine uppercarr. CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded Last received value or replacement value 300501: Check cable / plug / Coupling module	A750		E	1
8B0502	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded Last received value or replacement value 300502: Check cable / plug / Gear module	A750		E	1
8B0503	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded Last received value or replacement value 300503: Check cable / plug / Gear module	A750		E	1
8B0504	Engine uppercarr. CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded Last received value or replacement value 300504: Check cable / plug / Gear module	A750		E	1
8B0505	Engine uppercarr. CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded Last received value or replacement value 300505: Check cable / plug / ABS/ASR-Module1	A750		E	1
8B0506	Engine uppercarr. CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded Last received value or replacement value 300506: Check cable / plug / ABS/ASR-Module1	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0507	Engine uppercarr. CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded Last received value or replacement value 300507: Check cable / plug / ABS/ASR-Module2	A750		E	1
8B0508	Engine uppercarr. CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded Last received value or replacement value 300508: Check cable / plug / ABS/ASR-Module2	A750		E	1
8B0509	Engine uppercarr. CAN-Data transfer Retarder (ID 772) erroneous/maximum cycle time exceeded Last received value or replacement value 300509: Check cable / plug / Retarder module	A750		E	1
8B050A	Engine uppercarr. CAN-Data transfer WSK (ID 776) erroneous/maximum cycle time exceeded Last received value or replacement value 300510: Check cable / plug / converter module	A750		E	1
8B050B	Engine uppercarr. CAN-Data transfer Overrun of receiving buffer Last received value or replacement value 300511: Turn ignition off/on, load new software in engine control unit or replace control unit	A750		E	1
8B0600	Engine uppercarr. CAN-Data transfer engine control unit Aborted (Passive error) Last received value or replacement value 300600: Check cable / plug / CAN-participant	A750		E	1
8B0601	Engine uppercarr. CAN-Data transfer engine control unit Aborted (BusOff) Last received value or replacement value 300601: Check cable / plug / CAN-participant	A750		E	1
8B0602	Engine uppercarr. CAN-Data transfer engine control unit Faulty / interrupted (Rx-warning) Last received value or replacement value 300602: Check cable / plug / CAN-participant	A750		E	1
8B0603	Engine uppercarr. CAN-Data transfer engine control unit Faulty / interrupted (Tx-warning) Last received value or replacement value 300603: Check cable / plug / CAN-participant	A750		E	1
8B0604	Engine uppercarr. CAN-Data transfer engine control unit Faulty / interrupted (send -timeout) Last received value or replacement value 300604: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0606	Engine uppercarr. CAN-Data transfer engine control unit Faulty / interrupted (complete transmission data) Last received value or replacement value 300606: Turn ignition off/on, Load new software in engine control unit or replace control unit	A750		E	1
8B0700	Engine uppercarr. CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded no reaction 300700: Check cable / plug / CAN-participant	A750		E	1
8B0701	Engine uppercarr. CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded no reaction 300701: Check cable / plug / CAN-participant	A750		E	1
8B0702	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300702: Check cable / plug / CAN-participant	A750		E	1
8B0703	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300703: Check cable / plug / CAN-participant	A750		E	1
8B0704	Engine uppercarr. CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded no reaction 300704: Check cable / plug / CAN-participant	A750		E	1
8B0705	Engine uppercarr. CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded 300705:	A750		E	1
8B0706	Engine uppercarr. CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded 300706:	A750		E	1
8B0707	Engine uppercarr. CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded 300707:	A750		E	1
8B0708	Engine uppercarr. CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded 300708:	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0800	Engine uppercarr. CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded emergency operation 300800: Check cable / plug / CAN-participant	A750		E	1
8B0801	Engine uppercarr. CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded emergency operation 300801: Check cable / plug / CAN-participant	A750		E	1
8B0802	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300802: Check cable / plug / CAN-participant	A750		E	1
8B0803	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300803: Check cable / plug / CAN-participant	A750		E	1
8B0804	Engine uppercarr. CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded emergency operation 300804: Check cable / plug / Master	A750		E	1
8B0900	Engine uppercarr. CAN-Data transfer Aborted (Passive error) Change over to plausible speed source 300900: Check cable / plug / CAN-participant	A750		E	1
8B0901	Engine uppercarr. CAN-Data transfer Aborted (BusOff) Change over to plausible speed source 300901: Check cable / plug / CAN-participant	A750		E	1
8B0902	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx-warning) no reaction 300902: Check cable / plug / CAN-participant	A750		E	1
8B0903	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx-warning) no reaction 300903: Check cable / plug / CAN-participant	A750		E	1
8B0904	Engine uppercarr. CAN-Data transfer Faulty / interrupted (send -timeout) Change over to plausible speed source 300904: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0905	Engine uppercarr. CAN-Data transfer Faulty / interrupted (TSC1) no reaction 300905: Check cable / plug / CAN-participant	A750		E	1
8B0A00	Engine uppercarr. CAN-Data transfer Aborted (Passive error) Change over to plausible speed source 301000: Check cable / plug / CAN-participant	A750		E	1
8B0A01	Engine uppercarr. CAN-Data transfer Aborted (BusOff) Change over to plausible speed source 301001: Check cable / plug / CAN-participant	A750		E	1
8B0A02	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx-warning) no reaction 301002: Check cable / plug / CAN-participant	A750		E	1
8B0A03	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx-warning) no reaction 301003: Check cable / plug / CAN-participant	A750		E	1
8B0A04	Engine uppercarr. CAN-Data transfer Faulty / interrupted (send -timeout) Possibly power reduction 301004: Check cable / plug / CAN-participant	A750		E	1
8B0A05	Engine uppercarr. CAN-Data transfer AGR-Module 1 erroneous/maximum cycle time exceeded Possibly power reduction 301005: Check cable / plug / CAN-participant	A750		E	1
8B0A06	Engine uppercarr. CAN-Data transfer AGR-Module 2 erroneous/maximum cycle time exceeded Possibly power reduction 301006: Check cable / plug / CAN-participant	A750		E	1
8B0A07	Engine uppercarr. CAN-Data transfer WasteGate-Module 1 erroneous/maximum cycle time exceeded Possibly power reduction 301007: Check cable / plug / CAN-participant	A750		E	1
8B0A08	Engine uppercarr. CAN-Data transfer WasteGate-Module 2 erroneous/maximum cycle time exceeded Possibly power reduction 301008: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0A09	Engine uppercarr. CAN-Data transfer Restrictor flap module erroneous/maximum cycle time exceeded Possibly power reduction 301009: Check cable / plug / CAN-participant	A750		E	1
8B0A0A	Engine uppercarr. CAN-Data transfer Tachograph erroneous/maximum cycle time exceeded Change over to plausible speed source 301010: Check cable / plug / CAN-participant	A750		E	1
8B0A0B	Engine uppercarr. CAN-Data transfer NOx-Lambda sensor up1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301011: Check cable / plug / CAN-participant	A750		E	1
8B0A0C	Engine uppercarr. CAN-Data transfer NOx-Lambda sensor down1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301012: Check cable / plug / CAN-participant	A750		E	1
8B0A0D	Engine uppercarr. CAN-Data transfer Mass flow sensor 1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301013: Check cable / plug / CAN-participant	A750		E	1
8B0B00	Engine uppercarr. CAN-Data transfer Aborted (Passive error) no reaction 301100: Check cable / plug / CAN-participant	A750		E	1
8B0B01	Engine uppercarr. CAN-Data transfer Aborted (BusOff) no reaction 301101: Check cable / plug / CAN-participant	A750		E	1
8B0B02	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301102: Check cable / plug / CAN-participant	A750		E	1
8B0B03	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx warning) no reaction 301103: Check cable / plug / CAN-participant	A750		E	1
8B0B04	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301104: Check cable / plug / CAN-participant check Master-Slave recognition-Pin	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0B05	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx timeout) No injection on slave modules will occur 301105: Check cable / plug / CAN-participant / Slave recognition Pin	A750		E	1
8B0B06	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx Send buffer overflow) 301106: Check cable / plug / CAN-participant	A750		E	1
8B0B07	Engine uppercarr. CAN-Data transfer Internal error, Software slave Module incompatible to master No injection on slave modules will occur 301107: Update slave and master module	A750		E	1
8B0B08	Engine uppercarr. CAN-Data transfer Internal error, calibration slave Module incompatible to master No injection on slave modules will occur 301108: Update slave and master module	A750		E	1
8B0C00	Engine uppercarr. CAN-Data transfer Motor CAN 2 HC-dosing unit (PRODPM2) faulty / interrupted Warning light on in operation no regeneration permitted 301200: Check cable / plug / CAN-participant	A750		E	1
8B0C01	Engine uppercarr. CAN-Data transfer Motor CAN 2 HC-dosing unit (HCDI1) faulty / interrupted Warning light on in operation no regeneration permitted 301201: Check cable / plug / CAN-participant	A750		E	1
8B0C02	Engine uppercarr. CAN-Data transfer Motor CAN 2 Mass flow sensor 2 faulty / interrupted Possibly power reduction 301202: Check cable / plug / CAN-participant	A750		E	1
8B0C03	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of mass flow sensor 1 failed Possibly power reduction 301203: Check cable / plug / CAN-participant	A750		E	1
8B0C04	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of mass flow sensor 2 failed Possibly power reduction 301204: Check cable / plug / CAN-participant	A750		E	1
8B0C05	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of Nox-sensors "Up1" failed Possibly power reduction 301205: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0C06	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of Nox-sensors "Down1" failed Possibly power reduction 301206: Check cable / plug / CAN-participant	A750		E	1
8B0C07	Engine uppercarr. CAN-Data transfer Motor CAN 2 Tachograph (Date, time) faulty / interrupted Change over to plausible speed source 301207: Check cable / plug / CAN-participant	A750		E	1
8B0C08	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of "Egr1" failed Power reduction of Diesel engine 301208: Check cable / plug / CAN-participant	A750		E	1
8B0C09	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of "Egr2" failed Power reduction of Diesel engine 301209: Check cable / plug / CAN-participant	A750		E	1
8B0C0A	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of "WG1" failed Power reduction of Diesel engine 301210: Check cable / plug / CAN-participant	A750		E	1
8B0C0B	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of "WG2" failed Power reduction of Diesel engine 301211: Check cable / plug / CAN-participant	A750		E	1
8B0C0C	Engine uppercarr. CAN-Data transfer Motor CAN 2 SCR-unit (SCR Sensors) faulty / interrupted Possibly power reduction 301212: Check cable / plug / CAN-participant	A750		E	1
8B0C0D	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of HC-dosing unit failed no reaction 301213: Check cable / plug / CAN-participant	A750		E	1
8B0D00	Engine uppercarr. CAN-Data transfer Aborted (Passive error) no reaction 301300: Check cable / plug / CAN-participant	A750		E	1
8B0D01	Engine uppercarr. CAN-Data transfer Aborted (BusOff) no reaction 301301: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0D02	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301302: Check cable / plug / CAN-participant	A750		E	1
8B0D03	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx warning) no reaction 301303: Check cable / plug / CAN-participant	A750		E	1
8B0D04	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx warning) No injection on Slave modules 301304: Check cable / plug / CAN-participant	A750		E	1
8B0D05	Engine uppercarr. CAN-Data transfer Incorrect transfer rate recognized No injection on Slave modules 301305: Check cable / plug / CAN-participant / Slave recognition Pin	A750		E	1
8B0D06	Engine uppercarr. CAN-Data transfer Unexpected messages recognized No injection on Slave modules 301306: Check cable / plug / CAN-participant / Slave recognition Pin	A750		E	1
8B0E00	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit (Tank sensors) faulty / interrupted Possibly power reduction 301400: Check cable / plug / CAN-participant	A750		E	1
8B0E01	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, metering status Possibly power reduction 301401: Check cable / plug / CAN-participant	A750		E	1
8B0E02	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, metering information Possibly power reduction 301402: Check cable / plug / CAN-participant	A750		E	1
8B0E03	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, dew-point recognition "NOxUp1" Possibly power reduction 301403: Check cable / plug / CAN-participant	A750		E	1
8B0E04	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, dew-point recognition "NOxDown1" Possibly power reduction 301404: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0E05	Engine uppercarr. CAN-Data transfer Motor CAN 3 Water pump faulty / interrupted (Status report) no reaction 301405: Check cable / plug / CAN-participant	A750		E	1
8B0E06	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, diagnostics not possible no reaction 301406: Check cable / plug / CAN-participant	A750		E	1
8B0E07	Engine uppercarr. CAN-Data transfer Motor CAN 3 Restrictor flap module faulty / interrupted, diagnostics not possible Possibly power reduction 301407: Check cable / plug / CAN-participant	A750		E	1
8B0E08	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, Service diagnostics not possible no reaction 301408: Check cable / plug / CAN-participant	A750		E	1
8B0E09	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, Service diagnostics not completed 301409:	A750		E	1
8B0E0A	Engine uppercarr. CAN-Data transfer Motor CAN 3 Nox-Lambda sensor "Up 2" faulty 301410: Check cable / plug / CAN-participant	A750		E	1
8B0E0B	Engine uppercarr. CAN-Data transfer Motor CAN 3 Nox-Lambda sensor "Down 2" faulty 301411: Check cable / plug / CAN-participant	A750		E	1
8B0E0C	Engine uppercarr. CAN-Data transfer Motor CAN 3 Diagnostics of NOx-Sensor "Up 2" failed 301412: Check cable / plug / CAN-participant	A750		E	1
8B0E0D	Engine uppercarr. CAN-Data transfer Motor CAN 3 Diagnostics of NOx-Sensor "Down 2" failed 301413: Check cable / plug / CAN-participant	A750		E	1
8B1000	Engine uppercarr. Engine protection function Excess temperature on exhaust turbine active Performance reduction 301600: Check exhaust system for leaks	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1200	Engine uppercarr. CAN constr. machines, download Memory error flash 0 301800:	A750		E	1
8B1201	Engine uppercarr. CAN constr. machines, download Memory error flash 0 301801:	A750		E	1
8B1202	Engine uppercarr. CAN constr. machines, download Memory error flash 0 301802:	A750		E	1
8B1203	Engine uppercarr. CAN constr. machines, download memory error EEPROM 0 301803:	A750		E	1
8B1204	Engine uppercarr. CAN constr. machines, download Check sum error 0 301804:	A750		E	1
8B1205	Engine uppercarr. CAN constr. machines, download Incorrect number of data 0 301805:	A750		E	1
8B1206	Engine uppercarr. CAN constr. machines, download Receive buffer overflow 0 301806:	A750		E	1
8B1207	Engine uppercarr. CAN constr. machines, download download active 0 301807:	A750		E	1
8B1208	Engine uppercarr. CAN constr. machines, download unknown area 0 301808:	A750		E	1
8B1300	Engine uppercarr. Internal error control equipment Stack-overflow Engine cannot be started or engine shut off 301900: Load new software in engine control unit or replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1301	Engine uppercarr. Internal error control equipment Exception error Engine cannot be started or engine shut off 301901: Load new software in engine control unit or replace engine control unit	A750		E	2
8B1302	Engine uppercarr. Internal error control equipment Program test Engine cannot be started or engine shut off 301902: Load new software in engine control unit or replace engine control unit	A750		E	2
8B1303	Engine uppercarr. Internal error control equipment RAM-Test Engine cannot be started or engine shut off 301903: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1304	Engine uppercarr. Internal error control equipment Overflow in error stack no reaction 301904: Load new software in engine control unit or replace engine control unit	A750		E	1
8B1305	Engine uppercarr. Internal error control equipment Comp. time error no reaction 301905: Load new software in engine control unit or replace engine control unit	A750		E	2
8B1306	Engine uppercarr. Internal error control equipment Error-Index too large The error cannot be saved 301906: Load new software in engine control unit or replace engine control unit	A750		E	1
8B1400	Engine uppercarr. Control unit defective (memory EEPROM) Error at EEPROM-access Engine cannot be started or engine shut off 302000: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1401	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error Parameter memory Engine cannot be started or engine shut off 302001: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1402	Engine uppercarr. Control unit defective (memory EEPROM) Parameter memory in EEPROM is invalid Engine cannot be started or engine shut off 302002: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1403	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error ECU-Page No reaction - possibly data sets or operating conditions could not be saved 302003: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1404	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error NMI-Page No reaction - possibly data sets or operating conditions could not be saved 302004: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1405	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error Workdata-Page No reaction - possibly data sets or operating conditions could not be saved 302005: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1406	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error load collective No reaction - possibly load collective data could not be saved 302006: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1407	Engine uppercarr. Control unit defective (memory EEPROM) Structure size of load collective has changed No reaction - possibly load collective data could not be saved 302007: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1408	Engine uppercarr. Control unit defective (memory EEPROM) EEPROM-Memory full (load collective) No reaction - possibly load collective data could not be saved 302008: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1409	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error permanent Data No reaction - possibly data sets or operating conditions could not be saved 302009: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B140A	Engine uppercarr. Control unit defective (memory EEPROM) EEPROM Data inconsistent No reaction - possibly data sets or operating conditions could not be saved 302010: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B140B	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error OBD-Page No reaction - possibly data sets or operating conditions could not be saved 302011: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B140C	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error EEPROM-areas No reaction - possibly data sets or operating conditions could not be saved 302012: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1500	Engine uppercarr. Power supply voltage below required value Engine cannot be started or engine shut off 302100: Check on board network (battery, alternator, wiring, plug)	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1501	Engine uppercarr. Power supply excess voltage Engine cannot be started or engine shut off 302101: Check on board network (battery, alternator, wiring, plug)	A750		E	2
8B1502	Engine uppercarr. Power supply Digital outlet short circuit after supply voltage Engine shut off 302102: Check wiring, engine control unit, possibly replace engine control unit	A750		E	2
8B1503	Engine uppercarr. Power supply Error release output outlets Engine shut off, shut off of all digital outlets 302103: Check wiring, engine control unit, possibly replace engine control unit	A750		E	2
8B1504	Engine uppercarr. Power supply PS1-Pin erroneous/missing Engine cannot be started or engine shut off 302104: Check on board network in ref. to PS1 (terminal 30/31), engine control unit	A750		E	2
8B1505	Engine uppercarr. Power supply Reference voltage 12V below permissible range Engine shut off 302105: Check supply voltage Rpm sensors, on board network, engine control unit	A750		E	2
8B1506	Engine uppercarr. Power supply Reference voltage 12V above permissible range Engine shut off 302106: Check supply voltage Rpm sensors, on board network, engine control unit	A750		E	2
8B1600	Engine uppercarr. Configuration error Fan control cooler The fan control is deactivated. Resulting in maximum vent position 302200: Load new software in engine control unit	A750		E	2
8B1601	Engine uppercarr. Configuration error Offset to full load curve The matching of the performance curve is internally limited 302201: Load new software in engine control unit	A750		E	2
8B1602	Engine uppercarr. Configuration error Monitoring Pedal unit Pedal unit is not monitored 302202: Load new software in engine control unit	A750		E	2
8B1603	Engine uppercarr. Configuration error Incorrect pump code Replacement value is used 302203: Check pump coding and change (via diagnostics or resp. diagnostics tool)	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1604	Engine uppercarr. Configuration error Incorrect assignment of high pressure sensors no reaction 302204: Load new software in engine control unit	A750		E	2
8B1605	Engine uppercarr. Configuration error No high pr. pump activated no reaction 302205: Load new software in engine control unit	A750		E	2
8B1606	Engine uppercarr. Configuration error Current output for VCV 1 not active no reaction 302206: Load new software in engine control unit	A750		E	2
8B1607	Engine uppercarr. Configuration error Current output for VCV 2 not active no reaction 302207: Load new software in engine control unit	A750		E	2
8B1608	Engine uppercarr. Configuration error CAN-messages no reaction 302208: Load new software in engine control unit	A750		E	2
8B1609	Engine uppercarr. Configuration error CAN-transfer rate no reaction 302209: Load new software in engine control unit	A750		E	2
8B160A	Engine uppercarr. Configuration error Incorrect assignment of analog sensor no reaction 302210: Load new software in engine control unit	A750		E	2
8B160B	Engine uppercarr. Configuration error Incorrect assignment switch no reaction 302211:	A750		E	2
8B160C	Engine uppercarr. Configuration error Motor configuration erroneous/missing Engine cannot be started or engine shut off 302212: Load new software in engine control unit	A750		E	2
8B160D	Engine uppercarr. Configuration error Parameterization actuator invalid Power reduction of Diesel engine 302213: Load new software in engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1700	Engine uppercarr. Configuration error Component ID of SCR-unit incorrect 302300:	A750		E	2
8B1701	Engine uppercarr. Configuration error Component ID of HC-metering unit incorrect The matching of the performance curve is internally limited 302201: Load new software in engine control unit	A750		E	1
8B1702	Engine uppercarr. Configuration error Component ID of restrictor flap incorrect Pedal unit is not monitored 302202: Load new software in engine control unit	A750		E	1
8B1703	Engine uppercarr. Configuration error Current output for PCV1 not active Replacement value is used 302203: Check pump coding and change (via diagnostics or resp. diagnostics tool)	A750		E	1
8B1704	Engine uppercarr. Configuration error Current output for PCV2 not active no reaction 302204: Load new software in engine control unit	A750		E	1
8B1800	Engine uppercarr. Configuration error Fan control cooler 302400:	A750		E	2
8B1900	Engine uppercarr. Control unit defective (FLASH-memory) Check sum error Parameter memory Engine cannot be started or engine shut off 302500: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1901	Engine uppercarr. Control unit defective (FLASH-memory) Invalid data, default values are used Engine cannot be started or engine shut off 302501: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1902	Engine uppercarr. Control unit defective (FLASH-memory) Error during delete Engine cannot be started or engine shut off 302502: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1903	Engine uppercarr. Control unit defective (FLASH-memory) Error during programming Engine cannot be started or engine shut off 302503: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1904	Engine uppercarr. Control unit defective (FLASH-memory) Error during check Engine cannot be started or engine shut off 302504: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1905	Engine uppercarr. Control unit defective (FLASH-memory) Data inconsistent Engine cannot be started or engine shut off 302505: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1A00	Engine uppercarr. Internal error control equipment Program error Engine shut off 302600: Program update to newest software version	A750		E	2
8B1A01	Engine uppercarr. Internal error control equipment Program error Engine shut off 302601: Program update to newest software version	A750		E	2
8B1A02	Engine uppercarr. Internal error control equipment Program error Engine shut off 302602: Program update to newest software version	A750		E	2
8B1A03	Engine uppercarr. Internal error control equipment Program error Engine shut off 302603: Program update to newest software version	A750		E	2
8B1A04	Engine uppercarr. Internal error control equipment Program error Engine shut off 302604: Program update to newest software version	A750		E	2
8B1A05	Engine uppercarr. Internal error control equipment Program error Engine shut off 302605: Program update to newest software version	A750		E	2
8B1A06	Engine uppercarr. Internal error control equipment Program error Engine shut off 302606: Program Update to newest software bersion	A750		E	2
8B1B00	Engine uppercarr. Speed recording Maximum difference travel speed Tacho<->Gear exceeded The larger speed value is used 302700: Check gear and tachograph	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1C00	Engine uppercarr. Actuation engine brake Broken wire or Short circuit after ground Engine brake flap is not actuated 302800: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C01	Engine uppercarr. Actuation engine brake Broken wire or short circuit after supply voltage Engine brake flap is not actuated 302801: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C02	Engine uppercarr. Actuation engine brake Hardware error (control unit defective) Engine brake flap is not actuated 302802: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C03	Engine uppercarr. Actuation engine brake Maximum signal difference to actuation exceeded Engine brake flap is not actuated 302803: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C04	Engine uppercarr. Actuation engine brake Maximum signal difference to actuation exceeded Engine brake flap is not actuated 302804: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C05	Engine uppercarr. Actuation engine brake Current measured without actuation Engine brake flap is not actuated 302805: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C06	Engine uppercarr. Actuation engine brake Current too low in actuated state Engine brake flap is not actuated 302806: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C07	Engine uppercarr. Actuation engine brake Current too high in actuated state Engine brake flap is not actuated 302807: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C08	Engine uppercarr. Actuation engine brake Ground switch overcurrent Engine brake flap is not actuated 302808: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C09	Engine uppercarr. Actuation engine brake Plus switch overcurrent Engine brake flap is not actuated 302809: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1C0A	Engine uppercarr. Actuation engine brake Maximum analog value exceeded (PWM) Engine brake flap is not actuated 302810: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1D00	Engine uppercarr. Alternator Charge control D+ of mass flow sensor no reaction 302900: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D01	Engine uppercarr. Alternator Charge control D+ Overvoltage at engine off no reaction 302901: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D02	Engine uppercarr. Alternator Charge control D+ undervoltage at engine on no reaction 302902: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D03	Engine uppercarr. Alternator Charge control D+ overvoltage at engine on no reaction 302903: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D04	Engine uppercarr. Alternator Charge control D+ voltage deviation to on board current too low no reaction 302904: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D05	Engine uppercarr. Alternator Charge control D+ voltage deviation to on board current too high no reaction 302905: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D06	Engine uppercarr. Alternator Implausibility at test of on board voltage Battery charge voltage regulated to 28.5V 302906: Check inputs of alternator	A750		E	0
8B1E00	Engine uppercarr. Alternator 2 Charge control D+ of mass flow sensor no reaction 303000: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1E01	Engine uppercarr. Alternator 2 Charge control D+ Overvoltage at engine off no reaction 303001: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1E02	Engine uppercarr. Alternator 2 Charge control D+ undervoltage at engine on no reaction 303002: wiring engine control unit to alternator (D+), check alternator and V-belt	A750		E	1
8B1E03	Engine uppercarr. Alternator 2 Charge control D+ overvoltage at engine on no reaction 303003: Check wiring engine control unit to alternator (D+), alternator and V-belt	A750		E	1
8B1E04	Engine uppercarr. Alternator 2 Charge control D+ voltage deviation to on board current too low no reaction 303004: Check wiring alternator (D+) to battery or to engine control unit, alternator	A750		E	1
8B1E05	Engine uppercarr. Alternator 2 Charge control D+ voltage deviation to on board current too high no reaction 303005: Check wiring alternator (D+) to battery or to engine control unit , alternator	A750		E	1
8B1F00	Engine uppercarr. Travel pedal No gas switch erroneous Use low value 303100: Check wiring engine control unit to travel pedal, check travel pedal, replace	A750		E	1
8B1F01	Engine uppercarr. Travel pedal maximum signal difference channel 1 and 2 exceeded Use low value 303101: Check wiring engine control unit to travel pedal, check travel pedal, replace	A750		E	1
8B2000	Engine uppercarr. Plausibility error Charge pressure to atmospheric pressure no reaction 303200: Replace sensor, check intake system for leaks	A750		E	0
8B2100	Engine uppercarr. Error in Rail pr. system Pressure relief valve 1 has been actuated High pressure regulation emergency operation activated 303300: Check engine Stop/start, Rail circuit, Test unit, wiring Test unit, Rail pr. sensor	A750		E	2
8B2101	Engine uppercarr. Error in Rail pr. system Pressure relief valve 2 has been actuated High pressure regulation emergency operation activated 303301: Check engine Stop/start, Rail circuit, Test unit, wiring Test unit, Rail pr. sensor	A750		E	2
8B2102	Engine uppercarr. Error in Rail pr. system Emerg. op. high pr. regulation activated Power reduction, high pressure pump control turned off 303302: Check rail circuit 1/2, Check wiring harness, plug	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2103	Engine uppercarr. Error in Rail pr. system Maximum pressure deviation high pr. sensor 1 and 2 exceeded No reaction on engine, the larger of the high pressure sensor values is used 303303: Check wiring harness, plug, rail pr. sensors, check rail circuit 1/2	A750		E	1
8B2104	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 1 too large deviation (positive) no reaction 303304: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2105	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 2 too large deviation (positive) no reaction 303305: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2106	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 1 too large deviation (negative) no reaction 303306: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2107	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 2 too large deviation (negative) no reaction 303307: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2108	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 1 has leakage no reaction 303308: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2109	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 2 has leakage no reaction 303309: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B210A	Engine uppercarr. Error in Rail pr. system VCV Plausibility error Pump 1 High pressure regulation emergency operation activated 303310: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	1
8B210B	Engine uppercarr. Error in Rail pr. system VCV Plausibility error Pump 2 303311: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	0
8B210C	Engine uppercarr. Error in Rail pr. system common-rail regulating circuit 1 has leakage (CRS-System) no reaction 303312: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B210D	Engine uppercarr. Error in Rail pr. system common-rail regulating circuit 2 has leakage (CRS-System) no reaction 303313: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	1
8B2200	Engine uppercarr. Current outlet 1 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303400: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2201	Engine uppercarr. Current outlet 1 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303401: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2202	Engine uppercarr. Current outlet 1 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303402: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2203	Engine uppercarr. Current outlet 1 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303403: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2204	Engine uppercarr. Current outlet 1 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303404: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2205	Engine uppercarr. Current outlet 1 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303405: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2206	Engine uppercarr. Current outlet 1 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303406: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2207	Engine uppercarr. Current outlet 1 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303407: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2208	Engine uppercarr. Current outlet 1 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303408: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2209	Engine uppercarr. Current outlet 1 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303409: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B220A	Engine uppercarr. Current outlet 1 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303410: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2300	Engine uppercarr. Current outlet 2 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303500: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2301	Engine uppercarr. Current outlet 2 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303501: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2302	Engine uppercarr. Current outlet 2 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303502: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2303	Engine uppercarr. Current outlet 2 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303503: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2304	Engine uppercarr. Current outlet 2 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303504: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2305	Engine uppercarr. Current outlet 2 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303505: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2306	Engine uppercarr. Current outlet 2 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303506: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2307	Engine uppercarr. Current outlet 2 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303507: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2308	Engine uppercarr. Current outlet 2 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303508: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2309	Engine uppercarr. Current outlet 2 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303509: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B230A	Engine uppercarr. Current outlet 2 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303510: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2400	Engine uppercarr. Current outlet 3 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303600: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2401	Engine uppercarr. Current outlet 3 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303601: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2402	Engine uppercarr. Current outlet 3 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303602: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2403	Engine uppercarr. Current outlet 3 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303603: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2404	Engine uppercarr. Current outlet 3 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303604: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2405	Engine uppercarr. Current outlet 3 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303605: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2406	Engine uppercarr. Current outlet 3 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303606: Check wiring harness, plug, CR-comp.3, engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2407	Engine uppercarr. Current outlet 3 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303607: Check wiring harness, plug, CR-comp.3, engine control unit	A750		E	2
8B2408	Engine uppercarr. Current outlet 3 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303608: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2409	Engine uppercarr. Current outlet 3 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303609: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B240A	Engine uppercarr. Current outlet 3 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303610: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2500	Engine uppercarr. Current outlet 4 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303700: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2501	Engine uppercarr. Current outlet 4 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303701: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2502	Engine uppercarr. Current outlet 4 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303702: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2503	Engine uppercarr. Current outlet 4 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303703: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2504	Engine uppercarr. Current outlet 4 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303704: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2505	Engine uppercarr. Current outlet 4 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303705: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2506	Engine uppercarr. Current outlet 4 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303706: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2507	Engine uppercarr. Current outlet 4 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303707: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2508	Engine uppercarr. Current outlet 4 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303708: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2509	Engine uppercarr. Current outlet 4 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303709: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B250A	Engine uppercarr. Current outlet 4 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303710: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2600	Engine uppercarr. Actuation Starter Broken wire or Short circuit after ground Engine start not possible 303800: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2601	Engine uppercarr. Actuation Starter Broken wire or short circuit after supply voltage Engine start not possible 303801: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2602	Engine uppercarr. Actuation Starter Hardware error (control unit defective) Engine start not possible 303802: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2603	Engine uppercarr. Actuation Starter Maximum signal difference to actuation exceeded no reaction 303803: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2604	Engine uppercarr. Actuation Starter Maximum signal difference to actuation exceeded no reaction 303804: Check wiring harness, plug, Starter, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2605	Engine uppercarr. Actuation Starter Current measured without actuation no reaction 303805: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2606	Engine uppercarr. Actuation Starter Current too low in actuated state no reaction 303806: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2607	Engine uppercarr. Actuation Starter Current too high in actuated state no reaction 303807: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2608	Engine uppercarr. Actuation Starter Ground switch overcurrent no reaction 303808: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2609	Engine uppercarr. Actuation Starter Plus switch overcurrent no reaction 303809: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B260A	Engine uppercarr. Actuation Starter Maximum analog value exceeded (PWM) no reaction 303810: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2700	Engine uppercarr. Actuation fan 1 cooling Broken wire or Short circuit after ground no reaction 303900: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2701	Engine uppercarr. Actuation fan 1 cooling Broken wire or short circuit after supply voltage no reaction 303901: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2702	Engine uppercarr. Actuation fan 1 cooling Hardware error (control unit defective) no reaction 303902: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2703	Engine uppercarr. Actuation fan 1 cooling Maximum signal difference to actuation exceeded no reaction 303903: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2704	Engine uppercarr. Actuation fan 1 cooling Maximum signal difference to actuation exceeded no reaction 303904: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2705	Engine uppercarr. Actuation fan 1 cooling Current measured without actuation no reaction 303905: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2706	Engine uppercarr. Actuation fan 1 cooling Current too low in actuated state no reaction 303906: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2707	Engine uppercarr. Actuation fan 1 cooling Current too high in actuated state no reaction 303907: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2708	Engine uppercarr. Actuation fan 1 cooling Ground switch overcurrent no reaction 303908: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2709	Engine uppercarr. Actuation fan 1 cooling Plus switch overcurrent no reaction 303909: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B270A	Engine uppercarr. Actuation fan 1 cooling Maximum analog value exceeded (PWM) no reaction 303910: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2800	Engine uppercarr. Actuation fan 2 cooling Broken wire or Short circuit after ground no reaction 304000: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2801	Engine uppercarr. Actuation fan 2 cooling Broken wire or short circuit after supply voltage no reaction 304001: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2802	Engine uppercarr. Actuation fan 2 cooling Hardware error (control unit defective) no reaction 304002: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2803	Engine uppercarr. Actuation fan 2 cooling Maximum signal difference to actuation exceeded no reaction 304003: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2804	Engine uppercarr. Actuation fan 2 cooling Maximum signal difference to actuation exceeded no reaction 304004: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2805	Engine uppercarr. Actuation fan 2 cooling Current measured without actuation no reaction 304005: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2806	Engine uppercarr. Actuation fan 2 cooling Current too low in actuated state no reaction 304006: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2807	Engine uppercarr. Actuation fan 2 cooling Current too high in actuated state no reaction 304007: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2808	Engine uppercarr. Actuation fan 2 cooling Ground switch overcurrent no reaction 304008: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2809	Engine uppercarr. Actuation fan 2 cooling Plus switch overcurrent no reaction 304009: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B280A	Engine uppercarr. Actuation fan 2 cooling Maximum analog value exceeded (PWM) no reaction 304010: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2900	Engine uppercarr. Actuation fan 1 inverted cooling Broken wire or Short circuit after ground no reaction 304100: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2901	Engine uppercarr. Actuation fan 1 inverted cooling Broken wire or short circuit after supply voltage no reaction 304101: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2902	Engine uppercarr. Actuation fan 1 inverted cooling Hardware error (control unit defective) no reaction 304102: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2903	Engine uppercarr. Actuation fan 1 inverted cooling Maximum signal difference to actuation exceeded no reaction 304103: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2904	Engine uppercarr. Actuation fan 1 inverted cooling Maximum signal difference to actuation exceeded no reaction 304104: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2905	Engine uppercarr. Actuation fan 1 inverted cooling Current measured without actuation no reaction 304105: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2906	Engine uppercarr. Actuation fan 1 inverted cooling Current too low in actuated state no reaction 304106: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2907	Engine uppercarr. Actuation fan 1 inverted cooling Current too high in actuated state no reaction 304107: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2908	Engine uppercarr. Actuation fan 1 inverted cooling Ground switch overcurrent no reaction 304108: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2909	Engine uppercarr. Actuation fan 1 inverted cooling Plus switch overcurrent no reaction 304109: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B290A	Engine uppercarr. Actuation fan 1 inverted cooling Maximum analog value exceeded (PWM) no reaction 304110: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A00	Engine uppercarr. Actuation fan 2 inverted cooling Broken wire or Short circuit after ground no reaction 304200: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2A01	Engine uppercarr. Actuation fan 2 inverted cooling Broken wire or short circuit after supply voltage no reaction 304201: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A02	Engine uppercarr. Actuation fan 2 inverted cooling Hardware error (control unit defective) no reaction 304202: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A03	Engine uppercarr. Actuation fan 2 inverted cooling Maximum signal difference to actuation exceeded no reaction 304203: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A04	Engine uppercarr. Actuation fan 2 inverted cooling Maximum signal difference to actuation exceeded no reaction 304204: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A05	Engine uppercarr. Actuation fan 2 inverted cooling Current measured without actuation no reaction 304205: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A06	Engine uppercarr. Actuation fan 2 inverted cooling Current too low in actuated state no reaction 304206: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A07	Engine uppercarr. Actuation fan 2 inverted cooling Current too high in actuated state no reaction 304207: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A08	Engine uppercarr. Actuation fan 2 inverted cooling Ground switch overcurrent no reaction 304208: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A09	Engine uppercarr. Actuation fan 2 inverted cooling Plus switch overcurrent no reaction 304209: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A0A	Engine uppercarr. Actuation fan 2 inverted cooling Maximum analog value exceeded (PWM) no reaction 304210: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2B00	Engine uppercarr. Actuation Heat flange / Flame start Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304300: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B01	Engine uppercarr. Actuation Heat flange / Flame start Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304301: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B02	Engine uppercarr. Actuation Heat flange / Flame start Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304302: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B03	Engine uppercarr. Actuation Heat flange / Flame start Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304303: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B04	Engine uppercarr. Actuation Heat flange / Flame start Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304304: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B05	Engine uppercarr. Actuation Heat flange / Flame start Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304305: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B06	Engine uppercarr. Actuation Heat flange / Flame start Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304306: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B07	Engine uppercarr. Actuation Heat flange / Flame start Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304307: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B08	Engine uppercarr. Actuation Heat flange / Flame start Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304308: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B09	Engine uppercarr. Actuation Heat flange / Flame start Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304309: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2B0A	Engine uppercarr. Actuation Heat flange / Flame start Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304310: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B0B	Engine uppercarr. Actuation Heat flange / Flame start No voltage measured on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304311: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B0C	Engine uppercarr. Actuation Heat flange / Flame start Voltage error on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304312: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C00	Engine uppercarr. Actuation Heat flange / Flame start 2 Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304400: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C01	Engine uppercarr. Actuation Heat flange / Flame start 2 Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304401: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C02	Engine uppercarr. Actuation Heat flange / Flame start 2 Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304402: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C03	Engine uppercarr. Actuation Heat flange / Flame start 2 Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304403: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C04	Engine uppercarr. Actuation Heat flange / Flame start 2 Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304404: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C05	Engine uppercarr. Actuation Heat flange / Flame start 2 Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304405: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C06	Engine uppercarr. Actuation Heat flange / Flame start 2 Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304406: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2C07	Engine uppercarr. Actuation Heat flange / Flame start 2 Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304407: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C08	Engine uppercarr. Actuation Heat flange / Flame start 2 Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304408: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C09	Engine uppercarr. Actuation Heat flange / Flame start 2 Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304409: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C0A	Engine uppercarr. Actuation Heat flange / Flame start 2 Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304410: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C0B	Engine uppercarr. Actuation Heat flange / Flame start 2 No voltage measured on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304411: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C0C	Engine uppercarr. Actuation Heat flange / Flame start 2 Voltage error on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304412: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D00	Engine uppercarr. Actuation Solenoid valve Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304500: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D01	Engine uppercarr. Actuation Solenoid valve Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304501: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D02	Engine uppercarr. Actuation Solenoid valve Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304502: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D03	Engine uppercarr. Actuation Solenoid valve Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304503: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2D04	Engine uppercarr. Actuation Solenoid valve Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304504: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D05	Engine uppercarr. Actuation Solenoid valve Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304505: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D06	Engine uppercarr. Actuation Solenoid valve Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304506: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D07	Engine uppercarr. Actuation Solenoid valve Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304507: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D08	Engine uppercarr. Actuation Solenoid valve Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304508: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D09	Engine uppercarr. Actuation Solenoid valve Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304509: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D0A	Engine uppercarr. Actuation Solenoid valve Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304510: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2E00	Engine uppercarr. Actuation Air flap Broken wire or Short circuit after ground no reaction 304600: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E01	Engine uppercarr. Actuation Air flap Broken wire or short circuit after supply voltage no reaction 304601: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E02	Engine uppercarr. Actuation Air flap Hardware error (control unit defective) no reaction 304602: Check wiring harness, plug, air flap, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2E03	Engine uppercarr. Actuation Air flap Maximum signal difference to actuation exceeded no reaction 304603: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E04	Engine uppercarr. Actuation Air flap Maximum signal difference to actuation exceeded no reaction 304604: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E05	Engine uppercarr. Actuation Air flap Current measured without actuation no reaction 304605: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E06	Engine uppercarr. Actuation Air flap Current too low in actuated state no reaction 304606: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E07	Engine uppercarr. Actuation Air flap Current too high in actuated state no reaction 304607: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E08	Engine uppercarr. Actuation Air flap Ground switch overcurrent no reaction 304608: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E09	Engine uppercarr. Actuation Air flap Plus switch overcurrent no reaction 304609: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E0A	Engine uppercarr. Actuation Air flap Maximum analog value exceeded (PWM) no reaction 304610: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2F00	Engine uppercarr. Actuation Turbocharger Broken wire or Short circuit after ground No reaction, change over to OL 304700: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F01	Engine uppercarr. Actuation Turbocharger Broken wire or short circuit after supply voltage No reaction, change over to OL 304701: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2F02	Engine uppercarr. Actuation Turbocharger Hardware error (control unit defective) No reaction, change over to OL 304702: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F03	Engine uppercarr. Actuation Turbocharger Maximum signal difference to actuation exceeded No reaction, change over to OL 304703: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F04	Engine uppercarr. Actuation Turbocharger Maximum signal difference to actuation exceeded No reaction, change over to OL 304704: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F05	Engine uppercarr. Actuation Turbocharger Current measured without actuation No reaction, change over to OL 304705: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F06	Engine uppercarr. Actuation Turbocharger Current too low in actuated state No reaction, change over to OL 304706: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F07	Engine uppercarr. Actuation Turbocharger Current too high in actuated state No reaction, change over to OL 304707: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F08	Engine uppercarr. Actuation Turbocharger Ground switch overcurrent No reaction, change over to OL 304708: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F09	Engine uppercarr. Actuation Turbocharger Plus switch overcurrent No reaction, change over to OL 304709: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F0A	Engine uppercarr. Actuation Turbocharger Maximum analog value exceeded (PWM) No reaction, change over to OL 304710: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3000	Engine uppercarr. Actuation Turbocharger 2 Broken wire or Short circuit after ground No reaction, change over to OL 304800: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3001	Engine uppercarr. Actuation Turbocharger 2 Broken wire or short circuit after supply voltage No reaction, change over to OL 304801: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3002	Engine uppercarr. Actuation Turbocharger 2 Hardware error (control unit defective) No reaction, change over to OL 304802: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3003	Engine uppercarr. Actuation Turbocharger 2 Maximum signal difference to actuation exceeded No reaction, change over to OL 304803: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3004	Engine uppercarr. Actuation Turbocharger 2 Maximum signal difference to actuation exceeded No reaction, change over to OL 304804: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3005	Engine uppercarr. Actuation Turbocharger 2 Current measured without actuation No reaction, change over to OL 304805: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3006	Engine uppercarr. Actuation Turbocharger 2 Current too low in actuated state No reaction, change over to OL 304806: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3007	Engine uppercarr. Actuation Turbocharger 2 Current too high in actuated state No reaction, change over to OL 304807: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3008	Engine uppercarr. Actuation Turbocharger 2 Ground switch overcurrent No reaction, change over to OL 304808: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3009	Engine uppercarr. Actuation Turbocharger 2 Plus switch overcurrent No reaction, change over to OL 304809: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B300A	Engine uppercarr. Actuation Turbocharger 2 Maximum analog value exceeded (PWM) No reaction, change over to OL 304810: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3100	Engine uppercarr. Actuation AGR 1 Broken wire or Short circuit after ground Function engine brake flap deactivated 304900: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3101	Engine uppercarr. Actuation AGR 1 Broken wire or short circuit after supply voltage Function engine brake flap deactivated 304901: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3102	Engine uppercarr. Actuation AGR 1 Hardware error (control unit defective) Function engine brake flap deactivated 304902: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3103	Engine uppercarr. Actuation AGR 1 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 304903: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3104	Engine uppercarr. Actuation AGR 1 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 304904: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3105	Engine uppercarr. Actuation AGR 1 Current measured without actuation Function engine brake flap deactivated 304905: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3106	Engine uppercarr. Actuation AGR 1 Current too low in actuated state Function engine brake flap deactivated 304906: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3107	Engine uppercarr. Actuation AGR 1 Current too high in actuated state Function engine brake flap deactivated 304907: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B310B	Engine uppercarr. Actuation AGR 1 Deviation error, AGR open too wide Function engine brake flap deactivated 304911: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B310C	Engine uppercarr. Actuation AGR 1 Deviation error, AGR open too little Function engine brake flap deactivated 304912: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B310D	Engine uppercarr. Actuation AGR 1 Error in CAN-Module AGR Function engine brake flap deactivated 304913: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3200	Engine uppercarr. Actuation AGR 2 Broken wire or Short circuit after ground Function engine brake flap deactivated 305000: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3201	Engine uppercarr. Actuation AGR 2 Broken wire or short circuit after supply voltage Function engine brake flap deactivated 305001: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3202	Engine uppercarr. Actuation AGR 2 Hardware error (control unit defective) Function engine brake flap deactivated 305002: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3203	Engine uppercarr. Actuation AGR 2 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 305003: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3204	Engine uppercarr. Actuation AGR 2 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 305004: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3205	Engine uppercarr. Actuation AGR 2 Current measured without actuation Function engine brake flap deactivated 305005: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3206	Engine uppercarr. Actuation AGR 2 Current too low in actuated state Function engine brake flap deactivated 305006: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3207	Engine uppercarr. Actuation AGR 2 Current too high in actuated state Function engine brake flap deactivated 305007: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B320B	Engine uppercarr. Actuation AGR 2 Deviation error, AGR open too wide Function engine brake flap deactivated 305011: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B320C	Engine uppercarr. Actuation AGR 2 Deviation error, AGR open too little Function engine brake flap deactivated 305012: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B320D	Engine uppercarr. Actuation AGR 2 Error in CAN-Module AGR Function engine brake flap deactivated 305013: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3300	Engine uppercarr. Lamp emerg. oper Broken wire or Short circuit after ground No reaction, status is not shown 305100: Check wiring	A750		E	1
8B3301	Engine uppercarr. Lamp emerg. oper Broken wire or short circuit after supply voltage No reaction, status is not shown 305101: Check wiring	A750		E	1
8B3302	Engine uppercarr. Lamp emerg. oper Hardware error (control unit defective) No reaction, status is not shown 305102: Check wiring	A750		E	1
8B3303	Engine uppercarr. Lamp emerg. oper Maximum signal difference to actuation exceeded No reaction, status is not shown 305103: Check wiring	A750		E	1
8B3304	Engine uppercarr. Lamp emerg. oper Maximum signal difference to actuation exceeded No reaction, status is not shown 305104: Check wiring	A750		E	1
8B3305	Engine uppercarr. Lamp emerg. oper Current measured without actuation No reaction, status is not shown 305105: Check wiring	A750		E	1
8B3306	Engine uppercarr. Lamp emerg. oper Current too low in actuated state No reaction, status is not shown 305106: Check wiring	A750		E	1
8B3307	Engine uppercarr. Lamp emerg. oper Current too high in actuated state No reaction, status is not shown 305107: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3308	Engine uppercarr. Lamp emerg. oper Ground switch overcurrent No reaction, status is not shown 305108: Check wiring	A750		E	1
8B3309	Engine uppercarr. Lamp emerg. oper Plus switch overcurrent No reaction, status is not shown 305109: Check wiring	A750		E	1
8B330A	Engine uppercarr. Lamp emerg. oper Maximum analog value exceeded (PWM) No reaction, status is not shown 305110: Check wiring	A750		E	1
8B3400	Engine uppercarr. Lamp cold start / Start readiness Broken wire or Short circuit after ground No reaction, status is not shown 305200: Check wiring	A750		E	1
8B3401	Engine uppercarr. Lamp cold start / Start readiness Broken wire or short circuit after supply voltage No reaction, status is not shown 305201: Check wiring	A750		E	1
8B3402	Engine uppercarr. Lamp cold start / Start readiness Hardware error (control unit defective) No reaction, status is not shown 305202: Check wiring	A750		E	1
8B3403	Engine uppercarr. Lamp cold start / Start readiness Maximum signal difference to actuation exceeded No reaction, status is not shown 305203: Check wiring	A750		E	1
8B3404	Engine uppercarr. Lamp cold start / Start readiness Maximum signal difference to actuation exceeded No reaction, status is not shown 305204: Check wiring	A750		E	1
8B3405	Engine uppercarr. Lamp cold start / Start readiness Current measured without actuation No reaction, status is not shown 305205: Check wiring	A750		E	1
8B3406	Engine uppercarr. Lamp cold start / Start readiness Current too low in actuated state No reaction, status is not shown 305206: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3407	Engine uppercarr. Lamp cold start / Start readiness Current too high in actuated state No reaction, status is not shown 305207: Check wiring	A750		E	1
8B3408	Engine uppercarr. Lamp cold start / Start readiness Ground switch overcurrent No reaction, status is not shown 305208: Check wiring	A750		E	1
8B3409	Engine uppercarr. Lamp cold start / Start readiness Plus switch overcurrent No reaction, status is not shown 305209: Check wiring	A750		E	1
8B340A	Engine uppercarr. Lamp cold start / Start readiness Maximum analog value exceeded (PWM) No reaction, status is not shown 305210: Check wiring	A750		E	1
8B3500	Engine uppercarr. Request engine stop Broken wire or Short circuit after ground No reaction, status is not shown 305300: Check wiring	A750		E	1
8B3501	Engine uppercarr. Request engine stop Broken wire or short circuit after supply voltage No reaction, status is not shown 305301: Check wiring	A750		E	1
8B3502	Engine uppercarr. Request engine stop Hardware error (control unit defective) No reaction, status is not shown 305302: Check wiring	A750		E	1
8B3503	Engine uppercarr. Request engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305303: Check wiring	A750		E	1
8B3504	Engine uppercarr. Request engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305304: Check wiring	A750		E	1
8B3505	Engine uppercarr. Request engine stop Current measured without actuation 305305: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3506	Engine uppercarr. Request engine stop Current too low in actuated state No reaction, status is not shown 305306: Check wiring	A750		E	1
8B3507	Engine uppercarr. Request engine stop Current too high in actuated state No reaction, status is not shown 305307: Check wiring	A750		E	1
8B3508	Engine uppercarr. Request engine stop Ground switch overcurrent No reaction, status is not shown 305308: Check wiring	A750		E	1
8B3509	Engine uppercarr. Request engine stop Plus switch overcurrent No reaction, status is not shown 305309: Check wiring	A750		E	1
8B350A	Engine uppercarr. Request engine stop Maximum analog value exceeded (PWM) No reaction, status is not shown 305310: Check wiring	A750		E	1
8B3600	Engine uppercarr. Outlet engine running Broken wire or Short circuit after ground No reaction, status is not shown 305400: Check wiring	A750		E	1
8B3601	Engine uppercarr. Outlet engine running Broken wire or short circuit after supply voltage No reaction, status is not shown 305401: Check wiring	A750		E	1
8B3602	Engine uppercarr. Outlet engine running Hardware error (control unit defective) No reaction, status is not shown 305402: Check wiring	A750		E	1
8B3603	Engine uppercarr. Outlet engine running Maximum signal difference to actuation exceeded No reaction, status is not shown 305403: Check wiring	A750		E	1
8B3604	Engine uppercarr. Outlet engine running Maximum signal difference to actuation exceeded No reaction, status is not shown 305404: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3605	Engine uppercarr. Outlet engine running Current measured without actuation No reaction, status is not shown 305405: Check wiring	A750		E	1
8B3606	Engine uppercarr. Outlet engine running Current too low in actuated state No reaction, status is not shown 305406: Check wiring	A750		E	1
8B3607	Engine uppercarr. Outlet engine running Current too high in actuated state No reaction, status is not shown 305407: Check wiring	A750		E	1
8B3608	Engine uppercarr. Outlet engine running Ground switch overcurrent No reaction, status is not shown 305408: Check wiring	A750		E	1
8B3609	Engine uppercarr. Outlet engine running Plus switch overcurrent No reaction, status is not shown 305409: Check wiring	A750		E	1
8B360A	Engine uppercarr. Outlet engine running Maximum analog value exceeded (PWM) No reaction, status is not shown 305410: Check wiring	A750		E	1
8B3700	Engine uppercarr. Display engine stop Broken wire or Short circuit after ground No reaction, status is not shown 305500: Check wiring	A750		E	1
8B3701	Engine uppercarr. Display engine stop Broken wire or short circuit after supply voltage No reaction, status is not shown 305501: Check wiring	A750		E	1
8B3702	Engine uppercarr. Display engine stop Hardware error (control unit defective) No reaction, status is not shown 305502: Check wiring	A750		E	1
8B3703	Engine uppercarr. Display engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305503: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3704	Engine uppercarr. Display engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305504: Check wiring	A750		E	1
8B3705	Engine uppercarr. Display engine stop Current measured without actuation No reaction, status is not shown 305505: Check wiring	A750		E	1
8B3706	Engine uppercarr. Display engine stop Current too low in actuated state No reaction, status is not shown 305506: Check wiring	A750		E	1
8B3707	Engine uppercarr. Display engine stop Current too high in actuated state No reaction, status is not shown 305507: Check wiring	A750		E	1
8B3708	Engine uppercarr. Display engine stop Ground switch overcurrent No reaction, status is not shown 305508: Check wiring	A750		E	1
8B3709	Engine uppercarr. Display engine stop Plus switch overcurrent No reaction, status is not shown 305509: Check wiring	A750		E	1
8B370A	Engine uppercarr. Display engine stop Maximum analog value exceeded (PWM) No reaction, status is not shown 305510: Check wiring	A750		E	1
8B3800	Engine uppercarr. DAReversible fan Broken wire or Short circuit after ground The reversible fan control 1 is not actuated 305600: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3801	Engine uppercarr. DAReversible fan Broken wire or short circuit after supply voltage The reversible fan control 1 is not actuated 305601: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3802	Engine uppercarr. DAReversible fan Hardware error (control unit defective) The reversible fan control 1 is not actuated 305602: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3803	Engine uppercarr. DAReversible fan Maximum signal difference to actuation exceeded The reversible fan control 1 is not actuated 305603: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3804	Engine uppercarr. DAReversible fan Maximum signal difference to actuation exceeded The reversible fan control 1 is not actuated 305604: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3805	Engine uppercarr. DAReversible fan Current measured without actuation The reversible fan control 1 is not actuated 305605: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3806	Engine uppercarr. DAReversible fan Current too low in actuated state The reversible fan control 1 is not actuated 305606: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3807	Engine uppercarr. DAReversible fan Current too high in actuated state The reversible fan control 1 is not actuated 305607: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3900	Engine uppercarr. Outlet engine rpm Broken wire or Short circuit after ground 305700:	A750		E	0
8B3901	Engine uppercarr. Outlet engine rpm Broken wire or short circuit after supply voltage 305701:	A750		E	0
8B3A00	Engine uppercarr. Outlet engine off Broken wire or Short circuit after ground no reaction 305800: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A01	Engine uppercarr. Outlet engine off Broken wire or short circuit after supply voltage no reaction 305801: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A02	Engine uppercarr. Outlet engine off Error on hardware recognized no reaction 305802: Check wiring, engine control unit and unit connected to this unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3A03	Engine uppercarr. Outlet engine off Regulating deviation negative too high no reaction 305803: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A04	Engine uppercarr. Outlet engine off Regulating deviation positive too high no reaction 305804: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A05	Engine uppercarr. Outlet engine off Current in shut off status too high no reaction 305805: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A06	Engine uppercarr. Outlet engine off Current too low no reaction 305806: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A07	Engine uppercarr. Outlet engine off Current too high no reaction 305807: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A08	Engine uppercarr. Outlet engine off Current on ground switch too high no reaction 305808: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A09	Engine uppercarr. Outlet engine off Current on plus switch too high no reaction 305809: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A0A	Engine uppercarr. Outlet engine off Pulse width (PWM) on maximum no reaction 305810: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B00	Engine uppercarr. Output warning signal (Amber Warning) Broken wire or Short circuit after ground no reaction 305900: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B01	Engine uppercarr. Output warning signal (Amber Warning) Broken wire or short circuit after supply voltage no reaction 305901: Check wiring, engine control unit and unit connected to this unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3B02	Engine uppercarr. Output warning signal (Amber Warning) Error on hardware recognized no reaction 305902: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B03	Engine uppercarr. Output warning signal (Amber Warning) Regulating deviation negative too high no reaction 305903: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B04	Engine uppercarr. Output warning signal (Amber Warning) Regulating deviation positive too high no reaction 305904: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B05	Engine uppercarr. Output warning signal (Amber Warning) Current in shut off status too high no reaction 305905: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B06	Engine uppercarr. Output warning signal (Amber Warning) Current too low no reaction 305906: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B07	Engine uppercarr. Output warning signal (Amber Warning) Current too high no reaction 305907: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B08	Engine uppercarr. Output warning signal (Amber Warning) Current on ground switch too high no reaction 305908: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B09	Engine uppercarr. Output warning signal (Amber Warning) Current on plus switch too high no reaction 305909: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3C00	Engine uppercarr. Mass flow sensor 1 Temperature sensor erroneous Possibly power reduction 306000: Replace sensor	A750		E	1
8B3C01	Engine uppercarr. Mass flow sensor 1 Absolute pressure sensor erroneous Possibly power reduction 306001: Replace sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3C02	Engine uppercarr. Mass flow sensor 1 Differential pressure sensor erroneous Possibly power reduction 306002: Replace sensor	A750		E	1
8B3C03	Engine uppercarr. Mass flow sensor 1 excess temperature Change over to 2nd Lambda Signal 306003: Replace sensor	A750		E	1
8B3C0A	Engine uppercarr. Mass flow sensor 1 Ground current signal 1 implausible, detection at high ground current Warning light on 306010: Clean sensor or replace	A750		E	1
8B3C0B	Engine uppercarr. Mass flow sensor 1 Ground current signal 1 implausible, detection at low ground current Warning light on 306011: Clean sensor or replace	A750		E	1
8B3D00	Engine uppercarr. Mass flow sensor 2 Temperature sensor erroneous Possibly power reduction 306100: Replace sensor	A750		E	1
8B3D01	Engine uppercarr. Mass flow sensor 2 Absolute pressure sensor erroneous Possibly power reduction 306101: Replace sensor	A750		E	1
8B3D02	Engine uppercarr. Mass flow sensor 2 Differential pressure sensor erroneous Possibly power reduction 306102: Replace sensor	A750		E	1
8B3D03	Engine uppercarr. Mass flow sensor 2 excess temperature Change over to 2nd Lambda Signal 306103: Replace sensor	A750		E	1
8B3D0A	Engine uppercarr. Mass flow sensor 2 Ground current signal 1 implausible, detection at high ground current Warning light on 306110: Clean sensor or replace	A750		E	1
8B3D0B	Engine uppercarr. Mass flow sensor 2 Ground current signal 1 implausible, detection at low ground current Warning light on 306111: Clean sensor or replace	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3E00	Engine uppercarr. NOx sensor "Up 1" Open line No Lambda correction - possibly power reduction 306200: Replace sensor	A750		E	1
8B3E01	Engine uppercarr. NOx sensor "Up 1" Short circuit No Lambda correction - possibly power reduction 306201: Replace sensor	A750		E	1
8B3E0A	Engine uppercarr. NOx sensor "Up 1" Value implausible Warning light on 306210: Replace sensor	A750		E	1
8B3F00	Engine uppercarr. NOx sensor "Down 1" Open line No Lambda correction - possibly power reduction 306300: Replace sensor	A750		E	1
8B3F01	Engine uppercarr. NOx sensor "Down 1" Short circuit No Lambda correction - possibly power reduction 306301: Replace sensor	A750		E	1
8B4000	Engine uppercarr. NOx sensor "Up 2" Open line No Lambda correction - possibly power reduction 306400: Replace sensor	A750		E	1
8B4001	Engine uppercarr. NOx sensor "Up 2" Short circuit No Lambda correction - possibly power reduction 306401: Replace sensor	A750		E	1
8B4100	Engine uppercarr. NOx sensor "Down 2" Open line No Lambda correction - possibly power reduction 306500: Replace sensor	A750		E	1
8B4101	Engine uppercarr. NOx sensor "Down 2" Short circuit No Lambda correction - possibly power reduction 306501: Replace sensor	A750		E	1
8B4200	Engine uppercarr. Water pump maximum rpm deviation exceeded no reaction 306600: Check wiring harness, plug, conn. Modul	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4300	Engine uppercarr. EGR-valve 1 excess temperature Power reduction of Diesel engine 306700: Check cooling module	A750		E	1
8B4301	Engine uppercarr. EGR-valve 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 306701: Check module: linkage, flap	A750		E	1
8B4302	Engine uppercarr. EGR-valve 1 Data communication CAN faulty Power reduction of Diesel engine 306702: Check wiring, Module	A750		E	1
8B4303	Engine uppercarr. EGR-valve 1 Data communication CAN interrupted Power reduction of Diesel engine 306703: Check wiring, Module	A750		E	1
8B4304	Engine uppercarr. EGR-valve 1 Spring erroneous Power reduction of Diesel engine 306704: Replace module	A750		E	1
8B4305	Engine uppercarr. EGR-valve 1 Gear erroneous Power reduction of Diesel engine 306705: Replace module	A750		E	1
8B4306	Engine uppercarr. EGR-valve 1 steering device error Power reduction of Diesel engine 306706: Replace module	A750		E	1
8B4307	Engine uppercarr. EGR-valve 1 Absolute position sensor erroneous Power reduction of Diesel engine 306707: Replace module	A750		E	1
8B4309	Engine uppercarr. EGR-valve 1 Calibration procedure erroneous Power reduction of Diesel engine 306709: Check module: linkage, flap	A750		E	1
8B430A	Engine uppercarr. EGR-valve 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306710: Check module: linkage, flap	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B430B	Engine uppercarr. EGR-valve 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306711: Check wiring alternator (D+) to battery or to engine control unit , alternator	A750		E	1
8B430C	Engine uppercarr. EGR-valve 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306712: Check module: linkage, flap	A750		E	1
8B430D	Engine uppercarr. EGR-valve 1 Reference to zero point erroneous Power reduction of Diesel engine 306713: Check module: linkage, flap	A750		E	1
8B4400	Engine uppercarr. EGR-valve 2 excess temperature Power reduction of Diesel engine 306800: Check cooling module	A750		E	1
8B4401	Engine uppercarr. EGR-valve 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 306801: Check module: linkage, flap	A750		E	1
8B4402	Engine uppercarr. EGR-valve 2 Data communication CAN faulty Power reduction of Diesel engine 306802: Check wiring, Module	A750		E	1
8B4403	Engine uppercarr. EGR-valve 2 Data communication CAN interrupted Power reduction of Diesel engine 306803: Check wiring, Module pruefen	A750		E	1
8B4404	Engine uppercarr. EGR-valve 2 Spring erroneous Power reduction of Diesel engine 306804: Replace module	A750		E	1
8B4405	Engine uppercarr. EGR-valve 2 Gear erroneous Power reduction of Diesel engine 306805: Replace module	A750		E	1
8B4406	Engine uppercarr. EGR-valve 2 steering device error Power reduction of Diesel engine 306806: Replace module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4407	Engine uppercarr. EGR-valve 2 Absolute position sensor erroneous Power reduction of Diesel engine 306807: Replace module	A750		E	1
8B4409	Engine uppercarr. EGR-valve 2 Calibration procedure erroneous Power reduction of Diesel engine 306809: Check module: linkage, flap	A750		E	1
8B440A	Engine uppercarr. EGR-valve 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306810: Check module: linkage, flap	A750		E	1
8B440B	Engine uppercarr. EGR-valve 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306811: Check wiring alternator (D+) to battery or to engine control unit, alternator	A750		E	1
8B440C	Engine uppercarr. EGR-valve 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306812: Check module: linkage, flap	A750		E	1
8B440D	Engine uppercarr. EGR-valve 2 Reference to zero point erroneous Power reduction of Diesel engine 306813: Check module: linkage, flap	A750		E	1
8B4500	Engine uppercarr. WG-valve 1 excess temperature Power reduction of Diesel engine 306900: Check cooling module	A750		E	1
8B4501	Engine uppercarr. WG-valve 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 306901: Check module: linkage, flap	A750		E	1
8B4502	Engine uppercarr. WG-valve 1 Data communication CAN faulty Power reduction of Diesel engine 306902: Check wiring, Module pruefen	A750		E	1
8B4503	Engine uppercarr. WG-valve 1 Data communication CAN interrupted Power reduction of Diesel engine 306903: Check wiring, Module pruefen	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4504	Engine uppercarr. WG-valve 1 Spring erroneous Power reduction of Diesel engine 306904: Replace module	A750		E	1
8B4505	Engine uppercarr. WG-valve 1 Gear erroneous Power reduction of Diesel engine 306905: Replace module	A750		E	1
8B4506	Engine uppercarr. WG-valve 1 steering device error Power reduction of Diesel engine 306906: Replace module	A750		E	1
8B4507	Engine uppercarr. WG-valve 1 Absolute position sensor erroneous Power reduction of Diesel engine 306907: Replace module	A750		E	1
8B4509	Engine uppercarr. WG-valve 1 Calibration procedure erroneous Power reduction of Diesel engine 306909: Check module: linkage, flap	A750		E	1
8B450A	Engine uppercarr. WG-valve 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306910: Check module: linkage, flap	A750		E	1
8B450B	Engine uppercarr. WG-valve 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306911: Check wiring alternator (D+) to battery or to engine control unit, alternator	A750		E	1
8B450C	Engine uppercarr. WG-valve 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306912: Check module: linkage, flap	A750		E	1
8B450D	Engine uppercarr. WG-valve 1 Reference to zero point erroneous Power reduction of Diesel engine 306913: Check module: linkage, flap	A750		E	1
8B4600	Engine uppercarr. WG-valve 2 excess temperature Power reduction of Diesel engine 307000: Check cooling module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4601	Engine uppercarr. WG-valve 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 307001: Check module: linkage, flap	A750		E	1
8B4602	Engine uppercarr. WG-valve 2 Data communication CAN faulty Power reduction of Diesel engine 307002: Check wiring, module	A750		E	1
8B4603	Engine uppercarr. WG-valve 2 Data communication CAN interrupted Power reduction of Diesel engine 307003: Check wiring, Module pruefen	A750		E	1
8B4604	Engine uppercarr. WG-valve 2 Spring erroneous Power reduction of Diesel engine 307004: Replace module	A750		E	1
8B4605	Engine uppercarr. WG-valve 2 Gear erroneous Power reduction of Diesel engine 307005: Replace module	A750		E	1
8B4606	Engine uppercarr. WG-valve 2 steering device error Power reduction of Diesel engine 307006: Replace module	A750		E	1
8B4607	Engine uppercarr. WG-valve 2 Absolute position sensor erroneous Power reduction of Diesel engine 307007: Replace module	A750		E	1
8B4609	Engine uppercarr. WG-valve 2 Calibration procedure erroneous Power reduction of Diesel engine 307009: Check module: linkage, flap	A750		E	1
8B460A	Engine uppercarr. WG-valve 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307010: Check module: linkage, flap	A750		E	1
8B460B	Engine uppercarr. WG-valve 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307011: Check wiring alternator (D+) to battery or to engine control unit , alternator	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B460C	Engine uppercarr. WG-valve 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307012: Check module: linkage, flap	A750		E	1
8B460D	Engine uppercarr. WG-valve 2 Reference to zero point erroneous Power reduction of Diesel engine 307013: Check module: linkage, flap	A750		E	1
8B4700	Engine uppercarr. Restrictor flap 1 excess temperature Power reduction of Diesel engine 307100: Check cooling module	A750		E	1
8B4701	Engine uppercarr. Restrictor flap 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 307101: Check module: linkage, flap	A750		E	1
8B4702	Engine uppercarr. Restrictor flap 1 Data communication CAN faulty Power reduction of Diesel engine 307102: Check wiring, Module pruefen	A750		E	1
8B4703	Engine uppercarr. Restrictor flap 1 Data communication CAN interrupted Power reduction of Diesel engine 307103: Check wiring, Module pruefen	A750		E	1
8B4704	Engine uppercarr. Restrictor flap 1 Spring erroneous Power reduction of Diesel engine 307104: Replace module	A750		E	1
8B4705	Engine uppercarr. Restrictor flap 1 Gear erroneous Power reduction of Diesel engine 307105: Replace module	A750		E	1
8B4706	Engine uppercarr. Restrictor flap 1 steering device error Power reduction of Diesel engine 307106: Replace module	A750		E	1
8B4707	Engine uppercarr. Restrictor flap 1 Absolute position sensor erroneous Power reduction of Diesel engine 307107: Replace module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4709	Engine uppercarr. Restrictor flap 1 Calibration procedure erroneous Power reduction of Diesel engine 307109: Check module: linkage, flap	A750		E	1
8B470A	Engine uppercarr. Restrictor flap 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307110: Check module: linkage, flap	A750		E	1
8B470B	Engine uppercarr. Restrictor flap 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307111: Check wiring alternator (D+) to battery or to engine control unit , alternator	A750		E	1
8B470C	Engine uppercarr. Restrictor flap 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307112: Check module: linkage, flap	A750		E	1
8B470D	Engine uppercarr. Restrictor flap 1 Reference to zero point erroneous Power reduction of Diesel engine 307113: Check module: linkage, flap	A750		E	1
8B4800	Engine uppercarr. Restrictor flap 2 excess temperature Power reduction of Diesel engine 307200: Check cooling module	A750		E	1
8B4801	Engine uppercarr. Restrictor flap 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 307201: Check module: linkage, flap	A750		E	1
8B4802	Engine uppercarr. Restrictor flap 2 Data communication CAN faulty Power reduction of Diesel engine 307202: Check wiring, modules	A750		E	1
8B4803	Engine uppercarr. Restrictor flap 2 Data communication CAN interrupted Power reduction of Diesel engine 307203: Check wiring, Module pruefen	A750		E	1
8B4804	Engine uppercarr. Restrictor flap 2 Spring erroneous Power reduction of Diesel engine 307204: Replace module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4805	Engine uppercarr. Restrictor flap 2 Gear erroneous Power reduction of Diesel engine 307205: Replace module	A750		E	1
8B4806	Engine uppercarr. Restrictor flap 2 steering device error Power reduction of Diesel engine 307206: Replace module	A750		E	1
8B4807	Engine uppercarr. Restrictor flap 2 Absolute position sensor erroneous Power reduction of Diesel engine 307207: Replace module	A750		E	1
8B4809	Engine uppercarr. Restrictor flap 2 Calibration procedure erroneous Power reduction of Diesel engine 307209: Check module: linkage, flap	A750		E	1
8B480A	Engine uppercarr. Restrictor flap 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307210: Check module: linkage, flap	A750		E	1
8B480B	Engine uppercarr. Restrictor flap 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307211: Check wiring alternator (D+) to batter or engine control unit , alternator	A750		E	1
8B480C	Engine uppercarr. Restrictor flap 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307212: Check module: linkage, flap	A750		E	1
8B480D	Engine uppercarr. Restrictor flap 2 Reference to zero point erroneous Power reduction of Diesel engine 307213: Check module: linkage, flap	A750		E	1
8B4900	Engine uppercarr. Relay outlet, sensors, actuators Line interruption or short circuit after ground 307300: Check wiring and control units	A750		E	1
8B4901	Engine uppercarr. Relay outlet, sensors, actuators Line interruption or short circuit after supply voltage 307301: Check wiring and control units	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4905	Engine uppercarr. Relay outlet, sensors, actuators Current too high in turned off status 307305: Check wiring and control units	A750		E	1
8B4906	Engine uppercarr. Relay outlet, sensors, actuators Current too low in turned off status 307306: Check wiring and control units	A750		E	1
8B4907	Engine uppercarr. Relay outlet, sensors, actuators Current too high in actuated status 307307: Check wiring and control units	A750		E	1
8B4A00	Engine uppercarr. Error machine Emerg. stop actuated, line interruption or short circuit after ground Engine stop 307400: Emerg. stop actuated, check wiring and emerg. stop button	A750		E	1
8B4B00	Engine uppercarr. Travel pedal Short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307500: Check wiring engine control unit/travel pedal sensor 1 (broken wire or short circuit after ground)	A750		E	1
8B4B01	Engine uppercarr. Travel pedal Sensor signal short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307501: Check wiring engine control unit/travel pedal sensor 1 (short circuit after batt. volt.)	A750		E	1
8B4B02	Engine uppercarr. Travel pedal Sensor supply voltage short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307502: Check wiring engine control unit/travel pedal sensor 1 (short circuit after ground)	A750		E	1
8B4B03	Engine uppercarr. Travel pedal Sensor supply voltage short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307503: Check wiring engine control unit/travel pedal sensor 1 (short circuit after batt. volt.)	A750		E	1
8B4B04	Engine uppercarr. Travel pedal Sensor signal outside permissible range 1 Remains at low idle when both travel pedal sensors failed 307504: Check operational status of engine	A750		E	1
8B4B05	Engine uppercarr. Travel pedal Sensor signal outside permissible range 2 Remains at low idle when both travel pedal sensors failed 307505: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4B06	Engine uppercarr. Travel pedal Plausibility error at engine off no reaction 307506: Check wiring engine control unit/sensor	A750		E	1
8B4C00	Engine uppercarr. accelerator 2 Short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307600: Check wiring engine control unit/travel pedal sensor 2 (broken wire or short circuit after ground)	A750		E	1
8B4C01	Engine uppercarr. accelerator 2 Sensor signal short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307601: Check wiring engine control unit/travel pedal sensor 2 (short circuit after batt. volt.)	A750		E	1
8B4C02	Engine uppercarr. accelerator 2 Sensor supply voltage short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307602: Check wiring engine control unit/travel pedal sensor 2 (short circuit after ground)	A750		E	1
8B4C03	Engine uppercarr. accelerator 2 Sensor supply voltage short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307603: Check wiring engine control unit/travel pedal sensor 2 (short circuit after batt. volt.)	A750		E	1
8B4C04	Engine uppercarr. accelerator 2 Sensor signal outside permissible range 1 Remains at low idle when both travel pedal sensors failed 307604: Check operational status of engine	A750		E	1
8B4C05	Engine uppercarr. accelerator 2 Sensor signal outside permissible range 2 Remains at low idle when both travel pedal sensors failed 307605: Check operational status of engine	A750		E	1
8B4C06	Engine uppercarr. accelerator 2 Plausibility error at engine off no reaction 307606: Check wiring engine control unit/sensor	A750		E	1
8B4D00	Engine uppercarr. Fill level sensor Urea tank Short circuit after ground or broken wire Benutzung des Ersatzwertes. 307700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B4D01	Engine uppercarr. Fill level sensor Urea tank Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 307701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4D02	Engine uppercarr. Fill level sensor Urea tank Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 307702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B4D03	Engine uppercarr. Fill level sensor Urea tank Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 307703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4D04	Engine uppercarr. Fill level sensor Urea tank Sensor signal outside permissible range 1 no reaction 307704: Ureastand	A750		E	1
8B4D05	Engine uppercarr. Fill level sensor Urea tank Sensor signal outside permissible range 2 no reaction 307705: Ureastand	A750		E	1
8B4D06	Engine uppercarr. Fill level sensor Urea tank Plausibility error at engine off no reaction 307706: Check wiring engine control unit/sensor	A750		E	1
8B4E00	Engine uppercarr. Fill level sensor engine oil Short circuit after ground or broken wire Benutzung des Ersatzwertes. 307800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B4E01	Engine uppercarr. Fill level sensor engine oil Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 307801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4E02	Engine uppercarr. Fill level sensor engine oil Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 307802: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B4E03	Engine uppercarr. Fill level sensor engine oil Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 307803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4E04	Engine uppercarr. Fill level sensor engine oil Sensor signal outside permissible range 1 no reaction 307804: Oil level, oil level sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4E05	Engine uppercarr. Fill level sensor engine oil Sensor signal outside permissible range 2 no reaction 307805: Oil level, oil level sensor	A750		E	1
8B4E06	Engine uppercarr. Fill level sensor engine oil Plausibility error at engine off no reaction 307806: Check wiring engine control unit/sensor	A750		E	1
8B4F00	Engine uppercarr. AGR Position sensor 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 307900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B4F01	Engine uppercarr. AGR Position sensor 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 307901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4F02	Engine uppercarr. AGR Position sensor 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 307902: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B4F03	Engine uppercarr. AGR Position sensor 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 307903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4F04	Engine uppercarr. AGR Position sensor 1 Sensor signal outside permissible range 1 no reaction 307904: AGR 1 Position sensor	A750		E	1
8B4F05	Engine uppercarr. AGR Position sensor 1 Sensor signal outside permissible range 2 no reaction 307905: AGR 1 Position sensor	A750		E	1
8B4F06	Engine uppercarr. AGR Position sensor 1 Plausibility error at engine off no reaction 307906: Check wiring engine control unit/sensor	A750		E	1
8B5000	Engine uppercarr. AGR Position sensor 2 Short circuit after ground or broken wire Use replacement value. Output red. in case of failure of both Commonrail pr. sensor, otherwise no reaction 308000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5001	Engine uppercarr. AGR Position sensor 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5002	Engine uppercarr. AGR Position sensor 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308002: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5003	Engine uppercarr. AGR Position sensor 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5004	Engine uppercarr. AGR Position sensor 2 Sensor signal outside permissible range 1 no reaction 308004: AGR 2 Position sensor	A750		E	1
8B5005	Engine uppercarr. AGR Position sensor 2 Sensor signal outside permissible range 2 no reaction 308005: AGR 2 Position sensor	A750		E	1
8B5006	Engine uppercarr. AGR Position sensor 2 Plausibility error at engine off no reaction 308006: Check wiring engine control unit/sensor	A750		E	1
8B5200	Engine uppercarr. Charge air pr. sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5201	Engine uppercarr. Charge air pr. sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5202	Engine uppercarr. Charge air pr. sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308202: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5203	Engine uppercarr. Charge air pr. sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5204	Engine uppercarr. Charge air pr. sensor Sensor signal outside permissible range 1 no reaction 308204: Check operational status of engine	A750		E	1
8B5205	Engine uppercarr. Charge air pr. sensor Sensor signal outside permissible range 2 no reaction 308205: Check operational status of engine	A750		E	1
8B5206	Engine uppercarr. Charge air pr. sensor Plausibility error at engine off no reaction 308206: Check wiring engine control unit/sensor	A750		E	1
8B5207	Engine uppercarr. Charge air pr. sensor Value implausible Warning light on, replace sensor 308207: Check wiring engine control unit/sensor	A750		E	1
8B5300	Engine uppercarr. Oil pressure sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5301	Engine uppercarr. Oil pressure sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5302	Engine uppercarr. Oil pressure sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308302: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5303	Engine uppercarr. Oil pressure sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5304	Engine uppercarr. Oil pressure sensor Sensor signal outside permissible range 1 no reaction 308304: Check operational status of engine	A750		E	1
8B5305	Engine uppercarr. Oil pressure sensor Sensor signal outside permissible range 2 no reaction 308305: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5306	Engine uppercarr. Oil pressure sensor Plausibility error at engine off no reaction 308306: Check wiring engine control unit/sensor	A750		E	1
8B5400	Engine uppercarr. Fuel pressure sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5401	Engine uppercarr. Fuel pressure sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5402	Engine uppercarr. Fuel pressure sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308402: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5403	Engine uppercarr. Fuel pressure sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5404	Engine uppercarr. Fuel pressure sensor Sensor signal outside permissible range 1 no reaction 308404: Check operational status of engine	A750		E	1
8B5405	Engine uppercarr. Fuel pressure sensor Sensor signal outside permissible range 2 no reaction 308405: Check operational status of engine	A750		E	1
8B5406	Engine uppercarr. Fuel pressure sensor Plausibility error at engine off no reaction 308406: Check wiring engine control unit/sensor	A750		E	1
8B5500	Engine uppercarr. Fuel pr. sensor 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5501	Engine uppercarr. Fuel pr. sensor 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5502	Engine uppercarr. Fuel pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308502: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5503	Engine uppercarr. Fuel pr. sensor 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5504	Engine uppercarr. Fuel pr. sensor 2 Sensor signal outside permissible range 1 no reaction 308504: Check operational status of engine	A750		E	1
8B5505	Engine uppercarr. Fuel pr. sensor 2 Sensor signal outside permissible range 2 no reaction 308505: Check operational status of engine	A750		E	1
8B5506	Engine uppercarr. Fuel pr. sensor 2 Plausibility error at engine off no reaction 308506: Check wiring engine control unit/sensor	A750		E	1
8B5600	Engine uppercarr. Air filter vacuum pr. sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5601	Engine uppercarr. Air filter vacuum pr. sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5602	Engine uppercarr. Air filter vacuum pr. sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308602: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5603	Engine uppercarr. Air filter vacuum pr. sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5604	Engine uppercarr. Air filter vacuum pr. sensor Sensor signal outside permissible range 1 no reaction 308604: Air filter 1, air pr. sensor 1	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5605	Engine uppercarr. Air filter vacuum pr. sensor Sensor signal outside permissible range 2 no reaction 308605: Air filter 1, air pr. sensor 1	A750		E	1
8B5606	Engine uppercarr. Air filter vacuum pr. sensor Plausibility error at engine off no reaction 308606: Check wiring engine control unit/sensor	A750		E	1
8B5700	Engine uppercarr. Air filter vacuum pr. sensor 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 308700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5701	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 308701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5702	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 308702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5703	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 308703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5704	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor signal outside permissible range 1 no reaction 308704: Air filter 2, air pr. sensor 2	A750		E	1
8B5705	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor signal outside permissible range 2 no reaction 308705: Air filter 2, air pr. sensor 2	A750		E	1
8B5706	Engine uppercarr. Air filter vacuum pr. sensor 2 Plausibility error at engine off no reaction 308706: Check wiring engine control unit/sensor	A750		E	1
8B5800	Engine uppercarr. Rail pr. sensor 1 Short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5801	Engine uppercarr. Rail pr. sensor 1 Sensor signal short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	2
8B5802	Engine uppercarr. Rail pr. sensor 1 Sensor supply voltage short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308802: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	2
8B5803	Engine uppercarr. Rail pr. sensor 1 Sensor supply voltage short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	2
8B5804	Engine uppercarr. Rail pr. sensor 1 Sensor signal outside permissible range 1 no reaction 308804: Check operational status of engine	A750		E	2
8B5805	Engine uppercarr. Rail pr. sensor 1 Sensor signal outside permissible range 2 Engine standstill after delay 308805: Check operational status of engine	A750		E	2
8B5806	Engine uppercarr. Rail pr. sensor 1 Plausibility error at engine off no reaction 308806: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	0
8B5807	Engine uppercarr. Rail pr. sensor 1 Value implausible High pressure regulation emergency operation activated 308807: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2
8B5808	Engine uppercarr. Rail pr. sensor 1 Pressure run implausible (Gradient) High pressure regulation emergency operation activated 308808: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2
8B5809	Engine uppercarr. Rail pr. sensor 1 Pressure value implausible to constant no reaction 308809: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	1
8B5900	Engine uppercarr. Rail pr. sensor 2 Short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5901	Engine uppercarr. Rail pr. sensor 2 Sensor signal short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	2
8B5902	Engine uppercarr. Rail pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308902: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	2
8B5903	Engine uppercarr. Rail pr. sensor 2 Sensor supply voltage short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	2
8B5904	Engine uppercarr. Rail pr. sensor 2 Sensor signal outside permissible range 1 Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308904: Check operational status of engine	A750		E	2
8B5905	Engine uppercarr. Rail pr. sensor 2 Sensor signal outside permissible range 2 Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308905: Check operational status of engine	A750		E	2
8B5906	Engine uppercarr. Rail pr. sensor 2 Plausibility error at engine off no reaction 308906: Check wiring engine control unit/sensor	A750		E	0
8B5907	Engine uppercarr. Rail pr. sensor 2 Value implausible High pressure regulation emergency operation activated 308907: Check wiring harness, plug, rail pr. sensors, check rail circuit 1/2	A750		E	2
8B5908	Engine uppercarr. Rail pr. sensor 2 Pressure run implausible (Gradient) High pressure regulation emergency operation activated 308908: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2
8B5909	Engine uppercarr. Rail pr. sensor 2 Pressure value implausible to constant no reaction 308909: Nitrogen circuit, Rail sensor 2, pr. relief valve 2, high pr. pump 2, Cable conn. engine control unit	A750		E	1
8B5A00	Engine uppercarr. Atmospheric pressure sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309000: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5A01	Engine uppercarr. Atmospheric pressure sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309001: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B5A02	Engine uppercarr. Atmospheric pressure sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309002: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B5A03	Engine uppercarr. Atmospheric pressure sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309003: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B5A04	Engine uppercarr. Atmospheric pressure sensor Sensor signal outside permissible range 1 no reaction 309004: Check operational status of engine	A750		E	1
8B5A05	Engine uppercarr. Atmospheric pressure sensor Sensor signal outside permissible range 2 no reaction 309005: Check operational status of engine	A750		E	1
8B5A06	Engine uppercarr. Atmospheric pressure sensor Plausibility error at engine off no reaction 309006: Check wiring engine control unit/sensor	A750		E	1
8B5A07	Engine uppercarr. Atmospheric pressure sensor Value implausible Warning light on, replace sensor 309007: Replace ECU	A750		E	1
8B5C00	Engine uppercarr. Exhaust pr. difference sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5C01	Engine uppercarr. Exhaust pr. difference sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309201: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5C02	Engine uppercarr. Exhaust pr. difference sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309202: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5C03	Engine uppercarr. Exhaust pr. difference sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309203: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5C04	Engine uppercarr. Exhaust pr. difference sensor Sensor signal outside permissible range 1 no reaction 309204: Check operational status of engine	A750		E	1
8B5C05	Engine uppercarr. Exhaust pr. difference sensor Sensor signal outside permissible range 2 no reaction 309205: Check operational status of engine	A750		E	1
8B5C06	Engine uppercarr. Exhaust pr. difference sensor Plausibility error at engine off no reaction 309206: Check wiring engine control unit/sensor	A750		E	1
8B5C07	Engine uppercarr. Exhaust pr. difference sensor Value implausible Warning light on 309207: Replace sensor	A750		E	1
8B5D00	Engine uppercarr. Battery voltage measuring Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5D01	Engine uppercarr. Battery voltage measuring Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309301: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5D02	Engine uppercarr. Battery voltage measuring Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309302: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5D03	Engine uppercarr. Battery voltage measuring Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309303: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5D04	Engine uppercarr. Battery voltage measuring Sensor signal outside permissible range 1 no reaction 309304: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5D05	Engine uppercarr. Battery voltage measuring Sensor signal outside permissible range 2 no reaction 309305: Check operational status of engine	A750		E	1
8B5D06	Engine uppercarr. Battery voltage measuring Plausibility error at engine off no reaction 309306: Check wiring engine control unit/sensor	A750		E	1
8B5E00	Engine uppercarr. Pressure sensor InterChargerUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5E01	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309401: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5E02	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309402: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5E03	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309403: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5E04	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor signal outside permissible range 1 no reaction 309404: Check operational status of engine	A750		E	1
8B5E05	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor signal outside permissible range 2 no reaction 309405: Check operational status of engine	A750		E	1
8B5E06	Engine uppercarr. Pressure sensor InterChargerUp 1 Plausibility error at engine off no reaction 309406: Check wiring engine control unit/sensor	A750		E	1
8B5E07	Engine uppercarr. Pressure sensor InterChargerUp 1 Value implausible Warning light on, replace sensor 309407: Check wiring engine control unit/sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5F00	Engine uppercarr. Pressure sensor InterChargerDown 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5F01	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309501: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5F02	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309502: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5F03	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309503: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5F04	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor signal outside permissible range 1 no reaction 309504: Check operational status of engine	A750		E	1
8B5F05	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor signal outside permissible range 2 no reaction 309505: Check operational status of engine	A750		E	1
8B5F06	Engine uppercarr. Pressure sensor InterChargerDown 1 Plausibility error at engine off no reaction 309506: Check wiring engine control unit/sensor	A750		E	1
8B5F07	Engine uppercarr. Pressure sensor InterChargerDown 1 Value implausible Warning light on, replace sensor 309507: Check wiring engine control unit/sensor	A750		E	1
8B6000	Engine uppercarr. Pressure sensor InterChargerUp 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6001	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309601: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6002	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309602: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6003	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309603: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6004	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor signal outside permissible range 1 no reaction 309604: Check operational status of engine	A750		E	1
8B6005	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor signal outside permissible range 2 no reaction 309605: Check operational status of engine	A750		E	1
8B6006	Engine uppercarr. Pressure sensor InterChargerUp 2 Plausibility error at engine off no reaction 309606: Check wiring engine control unit/sensor	A750		E	1
8B6100	Engine uppercarr. Pressure sensor InterChargerDown 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6101	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309701: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6102	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309702: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6103	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309703: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6104	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor signal outside permissible range 1 no reaction 309704: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6105	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor signal outside permissible range 2 no reaction 309705: Check operational status of engine	A750		E	1
8B6106	Engine uppercarr. Pressure sensor InterChargerDown 2 Plausibility error at engine off no reaction 309706: Check wiring engine control unit/sensor	A750		E	1
8B6107	Engine uppercarr. Pressure sensor InterChargerDown 2 Value implausible 309707:	A750		E	1
8B6200	Engine uppercarr. Pressure sensor InterCoolerUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 309800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6201	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 309801: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6202	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 309802: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6203	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 309803: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6204	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor signal outside permissible range 1 no reaction 309804: Check operational status of engine	A750		E	1
8B6205	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor signal outside permissible range 2 no reaction 309805: Check operational status of engine	A750		E	1
8B6206	Engine uppercarr. Pressure sensor InterCoolerUp 1 Plausibility error at engine off no reaction 309806: Check wiring engine control unit/sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6207	Engine uppercarr. Pressure sensor InterCoolerUp 1 Value implausible Warning light on, replace sensor 309807: Check wiring engine control unit/sensor	A750		E	1
8B6900	Engine uppercarr. Exhaust temperature sensor 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6901	Engine uppercarr. Exhaust temperature sensor 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6902	Engine uppercarr. Exhaust temperature sensor 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310502: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6903	Engine uppercarr. Exhaust temperature sensor 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6904	Engine uppercarr. Exhaust temperature sensor 1 Sensor signal outside permissible range 1 no reaction 310504: Check operational status of engine	A750		E	1
8B6905	Engine uppercarr. Exhaust temperature sensor 1 Sensor signal outside permissible range 2 no reaction 310505: Check operational status of engine	A750		E	1
8B6906	Engine uppercarr. Exhaust temperature sensor 1 Plausibility error at engine off no reaction 310506: Check wiring engine control unit/sensor	A750		E	1
8B6A00	Engine uppercarr. Exhaust temperature sensor 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6A01	Engine uppercarr. Exhaust temperature sensor 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6A02	Engine uppercarr. Exhaust temperature sensor 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310602: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6A03	Engine uppercarr. Exhaust temperature sensor 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6A04	Engine uppercarr. Exhaust temperature sensor 2 Sensor signal outside permissible range 1 no reaction 310604: Check operational status of engine	A750		E	1
8B6A05	Engine uppercarr. Exhaust temperature sensor 2 Sensor signal outside permissible range 2 no reaction 310605: Check operational status of engine	A750		E	1
8B6A06	Engine uppercarr. Exhaust temperature sensor 2 Plausibility error at engine off no reaction 310606: Check wiring engine control unit/sensor	A750		E	1
8B6B00	Engine uppercarr. Temperature sensor DOCUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6B01	Engine uppercarr. Temperature sensor DOCUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6B02	Engine uppercarr. Temperature sensor DOCUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6B03	Engine uppercarr. Temperature sensor DOCUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6B04	Engine uppercarr. Temperature sensor DOCUp 1 Sensor signal outside permissible range 1 no reaction 310704: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6B05	Engine uppercarr. Temperature sensor DOCUp 1 Sensor signal outside permissible range 2 no reaction 310705: Check operational status of engine	A750		E	1
8B6B06	Engine uppercarr. Temperature sensor DOCUp 1 Plausibility error at engine off no reaction 310706: Check wiring engine control unit/sensor	A750		E	1
8B6B07	Engine uppercarr. Temperature sensor DOCUp 1 Value implausible Warning light on 310707: Check wiring engine control unit/sensor	A750		E	1
8B6B0A	Engine uppercarr. Temperature sensor DOCUp 1 Pressure value at engine start too low Warning light on 310710: Check wiring engine control unit/sensor	A750		E	1
8B6C00	Engine uppercarr. Temperature sensor DPFUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6C01	Engine uppercarr. Temperature sensor DPFUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6C02	Engine uppercarr. Temperature sensor DPFUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310802: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6C03	Engine uppercarr. Temperature sensor DPFUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6C04	Engine uppercarr. Temperature sensor DPFUp 1 Sensor signal outside permissible range 1 no reaction 310804: Check operational status of engine	A750		E	1
8B6C05	Engine uppercarr. Temperature sensor DPFUp 1 Sensor signal outside permissible range 2 no reaction 310805: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6C06	Engine uppercarr. Temperature sensor DPFDUp 1 Plausibility error at engine off no reaction 310806: Check wiring engine control unit/sensor	A750		E	1
8B6C07	Engine uppercarr. Temperature sensor DPFDUp 1 Value implausible Warning light on 310807: Replace sensor	A750		E	1
8B6C0A	Engine uppercarr. Temperature sensor DPFDUp 1 Pressure value at engine start too low Warning light on 310810: Check wiring engine control unit/sensor	A750		E	1
8B6D00	Engine uppercarr. Temperature sensor DPFDDown 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 310900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6D01	Engine uppercarr. Temperature sensor DPFDDown 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 310901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6D02	Engine uppercarr. Temperature sensor DPFDDown 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 310902: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6D03	Engine uppercarr. Temperature sensor DPFDDown 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 310903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6D04	Engine uppercarr. Temperature sensor DPFDDown 1 Sensor signal outside permissible range 1 no reaction 310904: Check operational status of engine	A750		E	1
8B6D05	Engine uppercarr. Temperature sensor DPFDDown 1 Sensor signal outside permissible range 2 no reaction 310905: Check operational status of engine	A750		E	1
8B6D06	Engine uppercarr. Temperature sensor DPFDDown 1 Plausibility error at engine off no reaction 310906: Check wiring engine control unit/sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6D07	Engine uppercarr. Temperature sensor DPFDn 1 Value implausible Warning light on 310907: Replace sensor	A750		E	1
8B6D0A	Engine uppercarr. Temperature sensor DPFDn 1 Pressure value at engine start too low Warning light on 310910: Check wiring engine control unit/sensor	A750		E	1
8B6E00	Engine uppercarr. Temperature sensor charge air cooler Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6E01	Engine uppercarr. Temperature sensor charge air cooler Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6E02	Engine uppercarr. Temperature sensor charge air cooler Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311002: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6E03	Engine uppercarr. Temperature sensor charge air cooler Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6E04	Engine uppercarr. Temperature sensor charge air cooler Sensor signal outside permissible range 1 no reaction 311004: Check operational status of engine	A750		E	1
8B6E05	Engine uppercarr. Temperature sensor charge air cooler Sensor signal outside permissible range 2 no reaction 311005: Check operational status of engine	A750		E	1
8B6E06	Engine uppercarr. Temperature sensor charge air cooler Plausibility error at engine off no reaction 311006: Check wiring engine control unit/sensor	A750		E	1
8B6E07	Engine uppercarr. Temperature sensor charge air cooler Value implausible Warning light on, replace sensor 311007: Check wiring engine control unit-Sensor check charge air cooler	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6F00	Engine uppercarr. Hydraulic oil temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311100: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6F01	Engine uppercarr. Hydraulic oil temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311101: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6F02	Engine uppercarr. Hydraulic oil temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311102: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6F03	Engine uppercarr. Hydraulic oil temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311103: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6F04	Engine uppercarr. Hydraulic oil temperature sensor Sensor signal outside permissible range 1 no reaction 311104: Check operational status of engine	A750		E	1
8B6F05	Engine uppercarr. Hydraulic oil temperature sensor Sensor signal outside permissible range 2 no reaction 311105: Check operational status of engine	A750		E	1
8B6F06	Engine uppercarr. Hydraulic oil temperature sensor Plausibility error at engine off no reaction 311106: Check wiring engine control unit/sensor	A750		E	1
8B7000	Engine uppercarr. Fuel temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7001	Engine uppercarr. Fuel temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7002	Engine uppercarr. Fuel temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311202: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7003	Engine uppercarr. Fuel temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7004	Engine uppercarr. Fuel temperature sensor Sensor signal outside permissible range 1 no reaction 311204: Check operational status of engine	A750		E	1
8B7005	Engine uppercarr. Fuel temperature sensor Sensor signal outside permissible range 2 no reaction 311205: Check operational status of engine	A750		E	1
8B7006	Engine uppercarr. Fuel temperature sensor Plausibility error at engine off no reaction 311206: Check wiring engine control unit/sensor	A750		E	1
8B7100	Engine uppercarr. Charge air temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7101	Engine uppercarr. Charge air temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7102	Engine uppercarr. Charge air temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311302: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7103	Engine uppercarr. Charge air temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7104	Engine uppercarr. Charge air temperature sensor Sensor signal outside permissible range 1 no reaction 311304: Check operational status of engine	A750		E	1
8B7105	Engine uppercarr. Charge air temperature sensor Sensor signal outside permissible range 2 no reaction 311305: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7106	Engine uppercarr. Charge air temperature sensor Plausibility error at engine off no reaction 311306: Check wiring engine control unit/sensor	A750		E	1
8B7107	Engine uppercarr. Charge air temperature sensor Value implausible Warning light on 311307: Replace sensor	A750		E	1
8B7200	Engine uppercarr. Coolant temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7201	Engine uppercarr. Coolant temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7202	Engine uppercarr. Coolant temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311402: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7203	Engine uppercarr. Coolant temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7204	Engine uppercarr. Coolant temperature sensor Sensor signal outside permissible range 1 no reaction 311404: Check operational status of engine	A750		E	1
8B7205	Engine uppercarr. Coolant temperature sensor Sensor signal outside permissible range 2 no reaction 311405: Check operational status of engine	A750		E	1
8B7206	Engine uppercarr. Coolant temperature sensor Plausibility error at engine off no reaction 311406: Check wiring engine control unit/sensor	A750		E	1
8B7207	Engine uppercarr. Coolant temperature sensor Value implausible Warning light on 311407: Replace sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7300	Engine uppercarr. Atmospheric temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7301	Engine uppercarr. Atmospheric temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7302	Engine uppercarr. Atmospheric temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311502: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7303	Engine uppercarr. Atmospheric temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7304	Engine uppercarr. Atmospheric temperature sensor Sensor signal outside permissible range 1 no reaction 311504: Check operational status of engine	A750		E	1
8B7305	Engine uppercarr. Atmospheric temperature sensor Sensor signal outside permissible range 2 no reaction 311505: Check operational status of engine	A750		E	1
8B7306	Engine uppercarr. Atmospheric temperature sensor Plausibility error at engine off no reaction 311506: Check wiring engine control unit/sensor	A750		E	1
8B7400	Engine uppercarr. Battery temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7401	Engine uppercarr. Battery temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7402	Engine uppercarr. Battery temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311602: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7403	Engine uppercarr. Battery temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7404	Engine uppercarr. Battery temperature sensor Sensor signal outside permissible range 1 no reaction 311604: Check operational status of engine	A750		E	1
8B7405	Engine uppercarr. Battery temperature sensor Sensor signal outside permissible range 2 no reaction 311605: Check operational status of engine	A750		E	1
8B7406	Engine uppercarr. Battery temperature sensor Plausibility error at engine off no reaction 311606: Check wiring engine control unit/sensor	A750		E	1
8B7500	Engine uppercarr. Temperature sensor TransfCasePump Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7501	Engine uppercarr. Temperature sensor TransfCasePump Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7502	Engine uppercarr. Temperature sensor TransfCasePump Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7503	Engine uppercarr. Temperature sensor TransfCasePump Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7504	Engine uppercarr. Temperature sensor TransfCasePump Sensor signal outside permissible range 1 no reaction 311704: Check operational status of engine	A750		E	1
8B7505	Engine uppercarr. Temperature sensor TransfCasePump Sensor signal outside permissible range 2 no reaction 311705: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7506	Engine uppercarr. Temperature sensor TransfCasePump Plausibility error at engine off no reaction 311706: Check wiring engine control unit/sensor	A750		E	1
8B7600	Engine uppercarr. Temperature sensor SCRUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7601	Engine uppercarr. Temperature sensor SCRUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7602	Engine uppercarr. Temperature sensor SCRUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311802: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7603	Engine uppercarr. Temperature sensor SCRUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7604	Engine uppercarr. Temperature sensor SCRUp 1 Sensor signal outside permissible range 1 no reaction 311804: Check operational status of engine	A750		E	1
8B7605	Engine uppercarr. Temperature sensor SCRUp 1 Sensor signal outside permissible range 2 no reaction 311805: Check operational status of engine	A750		E	1
8B7606	Engine uppercarr. Temperature sensor SCRUp 1 Plausibility error at engine off no reaction 311806: Check wiring engine control unit/sensor	A750		E	1
8B7700	Engine uppercarr. Temperature sensor SCRDown 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 311900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7701	Engine uppercarr. Temperature sensor SCRDown 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 311901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7702	Engine uppercarr. Temperature sensor SCRDown 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 311902: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7703	Engine uppercarr. Temperature sensor SCRDown 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 311903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7704	Engine uppercarr. Temperature sensor SCRDown 1 Sensor signal outside permissible range 1 no reaction 311904: Check operational status of engine	A750		E	1
8B7705	Engine uppercarr. Temperature sensor SCRDown 1 Sensor signal outside permissible range 2 no reaction 311905: Check operational status of engine	A750		E	1
8B7706	Engine uppercarr. Temperature sensor SCRDown 1 Plausibility error at engine off no reaction 311906: Check wiring engine control unit/sensor	A750		E	1
8B7800	Engine uppercarr. oil temperature sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7801	Engine uppercarr. oil temperature sensor Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7802	Engine uppercarr. oil temperature sensor Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312002: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7803	Engine uppercarr. oil temperature sensor Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7804	Engine uppercarr. oil temperature sensor Sensor signal outside permissible range 1 no reaction 312004: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7805	Engine uppercarr. oil temperature sensor Sensor signal outside permissible range 2 no reaction 312005: Check operational status of engine	A750		E	1
8B7806	Engine uppercarr. oil temperature sensor Plausibility error at engine off no reaction 312006: Check wiring engine control unit/sensor	A750		E	1
8B7900	Engine uppercarr. Temperature sensor InterChargerUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312100: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7901	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312101: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7902	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312102: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7903	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312103: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7904	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor signal outside permissible range 1 no reaction 312104: Check operational status of engine	A750		E	1
8B7905	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor signal outside permissible range 2 no reaction 312105: Check operational status of engine	A750		E	1
8B7906	Engine uppercarr. Temperature sensor InterChargerUp 1 Plausibility error at engine off no reaction 312106: Check wiring engine control unit/sensor	A750		E	1
8B7907	Engine uppercarr. Temperature sensor InterChargerUp 1 Value implausible 312107:	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7A00	Engine uppercarr. Temperature sensor InterChargerDown 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7A01	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7A02	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312202: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7A03	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7A04	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor signal outside permissible range 1 no reaction 312204: Check operational status of engine	A750		E	1
8B7A05	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor signal outside permissible range 2 no reaction 312205: Check operational status of engine	A750		E	1
8B7A06	Engine uppercarr. Temperature sensor InterChargerDown 1 Plausibility error at engine off no reaction 312206: Check wiring engine control unit/sensor	A750		E	1
8B7A07	Engine uppercarr. Temperature sensor InterChargerDown 1 Value implausible Warning light on 312207: Replace sensor	A750		E	1
8B7B00	Engine uppercarr. Temperature sensor InterChargerUp 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7B01	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7B02	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312302: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7B03	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7B04	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor signal outside permissible range 1 no reaction 312304: Check operational status of engine	A750		E	1
8B7B05	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor signal outside permissible range 2 no reaction 312305: Check operational status of engine	A750		E	1
8B7B06	Engine uppercarr. Temperature sensor InterChargerUp 2 Plausibility error at engine off no reaction 312306: Check wiring engine control unit/sensor	A750		E	1
8B7C00	Engine uppercarr. Temperature sensor InterChargerDown 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7C01	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7C02	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312402: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7C03	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7C04	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor signal outside permissible range 1 no reaction 312404: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7C05	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor signal outside permissible range 2 no reaction 312405: Check operational status of engine	A750		E	1
8B7C06	Engine uppercarr. Temperature sensor InterChargerDown 2 Plausibility error at engine off no reaction 312406: Check wiring engine control unit/sensor	A750		E	1
8B7C07	Engine uppercarr. Temperature sensor InterChargerDown 2 Value implausible Warning light on 312407: Replace sensor	A750		E	1
8B7D00	Engine uppercarr. Temperature sensor InterCoolerUp 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7D01	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7D02	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312502: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7D03	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7D04	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor signal outside permissible range 1 no reaction 312504: Check operational status of engine	A750		E	1
8B7D05	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor signal outside permissible range 2 no reaction 312505: Check operational status of engine	A750		E	1
8B7D06	Engine uppercarr. Temperature sensor InterCoolerUp 1 Plausibility error at engine off no reaction 312506: Check wiring engine control unit/sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7D07	Engine uppercarr. Temperature sensor InterCoolerUp 1 Value implausible Warning light on, replace sensor 312507: Check wiring engine control unit/sensor	A750		E	1
8B7E00	Engine uppercarr. Temperature sensor SCRUp 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7E01	Engine uppercarr. Temperature sensor SCRUp 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7E02	Engine uppercarr. Temperature sensor SCRUp 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312602: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7E03	Engine uppercarr. Temperature sensor SCRUp 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7E04	Engine uppercarr. Temperature sensor SCRUp 2 Sensor signal outside permissible range 1 no reaction 312604: Check operational status of engine	A750		E	1
8B7E05	Engine uppercarr. Temperature sensor SCRUp 2 Sensor signal outside permissible range 2 no reaction 312605: Check operational status of engine	A750		E	1
8B7E06	Engine uppercarr. Temperature sensor SCRUp 2 Plausibility error at engine off no reaction 312606: Check wiring engine control unit/sensor	A750		E	1
8B7F00	Engine uppercarr. Temperature sensor SCRDown 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 312700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7F01	Engine uppercarr. Temperature sensor SCRDown 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 312701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7F02	Engine uppercarr. Temperature sensor SCRDown 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 312702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7F03	Engine uppercarr. Temperature sensor SCRDown 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 312703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7F04	Engine uppercarr. Temperature sensor SCRDown 2 Sensor signal outside permissible range 1 no reaction 312704: Check operational status of engine	A750		E	1
8B7F05	Engine uppercarr. Temperature sensor SCRDown 2 Sensor signal outside permissible range 2 no reaction 312705: Check operational status of engine	A750		E	1
8B7F06	Engine uppercarr. Temperature sensor SCRDown 2 Plausibility error at engine off no reaction 312706: Check wiring engine control unit/sensor	A750		E	1
8B8500	Engine uppercarr. Hardware temperature sensor control unit Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B8501	Engine uppercarr. Hardware temperature sensor control unit Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 313301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B8502	Engine uppercarr. Hardware temperature sensor control unit Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 313302: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B8503	Engine uppercarr. Hardware temperature sensor control unit Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 313303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B8504	Engine uppercarr. Hardware temperature sensor control unit Sensor signal outside permissible range 1 no reaction 313304: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8505	Engine uppercarr. Hardware temperature sensor control unit Sensor signal outside permissible range 2 no reaction 313305: Check operational status of engine	A750		E	1
8B8506	Engine uppercarr. Hardware temperature sensor control unit Plausibility error at engine off no reaction 313306: Check wiring engine control unit/sensor	A750		E	1
8B8600	Engine uppercarr. Hardware temperature sensor control unit CPU Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B8601	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 313401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B8602	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 313402: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B8603	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 313403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B8604	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor signal outside permissible range 1 no reaction 313404: Check operational status of engine	A750		E	1
8B8605	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor signal outside permissible range 2 no reaction 313405: Check operational status of engine	A750		E	1
8B8606	Engine uppercarr. Hardware temperature sensor control unit CPU Plausibility error at engine off no reaction 313406: Check wiring engine control unit/sensor	A750		E	1
8B8800	Engine uppercarr. Switch signal 1 Alternator short circuit to ground Benutzung des Ersatzwertes. 313600: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8801	Engine uppercarr. Switch signal 1 Alternator Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 313601: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8802	Engine uppercarr. Switch signal 1 Alternator Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313602: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8803	Engine uppercarr. Switch signal 1 Alternator short circuit to supply voltage Benutzung des Ersatzwertes. 313603:	A750		E	1
8B8804	Engine uppercarr. Switch signal 1 Alternator Operating status outside permissible range Benutzung des Ersatzwertes. 313604: Check operational status of engine	A750		E	1
8B8806	Engine uppercarr. Switch signal 1 Alternator Value implausible at engine standstill no reaction 313606: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8900	Engine uppercarr. Switch signal 2 Alternator short circuit to ground Benutzung des Ersatzwertes. 313700: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8901	Engine uppercarr. Switch signal 2 Alternator Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 313701: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8902	Engine uppercarr. Switch signal 2 Alternator Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313702: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8903	Engine uppercarr. Switch signal 2 Alternator short circuit to supply voltage Benutzung des Ersatzwertes. 313703:	A750		E	1
8B8904	Engine uppercarr. Switch signal 2 Alternator Operating status outside permissible range Benutzung des Ersatzwertes. 313704: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8906	Engine uppercarr. Switch signal 2 Alternator Value implausible at engine standstill no reaction 313706: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A00	Engine uppercarr. Switch signal Heater unit "SupV" 1 short circuit to ground Benutzung des Ersatzwertes. 313800: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A01	Engine uppercarr. Switch signal Heater unit "SupV" 1 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 313801: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A02	Engine uppercarr. Switch signal Heater unit "SupV" 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313802: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A03	Engine uppercarr. Switch signal Heater unit "SupV" 1 short circuit to supply voltage Benutzung des Ersatzwertes. 313803: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A04	Engine uppercarr. Switch signal Heater unit "SupV" 1 Operating status outside permissible range Benutzung des Ersatzwertes. 313804: Check operational status of engine	A750		E	1
8B8A06	Engine uppercarr. Switch signal Heater unit "SupV" 1 Value implausible at engine standstill no reaction 313806: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8B00	Engine uppercarr. Switch signal Heater unit "SupV" 2 short circuit to ground Benutzung des Ersatzwertes. 313900: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8B01	Engine uppercarr. Switch signal Heater unit "SupV" 2 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 313901: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8B02	Engine uppercarr. Switch signal Heater unit "SupV" 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 313902: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8B03	Engine uppercarr. Switch signal Heater unit "SupV" 2 short circuit to supply voltage Benutzung des Ersatzwertes. 313903: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8B04	Engine uppercarr. Switch signal Heater unit "SupV" 2 Operating status outside permissible range Benutzung des Ersatzwertes. 313904: Check operational status of engine	A750		E	1
8B8B06	Engine uppercarr. Switch signal Heater unit "SupV" 2 Value implausible at engine standstill no reaction 313906: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C00	Engine uppercarr. Switch signal Starter short circuit to ground Benutzung des Ersatzwertes. 314000: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C01	Engine uppercarr. Switch signal Starter Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314001: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C02	Engine uppercarr. Switch signal Starter Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314002: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C03	Engine uppercarr. Switch signal Starter short circuit to supply voltage Benutzung des Ersatzwertes. 314003: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C04	Engine uppercarr. Switch signal Starter Operating status outside permissible range Benutzung des Ersatzwertes. 314004: Check operational status of engine	A750		E	1
8B8C06	Engine uppercarr. Switch signal Starter Value implausible at engine standstill no reaction 314006: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D00	Engine uppercarr. Idle switch signal short circuit to ground Benutzung des Ersatzwertes. 314100: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8D01	Engine uppercarr. Idle switch signal Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314101: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D02	Engine uppercarr. Idle switch signal Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314102: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D03	Engine uppercarr. Idle switch signal short circuit to supply voltage Benutzung des Ersatzwertes. 314103: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D04	Engine uppercarr. Idle switch signal Operating status outside permissible range Benutzung des Ersatzwertes. 314104: Check operational status of engine	A750		E	1
8B8D06	Engine uppercarr. Idle switch signal Value implausible at engine standstill no reaction 314106: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E00	Engine uppercarr. Switch signal Test op. short circuit to ground Benutzung des Ersatzwertes. 314200: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E01	Engine uppercarr. Switch signal Test op. Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314201: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E02	Engine uppercarr. Switch signal Test op. Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314202: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E03	Engine uppercarr. Switch signal Test op. short circuit to supply voltage Benutzung des Ersatzwertes. 314203: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E04	Engine uppercarr. Switch signal Test op. Operating status outside permissible range Benutzung des Ersatzwertes. 314204: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8E06	Engine uppercarr. Switch signal Test op. Value implausible at engine standstill no reaction 314206: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F00	Engine uppercarr. Switch signal "SupvEgr" 1 short circuit to ground Benutzung des Ersatzwertes. 314300: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F01	Engine uppercarr. Switch signal "SupvEgr" 1 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314301: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F02	Engine uppercarr. Switch signal "SupvEgr" 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314302: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F03	Engine uppercarr. Switch signal "SupvEgr" 1 short circuit to supply voltage Benutzung des Ersatzwertes. 314303: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F04	Engine uppercarr. Switch signal "SupvEgr" 1 Operating status outside permissible range Benutzung des Ersatzwertes. 314304: Check operational status of engine	A750		E	1
8B8F06	Engine uppercarr. Switch signal "SupvEgr" 1 Value implausible at engine standstill no reaction 314306: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9000	Engine uppercarr. Switch signal "SupvEgr" 2 short circuit to ground Benutzung des Ersatzwertes. 314400: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9001	Engine uppercarr. Switch signal "SupvEgr" 2 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314401: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9002	Engine uppercarr. Switch signal "SupvEgr" 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314402: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9003	Engine uppercarr. Switch signal "SupvEgr" 2 short circuit to supply voltage Benutzung des Ersatzwertes. 314403: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9004	Engine uppercarr. Switch signal "SupvEgr" 2 Operating status outside permissible range Benutzung des Ersatzwertes. 314404: Check operational status of engine	A750		E	1
8B9006	Engine uppercarr. Switch signal "SupvEgr" 2 Value implausible at engine standstill no reaction 314406: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9100	Engine uppercarr. Switch signal Fixed rpm short circuit to ground Benutzung des Ersatzwertes. 314500: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9101	Engine uppercarr. Switch signal Fixed rpm Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314501: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9102	Engine uppercarr. Switch signal Fixed rpm Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314502: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9103	Engine uppercarr. Switch signal Fixed rpm short circuit to supply voltage Benutzung des Ersatzwertes. 314503: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9104	Engine uppercarr. Switch signal Fixed rpm Operating status outside permissible range Benutzung des Ersatzwertes. 314504: Check operational status of engine	A750		E	1
8B9106	Engine uppercarr. Switch signal Fixed rpm Value implausible at engine standstill no reaction 314506: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9200	Engine uppercarr. Empty gas switch signal short circuit to ground Benutzung des Ersatzwertes. 314600: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9201	Engine uppercarr. Empty gas switch signal Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314601: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9202	Engine uppercarr. Empty gas switch signal Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314602: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9203	Engine uppercarr. Empty gas switch signal short circuit to supply voltage Benutzung des Ersatzwertes. 314603: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9204	Engine uppercarr. Empty gas switch signal Operating status outside permissible range Benutzung des Ersatzwertes. 314604: Check operational status of engine	A750		E	1
8B9206	Engine uppercarr. Empty gas switch signal Value implausible at engine standstill no reaction 314606: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9300	Engine uppercarr. Switch signal "EcyStart" short circuit to ground Benutzung des Ersatzwertes. 314700: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9301	Engine uppercarr. Switch signal "EcyStart" Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314701: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9302	Engine uppercarr. Switch signal "EcyStart" Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314702: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9303	Engine uppercarr. Switch signal "EcyStart" short circuit to supply voltage Benutzung des Ersatzwertes. 314703: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9304	Engine uppercarr. Switch signal "EcyStart" Operating status outside permissible range Benutzung des Ersatzwertes. 314704: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9306	Engine uppercarr. Switch signal "EcyStart" Value implausible at engine standstill no reaction 314706: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9400	Engine uppercarr. Switch signal "DelayEcyStart" short circuit to ground Benutzung des Ersatzwertes. 314800: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9401	Engine uppercarr. Switch signal "DelayEcyStart" Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314801: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9402	Engine uppercarr. Switch signal "DelayEcyStart" Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314802: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9403	Engine uppercarr. Switch signal "DelayEcyStart" short circuit to supply voltage Benutzung des Ersatzwertes. 314803: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9404	Engine uppercarr. Switch signal "DelayEcyStart" Operating status outside permissible range Benutzung des Ersatzwertes. 314804: Check operational status of engine	A750		E	1
8B9406	Engine uppercarr. Switch signal "DelayEcyStart" Value implausible at engine standstill no reaction 314806: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9500	Engine uppercarr. Switch signal Notstopp short circuit to ground Benutzung des Ersatzwertes. 314900: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9501	Engine uppercarr. Switch signal Notstopp Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 314901: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9502	Engine uppercarr. Switch signal Notstopp Short circuit after ground or broken wire Benutzung des Ersatzwertes. 314902: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9503	Engine uppercarr. Switch signal Notstopp short circuit to supply voltage Benutzung des Ersatzwertes. 314903: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9504	Engine uppercarr. Switch signal Notstopp Operating status outside permissible range Benutzung des Ersatzwertes. 314904: Check operational status of engine	A750		E	1
8B9506	Engine uppercarr. Switch signal Notstopp Value implausible at engine standstill no reaction 314906: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9600	Engine uppercarr. Switch signal "Slave on" short circuit to ground Benutzung des Ersatzwertes. 315000: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9601	Engine uppercarr. Switch signal "Slave on" Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315001: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9602	Engine uppercarr. Switch signal "Slave on" Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315002: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9603	Engine uppercarr. Switch signal "Slave on" short circuit to supply voltage Benutzung des Ersatzwertes. 315003: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9604	Engine uppercarr. Switch signal "Slave on" Operating status outside permissible range Benutzung des Ersatzwertes. 315004: Check operational status of engine	A750		E	1
8B9606	Engine uppercarr. Switch signal "Slave on" Value implausible at engine standstill no reaction 315006: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9700	Engine uppercarr. Switch signal fan reversed short circuit to ground Benutzung des Ersatzwertes. 315100: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9701	Engine uppercarr. Switch signal fan reversed Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315101: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9702	Engine uppercarr. Switch signal fan reversed Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315102: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9703	Engine uppercarr. Switch signal fan reversed short circuit to supply voltage Benutzung des Ersatzwertes. 315103: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9704	Engine uppercarr. Switch signal fan reversed Operating status outside permissible range Benutzung des Ersatzwertes. 315104: Check operational status of engine	A750		E	1
8B9706	Engine uppercarr. Switch signal fan reversed Value implausible at engine standstill no reaction 315106: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9800	Engine uppercarr. Switch signal fan reversed manual short circuit to ground Benutzung des Ersatzwertes. 315200: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9801	Engine uppercarr. Switch signal fan reversed manual Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315201: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9802	Engine uppercarr. Switch signal fan reversed manual Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315202: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9803	Engine uppercarr. Switch signal fan reversed manual short circuit to supply voltage Benutzung des Ersatzwertes. 315203: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9804	Engine uppercarr. Switch signal fan reversed manual Operating status outside permissible range Benutzung des Ersatzwertes. 315204: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9806	Engine uppercarr. Switch signal fan reversed manual Value implausible at engine standstill no reaction 315206: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9900	Engine uppercarr. Air filter vacuum pr. switch 1 short circuit to ground Benutzung des Ersatzwertes. 315300: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9901	Engine uppercarr. Air filter vacuum pr. switch 1 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315301: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9902	Engine uppercarr. Air filter vacuum pr. switch 1 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315302: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9903	Engine uppercarr. Air filter vacuum pr. switch 1 short circuit to supply voltage Benutzung des Ersatzwertes. 315303: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9904	Engine uppercarr. Air filter vacuum pr. switch 1 Operating status outside permissible range Benutzung des Ersatzwertes. 315304: Check operational status of engine	A750		E	1
8B9906	Engine uppercarr. Air filter vacuum pr. switch 1 Value implausible at engine standstill no reaction 315306: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9A00	Engine uppercarr. Air filter vacuum pr. switch 2 short circuit to ground Benutzung des Ersatzwertes. 315400: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9A01	Engine uppercarr. Air filter vacuum pr. switch 2 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315401: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9A02	Engine uppercarr. Air filter vacuum pr. switch 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315402: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9A03	Engine uppercarr. Air filter vacuum pr. switch 2 short circuit to supply voltage Benutzung des Ersatzwertes. 315403: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9A04	Engine uppercarr. Air filter vacuum pr. switch 2 Operating status outside permissible range Benutzung des Ersatzwertes. 315404: Check operational status of engine	A750		E	1
8B9A06	Engine uppercarr. Air filter vacuum pr. switch 2 Value implausible at engine standstill no reaction 315406: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B00	Engine uppercarr. Sensor Water in fuel short circuit to ground Benutzung des Ersatzwertes. 315500: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B01	Engine uppercarr. Sensor Water in fuel Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315501: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B02	Engine uppercarr. Sensor Water in fuel Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315502: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B03	Engine uppercarr. Sensor Water in fuel short circuit to supply voltage Benutzung des Ersatzwertes. 315503: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B04	Engine uppercarr. Sensor Water in fuel Operating status outside permissible range Benutzung des Ersatzwertes. 315504: Check operational status of engine	A750		E	1
8B9B06	Engine uppercarr. Sensor Water in fuel Value implausible at engine standstill no reaction 315506: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C00	Engine uppercarr. Coolant level sensor short circuit to ground Benutzung des Ersatzwertes. 315600: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9C01	Engine uppercarr. Coolant level sensor Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315601: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C02	Engine uppercarr. Coolant level sensor Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315602: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C03	Engine uppercarr. Coolant level sensor short circuit to supply voltage Benutzung des Ersatzwertes. 315603: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C04	Engine uppercarr. Coolant level sensor Operating status outside permissible range Benutzung des Ersatzwertes. 315604: Check operational status of engine	A750		E	1
8B9C06	Engine uppercarr. Coolant level sensor Value implausible at engine standstill no reaction 315606: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9D00	Engine uppercarr. Flame start system short circuit to ground Benutzung des Ersatzwertes. 315700: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9D01	Engine uppercarr. Flame start system Line interruption or short circuit after supply voltage Benutzung des Ersatzwertes. 315701: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9D02	Engine uppercarr. Flame start system Line interruption or short circuit after ground Benutzung des Ersatzwertes. 315702: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9D03	Engine uppercarr. Flame start system short circuit to supply voltage Benutzung des Ersatzwertes. 315703: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9D04	Engine uppercarr. Flame start system Operating data outside permissible range Benutzung des Ersatzwertes. 315704: Check op. status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9D06	Engine uppercarr. Flame start system Test values implausible at engine standstill no reaction 315706: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E00	Engine uppercarr. Flame start system 2 short circuit to ground Benutzung des Ersatzwertes. 315800: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E01	Engine uppercarr. Flame start system 2 Line interruption or short circuit after supply voltage Benutzung des Ersatzwertes. 315801: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E02	Engine uppercarr. Flame start system 2 Line interruption or short circuit after ground Benutzung des Ersatzwertes. 315802: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E03	Engine uppercarr. Flame start system 2 short circuit to supply voltage Benutzung des Ersatzwertes. 315803: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E04	Engine uppercarr. Flame start system 2 Operating data outside permissible range Benutzung des Ersatzwertes. 315804: Check op. status of engine	A750		E	1
8B9E06	Engine uppercarr. Flame start system 2 Test values implausible at engine standstill no reaction 315806: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9F00	Engine uppercarr. Input signal request engine brake short circuit to ground Benutzung des Ersatzwertes. 315900: Check wiring, control unit	A750		E	1
8B9F01	Engine uppercarr. Input signal request engine brake Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315901: Check wiring, control unit	A750		E	1
8B9F02	Engine uppercarr. Input signal request engine brake Short circuit after ground or broken wire Benutzung des Ersatzwertes. 315902: Check wiring, control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9F03	Engine uppercarr. Input signal request engine brake short circuit to supply voltage Benutzung des Ersatzwertes. 315903: Check wiring, control unit	A750		E	1
8B9F04	Engine uppercarr. Input signal request engine brake Operating status outside permissible range Benutzung des Ersatzwertes. 315904: Check wiring, control unit	A750		E	1
8B9F06	Engine uppercarr. Input signal request engine brake Value implausible at engine standstill no reaction 315906: Check wiring, control unit	A750		E	1
8BA000	Engine uppercarr. Input signal water in fuel 2 short circuit to ground Benutzung des Ersatzwertes. 315900: Check wiring, control unit	A750		E	1
8BA001	Engine uppercarr. Input signal water in fuel 2 Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 315901: Check wiring, control unit	A750		E	1
8BA002	Engine uppercarr. Input signal water in fuel 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 316000: Check wiring, control unit	A750		E	1
8BA003	Engine uppercarr. Input signal water in fuel 2 short circuit to supply voltage Benutzung des Ersatzwertes. 316001: Check wiring, control unit	A750		E	1
8BA004	Engine uppercarr. Input signal water in fuel 2 Operating status outside permissible range Benutzung des Ersatzwertes. 316002: Check wiring, control unit	A750		E	1
8BA006	Engine uppercarr. Input signal water in fuel 2 Value implausible at engine standstill no reaction 316004: Check wiring, control unit	A750		E	1
8BA100	Engine uppercarr. Input signal rpm increase short circuit to ground Benutzung des Ersatzwertes. 316005: Check wiring, control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BA101	Engine uppercarr. Input signal rpm increase Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 316006: Check wiring, control unit	A750		E	1
8BA102	Engine uppercarr. Input signal rpm increase Short circuit after ground or broken wire Benutzung des Ersatzwertes. 316100: Check wiring, control unit	A750		E	1
8BA103	Engine uppercarr. Input signal rpm increase short circuit to supply voltage Benutzung des Ersatzwertes. 316101: Check wiring, control unit	A750		E	1
8BA104	Engine uppercarr. Input signal rpm increase Operating status outside permissible range Benutzung des Ersatzwertes. 316102: Check wiring, control unit	A750		E	1
8BA106	Engine uppercarr. Input signal rpm increase Value implausible at engine standstill no reaction 316103: Check wiring, control unit	A750		E	1
8BA200	Engine uppercarr. Input signal rpm decrease short circuit to ground Benutzung des Ersatzwertes. 316106: Check wiring, control unit	A750		E	1
8BA201	Engine uppercarr. Input signal rpm decrease Short circuit after supply voltage or broken wire Benutzung des Ersatzwertes. 316200: Check wiring, control unit	A750		E	1
8BA202	Engine uppercarr. Input signal rpm decrease Short circuit after ground or broken wire Benutzung des Ersatzwertes. 316201: Check wiring, control unit	A750		E	1
8BA203	Engine uppercarr. Input signal rpm decrease short circuit to supply voltage Benutzung des Ersatzwertes. 316202: Check wiring, control unit	A750		E	1
8BA204	Engine uppercarr. Input signal rpm decrease Operating status outside permissible range Benutzung des Ersatzwertes. 316203: Check wiring, control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BA206	Engine uppercarr. Input signal rpm decrease Value implausible at engine standstill no reaction 316206: Check wiring, control unit	A750		E	1
8BA300	Engine uppercarr. Input signal fixed rpm short circuit to ground 319500	A750		E	1
8BA301	Engine uppercarr. Input signal fixed rpm Line interruption or short circuit after supply voltage 319501	A750		E	1
8BA302	Engine uppercarr. Input signal fixed rpm Line interruption or short circuit after ground 319502	A750		E	1
8BA303	Engine uppercarr. Input signal fixed rpm short circuit to supply voltage 319503	A750		E	1
8BA306	Engine uppercarr. Input signal fixed rpm Test values implausible at engine standstill 319504	A750		E	1
8BC300	Engine uppercarr. Actuation Injection Cyl. 1 Interruption or current remeasuring erroneous no reaction 319500: Check cable, plug, injector, engine control unit	A750		E	1
8BC301	Engine uppercarr. Actuation Injection Cyl. 1 Maximum current ground switch exceeded Injector unit is not energized 319501: Check cable, plug, injector, engine control unit	A750		E	1
8BC302	Engine uppercarr. Actuation Injection Cyl. 1 Maximum current Plus switch exceeded Injector unit is not energized 319502: Check cable, plug, injector, engine control unit	A750		E	1
8BC303	Engine uppercarr. Actuation Injection Cyl. 1 No increase time measured no reaction 319503: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC304	Engine uppercarr. Actuation Injection Cyl. 1 Increase time too large no reaction 319504: Check cable, plug, injector, engine control unit	A750		E	1
8BC305	Engine uppercarr. Actuation Injection Cyl. 1 Cyl. Overlap Engine shut off 319505: Load new software in engine control unit	A750		E	1
8BC306	Engine uppercarr. Actuation Injection Cyl. 1 No fly time measured no reaction 319506: Check cable, plug, injector, engine control unit	A750		E	1
8BC307	Engine uppercarr. Actuation Injection Cyl. 1 Fly time too small no reaction 319507: Check cable, plug, injector, engine control unit	A750		E	1
8BC308	Engine uppercarr. Actuation Injection Cyl. 1 Fly time too large no reaction 319508: Check cable, plug, injector, engine control unit	A750		E	1
8BC400	Engine uppercarr. Actuation Injection Cyl. 2 Interruption or current remeasuring erroneous no reaction 319600: Check cable, plug, injector, engine control unit	A750		E	1
8BC401	Engine uppercarr. Actuation Injection Cyl. 2 Maximum current ground switch exceeded Injector unit is not energized 319601: Check cable, plug, injector, engine control unit	A750		E	1
8BC402	Engine uppercarr. Actuation Injection Cyl. 2 Maximum current Plus switch exceeded Injector unit is not energized 319602: Check cable, plug, injector, engine control unit	A750		E	1
8BC403	Engine uppercarr. Actuation Injection Cyl. 2 No increase time measured no reaction 319603: Check cable, plug, injector, engine control unit	A750		E	1
8BC404	Engine uppercarr. Actuation Injection Cyl. 2 Increase time too large no reaction 319604: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC405	Engine uppercarr. Actuation Injection Cyl. 2 Cyl. Overlap Engine shut off 319605: Load new software in engine control unit	A750		E	1
8BC406	Engine uppercarr. Actuation Injection Cyl. 2 No fly time measured no reaction 319606: Check cable, plug, injector, engine control unit	A750		E	1
8BC407	Engine uppercarr. Actuation Injection Cyl. 2 Fly time too small no reaction 319607: Check cable, plug, injector, engine control unit	A750		E	1
8BC408	Engine uppercarr. Actuation Injection Cyl. 2 Fly time too large no reaction 319608: Check cable, plug, injector, engine control unit	A750		E	1
8BC500	Engine uppercarr. Actuation Injection Cyl. 3 Interruption or current remeasuring erroneous no reaction 319700: Check cable, plug, injector, engine control unit	A750		E	1
8BC501	Engine uppercarr. Actuation Injection Cyl. 3 Maximum current ground switch exceeded Injector unit is not energized 319701: Check cable, plug, injector, engine control unit	A750		E	1
8BC502	Engine uppercarr. Actuation Injection Cyl. 3 Maximum current Plus switch exceeded Injector unit is not energized 319702: Check cable, plug, injector, engine control unit	A750		E	1
8BC503	Engine uppercarr. Actuation Injection Cyl. 3 No increase time measured no reaction 319703: Check cable, plug, injector, engine control unit	A750		E	1
8BC504	Engine uppercarr. Actuation Injection Cyl. 3 Increase time too large no reaction 319704: Check cable, plug, injector, engine control unit	A750		E	1
8BC505	Engine uppercarr. Actuation Injection Cyl. 3 Cyl. Overlap Engine shut off 319705: Load new software in engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC506	Engine uppercarr. Actuation Injection Cyl. 3 No fly time measured no reaction 319706: Check cable, plug, injector, engine control unit	A750		E	1
8BC507	Engine uppercarr. Actuation Injection Cyl. 3 Fly time too small no reaction 319707: Check cable, plug, injector, engine control unit	A750		E	1
8BC508	Engine uppercarr. Actuation Injection Cyl. 3 Fly time too large no reaction 319708: Check cable, plug, injector, engine control unit	A750		E	1
8BC600	Engine uppercarr. Actuation Injection Cyl. 4 Interruption or current remeasuring erroneous no reaction 319800: Check cable, plug, injector, engine control unit	A750		E	1
8BC601	Engine uppercarr. Actuation Injection Cyl. 4 Maximum current ground switch exceeded Injector unit is not energized 319801: Check cable, plug, injector, engine control unit	A750		E	1
8BC602	Engine uppercarr. Actuation Injection Cyl. 4 Maximum current Plus switch exceeded Injector unit is not energized 319802: Check cable, plug, injector, engine control unit	A750		E	1
8BC603	Engine uppercarr. Actuation Injection Cyl. 4 No increase time measured no reaction 319803: Check cable, plug, injector, engine control unit	A750		E	1
8BC604	Engine uppercarr. Actuation Injection Cyl. 4 Increase time too large no reaction 319804: Check cable, plug, injector, engine control unit	A750		E	1
8BC605	Engine uppercarr. Actuation Injection Cyl. 4 Cyl. Overlap Engine shut off 319805: Load new software in engine control unit	A750		E	1
8BC606	Engine uppercarr. Actuation Injection Cyl. 4 No fly time measured no reaction 319806: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC607	Engine uppercarr. Actuation Injection Cyl. 4 Fly time too small no reaction 319807: Check cable, plug, injector, engine control unit	A750		E	1
8BC608	Engine uppercarr. Actuation Injection Cyl. 4 Fly time too large no reaction 319808: Check cable, plug, injector, engine control unit	A750		E	1
8BC700	Engine uppercarr. Actuation Injection Cyl. 5 Interruption or current remeasuring erroneous no reaction 319900: Check cable, plug, injector, engine control unit	A750		E	1
8BC701	Engine uppercarr. Actuation Injection Cyl. 5 Maximum current ground switch exceeded Injector unit is not energized 319901: Check cable, plug, injector, engine control unit	A750		E	1
8BC702	Engine uppercarr. Actuation Injection Cyl. 5 Maximum current Plus switch exceeded Injector unit is not energized 319902: Check cable, plug, injector, engine control unit	A750		E	1
8BC703	Engine uppercarr. Actuation Injection Cyl. 5 No increase time measured no reaction 319903: Check cable, plug, injector, engine control unit	A750		E	1
8BC704	Engine uppercarr. Actuation Injection Cyl. 5 Increase time too large no reaction 319904: Check cable, plug, injector, engine control unit	A750		E	1
8BC705	Engine uppercarr. Actuation Injection Cyl. 5 Cyl. Overlap Engine shut off 319905: Load new software in engine control unit	A750		E	1
8BC706	Engine uppercarr. Actuation Injection Cyl. 5 No fly time measured no reaction 319906: Check cable, plug, injector, engine control unit	A750		E	1
8BC707	Engine uppercarr. Actuation Injection Cyl. 5 Fly time too small no reaction 319907: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC708	Engine uppercarr. Actuation Injection Cyl. 5 Fly time too large no reaction 319908: Check cable, plug, injector, engine control unit	A750		E	1
8BC800	Engine uppercarr. Actuation Injection Cyl. 6 Interruption or current remeasuring erroneous no reaction 320000: Check cable, plug, injector, engine control unit	A750		E	1
8BC801	Engine uppercarr. Actuation Injection Cyl. 6 Maximum current ground switch exceeded Injector unit is not energized 320001: Check cable, plug, injector, engine control unit	A750		E	1
8BC802	Engine uppercarr. Actuation Injection Cyl. 6 Maximum current Plus switch exceeded Injector unit is not energized 320002: Check cable, plug, injector, engine control unit	A750		E	1
8BC803	Engine uppercarr. Actuation Injection Cyl. 6 No increase time measured no reaction 320003: Check cable, plug, injector, engine control unit	A750		E	1
8BC804	Engine uppercarr. Actuation Injection Cyl. 6 Increase time too large no reaction 320004: Check cable, plug, injector, engine control unit	A750		E	1
8BC805	Engine uppercarr. Actuation Injection Cyl. 6 Cyl. Overlap Engine shut off 320005: Load new software in engine control unit	A750		E	1
8BC806	Engine uppercarr. Actuation Injection Cyl. 6 No fly time measured no reaction 320006: Check cable, plug, injector, engine control unit	A750		E	1
8BC807	Engine uppercarr. Actuation Injection Cyl. 6 Fly time too small no reaction 320007: Check cable, plug, injector, engine control unit	A750		E	1
8BC808	Engine uppercarr. Actuation Injection Cyl. 6 Fly time too large no reaction 320008: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC900	Engine uppercarr. Actuation Injection Cyl. 7 Interruption or current remeasuring erroneous no reaction 320100: Check cable, plug, injector, engine control unit	A750		E	1
8BC901	Engine uppercarr. Actuation Injection Cyl. 7 Maximum current ground switch exceeded Injector unit is not energized 320101: Check cable, plug, injector, engine control unit	A750		E	1
8BC902	Engine uppercarr. Actuation Injection Cyl. 7 Maximum current Plus switch exceeded Injector unit is not energized 320102: Check cable, plug, injector, engine control unit	A750		E	1
8BC903	Engine uppercarr. Actuation Injection Cyl. 7 No increase time measured no reaction 320103: Check cable, plug, injector, engine control unit	A750		E	1
8BC904	Engine uppercarr. Actuation Injection Cyl. 7 Increase time too large no reaction 320104: Check cable, plug, injector, engine control unit	A750		E	1
8BC905	Engine uppercarr. Actuation Injection Cyl. 7 Cyl. Overlap Engine shut off 320105: Load new software in engine control unit	A750		E	1
8BC906	Engine uppercarr. Actuation Injection Cyl. 7 No fly time measured no reaction 320106: Check cable, plug, injector, engine control unit	A750		E	1
8BC907	Engine uppercarr. Actuation Injection Cyl. 7 Fly time too small no reaction 320107: Check cable, plug, injector, engine control unit	A750		E	1
8BC908	Engine uppercarr. Actuation Injection Cyl. 7 Fly time too large no reaction 320108: Check cable, plug, injector, engine control unit	A750		E	1
8BCA00	Engine uppercarr. Actuation Injection Cyl. 8 Interruption or current remeasuring erroneous no reaction 320200: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCA01	Engine uppercarr. Actuation Injection Cyl. 8 Maximum current ground switch exceeded Injector unit is not energized 320201: Check cable, plug, injector, engine control unit	A750		E	1
8BCA02	Engine uppercarr. Actuation Injection Cyl. 8 Maximum current Plus switch exceeded Injector unit is not energized 320202: Check cable, plug, injector, engine control unit	A750		E	1
8BCA03	Engine uppercarr. Actuation Injection Cyl. 8 No increase time measured no reaction 320203: Check cable, plug, injector, engine control unit	A750		E	1
8BCA04	Engine uppercarr. Actuation Injection Cyl. 8 Increase time too large no reaction 320204: Check cable, plug, injector, engine control unit	A750		E	1
8BCA05	Engine uppercarr. Actuation Injection Cyl. 8 Cyl. Overlap Engine shut off 320205: Load new software in engine control unit	A750		E	1
8BCA06	Engine uppercarr. Actuation Injection Cyl. 8 No fly time measured no reaction 320206: Check cable, plug, injector, engine control unit	A750		E	1
8BCA07	Engine uppercarr. Actuation Injection Cyl. 8 Fly time too small no reaction 320207: Check cable, plug, injector, engine control unit	A750		E	1
8BCA08	Engine uppercarr. Actuation Injection Cyl. 8 Fly time too large no reaction 320208: Check cable, plug, injector, engine control unit	A750		E	1
8BCB00	Engine uppercarr. Actuation Injection Cyl. 9 Interruption or current remeasuring erroneous no reaction 320300: Check cable, plug, injector, engine control unit	A750		E	1
8BCB01	Engine uppercarr. Actuation Injection Cyl. 9 Maximum current ground switch exceeded Injector unit is not energized 320301: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCB02	Engine uppercarr. Actuation Injection Cyl. 9 Maximum current Plus switch exceeded Injector unit is not energized 320302: Check cable, plug, injector, engine control unit	A750		E	1
8BCB03	Engine uppercarr. Actuation Injection Cyl. 9 No increase time measured no reaction 320303: Check cable, plug, injector, engine control unit	A750		E	1
8BCB04	Engine uppercarr. Actuation Injection Cyl. 9 Increase time too large no reaction 320304: Check cable, plug, injector, engine control unit	A750		E	1
8BCB05	Engine uppercarr. Actuation Injection Cyl. 9 Cyl. Overlap Engine shut off 320305: Load new software in engine control unit	A750		E	1
8BCB06	Engine uppercarr. Actuation Injection Cyl. 9 No fly time measured no reaction 320306: Check cable, plug, injector, engine control unit	A750		E	1
8BCB07	Engine uppercarr. Actuation Injection Cyl. 9 Fly time too small no reaction 320307: Check cable, plug, injector, engine control unit	A750		E	1
8BCB08	Engine uppercarr. Actuation Injection Cyl. 9 Fly time too large no reaction 320308: Check cable, plug, injector, engine control unit	A750		E	1
8BCC00	Engine uppercarr. Actuation Injection Cyl. 10 Interruption or current remeasuring erroneous no reaction 320400: Check cable, plug, injector, engine control unit	A750		E	1
8BCC01	Engine uppercarr. Actuation Injection Cyl. 10 Maximum current ground switch exceeded Injector unit is not energized 320401: Check cable, plug, injector, engine control unit	A750		E	1
8BCC02	Engine uppercarr. Actuation Injection Cyl. 10 Maximum current Plus switch exceeded Injector unit is not energized 320402: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCC03	Engine uppercarr. Actuation Injection Cyl. 10 No increase time measured no reaction 320403: Check cable, plug, injector, engine control unit	A750		E	1
8BCC04	Engine uppercarr. Actuation Injection Cyl. 10 Increase time too large no reaction 320404: Check cable, plug, injector, engine control unit	A750		E	1
8BCC05	Engine uppercarr. Actuation Injection Cyl. 10 Cyl. Overlap Engine shut off 320405: Load new software in engine control unit	A750		E	1
8BCC06	Engine uppercarr. Actuation Injection Cyl. 10 No fly time measured no reaction 320406: Check cable, plug, injector, engine control unit	A750		E	1
8BCC07	Engine uppercarr. Actuation Injection Cyl. 10 Fly time too small no reaction 320407: Check cable, plug, injector, engine control unit	A750		E	1
8BCC08	Engine uppercarr. Actuation Injection Cyl. 10 Fly time too large no reaction 320408: Check cable, plug, injector, engine control unit	A750		E	1
8BCD00	Engine uppercarr. Actuation Injection Cyl. 11 Interruption or current remeasuring erroneous no reaction 320500: Check cable, plug, injector, engine control unit	A750		E	1
8BCD01	Engine uppercarr. Actuation Injection Cyl. 11 Maximum current ground switch exceeded Injector unit is not energized 320501: Check cable, plug, injector, engine control unit	A750		E	1
8BCD02	Engine uppercarr. Actuation Injection Cyl. 11 Maximum current Plus switch exceeded Injector unit is not energized 320502: Check cable, plug, injector, engine control unit	A750		E	1
8BCD03	Engine uppercarr. Actuation Injection Cyl. 11 No increase time measured no reaction 320503: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCD04	Engine uppercarr. Actuation Injection Cyl. 11 Increase time too large no reaction 320504: Check cable, plug, injector, engine control unit	A750		E	1
8BCD05	Engine uppercarr. Actuation Injection Cyl. 11 Cyl. Overlap Engine shut off 320505: Load new software in engine control unit	A750		E	1
8BCD06	Engine uppercarr. Actuation Injection Cyl. 11 No fly time measured no reaction 320506: Check cable, plug, injector, engine control unit	A750		E	1
8BCD07	Engine uppercarr. Actuation Injection Cyl. 11 Fly time too small no reaction 320507: Check cable, plug, injector, engine control unit	A750		E	1
8BCD08	Engine uppercarr. Actuation Injection Cyl. 11 Fly time too large no reaction 320508: Check cable, plug, injector, engine control unit	A750		E	1
8BCE00	Engine uppercarr. Actuation Injection Cyl. 12 Interruption or current remeasuring erroneous no reaction 320600: Check cable, plug, injector, engine control unit	A750		E	1
8BCE01	Engine uppercarr. Actuation Injection Cyl. 12 Maximum current ground switch exceeded Injector unit is not energized 320601: Check cable, plug, injector, engine control unit	A750		E	1
8BCE02	Engine uppercarr. Actuation Injection Cyl. 12 Maximum current Plus switch exceeded Injector unit is not energized 320602: Check cable, plug, injector, engine control unit	A750		E	1
8BCE03	Engine uppercarr. Actuation Injection Cyl. 12 No increase time measured no reaction 320603: Check cable, plug, injector, engine control unit	A750		E	1
8BCE04	Engine uppercarr. Actuation Injection Cyl. 12 Increase time too large no reaction 320604: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCE05	Engine uppercarr. Actuation Injection Cyl. 12 Cyl. Overlap Engine shut off 320605: Load new software in engine control unit	A750		E	1
8BCE06	Engine uppercarr. Actuation Injection Cyl. 12 No fly time measured no reaction 320606: Check cable, plug, injector, engine control unit	A750		E	1
8BCE07	Engine uppercarr. Actuation Injection Cyl. 12 Fly time too small no reaction 320607: Check cable, plug, injector, engine control unit	A750		E	1
8BCE08	Engine uppercarr. Actuation Injection Cyl. 12 Fly time too large no reaction 320608: Check cable, plug, injector, engine control unit	A750		E	1
8BCF00	Engine uppercarr. Actuation injection cylinder 13 Interruption or current remeasuring erroneous no reaction 320700: Check cable, plug, injector, engine control unit	A750		E	1
8BCF01	Engine uppercarr. Actuation injection cylinder 13 Maximum current ground switch exceeded Injector unit is not energized 320701: Check cable, plug, injector, engine control unit	A750		E	1
8BCF02	Engine uppercarr. Actuation injection cylinder 13 Maximum current Plus switch exceeded Injector unit is not energized 320702: Check cable, plug, injector, engine control unit	A750		E	1
8BCF03	Engine uppercarr. Actuation injection cylinder 13 No increase time measured no reaction 320703: Check cable, plug, injector, engine control unit	A750		E	1
8BCF04	Engine uppercarr. Actuation injection cylinder 13 Increase time too large no reaction 320704: Check cable, plug, injector, engine control unit	A750		E	1
8BCF05	Engine uppercarr. Actuation injection cylinder 13 Cyl. Overlap Engine shut off 320705: Load new software in engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCF06	Engine uppercarr. Actuation injection cylinder 13 No fly time measured no reaction 320706: Check cable, plug, injector, engine control unit	A750		E	1
8BCF07	Engine uppercarr. Actuation injection cylinder 13 Fly time too small no reaction 320707: Check cable, plug, injector, engine control unit	A750		E	1
8BCF08	Engine uppercarr. Actuation injection cylinder 13 Fly time too large no reaction 320708: Check cable, plug, injector, engine control unit	A750		E	1
8BD000	Engine uppercarr. Actuation injection cylinder 14 Interruption or current remeasuring erroneous no reaction 320800: Check cable, plug, injector, engine control unit	A750		E	1
8BD001	Engine uppercarr. Actuation injection cylinder 14 Maximum current ground switch exceeded Injector unit is not energized 320801: Check cable, plug, injector, engine control unit	A750		E	1
8BD002	Engine uppercarr. Actuation injection cylinder 14 Maximum current Plus switch exceeded Injector unit is not energized 320802: Check cable, plug, injector, engine control unit	A750		E	1
8BD003	Engine uppercarr. Actuation injection cylinder 14 No increase time measured no reaction 320803: Check cable, plug, injector, engine control unit	A750		E	1
8BD004	Engine uppercarr. Actuation injection cylinder 14 Increase time too large no reaction 320804: Check cable, plug, injector, engine control unit	A750		E	1
8BD005	Engine uppercarr. Actuation injection cylinder 14 Cyl. Overlap Engine shut off 320805: Load new software in engine control unit	A750		E	1
8BD006	Engine uppercarr. Actuation injection cylinder 14 No fly time measured no reaction 320806: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD007	Engine uppercarr. Actuation injection cylinder 14 Fly time too small no reaction 320807: Check cable, plug, injector, engine control unit	A750		E	1
8BD008	Engine uppercarr. Actuation injection cylinder 14 Fly time too large no reaction 320808: Check cable, plug, injector, engine control unit	A750		E	1
8BD100	Engine uppercarr. Actuation injection cylinder 15 Interruption or current remeasuring erroneous no reaction 320900: Check cable, plug, injector, engine control unit	A750		E	1
8BD101	Engine uppercarr. Actuation injection cylinder 15 Maximum current ground switch exceeded Injector unit is not energized 320901: Check cable, plug, injector, engine control unit	A750		E	1
8BD102	Engine uppercarr. Actuation injection cylinder 15 Maximum current Plus switch exceeded Injector unit is not energized 320902: Check cable, plug, injector, engine control unit	A750		E	1
8BD103	Engine uppercarr. Actuation injection cylinder 15 No increase time measured no reaction 320903: Check cable, plug, injector, engine control unit	A750		E	1
8BD104	Engine uppercarr. Actuation injection cylinder 15 Increase time too large no reaction 320904: Check cable, plug, injector, engine control unit	A750		E	1
8BD105	Engine uppercarr. Actuation injection cylinder 15 Cyl. Overlap Engine shut off 320905: Load new software in engine control unit	A750		E	1
8BD106	Engine uppercarr. Actuation injection cylinder 15 No fly time measured no reaction 320906: Check cable, plug, injector, engine control unit	A750		E	1
8BD107	Engine uppercarr. Actuation injection cylinder 15 Fly time too small no reaction 320907: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD108	Engine uppercarr. Actuation injection cylinder 15 Fly time too large no reaction 320908: Check cable, plug, injector, engine control unit	A750		E	1
8BD200	Engine uppercarr. Actuation injection cylinder 16 Interruption or current remeasuring erroneous no reaction 321000: Check cable, plug, injector, engine control unit	A750		E	1
8BD201	Engine uppercarr. Actuation injection cylinder 16 Maximum current ground switch exceeded Injector unit is not energized 321001: Check cable, plug, injector, engine control unit	A750		E	1
8BD202	Engine uppercarr. Actuation injection cylinder 16 Maximum current Plus switch exceeded Injector unit is not energized 321002: Check cable, plug, injector, engine control unit	A750		E	1
8BD203	Engine uppercarr. Actuation injection cylinder 16 No increase time measured no reaction 321003: Check cable, plug, injector, engine control unit	A750		E	1
8BD204	Engine uppercarr. Actuation injection cylinder 16 Increase time too large no reaction 321004: Check cable, plug, injector, engine control unit	A750		E	1
8BD205	Engine uppercarr. Actuation injection cylinder 16 Cyl. Overlap Engine shut off 321005: Load new software in engine control unit	A750		E	1
8BD206	Engine uppercarr. Actuation injection cylinder 16 No fly time measured no reaction 321006: Check cable, plug, injector, engine control unit	A750		E	1
8BD207	Engine uppercarr. Actuation injection cylinder 16 Fly time too small no reaction 321007: Check cable, plug, injector, engine control unit	A750		E	1
8BD208	Engine uppercarr. Actuation injection cylinder 16 Fly time too large no reaction 321008: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD400	Engine uppercarr. Injection system Cylinder error Engine shut off 321200: Check cable, plug, injector, engine control unit	A750		E	1
8BD401	Engine uppercarr. Injection system Overlap of injection on cyl. bank A Engine shut off 321201: Load new software in engine control unit	A750		E	1
8BD402	Engine uppercarr. Injection system Overlap of injection on cyl. bank B Engine shut off 321202: Load new software in engine control unit	A750		E	1
8BD403	Engine uppercarr. Injection system Overlap of injection on cyl. bank C Engine shut off 321203: Load new software in engine control unit	A750		E	1
8BD404	Engine uppercarr. Injection system Overlap of injection on cyl. bank D Engine shut off 321204: Load new software in engine control unit	A750		E	1
8BD500	Engine uppercarr. Rpm monitoring Rpm sensor 1 has warning threshold exceeded no reaction 321300: Check engine op.(overspeed due to push op.)	A750		E	1
8BD501	Engine uppercarr. Rpm monitoring Rpm sensor 2 has warning threshold exceeded no reaction 321301: Check engine op.(overspeed due to push op.)	A750		E	1
8BD502	Engine uppercarr. Rpm monitoring Rpm sensor 1 has safety threshold exceeded Engine shut off 321302: Check engine op.(overspeed due to push op.)	A750		E	1
8BD503	Engine uppercarr. Rpm monitoring Rpm sensor 2 has safety threshold exceeded Engine shut off 321303: Check engine op.(overspeed due to push op.)	A750		E	1
8BD504	Engine uppercarr. Rpm monitoring Warning threshold exceeded no reaction 321304: Check engine op.(overspeed due to push op.)	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD505	Engine uppercarr. Rpm monitoring Safety threshold exceeded Engine shut off 321305: Check engine op.(overspeed due to push op.)	A750		E	2
8BD600	Engine uppercarr. Synchronization Rpm signals No synchronization no reaction 321400: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BD601	Engine uppercarr. Synchronization Rpm signals Incorrect distance gap <> Phase sensor no reaction 321401: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BD602	Engine uppercarr. Synchronization Rpm signals Tooth number (Impulse number) wrong Engine start not possible 321402: Turn ignition off/on, check teeth on flywheel, check rpm sensor	A750		E	1
8BD603	Engine uppercarr. Synchronization Rpm signals not possible, Rpm too low no reaction 321403: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BD604	Engine uppercarr. Synchronization Rpm signals Index counter cam shaft gear erroneous no reaction 321404: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BD700	Engine uppercarr. RPM sensor 1 Signal lost Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321500: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD701	Engine uppercarr. RPM sensor 1 No signal Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321501: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD702	Engine uppercarr. RPM sensor 1 Permissible signal difference within test interval exceeded Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321502: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD703	Engine uppercarr. RPM sensor 1 Limit frequency exceeded Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321503: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD704	Engine uppercarr. RPM sensor 1 Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321504: Check rpm sensor inst., engine control unit	A750		E	1
8BD705	Engine uppercarr. RPM sensor 1 Measurement erroneous Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321505: Check rpm sensor inst., engine control unit	A750		E	1
8BD800	Engine uppercarr. RPM sensor 2 Signal lost Em. Shut off at simult. failure of both Rpm sensors 321600: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD801	Engine uppercarr. RPM sensor 2 No signal Em. Shut off at simult. failure of both Rpm sensors 321601: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD802	Engine uppercarr. RPM sensor 2 Permissible signal difference within test interval exceeded Em. Shut off at simult. failure of both Rpm sensors 321602: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD803	Engine uppercarr. RPM sensor 2 Limit frequency exceeded Em. Shut off at simult. failure of both Rpm sensors 321603: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD804	Engine uppercarr. RPM sensor 2 Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321604: Check rpm sensor inst., sensor.	A750		E	1
8BD805	Engine uppercarr. RPM sensor 2 Measurement erroneous RPM determination via functioning sensor. 321605: Check rpm sensor inst., sensor.	A750		E	1
8BD900	Engine uppercarr. Index sensor Signal lost Em. Shut off at simult. failure of both Rpm sensors 321700: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD901	Engine uppercarr. Index sensor No signal Em. Shut off at simult. failure of both Rpm sensors 321701: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD902	Engine uppercarr. Index sensor Permissible signal difference within test interval exceeded Em. Shut off at simult. failure of both Rpm sensors 321702: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD903	Engine uppercarr. Index sensor Limit frequency exceeded Em. Shut off at simult. failure of both Rpm sensors 321703: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD904	Engine uppercarr. Index sensor Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321704: Check rpm sensor inst., sensor.	A750		E	1
8BD905	Engine uppercarr. Index sensor Measurement erroneous RPM determination via functioning sensor. 321705: Check rpm sensor inst., sensor.	A750		E	1
8BDA04	Engine uppercarr. Lambda-Measurement Regulation deviation, Lambda value too low Warning light on 321804: - Ground current sensor - Lambda Sensor - exhaust return	A750		E	1
8BDA05	Engine uppercarr. Lambda-Measurement Regulation deviation, Lambda value too high Warning light on 321805: - Ground current sensor - Lambda Sensor - exhaust return	A750		E	1
8BDA07	Engine uppercarr. Lambda-Measurement EGR Flow between Bank 1 and Bank 2 very asymmetric Warning light on 321807: Clean / replace actuator, check lines/linkage	A750		E	1
8BDB04	Engine uppercarr. Lambda-Measurement Permanent regulation deviation, Lambda value too low Warning light on 321904: - Ground current sensor - Lambda Sensor - exhaust return	A750		E	1
8BDB05	Engine uppercarr. Lambda-Measurement Permanent regulation deviation, Lambda value too high Warning light on 321905: - Ground current sensor - Lambda Sensor - exhaust return	A750		E	1
8BDC04	Engine uppercarr. charge air pressure minimum limit value fallen below Warning light on 322004: Check intake system for leaks	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BDC05	Engine uppercarr. charge air pressure maximum limit value exceeded Warning light on 322005: Check for stuck Wastegate	A750		E	1
8BE200	Engine uppercarr. Injection system 2 Cylinder error Slave Modules not running (there will be no injection on this module) 322600: Check cable, plug, injector, engine control unit	A750		E	1
8BE201	Engine uppercarr. Injection system 2 Overlap of injection on cyl. bank A Slave Modules not running (there will be no injection on this module) 322601: Load new software in engine control unit	A750		E	1
8BE202	Engine uppercarr. Injection system 2 Overlap of injection on cyl. bank B Slave Modules not running (there will be no injection on this module) 322602: Load new software in engine control unit	A750		E	1
8BE203	Engine uppercarr. Injection system 2 Overlap of injection on cyl. bank C Slave Modules not running (there will be no injection on this module) 322603: Load new software in engine control unit	A750		E	1
8BE204	Engine uppercarr. Injection system 2 Overlap of injection on cyl. bank D Slave Modules not running (there will be no injection on this module) 322604: Load new software in engine control unit	A750		E	1
8BE205	Engine uppercarr. Injection system 2 Plus switch cyl. bank A Short circuit after ground no reaction 322605: Check cable, plug, injector, engine control unit	A750		E	1
8BE206	Engine uppercarr. Injection system 2 Plus switch cyl. bank B Short circuit after ground no reaction 322606: Check cable, plug, injector, engine control unit	A750		E	1
8BE207	Engine uppercarr. Injection system 2 Plus switch cyl. bank A short circuit after supply voltage no reaction 322607: Check cable, plug, injector, engine control unit	A750		E	1
8BE208	Engine uppercarr. Injection system 2 Plus switch cyl. bank B short circuit after supply voltage no reaction 322608: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE209	Engine uppercarr. Injection system 2 Ground switch cyl. bank A Short circuit after ground At CR-Motor Shut off of Bank A on Slave Module 322609: Check cable, plug, injector, engine control unit	A750		E	1
8BE20A	Engine uppercarr. Injection system 2 Ground switch cyl. bank B Short circuit after ground At CR-Motor Shut off of Bank B on Slave Module 322610: Check cable, plug, injector, engine control unit	A750		E	1
8BE20B	Engine uppercarr. Injection system 2 Ground switch cyl. bank A short circuit after supply voltage no reaction 322611: Check cable, plug, injector, engine control unit	A750		E	1
8BE20C	Engine uppercarr. Injection system 2 Ground switch cyl. bank B short circuit after supply voltage no reaction 322612: Check cable, plug, injector, engine control unit	A750		E	1
8BE300	Engine uppercarr. Synchronization Rpm signals System 2 No synchronization no reaction 322700: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BE301	Engine uppercarr. Synchronization Rpm signals System 2 Incorrect distance gap <> Phase sensor no reaction 322701: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BE302	Engine uppercarr. Synchronization Rpm signals System 2 Tooth number (Impulse number) wrong Slave Modules not running (there will be no injection on this module) 322702: Turn ignition off/on, check teeth on flywheel, rpm sensor	A750		E	1
8BE303	Engine uppercarr. Synchronization Rpm signals System 2 not possible, Rpm too low no reaction 322703: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BE304	Engine uppercarr. Synchronization Rpm signals System 2 Index counter cam shaft gear erroneous no reaction 322704: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BE400	Engine uppercarr. Rpm sensor 1 System 2 Signal lost Engine output reduced. Rpm recording via camshaft sensor if o.k. 322800: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE401	Engine uppercarr. Rpm sensor 1 System 2 No signal Engine output reduced. Rpm recording via camshaft sensor if o.k. 322801: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE402	Engine uppercarr. Rpm sensor 1 System 2 Permissible signal difference within test interval exceeded Engine output reduced. Rpm recording via camshaft sensor if o.k. 322802: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE403	Engine uppercarr. Rpm sensor 1 System 2 Limit frequency exceeded Engine output reduced. Rpm recording via camshaft sensor if o.k. 322803: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE404	Engine uppercarr. Rpm sensor 1 System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322804: Check rpm sensor inst., engine control unit	A750		E	1
8BE405	Engine uppercarr. Rpm sensor 1 System 2 Measurement erroneous Engine output reduced. Rpm recording via camshaft sensor if o.k. 322805: Check rpm sensor inst., engine control unit	A750		E	1
8BE500	Engine uppercarr. Rpm sensor 2 System 2 Signal lost Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322900: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE501	Engine uppercarr. Rpm sensor 2 System 2 No signal Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322901: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE502	Engine uppercarr. Rpm sensor 2 System 2 Permissible signal difference within test interval exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322902: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE503	Engine uppercarr. Rpm sensor 2 System 2 Limit frequency exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322903: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE504	Engine uppercarr. Rpm sensor 2 System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322904: Check rpm sensor inst., sensor.	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE505	Engine uppercarr. Rpm sensor 2 System 2 Measurement erroneous RPM determination via functioning sensor. 322905: Check rpm sensor inst., sensor.	A750		E	1
8BE600	Engine uppercarr. Index sensor System 2 Signal lost Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323000: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE601	Engine uppercarr. Index sensor System 2 No signal Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323001: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE602	Engine uppercarr. Index sensor System 2 Permissible signal difference within test interval exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323002: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE603	Engine uppercarr. Index sensor System 2 Limit frequency exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323003: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE604	Engine uppercarr. Index sensor System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323004: Check rpm sensor inst., sensor	A750		E	1
8BE605	Engine uppercarr. Index sensor System 2 Measurement erroneous RPM determination via functioning sensor. 323005: Check rpm sensor inst., sensor.	A750		E	1
8BE700	Engine uppercarr. Hardware temperature sensor control unit 2 Short circuit after ground or broken wire Benutzung des Ersatzwertes. 323100: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE701	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 323101: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE702	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 323102: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE703	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 323103: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE704	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor signal outside permissible range 1 Benutzung des Ersatzwertes. 323104: Check operational status of engine	A750		E	1
8BE705	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor signal outside permissible range 2 Benutzung des Ersatzwertes. 323105: Check operational status of engine	A750		E	1
8BE706	Engine uppercarr. Hardware temperature sensor control unit 2 Plausibility error at engine off no reaction 323106: Check operational status of engine	A750		E	1
8BE800	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Short circuit after ground or broken wire Benutzung des Ersatzwertes. 323200: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE801	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor signal short circuit after supply voltage Benutzung des Ersatzwertes. 323201: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE802	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor supply voltage short circuit after ground or broken wire Benutzung des Ersatzwertes. 323202: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE803	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor supply voltage short circuit after supply voltage Benutzung des Ersatzwertes. 323203: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE804	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor signal outside permissible range 1 Benutzung des Ersatzwertes. 323204: Check operational status of engine	A750		E	1
8BE805	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor signal outside permissible range 2 Benutzung des Ersatzwertes. 323205: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE806	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Plausibility error at engine off no reaction 323206: Check operational status of engine	A750		E	1
8BE900	Engine uppercarr. Internal error control unit 2 Stack-overflow Slave Modules not running (there will be no injection on this module) 323300: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE901	Engine uppercarr. Internal error control unit 2 Exception error Slave Modules not running (there will be no injection on this module) 323301: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE902	Engine uppercarr. Internal error control unit 2 Program test Slave Modules not running (there will be no injection on this module) 323302: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE903	Engine uppercarr. Internal error control unit 2 RAM-Test Slave Modules not running (there will be no injection on this module) 323303: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BE904	Engine uppercarr. Internal error control unit 2 Overflow in error stack no reaction 323304: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE905	Engine uppercarr. Internal error control unit 2 Comp. time error no reaction 323305: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE906	Engine uppercarr. Internal error control unit 2 Error-Index too large The error cannot be saved 323306: Load new software in engine control unit or replace engine control unit	A750		E	1
8BEA00	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Error at EEPROM-access Slave Modules not running (there will be no injection on this module) 323400: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA01	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error Parameter memory Slave Modules not running (there will be no injection on this module) 323401: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEA02	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Parameter memory in EEPROM is invalid Slave Modules not running (there will be no injection on this module) 323402: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA03	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error ECU-Page No reaction - possibly data sets or operating conditions could not be saved 323403: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA04	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error NMI-Page No reaction - possibly data sets or operating conditions could not be saved 323404: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA05	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error Workdata-Page No reaction - possibly data sets or operating conditions could not be saved 323405: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA06	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error load collective No reaction - possibly load collective data could not be saved 323406: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA07	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Structure size of load collective has changed No reaction - possibly load collective data could not be saved 323407: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA08	Engine uppercarr. Control unit 2 defective (Memory EEPROM) EEPROM-Memory full (load collective) No reaction - possibly load collective data could not be saved 323408: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA09	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error permanent Data No reaction - possibly data sets or operating conditions could not be saved 323409: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEB00	Engine uppercarr. Voltage supply System 2 voltage below required value Slave Modules not running (there will be no injection on this module) 323500: Check on board network(battery, alternator, wiring, plug).	A750		E	1
8BEB01	Engine uppercarr. Voltage supply System 2 excess voltage Slave Modules not running (there will be no injection on this module) 323501: Check on board network (battery, alternator, wiring, plug)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEB02	Engine uppercarr. Voltage supply System 2 Digital outlet short circuit after supply voltage Slave Modules not running (there will be no injection on this module) 323502: Check wiring, engine control unit, possibly replace engine control unit	A750		E	1
8BEB03	Engine uppercarr. Voltage supply System 2 Error release output outlets Slave Modules not running (there will be no injection on this module) 323503: Check wiring, engine control unit, possibly replace engine control unit	A750		E	1
8BEB04	Engine uppercarr. Voltage supply System 2 PS1-Pin erroneous/missing Slave Modules not running (there will be no injection on this module) 323504: Check on board network in ref. to PS1 (terminal 30/31), engine control unit	A750		E	1
8BEB05	Engine uppercarr. Voltage supply System 2 Reference voltage 12V below permissible range Slave Modules not running (there will be no injection on this module) 323505: Check supply voltage Rpm sensors, on board network, engine control unit	A750		E	1
8BEB06	Engine uppercarr. Voltage supply System 2 Reference voltage 12V above permissible range Slave Modules not running (there will be no injection on this module) 323506: Check supply voltage Rpm sensors, on board network, engine control unit	A750		E	1
8BEC00	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Check sum error Parameter memory Slave Modules not running (there will be no injection on this module) 323600: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEC01	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Invalid data, default values are used Slave Modules not running (there will be no injection on this module) 323601: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEC02	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Error during delete Slave Modules not running (there will be no injection on this module) 323602: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEC03	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Error during programming Slave Modules not running (there will be no injection on this module) 323603: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEC04	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Error during check Slave Modules not running (there will be no injection on this module) 323604: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEC05	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Data inconsistent Slave Modules not running (there will be no injection on this module) 323605: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BED00	Engine uppercarr. Outlet engine rpm System 2 Broken wire or Short circuit after ground 323700: Check wiring harness, plug, conn. Modul	A750		E	1
8BED01	Engine uppercarr. Outlet engine rpm System 2 Broken wire or short circuit after supply voltage 323701: Check wiring harness, plug, conn. Modul	A750		E	1
8BEE00	Engine uppercarr. Safety checks (SIL) Access error Data memory Engine stop, Start lock 323800: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE01	Engine uppercarr. Safety checks (SIL) Access error Data memory Engine stop, Start lock 323801: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE02	Engine uppercarr. Safety checks (SIL) Access error Data memory Engine stop, Start lock 323802: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE03	Engine uppercarr. Safety checks (SIL) Emerg. shut off (DI6) Engine stop, Start lock 323803: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE04	Engine uppercarr. Safety checks (SIL) Emerg. shut off (Level DI6) Engine stop, Start lock 323804: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE05	Engine uppercarr. Safety checks (SIL) Plausibility error status KI.15 <=> emerg. stop Engine stop, Start lock 323805: Deactivate emerg. stop and turn ignition on / off	A750		E	2
8BEE06	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring KI.15 Engine stop, Start lock 323806: Turn ignition on / off, Update or replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEE07	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring KI.15 Engine stop, Start lock 323807: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE08	Engine uppercarr. Safety checks (SIL) Reference voltage 1.5 V ADC/DMA erroneous Engine stop, Start lock 323808: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE09	Engine uppercarr. Safety checks (SIL) Error in program run control Engine stop, Start lock 323809: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE0A	Engine uppercarr. Safety checks (SIL) Error in program run control Engine stop, Start lock 323810: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE0B	Engine uppercarr. Safety checks (SIL) Error in program run control Engine stop, Start lock 323811: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE0D	Engine uppercarr. Safety checks (SIL) Internal error data memory (checksum flash) Engine stop, Start lock 323813: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF00	Engine uppercarr. Safety checks (SIL) Internal error data memory (checksum Parameter) Engine stop, Start lock 323900: Load valid data set	A750		E	2
8BEF01	Engine uppercarr. Safety checks (SIL) Internal error data memory (Safety buffer) Engine stop, Start lock 323901: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF02	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring PS1-Pin Engine stop, Start lock 323902: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF03	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring PS1-Pin Engine stop, Start lock 323903: Turn ignition on / off, Update or replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEF04	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring KI.50 Engine stop, Start lock 323904: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF05	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring air flap Engine stop, Start lock 323905: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF06	Engine uppercarr. Safety checks (SIL) Injector Bank A permanently energized Engine stop, Start lock 323906: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF07	Engine uppercarr. Safety checks (SIL) Injector Bank B permanently energized Engine stop, Start lock 323907: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF08	Engine uppercarr. Safety checks (SIL) Injector Bank C permanently energized Engine stop, Start lock 323908: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF09	Engine uppercarr. Safety checks (SIL) Injector Bank D permanently energized Engine stop, Start lock 323909: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF0A	Engine uppercarr. Safety checks (SIL) Injector excessive current Engine stop, Start lock 323910: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF0B	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring PS2-Pin Engine stop, Start lock 323911: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF0C	Engine uppercarr. Safety checks (SIL) Max. temperature injector exceeded Engine stop, Start lock 323912: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF0D	Engine uppercarr. Safety checks (SIL) Internal error CPU (excessive temperature) Engine stop, Start lock 323913: Turn ignition on / off, Update or replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF000	Engine uppercarr. Safety checks (SIL) Plausibility error rpm monitoring Engine stop, Start lock 324000: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF001	Engine uppercarr. Safety checks (SIL) all rpm signals erroneous/missing Engine stop, Start lock 324001: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF002	Engine uppercarr. Safety checks (SIL) Crankshaft signals erroneous/implausible (Signal sample) Engine stop, Start lock 324002: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF003	Engine uppercarr. Safety checks (SIL) Crankshaft signals erroneous/implausible (failure) Engine stop, Start lock 324003: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF004	Engine uppercarr. Safety checks (SIL) Crankshaft signals erroneous/implausible (difference) Engine stop, Start lock 324004: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF005	Engine uppercarr. Safety checks (SIL) Nockenwellensignale erroneous/implausible (Signal sample) Engine stop, Start lock 324005: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF006	Engine uppercarr. Safety checks (SIL) Nockenwellensignale erroneous/implausible (failure) Engine stop, Start lock 324006: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF007	Engine uppercarr. Safety checks (SIL) Nockenwellensignale erroneous/implausible (difference) Engine stop, Start lock 324007: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF008	Engine uppercarr. Safety checks (SIL) Reference voltage 12V outside permissible range Engine stop, Start lock 324008: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF009	Engine uppercarr. Safety checks (SIL) Incorrect software or hardware version (not SIL-able) Engine stop, Start lock 324009: Replace control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF00A	Engine uppercarr. Safety checks (SIL) Incorrect hardware version (not SIL-able) Engine stop, Start lock 324010: Replace control unit	A750		E	2
8BF00B	Engine uppercarr. Safety checks (SIL) Temperature difference between injector / end stage too high Engine stop, Start lock 324011: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF100	Engine uppercarr. Safety checks (SIL) Internal software error (incorrect Parameter) Engine stop, Start lock 324100: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF105	Engine uppercarr. Safety checks (SIL) Starter turns without actuation Engine stop, Start lock 324105: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF106	Engine uppercarr. Safety checks (SIL) Injectors do not turn off Engine stop, Start lock 324106: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF107	Engine uppercarr. Safety checks (SIL) Fatal internal error (Monitoring Status machine) Engine stop, Start lock 324107: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF108	Engine uppercarr. Safety checks (SIL) Configuration error Vehicle-CAN Engine stop, Start lock 324108: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF109	Engine uppercarr. Safety checks (SIL) Datenuebertragung Vehicle -CAN gestoert Engine stop, Start lock 324109: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF10A	Engine uppercarr. Safety checks (SIL) Plausibility error Signals Vehicle -CAN Engine stop, Start lock 324110: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF200	Engine uppercarr. SCR-control unit Hardware error metering unit No measures or pump is in off mode 324200:	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF201	Engine uppercarr. SCR-control unit Metering unit outside permissible limits Pump is in off mode 324201: No measures, error due to environmental cond.	A750		E	1
8BF202	Engine uppercarr. SCR-control unit mechanical error metering unit Pump is in off mode 324202: Check meter	A750		E	1
8BF203	Engine uppercarr. SCR-control unit Memory error metering unit Pump is in off mode 324203: Calibrate meter, if error present always, flash meters	A750		E	1
8BF204	Engine uppercarr. SCR-control unit Urea pressure, output line no reaction 324204: Check outgoing line and its conn.	A750		E	1
8BF205	Engine uppercarr. SCR-control unit Urea pressure, input line No measures or pump is in off mode 324205: Check input line and its connections	A750		E	1
8BF206	Engine uppercarr. SCR-control unit Urea pressure, nozzle no reaction 324206: Check the spray on nozzle	A750		E	1
8BF207	Engine uppercarr. SCR-control unit Urea pressure, injector Pump is in off mode 324207: Check both pins of plugs, if not short circuited, replace bad units	A750		E	1
8BF208	Engine uppercarr. SCR-control unit Control unit error, CAN-communication, display No measures or pump is in off mode 324208: Check CAN-connections	A750		E	1
8BF209	Engine uppercarr. SCR-control unit Battery voltage outside permissible limits Pump is in off mode 324209: Check supply voltage	A750		E	1
8BF20A	Engine uppercarr. SCR-control unit Temperature CAT, Sensor inflow outside permissible limits Pump is in off mode 324210: No measures, error due to environmental cond.	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF20B	Engine uppercarr. SCR-control unit Temperature CAT, Sensor inflow erroneous Pump is in off mode 324211: Check both pins of plugs, if not short circuited, replace bad units	A750		E	1
8BF20C	Engine uppercarr. SCR-control unit TemperatureCAT, Sensor outflow outside permissible limits Pump is in off mode 324212: No measures, error due to environmental cond.	A750		E	1
8BF20D	Engine uppercarr. SCR-control unit Temperature CAT, Sensor outflow erroneous Pump is in off mode 324213: Check both pins of plugs, if not short circuited, replace bad units	A750		E	1
8BF300	Engine uppercarr. SCR-control unit Tank sensor erroneous No measures or pump is in off mode 324300: Check both pins of plugs, if not short circuited, replace bad units	A750		E	1
8BF301	Engine uppercarr. SCR-control unit Tank sensor outside permissible range 324301: No measures, error due to environmental cond.	A750		E	1
8BF302	Engine uppercarr. SCR-control unit Line heating erroneous No measures, error due to environmental cond. 324302: Check both pins of plugs, if not short circuited, replace bad units	A750		E	1
8BF303	Engine uppercarr. SCR-control unit Line heating, temperature outside permissible range Pump is in off mode 324303: No measures, error due to environmental cond.	A750		E	1
8BF304	Engine uppercarr. SCR-control unit Valve heat pump erroneous Pump is in off mode 324304: Defrost system	A750		E	1
8BF305	Engine uppercarr. SCR-control unit Communcation error NOx-Sensor inflow Pump is in off mode 324305: Check electr. conn. of SCR System	A750		E	1
8BF306	Engine uppercarr. SCR-control unit Heater and O2 NOx-Sensor inflow erroneous No measures or pump is in off mode 324306: Replace Upstream NOx Sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF307	Engine uppercarr. SCR-control unit NOx-Sensor inflow erroneous No measures or pump is in off mode 324307: Check both pins of plugs, if not short circuited, replace bad units	A750		E	1
8BF308	Engine uppercarr. SCR-control unit Communcation error NOx-Sensor outflow Pump is in off mode 324308: Check electr. conn. of SCR System	A750		E	1
8BF309	Engine uppercarr. SCR-control unit Heater and O2 NOx-Sensor outflow erroneous No measures or pump is in off mode 324309: Replace downstream NOx Sensor	A750		E	1
8BF30A	Engine uppercarr. SCR-control unit NOx-Sensor outflow erroneous No measures or pump is in off mode 324310: Check both pins of plugs, if not short circuited, replace bad units	A750		E	1
8BF500	Engine uppercarr. Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324500: Check for plugged/ damaged nitrogen line or IV is closed blocked	A750		E	1
8BF501	Engine uppercarr. Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324501: Check nitrogen line for leaks or IV in open position blocked.	A750		E	1
8BF502	Engine uppercarr. Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324502: Check nitrogen supply	A750		E	1
8BF503	Engine uppercarr. Dosing unit 1 Urea "DEF" Data transfer on CAN erroneous/missing Possibly regeneration not possible 324503: Check nitrogen supply line for leaks or plugs, check pump nitrogen supply	A750		E	1
8BF504	Engine uppercarr. Dosing unit 1 Urea "DEF" Electric defect on shut off valve Possibly regeneration not possible 324504: Broken line DCU 17 to test unit, visual check, moisture, wiring	A750		E	1
8BF505	Engine uppercarr. Dosing unit 1 Urea "DEF" System error control shut off valve Possibly regeneration not possible 324505: Shut off valve plugged: - replace MU, bleed system.	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF506	Engine uppercarr. Dosing unit 1 Urea "DEF" Back flow error on sensor pressure+temperature Possibly regeneration not possible 324506: Check nitrogen line for leaks or IV in open position blocked.	A750		E	1
8BF507	Engine uppercarr. Dosing unit 1 Urea "DEF" Back flow error on sensor pressure+temperature Possibly regeneration not possible 324507: Broken line DCU 17 to test unit, visual check, moisture, wiring	A750		E	1
8BF508	Engine uppercarr. Dosing unit 1 Urea "DEF" Electric defect on Dosing valve Possibly regeneration not possible 324508: Broken line DCU 17 to test unit, visual check, moisture, wiring	A750		E	1
8BF509	Engine uppercarr. Dosing unit 1 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324509: Changer MU, System Entlueften	A750		E	1
8BF50A	Engine uppercarr. Dosing unit 1 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324510: Metering valve opens too slow: - check power supply, - start system again change MU, bleed system	A750		E	1
8BF50B	Engine uppercarr. Dosing unit 1 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324511: Broken line DCU 17 to pressure sensor, visual check, moisture, wiring	A750		E	1
8BF50C	Engine uppercarr. Dosing unit 1 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324512: Downstream pressure sensor signal not plausible: - change MU, bleed system	A750		E	1
8BF50D	Engine uppercarr. Dosing unit 1 Urea "DEF" Control unit injection system erroneous Possibly regeneration not possible 324513: Change U, bleed system	A750		E	1
8BF600	Engine uppercarr. Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324600: DCU17 wechseln	A750		E	1
8BF601	Engine uppercarr. Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324601: Check power supply of DCU17, replace control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF602	Engine uppercarr. Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324602: Check Can connection lines incl. connections of connections	A750		E	1
8BF603	Engine uppercarr. Dosing unit 2 Urea "DEF" Data transfer on CAN erroneous/missing Possibly regeneration not possible 324603: Data from LIDEC incorrect, not present or not correct. Check LIDEC error stack.	A750		E	1
8BF604	Engine uppercarr. Dosing unit 2 Urea "DEF" Electric defect on shut off valve Possibly regeneration not possible 324604: Voltage supply of DCU17 is too high, check electr. Lines of DCU17 for short circuit	A750		E	1
8BF605	Engine uppercarr. Dosing unit 2 Urea "DEF" System error control shut off valve Possibly regeneration not possible 324605: Problem during System, check DCU17 error stack trouble shooting dep. failure	A750		E	1
8BF60A	Engine uppercarr. Dosing unit 2 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324610: Reset des HC-meters (KeyOff- wait 5 sec. - KeyOn)	A750		E	1
8BF60B	Engine uppercarr. Dosing unit 2 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324611: Check application dating - check Software Version of HC-meter	A750		E	1
8BF60C	Engine uppercarr. Dosing unit 2 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324612: Turn HC-meter off (wait 5 sec.), turn on, check Software version, replace HC-meter	A750		E	1
8BF60D	Engine uppercarr. Dosing unit 2 Urea "DEF" Control unit injection system erroneous Possibly regeneration not possible 324613:	A750		E	1
8BF704	Engine uppercarr. Temperature monitoring "DOC" Minimum temperature fallen below Warning light on in operation no regeneration permitted 324704: Check HC meter, DOC, then carry out Service Regeneration	A750		E	1
8BF705	Engine uppercarr. Temperature monitoring "DOC" Maximum temperature exceeded Warning light on - in operation no regeneration permitted - power reduction 324705: Check HC meter, DOC, then carry out Service Regeneration	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF800	Engine uppercarr. Monitoring Particle filter "DPF" Oil in exhaust system Warning light on in operation no regeneration permitted 324800: Check: - DOC (possibly replace or turn over and service regeneration)	A750		E	1
8BF801	Engine uppercarr. Monitoring Particle filter "DPF" Maximum ash load reached Warning light on in operation no regeneration permitted 324801: Clean DPF or replace	A750		E	1
8BF802	Engine uppercarr. Monitoring Particle filter "DPF" Differnce pressure filter too high Warning light on- in operation no regeneration permitted possible power reduction 324802: Clean DPF or replace	A750		E	1
8BF803	Engine uppercarr. Monitoring Particle filter "DPF" Differnce pressure filter too low Warning light on - in operation no regeneration permitted - power reduction 324803: Replace DPF	A750		E	1
8BF804	Engine uppercarr. Monitoring Particle filter "DPF" Maximum number aborted heat phases exceeded Warning light on- in operation no regeneration permitted possible power reduction 324804: Request Service regeneration	A750		E	1
8BF805	Engine uppercarr. Monitoring Particle filter "DPF" Maximum number aborted regeneration phases exceeded Warning light on- in operation no regeneration permitted possible power reduction 324805: Request Service regeneration	A750		E	1
8BF806	Engine uppercarr. Monitoring Particle filter "DPF" Maximum temperature increase and max. temperature exceeded Warning light on 324806: Replace DPF	A750		E	1
8BF807	Engine uppercarr. Monitoring Particle filter "DPF" Maximum temperature limit exceeded Warning light on 324807: Replace DPF	A750		E	1
8BF900	Engine uppercarr. OBD Error Ambient pressure sensor Error Use replacement value, no reaction 324900: Check op. status of engine, replace engine control unit	A750		E	1
8BF901	Engine uppercarr. OBD Error Ambient temperature sensor Error Use replacement value, no reaction 324901: Check wiring, control units, sensors	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF902	Engine uppercarr. OBD Error ChargeAir Temperature sensor Error Use replacement value, no reaction 324902: Check wiring, control units, sensors	A750		E	1
8BF903	Engine uppercarr. OBD Error Charge air pressure sensor error Use replacement value, no reaction 324903: Check wiring, control units, sensors	A750		E	1
8BF904	Engine uppercarr. OBD Error Error Pressure deviation charge air pr. regulator Warning light on 324904: Check intake system for leaks, Wastegate	A750		E	1
8BF905	Engine uppercarr. OBD Error Error restrictor flap Power reduction of Diesel engine 324905: Check wiring, control units, sensors	A750		E	1
8BF906	Engine uppercarr. OBD Error Rail pressure sensor 1 Error Power red. in case of failure of both Commonrail pr.sensors, otherwise no reaction, engine standstill after delay 324906: Check wiring, control units, sensors	A750		E	1
8BF907	Engine uppercarr. OBD Error Rail pressure sensor 2 Error Power red. in case of failure of both Commonrail pr.sensors, otherwise no reaction, engine standstill after delay 324907: Check wiring, control units, sensors	A750		E	1
8BF908	Engine uppercarr. OBD Error Pressure reg. valve (PCV) Error Possibly high pr. reg/ emerg. op. activated 324908: Check wiring harness, plug, CR-components2, engine control unit	A750		E	1
8BF909	Engine uppercarr. OBD Error Rail pressure reg. 1 Error no reaction 324909: Nitrogen circuit,Rail sensor,DBV,high pr. pump,wiring	A750		E	1
8BF90A	Engine uppercarr. OBD Error Rail pressure reg. 2 Error no reaction 324910: Nitrogen circuit,Rail sensor,DBV,high pr. pump,wiring	A750		E	1
8BF90B	Engine uppercarr. OBD Error Metering unit (VCV) Error Possibly high pr. reg/ emerg. op. activated 324911: Check wiring harness, plug, CR-components1, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF90C	Engine uppercarr. OBD Error Error Injector 1 Injector is not energized, no reaction 324912: Check wiring, plug, injector, engine control unit	A750		E	1
8BF90D	Engine uppercarr. OBD Error Error Injector 2 Injector is not energized, no reaction 324913: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA00	Engine uppercarr. OBD Error Error Injector 3 Injector is not energized, no reaction 325000: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA01	Engine uppercarr. OBD Error Error Injector 4 Injector is not energized, no reaction 325001: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA02	Engine uppercarr. OBD Error Error Injector 5 Injector is not energized, no reaction 325002: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA03	Engine uppercarr. OBD Error Error Injector 6 Injector is not energized, no reaction 325003: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA04	Engine uppercarr. OBD Error Error Injector 7 Injector is not energized, no reaction 325004: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA05	Engine uppercarr. OBD Error Error Injector 8 Injector is not energized, no reaction 325005: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA06	Engine uppercarr. OBD Error Error fuel temperature sensor Use replacement value, no reaction 325006: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA07	Engine uppercarr. OBD Error Error coolant temperature sensor Use replacement value, no reaction 325007: Check wiring, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFA08	Engine uppercarr. OBD Error Error crankshaft rpm sensor Emerg. shut off only at sim. Failure of both Rpm sensors 325008: Check rpm sensor, distance sensor to flywheel	A750		E	1
8BFA09	Engine uppercarr. OBD Error Error Index sensor camshaft Emerg. shut off only at sim. Failure of both Rpm sensors 325009: Check rpm sensor, distance sensor to flywheel	A750		E	1
8BFA0A	Engine uppercarr. OBD Error SCR catalytic converter inflow temp. sensor error Pump is in off mode 325010: No measures, error due to environmental conditions	A750		E	1
8BFA0B	Engine uppercarr. OBD Error SCR catalytic converter inflow temp. sensor error - OOR MIN Pump is in off mode 325011: No measures, error due to environmental cond.	A750		E	1
8BFA0C	Engine uppercarr. OBD Error SCR catalytic converter outflow temp. sensor error Pump is in off mode 325012: No measures, error due to environmental cond.	A750		E	1
8BFA0D	Engine uppercarr. OBD Error SCR catalytic converter Efficiency error (DEF-Quality, defective cat.) Actuation error lights, possible momentum reduction 325013: Check SCR-control unit, System for leaks, DEF-Quality	A750		E	1
8BFB00	Engine uppercarr. OBD Error SCR catalytic converter Efficiency error (Monitor 2) Actuation warning lights, possible momentum limitation 325100: Check SCR-control unit, System for leaks, DEF-Quality	A750		E	1
8BFB01	Engine uppercarr. OBD Error SCR catalytic converter Efficiency error (incorrect medium, Monitor 2) Actuation warning lights, possible momentum limitation 325101: Check SCR-control unit, System for leaks, DEF-Quality	A750		E	1
8BFB02	Engine uppercarr. OBD Error NOx (Upstream) - Error Sensor communication Pump is in off mode 325102: Check electr. conn. from SCR System	A750		E	1
8BFB03	Engine uppercarr. OBD Error NOx (Upstream) - Error Sensor No measures or pump is in off mode 325103: Check plug, wiring, control units	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFB04	Engine uppercarr. OBD Error NOx (Downstream) - Error Sensor communication Pump is in off mode 325104: Check electr. conn. from SCR System	A750		E	1
8BFB05	Engine uppercarr. OBD Error NOx (Downstream) - Error Sensor No measures or pump is in off mode 325105: Check plug, wiring, control units	A750		E	1
8BFB06	Engine uppercarr. OBD Error Urea Injector Error - short circuit Pump is in off mode 325106: Check plug, wiring, control units	A750		E	1
8BFB07	Engine uppercarr. OBD Error Urea Injector Error open line Pump is in off mode 325107: Check plug, wiring, control units	A750		E	1
8BFB08	Engine uppercarr. OBD Error Urea pressure Error Pump is in Off mode, no measures or pump is in Off mode 325108: Check plug, wiring, control units	A750		E	1
8BFB09	Engine uppercarr. OBD Error Urea pressure Error - OOR MIN No measures or pump is in off mode 325109:	A750		E	1
8BFB0A	Engine uppercarr. OBD Error Urea pressure mechanical error 1 no reaction 325110: Check the spray on nozzle	A750		E	1
8BFB0B	Engine uppercarr. OBD Error Urea pressure mechanical error 3 no reaction 325111: Check the spray on nozzle	A750		E	1
8BFB0C	Engine uppercarr. OBD Error Metering error Pump is in off mode 325112: check meter, replace if nec.	A750		E	1
8BFB0D	Engine uppercarr. OBD Error Pump temperature and heater error Pump is in Off mode, no measures or pump is in Off mode 325113: No measures, error due to environmental cond.	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFC00	Engine uppercarr. OBD Error Urea tank Heater erroneous (driver) No measures or pump is in off mode 325200: Check plug, wiring, control units	A750		E	1
8BFC01	Engine uppercarr. OBD Error Line heating Urea erroneous (driver) No measures, error due to environmental cond. 325201: Check plug, wiring, control units	A750		E	1
8BFC02	Engine uppercarr. OBD Error Pump heater Urea erroneous (driver) No measures or pump is in off mode 325202:	A750		E	1
8BFC03	Engine uppercarr. OBD Error Urea tank Temperature sensor erroneous No measures, error due to environmental cond. 325203: No measures, error due to environmental cond.	A750		E	1
8BFC04	Engine uppercarr. OBD Error Urea tank Temperature sensor erroneous (OOR MIN) 325204: No measures, error due to environmental cond.	A750		E	1
8BFC05	Engine uppercarr. OBD Error Urea tank fill level sensor erroneous No measures or pump is in off mode 325205: Check plug, wiring, control units	A750		E	1
8BFC06	Engine uppercarr. OBD Error Urea tank fill level sensor erroneous no reaction 325206: No measure	A750		E	1
8BFC07	Engine uppercarr. OBD Error Fill level urea tank threshold 3 Actuation warning lights, possible momentum limitation 325207: Refill urea tank	A750		E	1
8BFC08	Engine uppercarr. OBD Error Fill level urea tank threshold 2 Actuation warning lights, possible momentum limitation 325208: Refill urea tank	A750		E	1
8BFC09	Engine uppercarr. OBD Error Fill level urea tank threshold 1 Actuation warning lights, possible momentum limitation 325209: Refill urea tank	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFC0A	Engine uppercarr. OBD Error Fill level urea tank threshold 0 Actuation warning lights, possible momentum limitation 325210: Refill urea tank	A750		E	1
8BFC0B	Engine uppercarr. OBD Error SCR ECM Error power supply Pump is in Off mode, no measures or pump is in Off mode 325211: Check supply voltage	A750		E	1
8BFC0C	Engine uppercarr. OBD Error SCR ECM Error Temperature Pump is in off mode 325212: No measures, error due to environmental cond.	A750		E	1
8BFC0D	Engine uppercarr. OBD Error SCR ECM CAN communication erroneous No measures or pump is in off mode 325213: Check CAN-connections	A750		E	1
8BFD00	Engine uppercarr. Error Exhaust treatment "AGN" Particle filter "DPF" load status threshold 4 reached Exhaust back pressure/DPF Temperature high 325300: Activate manual regeneration	A750		E	1
8BFD01	Engine uppercarr. Error Exhaust treatment "AGN" Particle filter "DPF" load status threshold 5 reached Exhaust back pressure/DPF Temperature high 325301: Activate Service Regeneration	A750		E	2
8BFE00	Engine uppercarr. OBD Error SCR power supply, Sensor error Engine cannot be started or engine shut off 325400: Check on board network	A750		E	1
8BFE01	Engine uppercarr. OBD Error ECM internal error control unit Engine cannot be started or engine shut off 325401: Load current software, replace engine control unit	A750		E	1
8BFE02	Engine uppercarr. OBD Error CAN-communication (J1939) interrupted Change over to plausible speed source 325402: Check cable / plug / CAN-participant	A750		E	1
8BFE03	Engine uppercarr. OBD Error CAN-communication (J1939) maximum transmission cycle exceeded Possibly power reduction 325403: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFE04	Engine uppercarr. OBD Error Injector 9 erroneous Injector unit is not energized 325404: Check cable, plug, injection unit, engine control unit	A750		E	1
8BFE0D	Engine uppercarr. OBD Error Start block, problem exhaust aftertreatment/fill level urea tank Start lock 325413: Check wiring, exhaust system; check fill level urea, add urea	A750		E	1
8C0116	Engine chassis: Environmental pressure sensor Plausibility error no reaction Check control unit	A700		E	1
8C0164	Engine chassis: Environmental pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C028A	Engine chassis: Air filter Combi sensor (humidity) Determination of the specific humidity faulty no reaction No remedy text	A700		E	1
8C028B	Engine chassis: Air filter Combi sensor (humidity) Determination of the relative humidity faulty no reaction No remedy text	A700		E	1
8C0307	Engine chassis: Air filter Combi sensor (pressure) Value below warning threshold Engine derating 25% (Mach-FL) Check air filter	A700		E	1
8C0393	Engine chassis: Air filter Combi sensor (pressure) Error during pressure measurement (Trican sensor) Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8C0416	Engine chassis: Air filter Combi sensor (temperature) Plausibility error no reaction Check components	A700		E	1
8C0494	Engine chassis: Air filter Combi sensor (temperature) Error during pressure measurement (Trican sensor) Engine reduction 25% (Mach-FL) No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C0505	Engine chassis: Air filter Combi sensor Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C0592	Engine chassis: Air filter Combi sensor Internal temperature error Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8C0603	Engine chassis: Charge air temperature sensor suction pipe short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C0604	Engine chassis: Charge air temperature sensor suction pipe short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C0608	Engine chassis: Charge air temperature sensor suction pipe Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C0609	Engine chassis: Charge air temperature sensor suction pipe Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C060A	Engine chassis: Charge air temperature sensor suction pipe Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C0616	Engine chassis: Charge air temperature sensor suction pipe Plausibility error no reaction Check components	A700		E	1
8C0664	Engine chassis: Charge air temperature sensor suction pipe Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C0703	Engine chassis: charge air pressure sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C0707	Engine chassis: charge air pressure sensor Value below warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8C0709	Engine chassis: charge air pressure sensor Value above warning threshold Engine derating 25% (Mach-FL) Check operation status of engine	A700		E	1
8C070A	Engine chassis: charge air pressure sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A700		E	1
8C070B	Engine chassis: charge air pressure sensor Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C070C	Engine chassis: charge air pressure sensor Value below critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8C0714	Engine chassis: charge air pressure sensor Signal remains below nominal value no reaction Air intake manifold, check wastegate	A700		E	1
8C0715	Engine chassis: charge air pressure sensor Signal remains above nominal value no reaction Air intake manifold, check wastegate	A700		E	1
8C0716	Engine chassis: charge air pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0764	Engine chassis: charge air pressure sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0774	Engine chassis: charge air pressure sensor Lower limit value for regulation reached no reaction Air intake manifold, check wastegate	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C0775	Engine chassis: charge air pressure sensor Upper limit value for regulation reached no reaction Air intake manifold, check wastegate	A700		E	1
8C0803	Engine chassis: Ambient temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C0804	Engine chassis: Ambient temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C0808	Engine chassis: Ambient temperature sensor Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C0816	Engine chassis: Ambient temperature sensor Plausibility error no reaction Check components	A700		E	1
8C0864	Engine chassis: Ambient temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C0903	Engine chassis: coolant temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0904	Engine chassis: coolant temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0908	Engine chassis: coolant temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0909	Engine chassis: coolant temperature sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C090A	Engine chassis: coolant temperature sensor Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C0916	Engine chassis: coolant temperature sensor Plausibility error no reaction Check components	A700		E	1
8C0964	Engine chassis: coolant temperature sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0A03	Engine chassis: Coolant level sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C0A07	Engine chassis: Coolant level sensor Value below warning threshold no reaction Check coolant level	A700		E	1
8C0A0B	Engine chassis: Coolant level sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C0A21	Engine chassis: Coolant level sensor Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8C0A64	Engine chassis: Coolant level sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C0B04	Engine chassis: Rail pressure sensor short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0B09	Engine chassis: Rail pressure sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C0B0A	Engine chassis: Rail pressure sensor Value above critical threshold Engine derating 50% (Mach-FL) Check operation status of engine	A700		E	1
8C0B0D	Engine chassis: Rail pressure sensor Short circuit after supply voltage or line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0B0E	Engine chassis: Rail pressure sensor Signal increases too fast no reaction Check wiring between control unit and components	A700		E	1
8C0B0F	Engine chassis: Rail pressure sensor Signal decreases too fast no reaction Check wiring between control unit and components	A700		E	1
8C0B10	Engine chassis: Rail pressure sensor Start pressure too low no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A700		E	1
8C0B11	Engine chassis: Rail pressure sensor Signal noise too high no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A700		E	1
8C0B12	Engine chassis: Rail pressure sensor No signal dynamics Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0B13	Engine chassis: Rail pressure sensor Leakage no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A700		E	1
8C0B14	Engine chassis: Rail pressure sensor Signal remains below nominal value Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A700		E	1
8C0B15	Engine chassis: Rail pressure sensor Signal remains above nominal value Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C0B16	Engine chassis: Rail pressure sensor Plausibility error no reaction No remedy text	A700		E	1
8C0B21	Engine chassis: Rail pressure sensor Voltage outside permissible range no reaction No remedy text	A700		E	1
8C0B64	Engine chassis: Rail pressure sensor Error supply voltage sensors Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0C14	Engine chassis: Fuel supply valve (VCV) flow regulation Signal remains below nominal value no reaction Check wiring, components, control unit	A700		E	1
8C0C15	Engine chassis: Fuel supply valve (VCV) flow regulation Signal remains above nominal value no reaction Check wiring, components, control unit	A700		E	1
8C0C16	Engine chassis: Fuel supply valve (VCV) flow regulation Plausibility error Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A700		E	1
8C0D03	Engine chassis: Fuel pressure sensor (low pressure system) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C0D07	Engine chassis: Fuel pressure sensor (low pressure system) Value below warning threshold no reaction Check operation status of engine	A700		E	1
8C0D09	Engine chassis: Fuel pressure sensor (low pressure system) Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C0D0A	Engine chassis: Fuel pressure sensor (low pressure system) Value above critical threshold no reaction Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C0D0B	Engine chassis: Fuel pressure sensor (low pressure system) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C0D0C	Engine chassis: Fuel pressure sensor (low pressure system) Value below critical threshold no reaction Check operation status of engine	A700		E	1
8C0D64	Engine chassis: Fuel pressure sensor (low pressure system) Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C0E03	Engine chassis: Fuel temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0E04	Engine chassis: Fuel temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0E08	Engine chassis: Fuel temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C0E09	Engine chassis: Fuel temperature sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C0E0A	Engine chassis: Fuel temperature sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A700		E	1
8C0E16	Engine chassis: Fuel temperature sensor Plausibility error no reaction Check components	A700		E	1
8C0E64	Engine chassis: Fuel temperature sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C0F03	Engine chassis: Oil level sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C0F07	Engine chassis: Oil level sensor Value below warning threshold no reaction Check oil level, oil level sensor, engine must be at incline 0degrees	A700		E	1
8C0F09	Engine chassis: Oil level sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C0F0B	Engine chassis: Oil level sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C0F0C	Engine chassis: Oil level sensor Value below critical threshold no reaction Check oil level, oil level sensor, engine must be at incline 0degrees	A700		E	1
8C0F64	Engine chassis: Oil level sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C1003	Engine chassis: oil pressure sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C1007	Engine chassis: oil pressure sensor Value below warning threshold no reaction Check operation status of engine	A700		E	1
8C100B	Engine chassis: oil pressure sensor Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C100C	Engine chassis: oil pressure sensor Value below critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1016	Engine chassis: oil pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check operation status of engine	A700		E	1
8C1064	Engine chassis: oil pressure sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C1103	Engine chassis: oil temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1104	Engine chassis: oil temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1108	Engine chassis: oil temperature sensor Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C1109	Engine chassis: oil temperature sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C110A	Engine chassis: oil temperature sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A700		E	1
8C110B	Engine chassis: oil temperature sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C1116	Engine chassis: oil temperature sensor Plausibility error no reaction No remedy text	A700		E	1
8C1164	Engine chassis: oil temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1203	Engine chassis: Water level probe fuel filter short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1204	Engine chassis: Water level probe fuel filter short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1208	Engine chassis: Water level probe fuel filter Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C120A	Engine chassis: Water level probe fuel filter Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A700		E	1
8C1221	Engine chassis: Water level probe fuel filter Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8C1264	Engine chassis: Water level probe fuel filter Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C1303	Engine chassis: Rpm sensor camshaft short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1304	Engine chassis: Rpm sensor camshaft short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1308	Engine chassis: Rpm sensor camshaft Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C1316	Engine chassis: Rpm sensor camshaft Plausibility error no reaction Check rpm sensors	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1364	Engine chassis: Rpm sensor camshaft Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8C1385	Engine chassis: Rpm sensor camshaft Error in the ground supply Engine reduction 50% (Mach-FL) Check wiring between control unit and component - B713	A700		E	1
8C1403	Engine chassis: Rpm sensor crankshaft short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C1404	Engine chassis: Rpm sensor crankshaft short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C1408	Engine chassis: Rpm sensor crankshaft Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C1416	Engine chassis: Rpm sensor crankshaft Plausibility error Engine derating 25% (Mach-FL) Check rpm sensors	A700		E	1
8C1464	Engine chassis: Rpm sensor crankshaft Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8C1485	Engine chassis: Rpm sensor crankshaft Error in the ground supply Engine reduction 50% (Mach-FL) Check wiring between control unit and component - B711	A700		E	1
8C1509	Engine chassis: Engine speed Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C150A	Engine chassis: Engine speed Value above critical threshold no reaction Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1598	Engine chassis: Engine speed No rpm detected with actuated starter no reaction Check wiring, starter	A700		E	1
8C1603	Engine chassis: Status Heat flange 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1604	Engine chassis: Status Heat flange 1 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1608	Engine chassis: Status Heat flange 1 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C166D	Engine chassis: Status Heat flange 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C166E	Engine chassis: Status Heat flange 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C166F	Engine chassis: Status Heat flange 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1670	Engine chassis: Status Heat flange 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1703	Engine chassis: Heat flange 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1704	Engine chassis: Heat flange 1 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1708	Engine chassis: Heat flange 1 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C176C	Engine chassis: Heat flange 1 Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C176D	Engine chassis: Heat flange 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C176E	Engine chassis: Heat flange 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C176F	Engine chassis: Heat flange 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1770	Engine chassis: Heat flange 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1782	Engine chassis: Heat flange 1 Output current too high no reaction Check wiring between control unit and component - E703	A700		E	1
8C1803	Engine chassis: Status Heat flange 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1804	Engine chassis: Status Heat flange 2 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1808	Engine chassis: Status Heat flange 2 Line interruption no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C186D	Engine chassis: Status Heat flange 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C186E	Engine chassis: Status Heat flange 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C186F	Engine chassis: Status Heat flange 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1870	Engine chassis: Status Heat flange 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1903	Engine chassis: Heat flange 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1904	Engine chassis: Heat flange 2 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1908	Engine chassis: Heat flange 2 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C196C	Engine chassis: Heat flange 2 Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C196D	Engine chassis: Heat flange 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C196E	Engine chassis: Heat flange 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C196F	Engine chassis: Heat flange 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1970	Engine chassis: Heat flange 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1982	Engine chassis: Heat flange 2 Output current too high no reaction Check wiring between control unit and component - E704	A700		E	1
8C1A03	Engine chassis: Urea (AdBlue) Tank heater valve short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1A04	Engine chassis: Urea (AdBlue) Tank heater valve short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1A08	Engine chassis: Urea (AdBlue) Tank heater valve Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C1A49	Engine chassis: Urea (AdBlue) Tank heater valve Error blocked open no reaction Check components	A700		E	1
8C1A4A	Engine chassis: Urea (AdBlue) Tank heater valve Error blocked closed no reaction Check components	A700		E	1
8C1A6C	Engine chassis: Urea (AdBlue) Tank heater valve Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C1A6D	Engine chassis: Urea (AdBlue) Tank heater valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1A6E	Engine chassis: Urea (AdBlue) Tank heater valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1A6F	Engine chassis: Urea (AdBlue) Tank heater valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1A70	Engine chassis: Urea (AdBlue) Tank heater valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1A82	Engine chassis: Urea (AdBlue) Tank heater valve Output current too high no reaction Check wiring between control unit and component - Y770	A700		E	1
8C1B03	Engine chassis: Urea (AdBlue) Pump heater valve short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1B04	Engine chassis: Urea (AdBlue) Pump heater valve short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1B08	Engine chassis: Urea (AdBlue) Pump heater valve Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C1B49	Engine chassis: Urea (AdBlue) Pump heater valve Error blocked open no reaction Check components	A700		E	1
8C1B4A	Engine chassis: Urea (AdBlue) Pump heater valve Error blocked closed no reaction Check components	A700		E	1
8C1B6C	Engine chassis: Urea (AdBlue) Pump heater valve Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1B6D	Engine chassis: Urea (AdBlue) Pump heater valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1B6E	Engine chassis: Urea (AdBlue) Pump heater valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1B6F	Engine chassis: Urea (AdBlue) Pump heater valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1B70	Engine chassis: Urea (AdBlue) Pump heater valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1B82	Engine chassis: Urea (AdBlue) Pump heater valve Output current too high no reaction Check wiring between control unit and component - Y770	A700		E	1
8C1C03	Engine chassis: Urea (AdBlue) Hose heater 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1C04	Engine chassis: Urea (AdBlue) Hose heater 1 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1C08	Engine chassis: Urea (AdBlue) Hose heater 1 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C1C6C	Engine chassis: Urea (AdBlue) Hose heater 1 Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C1C6D	Engine chassis: Urea (AdBlue) Hose heater 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1C6E	Engine chassis: Urea (AdBlue) Hose heater 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1C6F	Engine chassis: Urea (AdBlue) Hose heater 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1C70	Engine chassis: Urea (AdBlue) Hose heater 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1C82	Engine chassis: Urea (AdBlue) Hose heater 1 Output current too high no reaction Check wiring between control unit and component - E770	A700		E	1
8C1D03	Engine chassis: Urea (AdBlue) Hose heater 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1D04	Engine chassis: Urea (AdBlue) Hose heater 2 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C1D08	Engine chassis: Urea (AdBlue) Hose heater 2 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C1D6C	Engine chassis: Urea (AdBlue) Hose heater 2 Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C1D6D	Engine chassis: Urea (AdBlue) Hose heater 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1D6E	Engine chassis: Urea (AdBlue) Hose heater 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1D6F	Engine chassis: Urea (AdBlue) Hose heater 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C1D70	Engine chassis: Urea (AdBlue) Hose heater 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C1D82	Engine chassis: Urea (AdBlue) Hose heater 2 Output current too high no reaction Check wiring between control unit and component - E771	A700		E	1
8C1E03	Engine chassis: SCR Urea (AdBlue) pressure sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C1E0B	Engine chassis: SCR Urea (AdBlue) pressure sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C1E14	Engine chassis: SCR Urea (AdBlue) pressure sensor Signal remains below nominal value no reaction Check SCR-System	A700		E	1
8C1E16	Engine chassis: SCR Urea (AdBlue) pressure sensor Plausibility error no reaction Check components	A700		E	1
8C1E26	Engine chassis: SCR Urea (AdBlue) pressure sensor Urea (AdBlue) line filling failed Inducement system activation (Mach-FL) Check SCR-System	A700		E	1
8C1E2B	Engine chassis: SCR Urea (AdBlue) pressure sensor Urea pressure too low (Plausibility vent valve open) Inducement system activation (Mach-FL) Check urea pump, turn ignition off / on	A700		E	1
8C1E64	Engine chassis: SCR Urea (AdBlue) pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C1E75	Engine chassis: SCR Urea (AdBlue) pressure sensor Upper limit value for regulation reached no reaction Check SCR System	A700		E	1
8C1F03	Engine chassis: SCR Urea (AdBlue) temperature sensor short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C1F04	Engine chassis: SCR Urea (AdBlue) temperature sensor short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C1F08	Engine chassis: SCR Urea (AdBlue) temperature sensor Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C1F09	Engine chassis: SCR Urea (AdBlue) temperature sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C1F0A	Engine chassis: SCR Urea (AdBlue) temperature sensor Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C1F16	Engine chassis: SCR Urea (AdBlue) temperature sensor Plausibility error no reaction Check components	A700		E	1
8C1F64	Engine chassis: SCR Urea (AdBlue) temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C2003	Engine chassis: SCR Urea (AdBlue) pump short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C2004	Engine chassis: SCR Urea (AdBlue) pump short circuit to ground no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2008	Engine chassis: SCR Urea (AdBlue) pump Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C2017	Engine chassis: SCR Urea (AdBlue) pump Short circuit of load no reaction Check wiring between control unit and components	A700		E	1
8C206C	Engine chassis: SCR Urea (AdBlue) pump Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C206D	Engine chassis: SCR Urea (AdBlue) pump Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C206E	Engine chassis: SCR Urea (AdBlue) pump Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C206F	Engine chassis: SCR Urea (AdBlue) pump Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C2070	Engine chassis: SCR Urea (AdBlue) pump Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C2082	Engine chassis: SCR Urea (AdBlue) pump Output current too high Engine reduction (Mach-FL) Check wiring between control unit and component - A776.X1	A700		E	1
8C2103	Engine chassis: SCR vent valve short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C2104	Engine chassis: SCR vent valve short circuit to ground no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2108	Engine chassis: SCR vent valve Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C216C	Engine chassis: SCR vent valve Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C216D	Engine chassis: SCR vent valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C216E	Engine chassis: SCR vent valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C216F	Engine chassis: SCR vent valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C2170	Engine chassis: SCR vent valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C2182	Engine chassis: SCR vent valve Output current too high Engine reduction (Mach-FL) Check wiring between control unit and component - A776.X2	A700		E	1
8C2203	Engine chassis: SCR connection compressed air short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C2204	Engine chassis: SCR connection compressed air short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C2208	Engine chassis: SCR connection compressed air Line interruption no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2217	Engine chassis: SCR connection compressed air Short circuit of load no reaction Check wiring between control unit and components	A700		E	1
8C226C	Engine chassis: SCR connection compressed air Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C226D	Engine chassis: SCR connection compressed air Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C226E	Engine chassis: SCR connection compressed air Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C226F	Engine chassis: SCR connection compressed air Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C2270	Engine chassis: SCR connection compressed air Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C2282	Engine chassis: SCR connection compressed air Output current too high Engine reduction (Mach-FL) Check wiring between control unit and component - A709	A700		E	1
8C2303	Engine chassis: SCR Air pressure sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C230B	Engine chassis: SCR Air pressure sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C2316	Engine chassis: SCR Air pressure sensor Plausibility error no reaction Check components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2328	Engine chassis: SCR Air pressure sensor Pressure too high when connecting compressed air Inducement system activation (Mach-FL) Check SCR-System	A700		E	1
8C2329	Engine chassis: SCR Air pressure sensor Pressure too low when connecting compressed air Inducement system activation (Mach-FL) Check connections, air pump, urea pump, injector, replace components	A700		E	1
8C2364	Engine chassis: SCR Air pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C2401	Engine chassis: Urea (AdBlue)-Tank Temperature sensor Value above max. test range no reaction Check wiring between control unit and components	A700		E	1
8C2402	Engine chassis: Urea (AdBlue)-Tank Temperature sensor Value below min. test range no reaction Check wiring between control unit and components	A700		E	1
8C2408	Engine chassis: Urea (AdBlue)-Tank Temperature sensor Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C2409	Engine chassis: Urea (AdBlue)-Tank Temperature sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C2416	Engine chassis: Urea (AdBlue)-Tank Temperature sensor Plausibility error no reaction Check components	A700		E	1
8C2418	Engine chassis: Urea (AdBlue)-Tank Temperature sensor Short circuit no reaction Check wiring between control unit and components	A700		E	1
8C2501	Engine chassis: Urea (AdBlue)-Tank Fill level sensor Value above max. test range no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2502	Engine chassis: Urea (AdBlue)-Tank Fill level sensor Value below min. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2508	Engine chassis: Urea (AdBlue)-Tank Fill level sensor Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2518	Engine chassis: Urea (AdBlue)-Tank Fill level sensor Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2519	Engine chassis: Urea (AdBlue)-Tank Fill level sensor Fill level low Inducement system activation (Mach-FL) Refill urea tank	A700		E	1
8C2605	Engine chassis: Urea (AdBlue)-Tank Sampling unit Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C2701	Engine chassis: Urea (AdBlue)-Tank Quality sensor Value above max. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2702	Engine chassis: Urea (AdBlue)-Tank Quality sensor Value below min. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2746	Engine chassis: Urea (AdBlue)-Tank Quality sensor Optical error Inducement system activation (Mach-FL) Check components	A700		E	1
8C2803	Engine chassis: Battery temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C2804	Engine chassis: Battery temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2808	Engine chassis: Battery temperature sensor Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C2816	Engine chassis: Battery temperature sensor Plausibility error no reaction Check components	A700		E	1
8C2864	Engine chassis: Battery temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C2901	Engine chassis: Exhaust temperature sensor (before SCR) Value above max. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2903	Engine chassis: Exhaust temperature sensor (before SCR) short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2904	Engine chassis: Exhaust temperature sensor (before SCR) short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2908	Engine chassis: Exhaust temperature sensor (before SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2909	Engine chassis: Exhaust temperature sensor (before SCR) Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C290A	Engine chassis: Exhaust temperature sensor (before SCR) Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C2916	Engine chassis: Exhaust temperature sensor (before SCR) Plausibility error Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C291B	Engine chassis: Exhaust temperature sensor (before SCR) Invalid data no reaction Check wiring, sensor	A700		E	1
8C2964	Engine chassis: Exhaust temperature sensor (before SCR) Error supply voltage sensors Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2A01	Engine chassis: Exhaust temperature sensor (after SCR) Value above max. test range no reaction Check wiring between control unit and components	A700		E	1
8C2A02	Engine chassis: Exhaust temperature sensor (after SCR) Value below min. test range no reaction Check wiring between control unit and components	A700		E	1
8C2A03	Engine chassis: Exhaust temperature sensor (after SCR) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C2A04	Engine chassis: Exhaust temperature sensor (after SCR) short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C2A08	Engine chassis: Exhaust temperature sensor (after SCR) Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C2A09	Engine chassis: Exhaust temperature sensor (after SCR) Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C2A0A	Engine chassis: Exhaust temperature sensor (after SCR) Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C2A16	Engine chassis: Exhaust temperature sensor (after SCR) Plausibility error no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2A1B	Engine chassis: Exhaust temperature sensor (after SCR) Invalid data no reaction Check wiring, sensor	A700		E	1
8C2A64	Engine chassis: Exhaust temperature sensor (after SCR) Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C2B03	Engine chassis: Hydraulic oil temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2B04	Engine chassis: Hydraulic oil temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2B08	Engine chassis: Hydraulic oil temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2B09	Engine chassis: Hydraulic oil temperature sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C2B0A	Engine chassis: Hydraulic oil temperature sensor Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C2B64	Engine chassis: Hydraulic oil temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C2C03	Engine chassis: Starter short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C2C04	Engine chassis: Starter short circuit to ground no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2C08	Engine chassis: Starter Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C2C6C	Engine chassis: Starter Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C2C6D	Engine chassis: Starter Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C2C6E	Engine chassis: Starter Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C2C6F	Engine chassis: Starter Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C2C70	Engine chassis: Starter Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C2C7C	Engine chassis: Starter Blocked due to excess temperature no reaction No remedy text	A700		E	1
8C2C82	Engine chassis: Starter Output current too high no reaction Check wiring between control unit and component - M700	A700		E	1
8C2E03	Engine chassis: Wastegate flap 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2E04	Engine chassis: Wastegate flap 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2E05	Engine chassis: Wastegate flap 1 Communication error no reaction Check wiring, flaps	A700		E	1
8C2E08	Engine chassis: Wastegate flap 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2E0A	Engine chassis: Wastegate flap 1 Value above critical threshold no reaction Check wiring, flaps	A700		E	1
8C2E17	Engine chassis: Wastegate flap 1 Short circuit of load Engine reduction 25% (Mach-FL) Check wiring between control unit and component - Y705	A700		E	1
8C2E34	Engine chassis: Wastegate flap 1 Hardware Error no reaction Check wiring, flaps	A700		E	1
8C2E36	Engine chassis: Wastegate flap 1 Calibration error no reaction Check wiring, flaps	A700		E	1
8C2E38	Engine chassis: Wastegate flap 1 Error Regulation deviation no reaction Check wiring, flaps	A700		E	1
8C2E39	Engine chassis: Wastegate flap 1 Error Absolute position no reaction Check wiring, flaps	A700		E	1
8C2E64	Engine chassis: Wastegate flap 1 Error supply voltage sensors no reaction Check wiring, flaps	A700		E	1
8C2E6C	Engine chassis: Wastegate flap 1 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2E6D	Engine chassis: Wastegate flap 1 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2E6E	Engine chassis: Wastegate flap 1 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2E6F	Engine chassis: Wastegate flap 1 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2E70	Engine chassis: Wastegate flap 1 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2E81	Engine chassis: Wastegate flap 1 Position feedback not available no reaction Check wiring, flaps	A700		E	1
8C2E82	Engine chassis: Wastegate flap 1 Output current too high Engine reduction 25% (Mach-FL) Check wiring between control unit and component - Y705	A700		E	1
8C2F03	Engine chassis: Fuel supply valve 1 (VCV) short circuit to supply voltage Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2F04	Engine chassis: Fuel supply valve 1 (VCV) short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2F08	Engine chassis: Fuel supply valve 1 (VCV) Line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2F0A	Engine chassis: Fuel supply valve 1 (VCV) Value above critical threshold no reaction Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2F0C	Engine chassis: Fuel supply valve 1 (VCV) Value below critical threshold no reaction Check operation status of engine	A700		E	1
8C2F15	Engine chassis: Fuel supply valve 1 (VCV) Signal remains above nominal value no reaction Check wiring, components, control unit	A700		E	1
8C2F17	Engine chassis: Fuel supply valve 1 (VCV) Short circuit of load Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2F52	Engine chassis: Fuel supply valve 1 (VCV) PWM plausibility no reaction Check components	A700		E	1
8C2F6C	Engine chassis: Fuel supply valve 1 (VCV) Reg. deviation current value Engine derating 50% (Mach-FL) Report all error parameters to Service	A700		E	1
8C2F6D	Engine chassis: Fuel supply valve 1 (VCV) Short circuit after supply voltage Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2F6E	Engine chassis: Fuel supply valve 1 (VCV) Short circuit after supply voltage ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2F6F	Engine chassis: Fuel supply valve 1 (VCV) Short circuit after ground Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2F70	Engine chassis: Fuel supply valve 1 (VCV) Short circuit after ground, ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C2F74	Engine chassis: Fuel supply valve 1 (VCV) Lower limit value for regulation reached no reaction No measure required	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C2F82	Engine chassis: Fuel supply valve 1 (VCV) Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y703	A700		E	1
8C3003	Engine chassis: Fuel high pressure regulating valve 1 (PCV) short circuit to supply voltage Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3004	Engine chassis: Fuel high pressure regulating valve 1 (PCV) short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3008	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C300A	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C300C	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Value below critical threshold no reaction Check operation status of engine	A700		E	1
8C300E	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Signal increases too fast no reaction Check components	A700		E	1
8C300F	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Signal decreases too fast no reaction Check components	A700		E	1
8C3015	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Signal remains above nominal value no reaction Check wiring, components, control unit	A700		E	1
8C3017	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Short circuit of load Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C301D	Engine chassis: Fuel high pressure regulating valve 1 (PCV) PCV Flow regulation upper stop no reaction Check components	A700		E	1
8C301E	Engine chassis: Fuel high pressure regulating valve 1 (PCV) PCV Flow regulation lower stop no reaction Check components	A700		E	1
8C3052	Engine chassis: Fuel high pressure regulating valve 1 (PCV) PWM plausibility no reaction Check components	A700		E	1
8C305D	Engine chassis: Fuel high pressure regulating valve 1 (PCV) PCV open due to excess pressure no reaction Check operation status of engine	A700		E	1
8C306C	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Reg. deviation current value Engine derating 50% (Mach-FL) Report all error parameters to Service	A700		E	1
8C306D	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Short circuit after supply voltage Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C306E	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Short circuit after supply voltage ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C306F	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Short circuit after ground Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3070	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Short circuit after ground, ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3074	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Lower limit value for regulation reached no reaction No measure required	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3082	Engine chassis: Fuel high pressure regulating valve 1 (PCV) Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y707	A700		E	1
8C3105	Engine chassis: Exhaust return valve 1 Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C3121	Engine chassis: Exhaust return valve 1 Voltage outside permissible range Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3133	Engine chassis: Exhaust return valve 1 Data transfer CAN problematic Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C3134	Engine chassis: Exhaust return valve 1 Hardware Error Engine derating 25% (Mach-FL) Check module	A700		E	1
8C3135	Engine chassis: Exhaust return valve 1 Excess temperature error Engine derating 25% (Mach-FL) Check cooling of module	A700		E	1
8C3136	Engine chassis: Exhaust return valve 1 Calibration error Engine derating 25% (Mach-FL) Check module	A700		E	1
8C3137	Engine chassis: Exhaust return valve 1 Error Reference position Engine derating 25% (Mach-FL) Check module	A700		E	1
8C3138	Engine chassis: Exhaust return valve 1 Error Regulation deviation Engine derating 25% (Mach-FL) Check components	A700		E	1
8C3139	Engine chassis: Exhaust return valve 1 Error Absolute position Engine derating 25% (Mach-FL) Check module	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3181	Engine chassis: Exhaust return valve 1 Position feedback not available Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8C3303	Engine chassis: Injector 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3304	Engine chassis: Injector 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3308	Engine chassis: Injector 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C331F	Engine chassis: Injector 1 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3320	Engine chassis: Injector 1 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3383	Engine chassis: Injector 1 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C3386	Engine chassis: Injector 1 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C3387	Engine chassis: Injector 1 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C3403	Engine chassis: Injector 2 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3404	Engine chassis: Injector 2 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3408	Engine chassis: Injector 2 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C341F	Engine chassis: Injector 2 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3420	Engine chassis: Injector 2 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3483	Engine chassis: Injector 2 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C3486	Engine chassis: Injector 2 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C3487	Engine chassis: Injector 2 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C3503	Engine chassis: Injector 3 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3504	Engine chassis: Injector 3 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3508	Engine chassis: Injector 3 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C351F	Engine chassis: Injector 3 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3520	Engine chassis: Injector 3 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3583	Engine chassis: Injector 3 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C3586	Engine chassis: Injector 3 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C3587	Engine chassis: Injector 3 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C3603	Engine chassis: Injector 4 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3604	Engine chassis: Injector 4 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3608	Engine chassis: Injector 4 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C361F	Engine chassis: Injector 4 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3620	Engine chassis: Injector 4 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3683	Engine chassis: Injector 4 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C3686	Engine chassis: Injector 4 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C3687	Engine chassis: Injector 4 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C3703	Engine chassis: Injector 5 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3704	Engine chassis: Injector 5 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3708	Engine chassis: Injector 5 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C371F	Engine chassis: Injector 5 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3720	Engine chassis: Injector 5 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3783	Engine chassis: Injector 5 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C3786	Engine chassis: Injector 5 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3787	Engine chassis: Injector 5 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C3803	Engine chassis: Injector 6 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3804	Engine chassis: Injector 6 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3808	Engine chassis: Injector 6 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C381F	Engine chassis: Injector 6 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3820	Engine chassis: Injector 6 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3883	Engine chassis: Injector 6 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C3886	Engine chassis: Injector 6 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C3887	Engine chassis: Injector 6 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C3903	Engine chassis: Injector 7 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3904	Engine chassis: Injector 7 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3908	Engine chassis: Injector 7 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C391F	Engine chassis: Injector 7 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3920	Engine chassis: Injector 7 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3983	Engine chassis: Injector 7 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C3986	Engine chassis: Injector 7 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C3987	Engine chassis: Injector 7 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C3A03	Engine chassis: Injector 8 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3A04	Engine chassis: Injector 8 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3A08	Engine chassis: Injector 8 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3A1F	Engine chassis: Injector 8 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3A20	Engine chassis: Injector 8 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A700		E	1
8C3A83	Engine chassis: Injector 8 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C3A86	Engine chassis: Injector 8 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C3A87	Engine chassis: Injector 8 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C3B03	Engine chassis: Travel pedal sensor 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C3B0B	Engine chassis: Travel pedal sensor 1 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C3C03	Engine chassis: Travel pedal sensor 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C3C0B	Engine chassis: Travel pedal sensor 2 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C3D16	Engine chassis: Travel pedal sensor Plausibility error no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3E03	Engine chassis: Fan 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3E04	Engine chassis: Fan 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3E08	Engine chassis: Fan 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3E17	Engine chassis: Fan 1 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3E6C	Engine chassis: Fan 1 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A700		E	1
8C3E6D	Engine chassis: Fan 1 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3E6E	Engine chassis: Fan 1 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3E6F	Engine chassis: Fan 1 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3E70	Engine chassis: Fan 1 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3E82	Engine chassis: Fan 1 Output current too high no reaction Check wiring between control unit and component - Y718	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C3F03	Engine chassis: Fan 2 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3F04	Engine chassis: Fan 2 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3F08	Engine chassis: Fan 2 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3F17	Engine chassis: Fan 2 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3F6C	Engine chassis: Fan 2 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A700		E	1
8C3F6D	Engine chassis: Fan 2 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3F6E	Engine chassis: Fan 2 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3F6F	Engine chassis: Fan 2 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3F70	Engine chassis: Fan 2 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C3F82	Engine chassis: Fan 2 Output current too high no reaction Check wiring between control unit and component - Y719	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C4003	Engine chassis: Alternator 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C4004	Engine chassis: Alternator 1 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C4221	Engine chassis: Motor Sensor supply U_VCC-M1 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4321	Engine chassis: Motor Sensor supply U_VCC-M2 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4421	Engine chassis: Motor Sensor supply U_VCC-M3 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4521	Engine chassis: Motor Sensor supply U_VCC-M4 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4621	Engine chassis: Motor Sensor supply U_VCC-M5 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4721	Engine chassis: Motor Sensor supply U_VCC-M6 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4821	Engine chassis: Motor Sensor supply U_VCC-M7 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4921	Engine chassis: Machine Sensor supply U_VCC-G1 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C4A21	Engine chassis: Machine Sensor supply U_VCC-G2 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4B21	Engine chassis: Machine Sensor supply U_VCC-G3 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A700		E	1
8C4C21	Engine chassis: Motor Sensor supply U_UBATT-M1 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C4D21	Engine chassis: Motor Sensor supply U_UBATT-M2 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C4E21	Engine chassis: Machine Sensor supply U_UBATT-G1 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C4F21	Engine chassis: Machine Sensor supply U_UBATT-G2 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C5021	Engine chassis: Machine Sensor supply U_UBATT-G3 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C5121	Engine chassis: Machine Sensor supply U_UBATT-G4 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C5221	Engine chassis: Machine Sensor supply U_UBATT-G5 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C5321	Engine chassis: Internal Sensor supply U_VCC_SENSOR 1 Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C5421	Engine chassis: Internal Sensor supply U_VDD_SENSOR 2 Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C5521	Engine chassis: Internal Sensor supply U_BATT_SENSOR (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C5621	Engine chassis: Temperature sensor supply U_TI_VCC_5V Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A700		E	1
8C5722	Engine chassis: Injection time Pre-injection before injection too close to pre-injection no reaction 0	A700		E	1
8C5723	Engine chassis: Injection time Pre-injector too close to main injection no reaction 0	A700		E	1
8C5724	Engine chassis: Injection time Post-injection too close to main injection no reaction 0	A700		E	1
8C5725	Engine chassis: Injection time Late post-injection too close to post-injection no reaction 0	A700		E	1
8C5814	Engine chassis: SCR System (pressure air pump) Signal remains below nominal value Inducement system activation (Mach-FL) Check SCR-System	A700		E	1
8C582C	Engine chassis: SCR System (pressure air pump) Status erroneous Inducement system activation (Mach-FL) 1) check lines for air supply 2) check fuse for air pump 3) check air supply system	A700		E	1
8C5927	Engine chassis: SCR System Urea (AdBlue) nozzle plugged Inducement system activation (Mach-FL) Check SCR-System	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C592A	Engine chassis: SCR System Interruption of ventilation procedure no reaction Check components	A700		E	1
8C5931	Engine chassis: SCR System Bad efficiency of NOX-reduction no reaction Check SCR-System	A700		E	1
8C5932	Engine chassis: SCR System Very bad efficiency of NOX-reduction Inducement system activation (Mach-FL) Check SCR-System	A700		E	1
8C596B	Engine chassis: SCR System Last venting of AdBlue line interrupted no reaction Report all error parameters to Service	A700		E	1
8C5984	Engine chassis: SCR System Air and urea pressure sensors on the urea pump reversed Engine reduction (Mach-FL) No remedy text	A700		E	1
8C5990	Engine chassis: SCR System Cleaning of SCR catalytic converter (HC) not feasible no reaction No remedy text	A700		E	1
8C599F	Engine chassis: SCR System Maximum urea thawing time (AdBlue) exceeded no reaction Check wiring, sensors, heating circuit	A700		E	1
8C5A08	Engine chassis: NOX Sensor (before SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C5A18	Engine chassis: NOX Sensor (before SCR) Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C5A1B	Engine chassis: NOX Sensor (before SCR) Invalid data Inducement system activation (Mach-FL) Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C5A2E	Engine chassis: NOX Sensor (before SCR) Sensor removed from exhaust line Inducement system activation (Mach-FL) Check components	A700		E	1
8C5A2F	Engine chassis: NOX Sensor (before SCR) Heating element broken Inducement system activation (Mach-FL) Check wiring, replace components	A700		E	1
8C5A30	Engine chassis: NOX Sensor (before SCR) Offset Error Inducement system activation (Mach-FL) Check operation status of engine	A700		E	1
8C5B05	Engine chassis: NOX Sensor (after SCR) Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C5B08	Engine chassis: NOX Sensor (after SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C5B18	Engine chassis: NOX Sensor (after SCR) Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C5B1B	Engine chassis: NOX Sensor (after SCR) Invalid data Inducement system activation (Mach-FL) Check operation status of engine	A700		E	1
8C5B2E	Engine chassis: NOX Sensor (after SCR) Sensor removed from exhaust line Inducement system activation (Mach-FL) Check wiring, replace components	A700		E	1
8C5B2F	Engine chassis: NOX Sensor (after SCR) Heating element broken Inducement system activation (Mach-FL) Check wiring, replace components	A700		E	1
8C5B30	Engine chassis: NOX Sensor (after SCR) Offset Error Inducement system activation (Mach-FL) Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C5C01	Engine chassis: Regulation alternator (voltage signal) Value above max. test range no reaction Check wiring between control unit and components	A700		E	1
8C5C06	Engine chassis: Regulation alternator (voltage signal) internal error no reaction Check components	A700		E	1
8C5C38	Engine chassis: Regulation alternator (voltage signal) Error Regulation deviation no reaction Check components	A700		E	1
8C5C4E	Engine chassis: Regulation alternator (voltage signal) Overload no reaction Check components	A700		E	1
8C5C4F	Engine chassis: Regulation alternator (voltage signal) Error when engine running no reaction Check components	A700		E	1
8C5C50	Engine chassis: Regulation alternator (voltage signal) Error intelligent alternator no reaction Check components	A700		E	1
8C5C51	Engine chassis: Regulation alternator (voltage signal) Fuse defective no reaction Check components	A700		E	1
8C5C88	Engine chassis: Regulation alternator (voltage signal) Alternating control deviation alternator voltage no reaction No remedy text	A700		E	1
8C5C89	Engine chassis: Regulation alternator (voltage signal) Alternator shut-off faulty no reaction No remedy text	A700		E	1
8C5D16	Engine chassis: Air filter monitor pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C5F05	Engine chassis: NOX Sensor Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C5F2D	Engine chassis: NOX Sensor Installation error Inducement system activation (Mach-FL) Check installation, position of sensors	A700		E	1
8C5F8F	Engine chassis: NOX Sensor Deviating measuring accuracy (drift) no reaction Check sensor value, sensor	A700		E	1
8C6003	Engine chassis: Distributor gear temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C6004	Engine chassis: Distributor gear temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C6008	Engine chassis: Distributor gear temperature sensor Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C6009	Engine chassis: Distributor gear temperature sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C600A	Engine chassis: Distributor gear temperature sensor Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C6064	Engine chassis: Distributor gear temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C6103	Engine chassis: Supply relay Engine sensory short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C6104	Engine chassis: Supply relay Engine sensory short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C6108	Engine chassis: Supply relay Engine sensory Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C616C	Engine chassis: Supply relay Engine sensory Reg. deviation current value Inducement system activation (Mach-FL) Report all error parameters to Service	A700		E	1
8C616D	Engine chassis: Supply relay Engine sensory Short circuit after supply voltage Plus switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C616E	Engine chassis: Supply relay Engine sensory Short circuit after supply voltage ground switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C616F	Engine chassis: Supply relay Engine sensory Short circuit after ground Plus switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C6170	Engine chassis: Supply relay Engine sensory Short circuit after ground, ground switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C6182	Engine chassis: Supply relay Engine sensory Output current too high Engine reduction (Mach-FL) Check wiring between control unit and component - K700	A700		E	1
8C6233	Engine chassis: AMET CAN (CAN ID 585) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6333	Engine chassis: AMET CAN (CAN ID 594) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C6433	Engine chassis: BAUMA CAN Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C647E	Engine chassis: BAUMA CAN invalid I/O configuration, master file no reaction Check I/O-Config file on Master Flash card	A700		E	1
8C6533	Engine chassis: ABS Control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6633	Engine chassis: ABS Control unit 2 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6733	Engine chassis: Coupling regulation Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6833	Engine chassis: CAN signal transmission control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6933	Engine chassis: CAN signal transmission control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6A33	Engine chassis: CAN signal transmission control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6B33	Engine chassis: Retarder control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6C33	Engine chassis: CAN- signal I/O module Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C6D33	Engine chassis: CAN- signal I/O module Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6E33	Engine chassis: CAN- signal I/O module Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C6F07	Engine chassis: Supply voltage Value below warning threshold no reaction Check control unit, supplies, battery voltage	A700		E	1
8C6F09	Engine chassis: Supply voltage Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C6F0A	Engine chassis: Supply voltage Value above critical threshold no reaction No remedy text	A700		E	1
8C6F64	Engine chassis: Supply voltage Error supply voltage sensors no reaction No remedy text	A700		E	1
8C6FA3	Engine chassis: Supply voltage Supply voltage term.30 switched off during ECU shut off delay no reaction Check wiring, fuses	A700		E	1
8C7005	Engine chassis: Exhaust flap 1 Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C7033	Engine chassis: Exhaust flap 1 Data transfer CAN problematic Inducement system activation (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C7034	Engine chassis: Exhaust flap 1 Hardware Error Inducement system activation (Mach-FL) Check module	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C7035	Engine chassis: Exhaust flap 1 Excess temperature error Inducement system activation (Mach-FL) Check cooling of module	A700		E	1
8C7036	Engine chassis: Exhaust flap 1 Calibration error Inducement system activation (Mach-FL) Check module	A700		E	1
8C7037	Engine chassis: Exhaust flap 1 Error Reference position Inducement system activation (Mach-FL) Check module	A700		E	1
8C7038	Engine chassis: Exhaust flap 1 Error Regulation deviation Engine derating 50% (Mach-FL) Check components	A700		E	1
8C7039	Engine chassis: Exhaust flap 1 Error Absolute position Inducement system activation (Mach-FL) Check module	A700		E	1
8C7121	Engine chassis: Supply voltage exhaust flap 1 Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C7181	Engine chassis: Supply voltage exhaust flap 1 Position feedback not available Engine reduction (Mach-FL) No remedy text	A700		E	1
8C7203	Engine chassis: Exhaust temperature sensor (before DOC) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7204	Engine chassis: Exhaust temperature sensor (before DOC) short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C7208	Engine chassis: Exhaust temperature sensor (before DOC) Line interruption no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C7209	Engine chassis: Exhaust temperature sensor (before DOC) Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C720A	Engine chassis: Exhaust temperature sensor (before DOC) Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C7216	Engine chassis: Exhaust temperature sensor (before DOC) Plausibility error no reaction Check wiring between control unit and components	A700		E	1
8C721B	Engine chassis: Exhaust temperature sensor (before DOC) Invalid data no reaction Check wiring, fuses	A700		E	1
8C7264	Engine chassis: Exhaust temperature sensor (before DOC) Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C7303	Engine chassis: Actuation central lubrication system short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7304	Engine chassis: Actuation central lubrication system short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C7308	Engine chassis: Actuation central lubrication system Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C736C	Engine chassis: Actuation central lubrication system Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C736D	Engine chassis: Actuation central lubrication system Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C736E	Engine chassis: Actuation central lubrication system Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C736F	Engine chassis: Actuation central lubrication system Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C7370	Engine chassis: Actuation central lubrication system Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C7382	Engine chassis: Actuation central lubrication system Output current too high no reaction Check wiring between control unit and components	A700		E	1
8C7403	Engine chassis: Actuation Air flap short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7404	Engine chassis: Actuation Air flap short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C7408	Engine chassis: Actuation Air flap Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C746C	Engine chassis: Actuation Air flap Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C746D	Engine chassis: Actuation Air flap Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C746E	Engine chassis: Actuation Air flap Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C746F	Engine chassis: Actuation Air flap Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C7470	Engine chassis: Actuation Air flap Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C7482	Engine chassis: Actuation Air flap Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C7503	Engine chassis: Machine configurable lamp outlet 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7504	Engine chassis: Machine configurable lamp outlet 1 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C7508	Engine chassis: Machine configurable lamp outlet 1 Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C756C	Engine chassis: Machine configurable lamp outlet 1 Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C756D	Engine chassis: Machine configurable lamp outlet 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C756E	Engine chassis: Machine configurable lamp outlet 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C756F	Engine chassis: Machine configurable lamp outlet 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C7570	Engine chassis: Machine configurable lamp outlet 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C7603	Engine chassis: Engine stop warning light output (RSL) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7604	Engine chassis: Engine stop warning light output (RSL) short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C7608	Engine chassis: Engine stop warning light output (RSL) Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C766C	Engine chassis: Engine stop warning light output (RSL) Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C766D	Engine chassis: Engine stop warning light output (RSL) Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C766E	Engine chassis: Engine stop warning light output (RSL) Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C766F	Engine chassis: Engine stop warning light output (RSL) Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C7670	Engine chassis: Engine stop warning light output (RSL) Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C7705	Engine chassis: Ammonia sensor Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C7706	Engine chassis: Ammonia sensor internal error Engine derating 25% (Mach-FL) Check components	A700		E	1
8C7709	Engine chassis: Ammonia sensor Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C773A	Engine chassis: Ammonia sensor Error Heater element Engine derating 25% (Mach-FL) Check wiring, replace components	A700		E	1
8C773B	Engine chassis: Ammonia sensor Error Resistance Engine derating 25% (Mach-FL) Check components	A700		E	1
8C773C	Engine chassis: Ammonia sensor Error Trim calibration Engine derating 25% (Mach-FL) Check wiring between module and sensor, replace sensor	A700		E	1
8C773D	Engine chassis: Ammonia sensor Electric error Engine derating 25% (Mach-FL) Check components	A700		E	1
8C774B	Engine chassis: Ammonia sensor Error supply heating element Engine derating 25% (Mach-FL) Check wiring, replace components	A700		E	1
8C7805	Engine chassis: Water pump Communication error no reaction Check wiring, CAN-participant	A700		E	1
8C783E	Engine chassis: Water pump Rpm nominal value cannot be reached no reaction Check components	A700		E	1
8C7857	Engine chassis: Water pump Engine error no reaction Check components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C793F	Engine chassis: Injector supply voltage Up converter cannot reach nominal current no reaction Check control unit	A700		E	1
8C7A40	Engine chassis: Emergency stop Signal Kl.15 on during active emerg. stop no reaction Check emerg. stop, Turn ignition off/on	A700		E	1
8C7B09	Engine chassis: Alternator 1 (Output voltage) Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C7B0A	Engine chassis: Alternator 1 (Output voltage) Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C7B0B	Engine chassis: Alternator 1 (Output voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C7B64	Engine chassis: Alternator 1 (Output voltage) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8C7C03	Engine chassis: Temperature sensor after charge air cooler short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7C04	Engine chassis: Temperature sensor after charge air cooler short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C7C08	Engine chassis: Temperature sensor after charge air cooler Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C7C09	Engine chassis: Temperature sensor after charge air cooler Value above warning threshold no reaction Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C7C0A	Engine chassis: Temperature sensor after charge air cooler Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C7C16	Engine chassis: Temperature sensor after charge air cooler Plausibility error no reaction No remedy text	A700		E	1
8C7C64	Engine chassis: Temperature sensor after charge air cooler Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C7D03	Engine chassis: Alternator 1 (Frequency input) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7D04	Engine chassis: Alternator 1 (Frequency input) short circuit to ground no reaction Check wiring, alternator	A700		E	1
8C7D0B	Engine chassis: Alternator 1 (Frequency input) Short circuit after ground or line interruption no reaction Check wiring, alternator	A700		E	1
8C7D0D	Engine chassis: Alternator 1 (Frequency input) Short circuit after supply voltage or line interruption no reaction Check wiring, alternator	A700		E	1
8C7D64	Engine chassis: Alternator 1 (Frequency input) Error supply voltage sensors no reaction Check wiring, alternator	A700		E	1
8C7E03	Engine chassis: Alternator 2 (Output voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7E04	Engine chassis: Alternator 2 (Output voltage) short circuit to ground no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C7E08	Engine chassis: Alternator 2 (Output voltage) Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C7E09	Engine chassis: Alternator 2 (Output voltage) Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C7E0A	Engine chassis: Alternator 2 (Output voltage) Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C7E16	Engine chassis: Alternator 2 (Output voltage) Plausibility error no reaction No remedy text	A700		E	1
8C7E64	Engine chassis: Alternator 2 (Output voltage) Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C7F03	Engine chassis: Alternator 2 (Lamp) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C7F09	Engine chassis: Alternator 2 (Lamp) Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C7F0A	Engine chassis: Alternator 2 (Lamp) Value above critical threshold no reaction Check operation status of engine	A700		E	1
8C7F0B	Engine chassis: Alternator 2 (Lamp) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C7F64	Engine chassis: Alternator 2 (Lamp) Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C7F72	Engine chassis: Alternator 2 (Lamp) Charge air pr. too high no reaction No remedy text	A700		E	1
8C7F73	Engine chassis: Alternator 2 (Lamp) Charge air pr. too low no reaction No remedy text	A700		E	1
8C8014	Engine chassis: SCR metering regulator Signal remains below nominal value no reaction Check components	A700		E	1
8C8015	Engine chassis: SCR metering regulator Signal remains above nominal value no reaction Check components	A700		E	1
8C8074	Engine chassis: SCR metering regulator Lower limit value for regulation reached no reaction No measure required	A700		E	1
8C8075	Engine chassis: SCR metering regulator Upper limit value for regulation reached no reaction No measure required	A700		E	1
8C8105	Engine chassis: Exhaust flap 2 Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C8133	Engine chassis: Exhaust flap 2 Data transfer CAN problematic Inducement system activation (Mach-FL) Check wiring, CAN-participant	A700		E	1
8C8134	Engine chassis: Exhaust flap 2 Hardware Error Inducement system activation (Mach-FL) Check module	A700		E	1
8C8135	Engine chassis: Exhaust flap 2 Excess temperature error Inducement system activation (Mach-FL) Check cooling of module	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C8136	Engine chassis: Exhaust flap 2 Calibration error Inducement system activation (Mach-FL) Check module	A700		E	1
8C8137	Engine chassis: Exhaust flap 2 Error Reference position Inducement system activation (Mach-FL) Check module	A700		E	1
8C8138	Engine chassis: Exhaust flap 2 Error Regulation deviation Engine derating 50% (Mach-FL) Check components	A700		E	1
8C8139	Engine chassis: Exhaust flap 2 Error Absolute position Inducement system activation (Mach-FL) Check module	A700		E	1
8C8221	Engine chassis: Supply voltage exhaust flap 2 Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C8281	Engine chassis: Supply voltage exhaust flap 2 Position feedback not available Engine reduction (Mach-FL) No remedy text	A700		E	1
8C8304	Engine chassis: Digital input Starter signal short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C8308	Engine chassis: Digital input Starter signal Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C8321	Engine chassis: Digital input Starter signal Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8C835B	Engine chassis: Digital input Starter signal Start block due to a short circuit no reaction Check wiring, components, control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C8364	Engine chassis: Digital input Starter signal Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C8408	Engine chassis: Digital input emerg. off Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C8421	Engine chassis: Digital input emerg. off Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8C8464	Engine chassis: Digital input emerg. off Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C8508	Engine chassis: Digital input test bench operation Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C8521	Engine chassis: Digital input test bench operation Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8C8564	Engine chassis: Digital input test bench operation Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C8608	Engine chassis: Digital input emerg. run rpm Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C8621	Engine chassis: Digital input emerg. run rpm Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8C8664	Engine chassis: Digital input emerg. run rpm Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C8708	Engine chassis: Digital input LWE emerg. Op. Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C8721	Engine chassis: Digital input LWE emerg. Op. Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8C8764	Engine chassis: Digital input LWE emerg. Op. Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8C8803	Engine chassis: Digital input Slave short circuit to supply voltage Inducement system activated Check wiring	A700		E	1
8C8804	Engine chassis: Digital input Slave short circuit to ground Inducement system activated Check wiring	A700		E	1
8C8808	Engine chassis: Digital input Slave Line interruption Inducement system activated Check wiring	A700		E	1
8C880B	Engine chassis: Digital input Slave Short circuit after ground or line interruption Inducement system activated Check wiring	A700		E	1
8C880D	Engine chassis: Digital input Slave Short circuit after supply voltage or line interruption Inducement system activated Check wiring	A700		E	1
8C8821	Engine chassis: Digital input Slave Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8C8864	Engine chassis: Digital input Slave Error supply voltage sensors Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C8907	Engine chassis: Reductions because of exhaust quality Value below warning threshold no reaction Read out error stack and note other system errors	A700		E	1
8C8941	Engine chassis: Reductions because of exhaust quality Power or speed limitation active no reaction Read out error stack and note other system errors	A700		E	1
8C8942	Engine chassis: Reductions because of exhaust quality Increased power or speed limitation active no reaction Read out error stack and note other system errors	A700		E	1
8C8943	Engine chassis: Reductions because of exhaust quality Blocked in increased power or speed limitation no reaction Read out error stack and note other system errors	A700		E	1
8C8944	Engine chassis: Reductions because of exhaust quality Engine start block due to empty urea tank no reaction Read out error stack and note other system errors	A700		E	1
8C8A38	Engine chassis: Signals vehicle speed Error Regulation deviation no reaction Check components	A700		E	1
8C8B21	Engine chassis: Urea (AdBlue) Quality Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C8B76	Engine chassis: Urea (AdBlue) Quality Urea quality outside tolerance range Inducement system activation (Mach-FL) 1) Empty, clean AdBlue tank, replace contents 2) check AdBlue sampling module, clean	A700		E	1
8C8BA4	Engine chassis: Urea (AdBlue) Quality Incorrect reducing agent Inducement system activated Check wiring	A700		E	1
8C8C08	Engine chassis: Data transfer CAN 1 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C8C18	Engine chassis: Data transfer CAN 1 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C8CA5	Engine chassis: Data transfer CAN 1 NOX emission values too high Inducement system activated Check wiring	A700		E	1
8C8D08	Engine chassis: Data transfer CAN 2 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A700		E	1
8C8D18	Engine chassis: Data transfer CAN 2 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C8E08	Engine chassis: Data transfer CAN 3 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A700		E	1
8C8E18	Engine chassis: Data transfer CAN 3 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A700		E	1
8C8F03	Engine chassis: Injector 9 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C8F04	Engine chassis: Injector 9 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C8F08	Engine chassis: Injector 9 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C8F1F	Engine chassis: Injector 9 No current increase time measureable no reaction Check wiring, components, control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C8F20	Engine chassis: Injector 9 Current increase time too long no reaction Check wiring, components, control unit	A700		E	1
8C8F83	Engine chassis: Injector 9 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C8F86	Engine chassis: Injector 9 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C8F87	Engine chassis: Injector 9 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C9003	Engine chassis: Injector 10 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C9004	Engine chassis: Injector 10 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C9008	Engine chassis: Injector 10 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C901F	Engine chassis: Injector 10 No current increase time measureable no reaction Check wiring, components, control unit	A700		E	1
8C9020	Engine chassis: Injector 10 Current increase time too long no reaction Check wiring, components, control unit	A700		E	1
8C9083	Engine chassis: Injector 10 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C9086	Engine chassis: Injector 10 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C9087	Engine chassis: Injector 10 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C9103	Engine chassis: Injector 11 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C9104	Engine chassis: Injector 11 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C9108	Engine chassis: Injector 11 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C911F	Engine chassis: Injector 11 No current increase time measureable no reaction Check wiring, components, control unit	A700		E	1
8C9120	Engine chassis: Injector 11 Current increase time too long no reaction Check wiring, components, control unit	A700		E	1
8C9183	Engine chassis: Injector 11 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C9186	Engine chassis: Injector 11 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C9187	Engine chassis: Injector 11 Minimum quantity correction faulty no reaction No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C9203	Engine chassis: Injector 12 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C9204	Engine chassis: Injector 12 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C9208	Engine chassis: Injector 12 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C921F	Engine chassis: Injector 12 No current increase time measureable no reaction Check wiring, components, control unit	A700		E	1
8C9220	Engine chassis: Injector 12 Current increase time too long no reaction Check wiring, components, control unit	A700		E	1
8C9283	Engine chassis: Injector 12 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A700		E	1
8C9286	Engine chassis: Injector 12 Minimum quantity correction calculation faulty no reaction No remedy text	A700		E	1
8C9287	Engine chassis: Injector 12 Minimum quantity correction faulty no reaction No remedy text	A700		E	1
8C930A	Engine chassis: Fuel supply valve 2 (VCV) Value above critical threshold no reaction No remedy text	A700		E	1
8C930C	Engine chassis: Fuel supply valve 2 (VCV) Value below critical threshold no reaction No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C9533	Engine chassis: CAN-message machine control (TSC1) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8C9603	Engine chassis: Fan 3 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C9604	Engine chassis: Fan 3 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C9608	Engine chassis: Fan 3 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C9617	Engine chassis: Fan 3 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C966C	Engine chassis: Fan 3 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A700		E	1
8C966D	Engine chassis: Fan 3 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C966E	Engine chassis: Fan 3 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C966F	Engine chassis: Fan 3 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8C9670	Engine chassis: Fan 3 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C9682	Engine chassis: Fan 3 Output current too high no reaction Check wiring between control unit and components	A700		E	1
8C9708	Engine chassis: Fuel supply valve 2 (VCV) Line interruption Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A700		E	1
8C9717	Engine chassis: Fuel supply valve 2 (VCV) Short circuit of load Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A700		E	1
8C9752	Engine chassis: Fuel supply valve 2 (VCV) PWM plausibility no reaction No action necessary	A700		E	1
8C976C	Engine chassis: Fuel supply valve 2 (VCV) Reg. deviation current value Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A700		E	1
8C976D	Engine chassis: Fuel supply valve 2 (VCV) Short circuit after supply voltage Plus switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A700		E	1
8C976E	Engine chassis: Fuel supply valve 2 (VCV) Short circuit after supply voltage ground switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A700		E	1
8C976F	Engine chassis: Fuel supply valve 2 (VCV) Short circuit after ground Plus switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A700		E	1
8C9770	Engine chassis: Fuel supply valve 2 (VCV) Short circuit after ground, ground switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A700		E	1
8C9774	Engine chassis: Fuel supply valve 2 (VCV) Lower limit value for regulation reached no reaction No action necessary	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C9782	Engine chassis: Fuel supply valve 2 (VCV) Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A700		E	1
8C9808	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Line interruption Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A700		E	1
8C980A	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Value above critical threshold no reaction No remedy text	A700		E	1
8C9817	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Short circuit of load Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A700		E	1
8C9852	Engine chassis: Fuel high pressure regulating valve 2 (PCV) PWM plausibility no reaction No remedy text	A700		E	1
8C985D	Engine chassis: Fuel high pressure regulating valve 2 (PCV) PCV open due to excess pressure no reaction No remedy text	A700		E	1
8C986C	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Reg. deviation current value Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A700		E	1
8C986D	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Short circuit after supply voltage Plus switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A700		E	1
8C986E	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Short circuit after supply voltage ground switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A700		E	1
8C986F	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Short circuit after ground Plus switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C9870	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Short circuit after ground, ground switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A700		E	1
8C9874	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Lower limit value for regulation reached no reaction No action necessary	A700		E	1
8C9882	Engine chassis: Fuel high pressure regulating valve 2 (PCV) Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A700		E	1
8C9914	Engine chassis: Fuel supply valve 2 (VCV) power regulation Signal remains below nominal value no reaction No action necessary	A700		E	1
8C9915	Engine chassis: Fuel supply valve 2 (VCV) power regulation Signal remains above nominal value no reaction No action necessary	A700		E	1
8C9A14	Engine chassis: Fuel high pressure regulating valve 2 PCV flow reg Signal remains below nominal value no reaction No action necessary	A700		E	1
8C9A15	Engine chassis: Fuel high pressure regulating valve 2 PCV flow reg Signal remains above nominal value no reaction No action necessary	A700		E	1
8C9B14	Engine chassis: Fuel high pressure regulating valve (PCV) flow reg Signal remains below nominal value no reaction Check wiring, components, control unit	A700		E	1
8C9B15	Engine chassis: Fuel high pressure regulating valve (PCV) flow reg Signal remains above nominal value no reaction Check wiring, components, control unit	A700		E	1
8C9C03	Engine chassis: Actuation after run relay short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C9C04	Engine chassis: Actuation after run relay short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8C9C08	Engine chassis: Actuation after run relay Line interruption no reaction Check wiring, wiring harness	A700		E	1
8C9C6C	Engine chassis: Actuation after run relay Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8C9C6D	Engine chassis: Actuation after run relay Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C9C6E	Engine chassis: Actuation after run relay Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8C9C6F	Engine chassis: Actuation after run relay Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8C9C70	Engine chassis: Actuation after run relay Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8C9C82	Engine chassis: Actuation after run relay Output current too high no reaction Check wiring between control unit and components	A700		E	1
8C9D01	Engine chassis: Urea tank (temperature at suction point) Value above max. test range no reaction Check wiring between control unit and components	A700		E	1
8C9D02	Engine chassis: Urea tank (temperature at suction point) Value below min. test range no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8C9D08	Engine chassis: Urea tank (temperature at suction point) Line interruption no reaction Check wiring between control unit and components	A700		E	1
8C9D09	Engine chassis: Urea tank (temperature at suction point) Value above warning threshold no reaction Check operation status of engine	A700		E	1
8C9D16	Engine chassis: Urea tank (temperature at suction point) Plausibility error no reaction Check components	A700		E	1
8C9D18	Engine chassis: Urea tank (temperature at suction point) Short circuit no reaction Check wiring between control unit and components	A700		E	1
8C9F03	Engine chassis: Particle filter pressure sensor 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8C9F0B	Engine chassis: Particle filter pressure sensor 1 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8C9F16	Engine chassis: Particle filter pressure sensor 1 Plausibility error no reaction Check components	A700		E	1
8C9F64	Engine chassis: Particle filter pressure sensor 1 Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8CA103	Engine chassis: Air filter pressure switch short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8CA10B	Engine chassis: Air filter pressure switch Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CA121	Engine chassis: Air filter pressure switch Voltage outside permissible range Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8CA164	Engine chassis: Air filter pressure switch Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8CA221	Engine chassis: Terminal 15 digital input Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8CA264	Engine chassis: Terminal 15 digital input Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8CA348	Engine chassis: Urea thawing procedure Efficiency error no reaction Check operation status of engine	A700		E	1
8CA409	Engine chassis: Urea heater system Value above warning threshold no reaction No action necessary	A700		E	1
8CA40A	Engine chassis: Urea heater system Value above critical threshold Engine reduction 50% (Mach-FL) Check electrical error, check high pressure fuel pump. Sensor OK	A700		E	1
8CA44C	Engine chassis: Urea heater system Actuator error Inducement system activation (Mach-FL) Read out error stack and note other system errors	A700		E	1
8CA44D	Engine chassis: Urea heater system Sensor error Inducement system activation (Mach-FL) Read out error stack and note other system errors	A700		E	1
8CA509	Engine chassis: coolant temperature sensor Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CA50A	Engine chassis: coolant temperature sensor Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CA516	Engine chassis: coolant temperature sensor Plausibility error no reaction No remedy text	A700		E	1
8CA564	Engine chassis: coolant temperature sensor Error supply voltage sensors Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8CA585	Engine chassis: coolant temperature sensor Error in the ground supply no reaction No remedy text	A700		E	1
8CA605	Engine chassis: Intelligent alternator Communication error no reaction Check wiring between control unit and components	A700		E	1
8CA608	Engine chassis: Intelligent alternator Line interruption no reaction Check wiring between control unit and components	A700		E	1
8CA617	Engine chassis: Intelligent alternator Short circuit of load no reaction Check wiring between control unit and components	A700		E	1
8CA66C	Engine chassis: Intelligent alternator Reg. deviation current value no reaction Check wiring between control unit and components	A700		E	1
8CA66D	Engine chassis: Intelligent alternator Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8CA66E	Engine chassis: Intelligent alternator Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CA66F	Engine chassis: Intelligent alternator Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8CA670	Engine chassis: Intelligent alternator Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8CA682	Engine chassis: Intelligent alternator Output current too high no reaction Check wiring between control unit and components	A700		E	1
8CA70A	Engine chassis: Fuel filter pressure sensor Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CA721	Engine chassis: Fuel filter pressure sensor Voltage outside permissible range no reaction No remedy text	A700		E	1
8CA764	Engine chassis: Fuel filter pressure sensor Error supply voltage sensors no reaction No remedy text	A700		E	1
8CA89E	Engine chassis: DOC Low conversion rate Power reduction Check AGN system	A700		E	1
8CA8A0	Engine chassis: DOC Component removed Power reduction Check AGN system	A700		E	1
8CA8A9	Engine chassis: DOC Leakage at post-injection no reaction Check AGN system	A700		E	1
8CA921	Engine chassis: Air filter pressure switch 2 Voltage outside permissible range Engine reduction 25% (Mach-FL) No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CA964	Engine chassis: Air filter pressure switch 2 Error supply voltage sensors Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8CAA04	Engine chassis: Rail pressure sensor 2 short circuit to ground Power reduction Check wiring, sensors, high pressure pump	A700		E	1
8CAA0D	Engine chassis: Rail pressure sensor 2 Short circuit after supply voltage or line interruption Power reduction Check wiring, sensors, high pressure pump	A700		E	1
8CAA10	Engine chassis: Rail pressure sensor 2 Start pressure too low no reaction Check high pressure pump	A700		E	1
8CAA12	Engine chassis: Rail pressure sensor 2 No signal dynamics Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CAA13	Engine chassis: Rail pressure sensor 2 Leakage no reaction No remedy text	A700		E	1
8CAA14	Engine chassis: Rail pressure sensor 2 Signal remains below nominal value Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CAA15	Engine chassis: Rail pressure sensor 2 Signal remains above nominal value Engine reduction 50% (Mach-FL) Check electrical error, check high pressure fuel pump.	A700		E	1
8CAA16	Engine chassis: Rail pressure sensor 2 Plausibility error Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CAA21	Engine chassis: Rail pressure sensor 2 Voltage outside permissible range no reaction No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CAA64	Engine chassis: Rail pressure sensor 2 Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CAB2D	Engine chassis: High pressure pump Installation error no reaction Check installation	A700		E	1
8CAC09	Engine chassis: Coolant temperature charge air cooler Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CAC0A	Engine chassis: Coolant temperature charge air cooler Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CAC64	Engine chassis: Coolant temperature charge air cooler Error supply voltage sensors no reaction No remedy text	A700		E	1
8CAD03	Engine chassis: charge air temperature sensor short circuit to supply voltage no reaction Check wiring, sensor	A700		E	1
8CAD04	Engine chassis: charge air temperature sensor short circuit to ground no reaction Check wiring, sensor	A700		E	1
8CAD08	Engine chassis: charge air temperature sensor Line interruption no reaction Check wiring, sensor	A700		E	1
8CAD09	Engine chassis: charge air temperature sensor Value above warning threshold no reaction Check wiring, sensor	A700		E	1
8CAD0A	Engine chassis: charge air temperature sensor Value above critical threshold no reaction Check wiring, sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CAD16	Engine chassis: charge air temperature sensor Plausibility error no reaction Check wiring, sensor	A700		E	1
8CAD64	Engine chassis: charge air temperature sensor Error supply voltage sensors no reaction Check wiring, sensor	A700		E	1
8CAE07	Engine chassis: Charge air temperature sensor 2 Value below warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CAE09	Engine chassis: Charge air temperature sensor 2 Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CAE0A	Engine chassis: Charge air temperature sensor 2 Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CAE0C	Engine chassis: Charge air temperature sensor 2 Value below critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CAE64	Engine chassis: Charge air temperature sensor 2 Error supply voltage sensors no reaction No remedy text	A700		E	1
8CAF16	Engine chassis: Charge air temperature sensor suction pipe 2 Plausibility error no reaction No remedy text	A700		E	1
8CAF64	Engine chassis: Charge air temperature sensor suction pipe 2 Error supply voltage sensors no reaction No remedy text	A700		E	1
8CB009	Engine chassis: Charge air temperature sensor 2 Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CB00A	Engine chassis: Charge air temperature sensor 2 Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CB016	Engine chassis: Charge air temperature sensor 2 Plausibility error Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8CB064	Engine chassis: Charge air temperature sensor 2 Error supply voltage sensors Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8CB216	Engine chassis: Turbo charger rpm sensor 1 Plausibility error no reaction No remedy text	A700		E	1
8CB304	Engine chassis: Engine short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8CB309	Engine chassis: Engine Value above warning threshold no reaction No remedy text	A700		E	1
8CB30A	Engine chassis: Engine Value above critical threshold no reaction No remedy text	A700		E	1
8CB30D	Engine chassis: Engine Short circuit after supply voltage or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CB38C	Engine chassis: Engine High NOX emissions no reaction No remedy text	A700		E	1
8CB3A5	Engine chassis: Engine NOX emission values too high no reaction Check the exhaust gas aftertreatment system AGN	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CB404	Engine chassis: Turbo charger rpm sensor 3 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8CB409	Engine chassis: Turbo charger rpm sensor 3 Value above warning threshold no reaction No remedy text	A700		E	1
8CB40A	Engine chassis: Turbo charger rpm sensor 3 Value above critical threshold no reaction No remedy text	A700		E	1
8CB40D	Engine chassis: Turbo charger rpm sensor 3 Short circuit after supply voltage or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CB48D	Engine chassis: Turbo charger rpm sensor 3 Actuated with active engine brake no reaction No remedy text	A700		E	1
8CB504	Engine chassis: Turbo charger rpm sensor 4 short circuit to ground no reaction Check wiring between control unit and components	A700		E	1
8CB509	Engine chassis: Turbo charger rpm sensor 4 Value above warning threshold no reaction No remedy text	A700		E	1
8CB50A	Engine chassis: Turbo charger rpm sensor 4 Value above critical threshold no reaction No remedy text	A700		E	1
8CB50D	Engine chassis: Turbo charger rpm sensor 4 Short circuit after supply voltage or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CB58E	Engine chassis: Turbo charger rpm sensor 4 Crankshaft and camshaft rpm sensors reversed no reaction No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CB653	Engine chassis: Monitoring system engine control unit Error plausibility starter actuation no reaction Check control unit	A700		E	1
8CB654	Engine chassis: Monitoring system engine control unit Ecu internal error no reaction Check components	A700		E	1
8CB65F	Engine chassis: Monitoring system engine control unit Error emerg. stop no reaction Check control unit	A700		E	1
8CB660	Engine chassis: Monitoring system engine control unit PME CAN Error no reaction Check control unit	A700		E	1
8CB665	Engine chassis: Monitoring system engine control unit Fuel injector plausibility error no reaction Check control unit	A700		E	1
8CB671	Engine chassis: Monitoring system engine control unit Injection plausibility, error in fuel injector monitoring no reaction Check control unit	A700		E	1
8CB709	Engine chassis: Control unit temperature Value above warning threshold no reaction Check operation status of engine	A700		E	1
8CB70A	Engine chassis: Control unit temperature Value above critical threshold no reaction Check operation status of engine	A700		E	1
8CB764	Engine chassis: Control unit temperature Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CB855	Engine chassis: Pressure relief valve high pressure injection syst Too many activations no reaction Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CB856	Engine chassis: Pressure relief valve high pressure injection syst Valve open Engine derating 25% (Mach-FL) Check operation status of engine	A700		E	1
8CB908	Engine chassis: Digital input emerg. start Line interruption no reaction Check wiring between control unit and components	A700		E	1
8CB921	Engine chassis: Digital input emerg. start Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8CB964	Engine chassis: Digital input emerg. start Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8CBA21	Engine chassis: Piston cooling pressure sensor 1 Voltage outside permissible range no reaction No remedy text	A700		E	1
8CBA64	Engine chassis: Piston cooling pressure sensor 1 Error supply voltage sensors no reaction No remedy text	A700		E	1
8CBB95	Engine chassis: Piston cooling pressure sensor 2 Line interruption at engine plug Engine reduction 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8CBB96	Engine chassis: Piston cooling pressure sensor 2 Line interruption at vehicle plug Engine reduction 25% (Mach-FL) Check wiring between control unit and components	A700		E	1
8CBC05	Engine chassis: Tachograph Communication error no reaction Check wiring between control unit and components	A700		E	1
8CBC07	Engine chassis: Tachograph Value below warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CBC09	Engine chassis: Tachograph Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CBC0A	Engine chassis: Tachograph Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CBC0C	Engine chassis: Tachograph Value below critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CBC64	Engine chassis: Tachograph Error supply voltage sensors no reaction No remedy text	A700		E	1
8CBE08	Engine chassis: Data transfer CAN 4 Line interruption no reaction Check wiring, wiring harness	A700		E	1
8CBE18	Engine chassis: Data transfer CAN 4 Short circuit no reaction Check wiring between control unit and components	A700		E	1
8CBF09	Engine chassis: Turbocharger 1 exhaust temperature Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CBF0A	Engine chassis: Turbocharger 1 exhaust temperature Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CC005	Engine chassis: Climatic control unit Communication error no reaction Check wiring	A700		E	1
8CC109	Engine chassis: Turbocharger 3 exhaust temperature Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CC10A	Engine chassis: Turbocharger 3 exhaust temperature Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CC209	Engine chassis: SCR system (HC overload) Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A700		E	1
8CC20A	Engine chassis: SCR system (HC overload) Value above critical threshold Power reduction Check the exhaust gas aftertreatment system AGN	A700		E	1
8CC305	Engine chassis: Cylinder head temperature sensor Communication error no reaction Check wiring between control unit and components	A700		E	1
8CC40A	Engine chassis: Water in fuel sensor 2 Value above critical threshold Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8CC421	Engine chassis: Water in fuel sensor 2 Voltage outside permissible range Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8CC464	Engine chassis: Water in fuel sensor 2 Error supply voltage sensors Engine reduction 25% (Mach-FL) No remedy text	A700		E	1
8CC558	Engine chassis: Exhaust return regulation Error auto calibration no reaction Check mechanics	A700		E	1
8CC559	Engine chassis: Exhaust return regulation Error teach in procedure no reaction Check mechanics	A700		E	1
8CC55A	Engine chassis: Exhaust return regulation Learned value lost in operation no reaction Check mechanics	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CC680	Engine chassis: Air flap excessive speed no reaction No remedy text	A700		E	1
8CC75C	Engine chassis: SCR urea Temperature Temperature measurement urea too high Inducement system activation (Mach-FL) Check AdBlue Heating system	A700		E	1
8CC858	Engine chassis: Exhaust flap regulation Error auto calibration Inducement system activation (Mach-FL) Check mechanics	A700		E	1
8CC859	Engine chassis: Exhaust flap regulation Error teach in procedure Inducement system activation (Mach-FL) Check mechanics	A700		E	1
8CC85A	Engine chassis: Exhaust flap regulation Learned value lost in operation Inducement system activation (Mach-FL) Check mechanics	A700		E	1
8CC958	Engine chassis: Exhaust flap regulation 2 Error auto calibration Inducement system activation (Mach-FL) Check mechanics	A700		E	1
8CC959	Engine chassis: Exhaust flap regulation 2 Error teach in procedure Inducement system activation (Mach-FL) Check mechanics	A700		E	1
8CC95A	Engine chassis: Exhaust flap regulation 2 Learned value lost in operation Inducement system activation (Mach-FL) Check mechanics	A700		E	1
8CCA21	Engine chassis: battle switch Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8CCA5E	Engine chassis: battle switch activated no reaction Report all error parameters to Service	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CCA64	Engine chassis: battle switch Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8CCC05	Engine chassis: Safety system PME CAN Communication error no reaction Check wiring, CAN-participant	A700		E	1
8CCE33	Engine chassis: J1939 Prop0 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8CCF03	Engine chassis: Input display alternator short circuit to supply voltage no reaction Check wiring, wiring harness	A700		E	1
8CCF0B	Engine chassis: Input display alternator Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CCF21	Engine chassis: Input display alternator Voltage outside permissible range no reaction Check wiring, wiring harness	A700		E	1
8CCF64	Engine chassis: Input display alternator Error supply voltage sensors no reaction Check wiring between control unit and components	A700		E	1
8CD061	Engine chassis: Particle filter DPF Regeneration failed no reaction Check operation status of engine	A700		E	1
8CD062	Engine chassis: Particle filter DPF Regeneration stopped (temp. too low) no reaction Check operation status of engine	A700		E	1
8CD063	Engine chassis: Particle filter DPF Regeneration stopped (temp. too low) no reaction Check operation status of engine	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CD068	Engine chassis: Particle filter DPF Assessment of soot load not plausible (too high) no reaction Check operation status of engine	A700		E	1
8CD069	Engine chassis: Particle filter DPF Assessment of soot load not plausible (too low) no reaction Check operation status of engine	A700		E	1
8CD077	Engine chassis: Particle filter DPF Particle load above warning threshold no reaction Report all error parameters to Service	A700		E	1
8CD078	Engine chassis: Particle filter DPF Particle load above critical threshold no reaction Report all error parameters to Service	A700		E	1
8CD079	Engine chassis: Particle filter DPF Cleaning interval reached, replace DPF filter element no reaction Report all error parameters to Service	A700		E	1
8CD07A	Engine chassis: Particle filter DPF Cleaning interval reached, replace DPF filter element-reduction! no reaction Report all error parameters to Service	A700		E	1
8CD091	Engine chassis: Particle filter DPF Motor stop during manual regeneration no reaction No remedy text	A700		E	1
8CD099	Engine chassis: Particle filter DPF Maximum operating duration without manual regeneration exceeded Power reduction Check the exhaust gas aftertreatment system AGN	A700		E	1
8CD0A1	Engine chassis: Particle filter DPF Differential pressure out of valid value range/too high Power reduction Check the exhaust gas aftertreatment system AGN	A700		E	1
8CD0A2	Engine chassis: Particle filter DPF Differential pressure out of valid value range/too low Power reduction Check the exhaust gas aftertreatment system AGN	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CD103	Engine chassis: Travel pedal sensor 1 (voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8CD10B	Engine chassis: Travel pedal sensor 1 (voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CD164	Engine chassis: Travel pedal sensor 1 (voltage) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CD203	Engine chassis: Travel pedal sensor 1 (current) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8CD20B	Engine chassis: Travel pedal sensor 1 (current) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CD264	Engine chassis: Travel pedal sensor 1 (current) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CD303	Engine chassis: Travel pedal sensor 2 (voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1
8CD30B	Engine chassis: Travel pedal sensor 2 (voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CD364	Engine chassis: Travel pedal sensor 2 (voltage) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CD403	Engine chassis: Travel pedal sensor 2 (current) short circuit to supply voltage no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CD40B	Engine chassis: Travel pedal sensor 2 (current) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CD464	Engine chassis: Travel pedal sensor 2 (current) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CD505	Engine chassis: Exhaust temp. before turbocharger (CMR Sensor) Communication error no reaction Check wiring	A700		E	1
8CD533	Engine chassis: Exhaust temp. before turbocharger (CMR Sensor) Data transfer CAN problematic no reaction Check wiring between control unit and components	A700		E	1
8CD69C	Engine chassis: Engine oil Change interval almost reached, observe influence on DPF regeneration! no reaction Check oil quality, change the oil	A700		E	1
8CD69D	Engine chassis: Engine oil Change interval reached, attention DPF regeneration not possible! no reaction Check oil quality, change the oil	A700		E	1
8CD72D	Engine chassis: Temp sensor exhaust aftertreatment (AGN) Installation error Power reduction Check wiring, installation	A700 Ignition control uni		E	1
8CD921	Engine chassis: Switch idle rpm specification Voltage outside permissible range no reaction Check wiring between control unit and components	A700		E	1
8CD964	Engine chassis: Switch idle rpm specification Error supply voltage sensors no reaction No remedy text	A700		E	1
8CDA03	Engine chassis: Coolant fill level sensor short circuit to supply voltage no reaction Check wiring between control unit and component - S710	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CDA0B	Engine chassis: Coolant fill level sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A700		E	1
8CDA21	Engine chassis: Coolant fill level sensor Voltage outside permissible range no reaction No remedy text	A700		E	1
8CDB33	Engine chassis: J1939 Prop3 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A700		E	1
8CDC66	Engine chassis: Engine run turbulant Injection qty. correction of a cyl. too high no reaction Report all error parameters to Service	A700		E	1
8CDC67	Engine chassis: Engine run turbulant Deviation segment rpm of a cyl. too high no reaction Report all error parameters to Service	A700		E	1
8CDD6A	Engine chassis: Engine protection power reduction Air intake manifold temperature no reaction Check operation status of engine	A700		E	1
8CDD72	Engine chassis: Engine protection power reduction Charge air pr. too high no reaction Report all error parameters to Service	A700		E	1
8CDD73	Engine chassis: Engine protection power reduction Charge air pr. too low no reaction Report all error parameters to Service	A700		E	1
8CDD7F	Engine chassis: Engine protection power reduction Turbocharger protection active no reaction No remedy text	A700		E	1
8CDE05	Engine chassis: SCR control unit Communication error Engine reduction (Mach-FL) Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CDE7B	Engine chassis: SCR control unit Emission relevant error Engine reduction (Mach-FL) No remedy text	A700		E	1
8CDF16	Engine chassis: Rpm sensor signal camshaft (voltage) Plausibility error no reaction Check operation status of engine	A700		E	1
8CE016	Engine chassis: Rpm sensor signal crankshaft (voltage) Plausibility error no reaction Check operation status of engine	A700		E	1
8CE15B	Engine chassis: Digital input Starter signal 2 Start block due to a short circuit no reaction Report all error parameters to Service	A700		E	1
8CE235	Engine chassis: Power reduction to protect AGN-Systems Excess temperature error no reaction Report all error parameters to Service	A700		E	1
8CE364	Engine chassis: Pr. sensor inlet AGR Error supply voltage sensors no reaction Check wiring, sensor	A700		E	1
8CE464	Engine chassis: Temperature sensor inlet AGR Error supply voltage sensors no reaction Check wiring, sensor	A700		E	1
8CE721	Engine chassis: Droop Switch Voltage outside permissible range no reaction No remedy text	A700		E	1
8CE764	Engine chassis: Droop Switch Error supply voltage sensors no reaction No remedy text	A700		E	1
8CE821	Engine chassis: Switch suppress error reactions Voltage outside permissible range no reaction No remedy text	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CE864	Engine chassis: Switch suppress error reactions Error supply voltage sensors no reaction No remedy text	A700		E	1
8CE921	Engine chassis: Switch Overspeed recognition Voltage outside permissible range no reaction No remedy text	A700		E	1
8CE964	Engine chassis: Switch Overspeed recognition Error supply voltage sensors no reaction No remedy text	A700		E	1
8CEA08	Engine chassis: Alternator (voltage regulation) Line interruption no reaction Check wiring between control unit and components	A700		E	1
8CEA6C	Engine chassis: Alternator (voltage regulation) Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8CEA6D	Engine chassis: Alternator (voltage regulation) Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8CEA6E	Engine chassis: Alternator (voltage regulation) Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8CEA6F	Engine chassis: Alternator (voltage regulation) Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8CEA70	Engine chassis: Alternator (voltage regulation) Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8CEB08	Engine chassis: Alternator (shut-off function) Line interruption no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CEB6C	Engine chassis: Alternator (shut-off function) Reg. deviation current value no reaction Report all error parameters to Service	A700		E	1
8CEB6D	Engine chassis: Alternator (shut-off function) Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1
8CEB6E	Engine chassis: Alternator (shut-off function) Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8CEB6F	Engine chassis: Alternator (shut-off function) Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8CEB70	Engine chassis: Alternator (shut-off function) Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8CEB82	Engine chassis: Alternator (shut-off function) Output current too high no reaction Check wiring between control unit and component - G700	A700		E	1
8CEC05	Engine chassis: Wastegate Regulating valve Communication error no reaction Check wiring, flaps (smart components)	A700		E	1
8CED08	Engine chassis: Machine configurable lamp outlet 3 Line interruption no reaction Check wiring between control unit and components	A700		E	1
8CED6C	Engine chassis: Machine configurable lamp outlet 3 Reg. deviation current value no reaction Check wiring between control unit and components	A700		E	1
8CED6D	Engine chassis: Machine configurable lamp outlet 3 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8CED6E	Engine chassis: Machine configurable lamp outlet 3 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A700		E	1
8CED6F	Engine chassis: Machine configurable lamp outlet 3 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A700		E	1
8CED70	Engine chassis: Machine configurable lamp outlet 3 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A700		E	1
8CED82	Engine chassis: Machine configurable lamp outlet 3 Output current too high no reaction Check wiring between control unit and components	A700		E	1
8CEE55	Engine chassis: Pr. relief valve high pr. injection system 2 Too many activations no reaction No remedy text	A700		E	1
8CEE56	Engine chassis: Pr. relief valve high pr. injection system 2 Valve open Engine reduction 50% (Mach-FL) No remedy text	A700		E	1
8CF521	Engine chassis: Oil filter 2 Voltage outside permissible range no reaction No remedy text	A700		E	1
8CF564	Engine chassis: Oil filter 2 Error supply voltage sensors no reaction No remedy text	A700		E	1
8CF97D	Engine chassis: Injection system Comp. factors qty. match outside tol. range no reaction Report all error parameters to Service	A700		E	1
8D0116	Engine uppercarr. Environmental pressure sensor Plausibility error no reaction Check control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0164	Engine uppercarr. Environmental pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D028A	Engine uppercarr. Air filter Combi sensor (humidity) Determination of the specific humidity faulty no reaction No remedy text	A750		E	1
8D028B	Engine uppercarr. Air filter Combi sensor (humidity) Determination of the relative humidity faulty no reaction No remedy text	A750		E	1
8D0307	Engine uppercarr. Air filter Combi sensor (pressure) Value below warning threshold Engine derating 25% (Mach-FL) Check air filter	A750		E	1
8D0393	Engine uppercarr. Air filter Combi sensor (pressure) Error during pressure measurement (Trican sensor) Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8D0416	Engine uppercarr. Air filter Combi sensor (temperature) Plausibility error no reaction Check components	A750		E	1
8D0494	Engine uppercarr. Air filter Combi sensor (temperature) Error during pressure measurement (Trican sensor) Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8D0505	Engine uppercarr. Air filter Combi sensor Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D0592	Engine uppercarr. Air filter Combi sensor Internal temperature error Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8D0603	Engine uppercarr. Charge air temperature sensor suction pipe short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0604	Engine uppercarr. Charge air temperature sensor suction pipe short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D0608	Engine uppercarr. Charge air temperature sensor suction pipe Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D0609	Engine uppercarr. Charge air temperature sensor suction pipe Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D060A	Engine uppercarr. Charge air temperature sensor suction pipe Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D0616	Engine uppercarr. Charge air temperature sensor suction pipe Plausibility error no reaction Check components	A750		E	1
8D0664	Engine uppercarr. Charge air temperature sensor suction pipe Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D0703	Engine uppercarr. charge air pressure sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0707	Engine uppercarr. charge air pressure sensor Value below warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8D0709	Engine uppercarr. charge air pressure sensor Value above warning threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1
8D070A	Engine uppercarr. charge air pressure sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D070B	Engine uppercarr. charge air pressure sensor Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D070C	Engine uppercarr. charge air pressure sensor Value below critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8D0714	Engine uppercarr. charge air pressure sensor Signal remains below nominal value no reaction Air intake manifold, check wastegate	A750		E	1
8D0715	Engine uppercarr. charge air pressure sensor Signal remains above nominal value no reaction Air intake manifold, check wastegate	A750		E	1
8D0716	Engine uppercarr. charge air pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0764	Engine uppercarr. charge air pressure sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0774	Engine uppercarr. charge air pressure sensor Lower limit value for regulation reached no reaction Air intake manifold, check wastegate	A750		E	1
8D0775	Engine uppercarr. charge air pressure sensor Upper limit value for regulation reached no reaction Air intake manifold, check wastegate	A750		E	1
8D0803	Engine uppercarr. Ambient temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D0804	Engine uppercarr. Ambient temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0808	Engine uppercarr. Ambient temperature sensor Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D0816	Engine uppercarr. Ambient temperature sensor Plausibility error no reaction Check components	A750		E	1
8D0864	Engine uppercarr. Ambient temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D0903	Engine uppercarr. coolant temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0904	Engine uppercarr. coolant temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0908	Engine uppercarr. coolant temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0909	Engine uppercarr. coolant temperature sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D090A	Engine uppercarr. coolant temperature sensor Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D0916	Engine uppercarr. coolant temperature sensor Plausibility error no reaction Check components	A750		E	1
8D0964	Engine uppercarr. coolant temperature sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0A03	Engine uppercarr. Coolant level sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D0A07	Engine uppercarr. Coolant level sensor Value below warning threshold no reaction Check coolant level	A750		E	1
8D0A0B	Engine uppercarr. Coolant level sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D0A21	Engine uppercarr. Coolant level sensor Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8D0A64	Engine uppercarr. Coolant level sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D0B04	Engine uppercarr. Rail pressure sensor short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0B09	Engine uppercarr. Rail pressure sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D0B0A	Engine uppercarr. Rail pressure sensor Value above critical threshold Engine derating 50% (Mach-FL) Check operation status of engine	A750		E	1
8D0B0D	Engine uppercarr. Rail pressure sensor Short circuit after supply voltage or line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0B0E	Engine uppercarr. Rail pressure sensor Signal increases too fast no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0B0F	Engine uppercarr. Rail pressure sensor Signal decreases too fast no reaction Check wiring between control unit and components	A750		E	1
8D0B10	Engine uppercarr. Rail pressure sensor Start pressure too low no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750		E	1
8D0B11	Engine uppercarr. Rail pressure sensor Signal noise too high no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750		E	1
8D0B12	Engine uppercarr. Rail pressure sensor No signal dynamics Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0B13	Engine uppercarr. Rail pressure sensor Leakage no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750		E	1
8D0B14	Engine uppercarr. Rail pressure sensor Signal remains below nominal value Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750		E	1
8D0B15	Engine uppercarr. Rail pressure sensor Signal remains above nominal value Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750		E	1
8D0B16	Engine uppercarr. Rail pressure sensor Plausibility error no reaction No remedy text	A750		E	1
8D0B21	Engine uppercarr. Rail pressure sensor Voltage outside permissible range no reaction No remedy text	A750		E	1
8D0B64	Engine uppercarr. Rail pressure sensor Error supply voltage sensors Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0C14	Engine uppercarr. Fuel supply valve (VCV) flow regulation Signal remains below nominal value no reaction Check wiring, components, control unit	A750		E	1
8D0C15	Engine uppercarr. Fuel supply valve (VCV) flow regulation Signal remains above nominal value no reaction Check wiring, components, control unit	A750		E	1
8D0C16	Engine uppercarr. Fuel supply valve (VCV) flow regulation Plausibility error Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750		E	1
8D0D03	Engine uppercarr. Fuel pressure sensor (low pressure system) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D0D07	Engine uppercarr. Fuel pressure sensor (low pressure system) Value below warning threshold no reaction Check operation status of engine	A750		E	1
8D0D09	Engine uppercarr. Fuel pressure sensor (low pressure system) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D0D0A	Engine uppercarr. Fuel pressure sensor (low pressure system) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D0D0B	Engine uppercarr. Fuel pressure sensor (low pressure system) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D0D0C	Engine uppercarr. Fuel pressure sensor (low pressure system) Value below critical threshold no reaction Check operation status of engine	A750		E	1
8D0D64	Engine uppercarr. Fuel pressure sensor (low pressure system) Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0E03	Engine uppercarr. Fuel temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0E04	Engine uppercarr. Fuel temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0E08	Engine uppercarr. Fuel temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0E09	Engine uppercarr. Fuel temperature sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D0E0A	Engine uppercarr. Fuel temperature sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1
8D0E16	Engine uppercarr. Fuel temperature sensor Plausibility error no reaction Check components	A750		E	1
8D0E64	Engine uppercarr. Fuel temperature sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D0F03	Engine uppercarr. Oil level sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D0F07	Engine uppercarr. Oil level sensor Value below warning threshold no reaction Check oil level, oil level sensor, engine must be at incline 0degrees	A750		E	1
8D0F09	Engine uppercarr. Oil level sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0F0B	Engine uppercarr. Oil level sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D0F0C	Engine uppercarr. Oil level sensor Value below critical threshold no reaction Check oil level, oil level sensor, engine must be at incline 0degrees	A750		E	1
8D0F64	Engine uppercarr. Oil level sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D1003	Engine uppercarr. oil pressure sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D1007	Engine uppercarr. oil pressure sensor Value below warning threshold no reaction Check operation status of engine	A750		E	1
8D100B	Engine uppercarr. oil pressure sensor Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D100C	Engine uppercarr. oil pressure sensor Value below critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1
8D1016	Engine uppercarr. oil pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1
8D1064	Engine uppercarr. oil pressure sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D1103	Engine uppercarr. oil temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1104	Engine uppercarr. oil temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1108	Engine uppercarr. oil temperature sensor Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D1109	Engine uppercarr. oil temperature sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D110A	Engine uppercarr. oil temperature sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1
8D110B	Engine uppercarr. oil temperature sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D1116	Engine uppercarr. oil temperature sensor Plausibility error no reaction No remedy text	A750		E	1
8D1164	Engine uppercarr. oil temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D1203	Engine uppercarr. Water level probe fuel filter short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1204	Engine uppercarr. Water level probe fuel filter short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1208	Engine uppercarr. Water level probe fuel filter Line interruption no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D120A	Engine uppercarr. Water level probe fuel filter Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1
8D1221	Engine uppercarr. Water level probe fuel filter Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8D1264	Engine uppercarr. Water level probe fuel filter Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D1303	Engine uppercarr. Rpm sensor camshaft short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1304	Engine uppercarr. Rpm sensor camshaft short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1308	Engine uppercarr. Rpm sensor camshaft Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D1316	Engine uppercarr. Rpm sensor camshaft Plausibility error no reaction Check rpm sensors	A750		E	1
8D1364	Engine uppercarr. Rpm sensor camshaft Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8D1385	Engine uppercarr. Rpm sensor camshaft Error in the ground supply Engine reduction 50% (Mach-FL) Check wiring between control unit and component - B713	A750		E	1
8D1403	Engine uppercarr. Rpm sensor crankshaft short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1404	Engine uppercarr. Rpm sensor crankshaft short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D1408	Engine uppercarr. Rpm sensor crankshaft Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D1416	Engine uppercarr. Rpm sensor crankshaft Plausibility error Engine derating 25% (Mach-FL) Check rpm sensors	A750		E	1
8D1464	Engine uppercarr. Rpm sensor crankshaft Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8D1485	Engine uppercarr. Rpm sensor crankshaft Error in the ground supply Engine reduction 50% (Mach-FL) Check wiring between control unit and component - B711	A750		E	1
8D1509	Engine uppercarr. Engine speed Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D150A	Engine uppercarr. Engine speed Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D1598	Engine uppercarr. Engine speed No rpm detected with actuated starter no reaction Check wiring, starter	A750		E	1
8D1603	Engine uppercarr. Status Heat flange 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1604	Engine uppercarr. Status Heat flange 1 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1608	Engine uppercarr. Status Heat flange 1 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D166D	Engine uppercarr. Status Heat flange 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D166E	Engine uppercarr. Status Heat flange 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D166F	Engine uppercarr. Status Heat flange 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1670	Engine uppercarr. Status Heat flange 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1703	Engine uppercarr. Heat flange 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1704	Engine uppercarr. Heat flange 1 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1708	Engine uppercarr. Heat flange 1 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D176C	Engine uppercarr. Heat flange 1 Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D176D	Engine uppercarr. Heat flange 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D176E	Engine uppercarr. Heat flange 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D176F	Engine uppercarr. Heat flange 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1770	Engine uppercarr. Heat flange 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1782	Engine uppercarr. Heat flange 1 Output current too high no reaction Check wiring between control unit and component - E703	A750		E	1
8D1803	Engine uppercarr. Status Heat flange 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1804	Engine uppercarr. Status Heat flange 2 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1808	Engine uppercarr. Status Heat flange 2 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D186D	Engine uppercarr. Status Heat flange 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D186E	Engine uppercarr. Status Heat flange 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D186F	Engine uppercarr. Status Heat flange 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1870	Engine uppercarr. Status Heat flange 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1903	Engine uppercarr. Heat flange 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1904	Engine uppercarr. Heat flange 2 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1908	Engine uppercarr. Heat flange 2 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D196C	Engine uppercarr. Heat flange 2 Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D196D	Engine uppercarr. Heat flange 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D196E	Engine uppercarr. Heat flange 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D196F	Engine uppercarr. Heat flange 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1970	Engine uppercarr. Heat flange 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1982	Engine uppercarr. Heat flange 2 Output current too high no reaction Check wiring between control unit and component - E704	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1A03	Engine uppercarr. Urea (AdBlue) Tank heater valve short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1A04	Engine uppercarr. Urea (AdBlue) Tank heater valve short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1A08	Engine uppercarr. Urea (AdBlue) Tank heater valve Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D1A49	Engine uppercarr. Urea (AdBlue) Tank heater valve Error blocked open no reaction Check components	A750		E	1
8D1A4A	Engine uppercarr. Urea (AdBlue) Tank heater valve Error blocked closed no reaction Check components	A750		E	1
8D1A6C	Engine uppercarr. Urea (AdBlue) Tank heater valve Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D1A6D	Engine uppercarr. Urea (AdBlue) Tank heater valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1A6E	Engine uppercarr. Urea (AdBlue) Tank heater valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1A6F	Engine uppercarr. Urea (AdBlue) Tank heater valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1A70	Engine uppercarr. Urea (AdBlue) Tank heater valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1A82	Engine uppercarr. Urea (AdBlue) Tank heater valve Output current too high no reaction Check wiring between control unit and component - Y770	A750		E	1
8D1B03	Engine uppercarr. Urea (AdBlue) Pump heater valve short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1B04	Engine uppercarr. Urea (AdBlue) Pump heater valve short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1B08	Engine uppercarr. Urea (AdBlue) Pump heater valve Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D1B49	Engine uppercarr. Urea (AdBlue) Pump heater valve Error blocked open no reaction Check components	A750		E	1
8D1B4A	Engine uppercarr. Urea (AdBlue) Pump heater valve Error blocked closed no reaction Check components	A750		E	1
8D1B6C	Engine uppercarr. Urea (AdBlue) Pump heater valve Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D1B6D	Engine uppercarr. Urea (AdBlue) Pump heater valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1B6E	Engine uppercarr. Urea (AdBlue) Pump heater valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1B6F	Engine uppercarr. Urea (AdBlue) Pump heater valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1B70	Engine uppercarr. Urea (AdBlue) Pump heater valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1B82	Engine uppercarr. Urea (AdBlue) Pump heater valve Output current too high no reaction Check wiring between control unit and component - Y770	A750		E	1
8D1C03	Engine uppercarr. Urea (AdBlue) Hose heater 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1C04	Engine uppercarr. Urea (AdBlue) Hose heater 1 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1C08	Engine uppercarr. Urea (AdBlue) Hose heater 1 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D1C6C	Engine uppercarr. Urea (AdBlue) Hose heater 1 Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D1C6D	Engine uppercarr. Urea (AdBlue) Hose heater 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1C6E	Engine uppercarr. Urea (AdBlue) Hose heater 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1C6F	Engine uppercarr. Urea (AdBlue) Hose heater 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1C70	Engine uppercarr. Urea (AdBlue) Hose heater 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1C82	Engine uppercarr. Urea (AdBlue) Hose heater 1 Output current too high no reaction Check wiring between control unit and component - E770	A750		E	1
8D1D03	Engine uppercarr. Urea (AdBlue) Hose heater 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1D04	Engine uppercarr. Urea (AdBlue) Hose heater 2 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D1D08	Engine uppercarr. Urea (AdBlue) Hose heater 2 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D1D6C	Engine uppercarr. Urea (AdBlue) Hose heater 2 Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D1D6D	Engine uppercarr. Urea (AdBlue) Hose heater 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1D6E	Engine uppercarr. Urea (AdBlue) Hose heater 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1D6F	Engine uppercarr. Urea (AdBlue) Hose heater 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D1D70	Engine uppercarr. Urea (AdBlue) Hose heater 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D1D82	Engine uppercarr. Urea (AdBlue) Hose heater 2 Output current too high no reaction Check wiring between control unit and component - E771	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1E03	Engine uppercarr. SCR Urea (AdBlue) pressure sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D1E0B	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D1E14	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Signal remains below nominal value no reaction Check SCR-System	A750		E	1
8D1E16	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Plausibility error no reaction Check components	A750		E	1
8D1E26	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Urea (AdBlue) line filling failed Inducement system activation (Mach-FL) Check SCR-System	A750		E	1
8D1E2B	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Urea pressure too low (Plausibility vent valve open) Inducement system activation (Mach-FL) Check urea pump, turn ignition off / on	A750		E	1
8D1E64	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D1E75	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Upper limit value for regulation reached no reaction Check SCR System	A750		E	1
8D1F03	Engine uppercarr. SCR Urea (AdBlue) temperature sensor short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D1F04	Engine uppercarr. SCR Urea (AdBlue) temperature sensor short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1F08	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D1F09	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D1F0A	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D1F16	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Plausibility error no reaction Check components	A750		E	1
8D1F64	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D2003	Engine uppercarr. SCR Urea (AdBlue) pump short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D2004	Engine uppercarr. SCR Urea (AdBlue) pump short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D2008	Engine uppercarr. SCR Urea (AdBlue) pump Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D2017	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit of load no reaction Check wiring between control unit and components	A750		E	1
8D206C	Engine uppercarr. SCR Urea (AdBlue) pump Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D206D	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D206E	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D206F	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D2070	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D2082	Engine uppercarr. SCR Urea (AdBlue) pump Output current too high Engine reduction (Mach-FL) Check wiring between control unit and component - A776.X1	A750		E	1
8D2103	Engine uppercarr. SCR vent valve short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D2104	Engine uppercarr. SCR vent valve short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D2108	Engine uppercarr. SCR vent valve Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D216C	Engine uppercarr. SCR vent valve Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D216D	Engine uppercarr. SCR vent valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D216E	Engine uppercarr. SCR vent valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D216F	Engine uppercarr. SCR vent valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D2170	Engine uppercarr. SCR vent valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D2182	Engine uppercarr. SCR vent valve Output current too high Engine reduction (Mach-FL) Check wiring between control unit and component - A776.X2	A750		E	1
8D2203	Engine uppercarr. SCR connection compressed air short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D2204	Engine uppercarr. SCR connection compressed air short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D2208	Engine uppercarr. SCR connection compressed air Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D2217	Engine uppercarr. SCR connection compressed air Short circuit of load no reaction Check wiring between control unit and components	A750		E	1
8D226C	Engine uppercarr. SCR connection compressed air Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D226D	Engine uppercarr. SCR connection compressed air Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D226E	Engine uppercarr. SCR connection compressed air Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D226F	Engine uppercarr. SCR connection compressed air Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D2270	Engine uppercarr. SCR connection compressed air Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D2282	Engine uppercarr. SCR connection compressed air Output current too high Engine reduction (Mach-FL) Check wiring between control unit and component - A709	A750		E	1
8D2303	Engine uppercarr. SCR Air pressure sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D230B	Engine uppercarr. SCR Air pressure sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D2316	Engine uppercarr. SCR Air pressure sensor Plausibility error no reaction Check components	A750		E	1
8D2328	Engine uppercarr. SCR Air pressure sensor Pressure too high when connecting compressed air Inducement system activation (Mach-FL) Check SCR-System	A750		E	1
8D2329	Engine uppercarr. SCR Air pressure sensor Pressure too low when connecting compressed air Inducement system activation (Mach-FL) Check connections, air pump, urea pump, injector, replace components	A750		E	1
8D2364	Engine uppercarr. SCR Air pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2401	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Value above max. test range no reaction Check wiring between control unit and components	A750		E	1
8D2402	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Value below min. test range no reaction Check wiring between control unit and components	A750		E	1
8D2408	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D2409	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D2416	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Plausibility error no reaction Check components	A750		E	1
8D2418	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Short circuit no reaction Check wiring between control unit and components	A750		E	1
8D2501	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Value above max. test range no reaction Check wiring between control unit and components	A750		E	1
8D2502	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Value below min. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2508	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2518	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2519	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Fill level low Inducement system activation (Mach-FL) Refill urea tank	A750		E	1
8D2605	Engine uppercarr. Urea (AdBlue)-Tank Sampling unit Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D2701	Engine uppercarr. Urea (AdBlue)-Tank Quality sensor Value above max. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2702	Engine uppercarr. Urea (AdBlue)-Tank Quality sensor Value below min. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2746	Engine uppercarr. Urea (AdBlue)-Tank Quality sensor Optical error Inducement system activation (Mach-FL) Check components	A750		E	1
8D2803	Engine uppercarr. Battery temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D2804	Engine uppercarr. Battery temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D2808	Engine uppercarr. Battery temperature sensor Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D2816	Engine uppercarr. Battery temperature sensor Plausibility error no reaction Check components	A750		E	1
8D2864	Engine uppercarr. Battery temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2901	Engine uppercarr. Exhaust temperature sensor (before SCR) Value above max. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2903	Engine uppercarr. Exhaust temperature sensor (before SCR) short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2904	Engine uppercarr. Exhaust temperature sensor (before SCR) short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2908	Engine uppercarr. Exhaust temperature sensor (before SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2909	Engine uppercarr. Exhaust temperature sensor (before SCR) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D290A	Engine uppercarr. Exhaust temperature sensor (before SCR) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D2916	Engine uppercarr. Exhaust temperature sensor (before SCR) Plausibility error Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D291B	Engine uppercarr. Exhaust temperature sensor (before SCR) Invalid data no reaction Check wiring, sensor	A750		E	1
8D2964	Engine uppercarr. Exhaust temperature sensor (before SCR) Error supply voltage sensors Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2A01	Engine uppercarr. Exhaust temperature sensor (after SCR) Value above max. test range no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2A02	Engine uppercarr. Exhaust temperature sensor (after SCR) Value below min. test range no reaction Check wiring between control unit and components	A750		E	1
8D2A03	Engine uppercarr. Exhaust temperature sensor (after SCR) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D2A04	Engine uppercarr. Exhaust temperature sensor (after SCR) short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D2A08	Engine uppercarr. Exhaust temperature sensor (after SCR) Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D2A09	Engine uppercarr. Exhaust temperature sensor (after SCR) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D2A0A	Engine uppercarr. Exhaust temperature sensor (after SCR) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D2A16	Engine uppercarr. Exhaust temperature sensor (after SCR) Plausibility error no reaction Check wiring between control unit and components	A750		E	1
8D2A1B	Engine uppercarr. Exhaust temperature sensor (after SCR) Invalid data no reaction Check wiring, sensor	A750		E	1
8D2A64	Engine uppercarr. Exhaust temperature sensor (after SCR) Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D2B03	Engine uppercarr. Hydraulic oil temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2B04	Engine uppercarr. Hydraulic oil temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2B08	Engine uppercarr. Hydraulic oil temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2B09	Engine uppercarr. Hydraulic oil temperature sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D2B0A	Engine uppercarr. Hydraulic oil temperature sensor Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D2B64	Engine uppercarr. Hydraulic oil temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D2C03	Engine uppercarr. Starter short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D2C04	Engine uppercarr. Starter short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D2C08	Engine uppercarr. Starter Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D2C6C	Engine uppercarr. Starter Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D2C6D	Engine uppercarr. Starter Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2C6E	Engine uppercarr. Starter Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D2C6F	Engine uppercarr. Starter Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D2C70	Engine uppercarr. Starter Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D2C7C	Engine uppercarr. Starter Blocked due to excess temperature no reaction No remedy text	A750		E	1
8D2C82	Engine uppercarr. Starter Output current too high no reaction Check wiring between control unit and component - M700	A750		E	1
8D2E03	Engine uppercarr. Wastegate flap 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2E04	Engine uppercarr. Wastegate flap 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2E05	Engine uppercarr. Wastegate flap 1 Communication error no reaction Check wiring, flaps	A750		E	1
8D2E08	Engine uppercarr. Wastegate flap 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2E0A	Engine uppercarr. Wastegate flap 1 Value above critical threshold no reaction Check wiring, flaps	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2E17	Engine uppercarr. Wastegate flap 1 Short circuit of load Engine reduction 25% (Mach-FL) Check wiring between control unit and component - Y705	A750		E	1
8D2E34	Engine uppercarr. Wastegate flap 1 Hardware Error no reaction Check wiring, flaps	A750		E	1
8D2E36	Engine uppercarr. Wastegate flap 1 Calibration error no reaction Check wiring, flaps	A750		E	1
8D2E38	Engine uppercarr. Wastegate flap 1 Error Regulation deviation no reaction Check wiring, flaps	A750		E	1
8D2E39	Engine uppercarr. Wastegate flap 1 Error Absolute position no reaction Check wiring, flaps	A750		E	1
8D2E64	Engine uppercarr. Wastegate flap 1 Error supply voltage sensors no reaction Check wiring, flaps	A750		E	1
8D2E6C	Engine uppercarr. Wastegate flap 1 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A750		E	1
8D2E6D	Engine uppercarr. Wastegate flap 1 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2E6E	Engine uppercarr. Wastegate flap 1 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2E6F	Engine uppercarr. Wastegate flap 1 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2E70	Engine uppercarr. Wastegate flap 1 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2E81	Engine uppercarr. Wastegate flap 1 Position feedback not available no reaction Check wiring, flaps	A750		E	1
8D2E82	Engine uppercarr. Wastegate flap 1 Output current too high Engine reduction 25% (Mach-FL) Check wiring between control unit and component - Y705	A750		E	1
8D2F03	Engine uppercarr. Fuel supply valve 1 (VCV) short circuit to supply voltage Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2F04	Engine uppercarr. Fuel supply valve 1 (VCV) short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2F08	Engine uppercarr. Fuel supply valve 1 (VCV) Line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2F0A	Engine uppercarr. Fuel supply valve 1 (VCV) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D2F0C	Engine uppercarr. Fuel supply valve 1 (VCV) Value below critical threshold no reaction Check operation status of engine	A750		E	1
8D2F15	Engine uppercarr. Fuel supply valve 1 (VCV) Signal remains above nominal value no reaction Check wiring, components, control unit	A750		E	1
8D2F17	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit of load Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2F52	Engine uppercarr. Fuel supply valve 1 (VCV) PWM plausibility no reaction Check components	A750		E	1
8D2F6C	Engine uppercarr. Fuel supply valve 1 (VCV) Reg. deviation current value Engine derating 50% (Mach-FL) Report all error parameters to Service	A750		E	1
8D2F6D	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit after supply voltage Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2F6E	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit after supply voltage ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2F6F	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit after ground Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2F70	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit after ground, ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D2F74	Engine uppercarr. Fuel supply valve 1 (VCV) Lower limit value for regulation reached no reaction No measure required	A750		E	1
8D2F82	Engine uppercarr. Fuel supply valve 1 (VCV) Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y703	A750		E	1
8D3003	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) short circuit to supply voltage Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3004	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3008	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D300A	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D300C	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Value below critical threshold no reaction Check operation status of engine	A750		E	1
8D300E	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Signal increases too fast no reaction Check components	A750		E	1
8D300F	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Signal decreases too fast no reaction Check components	A750		E	1
8D3015	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Signal remains above nominal value no reaction Check wiring, components, control unit	A750		E	1
8D3017	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit of load Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D301D	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) PCV Flow regulation upper stop no reaction Check components	A750		E	1
8D301E	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) PCV Flow regulation lower stop no reaction Check components	A750		E	1
8D3052	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) PWM plausibility no reaction Check components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D305D	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) PCV open due to excess pressure no reaction Check operation status of engine	A750		E	1
8D306C	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Reg. deviation current value Engine derating 50% (Mach-FL) Report all error parameters to Service	A750		E	1
8D306D	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit after supply voltage Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D306E	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit after supply voltage ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D306F	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit after ground Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3070	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit after ground, ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3074	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Lower limit value for regulation reached no reaction No measure required	A750		E	1
8D3082	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y707	A750		E	1
8D3105	Engine uppercarr. Exhaust return valve 1 Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D3121	Engine uppercarr. Exhaust return valve 1 Voltage outside permissible range Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3133	Engine uppercarr. Exhaust return valve 1 Data transfer CAN problematic Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D3134	Engine uppercarr. Exhaust return valve 1 Hardware Error Engine derating 25% (Mach-FL) Check module	A750		E	1
8D3135	Engine uppercarr. Exhaust return valve 1 Excess temperature error Engine derating 25% (Mach-FL) Check cooling of module	A750		E	1
8D3136	Engine uppercarr. Exhaust return valve 1 Calibration error Engine derating 25% (Mach-FL) Check module	A750		E	1
8D3137	Engine uppercarr. Exhaust return valve 1 Error Reference position Engine derating 25% (Mach-FL) Check module	A750		E	1
8D3138	Engine uppercarr. Exhaust return valve 1 Error Regulation deviation Engine derating 25% (Mach-FL) Check components	A750		E	1
8D3139	Engine uppercarr. Exhaust return valve 1 Error Absolute position Engine derating 25% (Mach-FL) Check module	A750		E	1
8D3181	Engine uppercarr. Exhaust return valve 1 Position feedback not available Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8D3303	Engine uppercarr. Injector 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3304	Engine uppercarr. Injector 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3308	Engine uppercarr. Injector 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D331F	Engine uppercarr. Injector 1 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3320	Engine uppercarr. Injector 1 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3383	Engine uppercarr. Injector 1 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D3386	Engine uppercarr. Injector 1 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D3387	Engine uppercarr. Injector 1 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D3403	Engine uppercarr. Injector 2 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3404	Engine uppercarr. Injector 2 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3408	Engine uppercarr. Injector 2 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D341F	Engine uppercarr. Injector 2 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3420	Engine uppercarr. Injector 2 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3483	Engine uppercarr. Injector 2 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D3486	Engine uppercarr. Injector 2 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D3487	Engine uppercarr. Injector 2 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D3503	Engine uppercarr. Injector 3 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3504	Engine uppercarr. Injector 3 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3508	Engine uppercarr. Injector 3 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D351F	Engine uppercarr. Injector 3 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3520	Engine uppercarr. Injector 3 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3583	Engine uppercarr. Injector 3 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3586	Engine uppercarr. Injector 3 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D3587	Engine uppercarr. Injector 3 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D3603	Engine uppercarr. Injector 4 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3604	Engine uppercarr. Injector 4 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3608	Engine uppercarr. Injector 4 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D361F	Engine uppercarr. Injector 4 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3620	Engine uppercarr. Injector 4 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3683	Engine uppercarr. Injector 4 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D3686	Engine uppercarr. Injector 4 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D3687	Engine uppercarr. Injector 4 Minimum quantity correction faulty no reaction No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3703	Engine uppercarr. Injector 5 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3704	Engine uppercarr. Injector 5 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3708	Engine uppercarr. Injector 5 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D371F	Engine uppercarr. Injector 5 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3720	Engine uppercarr. Injector 5 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3783	Engine uppercarr. Injector 5 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D3786	Engine uppercarr. Injector 5 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D3787	Engine uppercarr. Injector 5 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D3803	Engine uppercarr. Injector 6 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3804	Engine uppercarr. Injector 6 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3808	Engine uppercarr. Injector 6 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D381F	Engine uppercarr. Injector 6 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3820	Engine uppercarr. Injector 6 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3883	Engine uppercarr. Injector 6 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D3886	Engine uppercarr. Injector 6 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D3887	Engine uppercarr. Injector 6 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D3903	Engine uppercarr. Injector 7 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3904	Engine uppercarr. Injector 7 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3908	Engine uppercarr. Injector 7 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D391F	Engine uppercarr. Injector 7 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3920	Engine uppercarr. Injector 7 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3983	Engine uppercarr. Injector 7 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D3986	Engine uppercarr. Injector 7 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D3987	Engine uppercarr. Injector 7 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D3A03	Engine uppercarr. Injector 8 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3A04	Engine uppercarr. Injector 8 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3A08	Engine uppercarr. Injector 8 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3A1F	Engine uppercarr. Injector 8 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3A20	Engine uppercarr. Injector 8 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750		E	1
8D3A83	Engine uppercarr. Injector 8 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3A86	Engine uppercarr. Injector 8 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D3A87	Engine uppercarr. Injector 8 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D3B03	Engine uppercarr. Travel pedal sensor 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D3B0B	Engine uppercarr. Travel pedal sensor 1 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D3C03	Engine uppercarr. Travel pedal sensor 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D3C0B	Engine uppercarr. Travel pedal sensor 2 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D3D16	Engine uppercarr. Travel pedal sensor Plausibility error no reaction Check wiring between control unit and components	A750		E	1
8D3E03	Engine uppercarr. Fan 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3E04	Engine uppercarr. Fan 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3E08	Engine uppercarr. Fan 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3E17	Engine uppercarr. Fan 1 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3E6C	Engine uppercarr. Fan 1 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A750		E	1
8D3E6D	Engine uppercarr. Fan 1 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3E6E	Engine uppercarr. Fan 1 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3E6F	Engine uppercarr. Fan 1 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3E70	Engine uppercarr. Fan 1 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3E82	Engine uppercarr. Fan 1 Output current too high no reaction Check wiring between control unit and component - Y718	A750		E	1
8D3F03	Engine uppercarr. Fan 2 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3F04	Engine uppercarr. Fan 2 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3F08	Engine uppercarr. Fan 2 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3F17	Engine uppercarr. Fan 2 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3F6C	Engine uppercarr. Fan 2 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A750		E	1
8D3F6D	Engine uppercarr. Fan 2 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3F6E	Engine uppercarr. Fan 2 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3F6F	Engine uppercarr. Fan 2 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3F70	Engine uppercarr. Fan 2 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D3F82	Engine uppercarr. Fan 2 Output current too high no reaction Check wiring between control unit and component - Y719	A750		E	1
8D4003	Engine uppercarr. Alternator 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D4004	Engine uppercarr. Alternator 1 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D4221	Engine uppercarr. Motor Sensor supply U_VCC-M1 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D4321	Engine uppercarr. Motor Sensor supply U_VCC-M2 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4421	Engine uppercarr. Motor Sensor supply U_VCC-M3 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4521	Engine uppercarr. Motor Sensor supply U_VCC-M4 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4621	Engine uppercarr. Motor Sensor supply U_VCC-M5 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4721	Engine uppercarr. Motor Sensor supply U_VCC-M6 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4821	Engine uppercarr. Motor Sensor supply U_VCC-M7 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4921	Engine uppercarr. Machine Sensor supply U_VCC-G1 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4A21	Engine uppercarr. Machine Sensor supply U_VCC-G2 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4B21	Engine uppercarr. Machine Sensor supply U_VCC-G3 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750		E	1
8D4C21	Engine uppercarr. Motor Sensor supply U_UBATT-M1 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D4D21	Engine uppercarr. Motor Sensor supply U_UBATT-M2 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D4E21	Engine uppercarr. Machine Sensor supply U_UBATT-G1 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D4F21	Engine uppercarr. Machine Sensor supply U_UBATT-G2 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5021	Engine uppercarr. Machine Sensor supply U_UBATT-G3 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5121	Engine uppercarr. Machine Sensor supply U_UBATT-G4 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5221	Engine uppercarr. Machine Sensor supply U_UBATT-G5 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5321	Engine uppercarr. Internal Sensor supply U_VCC_SENSOR 1 Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5421	Engine uppercarr. Internal Sensor supply U_VDD_SENSOR 2 Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5521	Engine uppercarr. Internal Sensor supply U_BATT_SENSOR (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5621	Engine uppercarr. Temperature sensor supply U_TI_VCC_5V Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D5722	Engine uppercarr. Injection time Pre-injection before injection too close to pre-injection no reaction 0	A750		E	1
8D5723	Engine uppercarr. Injection time Pre-injecton too close to main injection no reaction 0	A750		E	1
8D5724	Engine uppercarr. Injection time Post-injection too close to main injection no reaction 0	A750		E	1
8D5725	Engine uppercarr. Injection time Late post-injection too close to post-injection no reaction 0	A750		E	1
8D5814	Engine uppercarr. SCR System (pressure air pump) Signal remains below nominal value Inducement system activation (Mach-FL) Check SCR-System	A750		E	1
8D582C	Engine uppercarr. SCR System (pressure air pump) Status erroneous Inducement system activation (Mach-FL) 1) check lines for air supply 2) check fuse for air pump 3) check air supply system	A750		E	1
8D5927	Engine uppercarr. SCR System Urea (AdBlue) nozzle plugged Inducement system activation (Mach-FL) Check SCR-System	A750		E	1
8D592A	Engine uppercarr. SCR System Interruption of ventilation procedure no reaction Check components	A750		E	1
8D5931	Engine uppercarr. SCR System Bad efficiency of NOX-reduction no reaction Check SCR-System	A750		E	1
8D5932	Engine uppercarr. SCR System Very bad efficiency of NOX-reduction Inducement system activation (Mach-FL) Check SCR-System	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D596B	Engine uppercarr. SCR System Last venting of AdBlue line interrupted no reaction Report all error parameters to Service	A750		E	1
8D5984	Engine uppercarr. SCR System Air and urea pressure sensors on the urea pump reversed Engine reduction (Mach-FL) No remedy text	A750		E	1
8D5990	Engine uppercarr. SCR System Cleaning of SCR catalytic converter (HC) not feasible no reaction No remedy text	A750		E	1
8D599F	Engine uppercarr. SCR System Maximum urea thawing time (AdBlue) exceeded no reaction Check wiring, sensors, heating circuit	A750		E	1
8D5A08	Engine uppercarr. NOX Sensor (before SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D5A18	Engine uppercarr. NOX Sensor (before SCR) Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D5A1B	Engine uppercarr. NOX Sensor (before SCR) Invalid data Inducement system activation (Mach-FL) Check operation status of engine	A750		E	1
8D5A2E	Engine uppercarr. NOX Sensor (before SCR) Sensor removed from exhaust line Inducement system activation (Mach-FL) Check components	A750		E	1
8D5A2F	Engine uppercarr. NOX Sensor (before SCR) Heating element broken Inducement system activation (Mach-FL) Check wiring, replace components	A750		E	1
8D5A30	Engine uppercarr. NOX Sensor (before SCR) Offset Error Inducement system activation (Mach-FL) Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D5B05	Engine uppercarr. NOX Sensor (after SCR) Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D5B08	Engine uppercarr. NOX Sensor (after SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D5B18	Engine uppercarr. NOX Sensor (after SCR) Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D5B1B	Engine uppercarr. NOX Sensor (after SCR) Invalid data Inducement system activation (Mach-FL) Check operation status of engine	A750		E	1
8D5B2E	Engine uppercarr. NOX Sensor (after SCR) Sensor removed from exhaust line Inducement system activation (Mach-FL) Check wiring, replace components	A750		E	1
8D5B2F	Engine uppercarr. NOX Sensor (after SCR) Heating element broken Inducement system activation (Mach-FL) Check wiring, replace components	A750		E	1
8D5B30	Engine uppercarr. NOX Sensor (after SCR) Offset Error Inducement system activation (Mach-FL) Check operation status of engine	A750		E	1
8D5C01	Engine uppercarr. Regulation alternator (voltage signal) Value above max. test range no reaction Check wiring between control unit and components	A750		E	1
8D5C06	Engine uppercarr. Regulation alternator (voltage signal) internal error no reaction Check components	A750		E	1
8D5C38	Engine uppercarr. Regulation alternator (voltage signal) Error Regulation deviation no reaction Check components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D5C4E	Engine uppercarr. Regulation alternator (voltage signal) Overload no reaction Check components	A750		E	1
8D5C4F	Engine uppercarr. Regulation alternator (voltage signal) Error when engine running no reaction Check components	A750		E	1
8D5C50	Engine uppercarr. Regulation alternator (voltage signal) Error intelligent alternator no reaction Check components	A750		E	1
8D5C51	Engine uppercarr. Regulation alternator (voltage signal) Fuse defective no reaction Check components	A750		E	1
8D5C88	Engine uppercarr. Regulation alternator (voltage signal) Alternating control deviation alternator voltage no reaction No remedy text	A750		E	1
8D5C89	Engine uppercarr. Regulation alternator (voltage signal) Alternator shut-off faulty no reaction No remedy text	A750		E	1
8D5D16	Engine uppercarr. Air filter monitor pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check components	A750		E	1
8D5F05	Engine uppercarr. NOX Sensor Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D5F2D	Engine uppercarr. NOX Sensor Installation error Inducement system activation (Mach-FL) Check installation, position of sensors	A750		E	1
8D5F8F	Engine uppercarr. NOX Sensor Deviating measuring accuracy (drift) no reaction Check sensor value, sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D6003	Engine uppercarr. Distributor gear temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D6004	Engine uppercarr. Distributor gear temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D6008	Engine uppercarr. Distributor gear temperature sensor Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D6009	Engine uppercarr. Distributor gear temperature sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D600A	Engine uppercarr. Distributor gear temperature sensor Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D6064	Engine uppercarr. Distributor gear temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D6103	Engine uppercarr. Supply relay Engine sensory short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D6104	Engine uppercarr. Supply relay Engine sensory short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D6108	Engine uppercarr. Supply relay Engine sensory Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D616C	Engine uppercarr. Supply relay Engine sensory Reg. deviation current value Inducement system activation (Mach-FL) Report all error parameters to Service	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D616D	Engine uppercarr. Supply relay Engine sensory Short circuit after supply voltage Plus switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D616E	Engine uppercarr. Supply relay Engine sensory Short circuit after supply voltage ground switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D616F	Engine uppercarr. Supply relay Engine sensory Short circuit after ground Plus switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D6170	Engine uppercarr. Supply relay Engine sensory Short circuit after ground, ground switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D6182	Engine uppercarr. Supply relay Engine sensory Output current too high Engine reduction (Mach-FL) Check wiring between control unit and component - K700	A750		E	1
8D6233	Engine uppercarr. AMET CAN (CAN ID 585) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6333	Engine uppercarr. AMET CAN (CAN ID 594) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6433	Engine uppercarr. BAUMA CAN Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D647E	Engine uppercarr. BAUMA CAN invalid I/O configuration, master file no reaction Check I/O-Config file on Master Flash card	A750		E	1
8D6533	Engine uppercarr. ABS Control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D6633	Engine uppercarr. ABS Control unit 2 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6733	Engine uppercarr. Coupling regulation Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6833	Engine uppercarr. CAN signal transmission control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6933	Engine uppercarr. CAN signal transmission control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6A33	Engine uppercarr. CAN signal transmission control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6B33	Engine uppercarr. Retarder control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6C33	Engine uppercarr. CAN- signal I/O module Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6D33	Engine uppercarr. CAN- signal I/O module Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6E33	Engine uppercarr. CAN- signal I/O module Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6F07	Engine uppercarr. Supply voltage Value below warning threshold no reaction Check control unit, supplies, battery voltage	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D6F09	Engine uppercarr. Supply voltage Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D6F0A	Engine uppercarr. Supply voltage Value above critical threshold no reaction No remedy text	A750		E	1
8D6F64	Engine uppercarr. Supply voltage Error supply voltage sensors no reaction No remedy text	A750		E	1
8D6FA3	Engine uppercarr. Supply voltage Supply voltage term.30 switched off during ECU shut off delay no reaction Check wiring, fuses	A750		E	1
8D7005	Engine uppercarr. Exhaust flap 1 Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D7033	Engine uppercarr. Exhaust flap 1 Data transfer CAN problematic Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D7034	Engine uppercarr. Exhaust flap 1 Hardware Error Inducement system activation (Mach-FL) Check module	A750		E	1
8D7035	Engine uppercarr. Exhaust flap 1 Excess temperature error Inducement system activation (Mach-FL) Check cooling of module	A750		E	1
8D7036	Engine uppercarr. Exhaust flap 1 Calibration error Inducement system activation (Mach-FL) Check module	A750		E	1
8D7037	Engine uppercarr. Exhaust flap 1 Error Reference position Inducement system activation (Mach-FL) Check module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7038	Engine uppercarr. Exhaust flap 1 Error Regulation deviation Engine derating 50% (Mach-FL) Check components	A750		E	1
8D7039	Engine uppercarr. Exhaust flap 1 Error Absolute position Inducement system activation (Mach-FL) Check module	A750		E	1
8D7121	Engine uppercarr. Supply voltage exhaust flap 1 Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D7181	Engine uppercarr. Supply voltage exhaust flap 1 Position feedback not available Engine reduction (Mach-FL) No remedy text	A750		E	1
8D7203	Engine uppercarr. Exhaust temperature sensor (before DOC) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7204	Engine uppercarr. Exhaust temperature sensor (before DOC) short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D7208	Engine uppercarr. Exhaust temperature sensor (before DOC) Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D7209	Engine uppercarr. Exhaust temperature sensor (before DOC) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D720A	Engine uppercarr. Exhaust temperature sensor (before DOC) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D7216	Engine uppercarr. Exhaust temperature sensor (before DOC) Plausibility error no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D721B	Engine uppercarr. Exhaust temperature sensor (before DOC) Invalid data no reaction Check wiring, fuses	A750		E	1
8D7264	Engine uppercarr. Exhaust temperature sensor (before DOC) Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D7303	Engine uppercarr. Actuation central lubrication system short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7304	Engine uppercarr. Actuation central lubrication system short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D7308	Engine uppercarr. Actuation central lubrication system Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D736C	Engine uppercarr. Actuation central lubrication system Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D736D	Engine uppercarr. Actuation central lubrication system Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D736E	Engine uppercarr. Actuation central lubrication system Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D736F	Engine uppercarr. Actuation central lubrication system Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D7370	Engine uppercarr. Actuation central lubrication system Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7382	Engine uppercarr. Actuation central lubrication system Output current too high no reaction Check wiring between control unit and components	A750		E	1
8D7403	Engine uppercarr. Actuation Air flap short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7404	Engine uppercarr. Actuation Air flap short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D7408	Engine uppercarr. Actuation Air flap Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D746C	Engine uppercarr. Actuation Air flap Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D746D	Engine uppercarr. Actuation Air flap Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D746E	Engine uppercarr. Actuation Air flap Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D746F	Engine uppercarr. Actuation Air flap Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D7470	Engine uppercarr. Actuation Air flap Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D7482	Engine uppercarr. Actuation Air flap Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7503	Engine uppercarr. Machine configurable lamp outlet 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7504	Engine uppercarr. Machine configurable lamp outlet 1 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D7508	Engine uppercarr. Machine configurable lamp outlet 1 Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D756C	Engine uppercarr. Machine configurable lamp outlet 1 Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D756D	Engine uppercarr. Machine configurable lamp outlet 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D756E	Engine uppercarr. Machine configurable lamp outlet 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D756F	Engine uppercarr. Machine configurable lamp outlet 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D7570	Engine uppercarr. Machine configurable lamp outlet 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D7603	Engine uppercarr. Engine stop warning light output (RSL) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7604	Engine uppercarr. Engine stop warning light output (RSL) short circuit to ground no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7608	Engine uppercarr. Engine stop warning light output (RSL) Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D766C	Engine uppercarr. Engine stop warning light output (RSL) Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8D766D	Engine uppercarr. Engine stop warning light output (RSL) Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D766E	Engine uppercarr. Engine stop warning light output (RSL) Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D766F	Engine uppercarr. Engine stop warning light output (RSL) Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D7670	Engine uppercarr. Engine stop warning light output (RSL) Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D7705	Engine uppercarr. Ammonia sensor Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D7706	Engine uppercarr. Ammonia sensor internal error Engine derating 25% (Mach-FL) Check components	A750		E	1
8D7709	Engine uppercarr. Ammonia sensor Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D773A	Engine uppercarr. Ammonia sensor Error Heater element Engine derating 25% (Mach-FL) Check wiring, replace components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D773B	Engine uppercarr. Ammonia sensor Error Resistance Engine derating 25% (Mach-FL) Check components	A750		E	1
8D773C	Engine uppercarr. Ammonia sensor Error Trim calibration Engine derating 25% (Mach-FL) Check wiring between module and sensor, replace sensor	A750		E	1
8D773D	Engine uppercarr. Ammonia sensor Electric error Engine derating 25% (Mach-FL) Check components	A750		E	1
8D774B	Engine uppercarr. Ammonia sensor Error supply heating element Engine derating 25% (Mach-FL) Check wiring, replace components	A750		E	1
8D7805	Engine uppercarr. Water pump Communication error no reaction Check wiring, CAN-participant	A750		E	1
8D783E	Engine uppercarr. Water pump Rpm nominal value cannot be reached no reaction Check components	A750		E	1
8D7857	Engine uppercarr. Water pump Engine error no reaction Check components	A750		E	1
8D793F	Engine uppercarr. Injector supply voltage Up converter cannot reach nominal current no reaction Check control unit	A750		E	1
8D7A40	Engine uppercarr. Emergency stop Signal KI.15 on during active emerg. stop no reaction Check emerg. stop, Turn ignition off/on	A750		E	1
8D7B09	Engine uppercarr. Alternator 1 (Output voltage) Value above warning threshold no reaction Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7B0A	Engine uppercarr. Alternator 1 (Output voltage) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D7B0B	Engine uppercarr. Alternator 1 (Output voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D7B64	Engine uppercarr. Alternator 1 (Output voltage) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8D7C03	Engine uppercarr. Temperature sensor after charge air cooler short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7C04	Engine uppercarr. Temperature sensor after charge air cooler short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D7C08	Engine uppercarr. Temperature sensor after charge air cooler Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D7C09	Engine uppercarr. Temperature sensor after charge air cooler Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D7C0A	Engine uppercarr. Temperature sensor after charge air cooler Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D7C16	Engine uppercarr. Temperature sensor after charge air cooler Plausibility error no reaction No remedy text	A750		E	1
8D7C64	Engine uppercarr. Temperature sensor after charge air cooler Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7D03	Engine uppercarr. Alternator 1 (Frequency input) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7D04	Engine uppercarr. Alternator 1 (Frequency input) short circuit to ground no reaction Check wiring, alternator	A750		E	1
8D7D0B	Engine uppercarr. Alternator 1 (Frequency input) Short circuit after ground or line interruption no reaction Check wiring, alternator	A750		E	1
8D7D0D	Engine uppercarr. Alternator 1 (Frequency input) Short circuit after supply voltage or line interruption no reaction Check wiring, alternator	A750		E	1
8D7D64	Engine uppercarr. Alternator 1 (Frequency input) Error supply voltage sensors no reaction Check wiring, alternator	A750		E	1
8D7E03	Engine uppercarr. Alternator 2 (Output voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7E04	Engine uppercarr. Alternator 2 (Output voltage) short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D7E08	Engine uppercarr. Alternator 2 (Output voltage) Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D7E09	Engine uppercarr. Alternator 2 (Output voltage) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D7E0A	Engine uppercarr. Alternator 2 (Output voltage) Value above critical threshold no reaction Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7E16	Engine uppercarr. Alternator 2 (Output voltage) Plausibility error no reaction No remedy text	A750		E	1
8D7E64	Engine uppercarr. Alternator 2 (Output voltage) Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D7F03	Engine uppercarr. Alternator 2 (Lamp) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D7F09	Engine uppercarr. Alternator 2 (Lamp) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D7F0A	Engine uppercarr. Alternator 2 (Lamp) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D7F0B	Engine uppercarr. Alternator 2 (Lamp) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D7F64	Engine uppercarr. Alternator 2 (Lamp) Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D7F72	Engine uppercarr. Alternator 2 (Lamp) Charge air pr. too high no reaction No remedy text	A750		E	1
8D7F73	Engine uppercarr. Alternator 2 (Lamp) Charge air pr. too low no reaction No remedy text	A750		E	1
8D8014	Engine uppercarr. SCR metering regulator Signal remains below nominal value no reaction Check components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8015	Engine uppercarr. SCR metering regulator Signal remains above nominal value no reaction Check components	A750		E	1
8D8074	Engine uppercarr. SCR metering regulator Lower limit value for regulation reached no reaction No measure required	A750		E	1
8D8075	Engine uppercarr. SCR metering regulator Upper limit value for regulation reached no reaction No measure required	A750		E	1
8D8105	Engine uppercarr. Exhaust flap 2 Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D8133	Engine uppercarr. Exhaust flap 2 Data transfer CAN problematic Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750		E	1
8D8134	Engine uppercarr. Exhaust flap 2 Hardware Error Inducement system activation (Mach-FL) Check module	A750		E	1
8D8135	Engine uppercarr. Exhaust flap 2 Excess temperature error Inducement system activation (Mach-FL) Check cooling of module	A750		E	1
8D8136	Engine uppercarr. Exhaust flap 2 Calibration error Inducement system activation (Mach-FL) Check module	A750		E	1
8D8137	Engine uppercarr. Exhaust flap 2 Error Reference position Inducement system activation (Mach-FL) Check module	A750		E	1
8D8138	Engine uppercarr. Exhaust flap 2 Error Regulation deviation Engine derating 50% (Mach-FL) Check components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8139	Engine uppercarr. Exhaust flap 2 Error Absolute position Inducement system activation (Mach-FL) Check module	A750		E	1
8D8221	Engine uppercarr. Supply voltage exhaust flap 2 Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D8281	Engine uppercarr. Supply voltage exhaust flap 2 Position feedback not available Engine reduction (Mach-FL) No remedy text	A750		E	1
8D8304	Engine uppercarr. Digital input Starter signal short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D8308	Engine uppercarr. Digital input Starter signal Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D8321	Engine uppercarr. Digital input Starter signal Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8D835B	Engine uppercarr. Digital input Starter signal Start block due to a short circuit no reaction Check wiring, components, control unit	A750		E	1
8D8364	Engine uppercarr. Digital input Starter signal Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D8408	Engine uppercarr. Digital input emerg. off Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D8421	Engine uppercarr. Digital input emerg. off Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8464	Engine uppercarr. Digital input emerg. off Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D8508	Engine uppercarr. Digital input test bench operation Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D8521	Engine uppercarr. Digital input test bench operation Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8D8564	Engine uppercarr. Digital input test bench operation Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D8608	Engine uppercarr. Digital input emerg. run rpm Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D8621	Engine uppercarr. Digital input emerg. run rpm Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8D8664	Engine uppercarr. Digital input emerg. run rpm Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D8708	Engine uppercarr. Digital input LWE emerg. Op. Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D8721	Engine uppercarr. Digital input LWE emerg. Op. Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8D8764	Engine uppercarr. Digital input LWE emerg. Op. Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8803	Engine uppercarr. Digital input Slave short circuit to supply voltage Inducement system activated Check wiring	A750		E	1
8D8804	Engine uppercarr. Digital input Slave short circuit to ground Inducement system activated Check wiring	A750		E	1
8D8808	Engine uppercarr. Digital input Slave Line interruption Inducement system activated Check wiring	A750		E	1
8D880B	Engine uppercarr. Digital input Slave Short circuit after ground or line interruption Inducement system activated Check wiring	A750		E	1
8D880D	Engine uppercarr. Digital input Slave Short circuit after supply voltage or line interruption Inducement system activated Check wiring	A750		E	1
8D8821	Engine uppercarr. Digital input Slave Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8D8864	Engine uppercarr. Digital input Slave Error supply voltage sensors Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D8907	Engine uppercarr. Reductions because of exhaust quality Value below warning threshold no reaction Read out error stack and note other system errors	A750		E	1
8D8941	Engine uppercarr. Reductions because of exhaust quality Power or speed limitation active no reaction Read out error stack and note other system errors	A750		E	1
8D8942	Engine uppercarr. Reductions because of exhaust quality Increased power or speed limitation active no reaction Read out error stack and note other system errors	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8943	Engine uppercarr. Reductions because of exhaust quality Blocked in increased power or speed limitation no reaction Read out error stack and note other system errors	A750		E	1
8D8944	Engine uppercarr. Reductions because of exhaust quality Engine start block due to empty urea tank no reaction Read out error stack and note other system errors	A750		E	1
8D8A38	Engine uppercarr. Signals vehicle speed Error Regulation deviation no reaction Check components	A750		E	1
8D8B21	Engine uppercarr. Urea (AdBlue) Quality Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D8B76	Engine uppercarr. Urea (AdBlue) Quality Urea quality outside tolerance range Inducement system activation (Mach-FL) 1) Empty, clean AdBlue tank, replace contents 2) check AdBlue sampling module, clean	A750		E	1
8D8BA4	Engine uppercarr. Urea (AdBlue) Quality Incorrect reducing agent Inducement system activated Check wiring	A750		E	1
8D8C08	Engine uppercarr. Data transfer CAN 1 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A750		E	1
8D8C18	Engine uppercarr. Data transfer CAN 1 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D8CA5	Engine uppercarr. Data transfer CAN 1 NOX emission values too high Inducement system activated Check wiring	A750		E	1
8D8D08	Engine uppercarr. Data transfer CAN 2 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8D18	Engine uppercarr. Data transfer CAN 2 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D8E08	Engine uppercarr. Data transfer CAN 3 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A750		E	1
8D8E18	Engine uppercarr. Data transfer CAN 3 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D8F03	Engine uppercarr. Injector 9 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D8F04	Engine uppercarr. Injector 9 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D8F08	Engine uppercarr. Injector 9 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D8F1F	Engine uppercarr. Injector 9 No current increase time measureable no reaction Check wiring, components, control unit	A750		E	1
8D8F20	Engine uppercarr. Injector 9 Current increase time too long no reaction Check wiring, components, control unit	A750		E	1
8D8F83	Engine uppercarr. Injector 9 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D8F86	Engine uppercarr. Injector 9 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8F87	Engine uppercarr. Injector 9 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D9003	Engine uppercarr. Injector 10 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D9004	Engine uppercarr. Injector 10 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D9008	Engine uppercarr. Injector 10 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D901F	Engine uppercarr. Injector 10 No current increase time measureable no reaction Check wiring, components, control unit	A750		E	1
8D9020	Engine uppercarr. Injector 10 Current increase time too long no reaction Check wiring, components, control unit	A750		E	1
8D9083	Engine uppercarr. Injector 10 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D9086	Engine uppercarr. Injector 10 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D9087	Engine uppercarr. Injector 10 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D9103	Engine uppercarr. Injector 11 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9104	Engine uppercarr. Injector 11 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D9108	Engine uppercarr. Injector 11 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D911F	Engine uppercarr. Injector 11 No current increase time measureable no reaction Check wiring, components, control unit	A750		E	1
8D9120	Engine uppercarr. Injector 11 Current increase time too long no reaction Check wiring, components, control unit	A750		E	1
8D9183	Engine uppercarr. Injector 11 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D9186	Engine uppercarr. Injector 11 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D9187	Engine uppercarr. Injector 11 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D9203	Engine uppercarr. Injector 12 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D9204	Engine uppercarr. Injector 12 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D9208	Engine uppercarr. Injector 12 Line interruption no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D921F	Engine uppercarr. Injector 12 No current increase time measureable no reaction Check wiring, components, control unit	A750		E	1
8D9220	Engine uppercarr. Injector 12 Current increase time too long no reaction Check wiring, components, control unit	A750		E	1
8D9283	Engine uppercarr. Injector 12 Voltage regulated minimum quantities adaptation failed no reaction No remedy text	A750		E	1
8D9286	Engine uppercarr. Injector 12 Minimum quantity correction calculation faulty no reaction No remedy text	A750		E	1
8D9287	Engine uppercarr. Injector 12 Minimum quantity correction faulty no reaction No remedy text	A750		E	1
8D930A	Engine uppercarr. Fuel supply valve 2 (VCV) Value above critical threshold no reaction No remedy text	A750		E	1
8D930C	Engine uppercarr. Fuel supply valve 2 (VCV) Value below critical threshold no reaction No remedy text	A750		E	1
8D9533	Engine uppercarr. CAN-message machine control (TSC1) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D9603	Engine uppercarr. Fan 3 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D9604	Engine uppercarr. Fan 3 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9608	Engine uppercarr. Fan 3 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D9617	Engine uppercarr. Fan 3 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D966C	Engine uppercarr. Fan 3 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A750		E	1
8D966D	Engine uppercarr. Fan 3 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D966E	Engine uppercarr. Fan 3 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D966F	Engine uppercarr. Fan 3 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D9670	Engine uppercarr. Fan 3 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8D9682	Engine uppercarr. Fan 3 Output current too high no reaction Check wiring between control unit and components	A750		E	1
8D9708	Engine uppercarr. Fuel supply valve 2 (VCV) Line interruption Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A750		E	1
8D9717	Engine uppercarr. Fuel supply valve 2 (VCV) Short circuit of load Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9752	Engine uppercarr. Fuel supply valve 2 (VCV) PWM plausibility no reaction No action necessary	A750		E	1
8D976C	Engine uppercarr. Fuel supply valve 2 (VCV) Reg. deviation current value Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A750		E	1
8D976D	Engine uppercarr. Fuel supply valve 2 (VCV) Short circuit after supply voltage Plus switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A750		E	1
8D976E	Engine uppercarr. Fuel supply valve 2 (VCV) Short circuit after supply voltage ground switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A750		E	1
8D976F	Engine uppercarr. Fuel supply valve 2 (VCV) Short circuit after ground Plus switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A750		E	1
8D9770	Engine uppercarr. Fuel supply valve 2 (VCV) Short circuit after ground, ground switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A750		E	1
8D9774	Engine uppercarr. Fuel supply valve 2 (VCV) Lower limit value for regulation reached no reaction No action necessary	A750		E	1
8D9782	Engine uppercarr. Fuel supply valve 2 (VCV) Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y704	A750		E	1
8D9808	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Line interruption Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A750		E	1
8D980A	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Value above critical threshold no reaction No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9817	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Short circuit of load Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A750		E	1
8D9852	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) PWM plausibility no reaction No remedy text	A750		E	1
8D985D	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) PCV open due to excess pressure no reaction No remedy text	A750		E	1
8D986C	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Reg. deviation current value Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A750		E	1
8D986D	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Short circuit after supply voltage Plus switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A750		E	1
8D986E	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Short circuit after supply voltage ground switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A750		E	1
8D986F	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Short circuit after ground Plus switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A750		E	1
8D9870	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Short circuit after ground, ground switch Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A750		E	1
8D9874	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Lower limit value for regulation reached no reaction No action necessary	A750		E	1
8D9882	Engine uppercarr. Fuel high pressure regulating valve 2 (PCV) Output current too high Engine reduction 50% (Mach-FL) Check wiring between control unit and component - Y708	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9914	Engine uppercarr. Fuel supply valve 2 (VCV) power regulation Signal remains below nominal value no reaction No action necessary	A750		E	1
8D9915	Engine uppercarr. Fuel supply valve 2 (VCV) power regulation Signal remains above nominal value no reaction No action necessary	A750		E	1
8D9A14	Engine uppercarr. Fuel high pressure regulating valve 2 PCV flow reg Signal remains below nominal value no reaction No action necessary	A750		E	1
8D9A15	Engine uppercarr. Fuel high pressure regulating valve 2 PCV flow reg Signal remains above nominal value no reaction No action necessary	A750		E	1
8D9B14	Engine uppercarr. Fuel high pressure regulating valve (PCV) flow reg Signal remains below nominal value no reaction Check wiring, components, control unit	A750		E	1
8D9B15	Engine uppercarr. Fuel high pressure regulating valve (PCV) flow reg Signal remains above nominal value no reaction Check wiring, components, control unit	A750		E	1
8D9C03	Engine uppercarr. Actuation after run relay short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D9C04	Engine uppercarr. Actuation after run relay short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D9C08	Engine uppercarr. Actuation after run relay Line interruption no reaction Check wiring, wiring harness	A750		E	1
8D9C6C	Engine uppercarr. Actuation after run relay Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9C6D	Engine uppercarr. Actuation after run relay Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D9C6E	Engine uppercarr. Actuation after run relay Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8D9C6F	Engine uppercarr. Actuation after run relay Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8D9C70	Engine uppercarr. Actuation after run relay Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8D9C82	Engine uppercarr. Actuation after run relay Output current too high no reaction Check wiring between control unit and components	A750		E	1
8D9D01	Engine uppercarr. Urea tank (temperature at suction point) Value above max. test range no reaction Check wiring between control unit and components	A750		E	1
8D9D02	Engine uppercarr. Urea tank (temperature at suction point) Value below min. test range no reaction Check wiring between control unit and components	A750		E	1
8D9D08	Engine uppercarr. Urea tank (temperature at suction point) Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D9D09	Engine uppercarr. Urea tank (temperature at suction point) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D9D16	Engine uppercarr. Urea tank (temperature at suction point) Plausibility error no reaction Check components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9D18	Engine uppercarr. Urea tank (temperature at suction point) Short circuit no reaction Check wiring between control unit and components	A750		E	1
8D9F03	Engine uppercarr. Particle filter pressure sensor 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D9F0B	Engine uppercarr. Particle filter pressure sensor 1 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D9F16	Engine uppercarr. Particle filter pressure sensor 1 Plausibility error no reaction Check components	A750		E	1
8D9F64	Engine uppercarr. Particle filter pressure sensor 1 Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8DA103	Engine uppercarr. Air filter pressure switch short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8DA10B	Engine uppercarr. Air filter pressure switch Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8DA121	Engine uppercarr. Air filter pressure switch Voltage outside permissible range Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8DA164	Engine uppercarr. Air filter pressure switch Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8DA221	Engine uppercarr. Terminal 15 digital input Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DA264	Engine uppercarr. Terminal 15 digital input Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8DA348	Engine uppercarr. Urea thawing procedure Efficiency error no reaction Check operation status of engine	A750		E	1
8DA409	Engine uppercarr. Urea heater system Value above warning threshold no reaction No action necessary	A750		E	1
8DA40A	Engine uppercarr. Urea heater system Value above critical threshold Engine reduction 50% (Mach-FL) Check electrical error, check high pressure fuel pump. Sensor OK	A750		E	1
8DA44C	Engine uppercarr. Urea heater system Actuator error Inducement system activation (Mach-FL) Read out error stack and note other system errors	A750		E	1
8DA44D	Engine uppercarr. Urea heater system Sensor error Inducement system activation (Mach-FL) Read out error stack and note other system errors	A750		E	1
8DA509	Engine uppercarr. coolant temperature sensor Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DA50A	Engine uppercarr. coolant temperature sensor Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DA516	Engine uppercarr. coolant temperature sensor Plausibility error no reaction No remedy text	A750		E	1
8DA564	Engine uppercarr. coolant temperature sensor Error supply voltage sensors Engine reduction 25% (Mach-FL) No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DA585	Engine uppercarr. coolant temperature sensor Error in the ground supply no reaction No remedy text	A750		E	1
8DA605	Engine uppercarr. Intelligent alternator Communication error no reaction Check wiring between control unit and components	A750		E	1
8DA608	Engine uppercarr. Intelligent alternator Line interruption no reaction Check wiring between control unit and components	A750		E	1
8DA617	Engine uppercarr. Intelligent alternator Short circuit of load no reaction Check wiring between control unit and components	A750		E	1
8DA66C	Engine uppercarr. Intelligent alternator Reg. deviation current value no reaction Check wiring between control unit and components	A750		E	1
8DA66D	Engine uppercarr. Intelligent alternator Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DA66E	Engine uppercarr. Intelligent alternator Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8DA66F	Engine uppercarr. Intelligent alternator Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DA670	Engine uppercarr. Intelligent alternator Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8DA682	Engine uppercarr. Intelligent alternator Output current too high no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DA70A	Engine uppercarr. Fuel filter pressure sensor Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DA721	Engine uppercarr. Fuel filter pressure sensor Voltage outside permissible range no reaction No remedy text	A750		E	1
8DA764	Engine uppercarr. Fuel filter pressure sensor Error supply voltage sensors no reaction No remedy text	A750		E	1
8DA89E	Engine uppercarr. DOC Low conversion rate Power reduction Check AGN system	A750		E	1
8DA8A0	Engine uppercarr. DOC Component removed Power reduction Check AGN system	A750		E	1
8DA8A9	Engine uppercarr. DOC Leakage at post-injection no reaction Check AGN system	A750		E	1
8DA921	Engine uppercarr. Air filter pressure switch 2 Voltage outside permissible range Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8DA964	Engine uppercarr. Air filter pressure switch 2 Error supply voltage sensors Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8DAA04	Engine uppercarr. Rail pressure sensor 2 short circuit to ground Power reduction Check wiring, sensors, high pressure pump	A750		E	1
8DAA0D	Engine uppercarr. Rail pressure sensor 2 Short circuit after supply voltage or line interruption Power reduction Check wiring, sensors, high pressure pump	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DAA10	Engine uppercarr. Rail pressure sensor 2 Start pressure too low no reaction Check high pressure pump	A750		E	1
8DAA12	Engine uppercarr. Rail pressure sensor 2 No signal dynamics Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DAA13	Engine uppercarr. Rail pressure sensor 2 Leakage no reaction No remedy text	A750		E	1
8DAA14	Engine uppercarr. Rail pressure sensor 2 Signal remains below nominal value Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DAA15	Engine uppercarr. Rail pressure sensor 2 Signal remains above nominal value Engine reduction 50% (Mach-FL) Check electrical error, check high pressure fuel pump.	A750		E	1
8DAA16	Engine uppercarr. Rail pressure sensor 2 Plausibility error Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DAA21	Engine uppercarr. Rail pressure sensor 2 Voltage outside permissible range no reaction No remedy text	A750		E	1
8DAA64	Engine uppercarr. Rail pressure sensor 2 Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DAB2D	Engine uppercarr. High pressure pump Installation error no reaction Check installation	A750		E	1
8DAC09	Engine uppercarr. Coolant temperature charge air cooler Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DAC0A	Engine uppercarr. Coolant temperature charge air cooler Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DAC64	Engine uppercarr. Coolant temperature charge air cooler Error supply voltage sensors no reaction No remedy text	A750		E	1
8DAD03	Engine uppercarr. charge air temperature sensor short circuit to supply voltage no reaction Check wiring, sensor	A750		E	1
8DAD04	Engine uppercarr. charge air temperature sensor short circuit to ground no reaction Check wiring, sensor	A750		E	1
8DAD08	Engine uppercarr. charge air temperature sensor Line interruption no reaction Check wiring, sensor	A750		E	1
8DAD09	Engine uppercarr. charge air temperature sensor Value above warning threshold no reaction Check wiring, sensor	A750		E	1
8DAD0A	Engine uppercarr. charge air temperature sensor Value above critical threshold no reaction Check wiring, sensor	A750		E	1
8DAD16	Engine uppercarr. charge air temperature sensor Plausibility error no reaction Check wiring, sensor	A750		E	1
8DAD64	Engine uppercarr. charge air temperature sensor Error supply voltage sensors no reaction Check wiring, sensor	A750		E	1
8DAE07	Engine uppercarr. Charge air temperature sensor 2 Value below warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DAE09	Engine uppercarr. Charge air temperature sensor 2 Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DAE0A	Engine uppercarr. Charge air temperature sensor 2 Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DAE0C	Engine uppercarr. Charge air temperature sensor 2 Value below critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DAE64	Engine uppercarr. Charge air temperature sensor 2 Error supply voltage sensors no reaction No remedy text	A750		E	1
8DAF16	Engine uppercarr. Charge air temperature sensor suction pipe 2 Plausibility error no reaction No remedy text	A750		E	1
8DAF64	Engine uppercarr. Charge air temperature sensor suction pipe 2 Error supply voltage sensors no reaction No remedy text	A750		E	1
8DB009	Engine uppercarr. Charge air temperature sensor 2 Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DB00A	Engine uppercarr. Charge air temperature sensor 2 Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DB016	Engine uppercarr. Charge air temperature sensor 2 Plausibility error Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8DB064	Engine uppercarr. Charge air temperature sensor 2 Error supply voltage sensors Engine reduction 25% (Mach-FL) No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DB216	Engine uppercarr. Turbo charger rpm sensor 1 Plausibility error no reaction No remedy text	A750		E	1
8DB304	Engine uppercarr. Engine short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8DB309	Engine uppercarr. Engine Value above warning threshold no reaction No remedy text	A750		E	1
8DB30A	Engine uppercarr. Engine Value above critical threshold no reaction No remedy text	A750		E	1
8DB30D	Engine uppercarr. Engine Short circuit after supply voltage or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DB38C	Engine uppercarr. Engine High NOX emissions no reaction No remedy text	A750		E	1
8DB3A5	Engine uppercarr. Engine NOX emission values too high no reaction Check the exhaust gas aftertreatment system AGN	A750		E	1
8DB404	Engine uppercarr. Turbo charger rpm sensor 3 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8DB409	Engine uppercarr. Turbo charger rpm sensor 3 Value above warning threshold no reaction No remedy text	A750		E	1
8DB40A	Engine uppercarr. Turbo charger rpm sensor 3 Value above critical threshold no reaction No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DB40D	Engine uppercarr. Turbo charger rpm sensor 3 Short circuit after supply voltage or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DB48D	Engine uppercarr. Turbo charger rpm sensor 3 Actuated with active engine brake no reaction No remedy text	A750		E	1
8DB504	Engine uppercarr. Turbo charger rpm sensor 4 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8DB509	Engine uppercarr. Turbo charger rpm sensor 4 Value above warning threshold no reaction No remedy text	A750		E	1
8DB50A	Engine uppercarr. Turbo charger rpm sensor 4 Value above critical threshold no reaction No remedy text	A750		E	1
8DB50D	Engine uppercarr. Turbo charger rpm sensor 4 Short circuit after supply voltage or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DB58E	Engine uppercarr. Turbo charger rpm sensor 4 Crankshaft and camshaft rpm sensors reversed no reaction No remedy text	A750		E	1
8DB653	Engine uppercarr. Monitoring system engine control unit Error plausibility starter actuation no reaction Check control unit	A750		E	1
8DB654	Engine uppercarr. Monitoring system engine control unit Ecu internal error no reaction Check components	A750		E	1
8DB65F	Engine uppercarr. Monitoring system engine control unit Error emerg. stop no reaction Check control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DB660	Engine uppercarr. Monitoring system engine control unit PME CAN Error no reaction Check control unit	A750		E	1
8DB665	Engine uppercarr. Monitoring system engine control unit Fuel injector plausibility error no reaction Check control unit	A750		E	1
8DB671	Engine uppercarr. Monitoring system engine control unit Injection plausibility, error in fuel injector monitoring no reaction Check control unit	A750		E	1
8DB709	Engine uppercarr. Control unit temperature Value above warning threshold no reaction Check operation status of engine	A750		E	1
8DB70A	Engine uppercarr. Control unit temperature Value above critical threshold no reaction Check operation status of engine	A750		E	1
8DB764	Engine uppercarr. Control unit temperature Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DB855	Engine uppercarr. Pressure relief valve high pressure injection syst Too many activations no reaction Check operation status of engine	A750		E	1
8DB856	Engine uppercarr. Pressure relief valve high pressure injection syst Valve open Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1
8DB908	Engine uppercarr. Digital input emerg. start Line interruption no reaction Check wiring between control unit and components	A750		E	1
8DB921	Engine uppercarr. Digital input emerg. start Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DB964	Engine uppercarr. Digital input emerg. start Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8DBA21	Engine uppercarr. Piston cooling pressure sensor 1 Voltage outside permissible range no reaction No remedy text	A750		E	1
8DBA64	Engine uppercarr. Piston cooling pressure sensor 1 Error supply voltage sensors no reaction No remedy text	A750		E	1
8DBB95	Engine uppercarr. Piston cooling pressure sensor 2 Line interruption at engine plug Engine reduction 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8DBB96	Engine uppercarr. Piston cooling pressure sensor 2 Line interruption at vehicle plug Engine reduction 25% (Mach-FL) Check wiring between control unit and components	A750		E	1
8DBC05	Engine uppercarr. Tachograph Communication error no reaction Check wiring between control unit and components	A750		E	1
8DBC07	Engine uppercarr. Tachograph Value below warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DBC09	Engine uppercarr. Tachograph Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DBC0A	Engine uppercarr. Tachograph Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DBC0C	Engine uppercarr. Tachograph Value below critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DBC64	Engine uppercarr. Tachograph Error supply voltage sensors no reaction No remedy text	A750		E	1
8DBE08	Engine uppercarr. Data transfer CAN 4 Line interruption no reaction Check wiring, wiring harness	A750		E	1
8DBE18	Engine uppercarr. Data transfer CAN 4 Short circuit no reaction Check wiring between control unit and components	A750		E	1
8DBF09	Engine uppercarr. Turbocharger 1 exhaust temperature Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DBF0A	Engine uppercarr. Turbocharger 1 exhaust temperature Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DC005	Engine uppercarr. Climatic control unit Communication error no reaction Check wiring	A750		E	1
8DC109	Engine uppercarr. Turbocharger 3 exhaust temperature Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DC10A	Engine uppercarr. Turbocharger 3 exhaust temperature Value above critical threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DC209	Engine uppercarr. SCR system (HC overload) Value above warning threshold no reaction Sensor value o.k. but outside limit values, sensor replacement not necessary	A750		E	1
8DC20A	Engine uppercarr. SCR system (HC overload) Value above critical threshold Power reduction Check the exhaust gas aftertreatment system AGN	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DC305	Engine uppercarr. Cylinder head temperature sensor Communication error no reaction Check wiring between control unit and components	A750		E	1
8DC40A	Engine uppercarr. Water in fuel sensor 2 Value above critical threshold Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8DC421	Engine uppercarr. Water in fuel sensor 2 Voltage outside permissible range Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8DC464	Engine uppercarr. Water in fuel sensor 2 Error supply voltage sensors Engine reduction 25% (Mach-FL) No remedy text	A750		E	1
8DC558	Engine uppercarr. Exhaust return regulation Error auto calibration no reaction Check mechanics	A750		E	1
8DC559	Engine uppercarr. Exhaust return regulation Error teach in procedure no reaction Check mechanics	A750		E	1
8DC55A	Engine uppercarr. Exhaust return regulation Learned value lost in operation no reaction Check mechanics	A750		E	1
8DC680	Engine uppercarr. Air flap excessive speed no reaction No remedy text	A750		E	1
8DC75C	Engine uppercarr. SCR urea Temperature Temperature measurement urea too high Inducement system activation (Mach-FL) Check AdBlue Heating system	A750		E	1
8DC858	Engine uppercarr. Exhaust flap regulation Error auto calibration Inducement system activation (Mach-FL) Check mechanics	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DC859	Engine uppercarr. Exhaust flap regulation Error teach in procedure Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC85A	Engine uppercarr. Exhaust flap regulation Learned value lost in operation Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC958	Engine uppercarr. Exhaust flap regulation 2 Error auto calibration Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC959	Engine uppercarr. Exhaust flap regulation 2 Error teach in procedure Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC95A	Engine uppercarr. Exhaust flap regulation 2 Learned value lost in operation Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DCA21	Engine uppercarr. battle switch Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8DCA5E	Engine uppercarr. battle switch activated no reaction Report all error parameters to Service	A750		E	1
8DCA64	Engine uppercarr. battle switch Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8DCC05	Engine uppercarr. Safety system PME CAN Communication error no reaction Check wiring, CAN-participant	A750		E	1
8DCE33	Engine uppercarr. J1939 Prop0 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DCF03	Engine uppercarr. Input display alternator short circuit to supply voltage no reaction Check wiring, wiring harness	A750		E	1
8DCF0B	Engine uppercarr. Input display alternator Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DCF21	Engine uppercarr. Input display alternator Voltage outside permissible range no reaction Check wiring, wiring harness	A750		E	1
8DCF64	Engine uppercarr. Input display alternator Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8DD061	Engine uppercarr. Particle filter DPF Regeneration failed no reaction Check operation status of engine	A750		E	1
8DD062	Engine uppercarr. Particle filter DPF Regeneration stopped (temp. too low) no reaction Check operation status of engine	A750		E	1
8DD063	Engine uppercarr. Particle filter DPF Regeneration stopped (temp. too low) no reaction Check operation status of engine	A750		E	1
8DD068	Engine uppercarr. Particle filter DPF Assessment of soot load not plausible (too high) no reaction Check operation status of engine	A750		E	1
8DD069	Engine uppercarr. Particle filter DPF Assessment of soot load not plausible (too low) no reaction Check operation status of engine	A750		E	1
8DD077	Engine uppercarr. Particle filter DPF Particle load above warning threshold no reaction Report all error parameters to Service	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DD078	Engine uppercarr. Particle filter DPF Particle load above critical threshold no reaction Report all error parameters to Service	A750		E	1
8DD079	Engine uppercarr. Particle filter DPF Cleaning interval reached, replace DPF filter element no reaction Report all error parameters to Service	A750		E	1
8DD07A	Engine uppercarr. Particle filter DPF Cleaning interval reached, replace DPF filter element-reduction! no reaction Report all error parameters to Service	A750		E	1
8DD091	Engine uppercarr. Particle filter DPF Motor stop during manual regeneration no reaction No remedy text	A750		E	1
8DD099	Engine uppercarr. Particle filter DPF Maximum operating duration without manual regeneration exceeded Power reduction Check the exhaust gas aftertreatment system AGN	A750		E	1
8DD0A1	Engine uppercarr. Particle filter DPF Differential pressure out of valid value range/too high Power reduction Check the exhaust gas aftertreatment system AGN	A750		E	1
8DD0A2	Engine uppercarr. Particle filter DPF Differential pressure out of valid value range/too low Power reduction Check the exhaust gas aftertreatment system AGN	A750		E	1
8DD103	Engine uppercarr. Travel pedal sensor 1 (voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8DD10B	Engine uppercarr. Travel pedal sensor 1 (voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DD164	Engine uppercarr. Travel pedal sensor 1 (voltage) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DD203	Engine uppercarr. Travel pedal sensor 1 (current) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8DD20B	Engine uppercarr. Travel pedal sensor 1 (current) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DD264	Engine uppercarr. Travel pedal sensor 1 (current) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DD303	Engine uppercarr. Travel pedal sensor 2 (voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8DD30B	Engine uppercarr. Travel pedal sensor 2 (voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DD364	Engine uppercarr. Travel pedal sensor 2 (voltage) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DD403	Engine uppercarr. Travel pedal sensor 2 (current) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8DD40B	Engine uppercarr. Travel pedal sensor 2 (current) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DD464	Engine uppercarr. Travel pedal sensor 2 (current) Error supply voltage sensors Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DD505	Engine uppercarr. Exhaust temp. before turbocharger (CMR Sensor) Communication error no reaction Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DD533	Engine uppercarr. Exhaust temp. before turbocharger (CMR Sensor) Data transfer CAN problematic no reaction Check wiring between control unit and components	A750		E	1
8DD69C	Engine uppercarr. Engine oil Change interval almost reached, observe influence on DPF regeneration! no reaction Check oil quality, change the oil	A750		E	1
8DD69D	Engine uppercarr. Engine oil Change interval reached, attention DPF regeneration not possible! no reaction Check oil quality, change the oil	A750		E	1
8DD72D	Engine uppercarr. Temp sensor exhaust aftertreatment (AGN) Installation error Power reduction Check wiring, installation	A750Ignition control uni		E	1
8DD921	Engine uppercarr. Switch idle rpm specification Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8DD964	Engine uppercarr. Switch idle rpm specification Error supply voltage sensors no reaction No remedy text	A750		E	1
8DDA03	Engine uppercarr. Coolant fill level sensor short circuit to supply voltage no reaction Check wiring between control unit and component - S710	A750		E	1
8DDA0B	Engine uppercarr. Coolant fill level sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DDA21	Engine uppercarr. Coolant fill level sensor Voltage outside permissible range no reaction No remedy text	A750		E	1
8DDB33	Engine uppercarr. J1939 Prop3 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DDC66	Engine uppercarr. Engine run turbulent Injection qty. correction of a cyl. too high no reaction Report all error parameters to Service	A750		E	1
8DDC67	Engine uppercarr. Engine run turbulent Deviation segment rpm of a cyl. too high no reaction Report all error parameters to Service	A750		E	1
8DDD6A	Engine uppercarr. Engine protection power reduction Air intake manifold temperature no reaction Check operation status of engine	A750		E	1
8DDD72	Engine uppercarr. Engine protection power reduction Charge air pr. too high no reaction Report all error parameters to Service	A750		E	1
8DDD73	Engine uppercarr. Engine protection power reduction Charge air pr. too low no reaction Report all error parameters to Service	A750		E	1
8DDD7F	Engine uppercarr. Engine protection power reduction Turbocharger protection active no reaction No remedy text	A750		E	1
8DDE05	Engine uppercarr. SCR control unit Communication error Engine reduction (Mach-FL) Check wiring between control unit and components	A750		E	1
8DDE7B	Engine uppercarr. SCR control unit Emission relevant error Engine reduction (Mach-FL) No remedy text	A750		E	1
8DDF16	Engine uppercarr. Rpm sensor signal camshaft (voltage) Plausibility error no reaction Check operation status of engine	A750		E	1
8DE016	Engine uppercarr. Rpm sensor signal crankshaft (voltage) Plausibility error no reaction Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DE15B	Engine uppercarr. Digital input Starter signal 2 Start block due to a short circuit no reaction Report all error parameters to Service	A750		E	1
8DE235	Engine uppercarr. Power reduction to protect AGN-Systems Excess temperature error no reaction Report all error parameters to Service	A750		E	1
8DE364	Engine uppercarr. Pr. sensor inlet AGR Error supply voltage sensors no reaction Check wiring, sensor	A750		E	1
8DE464	Engine uppercarr. Temperature sensor inlet AGR Error supply voltage sensors no reaction Check wiring, sensor	A750		E	1
8DE721	Engine uppercarr. Droop Switch Voltage outside permissible range no reaction No remedy text	A750		E	1
8DE764	Engine uppercarr. Droop Switch Error supply voltage sensors no reaction No remedy text	A750		E	1
8DE821	Engine uppercarr. Switch suppress error reactions Voltage outside permissible range no reaction No remedy text	A750		E	1
8DE864	Engine uppercarr. Switch suppress error reactions Error supply voltage sensors no reaction No remedy text	A750		E	1
8DE921	Engine uppercarr. Switch Overspeed recognition Voltage outside permissible range no reaction No remedy text	A750		E	1
8DE964	Engine uppercarr. Switch Overspeed recognition Error supply voltage sensors no reaction No remedy text	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DEA08	Engine uppercarr. Alternator (voltage regulation) Line interruption no reaction Check wiring between control unit and components	A750		E	1
8DEA6C	Engine uppercarr. Alternator (voltage regulation) Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8DEA6D	Engine uppercarr. Alternator (voltage regulation) Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DEA6E	Engine uppercarr. Alternator (voltage regulation) Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8DEA6F	Engine uppercarr. Alternator (voltage regulation) Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DEA70	Engine uppercarr. Alternator (voltage regulation) Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8DEB08	Engine uppercarr. Alternator (shut-off function) Line interruption no reaction Check wiring between control unit and components	A750		E	1
8DEB6C	Engine uppercarr. Alternator (shut-off function) Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8DEB6D	Engine uppercarr. Alternator (shut-off function) Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DEB6E	Engine uppercarr. Alternator (shut-off function) Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DEB6F	Engine uppercarr. Alternator (shut-off function) Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DEB70	Engine uppercarr. Alternator (shut-off function) Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8DEB82	Engine uppercarr. Alternator (shut-off function) Output current too high no reaction Check wiring between control unit and component - G700	A750		E	1
8DEC05	Engine uppercarr. Wastegate Regulating valve Communication error no reaction Check wiring, flaps (smart components)	A750		E	1
8DED08	Engine uppercarr. Machine configurable lamp outlet 3 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8DED6C	Engine uppercarr. Machine configurable lamp outlet 3 Reg. deviation current value no reaction Check wiring between control unit and components	A750		E	1
8DED6D	Engine uppercarr. Machine configurable lamp outlet 3 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DED6E	Engine uppercarr. Machine configurable lamp outlet 3 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8DED6F	Engine uppercarr. Machine configurable lamp outlet 3 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DED70	Engine uppercarr. Machine configurable lamp outlet 3 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DED82	Engine uppercarr. Machine configurable lamp outlet 3 Output current too high no reaction Check wiring between control unit and components	A750		E	1
8DEE55	Engine uppercarr. Pr. relief valve high pr. injection system 2 Too many activations no reaction No remedy text	A750		E	1
8DEE56	Engine uppercarr. Pr. relief valve high pr. injection system 2 Valve open Engine reduction 50% (Mach-FL) No remedy text	A750		E	1
8DF521	Engine uppercarr. Oil filter 2 Voltage outside permissible range no reaction No remedy text	A750		E	1
8DF564	Engine uppercarr. Oil filter 2 Error supply voltage sensors no reaction No remedy text	A750		E	1
8DF97D	Engine uppercarr. Injection system Comp. factors qty. match outside tol. range no reaction Report all error parameters to Service	A750		E	1
930106	engine V8: control device engine Data communication CAN faulty / interrupted emergency operation check cable/plugs for shorts			E	1
930107	engine V8: control device engine Data communication CAN cancelled emergency operation check cable/plugs for UB- or shorts to ground			E	1
930208	engine V8: CAN-participant ABV (ABS/ASR) Data transfer faulty/missing, max. cycle time exceeded limited function check cable/plugs/ABS-/ASR-electronics			E	1
930308	engine V8: CAN-participant gear Data transfer faulty/missing, max. cycle time exceeded limited function check cable/plugs/gear electronics			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
930408	engine V8: CAN-participant E/A-Modul Data transfer faulty/missing, max. cycle time exceeded emergency operation check cable/plugs/E/A-Modul(e)			E	1
930508	engine V8: CAN signals gear Data transfer faulty/missing, max. cycle time exceeded limited function check cable/plugs/gear electronics			E	1
930608	engine V8: CAN signals travel switch Data transfer faulty/missing, max. cycle time exceeded limited function check cable/plugs/E/A-Modul(e)			E	1
930709	engine V8: speed sensor 1 gradient damage switch-over to speed 2 or engine-stop with error code 0809 check cable/plugs/sensor, distance to flywheel			E	1
930809	engine V8: speed sensor 2 gradient damage switch-over to speed 2 or engine-stop with error code 0709 check cable/plugs/sensor, distance to flywheel			E	1
930910	engine V8: speed 1/2 inadmissible signal difference/plausability control defective switch-over to other speed sensor or engine-stop check cable/plugs/sensor, distance to flywheel			E	1
931002	engine V8: accelerator 1 sensor defect high/short circ. to supply voltage switch-over to accelerator 2,speed limitation, torque limitation or 20-23 check cable/plugs for UB-shorts			E	1
931003	engine V8: accelerator 1 sensor defect low/short circuit to ground switch-over to accelerator 2,speed limitation, torque limitation or 20-23 check cable/plugs for breaks or short to ground			E	1
931004	engine V8: accelerator 1 level exceeded switch-over to accelerator 2,speed limitation, torque limitation or 20-23 check cable/plugs for UB-shorts, check pedal unit			E	1
931005	engine V8: accelerator 1 below minimum level switch-over to accelerator 2,speed limitation, torque limitation or 20-23 check cable/plugs for break or short to ground, check pedal unit			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
931102	engine V8: accelerator 2 sensor defect high/short circ. to supply voltage switch-over to accelerator 1, speed limitation, torque limitation or emergency operation at error code 16-19 check cable/plugs for UB-shorts			E	1
931103	engine V8: accelerator 2 sensor defect low/short circuit to ground switch-over to accelerator 1, speed limitation, torque limitation or emergency operation at error code 16-19 check cable/plugs for breaks or short to ground			E	1
931104	engine V8: accelerator 2 level exceeded switch-over to accelerator 1, speed limitation, torque limitation or emergency operation at error code 16-19 check cable/plugs for UB-shorts, check pedal unit			E	1
931105	engine V8: accelerator 2 below minimum level switch-over to accelerator 1, speed limitation, torque limitation or emergency operation at error code 16-19 check cable/plugs for break or short to ground, check pedal unit			E	1
931201	engine V8: accelerator 1/2 unit defect gas reduction or gas withdrawal (idle) test error code 16-23, check pedal unit			E	1
931210	engine V8: accelerator 1/2 inadmissible signal difference/plausability control defective gas withdrawal (idle) check pedal unit, check condition of operation brake			E	1
931280	engine V8: accelerator 1/2 Actuation with selected/active auxiliary brake Travel pedal lock Release travel pedal, switch off auxiliary brake			B	
931611	engine V8: trigger signal box EDC excess current recognition engine-Stop check cable/plugs, replace LH-ECU1, check EDC-actuator, if necessary replace injector pump			E	1
931701	engine V8: signal box feedback EDC unit defect engine-Stop check cable/plugs, replace LH-ECU1, check EDC-actuator, if necessary replace injector pump			E	1
931812	engine V8: alternator D+ short circuit to ground warning check cable/plugs for short to ground			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
931813	engine V8: alternator D+ open signal circuits signal ignored check cable/plugs for breaks			E	1
931814	engine V8: alternator D+ short circuit to supply voltage signal ignored check cable/plugs for UB-shorts			E	1
931916	engine V8: supply KL30 excess voltage generate error report; Reset: automatic after error counter sequence or regulator reset check main circuit voltage, check battery			E	1
931917	engine V8: supply KL30 voltage below required value generate error report; Reset: automatic after error counter sequence or regulator reset check main circuit voltage, check battery			E	1
932012	engine V8: start engine KL50 short circuit to ground generate error report; Reset: automatic after error counter sequence or regulator reset check cable/plugs for short to ground			E	1
932112	engine V8: DA, flame type heater plugs diagnosis short circuit to ground error report check cable/plugs for short to ground, replace Relaismodul			E	1
932113	engine V8: DA, flame type heater plugs diagnosis open signal circuits shut off FGK and MVE check cable/plugs for breaks, replace Relaismodul			E	1
932114	engine V8: DA, flame type heater plugs diagnosis short circuit to supply voltage error report check cable/plugs for UB-shorts, replace Relaismodul			E	1
932211	engine V8: Actuator prestroke excess current recognition Engine-stop Check or replace line connection ECU<->EDC-actuator, EDC-actuator, injection pump			E	1
932312	engine V8: Control blower short circuit to ground Blower turns at full speed following wire break/short-circuit, no blower regulation possible Line connection ECU<->fan, ECU-output, check fan valve			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
932315	engine V8: Control blower open electric circuit Blower turns at full speed following wire break/short-circuit, no blower regulation possible Line connection ECU<->fan, ECU-output, check fan valve			E	1
932318	engine V8: Control blower excess temperature Blower turns at full speed following wire break/short-circuit, no blower regulation possible Line connection ECU<->fan, ECU-output, check fan valve			E	1
932512	engine V8: Speed signal tachograph short circuit to ground Signal is ignored, switch off of functions TMAT/TSET, reduction of maximum moment due to Vset Check or replace line connection tachograph<->ECU, tachograph, ECU			E	1
932513	engine V8: Speed signal tachograph open signal circuits Signal is ignored, switch off of functions TMAT/TSET, reduction of maximum moment due to Vset Check or replace line connection tachograph<->ECU, tachograph, ECU			E	1
932514	engine V8: Speed signal tachograph short circuit to supply voltage Signal is ignored, switch off of functions TMAT/TSET, reduction of maximum moment due to Vset Check or replace line connection tachograph<->ECU, tachograph, ECU			E	1
932602	engine V8: oil pressure sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
932603	engine V8: oil pressure sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
932702	engine V8: charge air pressure sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
932703	engine V8: charge air pressure sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
932802	engine V8: air filter sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
932803	engine V8: air filter sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
933102	engine V8: charge air temperature sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
933103	engine V8: charge air temperature sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
933202	engine V8: coolant temperature sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
933203	engine V8: coolant temperature sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
933313	engine V8: coolant level sensor open signal circuits signal ignored, substitute value used check cable/plugs for defects or breaks, replace sensor			E	1
933402	engine V8: oil temperature sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
933403	engine V8: oil temperature sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
933512	engine V8: Sensor jib-movement-detector (NBF) short circuit to ground Change-over to power-regulated operation Check line connection ECU<->NBF sensor, NBV sensor; Replace NBF sensor			E	1
933513	engine V8: Sensor jib-movement-detector (NBF) open signal circuits Change-over to power-regulated operation Check line connection ECU<->NBF sensor, NBV sensor; Replace NBF sensor			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
933514	engine V8: Sensor jib-movement-detector (NBF) short circuit to supply voltage Change-over to power-regulated operation Check line connection ECU<->NBF sensor, NBV sensor; Replace NBF sensor			E	1
933601	engine V8: trigger flame type heater plug(s) FGK unit defect shut off FGK and MVE check cable/plugs for defects or breaks, check FGK, replace Relaismodul			E	1
933614	engine V8: trigger flame type heater plug(s) FGK short circuit to supply voltage			E	1
933615	engine V8: trigger flame type heater plug(s) FGK open electric circuit error report check cable/plugs for breaks, replace Relaismodul			E	1
933618	engine V8: trigger flame type heater plug(s) FGK excess temperature shut off FGK and MVE check cable/plugs for short to ground, replace Relaismodul			E	1
933714	engine V8: solenoid valve additional flow for starting short circuit to supply voltage			E	1
933715	engine V8: solenoid valve additional flow for starting open electric circuit FSA data defective, FGK activation removed, MVE reset: automatic after error counter sequence, after regulator reset			E	1
933718	engine V8: solenoid valve additional flow for starting excess temperature shut off FGK and MVE check cable/plugs for short to ground, replace Relaismodul			E	1
933814	engine V8: engine start 50A short circuit to supply voltage			E	1
933815	engine V8: engine start 50A open electric circuit starting procedure interrupted, shut down FGK and MVE check cable/plugs for breaks, replace Relaismodul			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
933818	engine V8: engine start 50A excess temperature starting procedure interrupted, shut down FGK and MVE check cable/plugs for short to ground, replace Relaismodul			E	1
933908	engine V8: CAN-signals retarder Data transfer faulty/missing, max. cycle time exceeded limited function Check cable/plug/RET-electronics/CAN-Bus system			E	1
934008	engine V8: CAN-signals WSK Data transfer faulty/missing, max. cycle time exceeded limited function Check cable/plug/WSK-electronics/CAN-Bus system			E	1
934118	engine V8: control device ECU excess temperature error report allow machine to cool, check installation location, if necessary take further cooling measures			E	1
934119	engine V8: control device ECU deviation engine-Stop regulator-reset (Kl.15), Check cable/plugs EDC-actuator, EDC-actuator; ECU, replace injector pump			E	1
934120	engine V8: control device ECU saving error replace ECU			E	1
934221	engine V8: RAM/FLASH memory invalid data record engine-Stop replace ECU			E	1
934320	engine V8: EEPROM memory saving error use of redundant memory (Flash-EPRM) replace ECU			E	1
934321	engine V8: EEPROM memory invalid data record engine start not possible replace ECU			E	1
934504	engine V8: Calculation spray begin (SB) level exceeded Change-over to controlled injection-start operation (SB)			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
934505	engine V8: Calculation spray begin (SB) below minimum level Change-over to controlled injection-start operation (SB)			E	1
934526	engine V8: Calculation spray begin (SB) No synchronisation possible Change-over to controlled injection-start operation (SB) Checking of OT signal transmitter and NBF			E	1
936124	engine V8: charge air temperature pre-warning disruption limit 1 warning, engine-protection-info, output reduction reduce output, check air suction routing and engine			E	1
936125	engine V8: charge air temperature pre-warning disruption limit 2 warning, engine-protection-info, output reduction reduce output, if necessary shut off engine, check air suction routing and engine			E	1
936224	engine V8: coolant temperature pre-warning disruption limit 1 warning, engine-protection-info, output reduction reduce output, check coolant level and engine			E	1
936225	engine V8: coolant temperature pre-warning disruption limit 2 warning, engine-protection-info, output reduction reduce output, if necessary shut off engine, check coolant level and engine			E	1
936324	engine V8: coolant level pre-warning disruption limit 1 warning shut off engine, check coolant level and if necessary replenish, check for leaks			E	1
936424	engine V8: oil pressure pre-warning disruption limit 1 warning shut off engine, check oil level and if necessary replenish, check for leaks			E	1
936522	engine V8: air filter pressure pre-warning disruption limit 1 pre-warning replace air filter at next opportunity			E	1
936525	engine V8: air filter pressure pre-warning disruption limit 2 warning replace air filter immediately			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
936624	engine V8: v-belt break pre-warning disruption limit 1 warning replace V-belts, check generator and replace if necessary			E	1
936724	engine V8: speed pre-warning disruption limit 1 warning, engine-protection-info, injector quantities 0, activation of engine brake shut off engine, regulator-reset (Kl.15)			E	1
936824	engine V8: charge air pressure pre-warning disruption limit 1 signal ignored, substitute value will be used, error report check air suction routing			E	1
936825	engine V8: charge air pressure pre-warning disruption limit 2 signal ignored, substitute value will be used, error report check air suction routing			E	1
936924	engine V8: oil temperature pre-warning disruption limit 1 signal ignored, substitute value will be used, error report check oil level/oil circulation			E	1
936925	engine V8: oil temperature pre-warning disruption limit 2 signal ignored, substitute value will be used, error report check oil level/oil circulation			E	1
938150	engine V8: v-belt-control service report interval 1 attained/exceeded report check and return			E	1
938250	engine V8: change engine oil filter service report interval 1 attained/exceeded report check and return			E	1
938350	engine V8: change engine oil service report interval 1 attained/exceeded report change oil and return			E	1
938351	engine V8: change engine oil service report interval 2 attained/exceeded report change oil and return			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
938352	engine V8: change engine oil service report interval 3 attained/exceeded report change oil and return			E	1
938353	engine V8: change engine oil service report interval 4 attained/exceeded report change oil and return			E	1
938354	engine V8: change engine oil service report interval 5 attained/exceeded report change oil and return			E	1
938355	engine V8: change engine oil service report interval 6 attained/exceeded report change oil and return			E	1
938356	engine V8: change engine oil service report interval 7 attained/exceeded report change oil and return			E	1
938357	engine V8: change engine oil service report interval 8 attained/exceeded report change oil and return			E	1
938358	engine V8: change engine oil service report interval 9 attained/exceeded report change oil and return			E	1
938359	engine V8: change engine oil service report interval 10 attained/exceeded report change oil and return			E	1
938650	engine V8: check battery service report interval 1 attained/exceeded report check and return			E	1
938750	engine V8: change water filter service report interval 1 attained/exceeded report change filter and return			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
938850	engine V8: check antifreeze service report interval 1 attained/exceeded report check and return			E	1
938950	engine V8: fuel filter level 1 service report interval 1 attained/exceeded report change filter and return			E	1
939050	engine V8: fuel filter level 2 service report interval 1 attained/exceeded report change filter and return			E	1
939150	engine V8: valve clearance service report interval 1 attained/exceeded report check and return			E	1
939250	engine V8: fuel injection valves service report interval 1 attained/exceeded report check and return			E	1
939350	engine V8: coolant service report interval 1 attained/exceeded report check and return			E	1
940106	Engine uppercarr. control device engine Data communication CAN faulty / interrupted emergency operation check cable/plugs for shorts			E	1
940107	Engine uppercarr. control device engine Data communication CAN cancelled emergency operation check cable/plugs for UB- or shorts to ground			E	1
940208	Engine uppercarr. CAN-participant ABV (ABS/ASR) Data transfer faulty/missing, max. cycle time exceeded limited function check cable/plugs/ABS-/ASR-electronics			E	1
940308	Engine uppercarr. CAN-participant gear Data transfer faulty/missing, max. cycle time exceeded limited function check cable/plugs/gear electronics			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
940408	Engine uppercarr. CAN-participant E/A-Modul Data transfer faulty/missing, max. cycle time exceeded emergency operation check cable/plugs/E/A-Modul(e)			E	1
940709	Engine uppercarr. speed sensor 1 gradient damage switch-over to speed 2 or engine-stop with error code 0809 check cable/plugs/sensor, distance to flywheel			E	1
940809	Engine uppercarr. speed sensor 2 gradient damage switch-over to speed 2 or engine-stop with error code 0709 check cable/plugs/sensor, distance to flywheel			E	1
940910	Engine uppercarr. speed 1/2 inadmissable signal difference/plausability control defective switch-over to other speed sensor or engine-stop check cable/plugs/sensor, distance to flywheel			E	1
941002	Engine uppercarr. accelerator 1 sensor defect high/short circ. to supply voltage switch-over to accelerator 2,speed limitation, torque limitation or 20-23 check cable/plugs for UB-shorts			E	1
941003	Engine uppercarr. accelerator 1 sensor defect low/short circuit to ground switch-over to accelerator 2,speed limitation, torque limitation or 20-23 check cable/plugs for breaks or short to ground			E	1
941004	Engine uppercarr. accelerator 1 level exceeded switch-over to accelerator 2,speed limitation, torque limitation or 20-23 check cable/plugs for UB-shorts, check pedal unit			E	1
941005	Engine uppercarr. accelerator 1 below minimum level switch-over to accelerator 2,speed limitation, torque limitation or 20-23 check cable/plugs for break or short to ground, check pedal unit			E	1
941102	Engine uppercarr. accelerator 2 sensor defect high/short circ. to supply voltage switch-over to accelerator 1, speed limitation, torque limitation or emergency operation at error code 16-19 check cable/plugs for UB-shorts			E	1
941103	Engine uppercarr. accelerator 2 sensor defect low/short circuit to ground switch-over to accelerator 1, speed limitation, torque limitation or emergency operation at error code 16-19 check cable/plugs for breaks or short to ground			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
941104	Engine uppercarr. accelerator 2 level exceeded switch-over to accelerator 1, speed limitation, torque limitation or emergency operation at error code 16-19 check cable/plugs for UB-shorts, check pedal unit			E	1
941105	Engine uppercarr. accelerator 2 below minimum level switch-over to accelerator 1, speed limitation, torque limitation or emergency operation at error code 16-19 check cable/plugs for break or short to ground, check pedal unit			E	1
941201	Engine uppercarr. accelerator 1/2 unit defect gas reduction or gas withdrawal (idle) test error code 16-23, check pedal unit			E	1
941210	Engine uppercarr. accelerator 1/2 inadmissible signal difference/plausability control defective gas withdrawal (idle) check pedal unit, check condition of operation brake			E	1
941611	Engine uppercarr. trigger signal box EDC excess current recognition engine-Stop check cable/plugs, replace LH-ECU1, check EDC-actuator, if necessary replace injector pump			E	1
941701	Engine uppercarr. signal box feedback EDC unit defect engine-Stop check cable/plugs, replace LH-ECU1, check EDC-actuator, if necessary replace injector pump			E	1
941812	Engine uppercarr. alternator D+ short circuit to ground warning check cable/plugs for short to ground			E	1
941813	Engine uppercarr. alternator D+ open signal circuits signal ignored check cable/plugs for breaks			E	1
941814	Engine uppercarr. alternator D+ short circuit to supply voltage signal ignored check cable/plugs for UB-shorts			E	1
941906	Engine uppercarr. supply KL30 Data communication CAN faulty / interrupted generate error report Reset: automatic after error counter sequence or after regulator-reset check main circuit voltage, check battery			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
941907	Engine uppercarr. supply KL30 Data communication CAN cancelled generate error report; Reset: automatic after error counter sequence or regulator reset check main circuit voltage, check battery			E	1
942012	Engine uppercarr. start engine KL50 short circuit to ground generate error report; Reset: automatic after error counter sequence or regulator reset check cable/plugs for short to ground			E	1
942112	Engine uppercarr. DA, flame type heater plugs diagnosis short circuit to ground error report check cable/plugs for short to ground, replace Relaismodul			E	1
942113	Engine uppercarr. DA, flame type heater plugs diagnosis open signal circuits shut off FGK and MVE check cable/plugs for breaks, replace Relaismodul			E	1
942114	Engine uppercarr. DA, flame type heater plugs diagnosis short circuit to supply voltage error report check cable/plugs for UB-shorts, replace Relaismodul			E	1
942602	Engine uppercarr. oil pressure sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
942603	Engine uppercarr. oil pressure sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
942702	Engine uppercarr. charge air pressure sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
942703	Engine uppercarr. charge air pressure sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
942802	Engine uppercarr. air filter sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
942803	Engine uppercarr. air filter sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
943102	Engine uppercarr. charge air temperature sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
943103	Engine uppercarr. charge air temperature sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
943202	Engine uppercarr. coolant temperature sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
943203	Engine uppercarr. coolant temperature sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
943313	Engine uppercarr. coolant level sensor open signal circuits signal ignored, substitute value used check cable/plugs for defects or breaks, replace sensor			E	1
943402	Engine uppercarr. oil temperature sensor sensor defect high/short circ. to supply voltage signal ignored, substitute value used check cable/plugs for shorts to ground, replace sensor			E	1
943403	Engine uppercarr. oil temperature sensor sensor defect low/short circuit to ground signal ignored, substitute value used check cable/plugs for UB-shorts, replace sensor			E	1
943601	Engine uppercarr. trigger flame type heater plug(s) FGK unit defect shut off FGK and MVE			E	1
943614	Engine uppercarr. trigger flame type heater plug(s) FGK short circuit to supply voltage			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
943615	Engine uppercarr. trigger flame type heater plug(s) FGK open electric circuit error report check cable/plugs for breaks, replace Relaismodul			E	1
943618	Engine uppercarr. trigger flame type heater plug(s) FGK excess temperature shut off FGK and MVE check cable/plugs for short to ground, replace Relaismodul			E	1
943714	Engine uppercarr. solenoid valve additional flow for starting short circuit to supply voltage			E	1
943715	Engine uppercarr. solenoid valve additional flow for starting open electric circuit FSA data defective, FGK activation removed, MVE reset: automatic after error counter sequence, after regulator reset			E	1
943718	Engine uppercarr. solenoid valve additional flow for starting excess temperature shut off FGK and MVE check cable/plugs for short to ground, replace Relaismodul			E	1
943814	Engine uppercarr. engine start 50A short circuit to supply voltage			E	1
943815	Engine uppercarr. engine start 50A open electric circuit starting procedure interrupted, shut down FGK and MVE check cable/plugs for breaks, replace Relaismodul			E	1
943818	Engine uppercarr. engine start 50A excess temperature starting procedure interrupted, shut down FGK and MVE check cable/plugs for short to ground, replace Relaismodul			E	1
944118	Engine uppercarr. control device ECU excess temperature error report allow machine to cool, check installation location, if necessary take further cooling measures			E	1
944119	Engine uppercarr. control device ECU deviation engine-Stop regulator-reset (Kl.15), Check cable/plugs EDC-actuator, EDC-actuator; ECU, replace injector pump			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
944120	Engine uppercarr. control device ECU saving error			E	1
944221	Engine uppercarr. RAM/FLASH memory invalid data record engine-Stop insert new EEPROM with appropriate data record and carry out paging or replace LH-ECU1, regulator-reset (KI.15)			E	1
944320	Engine uppercarr. EEPROM memory saving error use of redundant memory (Flash-EEPROM) insert new EEPROM and carry out paging or replace LH-ECU1, regulator-reset (KI.15)			E	1
944321	Engine uppercarr. EEPROM memory invalid data record engine start not possible insert correct EEPROM with appropriate data record or replace LH-ECU1, regulator-reset (KI.15)			E	1
946124	Engine uppercarr. charge air temperature pre-warning disruption limit 1 warning, engine-protection-info, output reduction reduce output, check air suction routing and engine			E	1
946125	Engine uppercarr. charge air temperature pre-warning disruption limit 2 warning, engine-protection-info, output reduction reduce output, if necessary shut off engine, check air suction routing and engine			E	1
946224	Engine uppercarr. coolant temperature pre-warning disruption limit 1 warning, engine-protection-info, output reduction reduce output, check coolant level and engine			E	1
946225	Engine uppercarr. coolant temperature pre-warning disruption limit 2 warning, engine-protection-info, output reduction reduce output, if necessary shut off engine, check coolant level and engine			E	1
946324	Engine uppercarr. coolant level pre-warning disruption limit 1 warning shut off engine, check coolant level and if necessary replenish, check for leaks			E	1
946424	Engine uppercarr. oil pressure pre-warning disruption limit 1 warning shut off engine, check oil level and if necessary replenish, check for leaks			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
946522	Engine uppercarr. air filter pressure pre-warning disruption limit 1 pre-warning replace air filter at next opportunity			E	1
946525	Engine uppercarr. air filter pressure pre-warning disruption limit 2 warning replace air filter immediately			E	1
946624	Engine uppercarr. v-belt break pre-warning disruption limit 1 warning replace V-belts, check generator and replace if necessary			E	1
946724	Engine uppercarr. speed pre-warning disruption limit 1 warning, engine-protection-info, injector quantities 0, activation of engine brake shut off engine, regulator-reset (Kl.15)			E	1
946824	Engine uppercarr. charge air pressure pre-warning disruption limit 1 signal ignored, substitute value will be used, error report check air suction routing			E	1
946825	Engine uppercarr. charge air pressure pre-warning disruption limit 2 signal ignored, substitute value will be used, error report check air suction routing			E	1
946924	Engine uppercarr. oil temperature pre-warning disruption limit 1 signal ignored, substitute value will be used, error report check oil level/oil circulation			E	1
946925	Engine uppercarr. oil temperature pre-warning disruption limit 2 signal ignored, substitute value will be used, error report check oil level/oil circulation			E	1
948150	Engine uppercarr. v-belt-control service report interval 1 attained/exceeded report check and return			E	1
948250	Engine uppercarr. change engine oil filter service report interval 1 attained/exceeded report check and return			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
948350	Engine uppercarr. change engine oil service report interval 1 attained/exceeded report change oil and return			E	1
948351	Engine uppercarr. change engine oil service report interval 2 attained/exceeded report change oil and return			E	1
948352	Engine uppercarr. change engine oil service report interval 3 attained/exceeded report change oil and return			E	1
948353	Engine uppercarr. change engine oil service report interval 4 attained/exceeded report change oil and return			E	1
948354	Engine uppercarr. change engine oil service report interval 5 attained/exceeded report change oil and return			E	1
948355	Engine uppercarr. change engine oil service report interval 6 attained/exceeded report change oil and return			E	1
948356	Engine uppercarr. change engine oil service report interval 7 attained/exceeded report change oil and return			E	1
948357	Engine uppercarr. change engine oil service report interval 8 attained/exceeded report change oil and return			E	1
948358	Engine uppercarr. change engine oil service report interval 9 attained/exceeded report change oil and return			E	1
948359	Engine uppercarr. change engine oil service report interval 10 attained/exceeded report change oil and return			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
948650	Engine uppercarr. check battery service report interval 1 attained/exceeded report check and return			E	1
948750	Engine uppercarr. change water filter service report interval 1 attained/exceeded report change filter and return			E	1
948850	Engine uppercarr. check antifreeze service report interval 1 attained/exceeded report check and return			E	1
948950	Engine uppercarr. fuel filter level 1 service report interval 1 attained/exceeded report change filter and return			E	1
949150	Engine uppercarr. valve clearance service report interval 1 attained/exceeded report check and return			E	1
949250	Engine uppercarr. fuel injection valves service report interval 1 attained/exceeded report check and return			E	1
949350	Engine uppercarr. coolant service report interval 1 attained/exceeded report check and return			E	1
949450	Engine uppercarr. Exhaust gas recirculation (AGR) service report interval 1 attained/exceeded report change filter and return			E	1
971020	gear ASTRONIC: Main cut-off valve Y10 short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching blocked - automatic blocked RESET - otherwise replace gear adjuster, ZF 10	A61		E	1
971021	gear ASTRONIC: Main cut-off valve Y10 short circuit to supply voltage Switching blocked RESET - otherwise replace gear adjuster, ZF 74	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
971022	gear ASTRONIC: Main cut-off valve Y10 interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 42	A61		E	2
971120	gear ASTRONIC: Solenoid valve Y1 gear brake short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear adjuster, ZF 17	A61		E	1
971121	gear ASTRONIC: Solenoid valve Y1 gear brake short circuit to supply voltage Switching blocked RESET - otherwise replace gear adjuster, ZF 81	A61		E	1
971122	gear ASTRONIC: Solenoid valve Y1 gear brake interruption Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear adjuster, ZF 49	A61		E	1
971220	gear ASTRONIC: Solenoid valve Y2 splitter short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 2	A61		E	2
971221	gear ASTRONIC: Solenoid valve Y2 splitter short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 66	A61		E	1
971222	gear ASTRONIC: Solenoid valve Y2 splitter interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 34	A61		E	2
971320	gear ASTRONIC: Solenoid valve Y3 splitter short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 3	A61		E	2
971321	gear ASTRONIC: Solenoid valve Y3 splitter short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 67	A61		E	2
971322	gear ASTRONIC: Solenoid valve Y3 splitter interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 35	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
971420	gear ASTRONIC: Solenoid valve Y4 gap short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 04	A61		E	2
971421	gear ASTRONIC: Solenoid valve Y4 gap short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 68	A61		E	2
971422	gear ASTRONIC: Solenoid valve Y4 gap interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 36	A61		E	2
971520	gear ASTRONIC: Solenoid valve Y5 gap short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 05	A61		E	2
971521	gear ASTRONIC: Solenoid valve Y5 gap short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 69	A61		E	2
971522	gear ASTRONIC: Solenoid valve Y5 gap interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 37	A61		E	2
971620	gear ASTRONIC: Solenoid valve Y6 switching short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 6	A61		E	2
971621	gear ASTRONIC: Solenoid valve Y6 switching short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 70	A61		E	2
971622	gear ASTRONIC: Solenoid valve Y6 switching interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 38	A61		E	2
971720	gear ASTRONIC: Solenoid valve Y7 switching short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 7	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
971721	gear ASTRONIC: Solenoid valve Y7 switching short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 71	A61		E	2
971722	gear ASTRONIC: Solenoid valve Y7 switching interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 39	A61		E	2
971820	gear ASTRONIC: Solenoid valve Y8 group short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 8	A61		E	2
971821	gear ASTRONIC: Solenoid valve Y8 group short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 72	A61		E	2
971822	gear ASTRONIC: Solenoid valve Y8 group interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 40	A61		E	2
971920	gear ASTRONIC: Solenoid valve Y9 group short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 9	A61		E	2
971921	gear ASTRONIC: Solenoid valve Y9 group short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 73	A61		E	2
971922	gear ASTRONIC: Solenoid valve Y9 group interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 41	A61		E	2
972033	gear ASTRONIC: Pressure reduction valve Mechanical error No function limitation RESET - otherwise replace pressure limiting valve, ZF 125	A61		E	1
972330	gear ASTRONIC: Splitter Switching error Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 149	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
972331	gear ASTRONIC: Splitter Activation error System not available RESET - otherwise replace gear adjuster, ZF 150	A61		E	1
972332	gear ASTRONIC: Splitter Deactivation error Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 148	A61		E	1
972430	gear ASTRONIC: Gap Switching error Only certain gears switchable, automatic neutral switching - automatic blocked RESET - otherwise replace gear adjuster, ZF 152	A61		E	1
972431	gear ASTRONIC: Gap Activation error Automatic neutral switching - automatic blocked RESET - otherwise replace gear adjuster, ZF 153	A61		E	1
972432	gear ASTRONIC: Gap Deactivation error Only certain gears switchable, automatic neutral switching - automatic blocked RESET - otherwise replace gear adjuster, ZF 151	A61		E	1
972530	gear ASTRONIC: Group Switching error Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 146	A61		E	1
972531	gear ASTRONIC: Group Activation error Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 147	A61		E	1
972532	gear ASTRONIC: Group Deactivation error Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 145	A61		E	1
972630	gear ASTRONIC: Main gear Switching error Automatic neutral switching. Gear engagement conditionally possible - automatic blocked RESET - otherwise replace gear adjuster, ZF 156	A61		E	1
972631	gear ASTRONIC: Main gear Activation error Automatic neutral switching. Gear engagement conditionally possible - automatic blocked RESET - otherwise replace gear adjuster, ZF 155	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
972632	gear ASTRONIC: Main gear Deactivation error Travel: No gear switching possible: Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 154	A61		E	1
972742	gear ASTRONIC: Pressure sensor faulty/not present Output AL on display - no function limitation if air pressure high enough - automatic blocked RESET - otherwise replace pressure sensor, ZF 126	A61		E	1
972842	gear ASTRONIC: Temperature sensor TCU faulty/not present No function limitation RESET - otherwise replace gear adjuster, ZF 127	A61		E	1
972942	gear ASTRONIC: Temperature sensor gear oil faulty/not present No function limitation RESET - otherwise replace gear adjuster, ZF 128	A61		E	1
973020	gear ASTRONIC: Sensor switching short circuit to ground Travel: Gear switching blocked - condition: Start-up gears can be switched RESET - otherwise replace gear adjuster, ZF 130	A61		E	1
973021	gear ASTRONIC: Sensor switching short circuit to supply voltage Travel: Gear switching blocked - condition: Start-up gears can be switched RESET - otherwise replace gear adjuster, ZF 129	A61		E	1
973022	gear ASTRONIC: Sensor switching interruption Travel: Gear switching blocked - condition: Start-up gears can be switched RESET - otherwise replace gear adjuster, ZF 131	A61		E	1
973025	gear ASTRONIC: Sensor switching Self-adjustment Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 132	A61		E	2
973042	gear ASTRONIC: Sensor switching faulty/not present Automatic neutral switching during travel; Automatic gear engagement during travel RESET - otherwise replace gear adjuster, ZF 158	A61		E	1
973120	gear ASTRONIC: Sensor gap short circuit to ground Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 134	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
973121	gear ASTRONIC: Sensor gap short circuit to supply voltage Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 133	A61		E	1
973122	gear ASTRONIC: Sensor gap interruption Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 135	A61		E	1
973125	gear ASTRONIC: Sensor gap Self-adjustment Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 136	A61		E	2
973220	gear ASTRONIC: Sensor group short circuit to ground Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 138	A61		E	1
973221	gear ASTRONIC: Sensor group short circuit to supply voltage Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 137	A61		E	1
973222	gear ASTRONIC: Sensor group interruption Only certain gears switchable - automatic blocked RESET - otherwise replace gear adjuster, ZF 139	A61		E	1
973225	gear ASTRONIC: Sensor group Self-adjustment Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 140	A61		E	2
973242	gear ASTRONIC: Sensor group faulty/not present Automatic neutral switching during travel; Automatic gear engagement during travel RESET - otherwise replace gear adjuster, ZF 159	A61		E	1
973320	gear ASTRONIC: Sensor splitter short circuit to ground Only every 2nd gear can be engaged, switch delay - automatic blocked RESET - otherwise replace gear adjuster, ZF 142	A61		E	1
973321	gear ASTRONIC: Sensor splitter short circuit to supply voltage Only every 2nd gear can be engaged, switch delay - automatic blocked RESET - otherwise replace gear adjuster, ZF 141	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
973322	gear ASTRONIC: Sensor splitter interruption Only every 2nd gear can be engaged, switch delay - automatic blocked RESET - otherwise replace gear adjuster, ZF 143	A61		E	1
973325	gear ASTRONIC: Sensor splitter Self-adjustment Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 144	A61		E	2
973342	gear ASTRONIC: Sensor splitter faulty/not present Automatic neutral switching during travel; Automatic gear engagement during travel RESET - otherwise replace gear adjuster, ZF 160	A61		E	1
973441	gear ASTRONIC: Sensor gear input speed Signal(s) implausible Travel: Switching blocked - cond.: Clutch opens, neut. switching blocked -system gear dep. conditionally available RESET - check speed sensor 1 and 2, ZF 102	A61		E	1
973442	gear ASTRONIC: Sensor gear input speed faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace gear adjuster, ZF 98	A61		E	1
973520	gear ASTRONIC: Sensor gear input speed 1 short circuit to ground Travel: Switching blocked - Automatic blocked RESET- otherwise replace sensor, cable harness or gear adjuster, ZF 22	A61.X2:6/11/18		E	1
973521	gear ASTRONIC: Sensor gear input speed 1 short circuit to supply voltage No function limitation - Automatic blocked RESET- otherwise replace sensor, cable harness or gear adjuster, ZF 86	A61.X2:6/11/18		E	1
973522	gear ASTRONIC: Sensor gear input speed 1 interruption Travel: Switching blocked - Automatic blocked RESET- otherwise replace sensor, cable harness or gear adjuster, ZF 54	A61.X2:6/11/18		E	1
973542	gear ASTRONIC: Sensor gear input speed 1 faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable harness or speed sensor, ZF 99	A61.X2:6/11/18		E	1
973642	gear ASTRONIC: Gear output rpm 2,travel speed CAN faulty/not present No function limitation RESET - check tacho system, ZF 100	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
973742	gear ASTRONIC: Sensor gear input speed 1/2 faulty/not present Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check speed sensor 1 and 2, ZF 101	A61		E	2
973831	gear ASTRONIC: TCU cut-off relay Activation error System not available RESET - check KI 30 ECU - otherwise replace gear adjuster, ZF 170	A61		E	2
973832	gear ASTRONIC: TCU cut-off relay Deactivation error System not available RESET - otherwise replace gear adjuster, ZF 169	A61		E	2
974020	gear ASTRONIC: Solenoid valve Y15 "Clutch closes slowly" short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear adjuster, ZF 19	A61.X2:7		E	1
974021	gear ASTRONIC: Solenoid valve Y15 "Clutch closes slowly" short circuit to supply voltage Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace cable harness coupling adjuster or coupling adjuster, ZF 83	A61.X2:7		E	2
974022	gear ASTRONIC: Solenoid valve Y15 "Clutch closes slowly" interruption Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable harness coupling adjuster or coupling adjuster, ZF 51	A61.X2:7		E	1
974033	gear ASTRONIC: Solenoid valve Y15 "Clutch closes slowly" Mechanical error Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace coupling adjuster, ZF 122	A61.X2:7		E	1
974120	gear ASTRONIC: Solenoid valve Y14 "Clutch closes quickly" short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear adjuster, ZF 21	A61.X2:8		E	1
974121	gear ASTRONIC: Solenoid valve Y14 "Clutch closes quickly" short circuit to supply voltage Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace cable harness coupling adjuster or coupling adjuster, ZF 85	A61.X2:8		E	2
974122	gear ASTRONIC: Solenoid valve Y14 "Clutch closes quickly" interruption Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable harness coupling adjuster or coupling adjuster, ZF 53	A61.X2:8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
974133	gear ASTRONIC: Solenoid valve Y14 "Clutch closes quickly" Mechanical error Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace coupling adjuster, ZF 123	A61.X2:8		E	1
974220	gear ASTRONIC: Solenoid valve Y17 "Clutch opens slowly" short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear adjuster, ZF 18	A61.X2:9		E	1
974221	gear ASTRONIC: Solenoid valve Y17 "Clutch opens slowly" short circuit to supply voltage Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace cable harness coupling adjuster or coupling adjuster, ZF 82	A61.X2:9		E	2
974222	gear ASTRONIC: Solenoid valve Y17 "Clutch opens slowly" interruption Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable harness coupling adjuster or coupling adjuster, ZF 50	A61.X2:9		E	1
974233	gear ASTRONIC: Solenoid valve Y17 "Clutch opens slowly" Mechanical error Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace coupling adjuster, ZF 120	A61.X2:9		E	1
974320	gear ASTRONIC: Solenoid valve Y16 "Clutch opens quickly" short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear adjuster, ZF 20	A61.X2:12		E	1
974321	gear ASTRONIC: Solenoid valve Y16 "Clutch opens quickly" short circuit to supply voltage Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace cable harness coupling adjuster or coupling adjuster, ZF 84	A61.X2:12		E	2
974322	gear ASTRONIC: Solenoid valve Y16 "Clutch opens quickly" interruption Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable harness coupling adjuster or coupling adjuster, ZF 52	A61.X2:12		E	1
974333	gear ASTRONIC: Solenoid valve Y16 "Clutch opens quickly" Mechanical error Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace coupling adjuster, ZF 121	A61.X2:12		E	1
974424	gear ASTRONIC: Sensor clutch voltage below required value Travel: Reduced comfort when travelling, no ranging, automatic time-controlled neutral switching, automatically blocked RESET - Replace gear adjuster or coupling adjuster, ZF 107	A61.X2:10/15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
974425	gear ASTRONIC: Sensor clutch Self-adjustment System not available RESET - otherwise replace gear adjuster, coupling adjuster, coupling, ZF 117	A61.X2:10/15		E	2
974442	gear ASTRONIC: Sensor clutch faulty/not present Travel: Reduced comfort when travelling, no ranging, automatic time-controlled neutral switching, automatically blocked RESET - otherwise replace coupling adjuster, ZF 124	A61.X2:10/15		E	1
974525	gear ASTRONIC: Clutch Self-adjustment System not available RESET - otherwise replace gear adjuster, coupling adjuster, coupling, ZF 117	A61		E	2
974531	gear ASTRONIC: Clutch Activation error Travel: Gear switching blocked - cond.: Engine stalled - automatic neutral switching - system not available RESET - otherwise replace gear adjuster, coupling adjuster, coupling, ZF 118	A61		E	2
974532	gear ASTRONIC: Clutch Deactivation error Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace gear adjuster, coupling adjuster, coupling, ZF 119	A61		E	2
974533	gear ASTRONIC: Clutch Mechanical error Standstill: forced neutral switching, if N reached, no further system limitation Switch off ignition, coupling opens, gear in N, ZF 114	A61		E	1
975421	gear ASTRONIC: TCU power supply short circuit to supply voltage No function limitation RESET - otherwise replace sensor or cables or gear adjuster, ZF 86	A61.X1:1/4/5		E	1
975422	gear ASTRONIC: TCU power supply interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace sensor or cables or gear adjuster, ZF 54	A61.X1:1/4/5		E	1
975923	gear ASTRONIC: On-board supply excess voltage No function limitation RESET - check on-board circuit voltage, ZF 104	A61		E	1
975924	gear ASTRONIC: On-board supply voltage below required value Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check on-board circuit voltage, ZF 105	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
976031	gear ASTRONIC: Ignition ON KI.15 Activation error Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check CAN-communication ECU - MOT, ZF 175	A61		E	1
976241	gear ASTRONIC: Idle switch Signal(s) implausible Condition: No ranging and start-up possible - automatic blocked RESET - check CAN-communication ECU - MOT (accelerator pedal), ZF 166	A61		E	1
976401	gear ASTRONIC: CAN-interface system Permanent error, Bus communication interrupted Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check cables of CAN communication, ZF 177	A61.X1:8/12		E	2
976404	gear ASTRONIC: CAN-interface system Memory error (queue overrun) Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check cables of CAN communication, ZF 179	A61.X1:8/12		E	2
976501	gear ASTRONIC: CAN-interface ZF Permanent error, Bus communication interrupted Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check cables of CAN communication, ZF 188	A61.X1:8/12		E	2
976503	gear ASTRONIC: CAN-interface ZF Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: automat. Engagement of last start-up gear - reverse gear blocked RESET - otherwise replace gear adjuster, ZF 110	A61.X1:8/12		E	1
976610	gear ASTRONIC: Internal error TCU Incorrect interrupt triggered Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - load software again - otherwise replace gear adjuster, ZF 188	A61.X1		E	2
976611	gear ASTRONIC: Internal error TCU Memory error (stack watch) Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - load software again - otherwise replace gear adjuster, ZF 189	A61.X1		E	2
976612	gear ASTRONIC: Internal error TCU Parameter faulty Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - load EOL parameter again, ZF 190	A61.X1		E	2
976613	gear ASTRONIC: Internal error TCU EEPROM parameter check sum Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Enter EOL parameter check sum again, ZF 191	A61.X1		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
976614	gear ASTRONIC: Internal error TCU EEPROM access faulty Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace gear adjuster, ZF 192	A61.X1		E	1
976640	gear ASTRONIC: Internal error TCU Communication faulty/not present Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear adjuster, ZF 90	A61.X1		E	2
976644	gear ASTRONIC: Internal error TCU excess temperature Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check cooling system gear again - otherwise replace gear adjuster, ZF 193	A61.X1		E	2
976703	gear ASTRONIC: CAN-data transfer ABS/ASR (ID 512) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check CAN-communication ECU - ABS, ZF 216	A61.X1:8/12		E	2
976803	gear ASTRONIC: CAN-data transfer ABS/ASR (ID 513) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check CAN-communication ECU - ABS, ZF 217	A61.X1:8/12		E	2
976903	gear ASTRONIC: CAN-data transfer E/A-module (ID 588) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check CAN-communication ECU - EA-module, ZF 230	A61.X1:8/12		E	2
977003	gear ASTRONIC: CAN-data transfer engine (ID 592) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check CAN-communication ECU - MOT, ZF 218	A61.X1:8/12		E	2
977103	gear ASTRONIC: CAN-data transfer engine (ID 593) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - check CAN-communication ECU - MOT, ZF 219	A61.X1:8/12		E	2
977203	gear ASTRONIC: CAN-data transfer retarder (ID 772) Faulty/missing, max. cycle time exceeded Loss of comfort during start-up, switching and ranging - automatic blocked RESET - check CAN-communication ECU - INT, ZF 220	A61.X1:8/12		E	1
977603	gear ASTRONIC: CAN-data transfer Intarder (12xx) Faulty/missing, max. cycle time exceeded Loss of comfort during start-up, switching and ranging RESET - check CAN-communication ECU - INT, ZF 225	A61.X1:8/12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
977703	gear ASTRONIC: CAN-data transfer engine (ID 1360) Faulty/missing, max. cycle time exceeded Loss of comfort during start-up, switching and ranging - automatic blocked RESET - check CAN-communication ECU - MOT, ZF 223	A61.X1:8/12		E	2
978042	gear ASTRONIC: CAN-signal travel speed faulty/not present No start-up gear calculation - no travel resistance calculation - travel strategy only operates conditionally RESET - check CAN signals ECU/ABS/ASR, ZF 92/93/94	A61.X1:8/12		E	1
978142	gear ASTRONIC: CAN-signal average speed front axle faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - check CAN-communication ECU - ABS, ZF 197	A61.X1:8/12		E	1
978242	gear ASTRONIC: CAN-signal differential speed front axle faulty/not present No function limitation RESET - check CAN-communication ECU - ABS, ZF 198	A61.X1:8/12		E	1
978342	gear ASTRONIC: CAN-signal intarder actual moment faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - check CAN-communication ECU - INT, ZF 28	A61.X1:8/12		E	1
978442	gear ASTRONIC: CAN-signal intarder shift-in faulty/not present No shift-in requirements with retarder operation - loss of cooling output RESET - check CAN-communication ECU - INT, ZF 29	A61.X1:8/12		E	1
978502	gear ASTRONIC: CAN-signal Telma actual moment Signal on CAN faulty/not present No function limitation RESET - check CAN-communication ECU - EA-module, ZF 229	A61.X1:8/12		E	1
978642	gear ASTRONIC: CAN-signal WSK-retarder faulty/not present Limited calculation of road resistance, error calculations with automatic gear selection thus possible Signals available on CAN again or switch on/off ignition, ZF 24	A61		E	1
979042	gear ASTRONIC: CAN-signal engine speed faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - check CAN-communication ECU - MOT, ZF 97	A61.X1:8/12		E	1
979140	gear ASTRONIC: CAN-signal drive moment Soll Communication faulty/not present Travel: Gear switching blocked - condition: Start-up gears can be switched - automatic blocked RESET - check CAN-communication ECU - MOT, ZF 163	A61.X1:8/12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
979242	gear ASTRONIC: CAN-signal drive moment 1st faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - check CAN-communication ECU - MOT, ZF 171	A61.X1:8/12		E	1
979342	gear ASTRONIC: CAN-signal engine moment dynamic faulty/not present No function limitation RESET - check CAN-communication ECU - MOT, ZF 167	A61.X1:8/12		E	1
979442	gear ASTRONIC: CAN-signal engine break moment faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - check CAN-communication ECU - MOT, ZF 31	A61.X1:8/12		E	1
979542	gear ASTRONIC: CAN-signal travel pedal faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - check CAN-communication ECU - MOT (accelerator pedal), ZF 165	A61.X1:8/12		E	1
979642	gear ASTRONIC: CAN-signal idle switch faulty/not present No function limitation RESET - check CAN-communication ECU - MOT (accelerator pedal), ZF 168	A61.X1:8/12		E	1
979742	gear ASTRONIC: CAN-signal brake switch faulty/not present Comfort impeded when braking - automatic blocked RESET - check CAN-communication ECU - MOT (brake switch), ZF 173	A61.X1:8/12		E	1
979942	gear ASTRONIC: CAN-signal Tempomat faulty/not present Switch oscillation in Tempomat operation possible RESET - check CAN-communication ECU - MOT (Tempomat), ZF 96	A61.X1:8/12		E	1
981113	WSK: Outlet recirculation valve Disconnection/wire break WSK-ECU no longer controls the outlet (recirculation valve), retarder response time increases Check cables, recirculation valve (inner res. approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 03	A63		E	1
981211	WSK: Outlet WK-valve short circuit to ground WSK-ECU no longer controls the outlet (WK-valve), only converter operation possible Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 04	A63		E	1
981212	WSK: Outlet WK-valve short circuit to supply voltage WSK-ECU no longer controls the outlet (WK-valve), no converter operation possible: line permanently active Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 05	A63		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
981213	WSK: Outlet WK-valve Disconnection/wire break WSK-ECU no longer controls the outlet (WK-valve), only converter operation possible Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 06	A63		E	1
981911	WSK: Outlet proportional valve retarder short circuit to ground WSK-ECU no longer controls the prop.-valve; no more retarder torque available Check cables, prop.-valve; replace WSK-ECU, ZF 10	A63		E	1
981912	WSK: Outlet proportional valve retarder short circuit to supply voltage WSK-ECU no longer controls the prop.-valve; (line permanently active; if no earth shut-down path - permanent brake) Check cables, prop.-valve; replace WSK-ECU, ZF 11	A63		E	1
981913	WSK: Outlet proportional valve retarder Disconnection/wire break WSK-ECU no longer controls the prop.-valve; no more retarder torque available Check cables, prop.-valve; replace WSK-ECU, ZF 12	A63		E	1
981914	WSK: Outlet proportional valve retarder Error in component/element/transmission WSK-ECU no longer controls the prop.-valve; no more retarder torque available Check cables, prop.-valve; replace WSK-ECU, ZF 13	A63		E	1
982111	WSK: Outlet earth switching proportional valve retarder short circuit to ground WSK-ECU shuts down the retarder; retarder no longer available. (line permanently active) Check cables, prop.-valve; replace WSK-ECU, ZF 14	A63		E	1
982112	WSK: Outlet earth switching proportional valve retarder short circuit to supply voltage WSK-ECU shuts down the retarder; retarder no longer available Check cables, prop.-valve; replace WSK-ECU, ZF 15	A63		E	1
982211	WSK: Outlet earth switching WK-valve short circuit to ground WSK-ECU no longer controls outlet (WK-valve), only converter operation possible (depending on status output WK-valve) Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 16	A63		E	1
982212	WSK: Outlet earth switching WK-valve short circuit to supply voltage WSK-ECU no longer controls outlet (WK-valve), only converter operation possible (depending on status output WK-valve) Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 17	A63		E	1
982213	WSK: Outlet earth switching WK-valve Disconnection/wire break WSK-ECU no longer controls the outlet (WK-valve), only converter operation possible Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 18	A63		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
982316	WSK: Current sensing proportional valve retarder Permissible signal range fallen short of WSK-ECU shuts down the retarder; retarder no longer available Replace WSK-ECU, ZF 24	A63		E	1
982317	WSK: Current sensing proportional valve retarder Permissible signal range exceeded WSK-ECU shuts down the retarder; retarder no longer available Replace WSK-ECU, ZF 25	A63		E	1
983119	WSK: Turbine speed Signal faulty/lacking Turbine speed interrupted: Limitation retarder power to 250mA; opened WK does not close; no active diagnosis Check CAN-Bus system, Bus subscriber, ZF 19	A63		E	1
983211	WSK: Oil temperature sensor short circuit to ground WSK-ECU limits the maximum permissible braking action to 100kW Check cables, temperature sensor; replace WSK-ECU, ZF 23	A63		E	1
983213	WSK: Oil temperature sensor Disconnection/wire break WSK-ECU limits the maximum permissible braking action to 100kW Check cables, temperature sensor; replace WSK-ECU, ZF 22	A63		E	1
983217	WSK: Oil temperature sensor Permissible signal range exceeded Warning information End converter operation; end or reduce retarder operation, ZF 20	A63		E	1
983419	WSK: Engine speed Signal faulty/lacking Engine speed interrupted: WK only closes at KD-threshold; no active diagnosis Check CAN-Bus system, Bus subscriber, ZF 34	A63		E	1
984319	WSK: CAN-transmission error Signal faulty/lacking No direct error reaction Check CAN-Bus system, Bus subscriber, ZF 37	A63		E	1
984415	WSK: CAN-bus system Error in component/element/transmission No direct error reaction Check CAN-Bus system, Bus subscriber, ZF 38	A63		E	1
984615	WSK: CAN-Bus transmission Error in component/element/transmission No direct error reaction Check CAN-Bus system, Bus subscriber, ZF 40	A63		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
985919	WSK: CAN-communication with engine (FMR1) Signal faulty/lacking Error reaction is dependent on the signals read in the message Check CAN-Bus system, Bus subscriber, ZF 48	A63		E	1
986119	WSK: CAN-communication with gear (EPS) Signal faulty/lacking Error reaction is dependent on the signals read in the message Check CAN-Bus system, Bus subscriber, ZF 50	A63		E	1
986219	WSK: CAN-communication with engine (FMR2) Signal faulty/lacking Error reaction is dependent on the signals read in the message Check CAN-Bus system, Bus subscriber, ZF 49	A63		E	1
986519	WSK: CAN-communication with gear (MKR) Signal faulty/lacking Error reaction is dependent on the signals read in the message Check CAN-Bus system, Bus subscriber, ZF 47	A63		E	1
987113	WSK: Terminal 30 Disconnection/wire break In operation: no reaction; with ignition OFF:no after-run operation Check supply of WSK-ECU (cables), check fuse terminal 30, ZF 26	A63		E	1
987216	WSK: Terminal 15 Permissible signal range fallen short of WSK-ECU shuts down the retarder; no retarder availability; digital outlets switched off; WK will not be closed Check on-board supply voltage (battery, alternator), ZF 28	A63		E	1
987217	WSK: Terminal 15 Permissible signal range exceeded WSK-ECU shuts down retarder; retarder no longer available Check on-board supply voltage (battery, alternator), ZF 27	A63		E	1
988218	WSK: Operating hours counter Plausibility error Operating hour meter can not be read from EEPROM, WSK-ECU resets operating hour meter to 0 Switch ignition on and off, if error is active again replace WSK-ECU, ZF 31	A63		E	0
988318	WSK: Error memory Plausibility error Error memory can not be read from EEPROM, WSK-ECU rejects the "old" error memory content Delete error memory, then switch ignition on and off, if error is active again replace WSK-ECU, ZF 32	A63		E	0
988415	WSK: System error Error in component/element/transmission Replace WSK-ECU, ZF 35	A63		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B78FA0	LSB-TE7: control heating/air conditioning Set air circ./ no fresh air ground/back measure short circuit VCC	A87		E	1
B78FA1	LSB-TE7: control heating/air conditioning Set air circ. / no fresh air VCC / back measure short circuit ground	A87		E	1
B78FA2	LSB-TE7: control heating/air conditioning Set air circ. / fresh air flap blocked	A87		E	1
B78FA3	LSB-TE7: control heating/air conditioning Set air circ. / fresh air left interruption / short circuit ground	A87		E	1
B78FA4	LSB-TE7: control heating/air conditioning Set air circ. / fresh air right interruption / short circuit ground	A87		E	1
B78FA5	LSB-TE7: control heating/air conditioning Set air foot / window ground missing / back measure short circuit VCC	A87		E	1
B78FA6	LSB-TE7: control heating/air conditioning Set air foot / window VCC missing / back measure short circuit ground	A87		E	1
B78FA7	LSB-TE7: control heating/air conditioning Set air foot / window flap blocked	A87		E	1
B78FA8	LSB-TE7: control heating/air conditioning Set air foot / window left interruption / short circuit ground	A87		E	1
B78FA9	LSB-TE7: control heating/air conditioning Set air foot / window right interruption / short circuit ground	A87		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EFF001	LSB-BTT: System error Data comm. Infrared or cable defect (charge impulse recognized) Fatal system error BTT, Data transfer interrupted Clean cover glass for infrared interface, replace BTT or payload bay			E	1
EFF002	LSB-BTT: System error Data communication via Infrared or cables without charge impulse Fatal system error BTT, Data transfer interrupted Clean charge contacts, replace BTT or payload bay			E	1
EFF003	LSB-BTT: System error General internal error Fatal system error BTT, Data transfer interrupted Reset, replace BTT			E	2
EFF004	LSB-BTT: System error Data transfer erroneous, Packet size incorrect Fatal system error BTT, Data transfer interrupted Reset, BTT or replace BTB			E	2
EFF005	LSB-BTT: System error Data transfer erroneous, Packet content incorrect Fatal system error BTT, Data transfer interrupted Reset, BTT or replace BTB			E	2
EFF006	LSB-BTT: System error Data transfer pictograms to BTT-E defective Fatal system error BTT, Data transfer interrupted Clean cover glass for infrared interface, replace BTT or BTT-E			E	2
EFF007	LSB-BTT: System error File system Fatal system error BTT, Data transfer interrupted After software change, load BTT, replace BTT			E	2
EFF008	LSB-BTT: System error Comm-driver Fatal system error BTT, Data transfer interrupted Reset, after software replacement load BTT, replace BTT			E	2
EFF009	LSB-BTT: System error Synchronization internal software processes (thread) erroneous Fatal system error BTT, Data transfer interrupted Reset, after software replacement load BTT, replace BTT			E	2
EFF010	LSB-BTT: System error Data format of a pictogram invalid Fatal system error BTT, Data transfer interrupted Replace software			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EFF011	LSB-BTT: System error Maximum number of pictograms exceeded Fatal system error BTT, Data transfer interrupted BTT-E tauschen			E	2
F00000	LSB-BKE1: Central lubrication system defective Indicator light red, entry in error stack Check central greasing system, change module if nec.	A371.X2:11	O-458.A3	E	1
F00110	LSB-BKE1: Tele control Pin condition Tele/tong erroneous/implausible Entry in error stack Check limit switch and electr. connections, change module if nec.	A371		E	1
F02000	LSB-BKE1: Airplane warning light defective Entry in error stack Check electr. connections and airplane warning light, replace module, if nec.	A371.X2:16	O-506.D5	E	1
F0605D	LSB-BKE1: Module temperature too high / prewarning Entry in error stack Check power users(headlights)+ electr. connections, replace module if nec.	A371		E	2
F0605E	LSB-BKE1: Module temperature too high / shut off of users Headlights are turned off step by step, entry in error stack Check power users(headlights)+ electr. connections, replace module if nec.	A371		E	2
F07090	LSB-BKE1: Keyboard Button actuated/erroneous Entry in error stack Replace module	A371		E	1
F08781	LSB-BKE1: Digital input E0.7 short circuit to supply voltage, open line Error display per blinking LED, Entry in error stack Test electr. connections and windshield wiper motor, change module if nec.	A371.X2:3	O-462.B2	E	1
F08881	LSB-BKE1: Digital input E0.8 short circuit to supply voltage, open line Error display per blinking LED, Entry in error stack Test electr. connections and windshield wiper motor, change module if nec.	A371.X2:1	O-462.B7	E	1
F08981	LSB-BKE1: Digital input E0.9 short circuit to supply voltage, open line Error display per blinking LED, Entry in error stack Test electr. connections and windshield wiper motor, change module if nec.	A371.X2:2	O-506.D2	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F0B05C	LSB-BKE1: Supply voltage 30.4 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X4:2/3	O-399.C5/399.C6	E	2
F0B15C	LSB-BKE1: Supply voltage 30.1 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X3:2	O-461.B6	E	2
F0B25C	LSB-BKE1: Supply voltage 30.2 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X3:3	O-461.B3	E	2
F0B35C	LSB-BKE1: Supply voltage 30.3 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X3:6	O-398.B5	E	2
F0B45C	LSB-BKE1: Supply voltage 15.2 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X4:6	O-399.C5	E	2
F0B55C	LSB-BKE1: Supply voltage 15.1 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X1:2	O-399.C4	E	2
F0C05B	LSB-BKE1: Switch outlet A0.0 open, insufficient load, short circuit,overload or excess temp. Entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:10	O-506.E6	E	1
F0C25B	LSB-BKE1: Switching output A0.2 open, insufficient load, short circuit,overload or excess temp. Entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:7	O-506.E5	E	1
F0C45B	LSB-BKE1: Switching output A0.4 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:8	O-506.D7	E	1
F0C55B	LSB-BKE1: Switching output A0.5 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:11	O-506.D7	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F0C65B	LSB-BKE1: Switching output A0.6 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:15	O-477.B2	E	1
F0C75B	LSB-BKE1: Switching output A0.7 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:8	O-477.B1	E	1
F0C85B	LSB-BKE1: Switching output A0.8 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:9	O-479.B2	E	1
F0C95B	LSB-BKE1: Switching output A0.9 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:12	O-479.B3	E	1
F0CA5B	LSB-BKE1: Switching output A0.10 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:9	O-462.B5	E	1
F0CB5B	LSB-BKE1: Switching output A0.11 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:12	O-462.B5	E	1
F0CC5B	LSB-BKE1: Switching output A0.12 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:15	O-462.B7	E	1
F0CE5B	LSB-BKE1: Switching output A0.14 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:14	O-462.B2	E	1
F0D15B	LSB-BKE1: Switching output A2.1 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:16	O-506.E7	E	1
F0D25B	LSB-BKE1: Switching output A2.2 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:5	O-319.A7	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F0D35B	LSB-BKE1: Switching output A2.3 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:1	O-478.B1	E	1
F0D45B	LSB-BKE1: Switching output A2.4 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:4	O-461.C3	E	1
F0D55B	LSB-BKE1: Switching output A2.5 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:7	O-461.C5	E	1
F0D65B	LSB-BKE1: Switching output A2.6 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:10	O-476.A2	E	1
F0D75B	LSB-BKE1: Switching output A2.7 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:13	O-479.B1	E	1
F0D85B	LSB-BKE1: Switching output A2.8 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:14	O-398.B7	E	1
F0D95B	LSB-BKE1: Switching output A2.9 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:11	O-398.B6	E	1
F0DA5B	LSB-BKE1: Switching output A2.10 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:17	O-398.B6	E	1
F0DB5B	LSB-BKE1: Switching output A2.11 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:13	O-400.D5	E	1
F0DC5B	LSB-BKE1: Switching output A2.12 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:1	O-506.E3	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F0DD5B	LSB-BKE1: Switching output A2.13 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:4	O-506.E4	E	1
F0E05B	LSB-BKE1: Switching output A2.15 open, insufficient load, short circuit, overload or excess temp. Entry in error stack, set error status bit EW5 Check outlet supply, user, change module if nec.	A371.X1:3	O-400.D2	E	1
F0F0A0	LSB-BKE1: Control Funktion blocked: button actuation without release Entry in error stack Carry out the manual buttons release	A371		B	1
F0F0A1	LSB-BKE1: Control Funktion locked: sequence of key actuation not observed Entry in error stack Carry out the manual buttons release	A371		B	1
F0F0A2	LSB-BKE1: Control Funktion blocked: button actuation impermissible Entry in error stack Press only one function key	A371		B	1
F0F108	LSB-BKE1: System error OS-CPU EEPROM erroneous Blinker code on internal LED, entry in error stack, no reaction Replace module	A371		E	1
F0F120	LSB-BKE1: System error OS-CPU task-watchdog expired Blinker code on internal LED, entry in error stack, no reaction Replace module	A371		E	2
F0F1C0	LSB-BKE1: System error OS-CPU Hardware / Software erroneous Blinker code on internal LED, entry in error stack, no reaction Replace module	A371		E	2
F0FC5A	LSB-BKE1: Control data transfer LSB Parameter block has erroneous test sum Entry in error stack Replace module	A371		E	1
F0FC5B	LSB-BKE1: Control data transfer LSB Short circuit on 2nd LSB-Transistor Entry in error stack Replace module	A371		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F41963	LSB-BTB4: LSBA Participant Adr. 25 not available or open line	A34.X4:12	O-383.D2	E	1
F41A63	LSB-BTB4: LSBA Participant Adr. 26 not available or open line	A34.X4:12	O-383.D2	E	1
F43508	LSB-BTB4: LSBB Participant Adr. 5 bus transmission exceeded	A34.X4:9	O-383.D3	E	1
F45FA4	LSB-BTB4: Control Radio remote control Oil supply stopped, no control	A34		E	1
F46003	LSB-BTB4: Control Radio remote control Locked, too many buttons on terminal actuated	A34		B	1
F460A4	LSB-BTB4: Control Radio remote control Oil supply stopped, no control	A34		E	1
F460B1	LSB-BTB4: Control Radio remote control Collective error Shut off winch 1 Check exact errors on Liccon	A34		E	1
F460B2	LSB-BTB4: Control Radio remote control Collective error Shut off winch 2 Check exact errors on Liccon	A34		E	1
F460B3	LSB-BTB4: Control Radio remote control Collective error Shut off winch 3 Check exact errors on Liccon	A34		E	1
F460B4	LSB-BTB4: Control Radio remote control Collective error Shut off winch 4 Check exact errors on Liccon	A34		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F460B5	LSB-BTB4: Control Radio remote control Collective error Shut off winch 5 Check exact errors on Liccon	A34		E	1
F460B6	LSB-BTB4: Control Radio remote control Collective error Shut off winch 6 Check exact errors on Liccon	A34		E	1
F460B7	LSB-BTB4: Control Radio remote control Collective error Shut off turning Check exact errors on Liccon	A34		E	1
F460B8	LSB-BTB4: Control Radio remote control Collective error Shut off ballast Check exact errors on Liccon	A34		E	1
F460B9	LSB-BTB4: Control Radio remote control Collective error Shut off assembly cyl. Check exact errors on Liccon	A34		E	1
F460BA	LSB-BTB4: Control Radio remote control Collective error Shut off hoist top Check exact errors on Liccon	A34		E	1
F460BB	LSB-BTB4: Control Radio remote control Collective error Shut off LMB Check exact errors on Liccon	A34		E	1
F460BC	LSB-BTB4: Control Radio remote control Collective error Shut off MS-BTTE	A34		E	1
F460BD	LSB-BTB4: Control Radio remote control Collective error engine not running	A34		E	1
F460BE	LSB-BTB4: Control Radio remote control Collective error Seat contact	A34		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F460BF	LSB-BTB4: Control Radio remote control Master switch BTT-E deflected without confirmation F7	A34		B	1
F46220	LSB-BTB4: Control hydraulic Pressure stage p0 - pressure too high - Shut off	A34		B	1
F462A0	LSB-BTB4: Control hydraulic No confirmation pump9 for hydr. shaft	A34		E	1
F462A1	LSB-BTB4: Control hydraulic Valve Y206 round run hydr. shaft switched erroneous	A34		E	1
F462A2	LSB-BTB4: Control hydraulic Pressure check hydr. shaft at turn on notOK	A34		E	1
F462A3	LSB-BTB4: Control hydraulic Pressure check hydr. shaft at turn off notOK	A34		E	1
F462A4	LSB-BTB4: Control hydraulic Hydr. shaft is turned on, pressure in round run erroneous	A34		E	1
F462A5	LSB-BTB4: Control hydraulic Pressure check op. hydr. shaft erroneous, pressure too low	A34		E	1
F462A6	LSB-BTB4: Control hydraulic Pump 9 from cab assigned, hydr. shaft not usable	A34		E	1
F47E25	LSB-BTB4: Boot up phase crane control / emerg.off Emerg. off active, at active radio remote control	A34		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F488E9	LSB-BTB4: control supports Current re-measure Supply CAN-valves erroneous	A34		E	1
F488EA	LSB-BTB4: control supports Return current measurement beacon erroneous	A34		E	1
F488EB	LSB-BTB4: control supports Return current measurement lighting support left erroneous	A34		E	1
F488EC	LSB-BTB4: control supports Return current measurement lighting support right erroneous	A34		E	1
F48A20	LSB-BTB4: Operation crawler High-speed gear crawler is not poss. - parallel op. crawler is on	A34		E	1
F48A23	LSB-BTB4: Operation crawler Parallel operation crawler cannot be selected	A34		E	1
F48A28	LSB-BTB4: Operation crawler Drive crawler not possible - crawler not turned on	A34		E	1
F4AC01	LSB-BTB4: operation supports operation of 2-hand-function without activation of 2-hand-key	A34		B	1
F4AC24	LSB-BTB4: operation supports no customized function in under-carriage operation mode	A34		B	1
F4ACE0	LSB-BTB4: operation supports Movement impermissible, turntable not in longitudinal axis	A34		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4ACEC	LSB-BTB4: operation supports Selection not permitted, since pressure sensor erroneous	A34		B	1
F4ACF0	LSB-BTB4: operation supports Incline too large for support	A34		B	1
F4ACF1	LSB-BTB4: operation supports Pressure of at least one support below limit value	A34		B	1
F4ACF2	LSB-BTB4: operation supports Support 1 may not proceed in this direction	A34		B	1
F4ACF3	LSB-BTB4: operation supports Support 2 may not proceed in this direction	A34		B	1
F4ACF4	LSB-BTB4: operation supports Support 3 may not proceed in this direction	A34		B	1
F4ACF5	LSB-BTB4: operation supports Support 4 may not proceed in this direction	A34		B	1
F4ACF6	LSB-BTB4: operation supports Selection not permitted since incline sensor faulty	A34		B	1
F4AE0C	LSB-BTB4: Operation crawler Simultaneous from different control locations	A34		B	1
F4C218	LSB-BTB4: Hardware excess temperature	A34		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4C21B	LSB-BTB4: Hardware digital shut off defective	A34		E	2
F4C21F	LSB-BTB4: Hardware After run logic defective	A34		E	2
F4C226	LSB-BTB4: Hardware Under temperature	A34		E	2
F4C261	LSB-BTB4: Hardware measuring system defect	A34		E	2
F4C504	LSB-BTB4: System voltage Logic / CPU0 level exceeded	A34		E	2
F4C505	LSB-BTB4: System voltage Logic / CPU0 below minimum level	A34		E	2
F4C50F	LSB-BTB4: System voltage Logic / CPU0 different information on other processor	A34		E	2
F4C604	LSB-BTB4: System voltage CPU/Logic / CPU0 level exceeded	A34		E	2
F4C605	LSB-BTB4: System voltage CPU/Logic / CPU0 below minimum level	A34		E	2
F4C60F	LSB-BTB4: System voltage CPU/Logic / CPU0 different information on other processor	A34		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4C704	LSB-BTB4: Supply voltage 30 (A0-7) / CPU0 level exceeded	A34.X1:2/3	O-381.C3	E	2
F4C705	LSB-BTB4: Supply voltage 30 (A0-7) / CPU0 below minimum level	A34.X1:2/3	O-381.C3	E	2
F4C804	LSB-BTB4: Supply voltage 15.1 / CPU0 level exceeded	A34.X1:1	O-381.C4	E	2
F4C805	LSB-BTB4: Supply voltage 15.1 / CPU0 below minimum level	A34.X1:1	O-381.C4	E	2
F4C80F	LSB-BTB4: Supply voltage 15.1 / CPU0 different information on other processor	A34.X1:1	O-381.C4	E	2
F4CC04	LSB-BTB4: System voltage Logic / CPU1 level exceeded	A34		E	2
F4CC05	LSB-BTB4: System voltage Logic / CPU1 below minimum level	A34		E	2
F4CC0F	LSB-BTB4: System voltage Logic / CPU1 different information on other processor	A34		E	2
F4CD04	LSB-BTB4: System voltage CPU/Logic / CPU1 level exceeded	A34		E	2
F4CD05	LSB-BTB4: System voltage CPU/Logic / CPU1 below minimum level	A34		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4CD0F	LSB-BTB4: System voltage CPU/Logic / CPU1 different information on other processor	A34		E	2
F4CE04	LSB-BTB4: Supply voltage 30 (A8-15) / CPU1 level exceeded	A34.X2:2/3	O-381.C6/381.C7	E	2
F4CE05	LSB-BTB4: Supply voltage 30 (A8-15) / CPU1 below minimum level	A34.X2:2/3	O-381.C6/381.C7	E	2
F4CF04	LSB-BTB4: Supply voltage 15.2 / CPU1 level exceeded	A34.X2:1	O-381.C5	E	2
F4CF05	LSB-BTB4: Supply voltage 15.2 / CPU1 below minimum level	A34.X2:1	O-381.C5	E	2
F4CF0F	LSB-BTB4: Supply voltage 15.2 / CPU1 different information on other processor	A34.X2:1	O-381.C5	E	2
F4D004	LSB-BTB4: Digital input E0 level exceeded	A34.X1:4	O-275.F2	E	2
F4D005	LSB-BTB4: Digital input E0 below minimum level	A34.X1:4	O-275.F2	E	2
F4D012	LSB-BTB4: Digital input E0 short circuit to ground	A34.X1:4	O-275.F2	E	1
F4D014	LSB-BTB4: Digital input E0 short circuit to supply voltage	A34.X1:4	O-275.F2	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4D104	LSB-BTB4: Digital input E1 level exceeded	A34.X1:5	O-187.E2	E	2
F4D105	LSB-BTB4: Digital input E1 below minimum level	A34.X1:5	O-187.E2	E	2
F4D204	LSB-BTB4: Digital input E2 level exceeded	A34.X1:6	O-507.A3	E	2
F4D205	LSB-BTB4: Digital input E2 below minimum level	A34.X1:6	O-507.A3	E	2
F4D304	LSB-BTB4: Digital input E3 level exceeded	A34.X1:7	O-507.A4	E	2
F4D305	LSB-BTB4: Digital input E3 below minimum level	A34.X1:7	O-507.A4	E	2
F4D354	LSB-BTB4: Digital input E3 short circuit to supply voltage	A34.X1:7	O-507.A4	E.	1
F4D356	LSB-BTB4: Digital input E3 open circuit or short circuit to ground	A34.X1:7	O-507.A4	E.	1
F4D454	LSB-BTB4: Digital input E4 short circuit to supply voltage	A34.X1:8	O-310.F2	E.	1
F4D456	LSB-BTB4: Digital input E4 open circuit or short circuit to ground	A34.X1:8	O-310.F2	E.	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4D554	LSB-BTB4: Digital input E5 short circuit to supply voltage	A34.X1:9	O-310.F1	E.	1
F4D556	LSB-BTB4: Digital input E5 open circuit or short circuit to ground	A34.X1:9	O-310.F1	E.	1
F4D804	LSB-BTB4: Digital input E8 level exceeded	A34.X2:4	O-381.C5	E	2
F4D805	LSB-BTB4: Digital input E8 below minimum level	A34.X2:4	O-381.C5	E	2
F4D904	LSB-BTB4: Digital input E9 level exceeded	A34.X2:5	O-184.F8	E	2
F4D905	LSB-BTB4: Digital input E9 below minimum level	A34.X2:5	O-184.F8	E	2
F4DA04	LSB-BTB4: Digital input E10 level exceeded	A34.X2:6	O-187.E3	E	2
F4DA05	LSB-BTB4: Digital input E10 below minimum level	A34.X2:6	O-187.E3	E	2
F4DB04	LSB-BTB4: Digital input E11 level exceeded	A34.X2:7	O-507.A4	E	2
F4DB05	LSB-BTB4: Digital input E11 below minimum level	A34.X2:7	O-507.A4	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4DE54	LSB-BTB4: Digital input E14 short circuit to supply voltage	A34.X2:10	O-507.A5	E	1
F4DE56	LSB-BTB4: Digital input E14 open circuit or short circuit to ground	A34.X2:10	O-507.A5	E	1
F4E012	LSB-BTB4: Switching output A0 short circuit to ground	A34.X1:12	O-507.C2	E	2
F4E01D	LSB-BTB4: Switching output A0 Initial current outside permissible range	A34.X1:12	O-507.C2	E	2
F4E054	LSB-BTB4: Switching output A0 short circuit to supply voltage	A34.X1:12	O-507.C2	E	2
F4E072	LSB-BTB4: Switching output A0 outside source feeding	A34.X1:12	O-507.C2	E	2
F4E112	LSB-BTB4: Switching output A1 short circuit to ground	A34.X1:13	O-507.C2	E	2
F4E11D	LSB-BTB4: Switching output A1 Initial current outside permissible range	A34.X1:13	O-507.C2	E	2
F4E154	LSB-BTB4: Switching output A1 short circuit to supply voltage	A34.X1:13	O-507.C2	E	2
F4E172	LSB-BTB4: Switching output A1 outside source feeding	A34.X1:13	O-507.C2	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4E212	LSB-BTB4: Switching output A2 short circuit to ground	A34.X1:14	O-274.A4	E	2
F4E21D	LSB-BTB4: Switching output A2 Initial current outside permissible range	A34.X1:14	O-274.A4	E	2
F4E254	LSB-BTB4: Switching output A2 short circuit to supply voltage	A34.X1:14	O-274.A4	E	2
F4E272	LSB-BTB4: Switching output A2 outside source feeding	A34.X1:14	O-274.A4	E	2
F4E312	LSB-BTB4: Switching output A3 short circuit to ground	A34.X1:15	O-412.F4	E	2
F4E31D	LSB-BTB4: Switching output A3 Initial current outside permissible range	A34.X1:15	O-412.F4	E	2
F4E354	LSB-BTB4: Switching output A3 short circuit to supply voltage	A34.X1:15	O-412.F4	E	2
F4E372	LSB-BTB4: Switching output A3 outside source feeding	A34.X1:15	O-412.F4	E	2
F4E412	LSB-BTB4: Switching output A4 short circuit to ground	A34.X1:16	O-274.A4	E	2
F4E41D	LSB-BTB4: Switching output A4 Initial current outside permissible range	A34.X1:16	O-274.A4	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4E454	LSB-BTB4: Switching output A4 short circuit to supply voltage	A34.X1:16	O-274.A4	E	2
F4E472	LSB-BTB4: Switching output A4 outside source feeding	A34.X1:16	O-274.A4	E	2
F4E512	LSB-BTB4: Switching output A5 short circuit to ground	A34.X1:17	O-507.C3	E	2
F4E51D	LSB-BTB4: Switching output A5 Initial current outside permissible range	A34.X1:17	O-507.C3	E	2
F4E554	LSB-BTB4: Switching output A5 short circuit to supply voltage	A34.X1:17	O-507.C3	E	2
F4E572	LSB-BTB4: Switching output A5 outside source feeding	A34.X1:17	O-507.C3	E	2
F4E612	LSB-BTB4: Switching output A6 short circuit to ground	A34.X1:18	O-384.A2	E	2
F4E61D	LSB-BTB4: Switching output A6 Initial current outside permissible range	A34.X1:18	O-384.A2	E	2
F4E654	LSB-BTB4: Switching output A6 short circuit to supply voltage	A34.X1:18	O-384.A2	E	2
F4E672	LSB-BTB4: Switching output A6 outside source feeding	A34.X1:18	O-384.A2	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4E712	LSB-BTB4: Switching output A7 short circuit to ground	A34.X1:19	O-310.A7	E	2
F4E71D	LSB-BTB4: Switching output A7 Initial current outside permissible range	A34.X1:19	O-310.A7	E	2
F4E754	LSB-BTB4: Switching output A7 short circuit to supply voltage	A34.X1:19	O-310.A7	E	2
F4E772	LSB-BTB4: Switching output A7 outside source feeding	A34.X1:19	O-310.A7	E	2
F4E812	LSB-BTB4: Switching output A8 short circuit to ground	A34.X2:12	O-310.A7	E	2
F4E81D	LSB-BTB4: Switching output A8 Initial current outside permissible range	A34.X2:12	O-310.A7	E	2
F4E854	LSB-BTB4: Switching output A8 short circuit to supply voltage	A34.X2:12	O-310.A7	E	2
F4E872	LSB-BTB4: Switching output A8 outside source feeding	A34.X2:12	O-310.A7	E	2
F4E912	LSB-BTB4: Switching output A9 short circuit to ground	A34.X2:13	O-310.A6	E	2
F4E91D	LSB-BTB4: Switching output A9 Initial current outside permissible range	A34.X2:13	O-310.A6	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4E954	LSB-BTB4: Switching output A9 short circuit to supply voltage	A34.X2:13	O-310.A6	E	2
F4E972	LSB-BTB4: Switching output A9 outside source feeding	A34.X2:13	O-310.A6	E	2
F4EA12	LSB-BTB4: Switching output A10 short circuit to ground	A34.X2:14	O-507.C4	E	2
F4EA1D	LSB-BTB4: Switching output A10 Initial current outside permissible range	A34.X2:14	O-507.C4	E	2
F4EA54	LSB-BTB4: Switching output A10 short circuit to supply voltage	A34.X2:14	O-507.C4	E	2
F4EA72	LSB-BTB4: Switching output A10 outside source feeding	A34.X2:14	O-507.C4	E	2
F4EB12	LSB-BTB4: Switching output A11 short circuit to ground	A34.X2:15	O-310.A8	E	2
F4EB1D	LSB-BTB4: Switching output A11 Initial current outside permissible range	A34.X2:15	O-310.A8	E	2
F4EB54	LSB-BTB4: Switching output A11 short circuit to supply voltage	A34.X2:15	O-310.A8	E	2
F4EB72	LSB-BTB4: Switching output A11 outside source feeding	A34.X2:15	O-310.A8	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4EC12	LSB-BTB4: Switching output A12 short circuit to ground	A34.X2:16	O-507.C4	E	2
F4EC1D	LSB-BTB4: Switching output A12 Initial current outside permissible range	A34.X2:16	O-507.C4	E	2
F4EC54	LSB-BTB4: Switching output A12 short circuit to supply voltage	A34.X2:16	O-507.C4	E	2
F4EC72	LSB-BTB4: Switching output A12 outside source feeding	A34.X2:16	O-507.C4	E	2
F4ED12	LSB-BTB4: Switching output A13 short circuit to ground	A34.X2:17	O-311.A1	E	2
F4ED1D	LSB-BTB4: Switching output A13 Initial current outside permissible range	A34.X2:17	O-311.A1	E	2
F4ED54	LSB-BTB4: Switching output A13 short circuit to supply voltage	A34.X2:17	O-311.A1	E	2
F4ED72	LSB-BTB4: Switching output A13 outside source feeding	A34.X2:17	O-311.A1	E	2
F4EE12	LSB-BTB4: Switching output A14 short circuit to ground	A34.X2:18	O-507.C5	E	2
F4EE1D	LSB-BTB4: Switching output A14 Initial current outside permissible range	A34.X2:18	O-507.C5	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4EE54	LSB-BTB4: Switching output A14 short circuit to supply voltage	A34.X2:18	O-507.C5	E	2
F4EE72	LSB-BTB4: Switching output A14 outside source feeding	A34.X2:18	O-507.C5	E	2
F4EF12	LSB-BTB4: Switching output A15 short circuit to ground	A34.X2:19	O-383.A7	E	2
F4EF1D	LSB-BTB4: Switching output A15 Initial current outside permissible range	A34.X2:19	O-383.A7	E	2
F4EF54	LSB-BTB4: Switching output A15 short circuit to supply voltage	A34.X2:19	O-383.A7	E	2
F4EF72	LSB-BTB4: Switching output A15 outside source feeding	A34.X2:19	O-383.A7	E	2
F4F002	LSB-BTB4: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous	A34		E	1
F4F013	LSB-BTB4: System error OS-CPU0 Test sum in FLASH erroneous	A34		E	1
F4F016	LSB-BTB4: System error OS-CPU0 system-, driver-watchdog expired	A34		E	1
F4F050	LSB-BTB4: System error OS-CPU0 file not available error report Reload application software	A34		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4F068	LSB-BTB4: System error OS-CPU0 impermissible interrupt	A34		E	1
F4F070	LSB-BTB4: System error OS-CPU0 various structure versions	A34		E	1
F4F073	LSB-BTB4: System error OS-CPU0 interpreter error At P0=00000013 carry out download	A34		E	1
F4F075	LSB-BTB4: System error OS-CPU0 SPI-error	A34		E	1
F4F078	LSB-BTB4: System error OS-CPU0 impermissible parameter	A34		E	1
F4F07A	LSB-BTB4: System error OS-CPU0 Configuration file missing or faulty	A34		E	2
F4F080	LSB-BTB4: System error OS-CPU0 Fatal internal error	A34		E	1
F4F082	LSB-BTB4: System error OS-CPU0 hardware-watchdog erroneous	A34		E	1
F4F0AC	LSB-BTB4: System error OS-CPU0 Restoration of CW-operandi failed	A34		E	1
F4F0C1	LSB-BTB4: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A34		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4F102	LSB-BTB4: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous	A34		E	1
F4F113	LSB-BTB4: System error OS-CPU1 Test sum in FLASH erroneous	A34		E	1
F4F116	LSB-BTB4: System error OS-CPU1 system-, driver-watchdog expired	A34		E	1
F4F150	LSB-BTB4: System error OS-CPU1 file not available error report Reload application software	A34		E	2
F4F168	LSB-BTB4: System error OS-CPU1 impermissible interrupt	A34		E	1
F4F170	LSB-BTB4: System error OS-CPU1 various structure versions	A34		E	1
F4F173	LSB-BTB4: System error OS-CPU1 interpreter error At P0=00000013 carry out download	A34		E	1
F4F175	LSB-BTB4: System error OS-CPU1 SPI-error	A34		E	1
F4F178	LSB-BTB4: System error OS-CPU1 impermissible parameter	A34		E	1
F4F17A	LSB-BTB4: System error OS-CPU1 Configuration file missing or faulty	A34		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4F180	LSB-BTB4: System error OS-CPU1 Fatal internal error	A34		E	1
F4F182	LSB-BTB4: System error OS-CPU1 hardware-watchdog erroneous	A34		E	1
F4F1AC	LSB-BTB4: System error OS-CPU1 Restoration of CW-operandi failed	A34		E	1
F4F1C1	LSB-BTB4: System error OS-CPU1 Incorrect or wrong system version for application error report Reload matching system version	A34		E	1
F4F800	LSB-BTB4: Control data transfer CAN EP0 internal error at Register-check Controller CAN-transfer is not started replace control device	A34.X3:7/8/3/3	O-507.C2/507.C4	E	2
F4F801	LSB-BTB4: Control data transfer CAN EP0 internal error at RAM-check Controller CAN-transfer is not started replace control device	A34.X3:7/8/3/3	O-507.C2/507.C4	E	2
F4F802	LSB-BTB4: Control data transfer CAN EP0 Configuration error Software Error message, CAN report is not configured Check software	A34.X3:7/8/3/3	O-507.C2/507.C4	E	1
F4F804	LSB-BTB4: Control data transfer CAN EP0 Configuration error time synchronization Time synchronization already active or is not configured Check software	A34.X3:7/8/3/3	O-507.C2/507.C4	E	1
F4F805	LSB-BTB4: Control data transfer CAN EP0 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A34.X3:7/8/3/3	O-507.C2/507.C4	E	1
F4F806	LSB-BTB4: Control data transfer CAN EP0 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A34.X3:7/8/3/3	O-507.C2/507.C4	E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4F811	LSB-BTB4: Control data transfer CAN EP0 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A34.X3:7/8/3/3	O-507.C2/507.C4	E	2
F4F900	LSB-BTB4: Control data transfer CAN EP1 internal error at Register-check Controller CAN-transfer is not started replace control device	A34.X4:1/2/14/13	O-507.D2/507.D4	E	2
F4F901	LSB-BTB4: Control data transfer CAN EP1 internal error at RAM-check Controller CAN-transfer is not started replace control device	A34.X4:1/2/14/13	O-507.D2/507.D4	E	2
F4F902	LSB-BTB4: Control data transfer CAN EP1 Configuration error Software Error message, CAN report is not configured Check software	A34.X4:1/2/14/13	O-507.D2/507.D4	E	1
F4F904	LSB-BTB4: Control data transfer CAN EP1 Configuration error time synchronization Time synchronization already active or is not configured Check software	A34.X4:1/2/14/13	O-507.D2/507.D4	E	1
F4F905	LSB-BTB4: Control data transfer CAN EP1 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A34.X4:1/2/14/13	O-507.D2/507.D4	E	1
F4F906	LSB-BTB4: Control data transfer CAN EP1 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A34.X4:1/2/14/13	O-507.D2/507.D4	E	2
F4F911	LSB-BTB4: Control data transfer CAN EP1 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A34.X4:1/2/14/13	O-507.D2/507.D4	E	2
F4FA00	LSB-BTB4: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A34.X3:7/8	O-507.C2	E	1
F4FA01	LSB-BTB4: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A34.X3:7/8	O-507.C2	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4FA02	LSB-BTB4: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A34.X3:7/8	O-507.C2	E	1
F4FA04	LSB-BTB4: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A34.X3:7/8	O-507.C2	E	1
F4FA05	LSB-BTB4: Control data transfer CAN-A Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A34.X3:7/8	O-507.C2	E	1
F4FA06	LSB-BTB4: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A34.X3:7/8	O-507.C2	E	2
F4FA11	LSB-BTB4: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A34.X3:7/8	O-507.C2	E	1
F4FB00	LSB-BTB4: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A34.X3:3/4	O-507.C4	E	1
F4FB01	LSB-BTB4: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A34.X3:3/4	O-507.C4	E	1
F4FB02	LSB-BTB4: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A34.X3:3/4	O-507.C4	E	1
F4FB04	LSB-BTB4: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A34.X3:3/4	O-507.C4	E	1
F4FB05	LSB-BTB4: Control data transfer CAN-B Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A34.X3:3/4	O-507.C4	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4FB06	LSB-BTB4: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A34.X3:3/4	O-507.C4	E	2
F4FB11	LSB-BTB4: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A34.X3:3/4	O-507.C4	E	1
F4FC00	LSB-BTB4: Control data transfer CAN-C internal error at Register-check Controller CAN-transfer is not started replace control device	A34.X4:1/2	O-507.D2	E	1
F4FC01	LSB-BTB4: Control data transfer CAN-C internal error at RAM-check Controller CAN-transfer is not started replace control device	A34.X4:1/2	O-507.D2	E	1
F4FC02	LSB-BTB4: Control data transfer CAN-C Configuration error Software Error message, CAN report is not configured Check software	A34.X4:1/2	O-507.D2	E	1
F4FC04	LSB-BTB4: Control data transfer CAN-C Configuration error time synchronization Time synchronization already active or is not configured Check software	A34.X4:1/2	O-507.D2	E	1
F4FC05	LSB-BTB4: Control data transfer CAN-C Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A34.X4:1/2	O-507.D2	E	1
F4FC06	LSB-BTB4: Control data transfer CAN-C fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A34.X4:1/2	O-507.D2	E	2
F4FC11	LSB-BTB4: Control data transfer CAN-C permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A34.X4:1/2	O-507.D2	E	1
F4FD00	LSB-BTB4: Control data transfer CAN-D internal error at Register-check Controller CAN-transfer is not started replace control device	A34.X4:14/13	O-507.D4	E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F4FD01	LSB-BTB4: Control data transfer CAN-D internal error at RAM-check Controller CAN-transfer is not started replace control device	A34.X4:14/13	O-507.D4	E	1
F4FD02	LSB-BTB4: Control data transfer CAN-D Configuration error Software Error message, CAN report is not configured Check software	A34.X4:14/13	O-507.D4	E	1
F4FD04	LSB-BTB4: Control data transfer CAN-D Configuration error time synchronization Time synchronization already active or is not configured Check software	A34.X4:14/13	O-507.D4	E	1
F4FD05	LSB-BTB4: Control data transfer CAN-D Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A34.X4:14/13	O-507.D4	E	1
F4FD06	LSB-BTB4: Control data transfer CAN-D fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A34.X4:14/13	O-507.D4	E	2
F4FD11	LSB-BTB4: Control data transfer CAN-D permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A34.X4:14/13	O-507.D4	E	1
FE0000	Unknown Device: System error or unknown path Configuration file missing or faulty			E	2
FE0171	Unknown Device: System error or unknown path Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module			E	2
FE017A	Unknown Device: System error or unknown path Configuration file missing or faulty error indication on display Inform Service of all error parameters and replace module			E	2