
LICCON Error Code Manual

LR-1500

074432

13.09.2016

**LIEBHERR-WERK EHINGEN GMBH, Postfach 1361, D-89582 Ebingen/Donau
Tel 0049 7391 502-0, Fax 0049 7391 502-3399
www.liebherr.com, E-Mail: info.lwe@liebherr.com**

LICCON ERROR CODE (LEC)

Reference	Identification number	Illustration number
Electrics Superstructure	2	8192000
Electrics Carrier	/tmp/zfile	25.08.2016
Error list	-3093583	9252-700.01.00.000.004

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0050	LSB-BSE1: LSBA Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0051	LSB-BSE1: LSBA Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0053	LSB-BSE1: LSBA Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0054	LSB-BSE1: LSBA Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0064	LSB-BSE1: LSBA Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0065	LSB-BSE1: LSBA Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0066	LSB-BSE1: LSBA Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0067	LSB-BSE1: LSBA Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0068	LSB-BSE1: LSBA Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A0069	LSB-BSE1: LSBA Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A006A	LSB-BSE1: LSBA Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A006B	LSB-BSE1: LSBA Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A006C	LSB-BSE1: LSBA Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A0150	LSB-BSE1: LSBA Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0151	LSB-BSE1: LSBA Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0153	LSB-BSE1: LSBA Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0154	LSB-BSE1: LSBA Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0164	LSB-BSE1: LSBA Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0165	LSB-BSE1: LSBA Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0166	LSB-BSE1: LSBA Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0167	LSB-BSE1: LSBA Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0168	LSB-BSE1: LSBA Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A0169	LSB-BSE1: LSBA Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A016A	LSB-BSE1: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A016B	LSB-BSE1: LSBA Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A016C	LSB-BSE1: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A0250	LSB-BSE1: LSBA Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0251	LSB-BSE1: LSBA Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0253	LSB-BSE1: LSBA Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0254	LSB-BSE1: LSBA Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0264	LSB-BSE1: LSBA Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0265	LSB-BSE1: LSBA Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0266	LSB-BSE1: LSBA Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0267	LSB-BSE1: LSBA Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0268	LSB-BSE1: LSBA Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A0269	LSB-BSE1: LSBA Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A026A	LSB-BSE1: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A026B	LSB-BSE1: LSBA Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A026C	LSB-BSE1: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A0350	LSB-BSE1: LSBA Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0351	LSB-BSE1: LSBA Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0353	LSB-BSE1: LSBA Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0354	LSB-BSE1: LSBA Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0364	LSB-BSE1: LSBA Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0365	LSB-BSE1: LSBA Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0366	LSB-BSE1: LSBA Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0367	LSB-BSE1: LSBA Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0368	LSB-BSE1: LSBA Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A0369	LSB-BSE1: LSBA Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A036A	LSB-BSE1: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A036B	LSB-BSE1: LSBA Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A036C	LSB-BSE1: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A0750	LSB-BSE1: LSBA Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0751	LSB-BSE1: LSBA Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0753	LSB-BSE1: LSBA Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0754	LSB-BSE1: LSBA Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0764	LSB-BSE1: LSBA Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0765	LSB-BSE1: LSBA Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0766	LSB-BSE1: LSBA Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0767	LSB-BSE1: LSBA Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0768	LSB-BSE1: LSBA Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A0769	LSB-BSE1: LSBA Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A076A	LSB-BSE1: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A076B	LSB-BSE1: LSBA Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A076C	LSB-BSE1: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A0850	LSB-BSE1: LSBA Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0851	LSB-BSE1: LSBA Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0853	LSB-BSE1: LSBA Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0854	LSB-BSE1: LSBA Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0864	LSB-BSE1: LSBA Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0865	LSB-BSE1: LSBA Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0866	LSB-BSE1: LSBA Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0867	LSB-BSE1: LSBA Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0868	LSB-BSE1: LSBA Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A0869	LSB-BSE1: LSBA Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A086A	LSB-BSE1: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A086B	LSB-BSE1: LSBA Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A086C	LSB-BSE1: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A0950	LSB-BSE1: LSBA Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0951	LSB-BSE1: LSBA Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0953	LSB-BSE1: LSBA Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0954	LSB-BSE1: LSBA Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0964	LSB-BSE1: LSBA Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0965	LSB-BSE1: LSBA Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0966	LSB-BSE1: LSBA Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0967	LSB-BSE1: LSBA Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0968	LSB-BSE1: LSBA Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A0969	LSB-BSE1: LSBA Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A096A	LSB-BSE1: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A096B	LSB-BSE1: LSBA Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A096C	LSB-BSE1: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A0B50	LSB-BSE1: LSBA Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0B51	LSB-BSE1: LSBA Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0B53	LSB-BSE1: LSBA Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0B54	LSB-BSE1: LSBA Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0B64	LSB-BSE1: LSBA Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0B65	LSB-BSE1: LSBA Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A0B66	LSB-BSE1: LSBA Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0B67	LSB-BSE1: LSBA Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0B68	LSB-BSE1: LSBA Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0B69	LSB-BSE1: LSBA Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0B6A	LSB-BSE1: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A0B6B	LSB-BSE1: LSBA Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A0B6C	LSB-BSE1: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A0F50	LSB-BSE1: LSBA Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A0F51	LSB-BSE1: LSBA Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A0F53	LSB-BSE1: LSBA Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A0F54	LSB-BSE1: LSBA Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A0F64	LSB-BSE1: LSBA Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A0F65	LSB-BSE1: LSBA Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A0F66	LSB-BSE1: LSBA Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A0F67	LSB-BSE1: LSBA Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A0F68	LSB-BSE1: LSBA Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A0F69	LSB-BSE1: LSBA Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A0F6A	LSB-BSE1: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A0F6B	LSB-BSE1: LSBA Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A0F6C	LSB-BSE1: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A1350	LSB-BSE1: LSBA Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1351	LSB-BSE1: LSBA Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1353	LSB-BSE1: LSBA Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1354	LSB-BSE1: LSBA Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1364	LSB-BSE1: LSBA Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1365	LSB-BSE1: LSBA Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1366	LSB-BSE1: LSBA Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1367	LSB-BSE1: LSBA Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1368	LSB-BSE1: LSBA Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A1369	LSB-BSE1: LSBA Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A136A	LSB-BSE1: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A136B	LSB-BSE1: LSBA Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A136C	LSB-BSE1: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1450	LSB-BSE1: LSBA Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1451	LSB-BSE1: LSBA Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1453	LSB-BSE1: LSBA Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1454	LSB-BSE1: LSBA Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1464	LSB-BSE1: LSBA Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1465	LSB-BSE1: LSBA Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1466	LSB-BSE1: LSBA Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1467	LSB-BSE1: LSBA Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1468	LSB-BSE1: LSBA Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A1469	LSB-BSE1: LSBA Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A146A	LSB-BSE1: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A146B	LSB-BSE1: LSBA Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A146C	LSB-BSE1: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A1750	LSB-BSE1: LSBA Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1751	LSB-BSE1: LSBA Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1753	LSB-BSE1: LSBA Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1754	LSB-BSE1: LSBA Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1764	LSB-BSE1: LSBA Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1765	LSB-BSE1: LSBA Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1766	LSB-BSE1: LSBA Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1767	LSB-BSE1: LSBA Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1768	LSB-BSE1: LSBA Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A1769	LSB-BSE1: LSBA Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A176A	LSB-BSE1: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A176B	LSB-BSE1: LSBA Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A176C	LSB-BSE1: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A1850	LSB-BSE1: LSBA Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1851	LSB-BSE1: LSBA Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1853	LSB-BSE1: LSBA Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1854	LSB-BSE1: LSBA Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1864	LSB-BSE1: LSBA Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1865	LSB-BSE1: LSBA Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1866	LSB-BSE1: LSBA Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1867	LSB-BSE1: LSBA Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1868	LSB-BSE1: LSBA Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A1869	LSB-BSE1: LSBA Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A186A	LSB-BSE1: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A186B	LSB-BSE1: LSBA Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A186C	LSB-BSE1: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A1950	LSB-BSE1: LSBA Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1951	LSB-BSE1: LSBA Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1953	LSB-BSE1: LSBA Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1954	LSB-BSE1: LSBA Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1964	LSB-BSE1: LSBA Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1965	LSB-BSE1: LSBA Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1966	LSB-BSE1: LSBA Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1967	LSB-BSE1: LSBA Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1968	LSB-BSE1: LSBA Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A1969	LSB-BSE1: LSBA Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A196A	LSB-BSE1: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A196B	LSB-BSE1: LSBA Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A196C	LSB-BSE1: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A1A50	LSB-BSE1: LSBA Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1A51	LSB-BSE1: LSBA Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1A53	LSB-BSE1: LSBA Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1A54	LSB-BSE1: LSBA Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1A64	LSB-BSE1: LSBA Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1
1A1A65	LSB-BSE1: LSBA Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1A66	LSB-BSE1: LSBA Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1A67	LSB-BSE1: LSBA Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1A68	LSB-BSE1: LSBA Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A1A69	LSB-BSE1: LSBA Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1A6A	LSB-BSE1: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A1A6B	LSB-BSE1: LSBA Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A1A6C	LSB-BSE1: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A1C50	LSB-BSE1: LSBA Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:9		E	2
1A1C51	LSB-BSE1: LSBA Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:9		E	2
1A1C53	LSB-BSE1: LSBA Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:9		E	1
1A1C54	LSB-BSE1: LSBA Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:9		E	2
1A1C64	LSB-BSE1: LSBA Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A1C65	LSB-BSE1: LSBA Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:9		E	2
1A1C66	LSB-BSE1: LSBA Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:9		E	2
1A1C67	LSB-BSE1: LSBA Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:9		E	1
1A1C68	LSB-BSE1: LSBA Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:9		E	1
1A1C69	LSB-BSE1: LSBA Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:9		E	1
1A1C6A	LSB-BSE1: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:9		E	2
1A1C6B	LSB-BSE1: LSBA Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:9		E	2
1A1C6C	LSB-BSE1: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:9		E	2
1A2052	LSB-BSE1: Control data transfer LSBA has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X4:9		E	0
1A2055	LSB-BSE1: Control data transfer LSBA Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A2056	LSB-BSE1: Control data transfer LSBA Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:9		E	2
1A2057	LSB-BSE1: Control data transfer LSBA has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X4:9		E	1
1A2058	LSB-BSE1: Control data transfer LSBA recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X4:9		E	0
1A2059	LSB-BSE1: Control data transfer LSBA recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X4:9		E	0
1A2060	LSB-BSE1: Control data transfer LSBA driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361.X4:9		E	2
1A2061	LSB-BSE1: Control data transfer LSBA driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361.X4:9		E	2
1A2062	LSB-BSE1: Control data transfer LSBA Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X4:9		E	2
1A3050	LSB-BSE1: LSBB Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3051	LSB-BSE1: LSBB Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3053	LSB-BSE1: LSBB Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3054	LSB-BSE1: LSBB Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3064	LSB-BSE1: LSBB Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3065	LSB-BSE1: LSBB Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3066	LSB-BSE1: LSBB Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3067	LSB-BSE1: LSBB Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3068	LSB-BSE1: LSBB Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3069	LSB-BSE1: LSBB Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A306A	LSB-BSE1: LSBB Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A306B	LSB-BSE1: LSBB Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A306C	LSB-BSE1: LSBB Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3150	LSB-BSE1: LSBB Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3151	LSB-BSE1: LSBB Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3153	LSB-BSE1: LSBB Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3154	LSB-BSE1: LSBB Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3164	LSB-BSE1: LSBB Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3165	LSB-BSE1: LSBB Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3166	LSB-BSE1: LSBB Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3167	LSB-BSE1: LSBB Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3168	LSB-BSE1: LSBB Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3169	LSB-BSE1: LSBB Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A316A	LSB-BSE1: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A316B	LSB-BSE1: LSBB Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A316C	LSB-BSE1: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3350	LSB-BSE1: LSBB Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3351	LSB-BSE1: LSBB Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3353	LSB-BSE1: LSBB Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3354	LSB-BSE1: LSBB Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3364	LSB-BSE1: LSBB Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3365	LSB-BSE1: LSBB Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3366	LSB-BSE1: LSBB Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3367	LSB-BSE1: LSBB Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3368	LSB-BSE1: LSBB Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3369	LSB-BSE1: LSBB Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A336A	LSB-BSE1: LSBB Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A336B	LSB-BSE1: LSBB Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A336C	LSB-BSE1: LSBB Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3450	LSB-BSE1: LSBB Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3451	LSB-BSE1: LSBB Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3453	LSB-BSE1: LSBB Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3454	LSB-BSE1: LSBB Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3464	LSB-BSE1: LSBB Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3465	LSB-BSE1: LSBB Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3466	LSB-BSE1: LSBB Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3467	LSB-BSE1: LSBB Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3468	LSB-BSE1: LSBB Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3469	LSB-BSE1: LSBB Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A346A	LSB-BSE1: LSBB Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A346B	LSB-BSE1: LSBB Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A346C	LSB-BSE1: LSBB Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3550	LSB-BSE1: LSBB Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3551	LSB-BSE1: LSBB Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3553	LSB-BSE1: LSBB Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3554	LSB-BSE1: LSBB Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3564	LSB-BSE1: LSBB Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3565	LSB-BSE1: LSBB Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3566	LSB-BSE1: LSBB Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3567	LSB-BSE1: LSBB Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3568	LSB-BSE1: LSBB Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3569	LSB-BSE1: LSBB Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A356A	LSB-BSE1: LSBB Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A356B	LSB-BSE1: LSBB Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A356C	LSB-BSE1: LSBB Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3650	LSB-BSE1: LSBB Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3651	LSB-BSE1: LSBB Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3653	LSB-BSE1: LSBB Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3654	LSB-BSE1: LSBB Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3664	LSB-BSE1: LSBB Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3665	LSB-BSE1: LSBB Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3666	LSB-BSE1: LSBB Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3667	LSB-BSE1: LSBB Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3668	LSB-BSE1: LSBB Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3669	LSB-BSE1: LSBB Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A366A	LSB-BSE1: LSBB Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A366B	LSB-BSE1: LSBB Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A366C	LSB-BSE1: LSBB Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3750	LSB-BSE1: LSBB Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3751	LSB-BSE1: LSBB Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3753	LSB-BSE1: LSBB Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3754	LSB-BSE1: LSBB Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3764	LSB-BSE1: LSBB Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3765	LSB-BSE1: LSBB Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3766	LSB-BSE1: LSBB Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3767	LSB-BSE1: LSBB Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3768	LSB-BSE1: LSBB Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3769	LSB-BSE1: LSBB Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A376A	LSB-BSE1: LSBB Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A376B	LSB-BSE1: LSBB Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A376C	LSB-BSE1: LSBB Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3850	LSB-BSE1: LSBB Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3851	LSB-BSE1: LSBB Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3853	LSB-BSE1: LSBB Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3854	LSB-BSE1: LSBB Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3864	LSB-BSE1: LSBB Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3865	LSB-BSE1: LSBB Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3866	LSB-BSE1: LSBB Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3867	LSB-BSE1: LSBB Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3868	LSB-BSE1: LSBB Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3869	LSB-BSE1: LSBB Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A386A	LSB-BSE1: LSBB Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A386B	LSB-BSE1: LSBB Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A386C	LSB-BSE1: LSBB Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3950	LSB-BSE1: LSBB Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3951	LSB-BSE1: LSBB Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3953	LSB-BSE1: LSBB Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3954	LSB-BSE1: LSBB Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3964	LSB-BSE1: LSBB Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3965	LSB-BSE1: LSBB Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3966	LSB-BSE1: LSBB Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3967	LSB-BSE1: LSBB Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3968	LSB-BSE1: LSBB Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3969	LSB-BSE1: LSBB Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A396A	LSB-BSE1: LSBB Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A396B	LSB-BSE1: LSBB Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A396C	LSB-BSE1: LSBB Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3A50	LSB-BSE1: LSBB Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3A51	LSB-BSE1: LSBB Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3A53	LSB-BSE1: LSBB Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3A54	LSB-BSE1: LSBB Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3A64	LSB-BSE1: LSBB Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3A65	LSB-BSE1: LSBB Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3A66	LSB-BSE1: LSBB Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3A67	LSB-BSE1: LSBB Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3A68	LSB-BSE1: LSBB Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3A69	LSB-BSE1: LSBB Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A3A6A	LSB-BSE1: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A3A6B	LSB-BSE1: LSBB Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A3A6C	LSB-BSE1: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3B50	LSB-BSE1: LSBB Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3B51	LSB-BSE1: LSBB Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3B53	LSB-BSE1: LSBB Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3B54	LSB-BSE1: LSBB Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3B64	LSB-BSE1: LSBB Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3B65	LSB-BSE1: LSBB Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3B66	LSB-BSE1: LSBB Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3B67	LSB-BSE1: LSBB Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3B68	LSB-BSE1: LSBB Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3B69	LSB-BSE1: LSBB Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A3B6A	LSB-BSE1: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A3B6B	LSB-BSE1: LSBB Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A3B6C	LSB-BSE1: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3C50	LSB-BSE1: LSBB Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3C51	LSB-BSE1: LSBB Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3C53	LSB-BSE1: LSBB Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3C54	LSB-BSE1: LSBB Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3C64	LSB-BSE1: LSBB Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3C65	LSB-BSE1: LSBB Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3C66	LSB-BSE1: LSBB Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3C67	LSB-BSE1: LSBB Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3C68	LSB-BSE1: LSBB Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3C69	LSB-BSE1: LSBB Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3C6A	LSB-BSE1: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A3C6B	LSB-BSE1: LSBB Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A3C6C	LSB-BSE1: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3D50	LSB-BSE1: LSBB Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3D51	LSB-BSE1: LSBB Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3D53	LSB-BSE1: LSBB Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3D54	LSB-BSE1: LSBB Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A3D64	LSB-BSE1: LSBB Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3D65	LSB-BSE1: LSBB Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3D66	LSB-BSE1: LSBB Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3D67	LSB-BSE1: LSBB Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3D68	LSB-BSE1: LSBB Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3D69	LSB-BSE1: LSBB Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A3D6A	LSB-BSE1: LSBB Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A3D6B	LSB-BSE1: LSBB Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A3D6C	LSB-BSE1: LSBB Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A3E50	LSB-BSE1: LSBB Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A3E51	LSB-BSE1: LSBB Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A3E53	LSB-BSE1: LSBB Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A3E54	LSB-BSE1: LSBB Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A3E64	LSB-BSE1: LSBB Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A3E65	LSB-BSE1: LSBB Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A3E66	LSB-BSE1: LSBB Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A3E67	LSB-BSE1: LSBB Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A3E68	LSB-BSE1: LSBB Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A3E69	LSB-BSE1: LSBB Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A3E6A	LSB-BSE1: LSBB Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A3E6B	LSB-BSE1: LSBB Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A3E6C	LSB-BSE1: LSBB Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4050	LSB-BSE1: LSBB Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4051	LSB-BSE1: LSBB Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4053	LSB-BSE1: LSBB Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4054	LSB-BSE1: LSBB Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4064	LSB-BSE1: LSBB Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4065	LSB-BSE1: LSBB Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4066	LSB-BSE1: LSBB Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4067	LSB-BSE1: LSBB Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4068	LSB-BSE1: LSBB Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4069	LSB-BSE1: LSBB Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A406A	LSB-BSE1: LSBB Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A406B	LSB-BSE1: LSBB Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A406C	LSB-BSE1: LSBB Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4350	LSB-BSE1: LSBB Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4351	LSB-BSE1: LSBB Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4353	LSB-BSE1: LSBB Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4354	LSB-BSE1: LSBB Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4364	LSB-BSE1: LSBB Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4365	LSB-BSE1: LSBB Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4366	LSB-BSE1: LSBB Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4367	LSB-BSE1: LSBB Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4368	LSB-BSE1: LSBB Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4369	LSB-BSE1: LSBB Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A436A	LSB-BSE1: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A436B	LSB-BSE1: LSBB Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A436C	LSB-BSE1: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4450	LSB-BSE1: LSBB Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4451	LSB-BSE1: LSBB Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4453	LSB-BSE1: LSBB Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4454	LSB-BSE1: LSBB Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4464	LSB-BSE1: LSBB Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4465	LSB-BSE1: LSBB Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4466	LSB-BSE1: LSBB Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4467	LSB-BSE1: LSBB Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4468	LSB-BSE1: LSBB Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4469	LSB-BSE1: LSBB Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A446A	LSB-BSE1: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A446B	LSB-BSE1: LSBB Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A446C	LSB-BSE1: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4550	LSB-BSE1: LSBB Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4551	LSB-BSE1: LSBB Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4553	LSB-BSE1: LSBB Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4554	LSB-BSE1: LSBB Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4564	LSB-BSE1: LSBB Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4565	LSB-BSE1: LSBB Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4566	LSB-BSE1: LSBB Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4567	LSB-BSE1: LSBB Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4568	LSB-BSE1: LSBB Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4569	LSB-BSE1: LSBB Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A456A	LSB-BSE1: LSBB Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A456B	LSB-BSE1: LSBB Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A456C	LSB-BSE1: LSBB Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4650	LSB-BSE1: LSBB Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4651	LSB-BSE1: LSBB Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4653	LSB-BSE1: LSBB Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4654	LSB-BSE1: LSBB Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4664	LSB-BSE1: LSBB Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4665	LSB-BSE1: LSBB Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4666	LSB-BSE1: LSBB Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4667	LSB-BSE1: LSBB Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4668	LSB-BSE1: LSBB Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4669	LSB-BSE1: LSBB Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A466A	LSB-BSE1: LSBB Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A466B	LSB-BSE1: LSBB Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A466C	LSB-BSE1: LSBB Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4750	LSB-BSE1: LSBB Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4751	LSB-BSE1: LSBB Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4753	LSB-BSE1: LSBB Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4754	LSB-BSE1: LSBB Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4764	LSB-BSE1: LSBB Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4765	LSB-BSE1: LSBB Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4766	LSB-BSE1: LSBB Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4767	LSB-BSE1: LSBB Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4768	LSB-BSE1: LSBB Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4769	LSB-BSE1: LSBB Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A476A	LSB-BSE1: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A476B	LSB-BSE1: LSBB Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A476C	LSB-BSE1: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4850	LSB-BSE1: LSBB Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4851	LSB-BSE1: LSBB Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4853	LSB-BSE1: LSBB Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4854	LSB-BSE1: LSBB Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4864	LSB-BSE1: LSBB Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4865	LSB-BSE1: LSBB Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4866	LSB-BSE1: LSBB Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4867	LSB-BSE1: LSBB Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4868	LSB-BSE1: LSBB Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4869	LSB-BSE1: LSBB Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A486A	LSB-BSE1: LSBB Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A486B	LSB-BSE1: LSBB Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A486C	LSB-BSE1: LSBB Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4950	LSB-BSE1: LSBB Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4951	LSB-BSE1: LSBB Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4953	LSB-BSE1: LSBB Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4954	LSB-BSE1: LSBB Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4964	LSB-BSE1: LSBB Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4965	LSB-BSE1: LSBB Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4966	LSB-BSE1: LSBB Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4967	LSB-BSE1: LSBB Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4968	LSB-BSE1: LSBB Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4969	LSB-BSE1: LSBB Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A496A	LSB-BSE1: LSBB Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A496B	LSB-BSE1: LSBB Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A496C	LSB-BSE1: LSBB Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4A50	LSB-BSE1: LSBB Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4A51	LSB-BSE1: LSBB Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4A53	LSB-BSE1: LSBB Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4A54	LSB-BSE1: LSBB Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4A64	LSB-BSE1: LSBB Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4A65	LSB-BSE1: LSBB Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4A66	LSB-BSE1: LSBB Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4A67	LSB-BSE1: LSBB Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4A68	LSB-BSE1: LSBB Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4A69	LSB-BSE1: LSBB Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A4A6A	LSB-BSE1: LSBB Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A4A6B	LSB-BSE1: LSBB Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A4A6C	LSB-BSE1: LSBB Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4B50	LSB-BSE1: LSBB Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4B51	LSB-BSE1: LSBB Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4B53	LSB-BSE1: LSBB Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4B54	LSB-BSE1: LSBB Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4B64	LSB-BSE1: LSBB Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4B65	LSB-BSE1: LSBB Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4B66	LSB-BSE1: LSBB Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4B67	LSB-BSE1: LSBB Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4B68	LSB-BSE1: LSBB Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4B69	LSB-BSE1: LSBB Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A4B6A	LSB-BSE1: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A4B6B	LSB-BSE1: LSBB Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A4B6C	LSB-BSE1: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4C50	LSB-BSE1: LSBB Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4C51	LSB-BSE1: LSBB Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4C53	LSB-BSE1: LSBB Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4C54	LSB-BSE1: LSBB Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4C64	LSB-BSE1: LSBB Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4C65	LSB-BSE1: LSBB Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4C66	LSB-BSE1: LSBB Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4C67	LSB-BSE1: LSBB Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4C68	LSB-BSE1: LSBB Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4C69	LSB-BSE1: LSBB Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A4C6A	LSB-BSE1: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4C6B	LSB-BSE1: LSBB Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A4C6C	LSB-BSE1: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4D50	LSB-BSE1: LSBB Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4D51	LSB-BSE1: LSBB Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4D53	LSB-BSE1: LSBB Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4D54	LSB-BSE1: LSBB Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4D64	LSB-BSE1: LSBB Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1
1A4D65	LSB-BSE1: LSBB Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4D66	LSB-BSE1: LSBB Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4D67	LSB-BSE1: LSBB Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4D68	LSB-BSE1: LSBB Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4D69	LSB-BSE1: LSBB Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A4D6A	LSB-BSE1: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A4D6B	LSB-BSE1: LSBB Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A4D6C	LSB-BSE1: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A4E50	LSB-BSE1: LSBB Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:10		E	2
1A4E51	LSB-BSE1: LSBB Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:10		E	2
1A4E53	LSB-BSE1: LSBB Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:10		E	1
1A4E54	LSB-BSE1: LSBB Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:10		E	2
1A4E64	LSB-BSE1: LSBB Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A4E65	LSB-BSE1: LSBB Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:10		E	2
1A4E66	LSB-BSE1: LSBB Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:10		E	2
1A4E67	LSB-BSE1: LSBB Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:10		E	1
1A4E68	LSB-BSE1: LSBB Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:10		E	1
1A4E69	LSB-BSE1: LSBB Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:10		E	1
1A4E6A	LSB-BSE1: LSBB Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:10		E	2
1A4E6B	LSB-BSE1: LSBB Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:10		E	2
1A4E6C	LSB-BSE1: LSBB Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:10		E	2
1A5052	LSB-BSE1: Control data transfer LSBB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X4:10		E	0
1A5055	LSB-BSE1: Control data transfer LSBB Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A5056	LSB-BSE1: Control data transfer LSBB Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:10		E	2
1A5057	LSB-BSE1: Control data transfer LSBB has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X4:10		E	1
1A5058	LSB-BSE1: Control data transfer LSBB recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X4:10		E	0
1A5059	LSB-BSE1: Control data transfer LSBB recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X4:10		E	0
1A5060	LSB-BSE1: Control data transfer LSBB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361.X4:10		E	2
1A5061	LSB-BSE1: Control data transfer LSBB driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361.X4:10		E	2
1A5062	LSB-BSE1: Control data transfer LSBB Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X4:10		E	2
1A6050	LSB-BSE1: LSBC Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6051	LSB-BSE1: LSBC Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6053	LSB-BSE1: LSBC Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6054	LSB-BSE1: LSBC Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6064	LSB-BSE1: LSBC Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6065	LSB-BSE1: LSBC Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6066	LSB-BSE1: LSBC Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6067	LSB-BSE1: LSBC Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6068	LSB-BSE1: LSBC Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6069	LSB-BSE1: LSBC Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A606A	LSB-BSE1: LSBC Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A606B	LSB-BSE1: LSBC Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A606C	LSB-BSE1: LSBC Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6150	LSB-BSE1: LSBC Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6151	LSB-BSE1: LSBC Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6153	LSB-BSE1: LSBC Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6154	LSB-BSE1: LSBC Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6164	LSB-BSE1: LSBC Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6165	LSB-BSE1: LSBC Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6166	LSB-BSE1: LSBC Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6167	LSB-BSE1: LSBC Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6168	LSB-BSE1: LSBC Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6169	LSB-BSE1: LSBC Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A616A	LSB-BSE1: LSBC Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A616B	LSB-BSE1: LSBC Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A616C	LSB-BSE1: LSBC Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6250	LSB-BSE1: LSBC Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6251	LSB-BSE1: LSBC Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6253	LSB-BSE1: LSBC Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6254	LSB-BSE1: LSBC Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6264	LSB-BSE1: LSBC Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6265	LSB-BSE1: LSBC Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6266	LSB-BSE1: LSBC Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6267	LSB-BSE1: LSBC Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6268	LSB-BSE1: LSBC Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6269	LSB-BSE1: LSBC Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A626A	LSB-BSE1: LSBC Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A626B	LSB-BSE1: LSBC Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A626C	LSB-BSE1: LSBC Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6450	LSB-BSE1: LSBC Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6451	LSB-BSE1: LSBC Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6453	LSB-BSE1: LSBC Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6454	LSB-BSE1: LSBC Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6464	LSB-BSE1: LSBC Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6465	LSB-BSE1: LSBC Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6466	LSB-BSE1: LSBC Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6467	LSB-BSE1: LSBC Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6468	LSB-BSE1: LSBC Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6469	LSB-BSE1: LSBC Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A646A	LSB-BSE1: LSBC Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A646B	LSB-BSE1: LSBC Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A646C	LSB-BSE1: LSBC Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6550	LSB-BSE1: LSBC Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6551	LSB-BSE1: LSBC Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6553	LSB-BSE1: LSBC Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6554	LSB-BSE1: LSBC Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6564	LSB-BSE1: LSBC Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6565	LSB-BSE1: LSBC Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6566	LSB-BSE1: LSBC Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6567	LSB-BSE1: LSBC Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6568	LSB-BSE1: LSBC Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6569	LSB-BSE1: LSBC Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A656A	LSB-BSE1: LSBC Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A656B	LSB-BSE1: LSBC Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A656C	LSB-BSE1: LSBC Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6650	LSB-BSE1: LSBC Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6651	LSB-BSE1: LSBC Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6653	LSB-BSE1: LSBC Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6654	LSB-BSE1: LSBC Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6664	LSB-BSE1: LSBC Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6665	LSB-BSE1: LSBC Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6666	LSB-BSE1: LSBC Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6667	LSB-BSE1: LSBC Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6668	LSB-BSE1: LSBC Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6669	LSB-BSE1: LSBC Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A666A	LSB-BSE1: LSBC Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A666B	LSB-BSE1: LSBC Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A666C	LSB-BSE1: LSBC Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6750	LSB-BSE1: LSBC Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6751	LSB-BSE1: LSBC Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6753	LSB-BSE1: LSBC Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6754	LSB-BSE1: LSBC Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6764	LSB-BSE1: LSBC Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6765	LSB-BSE1: LSBC Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6766	LSB-BSE1: LSBC Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6767	LSB-BSE1: LSBC Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6768	LSB-BSE1: LSBC Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6769	LSB-BSE1: LSBC Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A676A	LSB-BSE1: LSBC Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A676B	LSB-BSE1: LSBC Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A676C	LSB-BSE1: LSBC Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6850	LSB-BSE1: LSBC Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6851	LSB-BSE1: LSBC Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6853	LSB-BSE1: LSBC Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6854	LSB-BSE1: LSBC Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6864	LSB-BSE1: LSBC Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6865	LSB-BSE1: LSBC Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6866	LSB-BSE1: LSBC Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6867	LSB-BSE1: LSBC Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6868	LSB-BSE1: LSBC Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6869	LSB-BSE1: LSBC Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A686A	LSB-BSE1: LSBC Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A686B	LSB-BSE1: LSBC Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A686C	LSB-BSE1: LSBC Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6950	LSB-BSE1: LSBC Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6951	LSB-BSE1: LSBC Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6953	LSB-BSE1: LSBC Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6954	LSB-BSE1: LSBC Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6964	LSB-BSE1: LSBC Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6965	LSB-BSE1: LSBC Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6966	LSB-BSE1: LSBC Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6967	LSB-BSE1: LSBC Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6968	LSB-BSE1: LSBC Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6969	LSB-BSE1: LSBC Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A696A	LSB-BSE1: LSBC Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A696B	LSB-BSE1: LSBC Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A696C	LSB-BSE1: LSBC Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6A50	LSB-BSE1: LSBC Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6A51	LSB-BSE1: LSBC Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6A53	LSB-BSE1: LSBC Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6A54	LSB-BSE1: LSBC Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6A64	LSB-BSE1: LSBC Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6A65	LSB-BSE1: LSBC Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6A66	LSB-BSE1: LSBC Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6A67	LSB-BSE1: LSBC Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6A68	LSB-BSE1: LSBC Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6A69	LSB-BSE1: LSBC Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A6A6A	LSB-BSE1: LSBC Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A6A6B	LSB-BSE1: LSBC Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A6A6C	LSB-BSE1: LSBC Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6B50	LSB-BSE1: LSBC Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6B51	LSB-BSE1: LSBC Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6B53	LSB-BSE1: LSBC Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6B54	LSB-BSE1: LSBC Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6B64	LSB-BSE1: LSBC Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6B65	LSB-BSE1: LSBC Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6B66	LSB-BSE1: LSBC Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6B67	LSB-BSE1: LSBC Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6B68	LSB-BSE1: LSBC Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6B69	LSB-BSE1: LSBC Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A6B6A	LSB-BSE1: LSBC Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A6B6B	LSB-BSE1: LSBC Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A6B6C	LSB-BSE1: LSBC Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6C50	LSB-BSE1: LSBC Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6C51	LSB-BSE1: LSBC Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6C53	LSB-BSE1: LSBC Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6C54	LSB-BSE1: LSBC Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6C64	LSB-BSE1: LSBC Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6C65	LSB-BSE1: LSBC Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6C66	LSB-BSE1: LSBC Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6C67	LSB-BSE1: LSBC Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6C68	LSB-BSE1: LSBC Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6C69	LSB-BSE1: LSBC Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6C6A	LSB-BSE1: LSBC Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A6C6B	LSB-BSE1: LSBC Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A6C6C	LSB-BSE1: LSBC Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6D50	LSB-BSE1: LSBC Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6D51	LSB-BSE1: LSBC Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6D53	LSB-BSE1: LSBC Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6D54	LSB-BSE1: LSBC Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6D64	LSB-BSE1: LSBC Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6D65	LSB-BSE1: LSBC Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6D66	LSB-BSE1: LSBC Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6D67	LSB-BSE1: LSBC Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6D68	LSB-BSE1: LSBC Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6D69	LSB-BSE1: LSBC Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A6D6A	LSB-BSE1: LSBC Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A6D6B	LSB-BSE1: LSBC Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A6D6C	LSB-BSE1: LSBC Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6E50	LSB-BSE1: LSBC Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A6E51	LSB-BSE1: LSBC Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6E53	LSB-BSE1: LSBC Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6E54	LSB-BSE1: LSBC Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6E64	LSB-BSE1: LSBC Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6E65	LSB-BSE1: LSBC Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6E66	LSB-BSE1: LSBC Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6E67	LSB-BSE1: LSBC Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6E68	LSB-BSE1: LSBC Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6E69	LSB-BSE1: LSBC Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A6E6A	LSB-BSE1: LSBC Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A6E6B	LSB-BSE1: LSBC Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A6E6C	LSB-BSE1: LSBC Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A6F50	LSB-BSE1: LSBC Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6F51	LSB-BSE1: LSBC Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A6F53	LSB-BSE1: LSBC Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A6F54	LSB-BSE1: LSBC Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A6F64	LSB-BSE1: LSBC Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A6F65	LSB-BSE1: LSBC Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A6F66	LSB-BSE1: LSBC Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A6F67	LSB-BSE1: LSBC Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A6F68	LSB-BSE1: LSBC Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A6F69	LSB-BSE1: LSBC Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A6F6A	LSB-BSE1: LSBC Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A6F6B	LSB-BSE1: LSBC Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A6F6C	LSB-BSE1: LSBC Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7050	LSB-BSE1: LSBC Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7051	LSB-BSE1: LSBC Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7053	LSB-BSE1: LSBC Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7054	LSB-BSE1: LSBC Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7064	LSB-BSE1: LSBC Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7065	LSB-BSE1: LSBC Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7066	LSB-BSE1: LSBC Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7067	LSB-BSE1: LSBC Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7068	LSB-BSE1: LSBC Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7069	LSB-BSE1: LSBC Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A706A	LSB-BSE1: LSBC Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A706B	LSB-BSE1: LSBC Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A706C	LSB-BSE1: LSBC Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7150	LSB-BSE1: LSBC Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7151	LSB-BSE1: LSBC Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7153	LSB-BSE1: LSBC Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7154	LSB-BSE1: LSBC Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7164	LSB-BSE1: LSBC Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7165	LSB-BSE1: LSBC Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7166	LSB-BSE1: LSBC Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7167	LSB-BSE1: LSBC Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7168	LSB-BSE1: LSBC Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7169	LSB-BSE1: LSBC Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A716A	LSB-BSE1: LSBC Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A716B	LSB-BSE1: LSBC Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A716C	LSB-BSE1: LSBC Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7250	LSB-BSE1: LSBC Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7251	LSB-BSE1: LSBC Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7253	LSB-BSE1: LSBC Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7254	LSB-BSE1: LSBC Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7264	LSB-BSE1: LSBC Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7265	LSB-BSE1: LSBC Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7266	LSB-BSE1: LSBC Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7267	LSB-BSE1: LSBC Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7268	LSB-BSE1: LSBC Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7269	LSB-BSE1: LSBC Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A726A	LSB-BSE1: LSBC Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A726B	LSB-BSE1: LSBC Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A726C	LSB-BSE1: LSBC Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7350	LSB-BSE1: LSBC Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7351	LSB-BSE1: LSBC Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7353	LSB-BSE1: LSBC Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7354	LSB-BSE1: LSBC Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7364	LSB-BSE1: LSBC Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7365	LSB-BSE1: LSBC Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7366	LSB-BSE1: LSBC Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7367	LSB-BSE1: LSBC Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7368	LSB-BSE1: LSBC Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7369	LSB-BSE1: LSBC Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A736A	LSB-BSE1: LSBC Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A736B	LSB-BSE1: LSBC Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A736C	LSB-BSE1: LSBC Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7450	LSB-BSE1: LSBC Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7451	LSB-BSE1: LSBC Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7453	LSB-BSE1: LSBC Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7454	LSB-BSE1: LSBC Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7464	LSB-BSE1: LSBC Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7465	LSB-BSE1: LSBC Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7466	LSB-BSE1: LSBC Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7467	LSB-BSE1: LSBC Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7468	LSB-BSE1: LSBC Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7469	LSB-BSE1: LSBC Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A746A	LSB-BSE1: LSBC Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A746B	LSB-BSE1: LSBC Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A746C	LSB-BSE1: LSBC Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7550	LSB-BSE1: LSBC Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7551	LSB-BSE1: LSBC Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7553	LSB-BSE1: LSBC Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7554	LSB-BSE1: LSBC Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7564	LSB-BSE1: LSBC Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7565	LSB-BSE1: LSBC Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7566	LSB-BSE1: LSBC Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7567	LSB-BSE1: LSBC Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7568	LSB-BSE1: LSBC Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7569	LSB-BSE1: LSBC Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A756A	LSB-BSE1: LSBC Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A756B	LSB-BSE1: LSBC Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A756C	LSB-BSE1: LSBC Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7650	LSB-BSE1: LSBC Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7651	LSB-BSE1: LSBC Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7653	LSB-BSE1: LSBC Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7654	LSB-BSE1: LSBC Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7664	LSB-BSE1: LSBC Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7665	LSB-BSE1: LSBC Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7666	LSB-BSE1: LSBC Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7667	LSB-BSE1: LSBC Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7668	LSB-BSE1: LSBC Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7669	LSB-BSE1: LSBC Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A766A	LSB-BSE1: LSBC Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A766B	LSB-BSE1: LSBC Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A766C	LSB-BSE1: LSBC Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7750	LSB-BSE1: LSBC Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7751	LSB-BSE1: LSBC Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7753	LSB-BSE1: LSBC Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7754	LSB-BSE1: LSBC Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7764	LSB-BSE1: LSBC Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7765	LSB-BSE1: LSBC Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7766	LSB-BSE1: LSBC Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7767	LSB-BSE1: LSBC Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7768	LSB-BSE1: LSBC Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7769	LSB-BSE1: LSBC Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A776A	LSB-BSE1: LSBC Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A776B	LSB-BSE1: LSBC Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A776C	LSB-BSE1: LSBC Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7850	LSB-BSE1: LSBC Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7851	LSB-BSE1: LSBC Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7853	LSB-BSE1: LSBC Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7854	LSB-BSE1: LSBC Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7864	LSB-BSE1: LSBC Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7865	LSB-BSE1: LSBC Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7866	LSB-BSE1: LSBC Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7867	LSB-BSE1: LSBC Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7868	LSB-BSE1: LSBC Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7869	LSB-BSE1: LSBC Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A786A	LSB-BSE1: LSBC Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A786B	LSB-BSE1: LSBC Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A786C	LSB-BSE1: LSBC Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7950	LSB-BSE1: LSBC Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7951	LSB-BSE1: LSBC Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7953	LSB-BSE1: LSBC Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7954	LSB-BSE1: LSBC Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7964	LSB-BSE1: LSBC Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7965	LSB-BSE1: LSBC Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7966	LSB-BSE1: LSBC Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7967	LSB-BSE1: LSBC Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7968	LSB-BSE1: LSBC Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7969	LSB-BSE1: LSBC Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A796A	LSB-BSE1: LSBC Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A796B	LSB-BSE1: LSBC Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A796C	LSB-BSE1: LSBC Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7A50	LSB-BSE1: LSBC Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7A51	LSB-BSE1: LSBC Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7A53	LSB-BSE1: LSBC Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7A54	LSB-BSE1: LSBC Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7A64	LSB-BSE1: LSBC Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7A65	LSB-BSE1: LSBC Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7A66	LSB-BSE1: LSBC Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7A67	LSB-BSE1: LSBC Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7A68	LSB-BSE1: LSBC Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7A69	LSB-BSE1: LSBC Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A7A6A	LSB-BSE1: LSBC Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A7A6B	LSB-BSE1: LSBC Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A7A6C	LSB-BSE1: LSBC Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7B50	LSB-BSE1: LSBC Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7B51	LSB-BSE1: LSBC Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7B53	LSB-BSE1: LSBC Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7B54	LSB-BSE1: LSBC Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7B64	LSB-BSE1: LSBC Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7B65	LSB-BSE1: LSBC Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7B66	LSB-BSE1: LSBC Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7B67	LSB-BSE1: LSBC Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7B68	LSB-BSE1: LSBC Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7B69	LSB-BSE1: LSBC Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A7B6A	LSB-BSE1: LSBC Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A7B6B	LSB-BSE1: LSBC Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A7B6C	LSB-BSE1: LSBC Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7C50	LSB-BSE1: LSBC Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7C51	LSB-BSE1: LSBC Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7C53	LSB-BSE1: LSBC Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7C54	LSB-BSE1: LSBC Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7C64	LSB-BSE1: LSBC Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7C65	LSB-BSE1: LSBC Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7C66	LSB-BSE1: LSBC Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7C67	LSB-BSE1: LSBC Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7C68	LSB-BSE1: LSBC Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7C69	LSB-BSE1: LSBC Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A7C6A	LSB-BSE1: LSBC Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A7C6B	LSB-BSE1: LSBC Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7C6C	LSB-BSE1: LSBC Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7D50	LSB-BSE1: LSBC Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7D51	LSB-BSE1: LSBC Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7D53	LSB-BSE1: LSBC Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7D54	LSB-BSE1: LSBC Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7D64	LSB-BSE1: LSBC Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7D65	LSB-BSE1: LSBC Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2
1A7D66	LSB-BSE1: LSBC Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7D67	LSB-BSE1: LSBC Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7D68	LSB-BSE1: LSBC Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7D69	LSB-BSE1: LSBC Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A7D6A	LSB-BSE1: LSBC Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A7D6B	LSB-BSE1: LSBC Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A7D6C	LSB-BSE1: LSBC Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A7E50	LSB-BSE1: LSBC Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:11		E	2
1A7E51	LSB-BSE1: LSBC Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:11		E	2
1A7E53	LSB-BSE1: LSBC Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:11		E	1
1A7E54	LSB-BSE1: LSBC Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:11		E	2
1A7E64	LSB-BSE1: LSBC Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:11		E	1
1A7E65	LSB-BSE1: LSBC Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A7E66	LSB-BSE1: LSBC Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:11		E	2
1A7E67	LSB-BSE1: LSBC Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:11		E	1
1A7E68	LSB-BSE1: LSBC Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:11		E	1
1A7E69	LSB-BSE1: LSBC Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:11		E	1
1A7E6A	LSB-BSE1: LSBC Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:11		E	2
1A7E6B	LSB-BSE1: LSBC Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:11		E	2
1A7E6C	LSB-BSE1: LSBC Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:11		E	2
1A8052	LSB-BSE1: Control data transfer LSBC has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X4:11		E	0
1A8055	LSB-BSE1: Control data transfer LSBC Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:11		E	2
1A8056	LSB-BSE1: Control data transfer LSBC Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A8057	LSB-BSE1: Control data transfer LSBC has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X4:11		E	1
1A8058	LSB-BSE1: Control data transfer LSBC recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X4:11		E	0
1A8059	LSB-BSE1: Control data transfer LSBC recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X4:11		E	0
1A8060	LSB-BSE1: Control data transfer LSBC driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361.X4:11		E	2
1A8061	LSB-BSE1: Control data transfer LSBC driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361.X4:11		E	2
1A8062	LSB-BSE1: Control data transfer LSBC Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X4:11		E	2
1A9050	LSB-BSE1: LSB-D Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9051	LSB-BSE1: LSB-D Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9053	LSB-BSE1: LSB-D Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9054	LSB-BSE1: LSB-D Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9064	LSB-BSE1: LSB-D Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9065	LSB-BSE1: LSB-D Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9066	LSB-BSE1: LSB-D Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9067	LSB-BSE1: LSB-D Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9068	LSB-BSE1: LSB-D Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9069	LSB-BSE1: LSB-D Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A906A	LSB-BSE1: LSB-D Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A906B	LSB-BSE1: LSB-D Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A906C	LSB-BSE1: LSB-D Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9150	LSB-BSE1: LSB-D Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9151	LSB-BSE1: LSB-D Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9153	LSB-BSE1: LSB-D Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9154	LSB-BSE1: LSB-D Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9164	LSB-BSE1: LSB-D Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9165	LSB-BSE1: LSB-D Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9166	LSB-BSE1: LSB-D Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9167	LSB-BSE1: LSB-D Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9168	LSB-BSE1: LSB-D Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9169	LSB-BSE1: LSB-D Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A916A	LSB-BSE1: LSB-D Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A916B	LSB-BSE1: LSB-D Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A916C	LSB-BSE1: LSB-D Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9250	LSB-BSE1: LSB-D Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9251	LSB-BSE1: LSB-D Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9253	LSB-BSE1: LSB-D Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9254	LSB-BSE1: LSB-D Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9264	LSB-BSE1: LSB-D Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9265	LSB-BSE1: LSB-D Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9266	LSB-BSE1: LSB-D Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9267	LSB-BSE1: LSB-D Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9268	LSB-BSE1: LSB-D Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9269	LSB-BSE1: LSB-D Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A926A	LSB-BSE1: LSB-D Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A926B	LSB-BSE1: LSB-D Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A926C	LSB-BSE1: LSB-D Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9350	LSB-BSE1: LSB-D Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9351	LSB-BSE1: LSB-D Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9353	LSB-BSE1: LSB-D Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9354	LSB-BSE1: LSB-D Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9364	LSB-BSE1: LSB-D Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9365	LSB-BSE1: LSB-D Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9366	LSB-BSE1: LSB-D Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9367	LSB-BSE1: LSB-D Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9368	LSB-BSE1: LSB-D Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9369	LSB-BSE1: LSB-D Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A936A	LSB-BSE1: LSB-D Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A936B	LSB-BSE1: LSB-D Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A936C	LSB-BSE1: LSB-D Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9450	LSB-BSE1: LSB-D Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9451	LSB-BSE1: LSB-D Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9453	LSB-BSE1: LSB-D Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9454	LSB-BSE1: LSB-D Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9464	LSB-BSE1: LSB-D Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9465	LSB-BSE1: LSB-D Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9466	LSB-BSE1: LSB-D Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9467	LSB-BSE1: LSB-D Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9468	LSB-BSE1: LSB-D Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9469	LSB-BSE1: LSB-D Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A946A	LSB-BSE1: LSB-D Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A946B	LSB-BSE1: LSB-D Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A946C	LSB-BSE1: LSB-D Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9550	LSB-BSE1: LSB-D Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9551	LSB-BSE1: LSB-D Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9553	LSB-BSE1: LSB-D Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9554	LSB-BSE1: LSB-D Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9564	LSB-BSE1: LSB-D Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9565	LSB-BSE1: LSB-D Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9566	LSB-BSE1: LSB-D Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9567	LSB-BSE1: LSB-D Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9568	LSB-BSE1: LSB-D Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9569	LSB-BSE1: LSB-D Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A956A	LSB-BSE1: LSB-D Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A956B	LSB-BSE1: LSB-D Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A956C	LSB-BSE1: LSB-D Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9650	LSB-BSE1: LSB-D Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9651	LSB-BSE1: LSB-D Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9653	LSB-BSE1: LSB-D Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9654	LSB-BSE1: LSB-D Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9664	LSB-BSE1: LSB-D Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9665	LSB-BSE1: LSB-D Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9666	LSB-BSE1: LSB-D Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9667	LSB-BSE1: LSB-D Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9668	LSB-BSE1: LSB-D Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9669	LSB-BSE1: LSB-D Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A966A	LSB-BSE1: LSB-D Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A966B	LSB-BSE1: LSB-D Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A966C	LSB-BSE1: LSB-D Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9750	LSB-BSE1: LSB-D Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9751	LSB-BSE1: LSB-D Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9753	LSB-BSE1: LSB-D Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9754	LSB-BSE1: LSB-D Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9764	LSB-BSE1: LSB-D Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9765	LSB-BSE1: LSB-D Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9766	LSB-BSE1: LSB-D Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9767	LSB-BSE1: LSB-D Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9768	LSB-BSE1: LSB-D Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9769	LSB-BSE1: LSB-D Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A976A	LSB-BSE1: LSB-D Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A976B	LSB-BSE1: LSB-D Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A976C	LSB-BSE1: LSB-D Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9850	LSB-BSE1: LSB-D Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9851	LSB-BSE1: LSB-D Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9853	LSB-BSE1: LSB-D Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9854	LSB-BSE1: LSB-D Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9864	LSB-BSE1: LSB-D Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9865	LSB-BSE1: LSB-D Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9866	LSB-BSE1: LSB-D Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9867	LSB-BSE1: LSB-D Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9868	LSB-BSE1: LSB-D Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9869	LSB-BSE1: LSB-D Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A986A	LSB-BSE1: LSB-D Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A986B	LSB-BSE1: LSB-D Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A986C	LSB-BSE1: LSB-D Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9950	LSB-BSE1: LSB-D Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9951	LSB-BSE1: LSB-D Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9953	LSB-BSE1: LSB-D Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9954	LSB-BSE1: LSB-D Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9964	LSB-BSE1: LSB-D Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9965	LSB-BSE1: LSB-D Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9966	LSB-BSE1: LSB-D Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9967	LSB-BSE1: LSB-D Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9968	LSB-BSE1: LSB-D Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9969	LSB-BSE1: LSB-D Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A996A	LSB-BSE1: LSB-D Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A996B	LSB-BSE1: LSB-D Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A996C	LSB-BSE1: LSB-D Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9A50	LSB-BSE1: LSB-D Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9A51	LSB-BSE1: LSB-D Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9A53	LSB-BSE1: LSB-D Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9A54	LSB-BSE1: LSB-D Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9A64	LSB-BSE1: LSB-D Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9A65	LSB-BSE1: LSB-D Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9A66	LSB-BSE1: LSB-D Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9A67	LSB-BSE1: LSB-D Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9A68	LSB-BSE1: LSB-D Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9A69	LSB-BSE1: LSB-D Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A9A6A	LSB-BSE1: LSB-D Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A9A6B	LSB-BSE1: LSB-D Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A9A6C	LSB-BSE1: LSB-D Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9B50	LSB-BSE1: LSB-D Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9B51	LSB-BSE1: LSB-D Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9B53	LSB-BSE1: LSB-D Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9B54	LSB-BSE1: LSB-D Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9B64	LSB-BSE1: LSB-D Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9B65	LSB-BSE1: LSB-D Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9B66	LSB-BSE1: LSB-D Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9B67	LSB-BSE1: LSB-D Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9B68	LSB-BSE1: LSB-D Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9B69	LSB-BSE1: LSB-D Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A9B6A	LSB-BSE1: LSB-D Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9B6B	LSB-BSE1: LSB-D Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A9B6C	LSB-BSE1: LSB-D Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9C50	LSB-BSE1: LSB-D Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9C51	LSB-BSE1: LSB-D Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9C53	LSB-BSE1: LSB-D Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9C54	LSB-BSE1: LSB-D Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9C64	LSB-BSE1: LSB-D Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9C65	LSB-BSE1: LSB-D Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9C66	LSB-BSE1: LSB-D Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9C67	LSB-BSE1: LSB-D Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9C68	LSB-BSE1: LSB-D Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9C69	LSB-BSE1: LSB-D Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A9C6A	LSB-BSE1: LSB-D Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A9C6B	LSB-BSE1: LSB-D Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A9C6C	LSB-BSE1: LSB-D Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9D50	LSB-BSE1: LSB-D Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9D51	LSB-BSE1: LSB-D Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9D53	LSB-BSE1: LSB-D Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9D54	LSB-BSE1: LSB-D Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9D64	LSB-BSE1: LSB-D Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9D65	LSB-BSE1: LSB-D Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9D66	LSB-BSE1: LSB-D Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9D67	LSB-BSE1: LSB-D Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9D68	LSB-BSE1: LSB-D Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9D69	LSB-BSE1: LSB-D Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A9D6A	LSB-BSE1: LSB-D Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A9D6B	LSB-BSE1: LSB-D Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A9D6C	LSB-BSE1: LSB-D Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9E50	LSB-BSE1: LSB-D Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9E51	LSB-BSE1: LSB-D Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9E53	LSB-BSE1: LSB-D Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9E54	LSB-BSE1: LSB-D Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9E64	LSB-BSE1: LSB-D Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9E65	LSB-BSE1: LSB-D Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9E66	LSB-BSE1: LSB-D Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9E67	LSB-BSE1: LSB-D Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9E68	LSB-BSE1: LSB-D Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1A9E69	LSB-BSE1: LSB-D Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A9E6A	LSB-BSE1: LSB-D Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A9E6B	LSB-BSE1: LSB-D Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9E6C	LSB-BSE1: LSB-D Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1A9F50	LSB-BSE1: LSB-D Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1A9F51	LSB-BSE1: LSB-D Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1A9F53	LSB-BSE1: LSB-D Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1A9F54	LSB-BSE1: LSB-D Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1A9F64	LSB-BSE1: LSB-D Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1A9F65	LSB-BSE1: LSB-D Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1A9F66	LSB-BSE1: LSB-D Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1A9F67	LSB-BSE1: LSB-D Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1A9F68	LSB-BSE1: LSB-D Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1A9F69	LSB-BSE1: LSB-D Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1A9F6A	LSB-BSE1: LSB-D Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1A9F6B	LSB-BSE1: LSB-D Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1A9F6C	LSB-BSE1: LSB-D Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA050	LSB-BSE1: LSB-D Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA051	LSB-BSE1: LSB-D Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA053	LSB-BSE1: LSB-D Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA054	LSB-BSE1: LSB-D Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA064	LSB-BSE1: LSB-D Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA065	LSB-BSE1: LSB-D Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA066	LSB-BSE1: LSB-D Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA067	LSB-BSE1: LSB-D Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA068	LSB-BSE1: LSB-D Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA069	LSB-BSE1: LSB-D Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA06A	LSB-BSE1: LSB-D Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA06B	LSB-BSE1: LSB-D Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA06C	LSB-BSE1: LSB-D Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA150	LSB-BSE1: LSB-D Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA151	LSB-BSE1: LSB-D Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA153	LSB-BSE1: LSB-D Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA154	LSB-BSE1: LSB-D Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA164	LSB-BSE1: LSB-D Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA165	LSB-BSE1: LSB-D Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA166	LSB-BSE1: LSB-D Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA167	LSB-BSE1: LSB-D Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA168	LSB-BSE1: LSB-D Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA169	LSB-BSE1: LSB-D Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA16A	LSB-BSE1: LSB-D Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA16B	LSB-BSE1: LSB-D Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA16C	LSB-BSE1: LSB-D Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA250	LSB-BSE1: LSB-D Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA251	LSB-BSE1: LSB-D Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA253	LSB-BSE1: LSB-D Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA254	LSB-BSE1: LSB-D Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA264	LSB-BSE1: LSB-D Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA265	LSB-BSE1: LSB-D Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA266	LSB-BSE1: LSB-D Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA267	LSB-BSE1: LSB-D Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA268	LSB-BSE1: LSB-D Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA269	LSB-BSE1: LSB-D Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA26A	LSB-BSE1: LSB-D Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA26B	LSB-BSE1: LSB-D Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA26C	LSB-BSE1: LSB-D Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA350	LSB-BSE1: LSB-D Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA351	LSB-BSE1: LSB-D Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA353	LSB-BSE1: LSB-D Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA354	LSB-BSE1: LSB-D Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA364	LSB-BSE1: LSB-D Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA365	LSB-BSE1: LSB-D Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA366	LSB-BSE1: LSB-D Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA367	LSB-BSE1: LSB-D Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA368	LSB-BSE1: LSB-D Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA369	LSB-BSE1: LSB-D Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA36A	LSB-BSE1: LSB-D Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA36B	LSB-BSE1: LSB-D Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA36C	LSB-BSE1: LSB-D Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA450	LSB-BSE1: LSB-D Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA451	LSB-BSE1: LSB-D Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA453	LSB-BSE1: LSB-D Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA454	LSB-BSE1: LSB-D Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA464	LSB-BSE1: LSB-D Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA465	LSB-BSE1: LSB-D Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA466	LSB-BSE1: LSB-D Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA467	LSB-BSE1: LSB-D Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA468	LSB-BSE1: LSB-D Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA469	LSB-BSE1: LSB-D Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA46A	LSB-BSE1: LSB-D Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA46B	LSB-BSE1: LSB-D Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA46C	LSB-BSE1: LSB-D Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA550	LSB-BSE1: LSB-D Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA551	LSB-BSE1: LSB-D Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA553	LSB-BSE1: LSB-D Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA554	LSB-BSE1: LSB-D Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA564	LSB-BSE1: LSB-D Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA565	LSB-BSE1: LSB-D Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA566	LSB-BSE1: LSB-D Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA567	LSB-BSE1: LSB-D Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA568	LSB-BSE1: LSB-D Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA569	LSB-BSE1: LSB-D Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA56A	LSB-BSE1: LSB-D Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA56B	LSB-BSE1: LSB-D Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA56C	LSB-BSE1: LSB-D Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA650	LSB-BSE1: LSB-D Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA651	LSB-BSE1: LSB-D Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA653	LSB-BSE1: LSB-D Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA654	LSB-BSE1: LSB-D Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA664	LSB-BSE1: LSB-D Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA665	LSB-BSE1: LSB-D Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA666	LSB-BSE1: LSB-D Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA667	LSB-BSE1: LSB-D Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA668	LSB-BSE1: LSB-D Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA669	LSB-BSE1: LSB-D Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA66A	LSB-BSE1: LSB-D Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA66B	LSB-BSE1: LSB-D Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA66C	LSB-BSE1: LSB-D Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA750	LSB-BSE1: LSB-D Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA751	LSB-BSE1: LSB-D Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA753	LSB-BSE1: LSB-D Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA754	LSB-BSE1: LSB-D Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA764	LSB-BSE1: LSB-D Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA765	LSB-BSE1: LSB-D Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA766	LSB-BSE1: LSB-D Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA767	LSB-BSE1: LSB-D Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA768	LSB-BSE1: LSB-D Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA769	LSB-BSE1: LSB-D Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA76A	LSB-BSE1: LSB-D Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA76B	LSB-BSE1: LSB-D Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA76C	LSB-BSE1: LSB-D Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA850	LSB-BSE1: LSB-D Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA851	LSB-BSE1: LSB-D Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA853	LSB-BSE1: LSB-D Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA854	LSB-BSE1: LSB-D Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA864	LSB-BSE1: LSB-D Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA865	LSB-BSE1: LSB-D Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA866	LSB-BSE1: LSB-D Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA867	LSB-BSE1: LSB-D Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA868	LSB-BSE1: LSB-D Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AA869	LSB-BSE1: LSB-D Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA86A	LSB-BSE1: LSB-D Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA86B	LSB-BSE1: LSB-D Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA86C	LSB-BSE1: LSB-D Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AA950	LSB-BSE1: LSB-D Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AA951	LSB-BSE1: LSB-D Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AA953	LSB-BSE1: LSB-D Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AA954	LSB-BSE1: LSB-D Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AA964	LSB-BSE1: LSB-D Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AA965	LSB-BSE1: LSB-D Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AA966	LSB-BSE1: LSB-D Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AA967	LSB-BSE1: LSB-D Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AA968	LSB-BSE1: LSB-D Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AA969	LSB-BSE1: LSB-D Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AA96A	LSB-BSE1: LSB-D Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AA96B	LSB-BSE1: LSB-D Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AA96C	LSB-BSE1: LSB-D Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AAA50	LSB-BSE1: LSB-D Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AAA51	LSB-BSE1: LSB-D Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AAA53	LSB-BSE1: LSB-D Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AAA54	LSB-BSE1: LSB-D Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AAA64	LSB-BSE1: LSB-D Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AAA65	LSB-BSE1: LSB-D Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AAA66	LSB-BSE1: LSB-D Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AAA67	LSB-BSE1: LSB-D Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AAA68	LSB-BSE1: LSB-D Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AAA69	LSB-BSE1: LSB-D Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AAA6A	LSB-BSE1: LSB-D Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AAA6B	LSB-BSE1: LSB-D Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AAA6C	LSB-BSE1: LSB-D Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AAB50	LSB-BSE1: LSB-D Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AAB51	LSB-BSE1: LSB-D Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AAB53	LSB-BSE1: LSB-D Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AAB54	LSB-BSE1: LSB-D Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AAB64	LSB-BSE1: LSB-D Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AAB65	LSB-BSE1: LSB-D Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AAB66	LSB-BSE1: LSB-D Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AAB67	LSB-BSE1: LSB-D Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AAB68	LSB-BSE1: LSB-D Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AAB69	LSB-BSE1: LSB-D Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AAB6A	LSB-BSE1: LSB-D Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AAB6B	LSB-BSE1: LSB-D Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AAB6C	LSB-BSE1: LSB-D Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AAC50	LSB-BSE1: LSB-D Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AAC51	LSB-BSE1: LSB-D Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AAC53	LSB-BSE1: LSB-D Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AAC54	LSB-BSE1: LSB-D Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AAC64	LSB-BSE1: LSB-D Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AAC65	LSB-BSE1: LSB-D Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AAC66	LSB-BSE1: LSB-D Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AAC67	LSB-BSE1: LSB-D Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AAC68	LSB-BSE1: LSB-D Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AAC69	LSB-BSE1: LSB-D Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AAC6A	LSB-BSE1: LSB-D Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AAC6B	LSB-BSE1: LSB-D Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AAC6C	LSB-BSE1: LSB-D Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AAD50	LSB-BSE1: LSB-D Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AAD51	LSB-BSE1: LSB-D Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AAD53	LSB-BSE1: LSB-D Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AAD54	LSB-BSE1: LSB-D Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2
1AAD64	LSB-BSE1: LSB-D Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AAD65	LSB-BSE1: LSB-D Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AAD66	LSB-BSE1: LSB-D Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AAD67	LSB-BSE1: LSB-D Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AAD68	LSB-BSE1: LSB-D Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AAD69	LSB-BSE1: LSB-D Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AAD6A	LSB-BSE1: LSB-D Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AAD6B	LSB-BSE1: LSB-D Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AAD6C	LSB-BSE1: LSB-D Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AAE50	LSB-BSE1: LSB-D Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X4:12		E	2
1AAE51	LSB-BSE1: LSB-D Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X4:12		E	2
1AAE53	LSB-BSE1: LSB-D Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X4:12		E	1
1AAE54	LSB-BSE1: LSB-D Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AAE64	LSB-BSE1: LSB-D Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X4:12		E	1
1AAE65	LSB-BSE1: LSB-D Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X4:12		E	2
1AAE66	LSB-BSE1: LSB-D Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X4:12		E	2
1AAE67	LSB-BSE1: LSB-D Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X4:12		E	1
1AAE68	LSB-BSE1: LSB-D Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X4:12		E	1
1AAE69	LSB-BSE1: LSB-D Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X4:12		E	1
1AAE6A	LSB-BSE1: LSB-D Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X4:12		E	2
1AAE6B	LSB-BSE1: LSB-D Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X4:12		E	2
1AAE6C	LSB-BSE1: LSB-D Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X4:12		E	2
1AB052	LSB-BSE1: Control data transfer LSB-D has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X4:12		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1AB055	LSB-BSE1: Control data transfer LSB-D Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:12		E	2
1AB056	LSB-BSE1: Control data transfer LSB-D Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X4:12		E	2
1AB057	LSB-BSE1: Control data transfer LSB-D has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X4:12		E	1
1AB058	LSB-BSE1: Control data transfer LSB-D recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X4:12		E	0
1AB059	LSB-BSE1: Control data transfer LSB-D recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X4:12		E	0
1AB060	LSB-BSE1: Control data transfer LSB-D driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361.X4:12		E	2
1AB061	LSB-BSE1: Control data transfer LSB-D driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361.X4:12		E	2
1AB062	LSB-BSE1: Control data transfer LSB-D Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X4:12		E	2
1B0050	LSB-BSE1: LSBE Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0051	LSB-BSE1: LSBE Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0053	LSB-BSE1: LSBE Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B0054	LSB-BSE1: LSBE Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B0064	LSB-BSE1: LSBE Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0065	LSB-BSE1: LSBE Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B0066	LSB-BSE1: LSBE Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B0067	LSB-BSE1: LSBE Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0068	LSB-BSE1: LSBE Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B0069	LSB-BSE1: LSBE Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B006A	LSB-BSE1: LSBE Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B006B	LSB-BSE1: LSBE Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B006C	LSB-BSE1: LSBE Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B0150	LSB-BSE1: LSBE Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0151	LSB-BSE1: LSBE Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B0153	LSB-BSE1: LSBE Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B0154	LSB-BSE1: LSBE Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B0164	LSB-BSE1: LSBE Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0165	LSB-BSE1: LSBE Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B0166	LSB-BSE1: LSBE Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B0167	LSB-BSE1: LSBE Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0168	LSB-BSE1: LSBE Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0169	LSB-BSE1: LSBE Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B016A	LSB-BSE1: LSBE Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B016B	LSB-BSE1: LSBE Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B016C	LSB-BSE1: LSBE Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B0250	LSB-BSE1: LSBE Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0251	LSB-BSE1: LSBE Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B0253	LSB-BSE1: LSBE Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B0254	LSB-BSE1: LSBE Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B0264	LSB-BSE1: LSBE Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0265	LSB-BSE1: LSBE Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0266	LSB-BSE1: LSBE Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B0267	LSB-BSE1: LSBE Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0268	LSB-BSE1: LSBE Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B0269	LSB-BSE1: LSBE Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B026A	LSB-BSE1: LSBE Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B026B	LSB-BSE1: LSBE Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B026C	LSB-BSE1: LSBE Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B0950	LSB-BSE1: LSBE Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0951	LSB-BSE1: LSBE Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B0953	LSB-BSE1: LSBE Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0954	LSB-BSE1: LSBE Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B0964	LSB-BSE1: LSBE Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0965	LSB-BSE1: LSBE Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B0966	LSB-BSE1: LSBE Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B0967	LSB-BSE1: LSBE Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0968	LSB-BSE1: LSBE Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B0969	LSB-BSE1: LSBE Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B096A	LSB-BSE1: LSBE Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B096B	LSB-BSE1: LSBE Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B096C	LSB-BSE1: LSBE Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0A50	LSB-BSE1: LSBE Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0A51	LSB-BSE1: LSBE Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B0A53	LSB-BSE1: LSBE Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B0A54	LSB-BSE1: LSBE Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B0A64	LSB-BSE1: LSBE Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0A65	LSB-BSE1: LSBE Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B0A66	LSB-BSE1: LSBE Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B0A67	LSB-BSE1: LSBE Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0A68	LSB-BSE1: LSBE Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B0A69	LSB-BSE1: LSBE Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0A6A	LSB-BSE1: LSBE Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B0A6B	LSB-BSE1: LSBE Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B0A6C	LSB-BSE1: LSBE Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B0B50	LSB-BSE1: LSBE Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0B51	LSB-BSE1: LSBE Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B0B53	LSB-BSE1: LSBE Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B0B54	LSB-BSE1: LSBE Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B0B64	LSB-BSE1: LSBE Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0B65	LSB-BSE1: LSBE Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B0B66	LSB-BSE1: LSBE Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0B67	LSB-BSE1: LSBE Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0B68	LSB-BSE1: LSBE Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B0B69	LSB-BSE1: LSBE Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B0B6A	LSB-BSE1: LSBE Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B0B6B	LSB-BSE1: LSBE Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B0B6C	LSB-BSE1: LSBE Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B0C50	LSB-BSE1: LSBE Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B0C51	LSB-BSE1: LSBE Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B0C53	LSB-BSE1: LSBE Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B0C54	LSB-BSE1: LSBE Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B0C64	LSB-BSE1: LSBE Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B0C65	LSB-BSE1: LSBE Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B0C66	LSB-BSE1: LSBE Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B0C67	LSB-BSE1: LSBE Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B0C68	LSB-BSE1: LSBE Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B0C69	LSB-BSE1: LSBE Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B0C6A	LSB-BSE1: LSBE Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B0C6B	LSB-BSE1: LSBE Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B0C6C	LSB-BSE1: LSBE Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B1150	LSB-BSE1: LSBE Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1151	LSB-BSE1: LSBE Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B1153	LSB-BSE1: LSBE Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B1154	LSB-BSE1: LSBE Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1164	LSB-BSE1: LSBE Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B1165	LSB-BSE1: LSBE Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B1166	LSB-BSE1: LSBE Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B1167	LSB-BSE1: LSBE Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B1168	LSB-BSE1: LSBE Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B1169	LSB-BSE1: LSBE Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B116A	LSB-BSE1: LSBE Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B116B	LSB-BSE1: LSBE Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B116C	LSB-BSE1: LSBE Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B1250	LSB-BSE1: LSBE Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B1251	LSB-BSE1: LSBE Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B1253	LSB-BSE1: LSBE Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B1254	LSB-BSE1: LSBE Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1264	LSB-BSE1: LSBE Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B1265	LSB-BSE1: LSBE Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B1266	LSB-BSE1: LSBE Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B1267	LSB-BSE1: LSBE Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1268	LSB-BSE1: LSBE Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B1269	LSB-BSE1: LSBE Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B126A	LSB-BSE1: LSBE Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B126B	LSB-BSE1: LSBE Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B126C	LSB-BSE1: LSBE Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B1350	LSB-BSE1: LSBE Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B1351	LSB-BSE1: LSBE Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B1353	LSB-BSE1: LSBE Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B1354	LSB-BSE1: LSBE Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1364	LSB-BSE1: LSBE Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1365	LSB-BSE1: LSBE Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B1366	LSB-BSE1: LSBE Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B1367	LSB-BSE1: LSBE Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B1368	LSB-BSE1: LSBE Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B1369	LSB-BSE1: LSBE Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B136A	LSB-BSE1: LSBE Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B136B	LSB-BSE1: LSBE Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B136C	LSB-BSE1: LSBE Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B1450	LSB-BSE1: LSBE Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B1451	LSB-BSE1: LSBE Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1453	LSB-BSE1: LSBE Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B1454	LSB-BSE1: LSBE Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1464	LSB-BSE1: LSBE Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B1465	LSB-BSE1: LSBE Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B1466	LSB-BSE1: LSBE Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B1467	LSB-BSE1: LSBE Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B1468	LSB-BSE1: LSBE Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B1469	LSB-BSE1: LSBE Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B146A	LSB-BSE1: LSBE Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B146B	LSB-BSE1: LSBE Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B146C	LSB-BSE1: LSBE Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B1750	LSB-BSE1: LSBE Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B1751	LSB-BSE1: LSBE Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B1753	LSB-BSE1: LSBE Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B1754	LSB-BSE1: LSBE Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1764	LSB-BSE1: LSBE Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B1765	LSB-BSE1: LSBE Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B1766	LSB-BSE1: LSBE Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B1767	LSB-BSE1: LSBE Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B1768	LSB-BSE1: LSBE Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1769	LSB-BSE1: LSBE Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B176A	LSB-BSE1: LSBE Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B176B	LSB-BSE1: LSBE Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B176C	LSB-BSE1: LSBE Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B1B50	LSB-BSE1: LSBE Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B1B51	LSB-BSE1: LSBE Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B1B53	LSB-BSE1: LSBE Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B1B54	LSB-BSE1: LSBE Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1B64	LSB-BSE1: LSBE Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B1B65	LSB-BSE1: LSBE Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1B66	LSB-BSE1: LSBE Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B1B67	LSB-BSE1: LSBE Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B1B68	LSB-BSE1: LSBE Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B1B69	LSB-BSE1: LSBE Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B1B6A	LSB-BSE1: LSBE Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B1B6B	LSB-BSE1: LSBE Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B1B6C	LSB-BSE1: LSBE Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B1C50	LSB-BSE1: LSBE Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B1C51	LSB-BSE1: LSBE Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B1C53	LSB-BSE1: LSBE Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1C54	LSB-BSE1: LSBE Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1C64	LSB-BSE1: LSBE Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B1C65	LSB-BSE1: LSBE Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B1C66	LSB-BSE1: LSBE Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B1C67	LSB-BSE1: LSBE Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B1C68	LSB-BSE1: LSBE Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B1C69	LSB-BSE1: LSBE Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B1C6A	LSB-BSE1: LSBE Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B1C6B	LSB-BSE1: LSBE Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B1C6C	LSB-BSE1: LSBE Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1D50	LSB-BSE1: LSBE Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B1D51	LSB-BSE1: LSBE Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B1D53	LSB-BSE1: LSBE Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B1D54	LSB-BSE1: LSBE Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1D64	LSB-BSE1: LSBE Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B1D65	LSB-BSE1: LSBE Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B1D66	LSB-BSE1: LSBE Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2
1B1D67	LSB-BSE1: LSBE Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B1D68	LSB-BSE1: LSBE Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B1D69	LSB-BSE1: LSBE Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1D6A	LSB-BSE1: LSBE Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B1D6B	LSB-BSE1: LSBE Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B1D6C	LSB-BSE1: LSBE Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B1E50	LSB-BSE1: LSBE Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:9		E	2
1B1E51	LSB-BSE1: LSBE Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:9		E	2
1B1E53	LSB-BSE1: LSBE Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:9		E	1
1B1E54	LSB-BSE1: LSBE Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:9		E	2
1B1E64	LSB-BSE1: LSBE Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:9		E	1
1B1E65	LSB-BSE1: LSBE Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:9		E	2
1B1E66	LSB-BSE1: LSBE Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B1E67	LSB-BSE1: LSBE Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:9		E	1
1B1E68	LSB-BSE1: LSBE Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:9		E	1
1B1E69	LSB-BSE1: LSBE Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:9		E	1
1B1E6A	LSB-BSE1: LSBE Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:9		E	2
1B1E6B	LSB-BSE1: LSBE Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:9		E	2
1B1E6C	LSB-BSE1: LSBE Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:9		E	2
1B2052	LSB-BSE1: Control data transfer LSBE has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X5:9		E	0
1B2055	LSB-BSE1: Control data transfer LSBE Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:9		E	2
1B2056	LSB-BSE1: Control data transfer LSBE Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:9		E	2
1B2057	LSB-BSE1: Control data transfer LSBE has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B2058	LSB-BSE1: Control data transfer LSBE recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X5:9		E	0
1B2059	LSB-BSE1: Control data transfer LSBE recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X5:9		E	0
1B2060	LSB-BSE1: Control data transfer LSBE driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361.X5:9		E	2
1B2061	LSB-BSE1: Control data transfer LSBE driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361.X5:9		E	2
1B2062	LSB-BSE1: Control data transfer LSBE Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X5:9		E	2
1B3050	LSB-BSE1: LSBF Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3051	LSB-BSE1: LSBF Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3053	LSB-BSE1: LSBF Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3054	LSB-BSE1: LSBF Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3064	LSB-BSE1: LSBF Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3065	LSB-BSE1: LSBF Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3066	LSB-BSE1: LSBF Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3067	LSB-BSE1: LSBF Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3068	LSB-BSE1: LSBF Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3069	LSB-BSE1: LSBF Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B306A	LSB-BSE1: LSBF Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B306B	LSB-BSE1: LSBF Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B306C	LSB-BSE1: LSBF Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3150	LSB-BSE1: LSBF Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3151	LSB-BSE1: LSBF Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3153	LSB-BSE1: LSBF Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3154	LSB-BSE1: LSBF Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3164	LSB-BSE1: LSBF Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3165	LSB-BSE1: LSBF Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3166	LSB-BSE1: LSBF Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3167	LSB-BSE1: LSBF Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3168	LSB-BSE1: LSBF Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3169	LSB-BSE1: LSBF Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B316A	LSB-BSE1: LSBF Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B316B	LSB-BSE1: LSBF Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B316C	LSB-BSE1: LSBF Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3250	LSB-BSE1: LSBF Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3251	LSB-BSE1: LSBF Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3253	LSB-BSE1: LSBF Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3254	LSB-BSE1: LSBF Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3264	LSB-BSE1: LSBF Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3265	LSB-BSE1: LSBF Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3266	LSB-BSE1: LSBF Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3267	LSB-BSE1: LSBF Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3268	LSB-BSE1: LSBF Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3269	LSB-BSE1: LSBF Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B326A	LSB-BSE1: LSBF Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B326B	LSB-BSE1: LSBF Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B326C	LSB-BSE1: LSBF Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3350	LSB-BSE1: LSBF Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3351	LSB-BSE1: LSBF Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3353	LSB-BSE1: LSBF Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3354	LSB-BSE1: LSBF Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3364	LSB-BSE1: LSBF Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3365	LSB-BSE1: LSBF Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3366	LSB-BSE1: LSBF Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3367	LSB-BSE1: LSBF Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3368	LSB-BSE1: LSBF Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3369	LSB-BSE1: LSBF Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B336A	LSB-BSE1: LSBF Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B336B	LSB-BSE1: LSBF Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B336C	LSB-BSE1: LSBF Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3450	LSB-BSE1: LSBF Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3451	LSB-BSE1: LSBF Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3453	LSB-BSE1: LSBF Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3454	LSB-BSE1: LSBF Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3464	LSB-BSE1: LSBF Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3465	LSB-BSE1: LSBF Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3466	LSB-BSE1: LSBF Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3467	LSB-BSE1: LSBF Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3468	LSB-BSE1: LSBF Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3469	LSB-BSE1: LSBF Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B346A	LSB-BSE1: LSBF Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B346B	LSB-BSE1: LSBF Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B346C	LSB-BSE1: LSBF Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3550	LSB-BSE1: LSBF Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3551	LSB-BSE1: LSBF Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3553	LSB-BSE1: LSBF Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3554	LSB-BSE1: LSBF Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3564	LSB-BSE1: LSBF Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3565	LSB-BSE1: LSBF Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3566	LSB-BSE1: LSBF Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3567	LSB-BSE1: LSBF Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3568	LSB-BSE1: LSBF Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3569	LSB-BSE1: LSBF Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B356A	LSB-BSE1: LSBF Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B356B	LSB-BSE1: LSBF Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B356C	LSB-BSE1: LSBF Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3650	LSB-BSE1: LSBF Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3651	LSB-BSE1: LSBF Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3653	LSB-BSE1: LSBF Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3654	LSB-BSE1: LSBF Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3664	LSB-BSE1: LSBF Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3665	LSB-BSE1: LSBF Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3666	LSB-BSE1: LSBF Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3667	LSB-BSE1: LSBF Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3668	LSB-BSE1: LSBF Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3669	LSB-BSE1: LSBF Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B366A	LSB-BSE1: LSBF Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B366B	LSB-BSE1: LSBF Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B366C	LSB-BSE1: LSBF Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3750	LSB-BSE1: LSBF Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3751	LSB-BSE1: LSBF Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3753	LSB-BSE1: LSBF Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3754	LSB-BSE1: LSBF Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3764	LSB-BSE1: LSBF Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3765	LSB-BSE1: LSBF Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3766	LSB-BSE1: LSBF Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3767	LSB-BSE1: LSBF Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3768	LSB-BSE1: LSBF Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3769	LSB-BSE1: LSBF Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B376A	LSB-BSE1: LSBF Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B376B	LSB-BSE1: LSBF Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B376C	LSB-BSE1: LSBF Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3850	LSB-BSE1: LSBF Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3851	LSB-BSE1: LSBF Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3853	LSB-BSE1: LSBF Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3854	LSB-BSE1: LSBF Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3864	LSB-BSE1: LSBF Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3865	LSB-BSE1: LSBF Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3866	LSB-BSE1: LSBF Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3867	LSB-BSE1: LSBF Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3868	LSB-BSE1: LSBF Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3869	LSB-BSE1: LSBF Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B386A	LSB-BSE1: LSBF Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B386B	LSB-BSE1: LSBF Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B386C	LSB-BSE1: LSBF Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3950	LSB-BSE1: LSBF Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3951	LSB-BSE1: LSBF Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3953	LSB-BSE1: LSBF Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3954	LSB-BSE1: LSBF Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3964	LSB-BSE1: LSBF Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3965	LSB-BSE1: LSBF Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3966	LSB-BSE1: LSBF Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3967	LSB-BSE1: LSBF Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3968	LSB-BSE1: LSBF Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3969	LSB-BSE1: LSBF Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B396A	LSB-BSE1: LSBF Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B396B	LSB-BSE1: LSBF Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B396C	LSB-BSE1: LSBF Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3A50	LSB-BSE1: LSBF Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3A51	LSB-BSE1: LSBF Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3A53	LSB-BSE1: LSBF Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3A54	LSB-BSE1: LSBF Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3A64	LSB-BSE1: LSBF Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3A65	LSB-BSE1: LSBF Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3A66	LSB-BSE1: LSBF Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3A67	LSB-BSE1: LSBF Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3A68	LSB-BSE1: LSBF Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3A69	LSB-BSE1: LSBF Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B3A6A	LSB-BSE1: LSBF Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B3A6B	LSB-BSE1: LSBF Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B3A6C	LSB-BSE1: LSBF Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3B50	LSB-BSE1: LSBF Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3B51	LSB-BSE1: LSBF Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3B53	LSB-BSE1: LSBF Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3B54	LSB-BSE1: LSBF Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3B64	LSB-BSE1: LSBF Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3B65	LSB-BSE1: LSBF Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3B66	LSB-BSE1: LSBF Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3B67	LSB-BSE1: LSBF Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3B68	LSB-BSE1: LSBF Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3B69	LSB-BSE1: LSBF Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B3B6A	LSB-BSE1: LSBF Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B3B6B	LSB-BSE1: LSBF Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3B6C	LSB-BSE1: LSBF Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3C50	LSB-BSE1: LSBF Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3C51	LSB-BSE1: LSBF Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3C53	LSB-BSE1: LSBF Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3C54	LSB-BSE1: LSBF Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3C64	LSB-BSE1: LSBF Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3C65	LSB-BSE1: LSBF Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3C66	LSB-BSE1: LSBF Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3C67	LSB-BSE1: LSBF Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3C68	LSB-BSE1: LSBF Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3C69	LSB-BSE1: LSBF Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B3C6A	LSB-BSE1: LSBF Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B3C6B	LSB-BSE1: LSBF Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B3C6C	LSB-BSE1: LSBF Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3D50	LSB-BSE1: LSBF Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3D51	LSB-BSE1: LSBF Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3D53	LSB-BSE1: LSBF Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3D54	LSB-BSE1: LSBF Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3D64	LSB-BSE1: LSBF Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3D65	LSB-BSE1: LSBF Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3D66	LSB-BSE1: LSBF Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3D67	LSB-BSE1: LSBF Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3D68	LSB-BSE1: LSBF Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3D69	LSB-BSE1: LSBF Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B3D6A	LSB-BSE1: LSBF Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B3D6B	LSB-BSE1: LSBF Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B3D6C	LSB-BSE1: LSBF Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B3E50	LSB-BSE1: LSBF Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3E51	LSB-BSE1: LSBF Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3E53	LSB-BSE1: LSBF Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3E54	LSB-BSE1: LSBF Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3E64	LSB-BSE1: LSBF Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3E65	LSB-BSE1: LSBF Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3E66	LSB-BSE1: LSBF Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3E67	LSB-BSE1: LSBF Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3E68	LSB-BSE1: LSBF Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3E69	LSB-BSE1: LSBF Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B3E6A	LSB-BSE1: LSBF Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B3E6B	LSB-BSE1: LSBF Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B3E6C	LSB-BSE1: LSBF Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3F50	LSB-BSE1: LSBF Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B3F51	LSB-BSE1: LSBF Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B3F53	LSB-BSE1: LSBF Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B3F54	LSB-BSE1: LSBF Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B3F64	LSB-BSE1: LSBF Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B3F65	LSB-BSE1: LSBF Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B3F66	LSB-BSE1: LSBF Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B3F67	LSB-BSE1: LSBF Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B3F68	LSB-BSE1: LSBF Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B3F69	LSB-BSE1: LSBF Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B3F6A	LSB-BSE1: LSBF Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B3F6B	LSB-BSE1: LSBF Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B3F6C	LSB-BSE1: LSBF Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4050	LSB-BSE1: LSBF Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4051	LSB-BSE1: LSBF Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4053	LSB-BSE1: LSBF Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4054	LSB-BSE1: LSBF Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4064	LSB-BSE1: LSBF Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4065	LSB-BSE1: LSBF Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4066	LSB-BSE1: LSBF Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4067	LSB-BSE1: LSBF Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4068	LSB-BSE1: LSBF Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4069	LSB-BSE1: LSBF Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B406A	LSB-BSE1: LSBF Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B406B	LSB-BSE1: LSBF Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B406C	LSB-BSE1: LSBF Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4150	LSB-BSE1: LSBF Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4151	LSB-BSE1: LSBF Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4153	LSB-BSE1: LSBF Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4154	LSB-BSE1: LSBF Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4164	LSB-BSE1: LSBF Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4165	LSB-BSE1: LSBF Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4166	LSB-BSE1: LSBF Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4167	LSB-BSE1: LSBF Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4168	LSB-BSE1: LSBF Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4169	LSB-BSE1: LSBF Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B416A	LSB-BSE1: LSBF Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B416B	LSB-BSE1: LSBF Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B416C	LSB-BSE1: LSBF Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4250	LSB-BSE1: LSBF Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4251	LSB-BSE1: LSBF Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4253	LSB-BSE1: LSBF Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4254	LSB-BSE1: LSBF Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4264	LSB-BSE1: LSBF Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4265	LSB-BSE1: LSBF Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4266	LSB-BSE1: LSBF Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4267	LSB-BSE1: LSBF Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4268	LSB-BSE1: LSBF Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4269	LSB-BSE1: LSBF Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B426A	LSB-BSE1: LSBF Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B426B	LSB-BSE1: LSBF Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B426C	LSB-BSE1: LSBF Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4350	LSB-BSE1: LSBF Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4351	LSB-BSE1: LSBF Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4353	LSB-BSE1: LSBF Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4354	LSB-BSE1: LSBF Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4364	LSB-BSE1: LSBF Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4365	LSB-BSE1: LSBF Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4366	LSB-BSE1: LSBF Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4367	LSB-BSE1: LSBF Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4368	LSB-BSE1: LSBF Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4369	LSB-BSE1: LSBF Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B436A	LSB-BSE1: LSBF Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B436B	LSB-BSE1: LSBF Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B436C	LSB-BSE1: LSBF Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4450	LSB-BSE1: LSBF Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4451	LSB-BSE1: LSBF Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4453	LSB-BSE1: LSBF Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4454	LSB-BSE1: LSBF Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4464	LSB-BSE1: LSBF Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4465	LSB-BSE1: LSBF Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4466	LSB-BSE1: LSBF Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4467	LSB-BSE1: LSBF Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4468	LSB-BSE1: LSBF Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4469	LSB-BSE1: LSBF Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B446A	LSB-BSE1: LSBF Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B446B	LSB-BSE1: LSBF Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B446C	LSB-BSE1: LSBF Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4550	LSB-BSE1: LSBF Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4551	LSB-BSE1: LSBF Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4553	LSB-BSE1: LSBF Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4554	LSB-BSE1: LSBF Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4564	LSB-BSE1: LSBF Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4565	LSB-BSE1: LSBF Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4566	LSB-BSE1: LSBF Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4567	LSB-BSE1: LSBF Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4568	LSB-BSE1: LSBF Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4569	LSB-BSE1: LSBF Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B456A	LSB-BSE1: LSBF Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B456B	LSB-BSE1: LSBF Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B456C	LSB-BSE1: LSBF Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4650	LSB-BSE1: LSBF Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4651	LSB-BSE1: LSBF Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4653	LSB-BSE1: LSBF Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4654	LSB-BSE1: LSBF Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4664	LSB-BSE1: LSBF Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4665	LSB-BSE1: LSBF Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4666	LSB-BSE1: LSBF Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4667	LSB-BSE1: LSBF Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4668	LSB-BSE1: LSBF Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4669	LSB-BSE1: LSBF Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B466A	LSB-BSE1: LSBF Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B466B	LSB-BSE1: LSBF Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B466C	LSB-BSE1: LSBF Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4750	LSB-BSE1: LSBF Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4751	LSB-BSE1: LSBF Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4753	LSB-BSE1: LSBF Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4754	LSB-BSE1: LSBF Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4764	LSB-BSE1: LSBF Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4765	LSB-BSE1: LSBF Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4766	LSB-BSE1: LSBF Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4767	LSB-BSE1: LSBF Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4768	LSB-BSE1: LSBF Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4769	LSB-BSE1: LSBF Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B476A	LSB-BSE1: LSBF Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B476B	LSB-BSE1: LSBF Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B476C	LSB-BSE1: LSBF Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4850	LSB-BSE1: LSBF Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4851	LSB-BSE1: LSBF Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4853	LSB-BSE1: LSBF Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4854	LSB-BSE1: LSBF Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4864	LSB-BSE1: LSBF Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4865	LSB-BSE1: LSBF Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4866	LSB-BSE1: LSBF Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4867	LSB-BSE1: LSBF Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4868	LSB-BSE1: LSBF Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4869	LSB-BSE1: LSBF Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B486A	LSB-BSE1: LSBF Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B486B	LSB-BSE1: LSBF Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B486C	LSB-BSE1: LSBF Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4950	LSB-BSE1: LSBF Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4951	LSB-BSE1: LSBF Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4953	LSB-BSE1: LSBF Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4954	LSB-BSE1: LSBF Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4964	LSB-BSE1: LSBF Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4965	LSB-BSE1: LSBF Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4966	LSB-BSE1: LSBF Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4967	LSB-BSE1: LSBF Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4968	LSB-BSE1: LSBF Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4969	LSB-BSE1: LSBF Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B496A	LSB-BSE1: LSBF Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B496B	LSB-BSE1: LSBF Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B496C	LSB-BSE1: LSBF Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4A50	LSB-BSE1: LSBF Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4A51	LSB-BSE1: LSBF Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4A53	LSB-BSE1: LSBF Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4A54	LSB-BSE1: LSBF Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4A64	LSB-BSE1: LSBF Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4A65	LSB-BSE1: LSBF Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4A66	LSB-BSE1: LSBF Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4A67	LSB-BSE1: LSBF Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4A68	LSB-BSE1: LSBF Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4A69	LSB-BSE1: LSBF Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B4A6A	LSB-BSE1: LSBF Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B4A6B	LSB-BSE1: LSBF Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B4A6C	LSB-BSE1: LSBF Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4B50	LSB-BSE1: LSBF Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4B51	LSB-BSE1: LSBF Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4B53	LSB-BSE1: LSBF Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4B54	LSB-BSE1: LSBF Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4B64	LSB-BSE1: LSBF Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4B65	LSB-BSE1: LSBF Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4B66	LSB-BSE1: LSBF Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4B67	LSB-BSE1: LSBF Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4B68	LSB-BSE1: LSBF Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4B69	LSB-BSE1: LSBF Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B4B6A	LSB-BSE1: LSBF Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B4B6B	LSB-BSE1: LSBF Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B4B6C	LSB-BSE1: LSBF Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4C50	LSB-BSE1: LSBF Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4C51	LSB-BSE1: LSBF Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4C53	LSB-BSE1: LSBF Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4C54	LSB-BSE1: LSBF Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4C64	LSB-BSE1: LSBF Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4C65	LSB-BSE1: LSBF Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4C66	LSB-BSE1: LSBF Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4C67	LSB-BSE1: LSBF Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4C68	LSB-BSE1: LSBF Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4C69	LSB-BSE1: LSBF Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B4C6A	LSB-BSE1: LSBF Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4C6B	LSB-BSE1: LSBF Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B4C6C	LSB-BSE1: LSBF Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4D50	LSB-BSE1: LSBF Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4D51	LSB-BSE1: LSBF Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4D53	LSB-BSE1: LSBF Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4D54	LSB-BSE1: LSBF Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4D64	LSB-BSE1: LSBF Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1
1B4D65	LSB-BSE1: LSBF Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4D66	LSB-BSE1: LSBF Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4D67	LSB-BSE1: LSBF Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4D68	LSB-BSE1: LSBF Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4D69	LSB-BSE1: LSBF Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B4D6A	LSB-BSE1: LSBF Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B4D6B	LSB-BSE1: LSBF Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B4D6C	LSB-BSE1: LSBF Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B4E50	LSB-BSE1: LSBF Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:10		E	2
1B4E51	LSB-BSE1: LSBF Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:10		E	2
1B4E53	LSB-BSE1: LSBF Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:10		E	1
1B4E54	LSB-BSE1: LSBF Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:10		E	2
1B4E64	LSB-BSE1: LSBF Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B4E65	LSB-BSE1: LSBF Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:10		E	2
1B4E66	LSB-BSE1: LSBF Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:10		E	2
1B4E67	LSB-BSE1: LSBF Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:10		E	1
1B4E68	LSB-BSE1: LSBF Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:10		E	1
1B4E69	LSB-BSE1: LSBF Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:10		E	1
1B4E6A	LSB-BSE1: LSBF Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:10		E	2
1B4E6B	LSB-BSE1: LSBF Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:10		E	2
1B4E6C	LSB-BSE1: LSBF Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:10		E	2
1B5052	LSB-BSE1: Control data transfer LSBF has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X5:10		E	0
1B5055	LSB-BSE1: Control data transfer LSBF Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B5056	LSB-BSE1: Control data transfer LSBF Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:10		E	2
1B5057	LSB-BSE1: Control data transfer LSBF has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X5:10		E	1
1B5058	LSB-BSE1: Control data transfer LSBF recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X5:10		E	0
1B5059	LSB-BSE1: Control data transfer LSBF recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X5:10		E	0
1B5060	LSB-BSE1: Control data transfer LSBF driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361.X5:10		E	2
1B5061	LSB-BSE1: Control data transfer LSBF driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361.X5:10		E	2
1B5062	LSB-BSE1: Control data transfer LSBF Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X5:10		E	2
1B6050	LSB-BSE1: LSBG Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6051	LSB-BSE1: LSBG Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6053	LSB-BSE1: LSBG Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6054	LSB-BSE1: LSBG Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6064	LSB-BSE1: LSBG Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6065	LSB-BSE1: LSBG Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6066	LSB-BSE1: LSBG Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6067	LSB-BSE1: LSBG Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6068	LSB-BSE1: LSBG Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6069	LSB-BSE1: LSBG Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B606A	LSB-BSE1: LSBG Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B606B	LSB-BSE1: LSBG Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B606C	LSB-BSE1: LSBG Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6150	LSB-BSE1: LSBG Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6151	LSB-BSE1: LSBG Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6153	LSB-BSE1: LSBG Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6154	LSB-BSE1: LSBG Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6164	LSB-BSE1: LSBG Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6165	LSB-BSE1: LSBG Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6166	LSB-BSE1: LSBG Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6167	LSB-BSE1: LSBG Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6168	LSB-BSE1: LSBG Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6169	LSB-BSE1: LSBG Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B616A	LSB-BSE1: LSBG Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B616B	LSB-BSE1: LSBG Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B616C	LSB-BSE1: LSBG Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6250	LSB-BSE1: LSBG Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6251	LSB-BSE1: LSBG Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6253	LSB-BSE1: LSBG Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6254	LSB-BSE1: LSBG Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6264	LSB-BSE1: LSBG Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6265	LSB-BSE1: LSBG Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6266	LSB-BSE1: LSBG Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6267	LSB-BSE1: LSBG Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6268	LSB-BSE1: LSBG Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6269	LSB-BSE1: LSBG Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B626A	LSB-BSE1: LSBG Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B626B	LSB-BSE1: LSBG Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B626C	LSB-BSE1: LSBG Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6350	LSB-BSE1: LSBG Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6351	LSB-BSE1: LSBG Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6353	LSB-BSE1: LSBG Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6354	LSB-BSE1: LSBG Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6364	LSB-BSE1: LSBG Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6365	LSB-BSE1: LSBG Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6366	LSB-BSE1: LSBG Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6367	LSB-BSE1: LSBG Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6368	LSB-BSE1: LSBG Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6369	LSB-BSE1: LSBG Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B636A	LSB-BSE1: LSBG Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B636B	LSB-BSE1: LSBG Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B636C	LSB-BSE1: LSBG Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6450	LSB-BSE1: LSBG Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6451	LSB-BSE1: LSBG Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6453	LSB-BSE1: LSBG Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6454	LSB-BSE1: LSBG Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6464	LSB-BSE1: LSBG Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6465	LSB-BSE1: LSBG Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6466	LSB-BSE1: LSBG Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6467	LSB-BSE1: LSBG Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6468	LSB-BSE1: LSBG Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6469	LSB-BSE1: LSBG Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B646A	LSB-BSE1: LSBG Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B646B	LSB-BSE1: LSBG Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B646C	LSB-BSE1: LSBG Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6550	LSB-BSE1: LSBG Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6551	LSB-BSE1: LSBG Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6553	LSB-BSE1: LSBG Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6554	LSB-BSE1: LSBG Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6564	LSB-BSE1: LSBG Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6565	LSB-BSE1: LSBG Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6566	LSB-BSE1: LSBG Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6567	LSB-BSE1: LSBG Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6568	LSB-BSE1: LSBG Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6569	LSB-BSE1: LSBG Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B656A	LSB-BSE1: LSBG Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B656B	LSB-BSE1: LSBG Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B656C	LSB-BSE1: LSBG Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6650	LSB-BSE1: LSBG Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6651	LSB-BSE1: LSBG Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6653	LSB-BSE1: LSBG Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6654	LSB-BSE1: LSBG Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6664	LSB-BSE1: LSBG Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6665	LSB-BSE1: LSBG Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6666	LSB-BSE1: LSBG Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6667	LSB-BSE1: LSBG Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6668	LSB-BSE1: LSBG Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6669	LSB-BSE1: LSBG Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B666A	LSB-BSE1: LSBG Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B666B	LSB-BSE1: LSBG Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B666C	LSB-BSE1: LSBG Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6750	LSB-BSE1: LSBG Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6751	LSB-BSE1: LSBG Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6753	LSB-BSE1: LSBG Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6754	LSB-BSE1: LSBG Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6764	LSB-BSE1: LSBG Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6765	LSB-BSE1: LSBG Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6766	LSB-BSE1: LSBG Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6767	LSB-BSE1: LSBG Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6768	LSB-BSE1: LSBG Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6769	LSB-BSE1: LSBG Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B676A	LSB-BSE1: LSBG Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B676B	LSB-BSE1: LSBG Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B676C	LSB-BSE1: LSBG Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6B50	LSB-BSE1: LSBG Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6B51	LSB-BSE1: LSBG Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6B53	LSB-BSE1: LSBG Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6B54	LSB-BSE1: LSBG Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6B64	LSB-BSE1: LSBG Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6B65	LSB-BSE1: LSBG Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6B66	LSB-BSE1: LSBG Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6B67	LSB-BSE1: LSBG Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6B68	LSB-BSE1: LSBG Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6B69	LSB-BSE1: LSBG Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B6B6A	LSB-BSE1: LSBG Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B6B6B	LSB-BSE1: LSBG Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B6B6C	LSB-BSE1: LSBG Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6C50	LSB-BSE1: LSBG Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6C51	LSB-BSE1: LSBG Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6C53	LSB-BSE1: LSBG Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6C54	LSB-BSE1: LSBG Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6C64	LSB-BSE1: LSBG Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6C65	LSB-BSE1: LSBG Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6C66	LSB-BSE1: LSBG Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6C67	LSB-BSE1: LSBG Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6C68	LSB-BSE1: LSBG Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6C69	LSB-BSE1: LSBG Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B6C6A	LSB-BSE1: LSBG Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B6C6B	LSB-BSE1: LSBG Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B6C6C	LSB-BSE1: LSBG Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6D50	LSB-BSE1: LSBG Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6D51	LSB-BSE1: LSBG Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6D53	LSB-BSE1: LSBG Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6D54	LSB-BSE1: LSBG Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6D64	LSB-BSE1: LSBG Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6D65	LSB-BSE1: LSBG Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6D66	LSB-BSE1: LSBG Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6D67	LSB-BSE1: LSBG Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6D68	LSB-BSE1: LSBG Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6D69	LSB-BSE1: LSBG Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B6D6A	LSB-BSE1: LSBG Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B6D6B	LSB-BSE1: LSBG Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B6D6C	LSB-BSE1: LSBG Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6E50	LSB-BSE1: LSBG Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6E51	LSB-BSE1: LSBG Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6E53	LSB-BSE1: LSBG Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6E54	LSB-BSE1: LSBG Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6E64	LSB-BSE1: LSBG Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6E65	LSB-BSE1: LSBG Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6E66	LSB-BSE1: LSBG Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B6E67	LSB-BSE1: LSBG Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6E68	LSB-BSE1: LSBG Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6E69	LSB-BSE1: LSBG Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6E6A	LSB-BSE1: LSBG Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B6E6B	LSB-BSE1: LSBG Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B6E6C	LSB-BSE1: LSBG Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B6F50	LSB-BSE1: LSBG Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B6F51	LSB-BSE1: LSBG Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B6F53	LSB-BSE1: LSBG Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B6F54	LSB-BSE1: LSBG Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B6F64	LSB-BSE1: LSBG Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B6F65	LSB-BSE1: LSBG Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B6F66	LSB-BSE1: LSBG Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B6F67	LSB-BSE1: LSBG Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B6F68	LSB-BSE1: LSBG Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B6F69	LSB-BSE1: LSBG Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B6F6A	LSB-BSE1: LSBG Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B6F6B	LSB-BSE1: LSBG Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B6F6C	LSB-BSE1: LSBG Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7050	LSB-BSE1: LSBG Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7051	LSB-BSE1: LSBG Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7053	LSB-BSE1: LSBG Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7054	LSB-BSE1: LSBG Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7064	LSB-BSE1: LSBG Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7065	LSB-BSE1: LSBG Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7066	LSB-BSE1: LSBG Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7067	LSB-BSE1: LSBG Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7068	LSB-BSE1: LSBG Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7069	LSB-BSE1: LSBG Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B706A	LSB-BSE1: LSBG Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B706B	LSB-BSE1: LSBG Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B706C	LSB-BSE1: LSBG Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7150	LSB-BSE1: LSBG Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7151	LSB-BSE1: LSBG Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7153	LSB-BSE1: LSBG Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7154	LSB-BSE1: LSBG Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7164	LSB-BSE1: LSBG Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7165	LSB-BSE1: LSBG Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7166	LSB-BSE1: LSBG Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7167	LSB-BSE1: LSBG Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7168	LSB-BSE1: LSBG Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7169	LSB-BSE1: LSBG Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B716A	LSB-BSE1: LSBG Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B716B	LSB-BSE1: LSBG Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B716C	LSB-BSE1: LSBG Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7250	LSB-BSE1: LSBG Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7251	LSB-BSE1: LSBG Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7253	LSB-BSE1: LSBG Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7254	LSB-BSE1: LSBG Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7264	LSB-BSE1: LSBG Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7265	LSB-BSE1: LSBG Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7266	LSB-BSE1: LSBG Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7267	LSB-BSE1: LSBG Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7268	LSB-BSE1: LSBG Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7269	LSB-BSE1: LSBG Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B726A	LSB-BSE1: LSBG Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B726B	LSB-BSE1: LSBG Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B726C	LSB-BSE1: LSBG Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7350	LSB-BSE1: LSBG Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7351	LSB-BSE1: LSBG Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7353	LSB-BSE1: LSBG Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7354	LSB-BSE1: LSBG Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7364	LSB-BSE1: LSBG Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7365	LSB-BSE1: LSBG Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7366	LSB-BSE1: LSBG Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7367	LSB-BSE1: LSBG Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7368	LSB-BSE1: LSBG Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7369	LSB-BSE1: LSBG Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B736A	LSB-BSE1: LSBG Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B736B	LSB-BSE1: LSBG Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B736C	LSB-BSE1: LSBG Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7450	LSB-BSE1: LSBG Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7451	LSB-BSE1: LSBG Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7453	LSB-BSE1: LSBG Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7454	LSB-BSE1: LSBG Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7464	LSB-BSE1: LSBG Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7465	LSB-BSE1: LSBG Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7466	LSB-BSE1: LSBG Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7467	LSB-BSE1: LSBG Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7468	LSB-BSE1: LSBG Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7469	LSB-BSE1: LSBG Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B746A	LSB-BSE1: LSBG Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B746B	LSB-BSE1: LSBG Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B746C	LSB-BSE1: LSBG Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7650	LSB-BSE1: LSBG Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7651	LSB-BSE1: LSBG Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7653	LSB-BSE1: LSBG Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7654	LSB-BSE1: LSBG Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7664	LSB-BSE1: LSBG Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7665	LSB-BSE1: LSBG Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7666	LSB-BSE1: LSBG Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7667	LSB-BSE1: LSBG Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7668	LSB-BSE1: LSBG Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7669	LSB-BSE1: LSBG Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B766A	LSB-BSE1: LSBG Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B766B	LSB-BSE1: LSBG Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B766C	LSB-BSE1: LSBG Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7750	LSB-BSE1: LSBG Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7751	LSB-BSE1: LSBG Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7753	LSB-BSE1: LSBG Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7754	LSB-BSE1: LSBG Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7764	LSB-BSE1: LSBG Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7765	LSB-BSE1: LSBG Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7766	LSB-BSE1: LSBG Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7767	LSB-BSE1: LSBG Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7768	LSB-BSE1: LSBG Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7769	LSB-BSE1: LSBG Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B776A	LSB-BSE1: LSBG Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B776B	LSB-BSE1: LSBG Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B776C	LSB-BSE1: LSBG Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7A50	LSB-BSE1: LSBG Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7A51	LSB-BSE1: LSBG Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7A53	LSB-BSE1: LSBG Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7A54	LSB-BSE1: LSBG Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7A64	LSB-BSE1: LSBG Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7A65	LSB-BSE1: LSBG Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7A66	LSB-BSE1: LSBG Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7A67	LSB-BSE1: LSBG Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7A68	LSB-BSE1: LSBG Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7A69	LSB-BSE1: LSBG Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B7A6A	LSB-BSE1: LSBG Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B7A6B	LSB-BSE1: LSBG Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B7A6C	LSB-BSE1: LSBG Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7B50	LSB-BSE1: LSBG Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7B51	LSB-BSE1: LSBG Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7B53	LSB-BSE1: LSBG Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7B54	LSB-BSE1: LSBG Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7B64	LSB-BSE1: LSBG Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7B65	LSB-BSE1: LSBG Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7B66	LSB-BSE1: LSBG Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7B67	LSB-BSE1: LSBG Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7B68	LSB-BSE1: LSBG Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7B69	LSB-BSE1: LSBG Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7B6A	LSB-BSE1: LSBG Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B7B6B	LSB-BSE1: LSBG Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B7B6C	LSB-BSE1: LSBG Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7C50	LSB-BSE1: LSBG Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7C51	LSB-BSE1: LSBG Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7C53	LSB-BSE1: LSBG Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7C54	LSB-BSE1: LSBG Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2
1B7C64	LSB-BSE1: LSBG Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7C65	LSB-BSE1: LSBG Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7C66	LSB-BSE1: LSBG Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7C67	LSB-BSE1: LSBG Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7C68	LSB-BSE1: LSBG Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7C69	LSB-BSE1: LSBG Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B7C6A	LSB-BSE1: LSBG Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B7C6B	LSB-BSE1: LSBG Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B7C6C	LSB-BSE1: LSBG Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B7D50	LSB-BSE1: LSBG Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:11		E	2
1B7D51	LSB-BSE1: LSBG Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:11		E	2
1B7D53	LSB-BSE1: LSBG Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:11		E	1
1B7D54	LSB-BSE1: LSBG Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B7D64	LSB-BSE1: LSBG Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:11		E	1
1B7D65	LSB-BSE1: LSBG Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:11		E	2
1B7D66	LSB-BSE1: LSBG Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:11		E	2
1B7D67	LSB-BSE1: LSBG Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:11		E	1
1B7D68	LSB-BSE1: LSBG Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:11		E	1
1B7D69	LSB-BSE1: LSBG Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:11		E	1
1B7D6A	LSB-BSE1: LSBG Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:11		E	2
1B7D6B	LSB-BSE1: LSBG Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:11		E	2
1B7D6C	LSB-BSE1: LSBG Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:11		E	2
1B8052	LSB-BSE1: Control data transfer LSBG has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X5:11		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B8055	LSB-BSE1: Control data transfer LSBG Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:11		E	2
1B8056	LSB-BSE1: Control data transfer LSBG Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:11		E	2
1B8057	LSB-BSE1: Control data transfer LSBG has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X5:11		E	1
1B8058	LSB-BSE1: Control data transfer LSBG recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X5:11		E	0
1B8059	LSB-BSE1: Control data transfer LSBG recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X5:11		E	0
1B8060	LSB-BSE1: Control data transfer LSBG driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361.X5:11		E	2
1B8061	LSB-BSE1: Control data transfer LSBG driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361.X5:11		E	2
1B8062	LSB-BSE1: Control data transfer LSBG Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X5:11		E	2
1B9050	LSB-BSE1: LSBH Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9051	LSB-BSE1: LSBH Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9053	LSB-BSE1: LSBH Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9054	LSB-BSE1: LSBH Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9064	LSB-BSE1: LSBH Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9065	LSB-BSE1: LSBH Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9066	LSB-BSE1: LSBH Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9067	LSB-BSE1: LSBH Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9068	LSB-BSE1: LSBH Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9069	LSB-BSE1: LSBH Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B906A	LSB-BSE1: LSBH Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B906B	LSB-BSE1: LSBH Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B906C	LSB-BSE1: LSBH Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9150	LSB-BSE1: LSBH Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9151	LSB-BSE1: LSBH Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9153	LSB-BSE1: LSBH Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9154	LSB-BSE1: LSBH Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9164	LSB-BSE1: LSBH Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9165	LSB-BSE1: LSBH Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9166	LSB-BSE1: LSBH Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9167	LSB-BSE1: LSBH Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9168	LSB-BSE1: LSBH Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9169	LSB-BSE1: LSBH Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B916A	LSB-BSE1: LSBH Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B916B	LSB-BSE1: LSBH Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B916C	LSB-BSE1: LSBH Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9350	LSB-BSE1: LSBH Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9351	LSB-BSE1: LSBH Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9353	LSB-BSE1: LSBH Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9354	LSB-BSE1: LSBH Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9364	LSB-BSE1: LSBH Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9365	LSB-BSE1: LSBH Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9366	LSB-BSE1: LSBH Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9367	LSB-BSE1: LSBH Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9368	LSB-BSE1: LSBH Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9369	LSB-BSE1: LSBH Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B936A	LSB-BSE1: LSBH Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B936B	LSB-BSE1: LSBH Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B936C	LSB-BSE1: LSBH Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9450	LSB-BSE1: LSBH Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9451	LSB-BSE1: LSBH Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9453	LSB-BSE1: LSBH Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9454	LSB-BSE1: LSBH Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9464	LSB-BSE1: LSBH Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9465	LSB-BSE1: LSBH Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9466	LSB-BSE1: LSBH Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9467	LSB-BSE1: LSBH Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9468	LSB-BSE1: LSBH Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9469	LSB-BSE1: LSBH Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B946A	LSB-BSE1: LSBH Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B946B	LSB-BSE1: LSBH Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B946C	LSB-BSE1: LSBH Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9550	LSB-BSE1: LSBH Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9551	LSB-BSE1: LSBH Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9553	LSB-BSE1: LSBH Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9554	LSB-BSE1: LSBH Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9564	LSB-BSE1: LSBH Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9565	LSB-BSE1: LSBH Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9566	LSB-BSE1: LSBH Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9567	LSB-BSE1: LSBH Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9568	LSB-BSE1: LSBH Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9569	LSB-BSE1: LSBH Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B956A	LSB-BSE1: LSBH Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B956B	LSB-BSE1: LSBH Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B956C	LSB-BSE1: LSBH Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9650	LSB-BSE1: LSBH Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9651	LSB-BSE1: LSBH Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9653	LSB-BSE1: LSBH Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9654	LSB-BSE1: LSBH Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9664	LSB-BSE1: LSBH Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9665	LSB-BSE1: LSBH Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9666	LSB-BSE1: LSBH Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9667	LSB-BSE1: LSBH Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9668	LSB-BSE1: LSBH Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9669	LSB-BSE1: LSBH Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B966A	LSB-BSE1: LSBH Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B966B	LSB-BSE1: LSBH Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B966C	LSB-BSE1: LSBH Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9750	LSB-BSE1: LSBH Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9751	LSB-BSE1: LSBH Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9753	LSB-BSE1: LSBH Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9754	LSB-BSE1: LSBH Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9764	LSB-BSE1: LSBH Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9765	LSB-BSE1: LSBH Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9766	LSB-BSE1: LSBH Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9767	LSB-BSE1: LSBH Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9768	LSB-BSE1: LSBH Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9769	LSB-BSE1: LSBH Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B976A	LSB-BSE1: LSBH Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B976B	LSB-BSE1: LSBH Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B976C	LSB-BSE1: LSBH Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9850	LSB-BSE1: LSBH Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9851	LSB-BSE1: LSBH Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9853	LSB-BSE1: LSBH Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9854	LSB-BSE1: LSBH Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9864	LSB-BSE1: LSBH Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9865	LSB-BSE1: LSBH Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9866	LSB-BSE1: LSBH Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9867	LSB-BSE1: LSBH Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9868	LSB-BSE1: LSBH Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9869	LSB-BSE1: LSBH Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B986A	LSB-BSE1: LSBH Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B986B	LSB-BSE1: LSBH Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B986C	LSB-BSE1: LSBH Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9950	LSB-BSE1: LSBH Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9951	LSB-BSE1: LSBH Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9953	LSB-BSE1: LSBH Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9954	LSB-BSE1: LSBH Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9964	LSB-BSE1: LSBH Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9965	LSB-BSE1: LSBH Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9966	LSB-BSE1: LSBH Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9967	LSB-BSE1: LSBH Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9968	LSB-BSE1: LSBH Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9969	LSB-BSE1: LSBH Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B996A	LSB-BSE1: LSBH Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B996B	LSB-BSE1: LSBH Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B996C	LSB-BSE1: LSBH Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9A50	LSB-BSE1: LSBH Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9A51	LSB-BSE1: LSBH Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9A53	LSB-BSE1: LSBH Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9A54	LSB-BSE1: LSBH Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9A64	LSB-BSE1: LSBH Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9A65	LSB-BSE1: LSBH Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9A66	LSB-BSE1: LSBH Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9A67	LSB-BSE1: LSBH Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9A68	LSB-BSE1: LSBH Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9A69	LSB-BSE1: LSBH Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B9A6A	LSB-BSE1: LSBH Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B9A6B	LSB-BSE1: LSBH Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B9A6C	LSB-BSE1: LSBH Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9B50	LSB-BSE1: LSBH Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9B51	LSB-BSE1: LSBH Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9B53	LSB-BSE1: LSBH Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9B54	LSB-BSE1: LSBH Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9B64	LSB-BSE1: LSBH Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9B65	LSB-BSE1: LSBH Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9B66	LSB-BSE1: LSBH Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9B67	LSB-BSE1: LSBH Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9B68	LSB-BSE1: LSBH Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9B69	LSB-BSE1: LSBH Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B9B6A	LSB-BSE1: LSBH Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B9B6B	LSB-BSE1: LSBH Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9B6C	LSB-BSE1: LSBH Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9C50	LSB-BSE1: LSBH Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9C51	LSB-BSE1: LSBH Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9C53	LSB-BSE1: LSBH Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9C54	LSB-BSE1: LSBH Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9C64	LSB-BSE1: LSBH Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9C65	LSB-BSE1: LSBH Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9C66	LSB-BSE1: LSBH Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9C67	LSB-BSE1: LSBH Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9C68	LSB-BSE1: LSBH Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9C69	LSB-BSE1: LSBH Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B9C6A	LSB-BSE1: LSBH Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B9C6B	LSB-BSE1: LSBH Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B9C6C	LSB-BSE1: LSBH Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9D50	LSB-BSE1: LSBH Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9D51	LSB-BSE1: LSBH Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9D53	LSB-BSE1: LSBH Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9D54	LSB-BSE1: LSBH Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9D64	LSB-BSE1: LSBH Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9D65	LSB-BSE1: LSBH Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9D66	LSB-BSE1: LSBH Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9D67	LSB-BSE1: LSBH Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9D68	LSB-BSE1: LSBH Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9D69	LSB-BSE1: LSBH Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B9D6A	LSB-BSE1: LSBH Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B9D6B	LSB-BSE1: LSBH Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B9D6C	LSB-BSE1: LSBH Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1B9E50	LSB-BSE1: LSBH Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9E51	LSB-BSE1: LSBH Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9E53	LSB-BSE1: LSBH Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9E54	LSB-BSE1: LSBH Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9E64	LSB-BSE1: LSBH Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9E65	LSB-BSE1: LSBH Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9E66	LSB-BSE1: LSBH Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9E67	LSB-BSE1: LSBH Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9E68	LSB-BSE1: LSBH Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9E69	LSB-BSE1: LSBH Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1B9E6A	LSB-BSE1: LSBH Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B9E6B	LSB-BSE1: LSBH Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B9E6C	LSB-BSE1: LSBH Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9F50	LSB-BSE1: LSBH Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1B9F51	LSB-BSE1: LSBH Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1B9F53	LSB-BSE1: LSBH Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1B9F54	LSB-BSE1: LSBH Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1B9F64	LSB-BSE1: LSBH Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1B9F65	LSB-BSE1: LSBH Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1B9F66	LSB-BSE1: LSBH Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1B9F67	LSB-BSE1: LSBH Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1B9F68	LSB-BSE1: LSBH Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1B9F69	LSB-BSE1: LSBH Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1B9F6A	LSB-BSE1: LSBH Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1B9F6B	LSB-BSE1: LSBH Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1B9F6C	LSB-BSE1: LSBH Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA050	LSB-BSE1: LSBH Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BA051	LSB-BSE1: LSBH Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BA053	LSB-BSE1: LSBH Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BA054	LSB-BSE1: LSBH Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BA064	LSB-BSE1: LSBH Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BA065	LSB-BSE1: LSBH Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BA066	LSB-BSE1: LSBH Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA067	LSB-BSE1: LSBH Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BA068	LSB-BSE1: LSBH Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BA069	LSB-BSE1: LSBH Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA06A	LSB-BSE1: LSBH Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BA06B	LSB-BSE1: LSBH Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BA06C	LSB-BSE1: LSBH Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA150	LSB-BSE1: LSBH Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BA151	LSB-BSE1: LSBH Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BA153	LSB-BSE1: LSBH Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BA154	LSB-BSE1: LSBH Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA164	LSB-BSE1: LSBH Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BA165	LSB-BSE1: LSBH Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BA166	LSB-BSE1: LSBH Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BA167	LSB-BSE1: LSBH Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BA168	LSB-BSE1: LSBH Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BA169	LSB-BSE1: LSBH Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA16A	LSB-BSE1: LSBH Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BA16B	LSB-BSE1: LSBH Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BA16C	LSB-BSE1: LSBH Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA250	LSB-BSE1: LSBH Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA251	LSB-BSE1: LSBH Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BA253	LSB-BSE1: LSBH Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BA254	LSB-BSE1: LSBH Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BA264	LSB-BSE1: LSBH Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BA265	LSB-BSE1: LSBH Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BA266	LSB-BSE1: LSBH Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BA267	LSB-BSE1: LSBH Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BA268	LSB-BSE1: LSBH Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BA269	LSB-BSE1: LSBH Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA26A	LSB-BSE1: LSBH Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA26B	LSB-BSE1: LSBH Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BA26C	LSB-BSE1: LSBH Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA350	LSB-BSE1: LSBH Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BA351	LSB-BSE1: LSBH Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BA353	LSB-BSE1: LSBH Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BA354	LSB-BSE1: LSBH Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BA364	LSB-BSE1: LSBH Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BA365	LSB-BSE1: LSBH Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BA366	LSB-BSE1: LSBH Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BA367	LSB-BSE1: LSBH Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA368	LSB-BSE1: LSBH Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BA369	LSB-BSE1: LSBH Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA36A	LSB-BSE1: LSBH Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BA36B	LSB-BSE1: LSBH Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BA36C	LSB-BSE1: LSBH Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA450	LSB-BSE1: LSBH Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BA451	LSB-BSE1: LSBH Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BA453	LSB-BSE1: LSBH Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BA454	LSB-BSE1: LSBH Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BA464	LSB-BSE1: LSBH Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA465	LSB-BSE1: LSBH Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BA466	LSB-BSE1: LSBH Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BA467	LSB-BSE1: LSBH Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BA468	LSB-BSE1: LSBH Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BA469	LSB-BSE1: LSBH Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA46A	LSB-BSE1: LSBH Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BA46B	LSB-BSE1: LSBH Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BA46C	LSB-BSE1: LSBH Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA550	LSB-BSE1: LSBH Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BA551	LSB-BSE1: LSBH Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA553	LSB-BSE1: LSBH Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BA554	LSB-BSE1: LSBH Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BA564	LSB-BSE1: LSBH Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BA565	LSB-BSE1: LSBH Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BA566	LSB-BSE1: LSBH Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BA567	LSB-BSE1: LSBH Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BA568	LSB-BSE1: LSBH Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BA569	LSB-BSE1: LSBH Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA56A	LSB-BSE1: LSBH Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BA56B	LSB-BSE1: LSBH Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA56C	LSB-BSE1: LSBH Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA650	LSB-BSE1: LSBH Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BA651	LSB-BSE1: LSBH Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BA653	LSB-BSE1: LSBH Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BA654	LSB-BSE1: LSBH Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BA664	LSB-BSE1: LSBH Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BA665	LSB-BSE1: LSBH Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BA666	LSB-BSE1: LSBH Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BA667	LSB-BSE1: LSBH Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BA668	LSB-BSE1: LSBH Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA669	LSB-BSE1: LSBH Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA66A	LSB-BSE1: LSBH Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BA66B	LSB-BSE1: LSBH Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BA66C	LSB-BSE1: LSBH Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA750	LSB-BSE1: LSBH Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BA751	LSB-BSE1: LSBH Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BA753	LSB-BSE1: LSBH Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BA754	LSB-BSE1: LSBH Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BA764	LSB-BSE1: LSBH Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BA765	LSB-BSE1: LSBH Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA766	LSB-BSE1: LSBH Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BA767	LSB-BSE1: LSBH Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BA768	LSB-BSE1: LSBH Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BA769	LSB-BSE1: LSBH Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA76A	LSB-BSE1: LSBH Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BA76B	LSB-BSE1: LSBH Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BA76C	LSB-BSE1: LSBH Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BA850	LSB-BSE1: LSBH Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BA851	LSB-BSE1: LSBH Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BA853	LSB-BSE1: LSBH Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BA854	LSB-BSE1: LSBH Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BA864	LSB-BSE1: LSBH Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BA865	LSB-BSE1: LSBH Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BA866	LSB-BSE1: LSBH Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BA867	LSB-BSE1: LSBH Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BA868	LSB-BSE1: LSBH Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BA869	LSB-BSE1: LSBH Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BA86A	LSB-BSE1: LSBH Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BA86B	LSB-BSE1: LSBH Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BA86C	LSB-BSE1: LSBH Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BAA50	LSB-BSE1: LSBH Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BAA51	LSB-BSE1: LSBH Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BAA53	LSB-BSE1: LSBH Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BAA54	LSB-BSE1: LSBH Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BAA64	LSB-BSE1: LSBH Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BAA65	LSB-BSE1: LSBH Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BAA66	LSB-BSE1: LSBH Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BAA67	LSB-BSE1: LSBH Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BAA68	LSB-BSE1: LSBH Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BAA69	LSB-BSE1: LSBH Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BAA6A	LSB-BSE1: LSBH Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BAA6B	LSB-BSE1: LSBH Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BAA6C	LSB-BSE1: LSBH Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BAB50	LSB-BSE1: LSBH Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BAB51	LSB-BSE1: LSBH Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BAB53	LSB-BSE1: LSBH Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BAB54	LSB-BSE1: LSBH Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BAB64	LSB-BSE1: LSBH Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BAB65	LSB-BSE1: LSBH Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BAB66	LSB-BSE1: LSBH Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BAB67	LSB-BSE1: LSBH Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BAB68	LSB-BSE1: LSBH Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BAB69	LSB-BSE1: LSBH Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BAB6A	LSB-BSE1: LSBH Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BAB6B	LSB-BSE1: LSBH Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BAB6C	LSB-BSE1: LSBH Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BAC50	LSB-BSE1: LSBH Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BAC51	LSB-BSE1: LSBH Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BAC53	LSB-BSE1: LSBH Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BAC54	LSB-BSE1: LSBH Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BAC64	LSB-BSE1: LSBH Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BAC65	LSB-BSE1: LSBH Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BAC66	LSB-BSE1: LSBH Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BAC67	LSB-BSE1: LSBH Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BAC68	LSB-BSE1: LSBH Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BAC69	LSB-BSE1: LSBH Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BAC6A	LSB-BSE1: LSBH Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BAC6B	LSB-BSE1: LSBH Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BAC6C	LSB-BSE1: LSBH Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BAD50	LSB-BSE1: LSBH Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BAD51	LSB-BSE1: LSBH Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BAD53	LSB-BSE1: LSBH Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BAD54	LSB-BSE1: LSBH Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BAD64	LSB-BSE1: LSBH Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BAD65	LSB-BSE1: LSBH Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BAD66	LSB-BSE1: LSBH Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BAD67	LSB-BSE1: LSBH Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1
1BAD68	LSB-BSE1: LSBH Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BAD69	LSB-BSE1: LSBH Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BAD6A	LSB-BSE1: LSBH Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BAD6B	LSB-BSE1: LSBH Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BAD6C	LSB-BSE1: LSBH Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BAE50	LSB-BSE1: LSBH Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361.X5:12		E	2
1BAE51	LSB-BSE1: LSBH Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361.X5:12		E	2
1BAE53	LSB-BSE1: LSBH Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361.X5:12		E	1
1BAE54	LSB-BSE1: LSBH Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361.X5:12		E	2
1BAE64	LSB-BSE1: LSBH Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361.X5:12		E	1
1BAE65	LSB-BSE1: LSBH Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361.X5:12		E	2
1BAE66	LSB-BSE1: LSBH Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361.X5:12		E	2
1BAE67	LSB-BSE1: LSBH Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BAE68	LSB-BSE1: LSBH Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361.X5:12		E	1
1BAE69	LSB-BSE1: LSBH Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361.X5:12		E	1
1BAE6A	LSB-BSE1: LSBH Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361.X5:12		E	2
1BAE6B	LSB-BSE1: LSBH Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361.X5:12		E	2
1BAE6C	LSB-BSE1: LSBH Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361.X5:12		E	2
1BB052	LSB-BSE1: Control data transfer LSBH has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361.X5:12		E	0
1BB055	LSB-BSE1: Control data transfer LSBH Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:12		E	2
1BB056	LSB-BSE1: Control data transfer LSBH Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361.X5:12		E	2
1BB057	LSB-BSE1: Control data transfer LSBH has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361.X5:12		E	1
1BB058	LSB-BSE1: Control data transfer LSBH recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361.X5:12		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1BB059	LSB-BSE1: Control data transfer LSBH recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361.X5:12		E	0
1BB060	LSB-BSE1: Control data transfer LSBH driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361.X5:12		E	2
1BB061	LSB-BSE1: Control data transfer LSBH driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361.X5:12		E	2
1BB062	LSB-BSE1: Control data transfer LSBH Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361.X5:12		E	2
1C0050	LSB-BSE1: LSBJ Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0051	LSB-BSE1: LSBJ Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0053	LSB-BSE1: LSBJ Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0054	LSB-BSE1: LSBJ Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0064	LSB-BSE1: LSBJ Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0065	LSB-BSE1: LSBJ Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0066	LSB-BSE1: LSBJ Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0067	LSB-BSE1: LSBJ Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0068	LSB-BSE1: LSBJ Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0069	LSB-BSE1: LSBJ Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C006A	LSB-BSE1: LSBJ Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C006B	LSB-BSE1: LSBJ Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C006C	LSB-BSE1: LSBJ Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0150	LSB-BSE1: LSBJ Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0151	LSB-BSE1: LSBJ Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0153	LSB-BSE1: LSBJ Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0154	LSB-BSE1: LSBJ Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0164	LSB-BSE1: LSBJ Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0165	LSB-BSE1: LSBJ Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0166	LSB-BSE1: LSBJ Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0167	LSB-BSE1: LSBJ Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0168	LSB-BSE1: LSBJ Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0169	LSB-BSE1: LSBJ Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C016A	LSB-BSE1: LSBJ Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C016B	LSB-BSE1: LSBJ Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C016C	LSB-BSE1: LSBJ Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0350	LSB-BSE1: LSBJ Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0351	LSB-BSE1: LSBJ Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0353	LSB-BSE1: LSBJ Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0354	LSB-BSE1: LSBJ Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0364	LSB-BSE1: LSBJ Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0365	LSB-BSE1: LSBJ Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0366	LSB-BSE1: LSBJ Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0367	LSB-BSE1: LSBJ Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0368	LSB-BSE1: LSBJ Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0369	LSB-BSE1: LSBJ Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C036A	LSB-BSE1: LSBJ Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C036B	LSB-BSE1: LSBJ Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C036C	LSB-BSE1: LSBJ Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0450	LSB-BSE1: LSBJ Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0451	LSB-BSE1: LSBJ Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0453	LSB-BSE1: LSBJ Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0454	LSB-BSE1: LSBJ Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0464	LSB-BSE1: LSBJ Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0465	LSB-BSE1: LSBJ Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0466	LSB-BSE1: LSBJ Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0467	LSB-BSE1: LSBJ Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0468	LSB-BSE1: LSBJ Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0469	LSB-BSE1: LSBJ Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C046A	LSB-BSE1: LSBJ Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C046B	LSB-BSE1: LSBJ Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C046C	LSB-BSE1: LSBJ Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0550	LSB-BSE1: LSBJ Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0551	LSB-BSE1: LSBJ Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0553	LSB-BSE1: LSBJ Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0554	LSB-BSE1: LSBJ Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0564	LSB-BSE1: LSBJ Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0565	LSB-BSE1: LSBJ Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0566	LSB-BSE1: LSBJ Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0567	LSB-BSE1: LSBJ Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0568	LSB-BSE1: LSBJ Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0569	LSB-BSE1: LSBJ Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C056A	LSB-BSE1: LSBJ Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C056B	LSB-BSE1: LSBJ Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C056C	LSB-BSE1: LSBJ Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0650	LSB-BSE1: LSBJ Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0651	LSB-BSE1: LSBJ Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0653	LSB-BSE1: LSBJ Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0654	LSB-BSE1: LSBJ Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0664	LSB-BSE1: LSBJ Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0665	LSB-BSE1: LSBJ Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0666	LSB-BSE1: LSBJ Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0667	LSB-BSE1: LSBJ Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0668	LSB-BSE1: LSBJ Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0669	LSB-BSE1: LSBJ Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C066A	LSB-BSE1: LSBJ Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C066B	LSB-BSE1: LSBJ Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C066C	LSB-BSE1: LSBJ Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0750	LSB-BSE1: LSBJ Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0751	LSB-BSE1: LSBJ Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0753	LSB-BSE1: LSBJ Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0754	LSB-BSE1: LSBJ Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0764	LSB-BSE1: LSBJ Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0765	LSB-BSE1: LSBJ Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0766	LSB-BSE1: LSBJ Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0767	LSB-BSE1: LSBJ Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0768	LSB-BSE1: LSBJ Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0769	LSB-BSE1: LSBJ Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C076A	LSB-BSE1: LSBJ Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C076B	LSB-BSE1: LSBJ Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C076C	LSB-BSE1: LSBJ Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0850	LSB-BSE1: LSBJ Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0851	LSB-BSE1: LSBJ Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0853	LSB-BSE1: LSBJ Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0854	LSB-BSE1: LSBJ Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0864	LSB-BSE1: LSBJ Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0865	LSB-BSE1: LSBJ Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0866	LSB-BSE1: LSBJ Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0867	LSB-BSE1: LSBJ Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0868	LSB-BSE1: LSBJ Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0869	LSB-BSE1: LSBJ Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C086A	LSB-BSE1: LSBJ Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C086B	LSB-BSE1: LSBJ Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C086C	LSB-BSE1: LSBJ Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0950	LSB-BSE1: LSBJ Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0951	LSB-BSE1: LSBJ Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0953	LSB-BSE1: LSBJ Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0954	LSB-BSE1: LSBJ Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0964	LSB-BSE1: LSBJ Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0965	LSB-BSE1: LSBJ Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0966	LSB-BSE1: LSBJ Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0967	LSB-BSE1: LSBJ Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0968	LSB-BSE1: LSBJ Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0969	LSB-BSE1: LSBJ Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C096A	LSB-BSE1: LSBJ Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C096B	LSB-BSE1: LSBJ Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C096C	LSB-BSE1: LSBJ Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0A50	LSB-BSE1: LSBJ Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0A51	LSB-BSE1: LSBJ Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0A53	LSB-BSE1: LSBJ Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0A54	LSB-BSE1: LSBJ Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0A64	LSB-BSE1: LSBJ Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0A65	LSB-BSE1: LSBJ Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0A66	LSB-BSE1: LSBJ Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0A67	LSB-BSE1: LSBJ Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0A68	LSB-BSE1: LSBJ Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0A69	LSB-BSE1: LSBJ Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C0A6A	LSB-BSE1: LSBJ Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C0A6B	LSB-BSE1: LSBJ Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C0A6C	LSB-BSE1: LSBJ Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0B50	LSB-BSE1: LSBJ Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0B51	LSB-BSE1: LSBJ Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0B53	LSB-BSE1: LSBJ Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0B54	LSB-BSE1: LSBJ Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0B64	LSB-BSE1: LSBJ Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0B65	LSB-BSE1: LSBJ Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0B66	LSB-BSE1: LSBJ Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0B67	LSB-BSE1: LSBJ Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0B68	LSB-BSE1: LSBJ Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0B69	LSB-BSE1: LSBJ Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C0B6A	LSB-BSE1: LSBJ Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C0B6B	LSB-BSE1: LSBJ Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C0B6C	LSB-BSE1: LSBJ Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C0C50	LSB-BSE1: LSBJ Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0C51	LSB-BSE1: LSBJ Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0C53	LSB-BSE1: LSBJ Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0C54	LSB-BSE1: LSBJ Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0C64	LSB-BSE1: LSBJ Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0C65	LSB-BSE1: LSBJ Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0C66	LSB-BSE1: LSBJ Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0C67	LSB-BSE1: LSBJ Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0C68	LSB-BSE1: LSBJ Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0C69	LSB-BSE1: LSBJ Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C0C6A	LSB-BSE1: LSBJ Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C0C6B	LSB-BSE1: LSBJ Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C0C6C	LSB-BSE1: LSBJ Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0F50	LSB-BSE1: LSBJ Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C0F51	LSB-BSE1: LSBJ Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C0F53	LSB-BSE1: LSBJ Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C0F54	LSB-BSE1: LSBJ Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C0F64	LSB-BSE1: LSBJ Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C0F65	LSB-BSE1: LSBJ Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C0F66	LSB-BSE1: LSBJ Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C0F67	LSB-BSE1: LSBJ Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C0F68	LSB-BSE1: LSBJ Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C0F69	LSB-BSE1: LSBJ Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C0F6A	LSB-BSE1: LSBJ Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C0F6B	LSB-BSE1: LSBJ Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C0F6C	LSB-BSE1: LSBJ Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1050	LSB-BSE1: LSBJ Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1051	LSB-BSE1: LSBJ Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1053	LSB-BSE1: LSBJ Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1054	LSB-BSE1: LSBJ Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1064	LSB-BSE1: LSBJ Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1065	LSB-BSE1: LSBJ Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1066	LSB-BSE1: LSBJ Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1067	LSB-BSE1: LSBJ Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1068	LSB-BSE1: LSBJ Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1069	LSB-BSE1: LSBJ Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C106A	LSB-BSE1: LSBJ Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C106B	LSB-BSE1: LSBJ Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C106C	LSB-BSE1: LSBJ Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1150	LSB-BSE1: LSBJ Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1151	LSB-BSE1: LSBJ Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1153	LSB-BSE1: LSBJ Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1154	LSB-BSE1: LSBJ Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1164	LSB-BSE1: LSBJ Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1165	LSB-BSE1: LSBJ Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1166	LSB-BSE1: LSBJ Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1167	LSB-BSE1: LSBJ Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1168	LSB-BSE1: LSBJ Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1169	LSB-BSE1: LSBJ Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C116A	LSB-BSE1: LSBJ Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C116B	LSB-BSE1: LSBJ Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C116C	LSB-BSE1: LSBJ Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1250	LSB-BSE1: LSBJ Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1251	LSB-BSE1: LSBJ Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1253	LSB-BSE1: LSBJ Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1254	LSB-BSE1: LSBJ Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1264	LSB-BSE1: LSBJ Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1265	LSB-BSE1: LSBJ Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1266	LSB-BSE1: LSBJ Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1267	LSB-BSE1: LSBJ Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1268	LSB-BSE1: LSBJ Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1269	LSB-BSE1: LSBJ Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C126A	LSB-BSE1: LSBJ Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C126B	LSB-BSE1: LSBJ Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C126C	LSB-BSE1: LSBJ Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1350	LSB-BSE1: LSBJ Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1351	LSB-BSE1: LSBJ Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1353	LSB-BSE1: LSBJ Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1354	LSB-BSE1: LSBJ Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1364	LSB-BSE1: LSBJ Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1365	LSB-BSE1: LSBJ Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1366	LSB-BSE1: LSBJ Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1367	LSB-BSE1: LSBJ Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1368	LSB-BSE1: LSBJ Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1369	LSB-BSE1: LSBJ Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C136A	LSB-BSE1: LSBJ Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C136B	LSB-BSE1: LSBJ Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C136C	LSB-BSE1: LSBJ Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1450	LSB-BSE1: LSBJ Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1451	LSB-BSE1: LSBJ Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1453	LSB-BSE1: LSBJ Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1454	LSB-BSE1: LSBJ Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1464	LSB-BSE1: LSBJ Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1465	LSB-BSE1: LSBJ Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1466	LSB-BSE1: LSBJ Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1467	LSB-BSE1: LSBJ Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1468	LSB-BSE1: LSBJ Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1469	LSB-BSE1: LSBJ Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C146A	LSB-BSE1: LSBJ Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C146B	LSB-BSE1: LSBJ Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C146C	LSB-BSE1: LSBJ Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1550	LSB-BSE1: LSBJ Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1551	LSB-BSE1: LSBJ Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1553	LSB-BSE1: LSBJ Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1554	LSB-BSE1: LSBJ Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1564	LSB-BSE1: LSBJ Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1565	LSB-BSE1: LSBJ Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1566	LSB-BSE1: LSBJ Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1567	LSB-BSE1: LSBJ Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1568	LSB-BSE1: LSBJ Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1569	LSB-BSE1: LSBJ Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C156A	LSB-BSE1: LSBJ Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C156B	LSB-BSE1: LSBJ Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C156C	LSB-BSE1: LSBJ Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1650	LSB-BSE1: LSBJ Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1651	LSB-BSE1: LSBJ Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1653	LSB-BSE1: LSBJ Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1654	LSB-BSE1: LSBJ Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1664	LSB-BSE1: LSBJ Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1665	LSB-BSE1: LSBJ Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1666	LSB-BSE1: LSBJ Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1667	LSB-BSE1: LSBJ Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1668	LSB-BSE1: LSBJ Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1669	LSB-BSE1: LSBJ Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C166A	LSB-BSE1: LSBJ Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C166B	LSB-BSE1: LSBJ Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C166C	LSB-BSE1: LSBJ Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1750	LSB-BSE1: LSBJ Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1751	LSB-BSE1: LSBJ Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1753	LSB-BSE1: LSBJ Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1754	LSB-BSE1: LSBJ Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1764	LSB-BSE1: LSBJ Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1765	LSB-BSE1: LSBJ Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1766	LSB-BSE1: LSBJ Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1767	LSB-BSE1: LSBJ Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1768	LSB-BSE1: LSBJ Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1769	LSB-BSE1: LSBJ Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C176A	LSB-BSE1: LSBJ Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C176B	LSB-BSE1: LSBJ Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C176C	LSB-BSE1: LSBJ Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C1850	LSB-BSE1: LSBJ Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1851	LSB-BSE1: LSBJ Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1853	LSB-BSE1: LSBJ Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1854	LSB-BSE1: LSBJ Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1864	LSB-BSE1: LSBJ Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1865	LSB-BSE1: LSBJ Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1866	LSB-BSE1: LSBJ Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1867	LSB-BSE1: LSBJ Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1868	LSB-BSE1: LSBJ Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1869	LSB-BSE1: LSBJ Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C186A	LSB-BSE1: LSBJ Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C186B	LSB-BSE1: LSBJ Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C186C	LSB-BSE1: LSBJ Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1E50	LSB-BSE1: LSBJ Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C1E51	LSB-BSE1: LSBJ Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C1E53	LSB-BSE1: LSBJ Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C1E54	LSB-BSE1: LSBJ Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C1E64	LSB-BSE1: LSBJ Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C1E65	LSB-BSE1: LSBJ Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C1E66	LSB-BSE1: LSBJ Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C1E67	LSB-BSE1: LSBJ Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C1E68	LSB-BSE1: LSBJ Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C1E69	LSB-BSE1: LSBJ Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C1E6A	LSB-BSE1: LSBJ Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C1E6B	LSB-BSE1: LSBJ Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C1E6C	LSB-BSE1: LSBJ Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C2052	LSB-BSE1: Control data transfer LSBJ has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A361		E	0
1C2055	LSB-BSE1: Control data transfer LSBJ Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1C2056	LSB-BSE1: Control data transfer LSBJ Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A361		E	2
1C2057	LSB-BSE1: Control data transfer LSBJ has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A361		E	1
1C2058	LSB-BSE1: Control data transfer LSBJ recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A361		E	0
1C2059	LSB-BSE1: Control data transfer LSBJ recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A361		E	0
1C2060	LSB-BSE1: Control data transfer LSBJ driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C2061	LSB-BSE1: Control data transfer LSBJ driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A361		E	2
1C2062	LSB-BSE1: Control data transfer LSBJ Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A361		E	2
1C3050	LSB-BSE1: LSBK Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C3051	LSB-BSE1: LSBK Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C3053	LSB-BSE1: LSBK Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C3054	LSB-BSE1: LSBK Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C3064	LSB-BSE1: LSBK Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C3065	LSB-BSE1: LSBK Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C3066	LSB-BSE1: LSBK Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C3067	LSB-BSE1: LSBK Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C3068	LSB-BSE1: LSBK Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C3069	LSB-BSE1: LSBK Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C306A	LSB-BSE1: LSBK Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C306B	LSB-BSE1: LSBK Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C306C	LSB-BSE1: LSBK Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C6050	LSB-BSE1: LSBL Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C6051	LSB-BSE1: LSBL Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2
1C6053	LSB-BSE1: LSBL Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C6054	LSB-BSE1: LSBL Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C6064	LSB-BSE1: LSBL Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C6065	LSB-BSE1: LSBL Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C6066	LSB-BSE1: LSBL Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C6067	LSB-BSE1: LSBL Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C6068	LSB-BSE1: LSBL Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C6069	LSB-BSE1: LSBL Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C606A	LSB-BSE1: LSBL Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C606B	LSB-BSE1: LSBL Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2
1C606C	LSB-BSE1: LSBL Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1C9050	LSB-BSE1: LSBM Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A361		E	2
1C9051	LSB-BSE1: LSBM Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C9053	LSB-BSE1: LSBM Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A361		E	1
1C9054	LSB-BSE1: LSBM Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A361		E	2
1C9064	LSB-BSE1: LSBM Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A361		E	1
1C9065	LSB-BSE1: LSBM Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A361		E	2
1C9066	LSB-BSE1: LSBM Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A361		E	2
1C9067	LSB-BSE1: LSBM Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A361		E	1
1C9068	LSB-BSE1: LSBM Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A361		E	1
1C9069	LSB-BSE1: LSBM Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A361		E	1
1C906A	LSB-BSE1: LSBM Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A361		E	2
1C906B	LSB-BSE1: LSBM Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1C906C	LSB-BSE1: LSBM Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A361		E	2
1D0058	LSB-BSE1: LMB Consistency test between length sensor and track recog. erroneous Only error message Check sensor	A361		E	1
1D006A	LSB-BSE1: LMB Measuring sleeve defective/missing 2 hook weighing poss. inaccurate Error message. 2-hook weighing with pull test bracket poss. inaccurate Check sensor	A361		E	1
1D007B	LSB-BSE1: LMB LMB1 not synchronous with LMB2 error report Correct operand on respective BSE	A361		E	1
1D0129	LSB-BSE1: LMB STOP, length indicator derrick counterweight faulty/not present LMB-STOP with error message Check length sensor of ballast sliding cylinder and replace if nec.	A361		E	1
1D0133	LSB-BSE1: LMB fly jib retaining cylinder inferior minimal pressure If main boom is above 10 degrees or relapse cyl. run together on limit switch, shut off occurs When RFP-pressure in test position not in tolerance window, replace RFP, otherwise check job rods	A361		E	1
1D0134	LSB-BSE1: LMB fly jib retaining cylinder exceeds maximum pressure If main boom is above 10 degrees or relapse cyl. run together on limit switch, shut off occurs When RFP-pressure in test position not in tolerance window, replace RFP, otherwise check job rods	A361		E	1
1D014F	LSB-BSE1: LMB STOP, load chart has development status Error message with LMB-Stop Load new load charts or new crane. Disclose all error parameters to customer service	A361		E	1
1D015D	LSB-BSE1: LMB Set up condition defective: manual pinning last telescope Error message with LMB-Stop Check manual pinning, check possible sensor	A361		E	1
1D015E	LSB-BSE1: LMB Set up condition faulty: Main boom not correctly detected. Error message with LMB-Stop Check set up condition	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D015F	LSB-BSE1: LMB Set up condition faulty: Accessories not correctly detected. Error message with LMB-Stop Check set up condition	A361		E	1
1D0160	LSB-BSE1: LMB Set up condition faulty: Accessory angle not correct. Error message with LMB-Stop Check set up condition, check angle sensor	A361		E	1
1D01A0	LSB-BSE1: LMB Load display in TY-operation incorrect; Y-angle sensor erroneous error report Report all error parameters to Service	A361		E	1
1D01AA	LSB-BSE1: LMB Force measuring point accessories implausible LMB-STOP with error message Check measuring point	A361		E	1
1D020C	LSB-BSE1: LMB STOP, Boom nose set up but dummy plug plugged in LMB-Stop Plug in boom nose and remove dummy plug or remove boom nose	A361			
1D0229	LSB-BSE1: LMB STOP, SA-frame assembly cylinder extended too far (limit switch) Error message with LMB-Stop Move assembly cylinder out from block position	A361		B	1
1D022A	LSB-BSE1: LMB Angle sensor SA-bracket deviates from theor. angle impermissible Only error message Check angle sensor SA-frame, replace if nec.; possibly incorrect main boom length set up, therefore incorrect angle valu	A361		E	1
1D022B	LSB-BSE1: LMB Stop, limit switch SA cyl. defect.. Block position is not recognized Error message with LMB-Stop Check SA-inductive switch for block pos.	A361		E	1
1D025A	LSB-BSE1: LMB STOP, pressure sensor, piston surface luffing cyl. different values LMB-Stop Check pressure sensor on luffing cylinder	A361		E	1
1D025B	LSB-BSE1: LMB STOP, Pressure sensor ring surface luffing cyl. uneven values LMB-Stop Check pressure sensor on luffing cylinder	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D026F	LSB-BSE1: LMB Stop, Ballast weighing not possible since LG defect	A361			
1D0270	LSB-BSE1: LMB Measured ballast weight negative LMB-Stop Check pressure sensor in ballast lift cyl.	A361		E	1
1D0271	LSB-BSE1: LMB Value difference too large in test points for ballast lift cyl. Report to SPS Rerun to match pulled forces in ballast lift cyl.	A361		E	1
1D0272	LSB-BSE1: LMB Pulled ballast weight exceeded the equipped ballast LMB-Stop In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A361		E	1
1D0273	LSB-BSE1: LMB STOP, Ballast suspended at insufficiently low pulled ballast weight LMB-Stop In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A361		E	1
1D0274	LSB-BSE1: LMB Force on F1 less than expected Only error message Check test points and pressure sensors for relapse cyl. of derrick	A361		E	1
1D0275	LSB-BSE1: LMB Force on F1 larger than expected Only error message Check test points and pressure sensors for relapse cyl. of derrick	A361		E	1
1D0276	LSB-BSE1: LMB Difference of parallel pull test brackets too large LMB-Stop Check pull test brackets of corr. test point (par. 2); if nec. elim. side pull to guying	A361		E	1
1D0277	LSB-BSE1: LMB Difference of serial pull test brackets too large LMB-Stop Check pull test brackets in the respective test point (Parameter 2)	A361		E	1
1D0278	LSB-BSE1: LMB Difference or pressure sensor on derrick-RFPs exceeded tolerance Only error message Check relapse cyl., as well as their pressure sensors on derrick	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D0279	LSB-BSE1: LMB Ballast weighing not possible. Hoist cyl. on block or LG not ok. Only error message Retrat or extend ballast hoist cyl. so that there is sufficient distance to block pos. or check length sensor	A361		E	1
1D027A	LSB-BSE1: LMB No derrick momentum calculation, since pulled ballast not determinable Only error message This is most often a subsequent error, therefore fix previous error w/respect to ballast hoist cylinder and susp. ballas	A361		E	1
1D027B	LSB-BSE1: LMB Difference of left/right boom relapse cyl. too large LMB-Stop Check main boom relapse cyl. as well as their pressure sensors and test axles	A361		E	1
1D027C	LSB-BSE1: LMB No hoist winch is assigned to main hook Only error message The assignment of winch in config. screen must be checked	A361		E	1
1D027D	LSB-BSE1: LMB Ballast suspended even though set up ballast not yet reached Only error message In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A361		E	1
1D027E	LSB-BSE1: LMB STOP, pressure sensor ad KMA on boom relapse cyl. not ok LMB-Stop Check pressure sensors and force test axles on main boom relapse cyl	A361		E	1
1D027F	LSB-BSE1: LMB Pressure sensor on boom relapse cyl. not ok Only error message Check pressure sensor on main boom relapse cyl	A361		E	1
1D0280	LSB-BSE1: LMB Force test axles on boom relapse cyl. not ok Only error message Check force test axles on main boom relapse cyl	A361		E	1
1D0281	LSB-BSE1: LMB Pressure sensor piston side on ballast lift cyl. defective Only error message Replace pressure sensor	A361		E	1
1D0282	LSB-BSE1: LMB Length sensor ballast lift cyl. defective. Calculation with incline se Only error message Replace length sensor	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D0283	LSB-BSE1: LMB Guying of rocker too short or too long, check guying! Only error message Check assembly of guying. Possible increased sagging due to assembly procedure	A361		E	1
1D0284	LSB-BSE1: LMB Inner angle accessories not in tolerance range. Incorrect assembly? Only error message Check assembly of guying, possibly increased sag, for ex. due to assembly procedure	A361			
1D0285	LSB-BSE1: LMB Guying main boom too short or too long, check guying Only error message Check assembly of guying, possibly increased sag, for ex. due to assembly procedure	A361			
1D0287	LSB-BSE1: LMB No weighing possible. HA-guying is possible placed in part Only error message possibly luff up Derrick / SA-luffing gear	A361		B	1
1D0288	LSB-BSE1: LMB KMA defective. Pressure sensors are used. Weighing possibly too high.. Only error message Check force test axle in S-relapse cyl., possibly replace force test axle	A361		E	1
1D0289	LSB-BSE1: LMB Sensor of RFP defective. Weighing is increased if RFP engaged Only error message Check pressure sensors in S-relapse cyl., possibly replace pressure sensors	A361		E	1
1D02A0	LSB-BSE1: LMB RFP-Block limit switch HA defect. Weighing in RFP-access pt. too high Only error message Check inductive sensors in S-relapse cyl., poss. replace inductive sensors	A361		E	1
1D02A1	LSB-BSE1: LMB RFP HA on block. Weighing too high? HA above 80 degr on luffing Only error message Main boom luffing up to over 80 degree	A361		E	1
1D02B0	LSB-BSE1: LMB STOP, Ballast recognition: one / sev. sensors not recognized Error message and LMB stop Check sensor, replace if necessary	A361		E	1
1D02B1	LSB-BSE1: LMB STOP, ballast detection: Ballast no.1 missing for set up condition Error message and LMB stop Check ballast coding	A361		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D02B2	LSB-BSE1: LMB STOP, ballast detection: Ballast no.2 missing for set up condition Error message and LMB stop Check ballast coding	A361		B	1
1D02B3	LSB-BSE1: LMB STOP, ballast detection: Ballast no.3 missing for set up condition Error message and LMB stop Check ballast coding	A361		B	1
1D02B4	LSB-BSE1: LMB STOP, ballast detection: Ballast no.4 missing for set up condition Error message and LMB stop Check ballast coding	A361		B	1
1D02B5	LSB-BSE1: LMB STOP, ballast detection: Ballast no.5 missing for set up condition Error message and LMB stop Check ballast coding	A361		B	1
1D02B6	LSB-BSE1: LMB STOP, ballast detection: Ballast no.6 missing for set up condition Error message and LMB stop Check ballast coding	A361		B	1
1D02C0	LSB-BSE1: LMB STOP, ballast detection: ballast not as set up Error message and LMB stop Check ballast radius	A361		B	1
1D02C1	LSB-BSE1: LMB STOP, ballast detection: Ballast no.1 may not be detected Error message and LMB stop Check ballast coding	A361		B	1
1D02C2	LSB-BSE1: LMB STOP, ballast detection: Ballast no.2 may not be detected Error message and LMB stop Check ballast coding	A361		B	1
1D02C3	LSB-BSE1: LMB STOP, ballast detection: Ballast no.3 may not be detected Error message and LMB stop Check ballast coding	A361		B	1
1D02C4	LSB-BSE1: LMB STOP, ballast detection: Ballast no.4 may not be detected Error message and LMB stop Check ballast coding	A361		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D02C5	LSB-BSE1: LMB STOP, ballast detection: Ballast no.5 may not be detected Error message and LMB stop Check ballast coding	A361		B	1
1D02C6	LSB-BSE1: LMB STOP, ballast detection: Ballast no.6 may not be detected Error message and LMB stop Check ballast coding	A361		B	1
1D0300	LSB-BSE1: LMB STOP save error (Note parameter) LMB-Stop Report all error parameters to Service	A361		E	1
1D0301	LSB-BSE1: LMB Save error (Note parameter) error report Report all error parameters to Service	A361		E	1
1D0310	LSB-BSE1: LMB STOP no weighing, reeving insufficient or lever arm cond. LMB-Stop Increase reeving	A361		E	1
1D0311	LSB-BSE1: LMB STOP chart values for SRFP not available Error message and LMB stop Report all error parameters to Service	A361		E	1
1D0312	LSB-BSE1: LMB STOP WG on main boom defective, SRPF nominal value can't be determined Error message and LMB stop Check angle sensor on main boom	A361		E	1
1D0317	LSB-BSE1: LMB STOP, max. superstructure length incline exceeded LMB-Stop Support crane horizontally	A361		E	1
1D0318	LSB-BSE1: LMB STOP, max. superstructure lateral incline exceeded LMB-Stop Support crane horizontally	A361		E	1
1D0319	LSB-BSE1: LMB STOP, max. chassis incline exceeded LMB-Stop Support crane horizontally	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D031A	LSB-BSE1: LMB STOP, maximum chassis length incline exceeded LMB-Stop Support crane horizontally	A361		E	1
1D031B	LSB-BSE1: LMB STOP, maximum chassis cross incline exceeded LMB-Stop Support crane horizontally	A361		E	1
1D031C	LSB-BSE1: LMB STOP, Number of last activated winch invalid LMB-Stop Initiate momentary movement down with one hoist winch	A361		E	1
1D031D	LSB-BSE1: LMB STOP, no winch is assigned to setting LMB-Stop Assignment of winches in geometry must be checked, possible also check in set up screen	A361		E	1
1D0355	LSB-BSE1: LMB STOP at last operation no pin information saved LMB-Stop Place manually or pin in retracted last telescope	A361		E	1
1D0356	LSB-BSE1: LMB STOP pin condition inconsistent, no tele pin hole found LMB-Stop Report all error parameters to Service	A361		E	1
1D0357	LSB-BSE1: LMB STOP pin condition inconsistent, no valid condition loadable LMB-Stop Report all error parameters to Service	A361		E	1
1D0358	LSB-BSE1: LMB STOP pin condition inconsistent, Telescope not reachable LMB-Stop Report all error parameters to Service	A361		E	1
1D0359	LSB-BSE1: LMB STOP Length s. defective to pinning point, tele length not valid LMB-Stop Report all error parameters to Service	A361		E	1
1D035A	LSB-BSE1: LMB STOP Pin condition Tele/cylinder inconsistent or no signal LMB-Stop Report all error parameters to Service	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D035C	LSB-BSE1: LMB STOP Length sensor tele cyl. larger than max. cyl. stroke LMB-Stop Report all error parameters to Service	A361		E	1
1D035D	LSB-BSE1: LMB STOP Length sensor tele cyl. smaller Null LMB-Stop Report all error parameters to Service	A361		E	1
1D0371	LSB-BSE1: LMB STOP second LMB delivers other result LMB-Stop can occur as follow up error at a LMB-Stop auftreten	A361		E	1
1D03A0	LSB-BSE1: LMB Pressure sensor RFP-Main boom does not match force test axle Only error message Check relapse cyl. on main boom	A361		E	1
1D03A1	LSB-BSE1: LMB Difference too large: Derrick angle sensor top and bottom LMB-Stop Check or replace angle sensor on derrick	A361		E	1
1D03A2	LSB-BSE1: LMB STOP, pressure sensor or KMA on boom-RFP not ok LMB-Stop Check main boom relapse cyl., as well as their pressure sensor and test axles	A361			
1D03A3	LSB-BSE1: LMB Difference of boom angle sensors too large LMB-Stop Check angle sensor on main boom	A361		E	1
1D0571	LSB-BSE1: remote control telescoping movement selected in manual operation Telescoping locked, error message Turn off ext. op. (radio control) or switch in telesc. view to "AUTO"	A361		B	
1D0590	LSB-BSE1: remote control Short circuit after supply voltage on radio input UEA Error is shown as system error Check line connections	A361		E	
1D0612	LSB-BSE1: Data recorder Start: not connected No recording possible! Check data logger in 1 sec. interval Connect data logger, if necessary, check connection from LICCON system to data logger	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D0620	LSB-BSE1: Data recorder Init: Firmware version incorrect/faulty Has not yet been checked! Report all error parameters to Service	A361		E	1
1D0621	LSB-BSE1: Data recorder Init: ATA-card not initialised STATUS-error: Data recorder software stops - no documentation possible! Initialize ATA-Card with PC-Software 'LICCON Manager'	A361		E	1
1D0622	LSB-BSE1: Data recorder Init: ATA-card contains different crane number STATUS-error: Data recorder software stops - no documentation possible! Use ATA card with correct crane number or newly initialised ATA card	A361		E	1
1D0623	LSB-BSE1: Data recorder Init: Format-File-Transfer faulty Repeat of Format-File transfers in 1 sec. cycles If necessary, correct type and country specific format file 'Lnnttt01vvr.Q' in EPROM 0	A361		E	1
1D0630	LSB-BSE1: Data recorder Transfer: Data transmission faulty Repeat of data transfers in 1 sec. cycles If necessary check connection from LICCON system to data recorder	A361		E	1
1D0631	LSB-BSE1: Data recorder Transfer: CSM-protocol error Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A361		E	1
1D0632	LSB-BSE1: Data recorder Transfer: Transmission error (CRC) Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A361		E	1
1D0633	LSB-BSE1: Data recorder Transfer: STATUS-error Resynchronize depending on STATUS in 1 sec.interval If necessary check connection from LICCON system to data recorder	A361		E	1
1D0634	LSB-BSE1: Data recorder Transfer: TAN-error Synchronise CSM protocol again completely If necessary check connection from LICCON system to data recorder	A361		E	1
1D0635	LSB-BSE1: Data recorder Transfer: Writing error Synchronise CSM protocol again completely If necessary check connection from LICCON-System to data recorder and ATA card	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D0849	LSB-BSE1: Operating hours counter urgent modul, ZE not available error report Report all error parameters to Service	A361		E	2
1D0878	LSB-BSE1: Operating hours counter impermissible parameter Error message, Parameter is possibly set to min or max Software update required, report all error parameter to Service Dept.	A361		E	2
1D094A	LSB-BSE1: Operating data protection not possible. Module missing, communication to module is erroneous error report In LICCON REMOTE DIAGNOSTICS - LSB DIAGNOSTICS localize missing LSB modules. Disclose all parameters to customer service	A361		E	2
1D0978	LSB-BSE1: Operating data protection impermissible parameter error report Software update required, report all error parameter to Service Dept.	A361		E	2
1D1200	LSB-BSE1: LPC No allocation for write cache requirement error report Reprogramming	A361		E	1
1D1201	LSB-BSE1: LPC Variable not available or connected error report Reprogramming	A361		E	1
1D1202	LSB-BSE1: LPC No write buffer release error report Reprogramming	A361		E	1
1D1203	LSB-BSE1: LPC Error at connection of one variable error report Reprogramming	A361		E	1
1D3001	LSB-BSE1: control winch 1 feed pressure supply missing/too low	A361		E	
1D3003	LSB-BSE1: control winch 1 Winch turn sensor, internal non-tolerable continuous error (P0=04H) Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3004	LSB-BSE1: control winch 1 Winch turn sensor, internal non-tolerable continuous error (P0=08H/40H) Operation conditional switch off, may not be shunted Reload data on internal EEPROM, otherwise replace sensor	A361		E	
1D3005	LSB-BSE1: control winch 1 Winch turn sensor, internal non-tolerable continuous error (P0=10H) Operation conditional switch off, may not be shunted replace sensor through new part	A361		E	
1D3006	LSB-BSE1: control winch 1 Winch turn sensor, internal non-tolerable continuous error (P0=20H) Output of error (resolution of sensor is bad) Replace sensor in the meantime	A361		E	
1D3007	LSB-BSE1: control winch 1 Winch turn sensor, internal, non-tolerable partial error Output of error Replace sensor in the meantime	A361		E	
1D3008	LSB-BSE1: control winch 1 Winch turn sensor, tolerable error(P0=01H), sensor not exact Output of error, adjusting with button does not work Check button, replace sensor in the meantime, if necessary	A361		E	
1D3009	LSB-BSE1: control winch 1 Winch turn sensor, tolerable error(P0=02H), replace external EEPROM Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3010	LSB-BSE1: control winch 1 Winch turn sensor, tolerable error (P0=04H) button pressed constantly Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3011	LSB-BSE1: control winch 1 Winch turn sensor, tolerable error (P0=08H) pressure sensor1 not 4-20mA Output of error, 2. shut off "Winch spooled out " does not work Replace sensor in the meantime	A361		E	
1D3012	LSB-BSE1: control winch 1 Winch turn sensor, tolerable error(P0=10H) pressure sensor2 not 4-20mA Output of error Replace sensor in the meantime	A361		E	
1D3013	LSB-BSE1: control winch 1 Winch turn sensor, tolerable error(P0=20H) Safety relay stuck Output of error Check winch	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3014	LSB-BSE1: control winch 1 Winch turn sensor, tolerable error(P0=40H)	A361		E	
1D3015	LSB-BSE1: control winch 1 tolerable error, maximum theoretical load collective reached Operation conditional switch off, may not be shunted in the LSB- sensor view of the test system: take over default values, otherwise replace sensor	A361		E	
1D3017	LSB-BSE1: control winch 1 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A361		E	
1D3018	LSB-BSE1: control winch 1 Pressure too high when pump is not actuated operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		E	
1D3022	LSB-BSE1: control winch 1 Winch not actuated and brake not completely applied Output of error, crane function is not selected. Check wiring winch brake monitor	A361		E	
1D3048	LSB-BSE1: control winch 1 Caution winch gear oil level too low Output of error Add oil. When actual oil level is OK and error is still shown, check sensor for function	A361		E	
1D305C	LSB-BSE1: control winch 1 Shutdown monitoring winch brake short circuit to VCC or mass Output of error, crane function is not selected. Check wiring winch brake monitor	A361		E	
1D305D	LSB-BSE1: control winch 1 Shut off Parallel operation winch, brake applied Output of error, crane function is not selected. Check wiring winch brake monitor	A361		E	
1D305E	LSB-BSE1: control winch 1 Shutdown winch brake applied with activated pump Output of error, crane function is not selected. Check wiring winch brake monitor	A361		E	
1D3101	LSB-BSE1: control winch 2 feed pressure supply missing/too low	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3103	LSB-BSE1: control winch 2 Winch turn sensor, internal non-tolerable continuous error (P0=04H) Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	A361		E	
1D3104	LSB-BSE1: control winch 2 Winch turn sensor, internal non-tolerable continuous error (P0=08H/40H) Operation conditional switch off, may not be shunted Reload data on internal EEPROM, otherwise replace sensor	A361		E	
1D3105	LSB-BSE1: control winch 2 Winch turn sensor, internal non-tolerable continuous error (P0=10H) Operation conditional switch off, may not be shunted replace sensor through new part	A361		E	
1D3106	LSB-BSE1: control winch 2 Winch turn sensor, internal non-tolerable continuous error (P0=20H) Output of error (resolution of sensor is bad) Replace sensor in the meantime	A361		E	
1D3107	LSB-BSE1: control winch 2 Winch turn sensor, internal, non-tolerable partial error Output of error Replace sensor in the meantime	A361		E	
1D3108	LSB-BSE1: control winch 2 Winch turn sensor, tolerable error(P0=01H), sensor not exact Output of error, adjusting with button does not work Check button, replace sensor in the meantime, if necessary	A361		E	
1D3109	LSB-BSE1: control winch 2 Winch turn sensor, tolerable error(P0=02H), replace external EEPROM Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3110	LSB-BSE1: control winch 2 Winch turn sensor, tolerable error (P0=04H) button pressed constantly Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3111	LSB-BSE1: control winch 2 Winch turn sensor, tolerable error (P0=08H) pressure sensor1 not 4-20mA Output of error, 2. shut off "Winch spooled out " does not work Replace sensor in the meantime	A361		E	
1D3112	LSB-BSE1: control winch 2 Winch turn sensor, tolerable error(P0=10H) pressure sensor2 not 4-20mA Output of error Replace sensor in the meantime	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3113	LSB-BSE1: control winch 2 Winch turn sensor, tolerable error(P0=20H) Safety relay stuck Output of error Check winch	A361		E	
1D3114	LSB-BSE1: control winch 2 Winch turn sensor, tolerable error(P0=40H)	A361		E	
1D3115	LSB-BSE1: control winch 2 tolerable error, maximum theoretical load collective reached Operation conditional switch off, may not be shunted in the LSB- sensor view of the test system: take over default values, otherwise replace sensor	A361		E	
1D3117	LSB-BSE1: control winch 2 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A361		E	
1D3118	LSB-BSE1: control winch 2 Pressure too high when pump is not actuated	A361		E	
1D3122	LSB-BSE1: control winch 2 Winch not actuated and brake not completely applied Output of error, crane function is not selected. Check wiring winch brake monitor	A361		E	
1D3148	LSB-BSE1: control winch 2 Caution winch gear oil level too low Output of error Add oil. When actual oil level is OK and error is still shown, check sensor for function	A361		E	
1D315C	LSB-BSE1: control winch 2 Shutdown monitoring winch brake short circuit to VCC or mass Output of error, crane function is not selected. Check wiring winch brake monitor	A361		E	
1D315D	LSB-BSE1: control winch 2 Shut off Parallel operation winch, brake applied Output of error, crane function is not selected. Check wiring winch brake monitor	A361		E	
1D315E	LSB-BSE1: control winch 2 Shutdown winch brake applied with activated pump Output of error, crane function is not selected. Check wiring winch brake monitor	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3201	LSB-BSE1: control winch 3 feed pressure supply missing/too low Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		E	
1D3203	LSB-BSE1: control winch 3 Winch turn sensor, internal non-tolerable continuous error (P0=04H) Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	A361		E	
1D3204	LSB-BSE1: control winch 3 Winch turn sensor, internal non-tolerable continuous error (P0=08H/40H) Operation conditional switch off, may not be shunted Reload data on internal EEPROM, otherwise replace sensor	A361		E	
1D3205	LSB-BSE1: control winch 3 Winch turn sensor, internal non-tolerable continuous error (P0=10H) Operation conditional switch off, may not be shunted replace sensor through new part	A361		E	
1D3206	LSB-BSE1: control winch 3 Winch turn sensor, internal non-tolerable continuous error (P0=20H) Output of error (resolution of sensor is bad) Replace sensor in the meantime	A361		E	
1D3207	LSB-BSE1: control winch 3 Winch turn sensor, internal, non-tolerable partial error Output of error Replace sensor in the meantime	A361		E	
1D3208	LSB-BSE1: control winch 3 Winch turn sensor, tolerable error(P0=01H), sensor not exact Output of error, adjusting with button does not work Check button, replace sensor in the meantime, if necessary	A361		E	
1D3209	LSB-BSE1: control winch 3 Winch turn sensor, tolerable error(P0=02H), replace external EEPROM Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3210	LSB-BSE1: control winch 3 Winch turn sensor, tolerable error (P0=04H) button pressed constantly Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3211	LSB-BSE1: control winch 3 Winch turn sensor,tolerable error (P0=08H) pressure sensor1 not 4-20mA Output of error, 2. shut off "Winch spooled out " does not work Replace sensor in the meantime	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3212	LSB-BSE1: control winch 3 Winch turn sensor, tolerable error(P0=10H) pressure sensor2 not 4-20mA Output of error Replace sensor in the meantime	A361		E	
1D3213	LSB-BSE1: control winch 3 Winch turn sensor, tolerable error(P0=20H) Safety relay stuck Output of error Check winch	A361		E	
1D3214	LSB-BSE1: control winch 3 Winch turn sensor, tolerable error(P0=40H)	A361		E	
1D3215	LSB-BSE1: control winch 3 tolerable error, maximum theoretical load collective reached Operation conditional switch off, may not be shunted in the LSB- sensor view of the test system: take over default values, otherwise replace sensor	A361		E	
1D3217	LSB-BSE1: control winch 3 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A361		E	
1D3218	LSB-BSE1: control winch 3 Pressure too high when pump is not actuated Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		E	
1D3301	LSB-BSE1: control winch 4 feed pressure supply missing/too low Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		E	
1D3303	LSB-BSE1: control winch 4 Winch turn sensor, internal non-tolerable continuous error (P0=04H) Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	A361		E	
1D3304	LSB-BSE1: control winch 4 Winch turn sensor, internal non-tolerable continuous error (P0=08H/40H) Operation conditional switch off, may not be shunted Reload data on internal EEPROM, otherwise replace sensor	A361		E	
1D3305	LSB-BSE1: control winch 4 Winch turn sensor, internal non-tolerable continuous error (P0=10H) Operation conditional switch off, may not be shunted replace sensor through new part	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3306	LSB-BSE1: control winch 4 Winch turn sensor, internal non-tolerable continuous error (P0=20H) Output of error (resolution of sensor is bad) Replace sensor in the meantime	A361		E	
1D3307	LSB-BSE1: control winch 4 Winch turn sensor, internal, non-tolerable partial error Output of error Replace sensor in the meantime	A361		E	
1D3308	LSB-BSE1: control winch 4 Winch turn sensor, tolerable error(P0=01H), sensor not exact Output of error, adjusting with button does not work Check button, replace sensor in the meantime, if necessary	A361		E	
1D3309	LSB-BSE1: control winch 4 Winch turn sensor, tolerable error(P0=02H), replace external EEPROM Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3310	LSB-BSE1: control winch 4 Winch turn sensor, tolerable error (P0=04H) button pressed constantly Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3311	LSB-BSE1: control winch 4 Winch turn sensor, tolerable error (P0=08H) pressure sensor1 not 4-20mA Output of error, 2. shut off "Winch spooled out " does not work Replace sensor in the meantime	A361		E	
1D3312	LSB-BSE1: control winch 4 Winch turn sensor, tolerable error(P0=10H) pressure sensor2 not 4-20mA Output of error Replace sensor in the meantime	A361		E	
1D3313	LSB-BSE1: control winch 4 Winch turn sensor, tolerable error(P0=20H) Safety relay stuck Output of error Check winch	A361		E	
1D3314	LSB-BSE1: control winch 4 Winch turn sensor, tolerable error(P0=40H)	A361		E	
1D3315	LSB-BSE1: control winch 4 tolerable error, maximum theoretical load collective reached Operation conditional switch off, may not be shunted in the LSB- sensor view of the test system: take over default values, otherwise replace sensor	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3317	LSB-BSE1: control winch 4 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A361		E	
1D3318	LSB-BSE1: control winch 4 Pressure too high when pump is not actuated Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		E	
1D3401	LSB-BSE1: control winch 5 feed pressure supply missing/too low	A361		E	
1D3403	LSB-BSE1: control winch 5 Winch turn sensor, internal non-tolerable continuous error (P0=04H) Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	A361		E	
1D3404	LSB-BSE1: control winch 5 Winch turn sensor, internal non-tolerable continuous error (P0=08H/40H) Operation conditional switch off, may not be shunted Reload data on internal EEPROM, otherwise replace sensor	A361		E	
1D3405	LSB-BSE1: control winch 5 Winch turn sensor, internal non-tolerable continuous error (P0=10H) Operation conditional switch off, may not be shunted replace sensor through new part	A361		E	
1D3406	LSB-BSE1: control winch 5 Winch turn sensor, internal non-tolerable continuous error (P0=20H) Output of error (resolution of sensor is bad) Replace sensor in the meantime	A361		E	
1D3407	LSB-BSE1: control winch 5 Winch turn sensor, internal, non-tolerable partial error Output of error Replace sensor in the meantime	A361		E	
1D3408	LSB-BSE1: control winch 5 Winch turn sensor, tolerable error(P0=01H), sensor not exact Output of error, adjusting with button does not work Check button, replace sensor in the meantime, if necessary	A361		E	
1D3409	LSB-BSE1: control winch 5 Winch turn sensor, tolerable error(P0=02H), replace external EEPROM Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3410	LSB-BSE1: control winch 5 Winch turn sensor, tolerable error (P0=04H) button pressed constantly Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3411	LSB-BSE1: control winch 5 Winch turn sensor, tolerable error (P0=08H) pressure sensor1 not 4-20mA Output of error, 2. shut off "Winch spooled out " does not work Replace sensor in the meantime	A361		E	
1D3412	LSB-BSE1: control winch 5 Winch turn sensor, tolerable error(P0=10H) pressure sensor2 not 4-20mA Output of error Replace sensor in the meantime	A361		E	
1D3413	LSB-BSE1: control winch 5 Winch turn sensor, tolerable error(P0=20H) Safety relay stuck Output of error Check winch	A361		E	
1D3414	LSB-BSE1: control winch 5 Winch turn sensor, tolerable error(P0=40H)	A361		E	
1D3415	LSB-BSE1: control winch 5 tolerable error, maximum theoretical load collective reached Operation conditional switch off, may not be shunted in the LSB- sensor view of the test system: take over default values, otherwise replace sensor	A361		E	
1D3417	LSB-BSE1: control winch 5 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A361		E	
1D3418	LSB-BSE1: control winch 5 Pressure too high when pump is not actuated operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A361		E	
1D341D	LSB-BSE1: control winch 5 Flap in position at angle threshold fallen below	A361		E	
1D3501	LSB-BSE1: control winch 6 feed pressure supply missing/too low	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3503	LSB-BSE1: control winch 6 Winch turn sensor, internal non-tolerable continuous error (P0=04H) Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	A361		E	
1D3504	LSB-BSE1: control winch 6 Winch turn sensor, internal non-tolerable continuous error (P0=08H/40H) Operation conditional switch off, may not be shunted Reload data on internal EEPROM, otherwise replace sensor	A361		E	
1D3505	LSB-BSE1: control winch 6 Winch turn sensor, internal non-tolerable continuous error (P0=10H) Operation conditional switch off, may not be shunted replace sensor through new part	A361		E	
1D3506	LSB-BSE1: control winch 6 Winch turn sensor, internal non-tolerable continuous error (P0=20H) Output of error (resolution of sensor is bad) Replace sensor in the meantime	A361		E	
1D3507	LSB-BSE1: control winch 6 Winch turn sensor, internal, non-tolerable partial error Output of error Replace sensor in the meantime	A361		E	
1D3508	LSB-BSE1: control winch 6 Winch turn sensor, tolerable error(P0=01H), sensor not exact Output of error, adjusting with button does not work Check button, replace sensor in the meantime, if necessary	A361		E	
1D3509	LSB-BSE1: control winch 6 Winch turn sensor, tolerable error(P0=02H), replace external EEPROM Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3510	LSB-BSE1: control winch 6 Winch turn sensor, tolerable error (P0=04H) button pressed constantly Output of error Check pressure sensor - Analog signal line to winch turn sensor, or replace this pressure sensor	A361		E	
1D3511	LSB-BSE1: control winch 6 Winch turn sensor, tolerable error (P0=08H) pressure sensor1 not 4-20mA Output of error, 2. shut off "Winch spooled out " does not work Replace sensor in the meantime	A361		E	
1D3512	LSB-BSE1: control winch 6 Winch turn sensor, tolerable error(P0=10H) pressure sensor2 not 4-20mA Output of error Replace sensor in the meantime	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3513	LSB-BSE1: control winch 6 Winch turn sensor, tolerable error(P0=20H) Safety relay stuck Output of error Check winch	A361		E	
1D3514	LSB-BSE1: control winch 6 Winch turn sensor, tolerable error(P0=40H)	A361		E	
1D3515	LSB-BSE1: control winch 6 tolerable error, maximum theoretical load collective reached warning Check pressure stages luffing/tele	A361		E	
1D3517	LSB-BSE1: control winch 6 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A361		E	
1D3518	LSB-BSE1: control winch 6 Pressure too high when pump is not actuated operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		E	
1D3650	LSB-BSE1: control telescoping Tele recognition faulty, more than one track switch reporting active	A361		B	
1D3720	LSB-BSE1: control luffing Maximum pressure of luffing cylinder exceeded Output of error, otherwise no reaction. If possible set another operation type.	A361		E	
1D3820	LSB-BSE1: control slewing Pressure switch Slewing brake reports open even though not actuated	A361		E	1
1D38A0	LSB-BSE1: control slewing Signal from slewing platform pinning not plausible Reports blinking error issue, no signal on control and LMB Check sensor, wiring, input contro unit	A361		E	1
1D38A4	LSB-BSE1: control slewing Signals slewing platform setting to rear90° <> 5° implausible Reports blinking error issue, no signal on control and LMB Check sensor, wiring, input contro unit	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3B00	LSB-BSE1: Control ballasting / counterweight carriage Limit switch "BW bolted" faulty / not present - Shut-down BW active Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Error remedy see corresponding system error.	A361		E	
1D3B01	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and FB inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following earthing or line interruption, checking of inputs.	A361		E	
1D3B02	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted and FB inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A361		E	
1D3B03	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and bolted and FB inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A361		E	
1D3B04	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - B inserted and FB not inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following supply voltage or earthing or line interruption.	A361		E	
1D3B05	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and B inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following supply voltage or earthing or line interruption.	A361		E	
1D3B06	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A361		E	
1D3B07	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and bolted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A361		E	
1D3B08	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted FB inserted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A361		E	
1D3B09	LSB-BSE1: Control ballasting / counterweight carriage Invalid assembly condition - entry combination does not make sense Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3B20	LSB-BSE1: Control ballasting / counterweight carriage Warning Limit switch Ballast cyl Block left erroneous / missing Issuance of error, crane function is not actuated Check LSB-sensor, check wiring, note system error	A361		E	
1D3B21	LSB-BSE1: Control ballasting / counterweight carriage Warning Limit switch Ballast cyl Block right erroneous / missing Issuance of error, crane function is not actuated Check LSB-sensor, check wiring, note system error	A361		E	
1D3B22	LSB-BSE1: Control ballasting / counterweight carriage Warning length sensor Ballast cyl left erroneous / missing Issuance of error, crane function is not actuated Check LSB-sensor, check wiring, note system error	A361		E	
1D3B23	LSB-BSE1: Control ballasting / counterweight carriage Warning length sensor Ballast cyl right erroneous / missing Issuance of error, crane function is not actuated Check LSB-sensor, check wiring, note system error	A361		E	
1D3C17	LSB-BSE1: Control crawler Pressure switch brake reports pressure with crawler not actuated Operational shut off Bring foot pedal in zero pos., check brake pr. crawler	A361		E	
1D3E41	LSB-BSE1: Switch cabinet LMB-bypass-emerg. or cont. actuation or Short circuit after Ubatt Check key switch, check input, check wiring	A361		E	
1D3F09	LSB-BSE1: crane control Pilot contact Derrick installed und LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F0A	LSB-BSE1: crane control Pilot contact Derrick not installed und LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F0B	LSB-BSE1: crane control Pilot contact main boom installed und LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F0C	LSB-BSE1: crane control Pilot contact main boom not installed und LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3F0D	LSB-BSE1: crane control Pilot contact Ballast installed und LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F0E	LSB-BSE1: crane control Pilot contact Ballast not installed und LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F10	LSB-BSE1: crane control Shut off valves relapse cyl. continuous actuation warning	A361		E	
1D3F11	LSB-BSE1: crane control Pilot contact swing installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F12	LSB-BSE1: crane control Pilot contact swing not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F13	LSB-BSE1: crane control Pilot contact boom nose HA not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F14	LSB-BSE1: crane control Pilot contact boom nose HA not installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F15	LSB-BSE1: crane control Warning - Pilot contact Derrick not installed active Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F16	LSB-BSE1: crane control Warning - Pilot contact main boom not installed active Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F19	LSB-BSE1: crane control no or invalid operation mode recognized	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3F1A	LSB-BSE1: crane control Master switch assignment from LSB-TE1 and LSB-TE2 different Movements blocked Check line connections	A361		E	
1D3F1B	LSB-BSE1: crane control MS assignment of LSB-TE1 and LSB-TE2 and LSB-TE3 different Movements blocked Check line connections	A361		E	
1D3F27	LSB-BSE1: crane control Caution bypass pressure difference Ballast cyl. active	A361		E	
1D3F28	LSB-BSE1: crane control Pilot contact boom nose ZUB installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F29	LSB-BSE1: crane control Pilot contact boom nose ZUB not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F2A	LSB-BSE1: crane control Pilot contact accessories installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F2B	LSB-BSE1: crane control Pilot contact accessories not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F2C	LSB-BSE1: crane control Pilot contact WA-bracket installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F2D	LSB-BSE1: crane control Pilot contact WA-bracket not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D3F41	LSB-BSE1: crane control Emergency operation switched on, Caution shut-downs ineffective Deactivate plug emerg. operation. Turn down control and restart	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3F50	LSB-BSE1: crane control Pressure relapse cyl. main boom smaller min. pressure Only error issue	A361		E	
1D3F51	LSB-BSE1: crane control Pressure relapse cyl. main boom larger max. pressure Only error issue	A361		E	
1D3F54	LSB-BSE1: crane control Pressure relapse cyl. Derrick smaller min. pressure Only error issue	A361		E	
1D3F55	LSB-BSE1: crane control Pressure relapse cyl. Derrick larger max. pressure Only error issue	A361		E	
1D3F56	LSB-BSE1: crane control Pressure relapse cylinder -S at low pressure outside nominal range Only error issue Check LSB - Pressure sensor, valve	A361		E	
1D3F57	LSB-BSE1: crane control Pressure relapse cylinder -SA at low pressure outside nominal range Only error issue Check LSB - Pressure sensor, valve	A361		E	
1D3F5A	LSB-BSE1: crane control Relapse cyl. -S left not moved out warning Pressure supply missing or stop valve of S-RFP does not open	A361		E	
1D3F5B	LSB-BSE1: crane control Relapse cyl. -S right not moved out warning Pressure supply missing or stop valve of S-RFP does not open	A361		E	
1D3F60	LSB-BSE1: crane control Warning second shut off diagram yields different result Error output	A361		E	
1D3F80	LSB-BSE1: crane control Combi slewing gear is prerequisite for working range limitation Error display Re-equip combi slewing gear	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3F81	LSB-BSE1: crane control Combi slewing gear is prerequisite for radio remote control Error display Re-equip combi slewing gear	A361		E	
1D3F82	LSB-BSE1: crane control Combi slewing gear is prerequisite for limited slewing range operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		E	
1D3F90	LSB-BSE1: crane control Test systems of test point 8 supply different test values	A361		B	
1D3FC0	LSB-BSE1: crane control System: Incremental sensor slewing gear implausible to absolute sensor Error is shown as system error Check both angle sensors.	A361		E	
1D3FC1	LSB-BSE1: crane control System: Telescopic length implausible to MPC Error is shown as system error Check pressure sensor on luffing cylinder and LS- pressure sensor. Check hydraulic components.	A361		E	
1D3FC2	LSB-BSE1: crane control System: Angle sensor on main boom relationship implausible Error is shown as system error Check pressure sensor Winch 1 and LS- Pressure sensor. Possibly check hydraulic components.	A361		E	
1D3FC3	LSB-BSE1: crane control System: Luffing cyl. pressure implausible to LS- pr. Error is shown as system error Check pressure sensor Winch 2 and LS- Pressure sensor. Possibly check hydraulic components.	A361		E	
1D3FC4	LSB-BSE1: crane control System: Pressure sensor on winch1 implausible to LS- pressure Error is shown as system error Check installation position cam switch. Possibly check turn sensor.	A361		E	
1D3FC5	LSB-BSE1: crane control System: Pressure sensor on winch2 implausible to LS- pressure Error is shown as system error Check angle sensor pivot section. Possibly check control chain "luffing main boom"	A361		E	
1D3FC6	LSB-BSE1: crane control System: Turns sensor implausible to cam switch Error is shown as system error Check angle sensor end section. Check possibly control chain "Luffing Main boom"	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3FC7	LSB-BSE1: crane control System: No value change on angle pivot section after actuation Error is shown as system error Check winch turn sensor 1. Possibly check control chain "hoist gear 1 up/down" ueberpruefen	A361		E	
1D3FC8	LSB-BSE1: crane control System: No value change on angle end section after actuation Error is shown as system error Check winch turn sensor 2. Possibly check control chain "hoist gear 1 up/down"	A361		E	
1D3FC9	LSB-BSE1: crane control System: No value change on winch turn sensor1 after actuation Error is shown as system error Check absolute turn sensor. Possibly check control chain "Turning"	A361		E	
1D3FCA	LSB-BSE1: crane control System: No value change on winch turn sensor2 after actuation Error is shown as system error Check telescope length sensor. Possibly check control chain "Telescoping"	A361		E	
1D3FCB	LSB-BSE1: crane control System: No value change on turn sensor after actuation Error is shown as system error Check angle sensor accessories. Possibly check control chain "luffing accessories"	A361		E	
1D3FCC	LSB-BSE1: crane control System: No value change on telescope length sensor after actuation Error is shown as system error Check angle sensor on pivot section	A361		E	
1D3FCD	LSB-BSE1: crane control System: No value change on angle access. after actuation Error is shown as system error Check telescope length sensor.	A361		E	
1D3FCE	LSB-BSE1: crane control System: Angle change Telescope without control Error is shown as system error Check winch turn sensor 1.	A361		E	
1D3FCF	LSB-BSE1: crane control System: Length change Telescope without control Error is shown as system error Check winch turn sensor 2.	A361		E	
1D3FD0	LSB-BSE1: crane control System: Wind on length modification Winch1 without control Error is shown as system error Check angle sensor accessories.	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D3FD1	LSB-BSE1: crane control System: Wind on length modification Winch2 without control Error is shown as system error Check absolute turn sensor.	A361		E	
1D3FD2	LSB-BSE1: crane control System: Angle change accessories without control Error is shown as system error Confirm configuration view with OK	A361		E	
1D3FD3	LSB-BSE1: crane control System: Angle change swing gear without control Error report. Slewing left and right blocked Switch off slewing limit or edge limit and slew Tele into permissible range, or determine new limit angle	A361		E	
1D3FF0	LSB-BSE1: crane control System: LMB not active Error message BSE System which sensors pulled at run time	A361		E	
1D4039	LSB-BSE1: instruments crane operators cab Seat contact operated permanently or short circuit after power supply error report Check seat contact, input, wiring	A361		E	
1D403D	LSB-BSE1: instruments crane operators cab LMB-bypass cont. actuation or short circuit after Ubatt Check key switch, check input, check wiring	A361		E	
1D5004	LSB-BSE1: operation winch 1 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A361		B	
1D5005	LSB-BSE1: operation winch 1 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D500B	LSB-BSE1: operation winch 1 Shut-down upper limit angle ULV (geometry, load capacity chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D500C	LSB-BSE1: operation winch 1 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D500F	LSB-BSE1: operation winch 1 Shut off winch, brake not completely released	A361		B	
1D5018	LSB-BSE1: operation winch 1 Shut-down measuring point 1 < F min operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D5019	LSB-BSE1: operation winch 1 no or invalid operation mode shut-down operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A361		B	
1D501F	LSB-BSE1: operation winch 1 Shut off LMB not active operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	
1D5020	LSB-BSE1: operation winch 1 LMB shut-down operational shut down disengage winch 1 in the control screen	A361		B	
1D5021	LSB-BSE1: operation winch 1 Shut-down measuring point 1 > F max - operation	A361		B	
1D5022	LSB-BSE1: operation winch 1 Shut-down measuring point 1 > F max - assembly	A361		B	
1D5024	LSB-BSE1: operation winch 1 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5025	LSB-BSE1: operation winch 1 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5026	LSB-BSE1: operation winch 1 Shut-down upper limit angle derrick OGWD operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5027	LSB-BSE1: operation winch 1 Shut-down lower limit angle derrick UGWD operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D5029	LSB-BSE1: operation winch 1 winch blocked (C-key monitor) operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	
1D502A	LSB-BSE1: operation winch 1 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A361		B	
1D502E	LSB-BSE1: operation winch 1 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D502F	LSB-BSE1: operation winch 1 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A361		B	
1D5030	LSB-BSE1: operation winch 1 master switch 1 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D5033	LSB-BSE1: operation winch 1 Shut-down parallel op. differential path between winches too great Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5037	LSB-BSE1: operation winch 1 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A361		B	
1D5039	LSB-BSE1: operation winch 1 seat contact shut-down operational shut down Actuate seat contact or press deadman	A361		B	
1D503E	LSB-BSE1: operation winch 1 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5044	LSB-BSE1: operation winch 1 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A361		B	
1D5049	LSB-BSE1: operation winch 1 Shut-down hoist limit switch 4 operational shut down	A361		B	
1D504A	LSB-BSE1: operation winch 1 Shut off Hoist limit switch 5 operational shut down	A361		B	
1D504B	LSB-BSE1: operation winch 1 Shut off upper relative limit angle Derrick ORGWD	A361		B	
1D504E	LSB-BSE1: operation winch 1 Shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D504F	LSB-BSE1: operation winch 1 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A361		B	
1D5050	LSB-BSE1: operation winch 1 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5051	LSB-BSE1: operation winch 1 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5052	LSB-BSE1: operation winch 1 end of stroke switch shut-down 3 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5057	LSB-BSE1: operation winch 1 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D505E	LSB-BSE1: operation winch 1 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A361		B	
1D505F	LSB-BSE1: operation winch 1 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5062	LSB-BSE1: operation winch 1 Emerg. shut-off winch-winch rotational sensor interrupts brake control Operation conditional switch off, may not be shunted Operate load hook in single operation winches 1 and 2 horizontally and set winches 1 and 2 in parallel operation.	A361		B	
1D5063	LSB-BSE1: operation winch 1 Crane engine in overspeed operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5064	LSB-BSE1: operation winch 1 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A361		B	
1D507A	LSB-BSE1: operation winch 1 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D507B	LSB-BSE1: operation winch 1 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D507C	LSB-BSE1: operation winch 1 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D507D	LSB-BSE1: operation winch 1 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A361		B	
1D507E	LSB-BSE1: operation winch 1 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5081	LSB-BSE1: operation winch 1 end of stroke switch 1 shut-down defective operational shut down	A361		B	
1D5082	LSB-BSE1: operation winch 1 end of stroke switch 2 shut-down defective operational shut down	A361		B	
1D5083	LSB-BSE1: operation winch 1 end of stroke switch 3 shut-down defective operational shut down	A361		B	
1D5089	LSB-BSE1: operation winch 1 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D508A	LSB-BSE1: operation winch 1 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D508C	LSB-BSE1: operation winch 1 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A361		B	
1D5090	LSB-BSE1: operation winch 1 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A361		B	
1D509A	LSB-BSE1: operation winch 1 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D509B	LSB-BSE1: operation winch 1 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D50A0	LSB-BSE1: operation winch 1 Shut off Parallel op. test systems W1-W2 deviate Operation conditional switch off, may not be shunted	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D50A7	LSB-BSE1: operation winch 1 Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A361		B	
1D50AB	LSB-BSE1: operation winch 1 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D50AC	LSB-BSE1: operation winch 1 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D50AD	LSB-BSE1: operation winch 1 Shut off upper relative limit angle acc. reached / exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D50B2	LSB-BSE1: operation winch 1 Shut off upper relative limit angle HA reached / exceeded	A361		B	
1D50BA	LSB-BSE1: operation winch 1 Winch operating temp. exceeded reduce output !	A361		B	
1D50BC	LSB-BSE1: operation winch 1 UGW HA Erection force reached - activate switch boom on ground	A361		B	
1D50BF	LSB-BSE1: operation winch 1 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D50C0	LSB-BSE1: operation winch 1 Shut off test point 3 > F max - Montage	A361		B	
1D50C5	LSB-BSE1: operation winch 1 OGW main boom erection force reached - luff up derrick, lift ballast	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D50C7	LSB-BSE1: operation winch 1 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D50C8	LSB-BSE1: operation winch 1 Shut off test point 2 > F max - assembly	A361		B	
1D50D0	LSB-BSE1: operation winch 1 Shut off since parallel op. set up, press deadman longer Operational shut off, bypassable Set up of parallel op., change over of MS assignment in TE to parallel op. or by pressing deadman	A361		B	
1D50D1	LSB-BSE1: operation winch 1 Shut off Parallel operation Operational shut off Release shut off, for error remedy see respective system error	A361		B	
1D50D2	LSB-BSE1: operation winch 1 Emerg. op. parallel control - monitoring hook incline required! The regulation of parallel op. is now via the winch turn sensor Switch over with key switch on monitor 2	A361		B	
1D50E6	LSB-BSE1: operation winch 1 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D50E7	LSB-BSE1: operation winch 1 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A361		B	
1D50E8	LSB-BSE1: operation winch 1 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A361		B	
1D5104	LSB-BSE1: operation winch 2 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A361		B	
1D5105	LSB-BSE1: operation winch 2 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D510B	LSB-BSE1: operation winch 2 Shut-down upper limit angle ULV (geometry, load capacity chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D510C	LSB-BSE1: operation winch 2 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D510F	LSB-BSE1: operation winch 2 Shut off winch, brake not completely released	A361		B	
1D5110	LSB-BSE1: operation winch 2 fly jib upper stop shut-down operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5111	LSB-BSE1: operation winch 2 fly jib upper flap shut-down	A361		B	
1D5112	LSB-BSE1: operation winch 2 shut-down as lower fly jib and NA-boom 3 not positioned	A361		B	
1D5113	LSB-BSE1: operation winch 2 shut-down as flap not positioned and angle threshold exceeded	A361		B	
1D5114	LSB-BSE1: operation winch 2 pressure retaining cylinder RFP N shut-down outside set range	A361		B	
1D5115	LSB-BSE1: operation winch 2 adjustable pulley-N on stop shut-down	A361		B	
1D5118	LSB-BSE1: operation winch 2 Shut-down measuring point 1 < F min	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5119	LSB-BSE1: operation winch 2 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D511F	LSB-BSE1: operation winch 2 Shut off LMB not active operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	
1D5120	LSB-BSE1: operation winch 2 LMB shut-down operational shut down release winch 2 in the control screen	A361		B	
1D5121	LSB-BSE1: operation winch 2 Shut-down measuring point 1 > F max - operation	A361		B	
1D5122	LSB-BSE1: operation winch 2 Shut-down measuring point 1 > F max - assembly	A361		B	
1D5124	LSB-BSE1: operation winch 2 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5125	LSB-BSE1: operation winch 2 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5126	LSB-BSE1: operation winch 2 Shut-down upper limit angle derrick OGWD operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A361		B	
1D5127	LSB-BSE1: operation winch 2 Shut-down lower limit angle derrick UGWD operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D5129	LSB-BSE1: operation winch 2 winch blocked (C-key monitor) operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D512A	LSB-BSE1: operation winch 2 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A361		B	
1D512E	LSB-BSE1: operation winch 2 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D512F	LSB-BSE1: operation winch 2 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A361		B	
1D5130	LSB-BSE1: operation winch 2 master switch 1 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A361		B	
1D5131	LSB-BSE1: operation winch 2 master switch 2 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D5133	LSB-BSE1: operation winch 2 Shut-down parallel op. differential path between winches too great	A361		B	
1D5137	LSB-BSE1: operation winch 2 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A361		B	
1D5139	LSB-BSE1: operation winch 2 seat contact shut-down operational shut down Actuate seat contact or press deadman	A361		B	
1D513E	LSB-BSE1: operation winch 2 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5144	LSB-BSE1: operation winch 2 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5149	LSB-BSE1: operation winch 2 Shut-down hoist limit switch 4 operational shut down	A361		B	
1D514A	LSB-BSE1: operation winch 2 Shut off Hoist limit switch 5 operational shut down	A361		B	
1D514B	LSB-BSE1: operation winch 2 Shut off upper relative limit angle Derrick ORGWD	A361		B	
1D514E	LSB-BSE1: operation winch 2 Shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D514F	LSB-BSE1: operation winch 2 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A361		B	
1D5150	LSB-BSE1: operation winch 2 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5151	LSB-BSE1: operation winch 2 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5152	LSB-BSE1: operation winch 2 end of stroke switch shut-down 3 operational shut down	A361		B	
1D5157	LSB-BSE1: operation winch 2 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D515E	LSB-BSE1: operation winch 2 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D515F	LSB-BSE1: operation winch 2 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5162	LSB-BSE1: operation winch 2 Emerg. shut-off winch-winch rotational sensor interrupts brake control operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5163	LSB-BSE1: operation winch 2 Crane engine in overspeed Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5164	LSB-BSE1: operation winch 2 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A361		B	
1D5170	LSB-BSE1: operation winch 2 shut-down both limit switches "flap in position" defect./missing	A361		B	
1D5171	LSB-BSE1: operation winch 2 shut-down both limit switches "NA-boom 3 pos." defect./missing	A361		B	
1D5173	LSB-BSE1: operation winch 2 shut-down both limit switches "lower fly jib" defective/missing	A361		B	
1D5174	LSB-BSE1: operation winch 2 shut-down both limit switches "upper fly jib flap" defect./missing	A361		B	
1D5175	LSB-BSE1: operation winch 2 shut-down both limit switches "upper fly jib stop"defect./missing	A361		B	
1D5176	LSB-BSE1: operation winch 2 shut-down limit switch adjustable pulley-N defective/missing	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D517A	LSB-BSE1: operation winch 2 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D517B	LSB-BSE1: operation winch 2 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D517C	LSB-BSE1: operation winch 2 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D517D	LSB-BSE1: operation winch 2 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A361		B	
1D517E	LSB-BSE1: operation winch 2 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	
1D5181	LSB-BSE1: operation winch 2 end of stroke switch 1 shut-down defective operational shut down	A361		B	
1D5182	LSB-BSE1: operation winch 2 end of stroke switch 2 shut-down defective operational shut down	A361		B	
1D5183	LSB-BSE1: operation winch 2 end of stroke switch 3 shut-down defective operational shut down	A361		B	
1D5189	LSB-BSE1: operation winch 2 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D518A	LSB-BSE1: operation winch 2 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D518C	LSB-BSE1: operation winch 2 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A361		B	
1D5190	LSB-BSE1: operation winch 2 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A361		B	
1D519A	LSB-BSE1: operation winch 2 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D519B	LSB-BSE1: operation winch 2 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D51A0	LSB-BSE1: operation winch 2 Shut off Parallel op. test systems W1-W2 deviate Operation conditional switch off, may not be shunted	A361		B	
1D51A7	LSB-BSE1: operation winch 2 Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A361		B	
1D51AB	LSB-BSE1: operation winch 2 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D51AC	LSB-BSE1: operation winch 2 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D51AD	LSB-BSE1: operation winch 2 Shut off upper relative limit angle acc. reached / exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D51B2	LSB-BSE1: operation winch 2 Shut off upper relative limit angle HA reached / exceeded	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D51BA	LSB-BSE1: operation winch 2 Winch operating temp. exceeded reduce output !	A361		B	
1D51BC	LSB-BSE1: operation winch 2 UGW HA Erection force reached - activate switch boom on ground	A361		B	
1D51BF	LSB-BSE1: operation winch 2 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D51C0	LSB-BSE1: operation winch 2 Shut off test point 3 > F max - Montage	A361		B	
1D51C5	LSB-BSE1: operation winch 2 OGW main boom erection force reached - luff up derrick, lift ballast	A361		B	
1D51C7	LSB-BSE1: operation winch 2 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D51C8	LSB-BSE1: operation winch 2 Shut off test point 2 > F max - assembly	A361		B	
1D51D0	LSB-BSE1: operation winch 2 Shut off since parallel op. set up, press deadman longer Operational shut off, bypassable Set up of parallel op., change over of MS assignment in TE to parallel op. or by pressing deadman	A361		B	
1D51D1	LSB-BSE1: operation winch 2 Shut off Parallel operation Operational shut off Release shut off, for error remedy see respective system error	A361		B	
1D51E6	LSB-BSE1: operation winch 2 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D51E7	LSB-BSE1: operation winch 2 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A361		B	
1D51E8	LSB-BSE1: operation winch 2 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A361		B	
1D5203	LSB-BSE1: operation winch 3 Shut-down jib lower	A361		B	
1D5204	LSB-BSE1: operation winch 3 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A361		B	
1D5205	LSB-BSE1: operation winch 3 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D5206	LSB-BSE1: operation winch 3 upper angle limit OGW shut-down Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5207	LSB-BSE1: operation winch 3 lower angle limit UGW shut-down Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D5208	LSB-BSE1: operation winch 3 luffing up main boom shut-down working area limitation ABB	A361		B	
1D5209	LSB-BSE1: operation winch 3 luffing down main boom shut-down working area limitation ABB Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D520B	LSB-BSE1: operation winch 3 Shut-down upper limit angle ULV (geometry, load capacity chart) operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D520C	LSB-BSE1: operation winch 3 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D520D	LSB-BSE1: operation winch 3 Shut off WA-Bock bottom Operation conditional switch off, may not be shunted reel winch in until limit switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D520F	LSB-BSE1: operation winch 3 Shut off winch, brake not completely released	A361		B	
1D5210	LSB-BSE1: operation winch 3 fly jib upper stop shut-down operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	
1D5211	LSB-BSE1: operation winch 3 fly jib upper flap shut-down Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5213	LSB-BSE1: operation winch 3 shut-down as flap not positioned and angle threshold exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5218	LSB-BSE1: operation winch 3 Shut-down measuring point 1 < F min	A361		B	
1D5219	LSB-BSE1: operation winch 3 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D521C	LSB-BSE1: operation winch 3 Shut off angle sensor N top faulty / missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D521F	LSB-BSE1: operation winch 3 Shut off LMB not active operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5220	LSB-BSE1: operation winch 3 LMB shut-down operational shut down release winch 3 in control screen	A361		B	
1D5221	LSB-BSE1: operation winch 3 Shut-down measuring point 1 > F max - operation operational shut down reel winch out until crane in working area again - shunting through shutting down of working area limitation	A361		B	
1D5222	LSB-BSE1: operation winch 3 Shut-down measuring point 1 > F max - assembly	A361		B	
1D5224	LSB-BSE1: operation winch 3 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5225	LSB-BSE1: operation winch 3 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5226	LSB-BSE1: operation winch 3 Shut-down upper limit angle derrick OGWD operational shut down Move Derrick boom into op. pos. shut off cannot be bypassed	A361		B	
1D5227	LSB-BSE1: operation winch 3 Shut-down lower limit angle derrick UGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	
1D5228	LSB-BSE1: operation winch 3 Shut-down upper limit angle main boom operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	
1D5229	LSB-BSE1: operation winch 3 winch blocked (C-key monitor) operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D522A	LSB-BSE1: operation winch 3 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D522C	LSB-BSE1: operation winch 3 Shut off winch 3 spooled up from main boom control	A361		B	
1D522E	LSB-BSE1: operation winch 3 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D522F	LSB-BSE1: operation winch 3 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A361		B	
1D5230	LSB-BSE1: operation winch 3 master switch 1 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A361		B	
1D5232	LSB-BSE1: operation winch 3 master switch 3 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D5234	LSB-BSE1: operation winch 3 Shut-down limit angle main boom - derrick Operation conditional switch off, may not be shunted Wind on winch until limit angle is fallen short of - shut-down may be shunted.	A361		B	
1D5237	LSB-BSE1: operation winch 3 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A361		B	
1D5239	LSB-BSE1: operation winch 3 seat contact shut-down operational shut down Actuate seat contact or press deadman	A361		B	
1D523A	LSB-BSE1: operation winch 3 Shut off Pulley block S/D Block erroneous/missing	A361		B	
1D523B	LSB-BSE1: operation winch 3 Shut off Pulley block S/D Block operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D523C	LSB-BSE1: operation winch 3 Shut off test point 8 > F max Assembly roll	A361		B	
1D523E	LSB-BSE1: operation winch 3 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D523F	LSB-BSE1: operation winch 3 Shut off Test point 8 erroneous / missing	A361		B	
1D5244	LSB-BSE1: operation winch 3 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A361		B	
1D5249	LSB-BSE1: operation winch 3 Shut-down hoist limit switch 4 operational shut down	A361		B	
1D524A	LSB-BSE1: operation winch 3 Shut off Hoist limit switch 5 operational shut down	A361		B	
1D524B	LSB-BSE1: operation winch 3 Shut off upper relative limit angle Derrick ORGWD operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D524E	LSB-BSE1: operation winch 3 Shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D524F	LSB-BSE1: operation winch 3 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A361		B	
1D5250	LSB-BSE1: operation winch 3 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5251	LSB-BSE1: operation winch 3 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5252	LSB-BSE1: operation winch 3 end of stroke switch shut-down 3 operational shut down	A361		B	
1D5254	LSB-BSE1: operation winch 3 Shut-down overtopping guard cylinder main boom in bump stop operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A361		B	
1D5255	LSB-BSE1: operation winch 3 Shut-down overtopping guard cylinder derrick boom in bump stop	A361		B	
1D5257	LSB-BSE1: operation winch 3 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D525C	LSB-BSE1: operation winch 3 Shut off Ballast lateral incline > max value	A361		B	
1D525D	LSB-BSE1: operation winch 3 Shut off Main boom upper limit angle reached/exceeded operational shut down Winch spool out to limit angle fallen below - Shut off with assembly bypassable (danger).	A361		B	
1D525E	LSB-BSE1: operation winch 3 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A361		B	
1D525F	LSB-BSE1: operation winch 3 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5262	LSB-BSE1: operation winch 3 Emerg. shut-off winch-winch rotational sensor interrupts brake control Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5263	LSB-BSE1: operation winch 3 Crane engine in overspeed operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5264	LSB-BSE1: operation winch 3 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A361		B	
1D5266	LSB-BSE1: operation winch 3 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5267	LSB-BSE1: operation winch 3 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D526B	LSB-BSE1: operation winch 3 Shut off angle sensor S or D erroneous / missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D526C	LSB-BSE1: operation winch 3 Shut off angle between S and D too low Operational shut off Increase angle between main boom and derrick. Move winch 3 down	A361		B	
1D526F	LSB-BSE1: operation winch 3 Shut off both limit switches "WA-Bock bottom" incorrect / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5270	LSB-BSE1: operation winch 3 shut-down both limit switches "flap in position" defect./missing Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A361		B	
1D5272	LSB-BSE1: operation winch 3 shut-down both angle sensors "fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5273	LSB-BSE1: operation winch 3 shut-down both limit switches "lower fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5274	LSB-BSE1: operation winch 3 shut-down both limit switches "upper fly jib flap" defect./missing	A361		B	
1D5275	LSB-BSE1: operation winch 3 shut-down both limit switches "upper fly jib stop"defect./missing operational shut down Wind on winch until limit angle is fallen short of - shut-down may be shunted (danger).	A361		B	
1D527A	LSB-BSE1: operation winch 3 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D527B	LSB-BSE1: operation winch 3 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D527C	LSB-BSE1: operation winch 3 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D527D	LSB-BSE1: operation winch 3 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A361		B	
1D527E	LSB-BSE1: operation winch 3 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	
1D5281	LSB-BSE1: operation winch 3 end of stroke switch 1 shut-down defective operational shut down	A361		B	
1D5282	LSB-BSE1: operation winch 3 end of stroke switch 2 shut-down defective operational shut down	A361		B	
1D5283	LSB-BSE1: operation winch 3 end of stroke switch 3 shut-down defective operational shut down	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5285	LSB-BSE1: operation winch 3 Shut-down limit switch right "RFP main boom" faulty / not present	A361		B	
1D5286	LSB-BSE1: operation winch 3 Shut-down limit switch "RFP Main boom" links faulty / not present Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A361		B	
1D5287	LSB-BSE1: operation winch 3 Shut-down limit switch right "Overtop guard cyl D" faulty/not pres Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5288	LSB-BSE1: operation winch 3 Shut-down limit switch left "Overtop guard cyl D" faulty/not preS Operation conditional switch off, may not be shunted Luff down derrick boom until limit switch no longer activated - Shut-down may not be shunted	A361		B	
1D5289	LSB-BSE1: operation winch 3 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D528A	LSB-BSE1: operation winch 3 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D528C	LSB-BSE1: operation winch 3 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A361		B	
1D5290	LSB-BSE1: operation winch 3 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A361		B	
1D5298	LSB-BSE1: operation winch 3 Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A361		B	
1D5299	LSB-BSE1: operation winch 3 Shut off pressure Relapse cyl. derrick outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D529A	LSB-BSE1: operation winch 3 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D529B	LSB-BSE1: operation winch 3 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D52A7	LSB-BSE1: operation winch 3 Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A361		B	
1D52A9	LSB-BSE1: operation winch 3 Shut off limit switch RFP-S moved out le/ri erroneous/missing Shut off, cannot be bypassed Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D52AB	LSB-BSE1: operation winch 3 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D52AC	LSB-BSE1: operation winch 3 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D52AD	LSB-BSE1: operation winch 3 Shut off upper relative limit angle acc. reached / exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D52AF	LSB-BSE1: operation winch 3 Shut off Danger of collision between support and flap	A361		B	
1D52B2	LSB-BSE1: operation winch 3 Shut off upper relative limit angle HA reached / exceeded operational shut down Winch spool out to limit angle fallen below - Shut off with assembly bypassable (danger).	A361		B	
1D52BB	LSB-BSE1: operation winch 3 Shut off limit angle folded down reached luff accessories up operational shut down With the luffing, luff up winch 5 and drive out of the lower limit angle shut-off	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D52BC	LSB-BSE1: operation winch 3 UGW HA Erection force reached - activate switch boom on ground	A361		B	
1D52BF	LSB-BSE1: operation winch 3 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D52C0	LSB-BSE1: operation winch 3 Shut off test point 3 > F max - Montage	A361		B	
1D52C2	LSB-BSE1: operation winch 3 Shut off Danger of collision Derrick with S-control, F3 too small	A361		B	
1D52C5	LSB-BSE1: operation winch 3 OGW main boom erection force reached - luff up derrick, lift ballast operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D52C7	LSB-BSE1: operation winch 3 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D52C8	LSB-BSE1: operation winch 3 Shut off test point 2 > F max - assembly	A361		B	
1D52C9	LSB-BSE1: operation winch 3 Shut off test point 2 < F min	A361		B	
1D52CF	LSB-BSE1: operation winch 3 Shut off UGW Derrick - in Derrick op. window run possible	A361		B	
1D52E0	LSB-BSE1: operation winch 3 Shut off Flap bottom fixed jib not Position	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D52E1	LSB-BSE1: operation winch 3 Shut off Flap top fixed jib not Position	A361		B	
1D52E2	LSB-BSE1: operation winch 3 Shut off Danger of collision ACC with fixed jib - ACC up possible	A361		B	
1D52E6	LSB-BSE1: operation winch 3 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D52E7	LSB-BSE1: operation winch 3 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A361		B	
1D52E8	LSB-BSE1: operation winch 3 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A361		B	
1D5300	LSB-BSE1: operation winch 4 Shut off pressure sensor "RFP SA-bracket" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5303	LSB-BSE1: operation winch 4 Shut-down jib lower Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A361		B	
1D5304	LSB-BSE1: operation winch 4 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A361		B	
1D5305	LSB-BSE1: operation winch 4 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D5306	LSB-BSE1: operation winch 4 upper angle limit OGW shut-down operational shut down Wind on winch until limit angle is fallen short of - shut-down may be shunted (danger).	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5307	LSB-BSE1: operation winch 4 lower angle limit UGW shut-down Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5308	LSB-BSE1: operation winch 4 luffing up main boom shut-down working area limitation ABB	A361		B	
1D5309	LSB-BSE1: operation winch 4 luffing down main boom shut-down working area limitation ABB operational shut down Wind off winch until derrick boom is in operating position - shut-down may be shunted (danger).	A361		B	
1D530B	LSB-BSE1: operation winch 4 Shut-down upper limit angle ULV (geometry, load capacity chart)	A361		B	
1D530C	LSB-BSE1: operation winch 4 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D530D	LSB-BSE1: operation winch 4 Shut off WA-Bock bottom Operation conditional switch off, may not be shunted reel winch in until limit switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D530F	LSB-BSE1: operation winch 4 Shut off winch, brake not completely released	A361		B	
1D5310	LSB-BSE1: operation winch 4 fly jib upper stop shut-down	A361		B	
1D5311	LSB-BSE1: operation winch 4 fly jib upper flap shut-down Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A361		B	
1D5313	LSB-BSE1: operation winch 4 shut-down as flap not positioned and angle threshold exceeded	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5318	LSB-BSE1: operation winch 4 Shut-down measuring point 1 < F min operational shut down Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5319	LSB-BSE1: operation winch 4 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D531F	LSB-BSE1: operation winch 4 Shut off LMB not active operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A361		B	
1D5320	LSB-BSE1: operation winch 4 LMB shut-down operational shut down Winch 4 released in control view	A361		B	
1D5321	LSB-BSE1: operation winch 4 Shut-down measuring point 1 > F max - operation	A361		B	
1D5322	LSB-BSE1: operation winch 4 Shut-down measuring point 1 > F max - assembly	A361		B	
1D5324	LSB-BSE1: operation winch 4 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5325	LSB-BSE1: operation winch 4 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5326	LSB-BSE1: operation winch 4 Shut-down upper limit angle derrick OGWD	A361		B	
1D5327	LSB-BSE1: operation winch 4 Shut-down lower limit angle derrick UGWD Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5328	LSB-BSE1: operation winch 4 Shut-down upper limit angle main boom Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5329	LSB-BSE1: operation winch 4 winch blocked (C-key monitor) operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D532A	LSB-BSE1: operation winch 4 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A361		B	
1D532D	LSB-BSE1: operation winch 4 Shut off winch 4 spooled up from derrick control Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A361		B	
1D532E	LSB-BSE1: operation winch 4 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D532F	LSB-BSE1: operation winch 4 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A361		B	
1D5330	LSB-BSE1: operation winch 4 master switch 1 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A361		B	
1D5332	LSB-BSE1: operation winch 4 master switch 3 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D5337	LSB-BSE1: operation winch 4 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A361		B	
1D5339	LSB-BSE1: operation winch 4 seat contact shut-down operational shut down Actuate seat contact or press deadman	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D533A	LSB-BSE1: operation winch 4 Shut off Pulley block S/D Block erroneous/missing operational shut down Bring master switch to zero pos., check sensor, lines and plugs	A361		B	
1D533B	LSB-BSE1: operation winch 4 Shut off Pulley block S/D Block operational shut down Bring master switch in zero pos. Move out of shut off in opposite direction with winch	A361		B	
1D533C	LSB-BSE1: operation winch 4 Shut off test point 8 > F max Assembly roll	A361		B	
1D533E	LSB-BSE1: operation winch 4 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D533F	LSB-BSE1: operation winch 4 Shut off Test point 8 erroneous / missing	A361		B	
1D5344	LSB-BSE1: operation winch 4 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A361		B	
1D5349	LSB-BSE1: operation winch 4 Shut-down hoist limit switch 4 operational shut down	A361		B	
1D534A	LSB-BSE1: operation winch 4 Shut off Hoist limit switch 5 operational shut down	A361		B	
1D534B	LSB-BSE1: operation winch 4 Shut off upper relative limit angle Derrick ORGWD	A361		B	
1D534C	LSB-BSE1: operation winch 4 Shut off Difference angle SA-frame - Derrick too large Operation conditional switch off, may not be shunted Release master switch – error remedy via winch 4 move lower	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D534E	LSB-BSE1: operation winch 4 Shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D534F	LSB-BSE1: operation winch 4 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A361		B	
1D5350	LSB-BSE1: operation winch 4 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5351	LSB-BSE1: operation winch 4 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5352	LSB-BSE1: operation winch 4 end of stroke switch shut-down 3 operational shut down	A361		B	
1D5354	LSB-BSE1: operation winch 4 Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5355	LSB-BSE1: operation winch 4 Shut-down overtopping guard cylinder derrick boom in bump stop	A361		B	
1D5356	LSB-BSE1: operation winch 4 Shut-down angle SA-frame < minimal angle Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A361		B	
1D5357	LSB-BSE1: operation winch 4 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D5358	LSB-BSE1: operation winch 4 Shut-down guide frame - counterweight bump stop upper Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5359	LSB-BSE1: operation winch 4 Shut-down guide frame - counterweight bump stop lower Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A361		B	
1D535C	LSB-BSE1: operation winch 4 Shut off Ballast lateral incline > max value	A361		B	
1D535D	LSB-BSE1: operation winch 4 Shut off Main boom upper limit angle reached/exceeded Operational shut off Bring master switch in zero pos. Luff down main boom control winch	A361		B	
1D535E	LSB-BSE1: operation winch 4 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A361		B	
1D535F	LSB-BSE1: operation winch 4 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5362	LSB-BSE1: operation winch 4 Emerg. shut-off winch-winch rotational sensor interrupts brake control operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5363	LSB-BSE1: operation winch 4 Crane engine in overspeed Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5364	LSB-BSE1: operation winch 4 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A361		B	
1D5366	LSB-BSE1: operation winch 4 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5367	LSB-BSE1: operation winch 4 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D536B	LSB-BSE1: operation winch 4 Shut off angle sensor S or D erroneous / missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D536C	LSB-BSE1: operation winch 4 Shut off angle between S and D too low Operational shut off Increase angle between main boom and derrick. Move winch 3 down	A361		B	
1D536F	LSB-BSE1: operation winch 4 Shut off both limit switches "WA-Bock bottom" incorrect / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5370	LSB-BSE1: operation winch 4 shut-down both limit switches "flap in position" defect./missing Operation conditional switch off, may not be shunted check as to why the flap is not in position - shut-down cannot be shunted	A361		B	
1D5372	LSB-BSE1: operation winch 4 shut-down both angle sensors "fly jib" defective/missing	A361		B	
1D5373	LSB-BSE1: operation winch 4 shut-down both limit switches "lower fly jib" defective/missing Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A361		B	
1D5374	LSB-BSE1: operation winch 4 shut-down both limit switches "upper fly jib flap" defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5375	LSB-BSE1: operation winch 4 shut-down both limit switches "upper fly jib stop"defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D537A	LSB-BSE1: operation winch 4 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D537B	LSB-BSE1: operation winch 4 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D537C	LSB-BSE1: operation winch 4 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D537D	LSB-BSE1: operation winch 4 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A361		B	
1D537E	LSB-BSE1: operation winch 4 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	
1D5381	LSB-BSE1: operation winch 4 end of stroke switch 1 shut-down defective operational shut down	A361		B	
1D5382	LSB-BSE1: operation winch 4 end of stroke switch 2 shut-down defective operational shut down	A361		B	
1D5383	LSB-BSE1: operation winch 4 end of stroke switch 3 shut-down defective operational shut down	A361		B	
1D5385	LSB-BSE1: operation winch 4 Shut-down limit switch right "RFP main boom" faulty / not present Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5386	LSB-BSE1: operation winch 4 Shut-down limit switch "RFP Main boom" links faulty / not present Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A361		B	
1D5387	LSB-BSE1: operation winch 4 Shut-down limit switch right "Overtop guard cyl D" faulty/not pres	A361		B	
1D5388	LSB-BSE1: operation winch 4 Shut-down limit switch left "Overtop guard cyl D" faulty/not preS Operation conditional switch off, may not be shunted Luff down derrick boom until limit switch no longer activated - Shut-down may not be shunted	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5389	LSB-BSE1: operation winch 4 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D538A	LSB-BSE1: operation winch 4 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D538C	LSB-BSE1: operation winch 4 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A361		B	
1D538E	LSB-BSE1: operation winch 4 SA-frame Assembly cylinder shut off Ring surface block	A361		B	
1D538F	LSB-BSE1: operation winch 4 Shut off SA-Bock angle > Max angle Operational shut off, bypassable Release master switch – Error remedy through bridging assembly button	A361		B	
1D5390	LSB-BSE1: operation winch 4 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A361		B	
1D5391	LSB-BSE1: operation winch 4 Shut-down limit switch right "Limit angle SA-frame" faulty/not pres Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5392	LSB-BSE1: operation winch 4 Shut-down limit switch left "Limit angle SA-frame" faulty/not prese Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5393	LSB-BSE1: operation winch 4 Shut-down limit switch right "Lower count. block" faulty/not pre Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D5394	LSB-BSE1: operation winch 4 Shut-down limit switch left "Lower count. block" faulty/not present Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5395	LSB-BSE1: operation winch 4 Shut-down limit switch right "Upper count. block" faulty/not presen Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D5396	LSB-BSE1: operation winch 4 Shut-down limit switch left "Upper count. block" faulty / not prese Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D5397	LSB-BSE1: operation winch 4 Shut off pressure Relapse cyl. SA br. outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5398	LSB-BSE1: operation winch 4 Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5399	LSB-BSE1: operation winch 4 Shut off pressure Relapse cyl. derrick outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D539A	LSB-BSE1: operation winch 4 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D539B	LSB-BSE1: operation winch 4 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D539D	LSB-BSE1: operation winch 4 Shut off angle sensor SA-frame erroneous/missing Operation conditional switch off, may not be shunted Release master switch - error remedy see corr. system error, check sensor	A361		B	
1D539E	LSB-BSE1: operation winch 4 Shut off angle sensor "RFP SA-frame" left erroneous/missing Operation conditional switch off, may not be shunted Release master switch - error remedy see corr. system error, check sensor	A361		B	
1D539F	LSB-BSE1: operation winch 4 Shut off angle sensor "RFP SA-frame" right erroneous/missing Operation conditional switch off, may not be shunted Release master switch - error remedy see corr. system error, check sensor	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D53A1	LSB-BSE1: operation winch 4 Shut off inductive sensor RFP SA-frame left Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D53A2	LSB-BSE1: operation winch 4 Shut off inductive sensor RFP SA-frame right Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D53A7	LSB-BSE1: operation winch 4 Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A361		B	
1D53A9	LSB-BSE1: operation winch 4 Shut off limit switch RFP-S moved out le/ri erroneous/missing Shut off, cannot be bypassed Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D53AB	LSB-BSE1: operation winch 4 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D53AC	LSB-BSE1: operation winch 4 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D53AD	LSB-BSE1: operation winch 4 Shut off upper relative limit angle acc. reached / exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D53AE	LSB-BSE1: operation winch 4 Shut off upper erection derrick angle reached / F3min reached	A361		B	
1D53AF	LSB-BSE1: operation winch 4 Shut off Danger of collision between support and flap	A361		B	
1D53B2	LSB-BSE1: operation winch 4 Shut off upper relative limit angle HA reached / exceeded	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D53BB	LSB-BSE1: operation winch 4 Shut off limit angle folded down reached luff accessories up operational shut down With the luffing, luff up winch 5 and drive out of the lower limit angle shut-off	A361		B	
1D53BC	LSB-BSE1: operation winch 4 UGW HA Erection force reached - activate switch boom on ground	A361		B	
1D53BF	LSB-BSE1: operation winch 4 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D53C0	LSB-BSE1: operation winch 4 Shut off test point 3 > F max - Montage	A361		B	
1D53C1	LSB-BSE1: operation winch 4 Shut off F1 too large take down main boom	A361		B	
1D53C7	LSB-BSE1: operation winch 4 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D53C8	LSB-BSE1: operation winch 4 Shut off test point 2 > F max - assembly	A361		B	
1D53C9	LSB-BSE1: operation winch 4 Shut off test point 2 < F min	A361		B	
1D53CF	LSB-BSE1: operation winch 4 Shut off UGW Derrick - in Derrick op. window run possible	A361		B	
1D53E0	LSB-BSE1: operation winch 4 Shut off Flap bottom fixed jib not Position	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D53E1	LSB-BSE1: operation winch 4 Shut off Flap top fixed jib not Position	A361		B	
1D53E6	LSB-BSE1: operation winch 4 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D53E7	LSB-BSE1: operation winch 4 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A361		B	
1D53E8	LSB-BSE1: operation winch 4 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A361		B	
1D5403	LSB-BSE1: operation winch 5 Shut-down jib lower	A361		B	
1D5404	LSB-BSE1: operation winch 5 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A361		B	
1D5405	LSB-BSE1: operation winch 5 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D5406	LSB-BSE1: operation winch 5 upper angle limit OGW shut-down Operation conditional switch off, may not be shunted Spool up - out winch 5 is only permitted at main boom positions small limit angle	A361		B	
1D5407	LSB-BSE1: operation winch 5 lower angle limit UGW shut-down Operation conditional switch off, may not be shunted Wind off winch until pressure is once again within the desired range - shut-down may not be shunted .	A361		B	
1D5408	LSB-BSE1: operation winch 5 luffing up main boom shut-down working area limitation ABB Operation conditional switch off, may not be shunted check as to why the flap is not in position - shut-down cannot be shunted	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5409	LSB-BSE1: operation winch 5 luffing down main boom shut-down working area limitation ABB Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D540B	LSB-BSE1: operation winch 5 Shut-down upper limit angle ULV (geometry, load capacity chart) operational shut down reel winch in until crane in working area again - shunting through shutting down of working area limitation	A361		B	
1D540C	LSB-BSE1: operation winch 5 Shut-down lower limit value LLV (geometry, load capacity chart) Operation conditional switch off, may not be shunted Luff up jib until limit switch no longer activated - shut-down may not be shunted	A361		B	
1D540D	LSB-BSE1: operation winch 5 Shut off WA-Bock bottom Operation conditional switch off, may not be shunted reel winch in until limit switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D540F	LSB-BSE1: operation winch 5 Shut off winch, brake not completely released	A361		B	
1D5410	LSB-BSE1: operation winch 5 fly jib upper stop shut-down operational shut down reel winch out until crane in working area again - shunting through shutting down of working area limitation	A361		B	
1D5411	LSB-BSE1: operation winch 5 fly jib upper flap shut-down operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5413	LSB-BSE1: operation winch 5 shut-down as flap not positioned and angle threshold exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5414	LSB-BSE1: operation winch 5 pressure retaining cylinder RFP N shut-down outside set range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5416	LSB-BSE1: operation winch 5 luffing up accessory shut-down working area limitation ABB Operation conditional switch off, may not be shunted Luff up main boom during erection procedure, luff down main boom or accessory during setting down procedure.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5417	LSB-BSE1: operation winch 5 luffing down accessory shut-down working area limitation ABB operational shut down reel winch in until the radius is within the load chart again - shut-down can be shunted (danger)	A361		B	
1D5418	LSB-BSE1: operation winch 5 Shut-down measuring point 1 < F min	A361		B	
1D5419	LSB-BSE1: operation winch 5 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D541C	LSB-BSE1: operation winch 5 Shut off angle sensor N top faulty / missing Operation conditional switch off, may not be shunted Luff down jib until limit switch no longer activated - shut-down may not be activated	A361		B	
1D541F	LSB-BSE1: operation winch 5 Shut off LMB not active operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A361		B	
1D5420	LSB-BSE1: operation winch 5 LMB shut-down operational shut down Winch 5 released in control view	A361		B	
1D5421	LSB-BSE1: operation winch 5 Shut-down measuring point 1 > F max - operation	A361		B	
1D5422	LSB-BSE1: operation winch 5 Shut-down measuring point 1 > F max - assembly operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	
1D5424	LSB-BSE1: operation winch 5 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5425	LSB-BSE1: operation winch 5 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5426	LSB-BSE1: operation winch 5 Shut-down upper limit angle derrick OGWD	A361		B	
1D5427	LSB-BSE1: operation winch 5 Shut-down lower limit angle derrick UGWD Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5428	LSB-BSE1: operation winch 5 Shut-down upper limit angle main boom Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5429	LSB-BSE1: operation winch 5 winch blocked (C-key monitor) operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D542A	LSB-BSE1: operation winch 5 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A361		B	
1D542E	LSB-BSE1: operation winch 5 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D542F	LSB-BSE1: operation winch 5 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A361		B	
1D5430	LSB-BSE1: operation winch 5 master switch 1 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D5431	LSB-BSE1: operation winch 5 master switch 2 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A361		B	
1D5432	LSB-BSE1: operation winch 5 master switch 3 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5437	LSB-BSE1: operation winch 5 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A361		B	
1D5438	LSB-BSE1: operation winch 5 Shut-down upper limit angle accessory	A361		B	
1D5439	LSB-BSE1: operation winch 5 seat contact shut-down operational shut down Actuate seat contact or press deadman	A361		B	
1D543E	LSB-BSE1: operation winch 5 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5444	LSB-BSE1: operation winch 5 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A361		B	
1D5449	LSB-BSE1: operation winch 5 Shut-down hoist limit switch 4 operational shut down	A361		B	
1D544A	LSB-BSE1: operation winch 5 Shut off Hoist limit switch 5 operational shut down	A361		B	
1D544B	LSB-BSE1: operation winch 5 Shut off upper relative limit angle Derrick ORGWD operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D544E	LSB-BSE1: operation winch 5 Shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D544F	LSB-BSE1: operation winch 5 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5450	LSB-BSE1: operation winch 5 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5451	LSB-BSE1: operation winch 5 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5452	LSB-BSE1: operation winch 5 end of stroke switch shut-down 3 operational shut down	A361		B	
1D5457	LSB-BSE1: operation winch 5 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D545E	LSB-BSE1: operation winch 5 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A361		B	
1D545F	LSB-BSE1: operation winch 5 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5462	LSB-BSE1: operation winch 5 Emerg. shut-off winch-winch rotational sensor interrupts brake control operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5463	LSB-BSE1: operation winch 5 Crane engine in overspeed Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5464	LSB-BSE1: operation winch 5 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A361		B	
1D546F	LSB-BSE1: operation winch 5 Shut off both limit switches "WA-Bock bottom" incorrect / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5470	LSB-BSE1: operation winch 5 shut-down both limit switches "flap in position" defect./missing	A361		B	
1D5472	LSB-BSE1: operation winch 5 shut-down both angle sensors "fly jib" defective/missing Operation conditional switch off, may not be shunted Luff down jib until limit switch no longer activated - shut-down may not be activated	A361		B	
1D5473	LSB-BSE1: operation winch 5 shut-down both limit switches "lower fly jib" defective/missing	A361		B	
1D5474	LSB-BSE1: operation winch 5 shut-down both limit switches "upper fly jib flap" defect./missing	A361		B	
1D5475	LSB-BSE1: operation winch 5 shut-down both limit switches "upper fly jib stop"defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D547A	LSB-BSE1: operation winch 5 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D547B	LSB-BSE1: operation winch 5 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D547C	LSB-BSE1: operation winch 5 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D547D	LSB-BSE1: operation winch 5 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A361		B	
1D547E	LSB-BSE1: operation winch 5 Shut off Radio BTT-E in crane mode active	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5481	LSB-BSE1: operation winch 5 end of stroke switch 1 shut-down defective operational shut down	A361		B	
1D5482	LSB-BSE1: operation winch 5 end of stroke switch 2 shut-down defective operational shut down	A361		B	
1D5483	LSB-BSE1: operation winch 5 end of stroke switch 3 shut-down defective operational shut down	A361		B	
1D5489	LSB-BSE1: operation winch 5 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D548A	LSB-BSE1: operation winch 5 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D548C	LSB-BSE1: operation winch 5 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A361		B	
1D5490	LSB-BSE1: operation winch 5 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A361		B	
1D549A	LSB-BSE1: operation winch 5 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D549B	LSB-BSE1: operation winch 5 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D549C	LSB-BSE1: operation winch 5 Shut off pressure sensor RFP-N erroneous / missing	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D54AB	LSB-BSE1: operation winch 5 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D54AC	LSB-BSE1: operation winch 5 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A361		B	
1D54AD	LSB-BSE1: operation winch 5 Shut off upper relative limit angle acc. reached / exceeded	A361		B	
1D54AF	LSB-BSE1: operation winch 5 Shut off Danger of collision between support and flap	A361		B	
1D54BB	LSB-BSE1: operation winch 5 Shut off limit angle folded down reached luff accessories up operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A361		B	
1D54BC	LSB-BSE1: operation winch 5 UGW HA Erection force reached - activate switch boom on ground	A361		B	
1D54BF	LSB-BSE1: operation winch 5 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D54C0	LSB-BSE1: operation winch 5 Shut off test point 3 > F max - Montage	A361		B	
1D54C7	LSB-BSE1: operation winch 5 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D54C8	LSB-BSE1: operation winch 5 Shut off test point 2 > F max - assembly	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D54C9	LSB-BSE1: operation winch 5 Shut off test point 2 < F min	A361		B	
1D54E0	LSB-BSE1: operation winch 5 Shut off Flap bottom fixed jib not Position	A361		B	
1D54E1	LSB-BSE1: operation winch 5 Shut off Flap top fixed jib not Position	A361		B	
1D54E2	LSB-BSE1: operation winch 5 Shut off Danger of collision ACC with fixed jib - ACC up possible	A361		B	
1D54E6	LSB-BSE1: operation winch 5 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D54E7	LSB-BSE1: operation winch 5 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A361		B	
1D54E8	LSB-BSE1: operation winch 5 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A361		B	
1D5504	LSB-BSE1: operation winch 6 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A361		B	
1D5505	LSB-BSE1: operation winch 6 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D550F	LSB-BSE1: operation winch 6 Shut off winch, brake not completely released	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5518	LSB-BSE1: operation winch 6 Shut-down measuring point 1 < F min operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D5519	LSB-BSE1: operation winch 6 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D551F	LSB-BSE1: operation winch 6 Shut off LMB not active operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A361		B	
1D5520	LSB-BSE1: operation winch 6 LMB shut-down operational shut down Winch 6 released in control view	A361		B	
1D5521	LSB-BSE1: operation winch 6 Shut-down measuring point 1 > F max - operation	A361		B	
1D5522	LSB-BSE1: operation winch 6 Shut-down measuring point 1 > F max - assembly	A361		B	
1D5524	LSB-BSE1: operation winch 6 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5525	LSB-BSE1: operation winch 6 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A361		B	
1D5526	LSB-BSE1: operation winch 6 Shut-down upper limit angle derrick OGWD Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A361		B	
1D5527	LSB-BSE1: operation winch 6 Shut-down lower limit angle derrick UGWD	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5529	LSB-BSE1: operation winch 6 winch blocked (C-key monitor) operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A361		B	
1D552A	LSB-BSE1: operation winch 6 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A361		B	
1D552E	LSB-BSE1: operation winch 6 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D552F	LSB-BSE1: operation winch 6 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A361		B	
1D5531	LSB-BSE1: operation winch 6 master switch 2 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A361		B	
1D5532	LSB-BSE1: operation winch 6 master switch 3 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A361		B	
1D5537	LSB-BSE1: operation winch 6 Winch rotational sensor faulty / missing operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5539	LSB-BSE1: operation winch 6 seat contact shut-down operational shut down Actuate seat contact or press deadman	A361		B	
1D553C	LSB-BSE1: operation winch 6 Shut off test point 8 > F max Assembly roll	A361		B	
1D553E	LSB-BSE1: operation winch 6 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D553F	LSB-BSE1: operation winch 6 Shut off Test point 8 erroneous / missing	A361		B	
1D5544	LSB-BSE1: operation winch 6 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A361		B	
1D5549	LSB-BSE1: operation winch 6 Shut-down hoist limit switch 4 operational shut down	A361		B	
1D554A	LSB-BSE1: operation winch 6 Shut off Hoist limit switch 5 operational shut down	A361		B	
1D554B	LSB-BSE1: operation winch 6 Shut off upper relative limit angle Derrick ORGWD operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D554E	LSB-BSE1: operation winch 6 Shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D554F	LSB-BSE1: operation winch 6 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A361		B	
1D5550	LSB-BSE1: operation winch 6 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5551	LSB-BSE1: operation winch 6 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A361		B	
1D5552	LSB-BSE1: operation winch 6 end of stroke switch shut-down 3 operational shut down	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5557	LSB-BSE1: operation winch 6 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D555E	LSB-BSE1: operation winch 6 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A361		B	
1D555F	LSB-BSE1: operation winch 6 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5562	LSB-BSE1: operation winch 6 Emerg. shut-off winch-winch rotational sensor interrupts brake control Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5563	LSB-BSE1: operation winch 6 Crane engine in overspeed	A361		B	
1D5564	LSB-BSE1: operation winch 6 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A361		B	
1D557A	LSB-BSE1: operation winch 6 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D557B	LSB-BSE1: operation winch 6 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D557C	LSB-BSE1: operation winch 6 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D557D	LSB-BSE1: operation winch 6 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D557E	LSB-BSE1: operation winch 6 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	
1D5581	LSB-BSE1: operation winch 6 end of stroke switch 1 shut-down defective operational shut down	A361		B	
1D5582	LSB-BSE1: operation winch 6 end of stroke switch 2 shut-down defective operational shut down	A361		B	
1D5583	LSB-BSE1: operation winch 6 end of stroke switch 3 shut-down defective operational shut down	A361		B	
1D5589	LSB-BSE1: operation winch 6 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D558A	LSB-BSE1: operation winch 6 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A361		B	
1D558C	LSB-BSE1: operation winch 6 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A361		B	
1D5590	LSB-BSE1: operation winch 6 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A361		B	
1D559A	LSB-BSE1: operation winch 6 Shut off Pressure relapse cyl. Main boom less than min. pressure	A361		B	
1D559B	LSB-BSE1: operation winch 6 Shut off Pressure relapse cyl. Derrick less than min. pressure	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D55BF	LSB-BSE1: operation winch 6 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D55C7	LSB-BSE1: operation winch 6 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A361		B	
1D55E6	LSB-BSE1: operation winch 6 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A361		B	
1D55E7	LSB-BSE1: operation winch 6 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A361		B	
1D55E8	LSB-BSE1: operation winch 6 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A361		B	
1D5601	LSB-BSE1: operation telescoping Shut off TY-frame not in position operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D5602	LSB-BSE1: operation telescoping Shut off TY Latch not open operational shut down Press button "Preselection page A/B" until both pages A and B are preselected	A361		B	
1D5608	LSB-BSE1: operation telescoping shut-down tele OUT main boom working area limitation ABB	A361		B	
1D5609	LSB-BSE1: operation telescoping shut-down tele IN main boom working area limitation ABB	A361		B	
1D560D	LSB-BSE1: operation telescoping Shut off Upper limit length OGL (geometry, Load chart)	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D560E	LSB-BSE1: operation telescoping Shut off Lower limit length UGL (geometry, Load chart)	A361		B	
1D5610	LSB-BSE1: operation telescoping fly jib upper stop shut-down	A361		B	
1D5611	LSB-BSE1: operation telescoping fly jib upper flap shut-down	A361		B	
1D5612	LSB-BSE1: operation telescoping shut-down as lower fly jib and NA-boom 3 not positioned	A361		B	
1D5614	LSB-BSE1: operation telescoping pressure retaining cylinder RFP N shut-down outside set range	A361		B	
1D5619	LSB-BSE1: operation telescoping no or invalid operation mode shut-down	A361		B	
1D561E	LSB-BSE1: operation telescoping Shut off tipping danger forward	A361		B	
1D561F	LSB-BSE1: operation telescoping Shut off LMB not active	A361		B	
1D5620	LSB-BSE1: operation telescoping LMB shut-down	A361		B	
1D5621	LSB-BSE1: operation telescoping shut-down release of extending LMB	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5622	LSB-BSE1: operation telescoping shut-down tipping risk to rear	A361		B	
1D5624	LSB-BSE1: operation telescoping Shut-off angle TY-tensioning not within set specification operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D5625	LSB-BSE1: operation telescoping Shut off Pressure switch reports brake TY-winch left closed operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D5626	LSB-BSE1: operation telescoping Shut off Pressure switch reports brake TY-winch right closed operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D5630	LSB-BSE1: operation telescoping master switch 1 defective/missing	A361		B	
1D5631	LSB-BSE1: operation telescoping master switch 2 defective/missing	A361		B	
1D5635	LSB-BSE1: operation telescoping right foot tipping switch defective/missing	A361		B	
1D5637	LSB-BSE1: operation telescoping Winch turn sensor TY Winch erroneous / missing operational shut down Release master switch - select telescope in function	A361		B	
1D5639	LSB-BSE1: operation telescoping seat contact shut-down	A361		B	
1D563E	LSB-BSE1: operation telescoping Shut off master switch zero position forced	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5640	LSB-BSE1: operation telescoping length measurement shut-down defective/missing	A361		B	
1D5641	LSB-BSE1: operation telescoping emergency op. telescope activated, caution switch-offs ineffective operational shut down Telescope in until hoist limit switch is no longer actuated	A361		B	
1D5644	LSB-BSE1: operation telescoping Shut-off crane engine not running operational shut down Telescope in until hoist limit switch is no longer actuated	A361		B	
1D5649	LSB-BSE1: operation telescoping Shut-down hoist limit switch 4	A361		B	
1D564A	LSB-BSE1: operation telescoping Shut off Hoist limit switch 5	A361		B	
1D564E	LSB-BSE1: operation telescoping Shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D564F	LSB-BSE1: operation telescoping Shut off control is off	A361		B	
1D5650	LSB-BSE1: operation telescoping end of stroke switch shut-down 1 operational shut down Telescope in until hoist limit switch is no longer actuated	A361		B	
1D5651	LSB-BSE1: operation telescoping end of stroke switch shut-down 2 operational shut down Telescope in until hoist limit switch is no longer actuated	A361		B	
1D5652	LSB-BSE1: operation telescoping end of stroke switch shut-down 3 operational shut down Telescope in until hoist limit switch is no longer actuated	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D565E	LSB-BSE1: operation telescoping Shut off limit switch "Main boom steep ok" erroneous / missing	A361		B	
1D565F	LSB-BSE1: operation telescoping Shut-down limit switch main boom steep	A361		B	
1D5660	LSB-BSE1: operation telescoping unbolting telescope not possible, cylinder is not bolted	A361		B	
1D5661	LSB-BSE1: operation telescoping unbolting telescope not possible, no LMB release	A361		B	
1D5662	LSB-BSE1: operation telescoping unbolting telescope/cylinder not possible, simultaneous selection	A361		B	
1D5663	LSB-BSE1: operation telescoping unbolting cylinder not possible, telescope is not bolted	A361		B	
1D5664	LSB-BSE1: operation telescoping unbolting cylinder not possible, automatic system adjusted	A361		B	
1D5665	LSB-BSE1: operation telescoping unbolting telescope not possible, automatic system adjusted	A361		B	
1D5670	LSB-BSE1: operation telescoping shut-down both limit switches "flap in position" defect./missing	A361		B	
1D5671	LSB-BSE1: operation telescoping shut-down both limit switches "NA-boom 3 pos." defect./missing	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5672	LSB-BSE1: operation telescoping shut-down both angle sensors "fly jib" defective/missing	A361		B	
1D5673	LSB-BSE1: operation telescoping shut-down both limit switches "lower fly jib" defective/missing operational shut down extend tele cylinder until limit switch no longer activated - shut-down cannot be shunted	A361		B	
1D5674	LSB-BSE1: operation telescoping shut-down both limit switches "upper fly jib flap" defect./missing	A361		B	
1D5675	LSB-BSE1: operation telescoping shut-down both limit switches "upper fly jib stop"defect./missing	A361		B	
1D5677	LSB-BSE1: operation telescoping Shut off Limit switch TY-frame Position right erroneous / missing operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D5678	LSB-BSE1: operation telescoping Shut off Limit switch TY-frame Position left erroneous / missing operational shut down activate "TA-strut luffing up" key until the symbol "TA-strut in position" is displayed	A361		B	
1D5681	LSB-BSE1: operation telescoping end of stroke switch 1 shut-down defective	A361		B	
1D5682	LSB-BSE1: operation telescoping end of stroke switch 2 shut-down defective	A361		B	
1D5683	LSB-BSE1: operation telescoping end of stroke switch 3 shut-down defective	A361		B	
1D5685	LSB-BSE1: operation telescoping Shut-off rotary sensor TY-tensioning left-hand faulty / missing operational shut down Fold in TA-frame to determined angle via key "Fold in TY-tensioning" in the instrument panel	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5686	LSB-BSE1: operation telescoping Shut-off rotary sensor TY-tensioning right-hand faulty / missing operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D5689	LSB-BSE1: operation telescoping Shut-down hoist limit switch 4 faulty	A361		B	
1D568A	LSB-BSE1: operation telescoping Shut off Hoist limit switch 5 erroneous	A361		B	
1D5690	LSB-BSE1: operation telescoping cylinder bolting is neither unpinned nor in a pivot section	A361		B	
1D5691	LSB-BSE1: operation telescoping telescope OUT/IN shut-down, cylinder is not pinned	A361		B	
1D5692	LSB-BSE1: operation telescoping cylinder OUT shut-down, pressure threshold reached	A361		B	
1D5697	LSB-BSE1: operation telescoping Shut off TY Side A not preselected	A361		B	
1D5698	LSB-BSE1: operation telescoping Shut off TY Side B not preselected operational shut down Release master switch - select telescope in function	A361		B	
1D5699	LSB-BSE1: operation telescoping Limit switch "Gear number Winch A" erroneous / missing operational shut down activate "open pawl" key until the symbol "pawl opened" is displayed	A361		B	
1D569A	LSB-BSE1: operation telescoping Limit switch "Gear number Winch B" erroneous / missing operational shut down Press button "Preselection page A/B" until both pages A and B are preselected	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D569B	LSB-BSE1: operation telescoping Shut off TY Winch A is spooled out	A361		B	
1D569C	LSB-BSE1: operation telescoping Shut off TY Winch B is spooled out	A361		B	
1D5708	LSB-BSE1: operation luffing luffing up of main boom shut-down working area limitation ABB	A361		B	
1D5709	LSB-BSE1: operation luffing luffing down of main boom shut-down working area limitation ABB	A361		B	
1D570B	LSB-BSE1: operation luffing Shut-down upper limit angle ULV (geometry, load capacity chart) operational shut down luff main boom down until crane is in working area again - shunting through shut-down of working area limitation	A361		B	
1D570C	LSB-BSE1: operation luffing Shut-down lower limit value LLV (geometry, load capacity chart) operational shut down luff main boom up until crane in working area again - shunting through shut-down of working area limitation	A361		B	
1D5719	LSB-BSE1: operation luffing no or invalid operation mode shut-down operational shut down eliminate cause of the "LMB Stop" see error report LMB - shut-down can be shunted (danger)	A361		B	
1D571E	LSB-BSE1: operation luffing Shut off tipping danger forward	A361		B	
1D571F	LSB-BSE1: operation luffing Shut off LMB not active operational shut down briefly release master switch, or error elimination see corresponding system error	A361		B	
1D5720	LSB-BSE1: operation luffing LMB shut-down operational shut down briefly release master switch, or error elimination see corresponding system error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D572F	LSB-BSE1: operation luffing Master switch mode not active	A361		B	
1D5730	LSB-BSE1: operation luffing master switch 1 defective/missing operational shut down sit down (seat limit switch) or dead man (in master switch) or check LICCON input, sensor lines, sensor	A361		B	
1D5731	LSB-BSE1: operation luffing master switch 2 defective/missing operational shut down Start crane engine. For test purposes actuate bridging "without engine" (control ON without engine).	A361		B	
1D5739	LSB-BSE1: operation luffing seat contact shut-down	A361		B	
1D573E	LSB-BSE1: operation luffing Shut off master switch zero position forced	A361		B	
1D5744	LSB-BSE1: operation luffing Shut-off crane engine not running	A361		B	
1D5747	LSB-BSE1: operation luffing Warning luffing up, dropping of load with reduction of reach operational shut down Luff main boom up until hoist limit switch is no longer actuated	A361		B	
1D5748	LSB-BSE1: operation luffing Shut-down luffing up, dropping of load with reduction of reach operational shut down Luff main boom up until hoist limit switch is no longer actuated	A361		B	
1D5749	LSB-BSE1: operation luffing Shut-down hoist limit switch 4	A361		B	
1D574A	LSB-BSE1: operation luffing Shut off Hoist limit switch 5 operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D574B	LSB-BSE1: operation luffing Reducing erection forces at reduction radius	A361		B	
1D574E	LSB-BSE1: operation luffing Shut off emerg. off not active	A361		B	
1D574F	LSB-BSE1: operation luffing Shut off control is off	A361		B	
1D5750	LSB-BSE1: operation luffing end of stroke switch shut-down 1 operational shut down Luff main boom up until hoist limit switch is no longer actuated	A361		B	
1D5751	LSB-BSE1: operation luffing end of stroke switch shut-down 2 operational shut down Luff main boom up until hoist limit switch is no longer actuated	A361		B	
1D5752	LSB-BSE1: operation luffing end of stroke switch shut-down 3 operational shut down Luff main boom up until hoist limit switch is no longer actuated	A361		B	
1D5760	LSB-BSE1: operation luffing Shut-down limit switch main boom steep operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A361		B	
1D5781	LSB-BSE1: operation luffing end of stroke switch 1 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A361		B	
1D5782	LSB-BSE1: operation luffing end of stroke switch 2 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A361		B	
1D5783	LSB-BSE1: operation luffing end of stroke switch 3 shut-down defective operational shut down Error remedying see corresponding system error - shut-down may be shunted (danger)	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5789	LSB-BSE1: operation luffing Shut-down hoist limit switch 4 faulty	A361		B	
1D578A	LSB-BSE1: operation luffing Shut off Hoist limit switch 5 erroneous operational shut down Set down load with "Hoist gear down" (if necessary, replace luffing cyl.)	A361		B	
1D5801	LSB-BSE1: operation slewing Shut-off ballast not lifted, confirm with key button Operational shut off Lift up ballast and confirm with "Ballast lifted" key button	A361		B	
1D5802	LSB-BSE1: operation slewing Shut-down counterweight on ground Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5803	LSB-BSE1: operation slewing Shut-down support counterweight carriage is not retracted Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5804	LSB-BSE1: operation slewing Shut-down wheels counterweight carriage not in rotary position Operation conditional switch off, may not be shunted With the pre-selection key "Rotary travel BW" turn the wheels of the counterweight carriage (BW) into turning position	A361		B	
1D5806	LSB-BSE1: operation slewing Shutdown slewing gear brake not released	A361		B	
1D5807	LSB-BSE1: operation slewing Shut off Slewing gear coasting not possible, pressure too high	A361		B	
1D5808	LSB-BSE1: operation slewing shut-down slewing right working area limitation ABB Operation conditional switch off, may not be shunted eliminate error see corresponding system error	A361		B	
1D5809	LSB-BSE1: operation slewing shut-down slewing left working area limitation ABB	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D580A	LSB-BSE1: operation slewing Shut off Ballast/Ballast trailer swing Block	A361		B	
1D5810	LSB-BSE1: operation slewing Shut-down free swing gear working area limitation ABB is active	A361		B	
1D5813	LSB-BSE1: operation slewing Shut off slewing gear non-permissible mode operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A361		B	
1D5819	LSB-BSE1: operation slewing no or invalid operation mode shut-down operational shut down slew left until crane is within support area again - shut-down can be shunted (danger)	A361		B	
1D581F	LSB-BSE1: operation slewing Shut off LMB not active operational shut down check why LMB not running. Operating mode OK, sensor defective, read out LMB error	A361		B	
1D5820	LSB-BSE1: operation slewing shut-down slewing right LMB Error is shown as system error	A361		B	
1D5821	LSB-BSE1: operation slewing shut-down slewing left LMB Error is shown as system error	A361		B	
1D5822	LSB-BSE1: operation slewing Shut-down right-hand swing maximum load exceeded	A361		B	
1D5823	LSB-BSE1: operation slewing Shut-down left-hand swing maximum load exceeded Operation conditional switch off, may not be shunted eliminate error see corresponding system error	A361		B	
1D5824	LSB-BSE1: operation slewing Shut-down free swing gear swing area limitation load is on	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D582F	LSB-BSE1: operation slewing Master switch mode not active operational shut down slew right until crane is in working area again - shunting through shut-down of working area limitation	A361		B	
1D5831	LSB-BSE1: operation slewing Master switch 2 faulty/not present operational shut down Start crane engine. For test purposes actuate bridging "without engine" (control ON without engine).	A361		B	
1D5837	LSB-BSE1: operation slewing Selection Turning without selection parking brake slewing gear open Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5839	LSB-BSE1: operation slewing seat contact shut-down report of error, otherwise no reaction	A361		B	
1D583C	LSB-BSE1: operation slewing Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	
1D583E	LSB-BSE1: operation slewing Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5844	LSB-BSE1: operation slewing Shut-off crane engine not running	A361		B	
1D5849	LSB-BSE1: operation slewing Shut off pressure difference ballast cylinder A/B too large Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D584D	LSB-BSE1: operation slewing Shut off radio interruption	A361		B	
1D584E	LSB-BSE1: operation slewing Shut off emerg. off not active	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D584F	LSB-BSE1: operation slewing Shut off control is off	A361		B	
1D5852	LSB-BSE1: operation slewing Shut-down measuring point 1 > F max - operation Operational shut off Move out with another gear from shut off. Run F1 force improved function winch 3,4 Ballast cylinder	A361		B	
1D5853	LSB-BSE1: operation slewing Shut-down measuring point 1 > F max - assembly Operational shut off Move out with another gear from shut off. Run F1 force improved function winch 3,4 Ballast cylinder	A361		B	
1D5854	LSB-BSE1: operation slewing Shut-down overtopping guard cylinder main boom in bump stop operational shut down Press "A-Stop" key or "B-Stop" key to move only one ballast cylinder to equalize forces in side A/B	A361		B	
1D5855	LSB-BSE1: operation slewing Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5858	LSB-BSE1: operation slewing Shut-down guide frame - counterweight bump stop upper Operation conditional switch off, may not be shunted With the pre-selection key "Rotary travel BW" turn the wheels of the counterweight carriage (BW) into turning position	A361		B	
1D5859	LSB-BSE1: operation slewing Shut-down guide frame - counterweight bump stop lower operational shut down slew left until crane is within support area again - shut-down can be shunted (danger)	A361		B	
1D5870	LSB-BSE1: operation slewing Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5871	LSB-BSE1: operation slewing Shut-down lim switch "Count. on ground" vo. right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5872	LSB-BSE1: operation slewing Shut-down lim switch "Count. on ground" hi. left faulty/not present Operational shut-down, shunable via raised key switch B/BW - only switch on if B/BW safely raised If possible raise the wheels via lifting the load or reducing the mounted suspended counterweight	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5873	LSB-BSE1: operation slewing Shut-down lim switch "Count. on ground" hi. right faulty/not presen Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5874	LSB-BSE1: operation slewing Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Retract support cylinder counterweight carriage completely	A361		B	
1D5875	LSB-BSE1: operation slewing Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5876	LSB-BSE1: operation slewing Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D5877	LSB-BSE1: operation slewing Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D5878	LSB-BSE1: operation slewing Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D5879	LSB-BSE1: operation slewing Shut off Radio assembly BTT-E max pulled Ballast exceeded	A361		B	
1D587A	LSB-BSE1: operation slewing Shut off limit switch B/BW swing left front erroneous/missing Operation conditional switch off, may not be shunted	A361		B	
1D587B	LSB-BSE1: operation slewing Shut off limit switch B/BW swing right front erroneous/missing Operation conditional switch off, may not be shunted	A361		B	
1D587C	LSB-BSE1: operation slewing Shut off limit switch B/BW swing left rear erroneous/missing Operation conditional switch off, may not be shunted Control B/BW again into an operational position	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D587D	LSB-BSE1: operation slewing Shut off limit switch B/BW swing right rear erroneous/missing	A361		B	
1D587E	LSB-BSE1: operation slewing Shut off BT swing lateral angle sensor le/ri erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A361		B	
1D587F	LSB-BSE1: operation slewing Shut off BT swing max. lateral angle exceeded Operation conditional switch off, may not be shunted With the ballast trailer move from shut off angle in operating angle	A361		B	
1D5880	LSB-BSE1: operation slewing Shut off BT pull force sensor le/ri erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A361		B	
1D5881	LSB-BSE1: operation slewing Shut off BT pull force > Fmax Operation conditional switch off, may not be shunted With ballast trailer move into operating force	A361		B	
1D5882	LSB-BSE1: operation slewing Shut off limit switch "Ballast on ground" not on SPMT Operation conditional switch off, may not be shunted The 4 limit switches "Ballast on ground" must sit on SPMT and be switched. with ballast cylinder or winch	A361		B	
1D5885	LSB-BSE1: operation slewing Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5886	LSB-BSE1: operation slewing Shut-down limit switch "RFP Main boom" links faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5887	LSB-BSE1: operation slewing Shut-down limit switch "Overtop guard cyl D" right faulty/not prese Operation conditional switch off, may not be shunted Wind off main boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A361		B	
1D5888	LSB-BSE1: operation slewing Shut-down limit switch "Overtop guard cyl D" left faulty/not presen Operation conditional switch off, may not be shunted Wind off derrick boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5890	LSB-BSE1: operation slewing Slewing platform not bolted or impermissible bolting condition Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5893	LSB-BSE1: operation slewing Shut-down limit switch right "Lower count. block" faulty/not pre Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5894	LSB-BSE1: operation slewing Shut-down limit switch "Lower count. block" left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5895	LSB-BSE1: operation slewing Shut-down limit switch "Upper count. block" right faulty/not presen Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A361		B	
1D5896	LSB-BSE1: operation slewing Shut-down limit switch "Upper count. block" left faulty/not present Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A361		B	
1D5897	LSB-BSE1: operation slewing Shut-down limit switch "Count. bolted" right faulty/not present Operational shut-off in BT operation Check wiring, check sensor	A361		B	
1D5898	LSB-BSE1: operation slewing Shut-down limit switch "Count. bolted" left faulty/not present Operational shut-off in BT operation Check wiring, check sensor	A361		B	
1D5899	LSB-BSE1: operation slewing Ballast trailer (BW) is not pinned Operation conditional switch off, may not be shunted Check for installation to suit op. if installed/pinned check signal	A361		B	
1D589A	LSB-BSE1: operation slewing Ballast trailer (BW) is not installed (pilot contact) Operation conditional switch off, may not be shunted Check for installation to suit op. and check signal	A361		B	
1D589B	LSB-BSE1: operation slewing Shut off brake pressure BW drive brake not open Operational shut off Check brake pressure of service brake why it doesn't open	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D58B3	LSB-BSE1: operation slewing Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A361		B	
1D58EC	LSB-BSE1: operation slewing Turntable pinning without release crane control Movement is not actuated Turn actuation of other aux. users off or remedy system error	A361		B	
1D58EE	LSB-BSE1: operation slewing Slewing platform pinning without 2-Hand-button	A361		B	
1D58F1	LSB-BSE1: operation slewing Slewing platform pinning not unpinned Symbol blinking, operating mode change over prevented Check mechanics, limit switch	A361		B	1
1D5A08	LSB-BSE1: operation additional equipment Shut off Luffing up fixed jib working range limitation ABB	A361		B	
1D5A09	LSB-BSE1: operation additional equipment Shut off Luffing down fixed jib working range limitation ABB	A361		B	
1D5A0B	LSB-BSE1: operation additional equipment Shut-down luffing up fixed tip upper limit value ULV (GEO, LCC)	A361		B	
1D5A0C	LSB-BSE1: operation additional equipment Shut-down luffing down fixed tip lower limit value LLV (GEO, LCC)	A361		B	
1D5A18	LSB-BSE1: operation additional equipment Shut-off incorrect operation type, incorrectly set up or not sold	A361		B	
1D5A19	LSB-BSE1: operation additional equipment no or invalid operation mode shut-down	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5A1E	LSB-BSE1: operation additional equipment Shut off tipping danger forward	A361		B	
1D5A1F	LSB-BSE1: operation additional equipment Shut off LMB not active	A361		B	
1D5A20	LSB-BSE1: operation additional equipment LMB shut-down	A361		B	
1D5A2F	LSB-BSE1: operation additional equipment Master switch mode not active	A361		B	
1D5A30	LSB-BSE1: operation additional equipment master switch 1 defective/missing	A361		B	
1D5A31	LSB-BSE1: operation additional equipment master switch 2 defective/missing	A361		B	
1D5A39	LSB-BSE1: operation additional equipment seat contact shut-down	A361		B	
1D5A3E	LSB-BSE1: operation additional equipment Shut off master switch zero position forced	A361		B	
1D5A44	LSB-BSE1: operation additional equipment Shut-off crane engine not running operational shut down Luff up until hoist limit switch is no longer actuated	A361		B	
1D5A47	LSB-BSE1: operation additional equipment Warning luffing up, dropping of load with reduction of reach operational shut down Luff up until hoist limit switch is no longer actuated	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5A48	LSB-BSE1: operation additional equipment Shut-down luffing up, dropping of load with reduction of reach operational shut down Luff up until hoist limit switch is no longer actuated	A361		B	
1D5A49	LSB-BSE1: operation additional equipment Shut off Luffing down fixed jib hoist limit switch 4	A361		B	
1D5A4A	LSB-BSE1: operation additional equipment Shut off Luff down pulley set hoist limit switch 5	A361		B	
1D5A4B	LSB-BSE1: operation additional equipment Warning, reducing load at reduction of radius	A361		B	
1D5A4E	LSB-BSE1: operation additional equipment Shut off emerg. off not active	A361		B	
1D5A4F	LSB-BSE1: operation additional equipment Shut off control is off	A361		B	
1D5A50	LSB-BSE1: operation additional equipment Shut off Luffing down fixed jib hoist limit switch 1 operational shut down Luff up until hoist limit switch is no longer actuated	A361		B	
1D5A51	LSB-BSE1: operation additional equipment Shut off Luffing down fixed jib hoist limit switch 2 operational shut down Luff up until hoist limit switch is no longer actuated	A361		B	
1D5A52	LSB-BSE1: operation additional equipment Shut off Luffing down fixed jib hoist limit switch 3	A361		B	
1D5A53	LSB-BSE1: operation additional equipment Shut off fixed jib no or invalid operating mode	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5A54	LSB-BSE1: operation additional equipment Shut off fixed jib LMB	A361		B	
1D5A81	LSB-BSE1: operation additional equipment Shut off Luff down fixed jib hoist limit switch 1 erroneous/missing	A361		B	
1D5A82	LSB-BSE1: operation additional equipment Shut off Luff down fixed jib hoist limit switch 2 erroneous/missing	A361		B	
1D5A83	LSB-BSE1: operation additional equipment Shut off Luff down fixed jib hoist limit switch 3 erroneous/missing	A361		B	
1D5A89	LSB-BSE1: operation additional equipment Shut off Luff down fixed jib hoist limit switch 4 erroneous/missing	A361		B	
1D5A8A	LSB-BSE1: operation additional equipment Shut off Luff down pulley set hoist limit switch 5 erroneous/missing No change over of MS-Assignment Set equip. config. accessories, otherwise no change over MS-Assignment	A361		B	
1D5B02	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down counterweight on ground Operational shut-down, shunable via raised key switch B/BW - only switch on if B/BW safely raised	A361		B	
1D5B03	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down support counterweight carriage is not retracted Operation conditional shut-down, may not be shunted. Retract support cylinder counterweight carriage completely.	A361		B	
1D5B04	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down counterweight carriage telescoping blocked Operational shut-down, shunable via raised key switch B/BW - only switch on if B/BW safely raised Press "Tow-travel on" key until the wheels are in the travel direction and the indicator lamp remains lit.	A361		B	
1D5B08	LSB-BSE1: Operation ballasting / counterweight carriage Counterweight carriage (BW) is inserted but not yet bolted report of error, otherwise no reaction Bolt or unplug counterweight carriage.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B09	LSB-BSE1: Operation ballasting / counterweight carriage BW is bolted but not inserted - dummy plug is inserted Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Unbolt or plug in counterweight carriage.	A361		B	
1D5B0C	LSB-BSE1: Operation ballasting / counterweight carriage Shut off support ballast trailer is retracted Operation conditional switch off, may not be shunted Move support Ballast trailer in	A361		B	
1D5B0D	LSB-BSE1: Operation ballasting / counterweight carriage Shut off BW steering wheel set not free operational shut down Switch in other permissible BW operating mode and bring BW in permissible pos.	A361		B	
1D5B10	LSB-BSE1: Operation ballasting / counterweight carriage No counterweight inserted or dummy plug not inserted report of error, otherwise no reaction Plug in dummy plug.	A361		B	
1D5B11	LSB-BSE1: Operation ballasting / counterweight carriage Counterweight carriage (BW) is bolted but not inserted Unbolt or plug in counterweight carriage.	A361		B	
1D5B13	LSB-BSE1: Operation ballasting / counterweight carriage Set B-table does not match the installed entries from B/BW Shut-down due to unclear recognition of assembly condition. Set load chart correctly or mount B/BW in accordance with the table setting.	A361		B	
1D5B14	LSB-BSE1: Operation ballasting / counterweight carriage Suspended counterweight (B) mounted but no B-table set Conversion to control operation type with suspended counterweight - requirements for operation with B must be met. Set load chart correctly or mount B/BW in accordance with the table setting.	A361		B	
1D5B16	LSB-BSE1: Operation ballasting / counterweight carriage Ballast trailer is stretched, not pinned and support retracted Error message as well as no release of turn and drive crawler The two BT limit switches not supported may not have switched, support must be extended	A361		B	
1D5B17	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast automatic Operational shut off Manually drive into permissible F1 range or out of shut-off, shut off the spline cylinder or ballast cylinder	A361		B	
1D5B18	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down measuring point 1 < F min	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B19	LSB-BSE1: Operation ballasting / counterweight carriage no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A361		B	
1D5B1A	LSB-BSE1: Operation ballasting / counterweight carriage Shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D5B1B	LSB-BSE1: Operation ballasting / counterweight carriage Shut off control is off output of error Restart crane monitors and wait until control booted up.	A361		B	
1D5B1C	LSB-BSE1: Operation ballasting / counterweight carriage Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A361		B	
1D5B1D	LSB-BSE1: Operation ballasting / counterweight carriage seat contact shut-down Operational shut off Cancel shut-off, sit on the driver's seat or actuate deadman on the master switch	A361		B	
1D5B1E	LSB-BSE1: Operation ballasting / counterweight carriage Shut off derrick angle not in op. position Operational shut off, only bypassable when derrick placed down With Derrick move further to rear in op. angle	A361		B	
1D5B1F	LSB-BSE1: Operation ballasting / counterweight carriage Shut off LMB not active operational shut down briefly release master switch, or error elimination see corresponding system error	A361		B	
1D5B20	LSB-BSE1: Operation ballasting / counterweight carriage LMB shut-down Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5B21	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down measuring point 1 > F max - operation Operation conditional switch off, may not be shunted Press button Ballast "Up / down" only if winch 4 is not actuated	A361		B	
1D5B22	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down measuring point 1 > F max - assembly Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B24	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B25	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B29	LSB-BSE1: Operation ballasting / counterweight carriage Shut-off ballast cylinder A-B length difference too large Output of error, crane function is not selected. Move the ballast cylinders together in individual operation. Move the two ballast cylinders to the same length	A361		B	
1D5B2A	LSB-BSE1: Operation ballasting / counterweight carriage Shut off brake pressure BW drive brake not open Operational shut off Check brake pressure of service brake why it doesn't open	A361		B	
1D5B2C	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E Main boom angle exceeded	A361		E	1
1D5B2D	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E Derrick angle exceeded	A361		E	1
1D5B2E	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E Accessory angle exceeded	A361		E	1
1D5B2F	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E max pulled Ballast exceeded Operational shut off Drive out of the shut-off in mode without radio with the master switch, only the ballast can be driven	A361		B	
1D5B3A	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast "on" left minimum length reached Issuance of error, crane function is not actuated Run down with ballasting cylinder	A361		B	
1D5B3B	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast "on" right minimum length reached Issuance of error, crane function is not actuated Run down with ballasting cylinder	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B3C	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast "off" left maximum length reached Issuance of error, crane function is not actuated Run up with ballasting cyl.	A361		B	
1D5B3D	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast "off" right maximum length reached Issuance of error, crane function is not actuated Run up with ballasting cyl.	A361		B	
1D5B3E	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballasting up / down mandatory zero position operational shut down Bring button to zero pos. and deflect desired movement again	A361		B	
1D5B43	LSB-BSE1: Operation ballasting / counterweight carriage Shut-off wheel set turn sensor erroneous / missing Operation conditional switch off, may not be shunted Check wheel sensor left / right turn sensor on LSB for error or line interruption	A361		B	
1D5B44	LSB-BSE1: Operation ballasting / counterweight carriage Shut-off crane engine not running Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B45	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast "Up / down" due to running winch 4	A361		B	
1D5B49	LSB-BSE1: Operation ballasting / counterweight carriage Shut off pressure difference ballast cylinder A/B too large operational shut down Bypass with key button, in its own responsibility back to good pressure difference with ballast cylinders	A361		B	
1D5B4E	LSB-BSE1: Operation ballasting / counterweight carriage Shut off length sensor ballast cyl. left erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A361		B	
1D5B4F	LSB-BSE1: Operation ballasting / counterweight carriage Shut off length sensor ballast cyl. right erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A361		B	
1D5B50	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast "up / down" due to running winch 3 Issuance of error, crane function is not actuated Do not actuate winch 3 anymore, then ballast can be moved up/down again	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B51	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast "In" left block position retracted reached Issuance of error, crane function is not actuated Run down with ballasting cylinder	A361		B	
1D5B52	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast "In" right block position retracted reached Issuance of error, crane function is not actuated Run down with ballasting cylinder	A361		B	
1D5B53	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast on ground lateral incline > max Wert Issuance of error, crane function is not actuated Do not run with stop button A or B into permissible position	A361		B	
1D5B54	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B55	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B56	LSB-BSE1: Operation ballasting / counterweight carriage Shut off ballast cylinder A pressure difference A-B too high Issuance of error, crane function is not actuated Move two cyl. via stop button into permissible position to be within pressure difference	A361		B	
1D5B57	LSB-BSE1: Operation ballasting / counterweight carriage Shut off ballast cylinder B pressure difference A-B too high Issuance of error, crane function is not actuated Move two cyl. via stop button into permissible position to be within pressure difference	A361		B	
1D5B58	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down guide frame - counterweight bump stop upper operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A361		B	
1D5B59	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down guide frame - counterweight bump stop lower operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A361		B	
1D5B5A	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast pallet / BW lateral incline > max side incline Operation conditional switch off, may not be shunted With stop buttons move ballast UP/DOWN/STOP cylinder A / STOP cylinder B knowingly in improved direction	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B5B	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast pallet / BW lateral incline < min side incline Operation conditional switch off, may not be shunted With stop buttons move ballast UP/DOWN/STOP cylinder A / STOP cylinder B knowingly in improved direction	A361		B	
1D5B5C	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	
1D5B5D	LSB-BSE1: Operation ballasting / counterweight carriage Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B5E	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B5F	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B68	LSB-BSE1: Operation ballasting / counterweight carriage Abschaltung fuer Freigabe Totmann laenger druecken Operational shut off Totmann Taste MS1 fuer 2 sek druecken damit wird Freigabe bestaetigt	A361		B	
1D5B70	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted	A361		B	
1D5B71	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" vo. right faulty/not presen Operation conditional switch off, may not be shunted	A361		B	
1D5B72	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" hi. left faulty/not present Operation conditional switch off, may not be shunted	A361		B	
1D5B73	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" hi. right faulty/not presen Operation conditional switch off, may not be shunted	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B74	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B75	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B76	LSB-BSE1: Operation ballasting / counterweight carriage Shut off limit switch "Winch frame installed" le. defective/missing Operational shut off Release shut off move into permissible movement	A361		B	
1D5B77	LSB-BSE1: Operation ballasting / counterweight carriage Shut off limit switch "Winch frame installed" ri. defective/missing Operational shut off Release shut off move into permissible movement	A361		B	
1D5B78	LSB-BSE1: Operation ballasting / counterweight carriage Shut-off of both retracted ballast limit switches faulty / missing Operational shut off Release shut off move into permissible movement	A361		B	
1D5B79	LSB-BSE1: Operation ballasting / counterweight carriage Shut-off of both extended ballast limit switches faulty / missing	A361		B	
1D5B7A	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Limit switch left Ballast retracted erroneous / missing Issuance of error, crane function is not actuated Check wiring, check sensor	A361		B	
1D5B7B	LSB-BSE1: Operation ballasting / counterweight carriage Shut off limit switch right Ballast retracted erroneous/missing Issuance of error, crane function is not actuated Check wiring, check sensor	A361		B	
1D5B7E	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Turn sensor swing B/BW erroneous / missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A361		B	
1D5B7F	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Turn sensor swing B/BW max perm lateral angle exceeded Operation conditional switch off, may not be shunted With ballast trailer / slewing gear move from shut off angle in operating angle	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B80	LSB-BSE1: Operation ballasting / counterweight carriage Ballast trailer equipped without swing Issuance of error, crane function is not actuated Install ballast pallet with swing	A361		B	
1D5B85	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Wind off main boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A361		B	
1D5B86	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "RFP Main boom" links faulty/not present operational shut down Press "A-Stop" key or "B-Stop" key to move only one ballast cylinder to equalize forces in side A/B	A361		B	
1D5B87	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Overtop guard cyl D" right faulty/not prese Operation conditional switch off, may not be shunted Wind off derrick boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A361		B	
1D5B88	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Overtop guard cyl D" left faulty/not presen Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B8C	LSB-BSE1: Operation ballasting / counterweight carriage Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A361		B	
1D5B8E	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Length sensor Sliding cyl. erroneous/missing Operational shut off Release shut off by checking LSB Sensor BW-Sliding cyl.	A361		B	
1D5B8F	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Length sensor Sliding cyl. moved out Operational shut off Release shut off by Release shut off move in a perm. movement - sliding cyl. in	A361		B	
1D5B90	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Length sensor Sliding cyl. moved in Operational shut off Release shut off move in a perm. movement – sliding cyl. out	A361		B	
1D5B91	LSB-BSE1: Operation ballasting / counterweight carriage Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5B92	LSB-BSE1: Operation ballasting / counterweight carriage Shut off pressure Relapse cyl. derrick outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A361		B	
1D5B93	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch right "Lower count. block" faulty/not pre Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A361		B	
1D5B94	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Lower count. block" left faulty/not present Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A361		B	
1D5B95	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Upper count. block" right faulty/not present Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B96	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Upper count. block" left faulty/not present Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A361		B	
1D5B97	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Count. bolted" right faulty/not present Issuance of error, crane function is not actuated Check LSB-sensor, wiring, pay attention to system error, if nec. Op. mode without BW set up	A361		B	
1D5B98	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down limit switch "Count. bolted" left faulty/not present Issuance of error, crane function is not actuated Check LSB-sensor, wiring, pay attention to system error, if nec. Op. mode without BW set up	A361		B	
1D5B99	LSB-BSE1: Operation ballasting / counterweight carriage Ballast trailer (BW) is not pinned Issuance of error, crane function is not actuated Check LSB-sensor, wiring, pay attention to system error, if nec. Op. mode without BW set up	A361		B	
1D5B9A	LSB-BSE1: Operation ballasting / counterweight carriage Ballast trailer (BW) is not installed (pilot contact) Operation conditional switch off, may not be shunted Check for installation to suit op. and check signal	A361		B	
1D5BAA	LSB-BSE1: Operation ballasting / counterweight carriage Ballast UP/DOWN prevented, 2Hand-button not pressed	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5BAB	LSB-BSE1: Operation ballasting / counterweight carriage Error in report or control ballasting	A361		B	
1D5BAC	LSB-BSE1: Operation ballasting / counterweight carriage Ballast UP/DOWN prevented, no release from crane control Movement is not actuated Turn actuation of other aux. users off or remedy system error	A361		B	
1D5BB3	LSB-BSE1: Operation ballasting / counterweight carriage Shut off pulled ballast > permissible and pallet not installed operational shut down Insert ballast pallet, sensor monitoring active, or set down ballast pallet, unpin, drive with empty rods	A361		B	
1D5BBC	LSB-BSE1: Operation ballasting / counterweight carriage Shut off lower limit angle HA erection reached luff up HA Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A361		B	
1D5BC0	LSB-BSE1: Operation ballasting / counterweight carriage Shut off test point 3 > F max - Montage Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A361		B	
1D5BC1	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down upper limit angle derrick OGWD Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A361		B	
1D5BC2	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down lower limit angle derrick UGWD Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A361		B	
1D5BC3	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down upper limit angle ULV (geometry, load capacity chart) operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A361		B	
1D5BC4	LSB-BSE1: Operation ballasting / counterweight carriage Shut-down lower limit value LLV (geometry, load capacity chart) operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A361		B	
1D5BC5	LSB-BSE1: Operation ballasting / counterweight carriage Shut off upper relative limit angle acces. reached / fallen below operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5BC6	LSB-BSE1: Operation ballasting / counterweight carriage Shut off upper relative limit angle HA reached / exceeded operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A361		B	
1D5BC7	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Upper limit angle Superstr. access. (geometry load chart) operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A361		B	
1D5BC8	LSB-BSE1: Operation ballasting / counterweight carriage Shut off test point 2 > F max - assembly Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A361		B	
1D5BC9	LSB-BSE1: Operation ballasting / counterweight carriage Shut off test point 2 < F min Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A361		B	
1D5BCA	LSB-BSE1: Operation ballasting / counterweight carriage Shut off upper relative limit angle OGWD operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A361		B	
1D5BCB	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast pressure monitoring not OK	A361		B	
1D5BCC	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast trailer pressure monitoring not OK	A361		B	
1D5BD0	LSB-BSE1: Operation ballasting / counterweight carriage Shut off SPMT control is off	A361		B	
1D5BD1	LSB-BSE1: Operation ballasting / counterweight carriage Shut off SPMT turn sensor swing B/BT erroneous/missing operational shut down Plug in bypass plug SPMT, check wiring, check sensor	A361		B	
1D5BD2	LSB-BSE1: Operation ballasting / counterweight carriage Shut off SPMT turn sensor swing B/BT max lateral angle operational shut down Plug in bypass plug SPMT, move with slewing gear out from shut off	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5BD3	LSB-BSE1: Operation ballasting / counterweight carriage Shut off SPMT limit switch swing front block operational shut down Plug in bypass plug SPMT move with crawler travel gear backward from shut off	A361		B	
1D5BD4	LSB-BSE1: Operation ballasting / counterweight carriage Shut off SPMT limit switch swing rear block operational shut down Plug in bypass plug SPMT move with crawler travel gear forward from shut off	A361		B	
1D5BD5	LSB-BSE1: Operation ballasting / counterweight carriage Shut off SPMT pull force sensor le/ri erroneous/missing operational shut down Plug in bypass plug SPMT, check wiring, check sensor	A361		B	
1D5BD6	LSB-BSE1: Operation ballasting / counterweight carriage Shut off SPMT pull force > Fmax operational shut down Plug in bypass plug SPMT, move with slewing gear out from shut off	A361		B	
1D5BD9	LSB-BSE1: Operation ballasting / counterweight carriage Ballast trailer Emerg. stop chain open since shut off SPMT active operational shut down Plug in bypass plug SPMT	A361		B	
1D5BDF	LSB-BSE1: Operation ballasting / counterweight carriage Shut off Ballast trailer forced zero pos. Operational shut off Release shut off move into permissible movement	A361		B	
1D5BFA	LSB-BSE1: Operation ballasting / counterweight carriage F1 outside perm. Tolerance no selection Ballast automatic Operational shut off Drive into a permissible F1 area in manual mode, drive out of the F1 min or F1 max threshold	A361		B	
1D5BFB	LSB-BSE1: Operation ballasting / counterweight carriage Incline outside perm. Tolerance no selection Ballast automatic Operational shut off Drive into a permissible incline range in manual mode	A361		B	
1D5BFD	LSB-BSE1: Operation ballasting / counterweight carriage Releases not present ballast automatic not selectable Operational shut off Sliding cylinder and ballast cylinder releases must be present to activate automatic mode	A361		B	
1D5C01	LSB-BSE1: Operation crawler Shut-off ballast not lifted, confirm with key button Operational shut off Lift up ballast and confirm with "Ballast lifted" key button	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5C02	LSB-BSE1: Operation crawler Shut-down counterweight on ground Operational shut-down, shutable via raised key switch B/BW - only switch on if B/BW safely raised Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C03	LSB-BSE1: Operation crawler Shut-down support counterweight carriage is not retracted Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C05	LSB-BSE1: Operation crawler Shut-down swing with parallel travel count. carriage not possible Operational shut-down, shutable via raised key switch B/BW - only switch on if B/BW safely raised Press tow-travel key until the wheels are in travel direction and the indicator lamp remains on.	A361		B	
1D5C06	LSB-BSE1: Operation crawler Shut-down swing gear brake has not opened with tow-travel BW Operational shut-down, shutable via raised key switch B/BW - only switch on if B/BW safely raised Check: Brake valve swing gear - electrical selection, short-circuit or interruption, hydraulics.	A361		B	
1D5C07	LSB-BSE1: Operation crawler Shut-down free swing gear is not on with tow-travel BW operational shut down Check: True run or brake swing gear - electrical selection, short-circuit or interruption, hydraulics.	A361		B	
1D5C08	LSB-BSE1: Operation crawler Shut-down swing gear brake has opened with parallel travel BW Operation conditional switch off, may not be shunted Check: Brake valve swing gear - electrical selection, short-circuit following supply voltage, hydraulics.	A361		B	
1D5C09	LSB-BSE1: Operation crawler Shut-down free swing gear is not on with parallel travel BW Operation conditional switch off, may not be shunted Check: True run or brake swing gear - electrical selection, short-circuit or interruption, hydraulics.	A361		B	
1D5C0A	LSB-BSE1: Operation crawler Shut off Ballast/Ballast trailer swing Block Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A361		B	
1D5C0B	LSB-BSE1: Operation crawler Shut off ballast trailer not lifted off operational shut down Lift off ball. trailer or select ball. trailer oper. mode where crawler driving with ball. trailer not lifted off perm.	A361		B	
1D5C0D	LSB-BSE1: Operation crawler Shutdown slewing gear brake not released	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5C0E	LSB-BSE1: Operation crawler Shut off Slewing gear coasting not possible, pressure switch not OK	A361		B	
1D5C0F	LSB-BSE1: Operation crawler Shut off drive crawler BW Pull force sensor le/ri erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A361		B	
1D5C10	LSB-BSE1: Operation crawler Shut off drive crawler BW Pull force > Fmax Operation conditional switch off, may not be shunted With ballast trailer or slewing gear move into operating force	A361		B	
1D5C12	LSB-BSE1: Operation crawler Shut off drive crawler - Op. mode parallel operation not active operational shut down Activate parallel operation crawler selection TE and parallel driving ballast trailer	A361		B	
1D5C13	LSB-BSE1: Operation crawler Shut-down wheels counterweight carriage not in travel position operational shut down Set ballast trailer wheels in travel position with respective ballast trailer operating mode	A361		B	
1D5C14	LSB-BSE1: Operation crawler Shut-off slewing gear brake closed and freewheeling not free	A361		B	
1D5C18	LSB-BSE1: Operation crawler Shut-off auxiliary support crawler carrier set up Operational shut off Dismantle auxiliary support and set up operating mode without auxiliary support	A361		B	
1D5C19	LSB-BSE1: Operation crawler no or invalid operation mode shut-down Operation conditional switch off, may not be shunted	A361		B	
1D5C1A	LSB-BSE1: Operation crawler Shut off BW sliding cylinder movement without actuation Operational shut off Check why sliding cyl. moves or extended without actuation, diagonal pull of ballast trailer	A361		B	
1D5C1F	LSB-BSE1: Operation crawler Shut off LMB not active Operation conditional switch off, may not be shunted check why LMB not running. Operating mode OK, sensor defective, read out LMB error	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5C28	LSB-BSE1: Operation crawler Drive crawler not possible - crawler not turned on Operation conditional switch off, may not be shunted Activate travel pedals in zero pos. and drive crawler on TE3	A361		B	
1D5C2A	LSB-BSE1: Operation crawler Shut off brake pressure BW drive brake not open Operational shut off Check brake pressure of service brake why it doesn't open	A361		B	
1D5C2D	LSB-BSE1: Operation crawler Master switch mode not active	A361		B	
1D5C33	LSB-BSE1: Operation crawler Parallel operation differential path between crawlers too great Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C39	LSB-BSE1: Operation crawler seat contact shut-down operational shut down Press "A-Stop" key or "B-Stop" key to move only one ballast cylinder to equalize forces in side A/B	A361		B	
1D5C3C	LSB-BSE1: Operation crawler Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	
1D5C3E	LSB-BSE1: Operation crawler Shut off master switch zero position forced Operation conditional switch off, may not be shunted	A361		B	
1D5C40	LSB-BSE1: Operation crawler Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D5C41	LSB-BSE1: Operation crawler Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	
1D5C42	LSB-BSE1: Operation crawler Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5C43	LSB-BSE1: Operation crawler Shut off Radio assembly BTT-E max pulled Ballast exceeded	A361		B	
1D5C44	LSB-BSE1: Operation crawler Shut-off crane engine not running operational shut down Switch off parallel crawler operation and switch on again, parallel operation is thus newly adjusted.	A361		B	
1D5C45	LSB-BSE1: Operation crawler Shut off Brake pressure monitoring Crawler left not OK Operational shut off Bring foot pedal in zero pos., check brake pr. crawler	A361		B	
1D5C46	LSB-BSE1: Operation crawler Shut off Brake pressure monitoring Crawler right not OK Operational shut off Bring foot pedal in zero pos., check brake pr. crawler	A361		B	
1D5C49	LSB-BSE1: Operation crawler Shut off pressure difference ballast cylinder A/B too large Operational shut off Using the key switch, drive the ballast cylinder in individual operation back into a balanced pressure difference	A361		B	
1D5C4D	LSB-BSE1: Operation crawler Shut off radio interruption	A361		B	
1D5C4E	LSB-BSE1: Operation crawler Shut off emerg. off not active	A361		B	
1D5C4F	LSB-BSE1: Operation crawler Shut off control is off	A361		B	
1D5C52	LSB-BSE1: Operation crawler Shut-down measuring point 1 > F max - operation Operational shut off Move out with another gear from shut off. Run F1 force improved function winch 3,4 Ballast cylinder	A361		B	
1D5C53	LSB-BSE1: Operation crawler Shut-down measuring point 1 > F max - assembly Operational shut off Move out with another gear from shut off. Run F1 force improved function winch 3,4 Ballast cylinder	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5C54	LSB-BSE1: Operation crawler Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C55	LSB-BSE1: Operation crawler Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C58	LSB-BSE1: Operation crawler Shut-down guide frame - counterweight bump stop upper operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A361		B	
1D5C59	LSB-BSE1: Operation crawler Shut-down guide frame - counterweight bump stop lower operational shut down Using the additional error reports determine which error is present with ballast configuration.	A361		B	
1D5C70	LSB-BSE1: Operation crawler Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C71	LSB-BSE1: Operation crawler Shut-down lim switch "Count. on ground" vo. right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C72	LSB-BSE1: Operation crawler Shut-down lim switch "Count. on ground" hi. left faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C73	LSB-BSE1: Operation crawler Shut-down lim switch "Count. on ground" hi. right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C74	LSB-BSE1: Operation crawler Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5C75	LSB-BSE1: Operation crawler Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5C76	LSB-BSE1: Operation crawler Shut off limit switch swing front block Operation conditional switch off, may not be shunted Drive crawler into improved direction possibly until shut off is released again.	A361		B	
1D5C77	LSB-BSE1: Operation crawler Shut off limit switch swing rear block Operation conditional switch off, may not be shunted Drive crawler into improved direction possibly until shut off is released again.	A361		B	
1D5C78	LSB-BSE1: Operation crawler Shut off swing turn sensor front allowance Operation conditional switch off, may not be shunted Drive crawler into improved direction possibly until shut off is released again.	A361		B	
1D5C79	LSB-BSE1: Operation crawler Shut off swing turn sensor rear allowance Operation conditional switch off, may not be shunted Drive crawler into improved direction possibly until shut off is released again.	A361		B	
1D5C7A	LSB-BSE1: Operation crawler Shut off limit switch B/BW swing left front erroneous/missing Operation conditional switch off, may not be shunted	A361		B	
1D5C7B	LSB-BSE1: Operation crawler Shut off limit switch B/BW swing right front erroneous/missing Operation conditional switch off, may not be shunted	A361		B	
1D5C7C	LSB-BSE1: Operation crawler Shut off limit switch B/BW swing left rear erroneous/missing Operation conditional switch off, may not be shunted Control B/BW again into an operational position	A361		B	
1D5C7D	LSB-BSE1: Operation crawler Shut off limit switch B/BW swing right rear erroneous/missing	A361		B	
1D5C7E	LSB-BSE1: Operation crawler Shut off Turn sensor swing B/BW erroneous / missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A361		B	
1D5C7F	LSB-BSE1: Operation crawler Shut off Turn sensor swing B/BW max lateral angle Operation conditional switch off, may not be shunted With the ballast trailer move from shut off angle in operating angle	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5C80	LSB-BSE1: Operation crawler Shut off limit switch "Ballast on ground" not on SPMT Operation conditional switch off, may not be shunted The 4 limit switches "Ballast on ground" must sit on SPMT and be switched. with ballast cylinder or winch	A361		B	
1D5C81	LSB-BSE1: Operation crawler Shut off B/BW lifted off and slewing gear brake open Operation conditional switch off, may not be shunted Slewing gear brake must be applied	A361		B	
1D5C85	LSB-BSE1: Operation crawler Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C86	LSB-BSE1: Operation crawler Shut-down limit switch "RFP Main boom" links faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C87	LSB-BSE1: Operation crawler Shut-down limit switch "Overtop guard cyl D" right faulty/not prese Operation conditional switch off, may not be shunted Retract support counterweight carriage completely.	A361		B	
1D5C88	LSB-BSE1: Operation crawler Shut-down limit switch "Overtop guard cyl D" left faulty/not presen Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A361		B	
1D5C93	LSB-BSE1: Operation crawler Shut-down limit switch right "Lower count. block" faulty/not pre Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5C94	LSB-BSE1: Operation crawler Shut-down limit switch "Lower count. block" left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A361		B	
1D5C95	LSB-BSE1: Operation crawler Shut-down limit switch "Upper count. block" right faulty/not presen Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A361		B	
1D5C96	LSB-BSE1: Operation crawler Shut-down limit switch "Upper count. block" left faulty/not present Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D5C97	LSB-BSE1: Operation crawler Shut-down limit switch "Count. bolted" right faulty/not present Operational shut-off in BT operation Check wiring, check sensor	A361		B	
1D5C98	LSB-BSE1: Operation crawler Shut-down limit switch "Count. bolted" left faulty/not present Operational shut-off in BT operation Check wiring, check sensor	A361		B	
1D5C99	LSB-BSE1: Operation crawler Ballast trailer (BW) is not pinned Operation conditional switch off, may not be shunted Check for installation to suit op. if installed/pinned check signal	A361		B	
1D5C9A	LSB-BSE1: Operation crawler Ballast trailer (BW) is not installed (pilot contact) Operational shut off Install BW and plug in, also enter one BW Op. mode to allow crawler move	A361		B	
1D5CA2	LSB-BSE1: Operation crawler Shut off: slewing gear turns without actuation Operational shut off When in a BW Op.mode BW drive moves against closed slewing gear br. check b. trailer	A361		B	
1D5CB3	LSB-BSE1: Operation crawler Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A361		B	
1D6005	LSB-BSE1: Operation undercarriage Illumination prevented, ignition chassis not on	A361		B	
1D6109	LSB-BSE1: Operation crane control Movement sel. crane operator s cab at operating mode preheating operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D610A	LSB-BSE1: Operation crane control Movement selection crane op. cab for operating recovery winch	A361		B	
1D6111	LSB-BSE1: Operation crane control Crane motor 2 cannot be added	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D6114	LSB-BSE1: Operation crane control Shut off all crane movements remote loading of software active	A361		E	
1D6117	LSB-BSE1: Operation crane control Shut off Radio BTT-E in crane mode active operational shut down Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A361		B	
1D611A	LSB-BSE1: Operation crane control Load tracing Working floodlight outside valid angle range	A361		B	
1D611D	LSB-BSE1: Operation crane control Flap bottom in Position at exceeded angle threshold F-jib Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D611E	LSB-BSE1: Operation crane control Flap top in Position at fallen below angle threshold F-jib Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A361		E	
1D613E	LSB-BSE1: Operation crane control Shut off master switch zero position forced operational shut down Drive out of the pending shut-off, see operating error for which shut-off is still pending	A361		B	
1D6148	LSB-BSE1: Operation crane control Selection bypass hoist top - not possible - try again	A361		B	
1D6149	LSB-BSE1: Operation crane control Selection bypass LMB - not possible - try again	A361		B	
1D614A	LSB-BSE1: Operation crane control Selection bypass LMB - not permissible for this utilization	A361		B	
1D614B	LSB-BSE1: Operation crane control Selection luff up at overload- not possible - retry	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D614C	LSB-BSE1: Operation crane control Selection bypass LMB emerg. operation -not possible- retry	A361		B	
1D614D	LSB-BSE1: Operation crane control Selection bypass LMB emerg. operation not possible	A361		B	
1D614E	LSB-BSE1: Operation crane control Caution special function for reductions/ bypasses activated Change data word DWx.xx	A361		B	
1D614F	LSB-BSE1: Operation crane control Caution, Activation EN13000 not possible EN 13000 is deactivated since option 85% chart is activated Bypass EN13000 here not possible	A361		E	
1D6150	LSB-BSE1: Operation crane control Shut off Warning signal not possible	A361		B	
1D6151	LSB-BSE1: Operation crane control Warning signal cannot be turned off. Min. turn on time exceeded	A361		B	
1D6152	LSB-BSE1: Operation crane control Selection bypass LMB assembly - not possible - try again EN 13000 is deactivated since option 85% chart is activated Bypass EN13000 here not possible	A361		B	
1D6154	LSB-BSE1: Operation crane control Data logger is not active no special function possible	A361		B	
1D6155	LSB-BSE1: Operation crane control Selection bypass LMB not permissible for this F1-utilization	A361		B	
1D6159	LSB-BSE1: Operation crane control Luffing in with susp. load after shut off press button again	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D615A	LSB-BSE1: Operation crane control Shut off Plug emerg. operation active operational shut down release master switch - error elimination see corresponding system error	A361		B	
1D615B	LSB-BSE1: Operation crane control Selection bypass hoist top not possible - no shut off	A361		B	
1D615C	LSB-BSE1: Operation crane control Selection this bypass not possible - sensor defect	A361		B	
1D615D	LSB-BSE1: Operation crane control Bypass LMB not possible - Max. pressure luffing cylinder reached	A361		B	
1D615F	LSB-BSE1: Operation crane control Selection bypass not possible - crane engine still running	A361		B	
1D6160	LSB-BSE1: Operation crane control Selection bypass not possible - seat contact not actuated	A361		B	
1D6161	LSB-BSE1: Operation crane control Selection bypass not possible - radio op. active	A361		B	
1D6162	LSB-BSE1: Operation crane control Selection bypass not possible - zero pos. force required	A361		B	
1D6165	LSB-BSE1: Operation crane control Bypass not possible - relieve boom head - lift ballast	A361		B	
1D6176	LSB-BSE1: Operation crane control Shut off Radio assembly BTT-E Main boom angle exceeded operational shut down Release shut off move into permissible movement	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D6177	LSB-BSE1: Operation crane control Shut off Radio assembly BTT-E Derrick angle exceeded operational shut down Release shut off move into permissible movement	A361		B	
1D6178	LSB-BSE1: Operation crane control Shut off Radio assembly BTT-E Accessory angle exceeded operational shut down Release shut off move into permissible movement	A361		B	
1D6179	LSB-BSE1: Operation crane control Shut off Radio assembly BTT-E max pulled Ballast exceeded Operational shut off Drive out of the shut-off in mode without radio with the master switch, only the ballast can be driven	A361		B	
1D61A0	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off LMB operational shut down Bring crane into a driveable status / position (drivable gears) without LMB Stop	A361		B	
1D61A1	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off crane engine not running Operation conditional switch off, may not be shunted Release master switch – Error remedy see respective system error	A361		B	
1D61A2	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off LMB not active operational shut down	A361		B	
1D61A3	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off seat contact operational shut down Actuate seat contact or press deadman button	A361		B	
1D61A4	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off no or invalid op. mode operational shut down Check LSB Sensor which are active and assigned for the desired to be driving /Operating mode	A361		B	
1D61A5	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off emerg. off not active operational shut down Check EMERG. OFF	A361		B	
1D61A6	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off control is off operational shut down Turn control ON, turn LICCON on	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D61A7	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off SA-frame not in op. angle operational shut down Move SA-frame with winch 4 in op.window where the assembly cyl. may be moved	A361		B	
1D61A8	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off Ring surface block operational shut down Move the assembly cyl. up	A361		B	
1D61A9	LSB-BSE1: Operation crane control SA-frame Assembly cylinder shut off pressure monitoring not OK operational shut down Check assembly cylinder pressure sensor for errors, check LSB diagnostics of the sensor, wiring	A361		B	
1D61AA	LSB-BSE1: Operation crane control Assembly Derrick not correct - pin guying on D-end section	A361		B	
1D61F1	LSB-BSE1: Operation crane control Winch 1 not set up Error message. Set up winches correctly or reeve via correct load position	A361		B	
1D61F2	LSB-BSE1: Operation crane control Winch 2 not set up Error message. Set up winches correctly or reeve via correct load position	A361		B	
1D61F3	LSB-BSE1: Operation crane control Winch 3 not set up Error message. Set up winches correctly or reeve via correct load position	A361		B	
1D61F4	LSB-BSE1: Operation crane control Winch 4 not set up Error message. Set up winches correctly or reeve via correct load position	A361		B	
1D61F5	LSB-BSE1: Operation crane control Winch 5 not set up Error message. Set up winches correctly or reeve via correct load position	A361		B	
1D61F6	LSB-BSE1: Operation crane control Winch 6 not set up Error message. Set up winches correctly or reeve via correct load position	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D6270	LSB-BSE1: operation instruments crane operators cab Master switch 3X has no winch allocated - operation type Output of error, otherwise no reaction. Switch of crawler travel operation.	A361		B	
1D6271	LSB-BSE1: operation instruments crane operators cab Master switch 3Y has no winch allocated - operation type Output of error, otherwise no reaction. Switch of crawler travel operation.	A361		B	
1D6272	LSB-BSE1: operation instruments crane operators cab Master switch 3X has no winch allocated - crawler is on Output of error, otherwise no reaction. Do not modulate master switch 2Y any more.	A361		B	
1D6273	LSB-BSE1: operation instruments crane operators cab Master switch 3Y has no winch allocated - crawler is on Output of error Mount winch 5 or do not defect master switch any more	A361		B	
1D6274	LSB-BSE1: operation instruments crane operators cab Master switch 3Y has no winch allocated - winch 6 is on Output of error Mount winch 3 or do not defect master switch any more	A361		B	
1D6275	LSB-BSE1: operation instruments crane operators cab Master switch 3Y is not assigned to a function - op. mode	A361		B	
1D6276	LSB-BSE1: operation instruments crane operators cab Master switch 3X is not assigned to a function - op. mode	A361		B	
1D6282	LSB-BSE1: operation instruments crane operators cab Master switch MS 3X is disengaged and winch 3 is not mounted Output of error Mount winch 4 or do not defect master switch any more	A361		B	
1D6283	LSB-BSE1: operation instruments crane operators cab Master switch MS 3X is disengaged and winch 5 is not mounted Output of error Assemble winch 6 or do not deflect master switch	A361		B	
1D6284	LSB-BSE1: operation instruments crane operators cab Master switch MS 3Y is disengaged and winch 4 is not mounted Output of error Mount winch 4 or do not defect master switch any more	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D6287	LSB-BSE1: operation instruments crane operators cab Master switch MS 3Y is deflected and winch 6 is not installed Output of error Mount winch 5 or do not defect master switch any more	A361		B	
1D6289	LSB-BSE1: operation instruments crane operators cab Master switch MS 3X is deflected and winch 4 is not installed	A361		B	
1D628A	LSB-BSE1: operation instruments crane operators cab Master switch MS 3Y is deflected and winch 5 is not installed	A361		B	
1D62A0	LSB-BSE1: operation instruments crane operators cab Funktion blocked: button actuation without release Issue of error prevention of activation of aux. user	A361		B	
1D6470	LSB-BSE1: operation instruments armrest right Master switch 1Y has no winch allocated - operation type Output of error Check operating mode	A361		B	
1D6471	LSB-BSE1: operation instruments armrest right Master switch 1X has no winch allocated - crawler is on Output of error Mount winch 3 or do not defect master switch any more	A361		B	
1D6472	LSB-BSE1: operation instruments armrest right Master switch 1X has no winch allocated - winch 6 is on Output of error Mount winch 4 or do not defect master switch any more	A361		B	
1D6473	LSB-BSE1: operation instruments armrest right Master switch 2Y has no winch allocated - crawler is on Output of error Winch 2 install or do not deflect master switch	A361		B	
1D6474	LSB-BSE1: operation instruments armrest right Master switch 2Y has no winch allocated - winch 4 is on Output of error Mount winch 5 or do not defect master switch any more	A361		B	
1D6475	LSB-BSE1: operation instruments armrest right Master switch 2Y is not assigned to a winch - winch 6 on MS 3Y	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D6476	LSB-BSE1: operation instruments armrest right Master switch 2Y is not assigned to any winch - operating mode Output of error, otherwise no reaction. If possible set another operation type.	A361		B	
1D6478	LSB-BSE1: operation instruments armrest right Master switch MS 2Y is not assigned to a function Output of error Select master sw. assignment where MS1X is assigned. No longer act. master sw. 1X	A361		B	
1D6479	LSB-BSE1: operation instruments armrest right Master switch MS 1X is not assigned to a function Output of error Select master sw. assignment where MS1X is assigned. No longer act. master sw. 1X	A361		B	
1D6480	LSB-BSE1: operation instruments armrest right Master switch MS 1X is disengaged and winch 3 is not mounted Output of error Mount winch 5 or do not defect master switch any more	A361		B	
1D6481	LSB-BSE1: operation instruments armrest right Master switch MS 1X is disengaged and winch 4 is not mounted Output of error Winch 1 install or do not deflect master switch	A361		B	
1D6482	LSB-BSE1: operation instruments armrest right Master switch MS 1X is disengaged and winch 5 is not mounted Output of error Winch 2 install or do not deflect master switch	A361		B	
1D6483	LSB-BSE1: operation instruments armrest right Master switch MS 1Y is disengaged and winch 1 is not mounted	A361		B	
1D6484	LSB-BSE1: operation instruments armrest right Master switch MS 1Y is disengaged and winch 2 is not mounted Output of error, otherwise no reaction. Switch of crawler travel operation.	A361		B	
1D6485	LSB-BSE1: operation instruments armrest right Master switch MS 2Y is disengaged and winch 2 is not mounted Output of error Assemble winch 6 or do not deflect master switch	A361		B	
1D6486	LSB-BSE1: operation instruments armrest right Master switch MS 2Y is disengaged and winch 5 is not mounted Output of error Switch winch selection switch to position 1 or 2	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D6487	LSB-BSE1: operation instruments armrest right Master switch MS 2Y is disengaged and winch 6 is not mounted Output of error If possible set another operation type.	A361		B	
1D6488	LSB-BSE1: operation instruments armrest right Master switch MS 2Y deflected and winch selection switch at position 3	A361		B	
1D6489	LSB-BSE1: operation instruments armrest right Master switch MS 2Y deflected and assembly cyl. not installed Output of error, otherwise no reaction. Bring master switch in zero position	A361		B	
1D6576	LSB-BSE1: operation instruments armrest left Master switch 2Y is not assigned to any winch - operating mode	A361		E	1
1D6577	LSB-BSE1: operation instruments armrest left Master switch MS 2X is not assigned to a function Output of error, otherwise no reaction. Select master sw. assignment where MS2X is assigned. No longer act. master sw. 2X	A361		B	
1D6578	LSB-BSE1: operation instruments armrest left Master switch MS 2Y is not assigned to a function Output of error, otherwise no reaction. Select master sw. assignment where MS2X is assigned. No longer act. master sw. 2X	A361		B	
1D6585	LSB-BSE1: operation instruments armrest left Master switch MS 2Y is disengaged and winch 2 is not mounted	A361		E	1
1D6587	LSB-BSE1: operation instruments armrest left Master switch MS 2Y is disengaged and winch 6 is not mounted	A361		E	1
1D6589	LSB-BSE1: operation instruments armrest left Master switch MS 2Y deflected and assembly cyl. not installed	A361		E	1
1D7005	LSB-BSE1: remote control Invalid tele length from LMB No movements possible via radio control	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D7006	LSB-BSE1: remote control No radio release on UEA No movements possible via radio control	A361		B	
1D7007	LSB-BSE1: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A361		B	
1D7008	LSB-BSE1: remote control MS assignment on TE1, TE2 und BTB does not match Movements for assembly locked Check line connections	A361		B	
1D7009	LSB-BSE1: remote control Turntable not pinned to front Movements for assembly locked Pin slewing platform to the front	A361		B	
1D700A	LSB-BSE1: remote control Data transfer Channel 1 problematic (watchdog) No radio mode crane control Check control units and LSB-connections	A361		B	
1D700B	LSB-BSE1: remote control Data transfer Channel 2 problematic (watchdog) No radio mode crane control Check control units and LSB-connections	A361		B	
1D700C	LSB-BSE1: remote control Ignition on in superstructure missing No change to radio menu on BTT possible Turn ignition on in Superstructure	A361		B	
1D700D	LSB-BSE1: remote control BTT in payload bay (no radio control operation) No change to radio menu on BTT possible Take BTT from payload bay	A361		B	
1D700E	LSB-BSE1: remote control LMB is not active No change to radio menu on BTT possible Confirm in equipment config. view	A361		B	
1D700F	LSB-BSE1: remote control Telescope not telescoped in Movements for assembly locked Telescope in	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D7013	LSB-BSE1: remote control Zero position force expected No radio mode crane control Bring all master switches to neutral position	A361		B	
1D7014	LSB-BSE1: remote control Telescope not pinned Movements for assembly op. mode swing accessories blocked Pin telescope	A361		B	
1D7015	LSB-BSE1: remote control Cylinder not pinned in last end section Movements for assembly op. mode swing accessories blocked Pin telescope in last tele end piece	A361		B	
1D7016	LSB-BSE1: remote control not all telescoping targets on 0% Movements for assembly op. mode swing accessories blocked Set all telescoping targets to 0%	A361		B	
1D7017	LSB-BSE1: remote control Luffing angle larger than 5 degrees Movements for assembly op. mode swing accessories blocked Luff down below 5 degrees	A361		B	
1D7019	LSB-BSE1: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A361		B	
1D7210	LSB-BSE1: ABB, working range limitation Programmed edge runs through swing ring center	A361		E	1
1D7280	LSB-BSE1: ABB, working range limitation Operation: Slewing angle outside of the permissible range. Error report. Lowering and extending blocked Reduce reach by luffing up and/or retracting	A361		B	
1D7281	LSB-BSE1: ABB, working range limitation Operation: Pulley head height outside of the permissible range. Error message. Luff up accessories is shut off. Move pulley head by luffing down HA and/or accessories and/or telescoping in into permissible range	A361		B	
1D7282	LSB-BSE1: ABB, working range limitation Operation: Reach outside the permissible range. Error message. Luff accessories down or up is locked, depending on accessory angle Decrease radius by telescoping in	A361		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D7283	LSB-BSE1: ABB, working range limitation Control: Pulley head height accessories outside permissible range Error display Re-equip combi slewing gear	A361		B	
1D7284	LSB-BSE1: ABB, working range limitation Control: Utilization accessories outside permissible range	A361		B	
1D7E03	LSB-BSE1: Boot phase crane control / emergency off Emerg. off active, motor control unit reports button actuated Emerg. off occurrence happens. Control turns off. Start lock engine is set. Reset via ignition Check emerg. off pin on engine control unit	A361		E	
1D7E09	LSB-BSE1: Boot phase crane control / emergency off Report emerg. off engine control unit invalid Delayed start release. Error issue Check if BTB2 is running. Check LSB of BTB2. Check engine-CAN. Possibly emerg. off pin on engine control unit not config	A361		E	
1D7E11	LSB-BSE1: Boot phase crane control / emergency off Report cond. Emerg. off bypassed from engine control unit error report Contact Service	A361		E	
1D7E14	LSB-BSE1: Boot phase crane control / emergency off Report emerg. off motor control unit reports short circuit after VCC Start lock emerg. off is active Check emerg. off pin on engine control unit	A361		E	
1D7E15	LSB-BSE1: Boot phase crane control / emergency off Report emergency of engine control unit reports open line Start lock emerg. off is active Emerg. off input on engine ECU reports open line. Check emerg. off line	A361		E	
1D7E1D	LSB-BSE1: Boot phase crane control / emergency off Emerg. off active, DSP0 input E1 reports button actuated Emerg. off occurrence happens. Control turns off. Start lock engine is set. Reset via ignition Possible line interruption on this input, release emerg. off button if actuated (reset via ignition superstr. off)	A361		E	
1D7E1E	LSB-BSE1: Boot phase crane control / emergency off Emerg. off active, DSP1 input E1 reports button actuated Emerg. off occurrence happens. Control turns off. Start lock engine is set. Reset via ignition Possible line interruption on this input, release emerg. off button if actuated (reset via ignition superstr. off)	A361		E	
1D7E20	LSB-BSE1: Boot phase crane control / emergency off Boot phase, emerg. off actuated or line interruption No release emergency off chain. Starter lock for engine is set Check BTB1, check emerg. off line, check emerg. off button, check supply emerg. off output	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D7E21	LSB-BSE1: Boot phase crane control / emergency off DSP0 input E1 Short circuit after VCC No release emerg. off chain. Start lock is set for engine. Check input or emerg. off line.	A361		E	
1D7E22	LSB-BSE1: Boot phase crane control / emergency off DSP1 input E1 Short circuit after VCC No release emerg. off chain. Start lock is set for engine. Check input or emerg. off line	A361		E	
1D7E23	LSB-BSE1: Boot phase crane control / emergency off DSP0 input E1 line interruption No release emergency off chain. Starter lock for engine is set Check input or emerg. off line	A361		E	
1D7E24	LSB-BSE1: Boot phase crane control / emergency off DSP1 input E1 line interruption No release emergency off chain. Starter lock for engine is set Check input or emerg. off line	A361		E	
1D7E25	LSB-BSE1: Boot phase crane control / emergency off Emerg. off active, at active radio remote control Emerg. off occurrence happens. Control turns off. Emerg. off occurrence is reset when radio connection is present again Release em. off or reestablish radio connection	A361		B	
1D7E26	LSB-BSE1: Boot phase crane control / emergency off Emerg. off active, BSE reports button actuated Emerg. off occurrence happens. Control turns off. Start lock engine is set. Reset via ignition Unlock em. off button, reset via ignition off	A361		E	
1D7E27	LSB-BSE1: Boot phase crane control / emergency off Emerg. off time exceeded - from signal request to report No release emergency off chain. Starter lock for engine is set Check BTB1 for function. Check LSB data transfer from BSE1/BTB1 (possibly bus collisions). Check wiring.	A361		E	
1D7E28	LSB-BSE1: Boot phase crane control / emergency off Caution -Emerg. off line activated via simulation error report In special screen "Control/superstr./Control/Simulation Emerg. stop OFF" turn off with Start/Stop button Simulation	A361		E	
1D7E29	LSB-BSE1: Boot phase crane control / emergency off Test Emerg. off chain not possible - No communication with BTB No release emergency off chain. Starter lock for engine is set Check BTB1 for function. Check LSB data transfer from BSE1/BTB1 (possibly bus collisions). Check wiring.	A361		E	
1D7E2A	LSB-BSE1: Boot phase crane control / emergency off Caution Emerg. off line activated via emerg. op No check of inputs made Stop emerg. op. or check BTB1	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D7E2B	LSB-BSE1: Boot phase crane control / emergency off Engine superstr. installed / removed - invalid Signal BTB Start lock emerg. off is active Check LSB, BTB1 as well as Engine CAN	A361		E	
1D7E2C	LSB-BSE1: Boot phase crane control / emergency off DSP1 input E1 short circuit after VCC -at DSP0-Relay ON- recognized Control does not turn on Check relay. Possibly contact stuck or backfeed by user. Check wiring	A361		E	
1D7E30	LSB-BSE1: Boot phase crane control / emergency off Cross comparison DSP0/DSP1 erroneous - Control on not possible Control does not turn on Reports of relay inputs / check relay (-K410/-K810 or -K411/-K811)	A361		E	
1D7E31	LSB-BSE1: Boot phase crane control / emergency off DSP0 input E0 Short circuit after VCC - Control on not possible Control does not turn on Check relay. Possibly contact stuck or backfeed by user. Check wiring	A361		E	
1D7E32	LSB-BSE1: Boot phase crane control / emergency off DSP1 input E0 Short circuit after VCC - Control on not possible Control does not turn on Check relay. Possibly contact stuck or backfeed by user. Check wiring	A361		E	
1D7E33	LSB-BSE1: Boot phase crane control / emergency off DSP0 input E0 reports open line at Control on LSB2, LSB3, LSB4, as well as LSB6, LSB7, LSB8 do not turn on Check relay and wiring, check fuse BSE (supply outputs). Check fuse from contact report	A361		E	
1D7E34	LSB-BSE1: Boot phase crane control / emergency off DSP1 input E0 reports open line at Control on LSB2, LSB3, LSB4, as well as LSB6, LSB7, LSB8 do not turn on Check relay and wiring, check fuse BSE (supply outputs). Check fuse from contact report	A361		E	
1D7E35	LSB-BSE1: Boot phase crane control / emergency off Control on -Simulation is turned on - Emerg. off no function!!! error report Reset simulation or run down system and restart	A361		B	
1D7E36	LSB-BSE1: Boot phase crane control / emergency off DSP1 input E2 Short circuit after VCC - Control on not possible Control does not turn on Check relay. Possibly contact stuck or backfeed by user. Check wiring	A361		E	
1D7E37	LSB-BSE1: Boot phase crane control / emergency off DSP1 input E2 reports open line at Motor relay on error report Check relay and wiring, check fuse BSE (supply outputs). Check fuse from contact report	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D7E38	LSB-BSE1: Boot phase crane control / emergency off DSP1 Input E2 short circuit after VCC error report Check relay. Possibly contact stuck or backfeed by user. Check wiring	A361		E	
1D7E43	LSB-BSE1: Boot phase crane control / emergency off Em. off active, engine control unit 1 reports button actuated Emerg. off occurrence happens. Control turns off. Start lock engine is set. Reset via ignition Check emerg. off pin on engine control unit	A361		E	
1D7E44	LSB-BSE1: Boot phase crane control / emergency off Report Em. off engine control unit 1 reports short circuit after VCC Start lock emerg. off is active Check emerg. off pin on engine control unit	A361		E	
1D7E45	LSB-BSE1: Boot phase crane control / emergency off Report Em. off engine control unit 1 reports open line Start lock emerg. off is active Emerg. off input on engine ECU reports open line. Check emerg. off line	A361		E	
1D7E49	LSB-BSE1: Boot phase crane control / emergency off Report Em. off engine control unit 1 invalid Delayed start release. Error issue Check if BTB2 is running. Check LSB of BTB2. Check engine-CAN. Possibly emerg. off pin on engine control unit not config	A361		E	
1D7E53	LSB-BSE1: Boot phase crane control / emergency off Em. off active, engine control unit 2 reports button actuated Emerg. off occurrence happens. Control turns off. Start lock engine is set. Reset via ignition Check emerg. off pin on engine control unit	A361		E	
1D7E54	LSB-BSE1: Boot phase crane control / emergency off Report Em. off engine control unit 2 reports short circuit after VCC Start lock emerg. off is active Check emerg. off pin on engine control unit	A361		E	
1D7E55	LSB-BSE1: Boot phase crane control / emergency off Report Em. off engine control unit 2 reports open line Start lock emerg. off is active Emerg. off input on engine ECU reports open line. Check emerg. off line	A361		E	
1D7E59	LSB-BSE1: Boot phase crane control / emergency off Report Em. off engine control unit 2 invalid Delayed start release. Error issue Check if BTB2 is running. Check LSB of BTB2. Check engine-CAN. Possibly emerg. off pin on engine control unit not config	A361		E	
1D80E6	LSB-BSE1: control engine Air flap closed. engine rpm large limit rpm Air flap in superstr. closed. Engine stop Remedy cause of excess rpm. Reset via ignition	A361		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D80E7	LSB-BSE1: control engine Report air flap reports broken wire or short circuit after ground error report Check relay. Possibly contact stuck or backfeed by user. Check wiring	A361		E	
1D80E8	LSB-BSE1: control engine Report air flap reports short circuit after supply voltage error report Check relay. Possibly contact stuck or backfeed by user. Check wiring	A361		E	
1D9600	LSB-BSE1: Diagnose Range exceeded Ballast Monitor	A361		E	1
1D9601	LSB-BSE1: Diagnose Range exceeded Crane operator s cab in Position	A361		E	1
1D9602	LSB-BSE1: Diagnose Range exceeded relapse cyl. jib block left	A361		E	1
1D9603	LSB-BSE1: Diagnose Range exceeded flap jib block left	A361		E	1
1D9604	LSB-BSE1: Diagnose Range exceeded flap jib in position left	A361		E	1
1D9605	LSB-BSE1: Diagnose Range exceeded jib bottom left	A361		E	1
1D9607	LSB-BSE1: Diagnose Range exceeded Telescope pinned	A361		E	1
1D9608	LSB-BSE1: Diagnose Range exceeded Telescope unpinned	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D9609	LSB-BSE1: Diagnose Range exceeded Telescoping cyl. left pinned	A361		E	1
1D960A	LSB-BSE1: Diagnose Range exceeded Telescoping cyl. left unpinned	A361		E	1
1D960B	LSB-BSE1: Diagnose Range exceeded Telescoping cyl. right pinned	A361		E	1
1D960C	LSB-BSE1: Diagnose Range exceeded Telescoping cyl. right unpinned	A361		E	1
1D960D	LSB-BSE1: Diagnose Range exceeded relapse cyl. jib Block right	A361		E	1
1D960E	LSB-BSE1: Diagnose Range exceeded flap jib Block right	A361		E	1
1D960F	LSB-BSE1: Diagnose Range exceeded flap jib in Position right	A361		E	1
1D9610	LSB-BSE1: Diagnose Range exceeded jib bottom right	A361		E	1
1D9612	LSB-BSE1: Diagnose Range exceeded boom steep	A361		E	1
1D9613	LSB-BSE1: Diagnose Range exceeded jib adjustment Block	A361		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1D9625	LSB-BSE1: Diagnose Range exceeded Folding jib folded in	A361		E	1
1D9626	LSB-BSE1: Diagnose Range exceeded Luffing cylinder/Tele pinned left	A361		E	1
1D9627	LSB-BSE1: Diagnose Range exceeded Luffing cylinder/Tele pinned right	A361		E	1
1D9628	LSB-BSE1: Diagnose Range exceeded cab up	A361		E	1
1D9629	LSB-BSE1: Diagnose Range exceeding transport pos. hook block	A361		E	1
1D9E6B	LSB-BSE1: operation engine No start possible via BKE, plug emerg. op. is active Issue of error no engine start via BKE Change from plug emerg. op to normal operation	A361		B	
1DD01E	LSB-BSE1: Supply voltage 15.3 / CPU0 Voltage outside permissible range error report Check voltage, electr. connections and fuse	A361.X1:1		E	2
1DD11E	LSB-BSE1: Supply voltage 30.3 / CPU0 Voltage outside permissible range error report Check battery, electr. connections and fuse	A361.X1:2		E	2
1DDE14	LSB-BSE1: Analog input 0E0 / DSP0 short circuit to supply voltage error report Check DSP0-output A0.0, relay, electr. connections	A361.X4:3		E	2
1DDF14	LSB-BSE1: Analog input 0E1 / DSP0 short circuit to supply voltage error report Check DSP0-output A0.0, relay, electr. connections	A361.X4:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DE012	LSB-BSE1: Analog input 0E2 / DSP0 short circuit to ground error report Check Em. Off switch, voltage, electr. connections	A361.X4:5		E	2
1DE117	LSB-BSE1: Supply voltage 30.1 / DSP0 voltage below required value error indication on display Check battery, voltage, electr. connections and fuse	A361.X4:7		E	2
1DE217	LSB-BSE1: Supply voltage 15.1 / DSP0 voltage below required value error indication on display Check voltage	A361.X4:8		E	2
1DE317	LSB-BSE1: Supply voltage 24V.1 (0A0-1) / DSP0 voltage below required value error indication on display Check voltage, electr. connections and fuse	A361.X4:15		E	2
1DE614	LSB-BSE1: Analog input 1E0 / DSP1 short circuit to supply voltage error report Check DSP1-output A0.0, relay, electr. connections	A361.X5:3		E	2
1DE714	LSB-BSE1: Analog input 1E1 / DSP1 short circuit to supply voltage error report Check DSP1-output A0.0, relay, electr. connections	A361.X5:4		E	2
1DE812	LSB-BSE1: Analog input 1E2 / DSP1 short circuit to ground error report Check Em. Off switch, voltage, electr. connections	A361.X5:5		E	2
1DE917	LSB-BSE1: Supply voltage 30.1 / DSP1 voltage below required value error indication on display Check battery, voltage, electr. connections and fuse	A361.X5:7		E	2
1DEA17	LSB-BSE1: Supply voltage 15.1 / DSP1 voltage below required value error indication on display Check voltage	A361.X5:8		E	2
1DEB17	LSB-BSE1: Supply voltage 24V.1 (0A0-1) / DSP1 voltage below required value error indication on display Check voltage, electr. connections and fuse	A361.X5:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DEC1B	LSB-BSE1: 2.Shut off channel / DSP0 digital shut off defective Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, fuse, replace module if nec.	A361		E	2
1DEC72	LSB-BSE1: 2.Shut off channel / DSP0 outside source feeding Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, replace module, if nec.	A361		E	2
1DED1B	LSB-BSE1: 2.Shut off channel / DSP1 digital shut off defective Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, fuse, replace module if nec.	A361		E	2
1DED72	LSB-BSE1: 2.Shut off channel / DSP1 outside source feeding Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, replace module, if nec.	A361		E	2
1DF006	LSB-BSE1: System error OS-DSP0 initialising error RAM erroneous Entry in error memory, program is stopped Inform Service of all error parameters and replace module	A361		E	2
1DF013	LSB-BSE1: System error OS-DSP0 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A361		E	2
1DF016	LSB-BSE1: System error OS-DSP0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A361		E	2
1DF050	LSB-BSE1: System error OS-DSP0 file not available error report Reload application software	A361		E	3
1DF073	LSB-BSE1: System error OS-DSP0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A361		E	2
1DF082	LSB-BSE1: System error OS-DSP0 hardware-watchdog erroneous Module reset Replace module	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DF0A1	LSB-BSE1: System error OS-DSP0 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF0A2	LSB-BSE1: System error OS-DSP0 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF0AD	LSB-BSE1: System error OS-DSP0 System voltage V26-Core outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF0B1	LSB-BSE1: System error OS-DSP0 Power-Fail-Status incorrect error report Check voltage	A361		E	2
1DF0C1	LSB-BSE1: System error OS-DSP0 Incorrect or wrong system version for application error report Reload matching system version	A361		E	1
1DF0D3	LSB-BSE1: System error OS-DSP0 Em. drop system is active -> System charge required Emerg. system takes over operation and allows repair of run time system Reestablish the defective DSP system via the 'Load system' menu point in the test system	A361		E	2
1DF106	LSB-BSE1: System error OS-DSP1 initialising error RAM erroneous Entry in error memory, program is stopped Inform Service of all error parameters and replace module	A361		E	2
1DF113	LSB-BSE1: System error OS-DSP1 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A361		E	2
1DF116	LSB-BSE1: System error OS-DSP1 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A361		E	2
1DF150	LSB-BSE1: System error OS-DSP1 file not available error report Reload application software	A361		E	3

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DF173	LSB-BSE1: System error OS-DSP1 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A361		E	2
1DF182	LSB-BSE1: System error OS-DSP1 hardware-watchdog erroneous Module reset Replace module	A361		E	2
1DF1A1	LSB-BSE1: System error OS-DSP1 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF1A2	LSB-BSE1: System error OS-DSP1 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF1AD	LSB-BSE1: System error OS-DSP1 System voltage V26-Core outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF1B1	LSB-BSE1: System error OS-DSP1 Power-Fail-Status incorrect error report Check voltage	A361		E	2
1DF1C1	LSB-BSE1: System error OS-DSP1 Incorrect or wrong system version for application error report Reload matching system version	A361		E	1
1DF1D3	LSB-BSE1: System error OS-DSP1 Em. drop system is active -> System charge required Emerg. system takes over operation and allows repair of run time system Reestablish the defective DSP system via the 'Load system' menu point in the test system	A361		E	2
1DF203	LSB-BSE1: System error OS-CPU0 CW Upload to data bank not carried out error report CW Carry out upload in data bank	A361		E	2
1DF280	LSB-BSE1: System error OS-CPU0 Fatal internal error error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DF299	LSB-BSE1: System error OS-CPU0 DSP0 erroneous error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF29A	LSB-BSE1: System error OS-CPU0 DSP1 erroneous error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF29B	LSB-BSE1: System error OS-CPU0 dsPIC erroneous error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF2A1	LSB-BSE1: System error OS-CPU0 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF2A2	LSB-BSE1: System error OS-CPU0 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF2A3	LSB-BSE1: System error OS-CPU0 Board temp. outside permissible range error indication on display Check coolant supply for monitor	A361		E	2
1DF2A4	LSB-BSE1: System error OS-CPU0 Inside temperature outside permissible range error indication on display Check coolant supply for monitor	A361		E	2
1DF2A5	LSB-BSE1: System error OS-CPU0 System voltage 12V-CCFL outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF2AB	LSB-BSE1: System error OS-CPU0 System voltage 5V-Standby outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF2AC	LSB-BSE1: System error OS-CPU0 Restoration of CW-operandi failed error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
1DF2AE	LSB-BSE1: System error OS-CPU0 System voltage PCMCIA erroneous error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF2AF	LSB-BSE1: System error OS-CPU0 System voltage 3V- cell-RTC too low error report If time is corrupt, replace battery Type CR1225 in monitor	A361		E	2
1DF2B0	LSB-BSE1: System error OS-CPU0 Time RTC erroneous (Low-Voltage) error report Replace battery Type CR1225 in monitor	A361		E	2
1DF2C0	LSB-BSE1: System error OS-CPU0 Hardware / Software erroneous error report If error repeated, repl. comp. group, report error param. to Service	A361		E	2
1DF2FA	LSB-BSE1: System error OS-CPU0 BSE to BSE communication via CAN erroneous error report Replace comp. group, report error parameter to Service	A361		E	2
1DFAC1	LSB-BSE1: Control data transfer CAN-A LSB-BSE1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A361.X1:21/22		E	1
2A0050	LSB-BSE2: LSBA Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0051	LSB-BSE2: LSBA Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0053	LSB-BSE2: LSBA Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0054	LSB-BSE2: LSBA Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0064	LSB-BSE2: LSBA Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0065	LSB-BSE2: LSBA Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0066	LSB-BSE2: LSBA Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0067	LSB-BSE2: LSBA Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0068	LSB-BSE2: LSBA Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0069	LSB-BSE2: LSBA Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A006A	LSB-BSE2: LSBA Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A006B	LSB-BSE2: LSBA Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A006C	LSB-BSE2: LSBA Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0150	LSB-BSE2: LSBA Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0151	LSB-BSE2: LSBA Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0153	LSB-BSE2: LSBA Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0154	LSB-BSE2: LSBA Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0164	LSB-BSE2: LSBA Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0165	LSB-BSE2: LSBA Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0166	LSB-BSE2: LSBA Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0167	LSB-BSE2: LSBA Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0168	LSB-BSE2: LSBA Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0169	LSB-BSE2: LSBA Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A016A	LSB-BSE2: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A016B	LSB-BSE2: LSBA Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A016C	LSB-BSE2: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0250	LSB-BSE2: LSBA Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0251	LSB-BSE2: LSBA Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0253	LSB-BSE2: LSBA Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0254	LSB-BSE2: LSBA Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0264	LSB-BSE2: LSBA Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0265	LSB-BSE2: LSBA Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0266	LSB-BSE2: LSBA Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0267	LSB-BSE2: LSBA Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0268	LSB-BSE2: LSBA Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0269	LSB-BSE2: LSBA Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A026A	LSB-BSE2: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A026B	LSB-BSE2: LSBA Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A026C	LSB-BSE2: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0350	LSB-BSE2: LSBA Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0351	LSB-BSE2: LSBA Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0353	LSB-BSE2: LSBA Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0354	LSB-BSE2: LSBA Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0364	LSB-BSE2: LSBA Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0365	LSB-BSE2: LSBA Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0366	LSB-BSE2: LSBA Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0367	LSB-BSE2: LSBA Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0368	LSB-BSE2: LSBA Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0369	LSB-BSE2: LSBA Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A036A	LSB-BSE2: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A036B	LSB-BSE2: LSBA Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A036C	LSB-BSE2: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0450	LSB-BSE2: LSBA Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0451	LSB-BSE2: LSBA Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0453	LSB-BSE2: LSBA Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0454	LSB-BSE2: LSBA Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0464	LSB-BSE2: LSBA Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0465	LSB-BSE2: LSBA Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0466	LSB-BSE2: LSBA Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0467	LSB-BSE2: LSBA Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0468	LSB-BSE2: LSBA Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0469	LSB-BSE2: LSBA Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A046A	LSB-BSE2: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A046B	LSB-BSE2: LSBA Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A046C	LSB-BSE2: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0550	LSB-BSE2: LSBA Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0551	LSB-BSE2: LSBA Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0553	LSB-BSE2: LSBA Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0554	LSB-BSE2: LSBA Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0564	LSB-BSE2: LSBA Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0565	LSB-BSE2: LSBA Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0566	LSB-BSE2: LSBA Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0567	LSB-BSE2: LSBA Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0568	LSB-BSE2: LSBA Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0569	LSB-BSE2: LSBA Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A056A	LSB-BSE2: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A056B	LSB-BSE2: LSBA Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A056C	LSB-BSE2: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0650	LSB-BSE2: LSBA Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0651	LSB-BSE2: LSBA Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0653	LSB-BSE2: LSBA Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0654	LSB-BSE2: LSBA Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0664	LSB-BSE2: LSBA Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0665	LSB-BSE2: LSBA Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0666	LSB-BSE2: LSBA Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0667	LSB-BSE2: LSBA Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0668	LSB-BSE2: LSBA Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0669	LSB-BSE2: LSBA Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A066A	LSB-BSE2: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A066B	LSB-BSE2: LSBA Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A066C	LSB-BSE2: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0750	LSB-BSE2: LSBA Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0751	LSB-BSE2: LSBA Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0753	LSB-BSE2: LSBA Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0754	LSB-BSE2: LSBA Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0764	LSB-BSE2: LSBA Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0765	LSB-BSE2: LSBA Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0766	LSB-BSE2: LSBA Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0767	LSB-BSE2: LSBA Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0768	LSB-BSE2: LSBA Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0769	LSB-BSE2: LSBA Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A076A	LSB-BSE2: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A076B	LSB-BSE2: LSBA Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A076C	LSB-BSE2: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0850	LSB-BSE2: LSBA Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0851	LSB-BSE2: LSBA Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0853	LSB-BSE2: LSBA Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0854	LSB-BSE2: LSBA Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0864	LSB-BSE2: LSBA Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0865	LSB-BSE2: LSBA Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0866	LSB-BSE2: LSBA Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0867	LSB-BSE2: LSBA Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0868	LSB-BSE2: LSBA Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0869	LSB-BSE2: LSBA Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A086A	LSB-BSE2: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A086B	LSB-BSE2: LSBA Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A086C	LSB-BSE2: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0950	LSB-BSE2: LSBA Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0951	LSB-BSE2: LSBA Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0953	LSB-BSE2: LSBA Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0954	LSB-BSE2: LSBA Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0964	LSB-BSE2: LSBA Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0965	LSB-BSE2: LSBA Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0966	LSB-BSE2: LSBA Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0967	LSB-BSE2: LSBA Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0968	LSB-BSE2: LSBA Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0969	LSB-BSE2: LSBA Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A096A	LSB-BSE2: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A096B	LSB-BSE2: LSBA Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A096C	LSB-BSE2: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0A50	LSB-BSE2: LSBA Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0A51	LSB-BSE2: LSBA Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0A53	LSB-BSE2: LSBA Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0A54	LSB-BSE2: LSBA Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0A64	LSB-BSE2: LSBA Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0A65	LSB-BSE2: LSBA Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0A66	LSB-BSE2: LSBA Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0A67	LSB-BSE2: LSBA Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0A68	LSB-BSE2: LSBA Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0A69	LSB-BSE2: LSBA Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A0A6A	LSB-BSE2: LSBA Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A0A6B	LSB-BSE2: LSBA Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A0A6C	LSB-BSE2: LSBA Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0B50	LSB-BSE2: LSBA Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0B51	LSB-BSE2: LSBA Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0B53	LSB-BSE2: LSBA Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0B54	LSB-BSE2: LSBA Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0B64	LSB-BSE2: LSBA Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0B65	LSB-BSE2: LSBA Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0B66	LSB-BSE2: LSBA Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0B67	LSB-BSE2: LSBA Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0B68	LSB-BSE2: LSBA Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0B69	LSB-BSE2: LSBA Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A0B6A	LSB-BSE2: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0B6B	LSB-BSE2: LSBA Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A0B6C	LSB-BSE2: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0C50	LSB-BSE2: LSBA Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0C51	LSB-BSE2: LSBA Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0C53	LSB-BSE2: LSBA Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0C54	LSB-BSE2: LSBA Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0C64	LSB-BSE2: LSBA Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0C65	LSB-BSE2: LSBA Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0C66	LSB-BSE2: LSBA Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0C67	LSB-BSE2: LSBA Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0C68	LSB-BSE2: LSBA Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0C69	LSB-BSE2: LSBA Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A0C6A	LSB-BSE2: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A0C6B	LSB-BSE2: LSBA Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A0C6C	LSB-BSE2: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0D50	LSB-BSE2: LSBA Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0D51	LSB-BSE2: LSBA Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0D53	LSB-BSE2: LSBA Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0D54	LSB-BSE2: LSBA Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0D64	LSB-BSE2: LSBA Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0D65	LSB-BSE2: LSBA Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0D66	LSB-BSE2: LSBA Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0D67	LSB-BSE2: LSBA Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0D68	LSB-BSE2: LSBA Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0D69	LSB-BSE2: LSBA Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A0D6A	LSB-BSE2: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A0D6B	LSB-BSE2: LSBA Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A0D6C	LSB-BSE2: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0E50	LSB-BSE2: LSBA Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0E51	LSB-BSE2: LSBA Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0E53	LSB-BSE2: LSBA Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0E54	LSB-BSE2: LSBA Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0E64	LSB-BSE2: LSBA Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0E65	LSB-BSE2: LSBA Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0E66	LSB-BSE2: LSBA Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0E67	LSB-BSE2: LSBA Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0E68	LSB-BSE2: LSBA Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A0E69	LSB-BSE2: LSBA Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A0E6A	LSB-BSE2: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A0E6B	LSB-BSE2: LSBA Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0E6C	LSB-BSE2: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A0F50	LSB-BSE2: LSBA Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A0F51	LSB-BSE2: LSBA Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A0F53	LSB-BSE2: LSBA Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A0F54	LSB-BSE2: LSBA Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A0F64	LSB-BSE2: LSBA Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A0F65	LSB-BSE2: LSBA Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A0F66	LSB-BSE2: LSBA Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A0F67	LSB-BSE2: LSBA Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A0F68	LSB-BSE2: LSBA Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A0F69	LSB-BSE2: LSBA Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A0F6A	LSB-BSE2: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A0F6B	LSB-BSE2: LSBA Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A0F6C	LSB-BSE2: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1050	LSB-BSE2: LSBA Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1051	LSB-BSE2: LSBA Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1053	LSB-BSE2: LSBA Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1054	LSB-BSE2: LSBA Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1064	LSB-BSE2: LSBA Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1065	LSB-BSE2: LSBA Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1066	LSB-BSE2: LSBA Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1067	LSB-BSE2: LSBA Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1068	LSB-BSE2: LSBA Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1069	LSB-BSE2: LSBA Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A106A	LSB-BSE2: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A106B	LSB-BSE2: LSBA Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A106C	LSB-BSE2: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1150	LSB-BSE2: LSBA Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1151	LSB-BSE2: LSBA Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1153	LSB-BSE2: LSBA Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1154	LSB-BSE2: LSBA Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1164	LSB-BSE2: LSBA Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1165	LSB-BSE2: LSBA Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1166	LSB-BSE2: LSBA Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1167	LSB-BSE2: LSBA Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1168	LSB-BSE2: LSBA Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1169	LSB-BSE2: LSBA Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A116A	LSB-BSE2: LSBA Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A116B	LSB-BSE2: LSBA Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A116C	LSB-BSE2: LSBA Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1250	LSB-BSE2: LSBA Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1251	LSB-BSE2: LSBA Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1253	LSB-BSE2: LSBA Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1254	LSB-BSE2: LSBA Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1264	LSB-BSE2: LSBA Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1265	LSB-BSE2: LSBA Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1266	LSB-BSE2: LSBA Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1267	LSB-BSE2: LSBA Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1268	LSB-BSE2: LSBA Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1269	LSB-BSE2: LSBA Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A126A	LSB-BSE2: LSBA Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A126B	LSB-BSE2: LSBA Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A126C	LSB-BSE2: LSBA Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1350	LSB-BSE2: LSBA Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1351	LSB-BSE2: LSBA Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1353	LSB-BSE2: LSBA Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1354	LSB-BSE2: LSBA Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1364	LSB-BSE2: LSBA Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1365	LSB-BSE2: LSBA Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1366	LSB-BSE2: LSBA Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1367	LSB-BSE2: LSBA Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1368	LSB-BSE2: LSBA Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1369	LSB-BSE2: LSBA Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A136A	LSB-BSE2: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A136B	LSB-BSE2: LSBA Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A136C	LSB-BSE2: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1450	LSB-BSE2: LSBA Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1451	LSB-BSE2: LSBA Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1453	LSB-BSE2: LSBA Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1454	LSB-BSE2: LSBA Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1464	LSB-BSE2: LSBA Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1465	LSB-BSE2: LSBA Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1466	LSB-BSE2: LSBA Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1467	LSB-BSE2: LSBA Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1468	LSB-BSE2: LSBA Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1469	LSB-BSE2: LSBA Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A146A	LSB-BSE2: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A146B	LSB-BSE2: LSBA Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A146C	LSB-BSE2: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1550	LSB-BSE2: LSBA Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1551	LSB-BSE2: LSBA Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1553	LSB-BSE2: LSBA Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1554	LSB-BSE2: LSBA Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1564	LSB-BSE2: LSBA Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1565	LSB-BSE2: LSBA Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1566	LSB-BSE2: LSBA Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1567	LSB-BSE2: LSBA Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1568	LSB-BSE2: LSBA Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1569	LSB-BSE2: LSBA Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A156A	LSB-BSE2: LSBA Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A156B	LSB-BSE2: LSBA Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A156C	LSB-BSE2: LSBA Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1650	LSB-BSE2: LSBA Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1651	LSB-BSE2: LSBA Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1653	LSB-BSE2: LSBA Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1654	LSB-BSE2: LSBA Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1664	LSB-BSE2: LSBA Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1665	LSB-BSE2: LSBA Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1666	LSB-BSE2: LSBA Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1667	LSB-BSE2: LSBA Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1668	LSB-BSE2: LSBA Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1669	LSB-BSE2: LSBA Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A166A	LSB-BSE2: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A166B	LSB-BSE2: LSBA Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A166C	LSB-BSE2: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1750	LSB-BSE2: LSBA Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1751	LSB-BSE2: LSBA Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1753	LSB-BSE2: LSBA Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1754	LSB-BSE2: LSBA Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1764	LSB-BSE2: LSBA Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1765	LSB-BSE2: LSBA Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1766	LSB-BSE2: LSBA Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1767	LSB-BSE2: LSBA Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1768	LSB-BSE2: LSBA Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1769	LSB-BSE2: LSBA Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A176A	LSB-BSE2: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A176B	LSB-BSE2: LSBA Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A176C	LSB-BSE2: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1850	LSB-BSE2: LSBA Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1851	LSB-BSE2: LSBA Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1853	LSB-BSE2: LSBA Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1854	LSB-BSE2: LSBA Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1864	LSB-BSE2: LSBA Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1865	LSB-BSE2: LSBA Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1866	LSB-BSE2: LSBA Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1867	LSB-BSE2: LSBA Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1868	LSB-BSE2: LSBA Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1869	LSB-BSE2: LSBA Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A186A	LSB-BSE2: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A186B	LSB-BSE2: LSBA Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A186C	LSB-BSE2: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1950	LSB-BSE2: LSBA Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1951	LSB-BSE2: LSBA Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1953	LSB-BSE2: LSBA Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1954	LSB-BSE2: LSBA Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1964	LSB-BSE2: LSBA Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1965	LSB-BSE2: LSBA Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1966	LSB-BSE2: LSBA Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1967	LSB-BSE2: LSBA Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1968	LSB-BSE2: LSBA Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1969	LSB-BSE2: LSBA Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A196A	LSB-BSE2: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A196B	LSB-BSE2: LSBA Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A196C	LSB-BSE2: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1A50	LSB-BSE2: LSBA Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1A51	LSB-BSE2: LSBA Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1A53	LSB-BSE2: LSBA Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1A54	LSB-BSE2: LSBA Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1A64	LSB-BSE2: LSBA Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1A65	LSB-BSE2: LSBA Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1A66	LSB-BSE2: LSBA Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1A67	LSB-BSE2: LSBA Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1A68	LSB-BSE2: LSBA Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1A69	LSB-BSE2: LSBA Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A1A6A	LSB-BSE2: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A1A6B	LSB-BSE2: LSBA Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A1A6C	LSB-BSE2: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1B50	LSB-BSE2: LSBA Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1B51	LSB-BSE2: LSBA Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1B53	LSB-BSE2: LSBA Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1B54	LSB-BSE2: LSBA Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1B64	LSB-BSE2: LSBA Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1B65	LSB-BSE2: LSBA Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1B66	LSB-BSE2: LSBA Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1B67	LSB-BSE2: LSBA Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1B68	LSB-BSE2: LSBA Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1B69	LSB-BSE2: LSBA Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A1B6A	LSB-BSE2: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A1B6B	LSB-BSE2: LSBA Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A1B6C	LSB-BSE2: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1C50	LSB-BSE2: LSBA Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1C51	LSB-BSE2: LSBA Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1C53	LSB-BSE2: LSBA Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1C54	LSB-BSE2: LSBA Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1C64	LSB-BSE2: LSBA Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1C65	LSB-BSE2: LSBA Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1C66	LSB-BSE2: LSBA Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1C67	LSB-BSE2: LSBA Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1C68	LSB-BSE2: LSBA Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1C69	LSB-BSE2: LSBA Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1C6A	LSB-BSE2: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A1C6B	LSB-BSE2: LSBA Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A1C6C	LSB-BSE2: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1D50	LSB-BSE2: LSBA Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1D51	LSB-BSE2: LSBA Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1D53	LSB-BSE2: LSBA Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1D54	LSB-BSE2: LSBA Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2
2A1D64	LSB-BSE2: LSBA Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1D65	LSB-BSE2: LSBA Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1D66	LSB-BSE2: LSBA Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1D67	LSB-BSE2: LSBA Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1D68	LSB-BSE2: LSBA Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1D69	LSB-BSE2: LSBA Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A1D6A	LSB-BSE2: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A1D6B	LSB-BSE2: LSBA Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A1D6C	LSB-BSE2: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A1E50	LSB-BSE2: LSBA Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:9		E	2
2A1E51	LSB-BSE2: LSBA Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:9		E	2
2A1E53	LSB-BSE2: LSBA Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:9		E	1
2A1E54	LSB-BSE2: LSBA Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A1E64	LSB-BSE2: LSBA Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:9		E	1
2A1E65	LSB-BSE2: LSBA Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:9		E	2
2A1E66	LSB-BSE2: LSBA Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:9		E	2
2A1E67	LSB-BSE2: LSBA Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:9		E	1
2A1E68	LSB-BSE2: LSBA Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:9		E	1
2A1E69	LSB-BSE2: LSBA Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:9		E	1
2A1E6A	LSB-BSE2: LSBA Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:9		E	2
2A1E6B	LSB-BSE2: LSBA Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:9		E	2
2A1E6C	LSB-BSE2: LSBA Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:9		E	2
2A2052	LSB-BSE2: Control data transfer LSBA has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362.X4:9		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A2055	LSB-BSE2: Control data transfer LSBA Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X4:9		E	2
2A2056	LSB-BSE2: Control data transfer LSBA Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X4:9		E	2
2A2057	LSB-BSE2: Control data transfer LSBA has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362.X4:9		E	1
2A2058	LSB-BSE2: Control data transfer LSBA recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362.X4:9		E	0
2A2059	LSB-BSE2: Control data transfer LSBA recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362.X4:9		E	0
2A2060	LSB-BSE2: Control data transfer LSBA driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362.X4:9		E	2
2A2061	LSB-BSE2: Control data transfer LSBA driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362.X4:9		E	2
2A2062	LSB-BSE2: Control data transfer LSBA Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362.X4:9		E	2
2A3050	LSB-BSE2: LSBB Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3051	LSB-BSE2: LSBB Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3053	LSB-BSE2: LSBB Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3054	LSB-BSE2: LSBB Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3064	LSB-BSE2: LSBB Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3065	LSB-BSE2: LSBB Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3066	LSB-BSE2: LSBB Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3067	LSB-BSE2: LSBB Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3068	LSB-BSE2: LSBB Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3069	LSB-BSE2: LSBB Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A306A	LSB-BSE2: LSBB Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A306B	LSB-BSE2: LSBB Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A306C	LSB-BSE2: LSBB Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3150	LSB-BSE2: LSBB Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3151	LSB-BSE2: LSBB Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3153	LSB-BSE2: LSBB Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3154	LSB-BSE2: LSBB Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3164	LSB-BSE2: LSBB Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3165	LSB-BSE2: LSBB Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3166	LSB-BSE2: LSBB Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3167	LSB-BSE2: LSBB Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3168	LSB-BSE2: LSBB Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3169	LSB-BSE2: LSBB Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A316A	LSB-BSE2: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A316B	LSB-BSE2: LSBB Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A316C	LSB-BSE2: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3350	LSB-BSE2: LSBB Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3351	LSB-BSE2: LSBB Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3353	LSB-BSE2: LSBB Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3354	LSB-BSE2: LSBB Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3364	LSB-BSE2: LSBB Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3365	LSB-BSE2: LSBB Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3366	LSB-BSE2: LSBB Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3367	LSB-BSE2: LSBB Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3368	LSB-BSE2: LSBB Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3369	LSB-BSE2: LSBB Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A336A	LSB-BSE2: LSBB Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A336B	LSB-BSE2: LSBB Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A336C	LSB-BSE2: LSBB Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3450	LSB-BSE2: LSBB Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3451	LSB-BSE2: LSBB Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3453	LSB-BSE2: LSBB Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3454	LSB-BSE2: LSBB Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3464	LSB-BSE2: LSBB Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3465	LSB-BSE2: LSBB Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3466	LSB-BSE2: LSBB Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3467	LSB-BSE2: LSBB Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3468	LSB-BSE2: LSBB Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3469	LSB-BSE2: LSBB Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A346A	LSB-BSE2: LSBB Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A346B	LSB-BSE2: LSBB Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A346C	LSB-BSE2: LSBB Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3550	LSB-BSE2: LSBB Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3551	LSB-BSE2: LSBB Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3553	LSB-BSE2: LSBB Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3554	LSB-BSE2: LSBB Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3564	LSB-BSE2: LSBB Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3565	LSB-BSE2: LSBB Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3566	LSB-BSE2: LSBB Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3567	LSB-BSE2: LSBB Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3568	LSB-BSE2: LSBB Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3569	LSB-BSE2: LSBB Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A356A	LSB-BSE2: LSBB Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A356B	LSB-BSE2: LSBB Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A356C	LSB-BSE2: LSBB Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3650	LSB-BSE2: LSBB Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3651	LSB-BSE2: LSBB Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3653	LSB-BSE2: LSBB Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3654	LSB-BSE2: LSBB Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3664	LSB-BSE2: LSBB Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3665	LSB-BSE2: LSBB Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3666	LSB-BSE2: LSBB Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3667	LSB-BSE2: LSBB Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3668	LSB-BSE2: LSBB Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3669	LSB-BSE2: LSBB Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A366A	LSB-BSE2: LSBB Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A366B	LSB-BSE2: LSBB Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A366C	LSB-BSE2: LSBB Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3750	LSB-BSE2: LSBB Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3751	LSB-BSE2: LSBB Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3753	LSB-BSE2: LSBB Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3754	LSB-BSE2: LSBB Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3764	LSB-BSE2: LSBB Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3765	LSB-BSE2: LSBB Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3766	LSB-BSE2: LSBB Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3767	LSB-BSE2: LSBB Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3768	LSB-BSE2: LSBB Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3769	LSB-BSE2: LSBB Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A376A	LSB-BSE2: LSBB Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A376B	LSB-BSE2: LSBB Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A376C	LSB-BSE2: LSBB Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3850	LSB-BSE2: LSBB Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3851	LSB-BSE2: LSBB Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3853	LSB-BSE2: LSBB Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3854	LSB-BSE2: LSBB Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3864	LSB-BSE2: LSBB Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3865	LSB-BSE2: LSBB Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3866	LSB-BSE2: LSBB Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3867	LSB-BSE2: LSBB Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3868	LSB-BSE2: LSBB Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3869	LSB-BSE2: LSBB Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A386A	LSB-BSE2: LSBB Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A386B	LSB-BSE2: LSBB Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A386C	LSB-BSE2: LSBB Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3950	LSB-BSE2: LSBB Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3951	LSB-BSE2: LSBB Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3953	LSB-BSE2: LSBB Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3954	LSB-BSE2: LSBB Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3964	LSB-BSE2: LSBB Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3965	LSB-BSE2: LSBB Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3966	LSB-BSE2: LSBB Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3967	LSB-BSE2: LSBB Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3968	LSB-BSE2: LSBB Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3969	LSB-BSE2: LSBB Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A396A	LSB-BSE2: LSBB Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A396B	LSB-BSE2: LSBB Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A396C	LSB-BSE2: LSBB Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3A50	LSB-BSE2: LSBB Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3A51	LSB-BSE2: LSBB Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3A53	LSB-BSE2: LSBB Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3A54	LSB-BSE2: LSBB Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3A64	LSB-BSE2: LSBB Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3A65	LSB-BSE2: LSBB Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3A66	LSB-BSE2: LSBB Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3A67	LSB-BSE2: LSBB Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3A68	LSB-BSE2: LSBB Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3A69	LSB-BSE2: LSBB Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A3A6A	LSB-BSE2: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A3A6B	LSB-BSE2: LSBB Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A3A6C	LSB-BSE2: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3B50	LSB-BSE2: LSBB Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3B51	LSB-BSE2: LSBB Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3B53	LSB-BSE2: LSBB Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3B54	LSB-BSE2: LSBB Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3B64	LSB-BSE2: LSBB Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3B65	LSB-BSE2: LSBB Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3B66	LSB-BSE2: LSBB Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3B67	LSB-BSE2: LSBB Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3B68	LSB-BSE2: LSBB Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3B69	LSB-BSE2: LSBB Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A3B6A	LSB-BSE2: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A3B6B	LSB-BSE2: LSBB Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3B6C	LSB-BSE2: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3C50	LSB-BSE2: LSBB Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3C51	LSB-BSE2: LSBB Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3C53	LSB-BSE2: LSBB Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3C54	LSB-BSE2: LSBB Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3C64	LSB-BSE2: LSBB Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3C65	LSB-BSE2: LSBB Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3C66	LSB-BSE2: LSBB Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3C67	LSB-BSE2: LSBB Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3C68	LSB-BSE2: LSBB Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3C69	LSB-BSE2: LSBB Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A3C6A	LSB-BSE2: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A3C6B	LSB-BSE2: LSBB Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A3C6C	LSB-BSE2: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3D50	LSB-BSE2: LSBB Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3D51	LSB-BSE2: LSBB Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3D53	LSB-BSE2: LSBB Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3D54	LSB-BSE2: LSBB Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3D64	LSB-BSE2: LSBB Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3D65	LSB-BSE2: LSBB Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3D66	LSB-BSE2: LSBB Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3D67	LSB-BSE2: LSBB Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3D68	LSB-BSE2: LSBB Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3D69	LSB-BSE2: LSBB Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A3D6A	LSB-BSE2: LSBB Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A3D6B	LSB-BSE2: LSBB Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A3D6C	LSB-BSE2: LSBB Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A3E50	LSB-BSE2: LSBB Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3E51	LSB-BSE2: LSBB Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3E53	LSB-BSE2: LSBB Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3E54	LSB-BSE2: LSBB Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3E64	LSB-BSE2: LSBB Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3E65	LSB-BSE2: LSBB Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3E66	LSB-BSE2: LSBB Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3E67	LSB-BSE2: LSBB Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3E68	LSB-BSE2: LSBB Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3E69	LSB-BSE2: LSBB Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A3E6A	LSB-BSE2: LSBB Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A3E6B	LSB-BSE2: LSBB Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A3E6C	LSB-BSE2: LSBB Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3F50	LSB-BSE2: LSBB Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A3F51	LSB-BSE2: LSBB Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A3F53	LSB-BSE2: LSBB Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A3F54	LSB-BSE2: LSBB Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A3F64	LSB-BSE2: LSBB Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A3F65	LSB-BSE2: LSBB Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A3F66	LSB-BSE2: LSBB Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A3F67	LSB-BSE2: LSBB Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A3F68	LSB-BSE2: LSBB Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A3F69	LSB-BSE2: LSBB Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A3F6A	LSB-BSE2: LSBB Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A3F6B	LSB-BSE2: LSBB Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A3F6C	LSB-BSE2: LSBB Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4050	LSB-BSE2: LSBB Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4051	LSB-BSE2: LSBB Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4053	LSB-BSE2: LSBB Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4054	LSB-BSE2: LSBB Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4064	LSB-BSE2: LSBB Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4065	LSB-BSE2: LSBB Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4066	LSB-BSE2: LSBB Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4067	LSB-BSE2: LSBB Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4068	LSB-BSE2: LSBB Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4069	LSB-BSE2: LSBB Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A406A	LSB-BSE2: LSBB Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A406B	LSB-BSE2: LSBB Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A406C	LSB-BSE2: LSBB Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4150	LSB-BSE2: LSBB Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4151	LSB-BSE2: LSBB Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4153	LSB-BSE2: LSBB Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4154	LSB-BSE2: LSBB Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4164	LSB-BSE2: LSBB Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4165	LSB-BSE2: LSBB Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4166	LSB-BSE2: LSBB Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4167	LSB-BSE2: LSBB Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4168	LSB-BSE2: LSBB Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4169	LSB-BSE2: LSBB Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A416A	LSB-BSE2: LSBB Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A416B	LSB-BSE2: LSBB Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A416C	LSB-BSE2: LSBB Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4250	LSB-BSE2: LSBB Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4251	LSB-BSE2: LSBB Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4253	LSB-BSE2: LSBB Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4254	LSB-BSE2: LSBB Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4264	LSB-BSE2: LSBB Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4265	LSB-BSE2: LSBB Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4266	LSB-BSE2: LSBB Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4267	LSB-BSE2: LSBB Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4268	LSB-BSE2: LSBB Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4269	LSB-BSE2: LSBB Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A426A	LSB-BSE2: LSBB Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A426B	LSB-BSE2: LSBB Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A426C	LSB-BSE2: LSBB Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4350	LSB-BSE2: LSBB Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4351	LSB-BSE2: LSBB Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4353	LSB-BSE2: LSBB Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4354	LSB-BSE2: LSBB Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4364	LSB-BSE2: LSBB Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4365	LSB-BSE2: LSBB Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4366	LSB-BSE2: LSBB Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4367	LSB-BSE2: LSBB Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4368	LSB-BSE2: LSBB Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4369	LSB-BSE2: LSBB Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A436A	LSB-BSE2: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A436B	LSB-BSE2: LSBB Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A436C	LSB-BSE2: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4450	LSB-BSE2: LSBB Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4451	LSB-BSE2: LSBB Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4453	LSB-BSE2: LSBB Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4454	LSB-BSE2: LSBB Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4464	LSB-BSE2: LSBB Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4465	LSB-BSE2: LSBB Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4466	LSB-BSE2: LSBB Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4467	LSB-BSE2: LSBB Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4468	LSB-BSE2: LSBB Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4469	LSB-BSE2: LSBB Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A446A	LSB-BSE2: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A446B	LSB-BSE2: LSBB Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A446C	LSB-BSE2: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4550	LSB-BSE2: LSBB Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4551	LSB-BSE2: LSBB Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4553	LSB-BSE2: LSBB Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4554	LSB-BSE2: LSBB Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4564	LSB-BSE2: LSBB Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4565	LSB-BSE2: LSBB Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4566	LSB-BSE2: LSBB Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4567	LSB-BSE2: LSBB Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4568	LSB-BSE2: LSBB Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4569	LSB-BSE2: LSBB Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A456A	LSB-BSE2: LSBB Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A456B	LSB-BSE2: LSBB Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A456C	LSB-BSE2: LSBB Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4650	LSB-BSE2: LSBB Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4651	LSB-BSE2: LSBB Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4653	LSB-BSE2: LSBB Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4654	LSB-BSE2: LSBB Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4664	LSB-BSE2: LSBB Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4665	LSB-BSE2: LSBB Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4666	LSB-BSE2: LSBB Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4667	LSB-BSE2: LSBB Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4668	LSB-BSE2: LSBB Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4669	LSB-BSE2: LSBB Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A466A	LSB-BSE2: LSBB Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A466B	LSB-BSE2: LSBB Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A466C	LSB-BSE2: LSBB Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4750	LSB-BSE2: LSBB Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4751	LSB-BSE2: LSBB Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4753	LSB-BSE2: LSBB Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4754	LSB-BSE2: LSBB Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4764	LSB-BSE2: LSBB Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4765	LSB-BSE2: LSBB Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4766	LSB-BSE2: LSBB Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4767	LSB-BSE2: LSBB Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4768	LSB-BSE2: LSBB Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4769	LSB-BSE2: LSBB Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A476A	LSB-BSE2: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A476B	LSB-BSE2: LSBB Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A476C	LSB-BSE2: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4850	LSB-BSE2: LSBB Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4851	LSB-BSE2: LSBB Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4853	LSB-BSE2: LSBB Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4854	LSB-BSE2: LSBB Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4864	LSB-BSE2: LSBB Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4865	LSB-BSE2: LSBB Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4866	LSB-BSE2: LSBB Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4867	LSB-BSE2: LSBB Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4868	LSB-BSE2: LSBB Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4869	LSB-BSE2: LSBB Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A486A	LSB-BSE2: LSBB Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A486B	LSB-BSE2: LSBB Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A486C	LSB-BSE2: LSBB Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4950	LSB-BSE2: LSBB Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4951	LSB-BSE2: LSBB Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4953	LSB-BSE2: LSBB Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4954	LSB-BSE2: LSBB Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4964	LSB-BSE2: LSBB Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4965	LSB-BSE2: LSBB Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4966	LSB-BSE2: LSBB Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4967	LSB-BSE2: LSBB Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4968	LSB-BSE2: LSBB Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4969	LSB-BSE2: LSBB Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A496A	LSB-BSE2: LSBB Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A496B	LSB-BSE2: LSBB Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A496C	LSB-BSE2: LSBB Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4A50	LSB-BSE2: LSBB Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4A51	LSB-BSE2: LSBB Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4A53	LSB-BSE2: LSBB Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4A54	LSB-BSE2: LSBB Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4A64	LSB-BSE2: LSBB Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4A65	LSB-BSE2: LSBB Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4A66	LSB-BSE2: LSBB Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4A67	LSB-BSE2: LSBB Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4A68	LSB-BSE2: LSBB Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4A69	LSB-BSE2: LSBB Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A4A6A	LSB-BSE2: LSBB Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A4A6B	LSB-BSE2: LSBB Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A4A6C	LSB-BSE2: LSBB Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4B50	LSB-BSE2: LSBB Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4B51	LSB-BSE2: LSBB Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4B53	LSB-BSE2: LSBB Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4B54	LSB-BSE2: LSBB Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4B64	LSB-BSE2: LSBB Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4B65	LSB-BSE2: LSBB Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4B66	LSB-BSE2: LSBB Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4B67	LSB-BSE2: LSBB Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4B68	LSB-BSE2: LSBB Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4B69	LSB-BSE2: LSBB Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A4B6A	LSB-BSE2: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A4B6B	LSB-BSE2: LSBB Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A4B6C	LSB-BSE2: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4C50	LSB-BSE2: LSBB Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4C51	LSB-BSE2: LSBB Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4C53	LSB-BSE2: LSBB Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4C54	LSB-BSE2: LSBB Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4C64	LSB-BSE2: LSBB Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4C65	LSB-BSE2: LSBB Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4C66	LSB-BSE2: LSBB Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4C67	LSB-BSE2: LSBB Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1
2A4C68	LSB-BSE2: LSBB Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4C69	LSB-BSE2: LSBB Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A4C6A	LSB-BSE2: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4C6B	LSB-BSE2: LSBB Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A4C6C	LSB-BSE2: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A4D50	LSB-BSE2: LSBB Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:10		E	2
2A4D51	LSB-BSE2: LSBB Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:10		E	2
2A4D53	LSB-BSE2: LSBB Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:10		E	1
2A4D54	LSB-BSE2: LSBB Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:10		E	2
2A4D64	LSB-BSE2: LSBB Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:10		E	1
2A4D65	LSB-BSE2: LSBB Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:10		E	2
2A4D66	LSB-BSE2: LSBB Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:10		E	2
2A4D67	LSB-BSE2: LSBB Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A4D68	LSB-BSE2: LSBB Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:10		E	1
2A4D69	LSB-BSE2: LSBB Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:10		E	1
2A4D6A	LSB-BSE2: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:10		E	2
2A4D6B	LSB-BSE2: LSBB Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:10		E	2
2A4D6C	LSB-BSE2: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:10		E	2
2A5052	LSB-BSE2: Control data transfer LSBB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362.X4:10		E	0
2A5055	LSB-BSE2: Control data transfer LSBB Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X4:10		E	2
2A5056	LSB-BSE2: Control data transfer LSBB Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X4:10		E	2
2A5057	LSB-BSE2: Control data transfer LSBB has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362.X4:10		E	1
2A5058	LSB-BSE2: Control data transfer LSBB recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362.X4:10		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A5059	LSB-BSE2: Control data transfer LSBB recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362.X4:10		E	0
2A5060	LSB-BSE2: Control data transfer LSBB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362.X4:10		E	2
2A5061	LSB-BSE2: Control data transfer LSBB driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362.X4:10		E	2
2A5062	LSB-BSE2: Control data transfer LSBB Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362.X4:10		E	2
2A6050	LSB-BSE2: LSBC Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6051	LSB-BSE2: LSBC Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6053	LSB-BSE2: LSBC Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6054	LSB-BSE2: LSBC Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6064	LSB-BSE2: LSBC Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6065	LSB-BSE2: LSBC Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6066	LSB-BSE2: LSBC Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6067	LSB-BSE2: LSBC Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6068	LSB-BSE2: LSBC Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6069	LSB-BSE2: LSBC Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A606A	LSB-BSE2: LSBC Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A606B	LSB-BSE2: LSBC Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A606C	LSB-BSE2: LSBC Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6150	LSB-BSE2: LSBC Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6151	LSB-BSE2: LSBC Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6153	LSB-BSE2: LSBC Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6154	LSB-BSE2: LSBC Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6164	LSB-BSE2: LSBC Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6165	LSB-BSE2: LSBC Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6166	LSB-BSE2: LSBC Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6167	LSB-BSE2: LSBC Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6168	LSB-BSE2: LSBC Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6169	LSB-BSE2: LSBC Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A616A	LSB-BSE2: LSBC Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A616B	LSB-BSE2: LSBC Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A616C	LSB-BSE2: LSBC Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6250	LSB-BSE2: LSBC Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6251	LSB-BSE2: LSBC Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6253	LSB-BSE2: LSBC Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6254	LSB-BSE2: LSBC Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6264	LSB-BSE2: LSBC Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6265	LSB-BSE2: LSBC Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6266	LSB-BSE2: LSBC Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6267	LSB-BSE2: LSBC Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6268	LSB-BSE2: LSBC Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6269	LSB-BSE2: LSBC Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A626A	LSB-BSE2: LSBC Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A626B	LSB-BSE2: LSBC Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A626C	LSB-BSE2: LSBC Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6350	LSB-BSE2: LSBC Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6351	LSB-BSE2: LSBC Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6353	LSB-BSE2: LSBC Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6354	LSB-BSE2: LSBC Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6364	LSB-BSE2: LSBC Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6365	LSB-BSE2: LSBC Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6366	LSB-BSE2: LSBC Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6367	LSB-BSE2: LSBC Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6368	LSB-BSE2: LSBC Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6369	LSB-BSE2: LSBC Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A636A	LSB-BSE2: LSBC Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A636B	LSB-BSE2: LSBC Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A636C	LSB-BSE2: LSBC Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6450	LSB-BSE2: LSBC Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6451	LSB-BSE2: LSBC Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6453	LSB-BSE2: LSBC Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6454	LSB-BSE2: LSBC Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6464	LSB-BSE2: LSBC Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6465	LSB-BSE2: LSBC Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6466	LSB-BSE2: LSBC Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6467	LSB-BSE2: LSBC Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6468	LSB-BSE2: LSBC Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6469	LSB-BSE2: LSBC Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A646A	LSB-BSE2: LSBC Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A646B	LSB-BSE2: LSBC Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A646C	LSB-BSE2: LSBC Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6550	LSB-BSE2: LSBC Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6551	LSB-BSE2: LSBC Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6553	LSB-BSE2: LSBC Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6554	LSB-BSE2: LSBC Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6564	LSB-BSE2: LSBC Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6565	LSB-BSE2: LSBC Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6566	LSB-BSE2: LSBC Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6567	LSB-BSE2: LSBC Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6568	LSB-BSE2: LSBC Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6569	LSB-BSE2: LSBC Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A656A	LSB-BSE2: LSBC Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A656B	LSB-BSE2: LSBC Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A656C	LSB-BSE2: LSBC Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6650	LSB-BSE2: LSBC Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6651	LSB-BSE2: LSBC Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6653	LSB-BSE2: LSBC Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6654	LSB-BSE2: LSBC Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6664	LSB-BSE2: LSBC Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6665	LSB-BSE2: LSBC Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6666	LSB-BSE2: LSBC Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6667	LSB-BSE2: LSBC Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6668	LSB-BSE2: LSBC Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6669	LSB-BSE2: LSBC Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A666A	LSB-BSE2: LSBC Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A666B	LSB-BSE2: LSBC Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A666C	LSB-BSE2: LSBC Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6750	LSB-BSE2: LSBC Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6751	LSB-BSE2: LSBC Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6753	LSB-BSE2: LSBC Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6754	LSB-BSE2: LSBC Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6764	LSB-BSE2: LSBC Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6765	LSB-BSE2: LSBC Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6766	LSB-BSE2: LSBC Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6767	LSB-BSE2: LSBC Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6768	LSB-BSE2: LSBC Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6769	LSB-BSE2: LSBC Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A676A	LSB-BSE2: LSBC Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A676B	LSB-BSE2: LSBC Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A676C	LSB-BSE2: LSBC Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6850	LSB-BSE2: LSBC Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6851	LSB-BSE2: LSBC Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6853	LSB-BSE2: LSBC Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6854	LSB-BSE2: LSBC Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6864	LSB-BSE2: LSBC Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6865	LSB-BSE2: LSBC Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6866	LSB-BSE2: LSBC Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6867	LSB-BSE2: LSBC Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6868	LSB-BSE2: LSBC Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6869	LSB-BSE2: LSBC Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A686A	LSB-BSE2: LSBC Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A686B	LSB-BSE2: LSBC Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A686C	LSB-BSE2: LSBC Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6950	LSB-BSE2: LSBC Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6951	LSB-BSE2: LSBC Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6953	LSB-BSE2: LSBC Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6954	LSB-BSE2: LSBC Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6964	LSB-BSE2: LSBC Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6965	LSB-BSE2: LSBC Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6966	LSB-BSE2: LSBC Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6967	LSB-BSE2: LSBC Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6968	LSB-BSE2: LSBC Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6969	LSB-BSE2: LSBC Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A696A	LSB-BSE2: LSBC Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A696B	LSB-BSE2: LSBC Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A696C	LSB-BSE2: LSBC Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6A50	LSB-BSE2: LSBC Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6A51	LSB-BSE2: LSBC Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6A53	LSB-BSE2: LSBC Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6A54	LSB-BSE2: LSBC Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6A64	LSB-BSE2: LSBC Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6A65	LSB-BSE2: LSBC Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6A66	LSB-BSE2: LSBC Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6A67	LSB-BSE2: LSBC Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6A68	LSB-BSE2: LSBC Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6A69	LSB-BSE2: LSBC Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A6A6A	LSB-BSE2: LSBC Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A6A6B	LSB-BSE2: LSBC Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A6A6C	LSB-BSE2: LSBC Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6B50	LSB-BSE2: LSBC Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6B51	LSB-BSE2: LSBC Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6B53	LSB-BSE2: LSBC Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6B54	LSB-BSE2: LSBC Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6B64	LSB-BSE2: LSBC Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6B65	LSB-BSE2: LSBC Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6B66	LSB-BSE2: LSBC Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6B67	LSB-BSE2: LSBC Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6B68	LSB-BSE2: LSBC Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6B69	LSB-BSE2: LSBC Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A6B6A	LSB-BSE2: LSBC Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A6B6B	LSB-BSE2: LSBC Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A6B6C	LSB-BSE2: LSBC Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6C50	LSB-BSE2: LSBC Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6C51	LSB-BSE2: LSBC Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6C53	LSB-BSE2: LSBC Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6C54	LSB-BSE2: LSBC Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6C64	LSB-BSE2: LSBC Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6C65	LSB-BSE2: LSBC Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6C66	LSB-BSE2: LSBC Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6C67	LSB-BSE2: LSBC Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6C68	LSB-BSE2: LSBC Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6C69	LSB-BSE2: LSBC Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6C6A	LSB-BSE2: LSBC Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A6C6B	LSB-BSE2: LSBC Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A6C6C	LSB-BSE2: LSBC Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6D50	LSB-BSE2: LSBC Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6D51	LSB-BSE2: LSBC Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6D53	LSB-BSE2: LSBC Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6D54	LSB-BSE2: LSBC Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A6D64	LSB-BSE2: LSBC Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6D65	LSB-BSE2: LSBC Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6D66	LSB-BSE2: LSBC Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6D67	LSB-BSE2: LSBC Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6D68	LSB-BSE2: LSBC Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6D69	LSB-BSE2: LSBC Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A6D6A	LSB-BSE2: LSBC Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A6D6B	LSB-BSE2: LSBC Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A6D6C	LSB-BSE2: LSBC Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A6E50	LSB-BSE2: LSBC Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A6E51	LSB-BSE2: LSBC Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A6E53	LSB-BSE2: LSBC Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A6E54	LSB-BSE2: LSBC Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A6E64	LSB-BSE2: LSBC Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A6E65	LSB-BSE2: LSBC Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A6E66	LSB-BSE2: LSBC Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A6E67	LSB-BSE2: LSBC Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A6E68	LSB-BSE2: LSBC Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A6E69	LSB-BSE2: LSBC Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A6E6A	LSB-BSE2: LSBC Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A6E6B	LSB-BSE2: LSBC Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A6E6C	LSB-BSE2: LSBC Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A7850	LSB-BSE2: LSBC Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A7851	LSB-BSE2: LSBC Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A7853	LSB-BSE2: LSBC Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A7854	LSB-BSE2: LSBC Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A7864	LSB-BSE2: LSBC Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A7865	LSB-BSE2: LSBC Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A7866	LSB-BSE2: LSBC Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A7867	LSB-BSE2: LSBC Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A7868	LSB-BSE2: LSBC Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A7869	LSB-BSE2: LSBC Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A786A	LSB-BSE2: LSBC Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A786B	LSB-BSE2: LSBC Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A786C	LSB-BSE2: LSBC Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A7950	LSB-BSE2: LSBC Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A7951	LSB-BSE2: LSBC Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A7953	LSB-BSE2: LSBC Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A7954	LSB-BSE2: LSBC Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A7964	LSB-BSE2: LSBC Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A7965	LSB-BSE2: LSBC Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A7966	LSB-BSE2: LSBC Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A7967	LSB-BSE2: LSBC Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A7968	LSB-BSE2: LSBC Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A7969	LSB-BSE2: LSBC Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A796A	LSB-BSE2: LSBC Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A796B	LSB-BSE2: LSBC Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A796C	LSB-BSE2: LSBC Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A7A50	LSB-BSE2: LSBC Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A7A51	LSB-BSE2: LSBC Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A7A53	LSB-BSE2: LSBC Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A7A54	LSB-BSE2: LSBC Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A7A64	LSB-BSE2: LSBC Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A7A65	LSB-BSE2: LSBC Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A7A66	LSB-BSE2: LSBC Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A7A67	LSB-BSE2: LSBC Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A7A68	LSB-BSE2: LSBC Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A7A69	LSB-BSE2: LSBC Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A7A6A	LSB-BSE2: LSBC Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A7A6B	LSB-BSE2: LSBC Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A7A6C	LSB-BSE2: LSBC Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A7B50	LSB-BSE2: LSBC Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A7B51	LSB-BSE2: LSBC Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A7B53	LSB-BSE2: LSBC Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A7B54	LSB-BSE2: LSBC Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A7B64	LSB-BSE2: LSBC Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A7B65	LSB-BSE2: LSBC Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A7B66	LSB-BSE2: LSBC Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A7B67	LSB-BSE2: LSBC Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A7B68	LSB-BSE2: LSBC Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A7B69	LSB-BSE2: LSBC Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A7B6A	LSB-BSE2: LSBC Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A7B6B	LSB-BSE2: LSBC Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A7B6C	LSB-BSE2: LSBC Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A7C50	LSB-BSE2: LSBC Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A7C51	LSB-BSE2: LSBC Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A7C53	LSB-BSE2: LSBC Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A7C54	LSB-BSE2: LSBC Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A7C64	LSB-BSE2: LSBC Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A7C65	LSB-BSE2: LSBC Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A7C66	LSB-BSE2: LSBC Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A7C67	LSB-BSE2: LSBC Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A7C68	LSB-BSE2: LSBC Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A7C69	LSB-BSE2: LSBC Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A7C6A	LSB-BSE2: LSBC Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A7C6B	LSB-BSE2: LSBC Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A7C6C	LSB-BSE2: LSBC Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A7D50	LSB-BSE2: LSBC Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A7D51	LSB-BSE2: LSBC Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A7D53	LSB-BSE2: LSBC Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1
2A7D54	LSB-BSE2: LSBC Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A7D64	LSB-BSE2: LSBC Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A7D65	LSB-BSE2: LSBC Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A7D66	LSB-BSE2: LSBC Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A7D67	LSB-BSE2: LSBC Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A7D68	LSB-BSE2: LSBC Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A7D69	LSB-BSE2: LSBC Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A7D6A	LSB-BSE2: LSBC Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A7D6B	LSB-BSE2: LSBC Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A7D6C	LSB-BSE2: LSBC Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2
2A7E50	LSB-BSE2: LSBC Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:11		E	2
2A7E51	LSB-BSE2: LSBC Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:11		E	2
2A7E53	LSB-BSE2: LSBC Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A7E54	LSB-BSE2: LSBC Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:11		E	2
2A7E64	LSB-BSE2: LSBC Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:11		E	1
2A7E65	LSB-BSE2: LSBC Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:11		E	2
2A7E66	LSB-BSE2: LSBC Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:11		E	2
2A7E67	LSB-BSE2: LSBC Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:11		E	1
2A7E68	LSB-BSE2: LSBC Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:11		E	1
2A7E69	LSB-BSE2: LSBC Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:11		E	1
2A7E6A	LSB-BSE2: LSBC Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:11		E	2
2A7E6B	LSB-BSE2: LSBC Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:11		E	2
2A7E6C	LSB-BSE2: LSBC Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A8052	LSB-BSE2: Control data transfer LSBC has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362.X4:11		E	0
2A8055	LSB-BSE2: Control data transfer LSBC Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X4:11		E	2
2A8056	LSB-BSE2: Control data transfer LSBC Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X4:11		E	2
2A8057	LSB-BSE2: Control data transfer LSBC has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362.X4:11		E	1
2A8058	LSB-BSE2: Control data transfer LSBC recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362.X4:11		E	0
2A8059	LSB-BSE2: Control data transfer LSBC recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362.X4:11		E	0
2A8060	LSB-BSE2: Control data transfer LSBC driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362.X4:11		E	2
2A8061	LSB-BSE2: Control data transfer LSBC driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362.X4:11		E	2
2A8062	LSB-BSE2: Control data transfer LSBC Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362.X4:11		E	2
2A9050	LSB-BSE2: LSB-D Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9051	LSB-BSE2: LSB-D Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9053	LSB-BSE2: LSB-D Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9054	LSB-BSE2: LSB-D Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9064	LSB-BSE2: LSB-D Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9065	LSB-BSE2: LSB-D Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9066	LSB-BSE2: LSB-D Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9067	LSB-BSE2: LSB-D Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9068	LSB-BSE2: LSB-D Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9069	LSB-BSE2: LSB-D Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A906A	LSB-BSE2: LSB-D Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A906B	LSB-BSE2: LSB-D Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A906C	LSB-BSE2: LSB-D Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9150	LSB-BSE2: LSB-D Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9151	LSB-BSE2: LSB-D Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9153	LSB-BSE2: LSB-D Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9154	LSB-BSE2: LSB-D Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9164	LSB-BSE2: LSB-D Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9165	LSB-BSE2: LSB-D Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9166	LSB-BSE2: LSB-D Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9167	LSB-BSE2: LSB-D Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9168	LSB-BSE2: LSB-D Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9169	LSB-BSE2: LSB-D Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A916A	LSB-BSE2: LSB-D Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A916B	LSB-BSE2: LSB-D Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A916C	LSB-BSE2: LSB-D Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9250	LSB-BSE2: LSB-D Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9251	LSB-BSE2: LSB-D Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9253	LSB-BSE2: LSB-D Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9254	LSB-BSE2: LSB-D Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9264	LSB-BSE2: LSB-D Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9265	LSB-BSE2: LSB-D Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9266	LSB-BSE2: LSB-D Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9267	LSB-BSE2: LSB-D Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9268	LSB-BSE2: LSB-D Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9269	LSB-BSE2: LSB-D Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A926A	LSB-BSE2: LSB-D Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A926B	LSB-BSE2: LSB-D Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A926C	LSB-BSE2: LSB-D Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9450	LSB-BSE2: LSB-D Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9451	LSB-BSE2: LSB-D Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9453	LSB-BSE2: LSB-D Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9454	LSB-BSE2: LSB-D Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9464	LSB-BSE2: LSB-D Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9465	LSB-BSE2: LSB-D Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9466	LSB-BSE2: LSB-D Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9467	LSB-BSE2: LSB-D Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9468	LSB-BSE2: LSB-D Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9469	LSB-BSE2: LSB-D Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A946A	LSB-BSE2: LSB-D Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A946B	LSB-BSE2: LSB-D Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A946C	LSB-BSE2: LSB-D Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9550	LSB-BSE2: LSB-D Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9551	LSB-BSE2: LSB-D Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9553	LSB-BSE2: LSB-D Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9554	LSB-BSE2: LSB-D Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9564	LSB-BSE2: LSB-D Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9565	LSB-BSE2: LSB-D Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9566	LSB-BSE2: LSB-D Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9567	LSB-BSE2: LSB-D Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9568	LSB-BSE2: LSB-D Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9569	LSB-BSE2: LSB-D Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A956A	LSB-BSE2: LSB-D Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A956B	LSB-BSE2: LSB-D Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A956C	LSB-BSE2: LSB-D Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9650	LSB-BSE2: LSB-D Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9651	LSB-BSE2: LSB-D Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9653	LSB-BSE2: LSB-D Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9654	LSB-BSE2: LSB-D Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9664	LSB-BSE2: LSB-D Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9665	LSB-BSE2: LSB-D Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9666	LSB-BSE2: LSB-D Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9667	LSB-BSE2: LSB-D Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9668	LSB-BSE2: LSB-D Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9669	LSB-BSE2: LSB-D Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A966A	LSB-BSE2: LSB-D Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A966B	LSB-BSE2: LSB-D Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A966C	LSB-BSE2: LSB-D Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9750	LSB-BSE2: LSB-D Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9751	LSB-BSE2: LSB-D Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9753	LSB-BSE2: LSB-D Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9754	LSB-BSE2: LSB-D Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9764	LSB-BSE2: LSB-D Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9765	LSB-BSE2: LSB-D Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9766	LSB-BSE2: LSB-D Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9767	LSB-BSE2: LSB-D Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9768	LSB-BSE2: LSB-D Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9769	LSB-BSE2: LSB-D Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A976A	LSB-BSE2: LSB-D Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A976B	LSB-BSE2: LSB-D Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A976C	LSB-BSE2: LSB-D Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9850	LSB-BSE2: LSB-D Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9851	LSB-BSE2: LSB-D Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9853	LSB-BSE2: LSB-D Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9854	LSB-BSE2: LSB-D Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9864	LSB-BSE2: LSB-D Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9865	LSB-BSE2: LSB-D Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9866	LSB-BSE2: LSB-D Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9867	LSB-BSE2: LSB-D Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9868	LSB-BSE2: LSB-D Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9869	LSB-BSE2: LSB-D Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A986A	LSB-BSE2: LSB-D Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A986B	LSB-BSE2: LSB-D Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A986C	LSB-BSE2: LSB-D Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9950	LSB-BSE2: LSB-D Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9951	LSB-BSE2: LSB-D Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9953	LSB-BSE2: LSB-D Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9954	LSB-BSE2: LSB-D Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9964	LSB-BSE2: LSB-D Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9965	LSB-BSE2: LSB-D Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9966	LSB-BSE2: LSB-D Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9967	LSB-BSE2: LSB-D Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9968	LSB-BSE2: LSB-D Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9969	LSB-BSE2: LSB-D Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A996A	LSB-BSE2: LSB-D Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A996B	LSB-BSE2: LSB-D Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A996C	LSB-BSE2: LSB-D Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9A50	LSB-BSE2: LSB-D Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9A51	LSB-BSE2: LSB-D Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9A53	LSB-BSE2: LSB-D Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9A54	LSB-BSE2: LSB-D Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9A64	LSB-BSE2: LSB-D Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9A65	LSB-BSE2: LSB-D Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9A66	LSB-BSE2: LSB-D Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9A67	LSB-BSE2: LSB-D Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9A68	LSB-BSE2: LSB-D Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9A69	LSB-BSE2: LSB-D Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A9A6A	LSB-BSE2: LSB-D Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A9A6B	LSB-BSE2: LSB-D Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A9A6C	LSB-BSE2: LSB-D Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9B50	LSB-BSE2: LSB-D Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9B51	LSB-BSE2: LSB-D Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9B53	LSB-BSE2: LSB-D Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9B54	LSB-BSE2: LSB-D Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9B64	LSB-BSE2: LSB-D Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9B65	LSB-BSE2: LSB-D Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9B66	LSB-BSE2: LSB-D Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9B67	LSB-BSE2: LSB-D Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9B68	LSB-BSE2: LSB-D Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9B69	LSB-BSE2: LSB-D Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A9B6A	LSB-BSE2: LSB-D Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9B6B	LSB-BSE2: LSB-D Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A9B6C	LSB-BSE2: LSB-D Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9C50	LSB-BSE2: LSB-D Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9C51	LSB-BSE2: LSB-D Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9C53	LSB-BSE2: LSB-D Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9C54	LSB-BSE2: LSB-D Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9C64	LSB-BSE2: LSB-D Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9C65	LSB-BSE2: LSB-D Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9C66	LSB-BSE2: LSB-D Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9C67	LSB-BSE2: LSB-D Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9C68	LSB-BSE2: LSB-D Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9C69	LSB-BSE2: LSB-D Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A9C6A	LSB-BSE2: LSB-D Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A9C6B	LSB-BSE2: LSB-D Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A9C6C	LSB-BSE2: LSB-D Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9D50	LSB-BSE2: LSB-D Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9D51	LSB-BSE2: LSB-D Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9D53	LSB-BSE2: LSB-D Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9D54	LSB-BSE2: LSB-D Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9D64	LSB-BSE2: LSB-D Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9D65	LSB-BSE2: LSB-D Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9D66	LSB-BSE2: LSB-D Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9D67	LSB-BSE2: LSB-D Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9D68	LSB-BSE2: LSB-D Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9D69	LSB-BSE2: LSB-D Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A9D6A	LSB-BSE2: LSB-D Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A9D6B	LSB-BSE2: LSB-D Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A9D6C	LSB-BSE2: LSB-D Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9E50	LSB-BSE2: LSB-D Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9E51	LSB-BSE2: LSB-D Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9E53	LSB-BSE2: LSB-D Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9E54	LSB-BSE2: LSB-D Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9E64	LSB-BSE2: LSB-D Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9E65	LSB-BSE2: LSB-D Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9E66	LSB-BSE2: LSB-D Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9E67	LSB-BSE2: LSB-D Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9E68	LSB-BSE2: LSB-D Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2A9E69	LSB-BSE2: LSB-D Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A9E6A	LSB-BSE2: LSB-D Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A9E6B	LSB-BSE2: LSB-D Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9E6C	LSB-BSE2: LSB-D Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2A9F50	LSB-BSE2: LSB-D Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2A9F51	LSB-BSE2: LSB-D Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2A9F53	LSB-BSE2: LSB-D Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2A9F54	LSB-BSE2: LSB-D Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2A9F64	LSB-BSE2: LSB-D Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2A9F65	LSB-BSE2: LSB-D Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2A9F66	LSB-BSE2: LSB-D Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2A9F67	LSB-BSE2: LSB-D Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2A9F68	LSB-BSE2: LSB-D Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2A9F69	LSB-BSE2: LSB-D Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2A9F6A	LSB-BSE2: LSB-D Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2A9F6B	LSB-BSE2: LSB-D Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2A9F6C	LSB-BSE2: LSB-D Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA050	LSB-BSE2: LSB-D Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA051	LSB-BSE2: LSB-D Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA053	LSB-BSE2: LSB-D Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA054	LSB-BSE2: LSB-D Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA064	LSB-BSE2: LSB-D Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA065	LSB-BSE2: LSB-D Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA066	LSB-BSE2: LSB-D Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA067	LSB-BSE2: LSB-D Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA068	LSB-BSE2: LSB-D Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA069	LSB-BSE2: LSB-D Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA06A	LSB-BSE2: LSB-D Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA06B	LSB-BSE2: LSB-D Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA06C	LSB-BSE2: LSB-D Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA150	LSB-BSE2: LSB-D Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA151	LSB-BSE2: LSB-D Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA153	LSB-BSE2: LSB-D Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA154	LSB-BSE2: LSB-D Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA164	LSB-BSE2: LSB-D Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA165	LSB-BSE2: LSB-D Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA166	LSB-BSE2: LSB-D Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA167	LSB-BSE2: LSB-D Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA168	LSB-BSE2: LSB-D Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA169	LSB-BSE2: LSB-D Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA16A	LSB-BSE2: LSB-D Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA16B	LSB-BSE2: LSB-D Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA16C	LSB-BSE2: LSB-D Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA250	LSB-BSE2: LSB-D Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA251	LSB-BSE2: LSB-D Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA253	LSB-BSE2: LSB-D Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA254	LSB-BSE2: LSB-D Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA264	LSB-BSE2: LSB-D Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA265	LSB-BSE2: LSB-D Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA266	LSB-BSE2: LSB-D Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA267	LSB-BSE2: LSB-D Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA268	LSB-BSE2: LSB-D Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA269	LSB-BSE2: LSB-D Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA26A	LSB-BSE2: LSB-D Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA26B	LSB-BSE2: LSB-D Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA26C	LSB-BSE2: LSB-D Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA350	LSB-BSE2: LSB-D Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA351	LSB-BSE2: LSB-D Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA353	LSB-BSE2: LSB-D Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA354	LSB-BSE2: LSB-D Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA364	LSB-BSE2: LSB-D Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA365	LSB-BSE2: LSB-D Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA366	LSB-BSE2: LSB-D Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA367	LSB-BSE2: LSB-D Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA368	LSB-BSE2: LSB-D Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA369	LSB-BSE2: LSB-D Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA36A	LSB-BSE2: LSB-D Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA36B	LSB-BSE2: LSB-D Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA36C	LSB-BSE2: LSB-D Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA450	LSB-BSE2: LSB-D Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA451	LSB-BSE2: LSB-D Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA453	LSB-BSE2: LSB-D Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA454	LSB-BSE2: LSB-D Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA464	LSB-BSE2: LSB-D Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA465	LSB-BSE2: LSB-D Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA466	LSB-BSE2: LSB-D Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA467	LSB-BSE2: LSB-D Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA468	LSB-BSE2: LSB-D Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA469	LSB-BSE2: LSB-D Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA46A	LSB-BSE2: LSB-D Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA46B	LSB-BSE2: LSB-D Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA46C	LSB-BSE2: LSB-D Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA550	LSB-BSE2: LSB-D Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA551	LSB-BSE2: LSB-D Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA553	LSB-BSE2: LSB-D Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA554	LSB-BSE2: LSB-D Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA564	LSB-BSE2: LSB-D Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA565	LSB-BSE2: LSB-D Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA566	LSB-BSE2: LSB-D Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA567	LSB-BSE2: LSB-D Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA568	LSB-BSE2: LSB-D Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA569	LSB-BSE2: LSB-D Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA56A	LSB-BSE2: LSB-D Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA56B	LSB-BSE2: LSB-D Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA56C	LSB-BSE2: LSB-D Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA650	LSB-BSE2: LSB-D Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA651	LSB-BSE2: LSB-D Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA653	LSB-BSE2: LSB-D Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA654	LSB-BSE2: LSB-D Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA664	LSB-BSE2: LSB-D Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA665	LSB-BSE2: LSB-D Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA666	LSB-BSE2: LSB-D Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA667	LSB-BSE2: LSB-D Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA668	LSB-BSE2: LSB-D Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA669	LSB-BSE2: LSB-D Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA66A	LSB-BSE2: LSB-D Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA66B	LSB-BSE2: LSB-D Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA66C	LSB-BSE2: LSB-D Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA750	LSB-BSE2: LSB-D Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA751	LSB-BSE2: LSB-D Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA753	LSB-BSE2: LSB-D Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA754	LSB-BSE2: LSB-D Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA764	LSB-BSE2: LSB-D Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA765	LSB-BSE2: LSB-D Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA766	LSB-BSE2: LSB-D Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA767	LSB-BSE2: LSB-D Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA768	LSB-BSE2: LSB-D Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA769	LSB-BSE2: LSB-D Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA76A	LSB-BSE2: LSB-D Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA76B	LSB-BSE2: LSB-D Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA76C	LSB-BSE2: LSB-D Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA850	LSB-BSE2: LSB-D Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA851	LSB-BSE2: LSB-D Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA853	LSB-BSE2: LSB-D Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA854	LSB-BSE2: LSB-D Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA864	LSB-BSE2: LSB-D Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA865	LSB-BSE2: LSB-D Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA866	LSB-BSE2: LSB-D Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA867	LSB-BSE2: LSB-D Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA868	LSB-BSE2: LSB-D Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AA869	LSB-BSE2: LSB-D Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA86A	LSB-BSE2: LSB-D Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA86B	LSB-BSE2: LSB-D Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA86C	LSB-BSE2: LSB-D Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AA950	LSB-BSE2: LSB-D Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AA951	LSB-BSE2: LSB-D Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AA953	LSB-BSE2: LSB-D Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AA954	LSB-BSE2: LSB-D Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AA964	LSB-BSE2: LSB-D Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AA965	LSB-BSE2: LSB-D Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AA966	LSB-BSE2: LSB-D Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AA967	LSB-BSE2: LSB-D Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AA968	LSB-BSE2: LSB-D Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AA969	LSB-BSE2: LSB-D Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AA96A	LSB-BSE2: LSB-D Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AA96B	LSB-BSE2: LSB-D Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AA96C	LSB-BSE2: LSB-D Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AAA50	LSB-BSE2: LSB-D Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AAA51	LSB-BSE2: LSB-D Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AAA53	LSB-BSE2: LSB-D Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AAA54	LSB-BSE2: LSB-D Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AAA64	LSB-BSE2: LSB-D Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AAA65	LSB-BSE2: LSB-D Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AAA66	LSB-BSE2: LSB-D Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AAA67	LSB-BSE2: LSB-D Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AAA68	LSB-BSE2: LSB-D Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AAA69	LSB-BSE2: LSB-D Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AAA6A	LSB-BSE2: LSB-D Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AAA6B	LSB-BSE2: LSB-D Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AAA6C	LSB-BSE2: LSB-D Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AAB50	LSB-BSE2: LSB-D Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AAB51	LSB-BSE2: LSB-D Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AAB53	LSB-BSE2: LSB-D Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AAB54	LSB-BSE2: LSB-D Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AAB64	LSB-BSE2: LSB-D Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AAB65	LSB-BSE2: LSB-D Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AAB66	LSB-BSE2: LSB-D Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AAB67	LSB-BSE2: LSB-D Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AAB68	LSB-BSE2: LSB-D Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AAB69	LSB-BSE2: LSB-D Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AAB6A	LSB-BSE2: LSB-D Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AAB6B	LSB-BSE2: LSB-D Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AAB6C	LSB-BSE2: LSB-D Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AAC50	LSB-BSE2: LSB-D Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AAC51	LSB-BSE2: LSB-D Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AAC53	LSB-BSE2: LSB-D Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AAC54	LSB-BSE2: LSB-D Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AAC64	LSB-BSE2: LSB-D Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AAC65	LSB-BSE2: LSB-D Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AAC66	LSB-BSE2: LSB-D Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AAC67	LSB-BSE2: LSB-D Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AAC68	LSB-BSE2: LSB-D Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AAC69	LSB-BSE2: LSB-D Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AAC6A	LSB-BSE2: LSB-D Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AAC6B	LSB-BSE2: LSB-D Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AAC6C	LSB-BSE2: LSB-D Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AAD50	LSB-BSE2: LSB-D Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AAD51	LSB-BSE2: LSB-D Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AAD53	LSB-BSE2: LSB-D Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AAD54	LSB-BSE2: LSB-D Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2
2AAD64	LSB-BSE2: LSB-D Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AAD65	LSB-BSE2: LSB-D Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AAD66	LSB-BSE2: LSB-D Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AAD67	LSB-BSE2: LSB-D Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AAD68	LSB-BSE2: LSB-D Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AAD69	LSB-BSE2: LSB-D Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AAD6A	LSB-BSE2: LSB-D Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AAD6B	LSB-BSE2: LSB-D Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AAD6C	LSB-BSE2: LSB-D Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AAE50	LSB-BSE2: LSB-D Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X4:12		E	2
2AAE51	LSB-BSE2: LSB-D Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X4:12		E	2
2AAE53	LSB-BSE2: LSB-D Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X4:12		E	1
2AAE54	LSB-BSE2: LSB-D Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AAE64	LSB-BSE2: LSB-D Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X4:12		E	1
2AAE65	LSB-BSE2: LSB-D Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X4:12		E	2
2AAE66	LSB-BSE2: LSB-D Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X4:12		E	2
2AAE67	LSB-BSE2: LSB-D Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X4:12		E	1
2AAE68	LSB-BSE2: LSB-D Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X4:12		E	1
2AAE69	LSB-BSE2: LSB-D Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X4:12		E	1
2AAE6A	LSB-BSE2: LSB-D Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X4:12		E	2
2AAE6B	LSB-BSE2: LSB-D Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X4:12		E	2
2AAE6C	LSB-BSE2: LSB-D Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X4:12		E	2
2AB052	LSB-BSE2: Control data transfer LSB-D has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362.X4:12		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2AB055	LSB-BSE2: Control data transfer LSB-D Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X4:12		E	2
2AB056	LSB-BSE2: Control data transfer LSB-D Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X4:12		E	2
2AB057	LSB-BSE2: Control data transfer LSB-D has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362.X4:12		E	1
2AB058	LSB-BSE2: Control data transfer LSB-D recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362.X4:12		E	0
2AB059	LSB-BSE2: Control data transfer LSB-D recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362.X4:12		E	0
2AB060	LSB-BSE2: Control data transfer LSB-D driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362.X4:12		E	2
2AB061	LSB-BSE2: Control data transfer LSB-D driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362.X4:12		E	2
2AB062	LSB-BSE2: Control data transfer LSB-D Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362.X4:12		E	2
2B0050	LSB-BSE2: LSBE Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0051	LSB-BSE2: LSBE Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0053	LSB-BSE2: LSBE Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0054	LSB-BSE2: LSBE Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0064	LSB-BSE2: LSBE Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0065	LSB-BSE2: LSBE Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0066	LSB-BSE2: LSBE Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0067	LSB-BSE2: LSBE Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0068	LSB-BSE2: LSBE Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0069	LSB-BSE2: LSBE Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B006A	LSB-BSE2: LSBE Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B006B	LSB-BSE2: LSBE Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B006C	LSB-BSE2: LSBE Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0150	LSB-BSE2: LSBE Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0151	LSB-BSE2: LSBE Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0153	LSB-BSE2: LSBE Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0154	LSB-BSE2: LSBE Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0164	LSB-BSE2: LSBE Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0165	LSB-BSE2: LSBE Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0166	LSB-BSE2: LSBE Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0167	LSB-BSE2: LSBE Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0168	LSB-BSE2: LSBE Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0169	LSB-BSE2: LSBE Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B016A	LSB-BSE2: LSBE Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B016B	LSB-BSE2: LSBE Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B016C	LSB-BSE2: LSBE Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0250	LSB-BSE2: LSBE Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0251	LSB-BSE2: LSBE Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0253	LSB-BSE2: LSBE Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0254	LSB-BSE2: LSBE Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0264	LSB-BSE2: LSBE Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0265	LSB-BSE2: LSBE Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0266	LSB-BSE2: LSBE Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0267	LSB-BSE2: LSBE Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0268	LSB-BSE2: LSBE Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0269	LSB-BSE2: LSBE Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B026A	LSB-BSE2: LSBE Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B026B	LSB-BSE2: LSBE Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B026C	LSB-BSE2: LSBE Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0350	LSB-BSE2: LSBE Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0351	LSB-BSE2: LSBE Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0353	LSB-BSE2: LSBE Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0354	LSB-BSE2: LSBE Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0364	LSB-BSE2: LSBE Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0365	LSB-BSE2: LSBE Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0366	LSB-BSE2: LSBE Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0367	LSB-BSE2: LSBE Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0368	LSB-BSE2: LSBE Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0369	LSB-BSE2: LSBE Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B036A	LSB-BSE2: LSBE Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B036B	LSB-BSE2: LSBE Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B036C	LSB-BSE2: LSBE Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0450	LSB-BSE2: LSBE Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0451	LSB-BSE2: LSBE Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0453	LSB-BSE2: LSBE Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0454	LSB-BSE2: LSBE Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0464	LSB-BSE2: LSBE Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0465	LSB-BSE2: LSBE Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0466	LSB-BSE2: LSBE Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0467	LSB-BSE2: LSBE Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0468	LSB-BSE2: LSBE Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0469	LSB-BSE2: LSBE Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B046A	LSB-BSE2: LSBE Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B046B	LSB-BSE2: LSBE Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B046C	LSB-BSE2: LSBE Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0550	LSB-BSE2: LSBE Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0551	LSB-BSE2: LSBE Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0553	LSB-BSE2: LSBE Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0554	LSB-BSE2: LSBE Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0564	LSB-BSE2: LSBE Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0565	LSB-BSE2: LSBE Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0566	LSB-BSE2: LSBE Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0567	LSB-BSE2: LSBE Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0568	LSB-BSE2: LSBE Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0569	LSB-BSE2: LSBE Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B056A	LSB-BSE2: LSBE Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B056B	LSB-BSE2: LSBE Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B056C	LSB-BSE2: LSBE Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0650	LSB-BSE2: LSBE Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0651	LSB-BSE2: LSBE Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0653	LSB-BSE2: LSBE Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0654	LSB-BSE2: LSBE Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0664	LSB-BSE2: LSBE Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0665	LSB-BSE2: LSBE Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0666	LSB-BSE2: LSBE Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0667	LSB-BSE2: LSBE Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0668	LSB-BSE2: LSBE Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0669	LSB-BSE2: LSBE Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B066A	LSB-BSE2: LSBE Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B066B	LSB-BSE2: LSBE Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B066C	LSB-BSE2: LSBE Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0750	LSB-BSE2: LSBE Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0751	LSB-BSE2: LSBE Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0753	LSB-BSE2: LSBE Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0754	LSB-BSE2: LSBE Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0764	LSB-BSE2: LSBE Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0765	LSB-BSE2: LSBE Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0766	LSB-BSE2: LSBE Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0767	LSB-BSE2: LSBE Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0768	LSB-BSE2: LSBE Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0769	LSB-BSE2: LSBE Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B076A	LSB-BSE2: LSBE Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B076B	LSB-BSE2: LSBE Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B076C	LSB-BSE2: LSBE Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0B50	LSB-BSE2: LSBE Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0B51	LSB-BSE2: LSBE Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0B53	LSB-BSE2: LSBE Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0B54	LSB-BSE2: LSBE Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0B64	LSB-BSE2: LSBE Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0B65	LSB-BSE2: LSBE Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0B66	LSB-BSE2: LSBE Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0B67	LSB-BSE2: LSBE Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0B68	LSB-BSE2: LSBE Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0B69	LSB-BSE2: LSBE Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B0B6A	LSB-BSE2: LSBE Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B0B6B	LSB-BSE2: LSBE Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B0B6C	LSB-BSE2: LSBE Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0C50	LSB-BSE2: LSBE Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0C51	LSB-BSE2: LSBE Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0C53	LSB-BSE2: LSBE Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0C54	LSB-BSE2: LSBE Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0C64	LSB-BSE2: LSBE Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0C65	LSB-BSE2: LSBE Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0C66	LSB-BSE2: LSBE Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0C67	LSB-BSE2: LSBE Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0C68	LSB-BSE2: LSBE Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0C69	LSB-BSE2: LSBE Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B0C6A	LSB-BSE2: LSBE Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B0C6B	LSB-BSE2: LSBE Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B0C6C	LSB-BSE2: LSBE Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0D50	LSB-BSE2: LSBE Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0D51	LSB-BSE2: LSBE Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0D53	LSB-BSE2: LSBE Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0D54	LSB-BSE2: LSBE Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0D64	LSB-BSE2: LSBE Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0D65	LSB-BSE2: LSBE Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0D66	LSB-BSE2: LSBE Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0D67	LSB-BSE2: LSBE Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0D68	LSB-BSE2: LSBE Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0D69	LSB-BSE2: LSBE Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B0D6A	LSB-BSE2: LSBE Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B0D6B	LSB-BSE2: LSBE Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0D6C	LSB-BSE2: LSBE Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0E50	LSB-BSE2: LSBE Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0E51	LSB-BSE2: LSBE Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0E53	LSB-BSE2: LSBE Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0E54	LSB-BSE2: LSBE Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0E64	LSB-BSE2: LSBE Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0E65	LSB-BSE2: LSBE Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B0E66	LSB-BSE2: LSBE Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0E67	LSB-BSE2: LSBE Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0E68	LSB-BSE2: LSBE Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0E69	LSB-BSE2: LSBE Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B0E6A	LSB-BSE2: LSBE Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B0E6B	LSB-BSE2: LSBE Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B0E6C	LSB-BSE2: LSBE Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B0F50	LSB-BSE2: LSBE Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B0F51	LSB-BSE2: LSBE Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B0F53	LSB-BSE2: LSBE Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B0F54	LSB-BSE2: LSBE Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B0F64	LSB-BSE2: LSBE Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B0F65	LSB-BSE2: LSBE Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B0F66	LSB-BSE2: LSBE Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B0F67	LSB-BSE2: LSBE Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B0F68	LSB-BSE2: LSBE Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B0F69	LSB-BSE2: LSBE Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B0F6A	LSB-BSE2: LSBE Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B0F6B	LSB-BSE2: LSBE Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B0F6C	LSB-BSE2: LSBE Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1050	LSB-BSE2: LSBE Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1051	LSB-BSE2: LSBE Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1053	LSB-BSE2: LSBE Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1054	LSB-BSE2: LSBE Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1064	LSB-BSE2: LSBE Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1065	LSB-BSE2: LSBE Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1066	LSB-BSE2: LSBE Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1067	LSB-BSE2: LSBE Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1068	LSB-BSE2: LSBE Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1069	LSB-BSE2: LSBE Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B106A	LSB-BSE2: LSBE Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B106B	LSB-BSE2: LSBE Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B106C	LSB-BSE2: LSBE Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1150	LSB-BSE2: LSBE Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1151	LSB-BSE2: LSBE Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1153	LSB-BSE2: LSBE Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1154	LSB-BSE2: LSBE Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1164	LSB-BSE2: LSBE Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1165	LSB-BSE2: LSBE Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1166	LSB-BSE2: LSBE Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1167	LSB-BSE2: LSBE Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1168	LSB-BSE2: LSBE Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1169	LSB-BSE2: LSBE Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B116A	LSB-BSE2: LSBE Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B116B	LSB-BSE2: LSBE Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B116C	LSB-BSE2: LSBE Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1250	LSB-BSE2: LSBE Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1251	LSB-BSE2: LSBE Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1253	LSB-BSE2: LSBE Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1254	LSB-BSE2: LSBE Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1264	LSB-BSE2: LSBE Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1265	LSB-BSE2: LSBE Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1266	LSB-BSE2: LSBE Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1267	LSB-BSE2: LSBE Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1268	LSB-BSE2: LSBE Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1269	LSB-BSE2: LSBE Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B126A	LSB-BSE2: LSBE Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B126B	LSB-BSE2: LSBE Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B126C	LSB-BSE2: LSBE Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1350	LSB-BSE2: LSBE Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1351	LSB-BSE2: LSBE Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1353	LSB-BSE2: LSBE Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1354	LSB-BSE2: LSBE Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1364	LSB-BSE2: LSBE Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1365	LSB-BSE2: LSBE Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1366	LSB-BSE2: LSBE Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1367	LSB-BSE2: LSBE Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1368	LSB-BSE2: LSBE Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1369	LSB-BSE2: LSBE Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B136A	LSB-BSE2: LSBE Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B136B	LSB-BSE2: LSBE Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B136C	LSB-BSE2: LSBE Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1450	LSB-BSE2: LSBE Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1451	LSB-BSE2: LSBE Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1453	LSB-BSE2: LSBE Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1454	LSB-BSE2: LSBE Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1464	LSB-BSE2: LSBE Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1465	LSB-BSE2: LSBE Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1466	LSB-BSE2: LSBE Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1467	LSB-BSE2: LSBE Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1468	LSB-BSE2: LSBE Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1469	LSB-BSE2: LSBE Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B146A	LSB-BSE2: LSBE Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B146B	LSB-BSE2: LSBE Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B146C	LSB-BSE2: LSBE Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1650	LSB-BSE2: LSBE Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1651	LSB-BSE2: LSBE Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1653	LSB-BSE2: LSBE Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1654	LSB-BSE2: LSBE Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1664	LSB-BSE2: LSBE Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1665	LSB-BSE2: LSBE Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1666	LSB-BSE2: LSBE Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1667	LSB-BSE2: LSBE Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1668	LSB-BSE2: LSBE Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1669	LSB-BSE2: LSBE Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B166A	LSB-BSE2: LSBE Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B166B	LSB-BSE2: LSBE Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B166C	LSB-BSE2: LSBE Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1750	LSB-BSE2: LSBE Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1751	LSB-BSE2: LSBE Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1753	LSB-BSE2: LSBE Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1754	LSB-BSE2: LSBE Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1764	LSB-BSE2: LSBE Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1765	LSB-BSE2: LSBE Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1766	LSB-BSE2: LSBE Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1767	LSB-BSE2: LSBE Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1768	LSB-BSE2: LSBE Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1769	LSB-BSE2: LSBE Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B176A	LSB-BSE2: LSBE Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B176B	LSB-BSE2: LSBE Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B176C	LSB-BSE2: LSBE Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1A50	LSB-BSE2: LSBE Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1A51	LSB-BSE2: LSBE Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1A53	LSB-BSE2: LSBE Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1A54	LSB-BSE2: LSBE Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1A64	LSB-BSE2: LSBE Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1A65	LSB-BSE2: LSBE Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1A66	LSB-BSE2: LSBE Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1A67	LSB-BSE2: LSBE Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1A68	LSB-BSE2: LSBE Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1A69	LSB-BSE2: LSBE Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B1A6A	LSB-BSE2: LSBE Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B1A6B	LSB-BSE2: LSBE Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1A6C	LSB-BSE2: LSBE Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1B50	LSB-BSE2: LSBE Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1B51	LSB-BSE2: LSBE Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1B53	LSB-BSE2: LSBE Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1B54	LSB-BSE2: LSBE Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1B64	LSB-BSE2: LSBE Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1B65	LSB-BSE2: LSBE Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1B66	LSB-BSE2: LSBE Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1B67	LSB-BSE2: LSBE Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1B68	LSB-BSE2: LSBE Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1B69	LSB-BSE2: LSBE Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B1B6A	LSB-BSE2: LSBE Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B1B6B	LSB-BSE2: LSBE Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B1B6C	LSB-BSE2: LSBE Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1C50	LSB-BSE2: LSBE Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1C51	LSB-BSE2: LSBE Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1C53	LSB-BSE2: LSBE Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1
2B1C54	LSB-BSE2: LSBE Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1C64	LSB-BSE2: LSBE Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1C65	LSB-BSE2: LSBE Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1C66	LSB-BSE2: LSBE Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1C67	LSB-BSE2: LSBE Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1C68	LSB-BSE2: LSBE Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1C69	LSB-BSE2: LSBE Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B1C6A	LSB-BSE2: LSBE Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B1C6B	LSB-BSE2: LSBE Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B1C6C	LSB-BSE2: LSBE Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2
2B1D50	LSB-BSE2: LSBE Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:9		E	2
2B1D51	LSB-BSE2: LSBE Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:9		E	2
2B1D53	LSB-BSE2: LSBE Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B1D54	LSB-BSE2: LSBE Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:9		E	2
2B1D64	LSB-BSE2: LSBE Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:9		E	1
2B1D65	LSB-BSE2: LSBE Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:9		E	2
2B1D66	LSB-BSE2: LSBE Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:9		E	2
2B1D67	LSB-BSE2: LSBE Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:9		E	1
2B1D68	LSB-BSE2: LSBE Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:9		E	1
2B1D69	LSB-BSE2: LSBE Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:9		E	1
2B1D6A	LSB-BSE2: LSBE Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:9		E	2
2B1D6B	LSB-BSE2: LSBE Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:9		E	2
2B1D6C	LSB-BSE2: LSBE Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B2052	LSB-BSE2: Control data transfer LSBE has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362.X5:9		E	0
2B2055	LSB-BSE2: Control data transfer LSBE Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X5:9		E	2
2B2056	LSB-BSE2: Control data transfer LSBE Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X5:9		E	2
2B2057	LSB-BSE2: Control data transfer LSBE has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362.X5:9		E	1
2B2058	LSB-BSE2: Control data transfer LSBE recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362.X5:9		E	0
2B2059	LSB-BSE2: Control data transfer LSBE recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362.X5:9		E	0
2B2060	LSB-BSE2: Control data transfer LSBE driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362.X5:9		E	2
2B2061	LSB-BSE2: Control data transfer LSBE driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362.X5:9		E	2
2B2062	LSB-BSE2: Control data transfer LSBE Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362.X5:9		E	2
2B3050	LSB-BSE2: LSBF Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3051	LSB-BSE2: LSBF Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3053	LSB-BSE2: LSBF Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3054	LSB-BSE2: LSBF Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3064	LSB-BSE2: LSBF Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3065	LSB-BSE2: LSBF Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3066	LSB-BSE2: LSBF Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3067	LSB-BSE2: LSBF Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3068	LSB-BSE2: LSBF Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3069	LSB-BSE2: LSBF Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B306A	LSB-BSE2: LSBF Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B306B	LSB-BSE2: LSBF Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B306C	LSB-BSE2: LSBF Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3150	LSB-BSE2: LSBF Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3151	LSB-BSE2: LSBF Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3153	LSB-BSE2: LSBF Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3154	LSB-BSE2: LSBF Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3164	LSB-BSE2: LSBF Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3165	LSB-BSE2: LSBF Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3166	LSB-BSE2: LSBF Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3167	LSB-BSE2: LSBF Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3168	LSB-BSE2: LSBF Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3169	LSB-BSE2: LSBF Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B316A	LSB-BSE2: LSBF Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B316B	LSB-BSE2: LSBF Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B316C	LSB-BSE2: LSBF Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3250	LSB-BSE2: LSBF Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3251	LSB-BSE2: LSBF Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3253	LSB-BSE2: LSBF Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3254	LSB-BSE2: LSBF Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3264	LSB-BSE2: LSBF Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3265	LSB-BSE2: LSBF Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3266	LSB-BSE2: LSBF Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3267	LSB-BSE2: LSBF Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3268	LSB-BSE2: LSBF Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3269	LSB-BSE2: LSBF Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B326A	LSB-BSE2: LSBF Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B326B	LSB-BSE2: LSBF Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B326C	LSB-BSE2: LSBF Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3350	LSB-BSE2: LSBF Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3351	LSB-BSE2: LSBF Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3353	LSB-BSE2: LSBF Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3354	LSB-BSE2: LSBF Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3364	LSB-BSE2: LSBF Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3365	LSB-BSE2: LSBF Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3366	LSB-BSE2: LSBF Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3367	LSB-BSE2: LSBF Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3368	LSB-BSE2: LSBF Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3369	LSB-BSE2: LSBF Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B336A	LSB-BSE2: LSBF Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B336B	LSB-BSE2: LSBF Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B336C	LSB-BSE2: LSBF Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3450	LSB-BSE2: LSBF Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3451	LSB-BSE2: LSBF Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3453	LSB-BSE2: LSBF Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3454	LSB-BSE2: LSBF Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3464	LSB-BSE2: LSBF Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3465	LSB-BSE2: LSBF Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3466	LSB-BSE2: LSBF Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3467	LSB-BSE2: LSBF Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3468	LSB-BSE2: LSBF Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3469	LSB-BSE2: LSBF Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B346A	LSB-BSE2: LSBF Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B346B	LSB-BSE2: LSBF Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B346C	LSB-BSE2: LSBF Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3550	LSB-BSE2: LSBF Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3551	LSB-BSE2: LSBF Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3553	LSB-BSE2: LSBF Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3554	LSB-BSE2: LSBF Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3564	LSB-BSE2: LSBF Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3565	LSB-BSE2: LSBF Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3566	LSB-BSE2: LSBF Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3567	LSB-BSE2: LSBF Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3568	LSB-BSE2: LSBF Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3569	LSB-BSE2: LSBF Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B356A	LSB-BSE2: LSBF Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B356B	LSB-BSE2: LSBF Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B356C	LSB-BSE2: LSBF Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3650	LSB-BSE2: LSBF Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3651	LSB-BSE2: LSBF Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3653	LSB-BSE2: LSBF Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3654	LSB-BSE2: LSBF Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3664	LSB-BSE2: LSBF Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3665	LSB-BSE2: LSBF Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3666	LSB-BSE2: LSBF Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3667	LSB-BSE2: LSBF Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3668	LSB-BSE2: LSBF Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3669	LSB-BSE2: LSBF Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B366A	LSB-BSE2: LSBF Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B366B	LSB-BSE2: LSBF Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B366C	LSB-BSE2: LSBF Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3750	LSB-BSE2: LSBF Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3751	LSB-BSE2: LSBF Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3753	LSB-BSE2: LSBF Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3754	LSB-BSE2: LSBF Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3764	LSB-BSE2: LSBF Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3765	LSB-BSE2: LSBF Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3766	LSB-BSE2: LSBF Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3767	LSB-BSE2: LSBF Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3768	LSB-BSE2: LSBF Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3769	LSB-BSE2: LSBF Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B376A	LSB-BSE2: LSBF Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B376B	LSB-BSE2: LSBF Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B376C	LSB-BSE2: LSBF Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3850	LSB-BSE2: LSBF Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3851	LSB-BSE2: LSBF Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3853	LSB-BSE2: LSBF Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3854	LSB-BSE2: LSBF Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3864	LSB-BSE2: LSBF Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3865	LSB-BSE2: LSBF Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3866	LSB-BSE2: LSBF Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3867	LSB-BSE2: LSBF Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3868	LSB-BSE2: LSBF Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3869	LSB-BSE2: LSBF Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B386A	LSB-BSE2: LSBF Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B386B	LSB-BSE2: LSBF Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B386C	LSB-BSE2: LSBF Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3950	LSB-BSE2: LSBF Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3951	LSB-BSE2: LSBF Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3953	LSB-BSE2: LSBF Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3954	LSB-BSE2: LSBF Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3964	LSB-BSE2: LSBF Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3965	LSB-BSE2: LSBF Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3966	LSB-BSE2: LSBF Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3967	LSB-BSE2: LSBF Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3968	LSB-BSE2: LSBF Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3969	LSB-BSE2: LSBF Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B396A	LSB-BSE2: LSBF Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B396B	LSB-BSE2: LSBF Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B396C	LSB-BSE2: LSBF Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3A50	LSB-BSE2: LSBF Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3A51	LSB-BSE2: LSBF Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3A53	LSB-BSE2: LSBF Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3A54	LSB-BSE2: LSBF Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3A64	LSB-BSE2: LSBF Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3A65	LSB-BSE2: LSBF Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3A66	LSB-BSE2: LSBF Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3A67	LSB-BSE2: LSBF Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3A68	LSB-BSE2: LSBF Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3A69	LSB-BSE2: LSBF Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B3A6A	LSB-BSE2: LSBF Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3A6B	LSB-BSE2: LSBF Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B3A6C	LSB-BSE2: LSBF Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3B50	LSB-BSE2: LSBF Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3B51	LSB-BSE2: LSBF Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3B53	LSB-BSE2: LSBF Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3B54	LSB-BSE2: LSBF Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3B64	LSB-BSE2: LSBF Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3B65	LSB-BSE2: LSBF Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3B66	LSB-BSE2: LSBF Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3B67	LSB-BSE2: LSBF Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3B68	LSB-BSE2: LSBF Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3B69	LSB-BSE2: LSBF Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B3B6A	LSB-BSE2: LSBF Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B3B6B	LSB-BSE2: LSBF Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B3B6C	LSB-BSE2: LSBF Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3C50	LSB-BSE2: LSBF Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3C51	LSB-BSE2: LSBF Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3C53	LSB-BSE2: LSBF Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3C54	LSB-BSE2: LSBF Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3C64	LSB-BSE2: LSBF Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3C65	LSB-BSE2: LSBF Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3C66	LSB-BSE2: LSBF Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3C67	LSB-BSE2: LSBF Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3C68	LSB-BSE2: LSBF Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3C69	LSB-BSE2: LSBF Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B3C6A	LSB-BSE2: LSBF Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B3C6B	LSB-BSE2: LSBF Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B3C6C	LSB-BSE2: LSBF Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3D50	LSB-BSE2: LSBF Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3D51	LSB-BSE2: LSBF Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3D53	LSB-BSE2: LSBF Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3D54	LSB-BSE2: LSBF Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3D64	LSB-BSE2: LSBF Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3D65	LSB-BSE2: LSBF Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3D66	LSB-BSE2: LSBF Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3D67	LSB-BSE2: LSBF Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3D68	LSB-BSE2: LSBF Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3D69	LSB-BSE2: LSBF Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B3D6A	LSB-BSE2: LSBF Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B3D6B	LSB-BSE2: LSBF Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3D6C	LSB-BSE2: LSBF Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3E50	LSB-BSE2: LSBF Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3E51	LSB-BSE2: LSBF Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3E53	LSB-BSE2: LSBF Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3E54	LSB-BSE2: LSBF Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3E64	LSB-BSE2: LSBF Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3E65	LSB-BSE2: LSBF Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B3E66	LSB-BSE2: LSBF Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3E67	LSB-BSE2: LSBF Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3E68	LSB-BSE2: LSBF Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3E69	LSB-BSE2: LSBF Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B3E6A	LSB-BSE2: LSBF Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B3E6B	LSB-BSE2: LSBF Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B3E6C	LSB-BSE2: LSBF Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B3F50	LSB-BSE2: LSBF Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B3F51	LSB-BSE2: LSBF Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B3F53	LSB-BSE2: LSBF Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B3F54	LSB-BSE2: LSBF Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B3F64	LSB-BSE2: LSBF Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B3F65	LSB-BSE2: LSBF Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B3F66	LSB-BSE2: LSBF Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B3F67	LSB-BSE2: LSBF Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B3F68	LSB-BSE2: LSBF Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B3F69	LSB-BSE2: LSBF Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B3F6A	LSB-BSE2: LSBF Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B3F6B	LSB-BSE2: LSBF Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B3F6C	LSB-BSE2: LSBF Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4050	LSB-BSE2: LSBF Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4051	LSB-BSE2: LSBF Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4053	LSB-BSE2: LSBF Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4054	LSB-BSE2: LSBF Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4064	LSB-BSE2: LSBF Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4065	LSB-BSE2: LSBF Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4066	LSB-BSE2: LSBF Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4067	LSB-BSE2: LSBF Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4068	LSB-BSE2: LSBF Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4069	LSB-BSE2: LSBF Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B406A	LSB-BSE2: LSBF Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B406B	LSB-BSE2: LSBF Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B406C	LSB-BSE2: LSBF Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4150	LSB-BSE2: LSBF Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4151	LSB-BSE2: LSBF Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4153	LSB-BSE2: LSBF Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4154	LSB-BSE2: LSBF Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4164	LSB-BSE2: LSBF Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4165	LSB-BSE2: LSBF Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4166	LSB-BSE2: LSBF Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4167	LSB-BSE2: LSBF Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4168	LSB-BSE2: LSBF Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4169	LSB-BSE2: LSBF Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B416A	LSB-BSE2: LSBF Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B416B	LSB-BSE2: LSBF Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B416C	LSB-BSE2: LSBF Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4250	LSB-BSE2: LSBF Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4251	LSB-BSE2: LSBF Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4253	LSB-BSE2: LSBF Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4254	LSB-BSE2: LSBF Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4264	LSB-BSE2: LSBF Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4265	LSB-BSE2: LSBF Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4266	LSB-BSE2: LSBF Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4267	LSB-BSE2: LSBF Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4268	LSB-BSE2: LSBF Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4269	LSB-BSE2: LSBF Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B426A	LSB-BSE2: LSBF Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B426B	LSB-BSE2: LSBF Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B426C	LSB-BSE2: LSBF Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4350	LSB-BSE2: LSBF Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4351	LSB-BSE2: LSBF Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4353	LSB-BSE2: LSBF Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4354	LSB-BSE2: LSBF Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4364	LSB-BSE2: LSBF Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4365	LSB-BSE2: LSBF Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4366	LSB-BSE2: LSBF Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4367	LSB-BSE2: LSBF Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4368	LSB-BSE2: LSBF Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4369	LSB-BSE2: LSBF Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B436A	LSB-BSE2: LSBF Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B436B	LSB-BSE2: LSBF Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B436C	LSB-BSE2: LSBF Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4450	LSB-BSE2: LSBF Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4451	LSB-BSE2: LSBF Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4453	LSB-BSE2: LSBF Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4454	LSB-BSE2: LSBF Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4464	LSB-BSE2: LSBF Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4465	LSB-BSE2: LSBF Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4466	LSB-BSE2: LSBF Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4467	LSB-BSE2: LSBF Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4468	LSB-BSE2: LSBF Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4469	LSB-BSE2: LSBF Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B446A	LSB-BSE2: LSBF Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B446B	LSB-BSE2: LSBF Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B446C	LSB-BSE2: LSBF Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4550	LSB-BSE2: LSBF Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4551	LSB-BSE2: LSBF Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4553	LSB-BSE2: LSBF Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4554	LSB-BSE2: LSBF Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4564	LSB-BSE2: LSBF Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4565	LSB-BSE2: LSBF Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4566	LSB-BSE2: LSBF Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4567	LSB-BSE2: LSBF Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4568	LSB-BSE2: LSBF Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4569	LSB-BSE2: LSBF Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B456A	LSB-BSE2: LSBF Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B456B	LSB-BSE2: LSBF Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B456C	LSB-BSE2: LSBF Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4650	LSB-BSE2: LSBF Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4651	LSB-BSE2: LSBF Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4653	LSB-BSE2: LSBF Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4654	LSB-BSE2: LSBF Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4664	LSB-BSE2: LSBF Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4665	LSB-BSE2: LSBF Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4666	LSB-BSE2: LSBF Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4667	LSB-BSE2: LSBF Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4668	LSB-BSE2: LSBF Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4669	LSB-BSE2: LSBF Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B466A	LSB-BSE2: LSBF Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B466B	LSB-BSE2: LSBF Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B466C	LSB-BSE2: LSBF Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4750	LSB-BSE2: LSBF Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4751	LSB-BSE2: LSBF Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4753	LSB-BSE2: LSBF Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4754	LSB-BSE2: LSBF Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4764	LSB-BSE2: LSBF Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4765	LSB-BSE2: LSBF Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4766	LSB-BSE2: LSBF Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4767	LSB-BSE2: LSBF Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4768	LSB-BSE2: LSBF Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4769	LSB-BSE2: LSBF Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B476A	LSB-BSE2: LSBF Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B476B	LSB-BSE2: LSBF Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B476C	LSB-BSE2: LSBF Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4850	LSB-BSE2: LSBF Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4851	LSB-BSE2: LSBF Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4853	LSB-BSE2: LSBF Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4854	LSB-BSE2: LSBF Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4864	LSB-BSE2: LSBF Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4865	LSB-BSE2: LSBF Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4866	LSB-BSE2: LSBF Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4867	LSB-BSE2: LSBF Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4868	LSB-BSE2: LSBF Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4869	LSB-BSE2: LSBF Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B486A	LSB-BSE2: LSBF Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B486B	LSB-BSE2: LSBF Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B486C	LSB-BSE2: LSBF Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4950	LSB-BSE2: LSBF Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4951	LSB-BSE2: LSBF Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4953	LSB-BSE2: LSBF Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4954	LSB-BSE2: LSBF Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4964	LSB-BSE2: LSBF Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4965	LSB-BSE2: LSBF Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4966	LSB-BSE2: LSBF Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4967	LSB-BSE2: LSBF Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4968	LSB-BSE2: LSBF Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4969	LSB-BSE2: LSBF Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B496A	LSB-BSE2: LSBF Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B496B	LSB-BSE2: LSBF Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B496C	LSB-BSE2: LSBF Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4A50	LSB-BSE2: LSBF Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4A51	LSB-BSE2: LSBF Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4A53	LSB-BSE2: LSBF Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4A54	LSB-BSE2: LSBF Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4A64	LSB-BSE2: LSBF Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4A65	LSB-BSE2: LSBF Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4A66	LSB-BSE2: LSBF Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4A67	LSB-BSE2: LSBF Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4A68	LSB-BSE2: LSBF Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4A69	LSB-BSE2: LSBF Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B4A6A	LSB-BSE2: LSBF Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B4A6B	LSB-BSE2: LSBF Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B4A6C	LSB-BSE2: LSBF Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4B50	LSB-BSE2: LSBF Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4B51	LSB-BSE2: LSBF Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4B53	LSB-BSE2: LSBF Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4B54	LSB-BSE2: LSBF Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4B64	LSB-BSE2: LSBF Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4B65	LSB-BSE2: LSBF Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4B66	LSB-BSE2: LSBF Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4B67	LSB-BSE2: LSBF Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4B68	LSB-BSE2: LSBF Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4B69	LSB-BSE2: LSBF Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4B6A	LSB-BSE2: LSBF Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B4B6B	LSB-BSE2: LSBF Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B4B6C	LSB-BSE2: LSBF Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4C50	LSB-BSE2: LSBF Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4C51	LSB-BSE2: LSBF Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4C53	LSB-BSE2: LSBF Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4C54	LSB-BSE2: LSBF Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4C64	LSB-BSE2: LSBF Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4C65	LSB-BSE2: LSBF Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4C66	LSB-BSE2: LSBF Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4C67	LSB-BSE2: LSBF Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4C68	LSB-BSE2: LSBF Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4C69	LSB-BSE2: LSBF Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B4C6A	LSB-BSE2: LSBF Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B4C6B	LSB-BSE2: LSBF Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B4C6C	LSB-BSE2: LSBF Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4D50	LSB-BSE2: LSBF Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2
2B4D51	LSB-BSE2: LSBF Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4D53	LSB-BSE2: LSBF Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4D54	LSB-BSE2: LSBF Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4D64	LSB-BSE2: LSBF Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4D65	LSB-BSE2: LSBF Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4D66	LSB-BSE2: LSBF Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4D67	LSB-BSE2: LSBF Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4D68	LSB-BSE2: LSBF Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4D69	LSB-BSE2: LSBF Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B4D6A	LSB-BSE2: LSBF Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2
2B4D6B	LSB-BSE2: LSBF Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B4D6C	LSB-BSE2: LSBF Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B4E50	LSB-BSE2: LSBF Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4E51	LSB-BSE2: LSBF Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:10		E	2
2B4E53	LSB-BSE2: LSBF Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:10		E	1
2B4E54	LSB-BSE2: LSBF Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:10		E	2
2B4E64	LSB-BSE2: LSBF Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:10		E	1
2B4E65	LSB-BSE2: LSBF Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:10		E	2
2B4E66	LSB-BSE2: LSBF Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:10		E	2
2B4E67	LSB-BSE2: LSBF Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:10		E	1
2B4E68	LSB-BSE2: LSBF Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:10		E	1
2B4E69	LSB-BSE2: LSBF Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:10		E	1
2B4E6A	LSB-BSE2: LSBF Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B4E6B	LSB-BSE2: LSBF Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:10		E	2
2B4E6C	LSB-BSE2: LSBF Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:10		E	2
2B5052	LSB-BSE2: Control data transfer LSBF has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362.X5:10		E	0
2B5055	LSB-BSE2: Control data transfer LSBF Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X5:10		E	2
2B5056	LSB-BSE2: Control data transfer LSBF Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X5:10		E	2
2B5057	LSB-BSE2: Control data transfer LSBF has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362.X5:10		E	1
2B5058	LSB-BSE2: Control data transfer LSBF recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362.X5:10		E	0
2B5059	LSB-BSE2: Control data transfer LSBF recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362.X5:10		E	0
2B5060	LSB-BSE2: Control data transfer LSBF driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362.X5:10		E	2
2B5061	LSB-BSE2: Control data transfer LSBF driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B5062	LSB-BSE2: Control data transfer LSBF Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362.X5:10		E	2
2B6050	LSB-BSE2: LSBG Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6051	LSB-BSE2: LSBG Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6053	LSB-BSE2: LSBG Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6054	LSB-BSE2: LSBG Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6064	LSB-BSE2: LSBG Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6065	LSB-BSE2: LSBG Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6066	LSB-BSE2: LSBG Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6067	LSB-BSE2: LSBG Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6068	LSB-BSE2: LSBG Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6069	LSB-BSE2: LSBG Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B606A	LSB-BSE2: LSBG Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B606B	LSB-BSE2: LSBG Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B606C	LSB-BSE2: LSBG Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6150	LSB-BSE2: LSBG Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6151	LSB-BSE2: LSBG Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6153	LSB-BSE2: LSBG Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6154	LSB-BSE2: LSBG Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6164	LSB-BSE2: LSBG Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6165	LSB-BSE2: LSBG Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6166	LSB-BSE2: LSBG Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6167	LSB-BSE2: LSBG Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6168	LSB-BSE2: LSBG Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6169	LSB-BSE2: LSBG Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B616A	LSB-BSE2: LSBG Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B616B	LSB-BSE2: LSBG Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B616C	LSB-BSE2: LSBG Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6450	LSB-BSE2: LSBG Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6451	LSB-BSE2: LSBG Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6453	LSB-BSE2: LSBG Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6454	LSB-BSE2: LSBG Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6464	LSB-BSE2: LSBG Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6465	LSB-BSE2: LSBG Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6466	LSB-BSE2: LSBG Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6467	LSB-BSE2: LSBG Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6468	LSB-BSE2: LSBG Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6469	LSB-BSE2: LSBG Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B646A	LSB-BSE2: LSBG Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B646B	LSB-BSE2: LSBG Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B646C	LSB-BSE2: LSBG Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6550	LSB-BSE2: LSBG Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6551	LSB-BSE2: LSBG Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6553	LSB-BSE2: LSBG Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6554	LSB-BSE2: LSBG Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6564	LSB-BSE2: LSBG Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6565	LSB-BSE2: LSBG Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6566	LSB-BSE2: LSBG Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6567	LSB-BSE2: LSBG Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6568	LSB-BSE2: LSBG Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6569	LSB-BSE2: LSBG Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B656A	LSB-BSE2: LSBG Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B656B	LSB-BSE2: LSBG Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B656C	LSB-BSE2: LSBG Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6650	LSB-BSE2: LSBG Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6651	LSB-BSE2: LSBG Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6653	LSB-BSE2: LSBG Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6654	LSB-BSE2: LSBG Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6664	LSB-BSE2: LSBG Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6665	LSB-BSE2: LSBG Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6666	LSB-BSE2: LSBG Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6667	LSB-BSE2: LSBG Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6668	LSB-BSE2: LSBG Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6669	LSB-BSE2: LSBG Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B666A	LSB-BSE2: LSBG Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B666B	LSB-BSE2: LSBG Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B666C	LSB-BSE2: LSBG Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6750	LSB-BSE2: LSBG Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6751	LSB-BSE2: LSBG Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6753	LSB-BSE2: LSBG Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6754	LSB-BSE2: LSBG Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6764	LSB-BSE2: LSBG Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6765	LSB-BSE2: LSBG Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6766	LSB-BSE2: LSBG Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6767	LSB-BSE2: LSBG Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6768	LSB-BSE2: LSBG Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6769	LSB-BSE2: LSBG Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B676A	LSB-BSE2: LSBG Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B676B	LSB-BSE2: LSBG Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B676C	LSB-BSE2: LSBG Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6850	LSB-BSE2: LSBG Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6851	LSB-BSE2: LSBG Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6853	LSB-BSE2: LSBG Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6854	LSB-BSE2: LSBG Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6864	LSB-BSE2: LSBG Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6865	LSB-BSE2: LSBG Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6866	LSB-BSE2: LSBG Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6867	LSB-BSE2: LSBG Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6868	LSB-BSE2: LSBG Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6869	LSB-BSE2: LSBG Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B686A	LSB-BSE2: LSBG Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B686B	LSB-BSE2: LSBG Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B686C	LSB-BSE2: LSBG Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6950	LSB-BSE2: LSBG Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6951	LSB-BSE2: LSBG Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6953	LSB-BSE2: LSBG Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6954	LSB-BSE2: LSBG Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6964	LSB-BSE2: LSBG Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6965	LSB-BSE2: LSBG Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6966	LSB-BSE2: LSBG Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6967	LSB-BSE2: LSBG Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6968	LSB-BSE2: LSBG Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6969	LSB-BSE2: LSBG Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B696A	LSB-BSE2: LSBG Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B696B	LSB-BSE2: LSBG Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B696C	LSB-BSE2: LSBG Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6A50	LSB-BSE2: LSBG Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6A51	LSB-BSE2: LSBG Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6A53	LSB-BSE2: LSBG Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6A54	LSB-BSE2: LSBG Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6A64	LSB-BSE2: LSBG Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6A65	LSB-BSE2: LSBG Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6A66	LSB-BSE2: LSBG Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6A67	LSB-BSE2: LSBG Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6A68	LSB-BSE2: LSBG Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6A69	LSB-BSE2: LSBG Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B6A6A	LSB-BSE2: LSBG Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B6A6B	LSB-BSE2: LSBG Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B6A6C	LSB-BSE2: LSBG Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6B50	LSB-BSE2: LSBG Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6B51	LSB-BSE2: LSBG Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6B53	LSB-BSE2: LSBG Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6B54	LSB-BSE2: LSBG Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6B64	LSB-BSE2: LSBG Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6B65	LSB-BSE2: LSBG Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6B66	LSB-BSE2: LSBG Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6B67	LSB-BSE2: LSBG Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6B68	LSB-BSE2: LSBG Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6B69	LSB-BSE2: LSBG Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B6B6A	LSB-BSE2: LSBG Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B6B6B	LSB-BSE2: LSBG Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6B6C	LSB-BSE2: LSBG Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6C50	LSB-BSE2: LSBG Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6C51	LSB-BSE2: LSBG Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6C53	LSB-BSE2: LSBG Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6C54	LSB-BSE2: LSBG Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6C64	LSB-BSE2: LSBG Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6C65	LSB-BSE2: LSBG Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6C66	LSB-BSE2: LSBG Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6C67	LSB-BSE2: LSBG Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6C68	LSB-BSE2: LSBG Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6C69	LSB-BSE2: LSBG Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B6C6A	LSB-BSE2: LSBG Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B6C6B	LSB-BSE2: LSBG Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B6C6C	LSB-BSE2: LSBG Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6E50	LSB-BSE2: LSBG Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6E51	LSB-BSE2: LSBG Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6E53	LSB-BSE2: LSBG Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B6E54	LSB-BSE2: LSBG Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6E64	LSB-BSE2: LSBG Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6E65	LSB-BSE2: LSBG Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6E66	LSB-BSE2: LSBG Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6E67	LSB-BSE2: LSBG Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6E68	LSB-BSE2: LSBG Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6E69	LSB-BSE2: LSBG Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B6E6A	LSB-BSE2: LSBG Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B6E6B	LSB-BSE2: LSBG Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B6E6C	LSB-BSE2: LSBG Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B6F50	LSB-BSE2: LSBG Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B6F51	LSB-BSE2: LSBG Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B6F53	LSB-BSE2: LSBG Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B6F54	LSB-BSE2: LSBG Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B6F64	LSB-BSE2: LSBG Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B6F65	LSB-BSE2: LSBG Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B6F66	LSB-BSE2: LSBG Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B6F67	LSB-BSE2: LSBG Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B6F68	LSB-BSE2: LSBG Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B6F69	LSB-BSE2: LSBG Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B6F6A	LSB-BSE2: LSBG Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B6F6B	LSB-BSE2: LSBG Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B6F6C	LSB-BSE2: LSBG Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7050	LSB-BSE2: LSBG Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7051	LSB-BSE2: LSBG Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7053	LSB-BSE2: LSBG Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7054	LSB-BSE2: LSBG Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7064	LSB-BSE2: LSBG Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7065	LSB-BSE2: LSBG Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7066	LSB-BSE2: LSBG Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7067	LSB-BSE2: LSBG Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7068	LSB-BSE2: LSBG Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7069	LSB-BSE2: LSBG Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B706A	LSB-BSE2: LSBG Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B706B	LSB-BSE2: LSBG Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B706C	LSB-BSE2: LSBG Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7150	LSB-BSE2: LSBG Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7151	LSB-BSE2: LSBG Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7153	LSB-BSE2: LSBG Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7154	LSB-BSE2: LSBG Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7164	LSB-BSE2: LSBG Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7165	LSB-BSE2: LSBG Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7166	LSB-BSE2: LSBG Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7167	LSB-BSE2: LSBG Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7168	LSB-BSE2: LSBG Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7169	LSB-BSE2: LSBG Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B716A	LSB-BSE2: LSBG Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B716B	LSB-BSE2: LSBG Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B716C	LSB-BSE2: LSBG Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7250	LSB-BSE2: LSBG Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7251	LSB-BSE2: LSBG Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7253	LSB-BSE2: LSBG Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7254	LSB-BSE2: LSBG Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7264	LSB-BSE2: LSBG Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7265	LSB-BSE2: LSBG Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7266	LSB-BSE2: LSBG Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7267	LSB-BSE2: LSBG Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7268	LSB-BSE2: LSBG Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7269	LSB-BSE2: LSBG Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B726A	LSB-BSE2: LSBG Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B726B	LSB-BSE2: LSBG Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B726C	LSB-BSE2: LSBG Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7350	LSB-BSE2: LSBG Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7351	LSB-BSE2: LSBG Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7353	LSB-BSE2: LSBG Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7354	LSB-BSE2: LSBG Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7364	LSB-BSE2: LSBG Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7365	LSB-BSE2: LSBG Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7366	LSB-BSE2: LSBG Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7367	LSB-BSE2: LSBG Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7368	LSB-BSE2: LSBG Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7369	LSB-BSE2: LSBG Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B736A	LSB-BSE2: LSBG Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B736B	LSB-BSE2: LSBG Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B736C	LSB-BSE2: LSBG Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7450	LSB-BSE2: LSBG Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7451	LSB-BSE2: LSBG Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7453	LSB-BSE2: LSBG Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7454	LSB-BSE2: LSBG Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7464	LSB-BSE2: LSBG Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7465	LSB-BSE2: LSBG Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7466	LSB-BSE2: LSBG Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7467	LSB-BSE2: LSBG Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7468	LSB-BSE2: LSBG Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7469	LSB-BSE2: LSBG Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B746A	LSB-BSE2: LSBG Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B746B	LSB-BSE2: LSBG Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B746C	LSB-BSE2: LSBG Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7550	LSB-BSE2: LSBG Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7551	LSB-BSE2: LSBG Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7553	LSB-BSE2: LSBG Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7554	LSB-BSE2: LSBG Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7564	LSB-BSE2: LSBG Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7565	LSB-BSE2: LSBG Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7566	LSB-BSE2: LSBG Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7567	LSB-BSE2: LSBG Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7568	LSB-BSE2: LSBG Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7569	LSB-BSE2: LSBG Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B756A	LSB-BSE2: LSBG Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B756B	LSB-BSE2: LSBG Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B756C	LSB-BSE2: LSBG Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7650	LSB-BSE2: LSBG Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7651	LSB-BSE2: LSBG Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7653	LSB-BSE2: LSBG Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7654	LSB-BSE2: LSBG Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7664	LSB-BSE2: LSBG Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7665	LSB-BSE2: LSBG Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7666	LSB-BSE2: LSBG Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7667	LSB-BSE2: LSBG Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7668	LSB-BSE2: LSBG Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7669	LSB-BSE2: LSBG Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B766A	LSB-BSE2: LSBG Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B766B	LSB-BSE2: LSBG Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B766C	LSB-BSE2: LSBG Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7750	LSB-BSE2: LSBG Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7751	LSB-BSE2: LSBG Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7753	LSB-BSE2: LSBG Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7754	LSB-BSE2: LSBG Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7764	LSB-BSE2: LSBG Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7765	LSB-BSE2: LSBG Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7766	LSB-BSE2: LSBG Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7767	LSB-BSE2: LSBG Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7768	LSB-BSE2: LSBG Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7769	LSB-BSE2: LSBG Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B776A	LSB-BSE2: LSBG Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B776B	LSB-BSE2: LSBG Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B776C	LSB-BSE2: LSBG Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7850	LSB-BSE2: LSBG Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7851	LSB-BSE2: LSBG Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7853	LSB-BSE2: LSBG Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7854	LSB-BSE2: LSBG Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7864	LSB-BSE2: LSBG Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7865	LSB-BSE2: LSBG Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7866	LSB-BSE2: LSBG Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7867	LSB-BSE2: LSBG Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7868	LSB-BSE2: LSBG Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7869	LSB-BSE2: LSBG Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B786A	LSB-BSE2: LSBG Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B786B	LSB-BSE2: LSBG Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B786C	LSB-BSE2: LSBG Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7A50	LSB-BSE2: LSBG Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7A51	LSB-BSE2: LSBG Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7A53	LSB-BSE2: LSBG Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7A54	LSB-BSE2: LSBG Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7A64	LSB-BSE2: LSBG Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7A65	LSB-BSE2: LSBG Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7A66	LSB-BSE2: LSBG Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7A67	LSB-BSE2: LSBG Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7A68	LSB-BSE2: LSBG Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7A69	LSB-BSE2: LSBG Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B7A6A	LSB-BSE2: LSBG Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B7A6B	LSB-BSE2: LSBG Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B7A6C	LSB-BSE2: LSBG Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7D50	LSB-BSE2: LSBG Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7D51	LSB-BSE2: LSBG Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7D53	LSB-BSE2: LSBG Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7D54	LSB-BSE2: LSBG Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7D64	LSB-BSE2: LSBG Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7D65	LSB-BSE2: LSBG Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7D66	LSB-BSE2: LSBG Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2
2B7D67	LSB-BSE2: LSBG Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7D68	LSB-BSE2: LSBG Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7D69	LSB-BSE2: LSBG Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7D6A	LSB-BSE2: LSBG Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B7D6B	LSB-BSE2: LSBG Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B7D6C	LSB-BSE2: LSBG Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B7E50	LSB-BSE2: LSBG Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:11		E	2
2B7E51	LSB-BSE2: LSBG Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:11		E	2
2B7E53	LSB-BSE2: LSBG Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:11		E	1
2B7E54	LSB-BSE2: LSBG Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:11		E	2
2B7E64	LSB-BSE2: LSBG Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:11		E	1
2B7E65	LSB-BSE2: LSBG Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:11		E	2
2B7E66	LSB-BSE2: LSBG Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B7E67	LSB-BSE2: LSBG Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:11		E	1
2B7E68	LSB-BSE2: LSBG Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:11		E	1
2B7E69	LSB-BSE2: LSBG Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:11		E	1
2B7E6A	LSB-BSE2: LSBG Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:11		E	2
2B7E6B	LSB-BSE2: LSBG Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:11		E	2
2B7E6C	LSB-BSE2: LSBG Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:11		E	2
2B8052	LSB-BSE2: Control data transfer LSBG has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362.X5:11		E	0
2B8055	LSB-BSE2: Control data transfer LSBG Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X5:11		E	2
2B8056	LSB-BSE2: Control data transfer LSBG Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X5:11		E	2
2B8057	LSB-BSE2: Control data transfer LSBG has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B8058	LSB-BSE2: Control data transfer LSBG recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362.X5:11		E	0
2B8059	LSB-BSE2: Control data transfer LSBG recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362.X5:11		E	0
2B8060	LSB-BSE2: Control data transfer LSBG driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362.X5:11		E	2
2B8061	LSB-BSE2: Control data transfer LSBG driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362.X5:11		E	2
2B8062	LSB-BSE2: Control data transfer LSBG Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362.X5:11		E	2
2B9050	LSB-BSE2: LSBH Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9051	LSB-BSE2: LSBH Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9053	LSB-BSE2: LSBH Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9054	LSB-BSE2: LSBH Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9064	LSB-BSE2: LSBH Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9065	LSB-BSE2: LSBH Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9066	LSB-BSE2: LSBH Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9067	LSB-BSE2: LSBH Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9068	LSB-BSE2: LSBH Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9069	LSB-BSE2: LSBH Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B906A	LSB-BSE2: LSBH Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B906B	LSB-BSE2: LSBH Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B906C	LSB-BSE2: LSBH Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9150	LSB-BSE2: LSBH Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9151	LSB-BSE2: LSBH Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9153	LSB-BSE2: LSBH Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9154	LSB-BSE2: LSBH Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9164	LSB-BSE2: LSBH Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9165	LSB-BSE2: LSBH Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9166	LSB-BSE2: LSBH Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9167	LSB-BSE2: LSBH Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9168	LSB-BSE2: LSBH Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9169	LSB-BSE2: LSBH Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B916A	LSB-BSE2: LSBH Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B916B	LSB-BSE2: LSBH Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B916C	LSB-BSE2: LSBH Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9350	LSB-BSE2: LSBH Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9351	LSB-BSE2: LSBH Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9353	LSB-BSE2: LSBH Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9354	LSB-BSE2: LSBH Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9364	LSB-BSE2: LSBH Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9365	LSB-BSE2: LSBH Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9366	LSB-BSE2: LSBH Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9367	LSB-BSE2: LSBH Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9368	LSB-BSE2: LSBH Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9369	LSB-BSE2: LSBH Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B936A	LSB-BSE2: LSBH Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B936B	LSB-BSE2: LSBH Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B936C	LSB-BSE2: LSBH Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9450	LSB-BSE2: LSBH Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9451	LSB-BSE2: LSBH Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9453	LSB-BSE2: LSBH Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9454	LSB-BSE2: LSBH Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9464	LSB-BSE2: LSBH Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9465	LSB-BSE2: LSBH Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9466	LSB-BSE2: LSBH Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9467	LSB-BSE2: LSBH Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9468	LSB-BSE2: LSBH Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9469	LSB-BSE2: LSBH Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B946A	LSB-BSE2: LSBH Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B946B	LSB-BSE2: LSBH Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B946C	LSB-BSE2: LSBH Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9550	LSB-BSE2: LSBH Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9551	LSB-BSE2: LSBH Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9553	LSB-BSE2: LSBH Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9554	LSB-BSE2: LSBH Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9564	LSB-BSE2: LSBH Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9565	LSB-BSE2: LSBH Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9566	LSB-BSE2: LSBH Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9567	LSB-BSE2: LSBH Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9568	LSB-BSE2: LSBH Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9569	LSB-BSE2: LSBH Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B956A	LSB-BSE2: LSBH Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B956B	LSB-BSE2: LSBH Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B956C	LSB-BSE2: LSBH Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9650	LSB-BSE2: LSBH Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9651	LSB-BSE2: LSBH Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9653	LSB-BSE2: LSBH Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9654	LSB-BSE2: LSBH Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9664	LSB-BSE2: LSBH Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9665	LSB-BSE2: LSBH Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9666	LSB-BSE2: LSBH Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9667	LSB-BSE2: LSBH Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9668	LSB-BSE2: LSBH Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9669	LSB-BSE2: LSBH Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B966A	LSB-BSE2: LSBH Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B966B	LSB-BSE2: LSBH Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B966C	LSB-BSE2: LSBH Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9750	LSB-BSE2: LSBH Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9751	LSB-BSE2: LSBH Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9753	LSB-BSE2: LSBH Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9754	LSB-BSE2: LSBH Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9764	LSB-BSE2: LSBH Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9765	LSB-BSE2: LSBH Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9766	LSB-BSE2: LSBH Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9767	LSB-BSE2: LSBH Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9768	LSB-BSE2: LSBH Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9769	LSB-BSE2: LSBH Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B976A	LSB-BSE2: LSBH Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B976B	LSB-BSE2: LSBH Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B976C	LSB-BSE2: LSBH Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9850	LSB-BSE2: LSBH Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9851	LSB-BSE2: LSBH Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9853	LSB-BSE2: LSBH Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9854	LSB-BSE2: LSBH Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9864	LSB-BSE2: LSBH Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9865	LSB-BSE2: LSBH Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9866	LSB-BSE2: LSBH Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9867	LSB-BSE2: LSBH Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9868	LSB-BSE2: LSBH Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9869	LSB-BSE2: LSBH Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B986A	LSB-BSE2: LSBH Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B986B	LSB-BSE2: LSBH Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B986C	LSB-BSE2: LSBH Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9950	LSB-BSE2: LSBH Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9951	LSB-BSE2: LSBH Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9953	LSB-BSE2: LSBH Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9954	LSB-BSE2: LSBH Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9964	LSB-BSE2: LSBH Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9965	LSB-BSE2: LSBH Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9966	LSB-BSE2: LSBH Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9967	LSB-BSE2: LSBH Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9968	LSB-BSE2: LSBH Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9969	LSB-BSE2: LSBH Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B996A	LSB-BSE2: LSBH Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B996B	LSB-BSE2: LSBH Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B996C	LSB-BSE2: LSBH Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9A50	LSB-BSE2: LSBH Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9A51	LSB-BSE2: LSBH Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9A53	LSB-BSE2: LSBH Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9A54	LSB-BSE2: LSBH Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9A64	LSB-BSE2: LSBH Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9A65	LSB-BSE2: LSBH Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9A66	LSB-BSE2: LSBH Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9A67	LSB-BSE2: LSBH Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9A68	LSB-BSE2: LSBH Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9A69	LSB-BSE2: LSBH Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B9A6A	LSB-BSE2: LSBH Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B9A6B	LSB-BSE2: LSBH Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B9A6C	LSB-BSE2: LSBH Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9B50	LSB-BSE2: LSBH Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9B51	LSB-BSE2: LSBH Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9B53	LSB-BSE2: LSBH Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9B54	LSB-BSE2: LSBH Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9B64	LSB-BSE2: LSBH Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9B65	LSB-BSE2: LSBH Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9B66	LSB-BSE2: LSBH Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9B67	LSB-BSE2: LSBH Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9B68	LSB-BSE2: LSBH Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9B69	LSB-BSE2: LSBH Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B9B6A	LSB-BSE2: LSBH Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B9B6B	LSB-BSE2: LSBH Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B9B6C	LSB-BSE2: LSBH Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9C50	LSB-BSE2: LSBH Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9C51	LSB-BSE2: LSBH Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9C53	LSB-BSE2: LSBH Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9C54	LSB-BSE2: LSBH Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9C64	LSB-BSE2: LSBH Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9C65	LSB-BSE2: LSBH Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9C66	LSB-BSE2: LSBH Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9C67	LSB-BSE2: LSBH Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9C68	LSB-BSE2: LSBH Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2B9C69	LSB-BSE2: LSBH Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B9C6A	LSB-BSE2: LSBH Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B9C6B	LSB-BSE2: LSBH Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9C6C	LSB-BSE2: LSBH Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2B9F50	LSB-BSE2: LSBH Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2B9F51	LSB-BSE2: LSBH Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2B9F53	LSB-BSE2: LSBH Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2B9F54	LSB-BSE2: LSBH Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2B9F64	LSB-BSE2: LSBH Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2B9F65	LSB-BSE2: LSBH Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2B9F66	LSB-BSE2: LSBH Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2B9F67	LSB-BSE2: LSBH Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2B9F68	LSB-BSE2: LSBH Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2B9F69	LSB-BSE2: LSBH Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2B9F6A	LSB-BSE2: LSBH Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2B9F6B	LSB-BSE2: LSBH Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2B9F6C	LSB-BSE2: LSBH Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BA050	LSB-BSE2: LSBH Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BA051	LSB-BSE2: LSBH Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BA053	LSB-BSE2: LSBH Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BA054	LSB-BSE2: LSBH Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BA064	LSB-BSE2: LSBH Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BA065	LSB-BSE2: LSBH Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA066	LSB-BSE2: LSBH Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BA067	LSB-BSE2: LSBH Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BA068	LSB-BSE2: LSBH Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA069	LSB-BSE2: LSBH Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BA06A	LSB-BSE2: LSBH Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BA06B	LSB-BSE2: LSBH Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BA06C	LSB-BSE2: LSBH Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BA150	LSB-BSE2: LSBH Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BA151	LSB-BSE2: LSBH Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BA153	LSB-BSE2: LSBH Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA154	LSB-BSE2: LSBH Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BA164	LSB-BSE2: LSBH Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BA165	LSB-BSE2: LSBH Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BA166	LSB-BSE2: LSBH Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BA167	LSB-BSE2: LSBH Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BA168	LSB-BSE2: LSBH Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA169	LSB-BSE2: LSBH Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BA16A	LSB-BSE2: LSBH Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BA16B	LSB-BSE2: LSBH Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BA16C	LSB-BSE2: LSBH Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA250	LSB-BSE2: LSBH Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BA251	LSB-BSE2: LSBH Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BA253	LSB-BSE2: LSBH Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BA254	LSB-BSE2: LSBH Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BA264	LSB-BSE2: LSBH Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BA265	LSB-BSE2: LSBH Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BA266	LSB-BSE2: LSBH Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BA267	LSB-BSE2: LSBH Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BA268	LSB-BSE2: LSBH Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA269	LSB-BSE2: LSBH Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA26A	LSB-BSE2: LSBH Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BA26B	LSB-BSE2: LSBH Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BA26C	LSB-BSE2: LSBH Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BA350	LSB-BSE2: LSBH Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BA351	LSB-BSE2: LSBH Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BA353	LSB-BSE2: LSBH Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BA354	LSB-BSE2: LSBH Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BA364	LSB-BSE2: LSBH Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BA365	LSB-BSE2: LSBH Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BA366	LSB-BSE2: LSBH Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA367	LSB-BSE2: LSBH Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BA368	LSB-BSE2: LSBH Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA369	LSB-BSE2: LSBH Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BA36A	LSB-BSE2: LSBH Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BA36B	LSB-BSE2: LSBH Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BA36C	LSB-BSE2: LSBH Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BA450	LSB-BSE2: LSBH Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BA451	LSB-BSE2: LSBH Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BA453	LSB-BSE2: LSBH Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BA454	LSB-BSE2: LSBH Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA464	LSB-BSE2: LSBH Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BA465	LSB-BSE2: LSBH Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BA466	LSB-BSE2: LSBH Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BA467	LSB-BSE2: LSBH Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BA468	LSB-BSE2: LSBH Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA469	LSB-BSE2: LSBH Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BA46A	LSB-BSE2: LSBH Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BA46B	LSB-BSE2: LSBH Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BA46C	LSB-BSE2: LSBH Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BA550	LSB-BSE2: LSBH Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA551	LSB-BSE2: LSBH Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BA553	LSB-BSE2: LSBH Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BA554	LSB-BSE2: LSBH Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BA564	LSB-BSE2: LSBH Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BA565	LSB-BSE2: LSBH Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BA566	LSB-BSE2: LSBH Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BA567	LSB-BSE2: LSBH Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BA568	LSB-BSE2: LSBH Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA569	LSB-BSE2: LSBH Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BA56A	LSB-BSE2: LSBH Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA56B	LSB-BSE2: LSBH Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BA56C	LSB-BSE2: LSBH Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BA650	LSB-BSE2: LSBH Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BA651	LSB-BSE2: LSBH Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BA653	LSB-BSE2: LSBH Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BA654	LSB-BSE2: LSBH Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BA664	LSB-BSE2: LSBH Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BA665	LSB-BSE2: LSBH Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BA666	LSB-BSE2: LSBH Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BA667	LSB-BSE2: LSBH Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA668	LSB-BSE2: LSBH Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA669	LSB-BSE2: LSBH Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BA66A	LSB-BSE2: LSBH Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BA66B	LSB-BSE2: LSBH Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BA66C	LSB-BSE2: LSBH Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BA750	LSB-BSE2: LSBH Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BA751	LSB-BSE2: LSBH Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BA753	LSB-BSE2: LSBH Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BA754	LSB-BSE2: LSBH Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BA764	LSB-BSE2: LSBH Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA765	LSB-BSE2: LSBH Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BA766	LSB-BSE2: LSBH Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BA767	LSB-BSE2: LSBH Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BA768	LSB-BSE2: LSBH Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA769	LSB-BSE2: LSBH Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BA76A	LSB-BSE2: LSBH Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BA76B	LSB-BSE2: LSBH Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BA76C	LSB-BSE2: LSBH Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BA850	LSB-BSE2: LSBH Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BA851	LSB-BSE2: LSBH Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA853	LSB-BSE2: LSBH Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BA854	LSB-BSE2: LSBH Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BA864	LSB-BSE2: LSBH Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BA865	LSB-BSE2: LSBH Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BA866	LSB-BSE2: LSBH Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BA867	LSB-BSE2: LSBH Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BA868	LSB-BSE2: LSBH Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1
2BA869	LSB-BSE2: LSBH Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BA86A	LSB-BSE2: LSBH Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BA86B	LSB-BSE2: LSBH Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BA86C	LSB-BSE2: LSBH Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BAE50	LSB-BSE2: LSBH Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362.X5:12		E	2
2BAE51	LSB-BSE2: LSBH Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362.X5:12		E	2
2BAE53	LSB-BSE2: LSBH Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362.X5:12		E	1
2BAE54	LSB-BSE2: LSBH Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362.X5:12		E	2
2BAE64	LSB-BSE2: LSBH Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362.X5:12		E	1
2BAE65	LSB-BSE2: LSBH Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362.X5:12		E	2
2BAE66	LSB-BSE2: LSBH Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362.X5:12		E	2
2BAE67	LSB-BSE2: LSBH Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362.X5:12		E	1
2BAE68	LSB-BSE2: LSBH Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BAE69	LSB-BSE2: LSBH Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362.X5:12		E	1
2BAE6A	LSB-BSE2: LSBH Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362.X5:12		E	2
2BAE6B	LSB-BSE2: LSBH Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362.X5:12		E	2
2BAE6C	LSB-BSE2: LSBH Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362.X5:12		E	2
2BB052	LSB-BSE2: Control data transfer LSBH has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362.X5:12		E	0
2BB055	LSB-BSE2: Control data transfer LSBH Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X5:12		E	2
2BB056	LSB-BSE2: Control data transfer LSBH Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362.X5:12		E	2
2BB057	LSB-BSE2: Control data transfer LSBH has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362.X5:12		E	1
2BB058	LSB-BSE2: Control data transfer LSBH recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362.X5:12		E	0
2BB059	LSB-BSE2: Control data transfer LSBH recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362.X5:12		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2BB060	LSB-BSE2: Control data transfer LSBH driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362.X5:12		E	2
2BB061	LSB-BSE2: Control data transfer LSBH driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362.X5:12		E	2
2BB062	LSB-BSE2: Control data transfer LSBH Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362.X5:12		E	2
2C0050	LSB-BSE2: LSBJ Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0051	LSB-BSE2: LSBJ Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0053	LSB-BSE2: LSBJ Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0054	LSB-BSE2: LSBJ Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0064	LSB-BSE2: LSBJ Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0065	LSB-BSE2: LSBJ Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0066	LSB-BSE2: LSBJ Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0067	LSB-BSE2: LSBJ Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0068	LSB-BSE2: LSBJ Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0069	LSB-BSE2: LSBJ Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C006A	LSB-BSE2: LSBJ Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C006B	LSB-BSE2: LSBJ Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C006C	LSB-BSE2: LSBJ Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0150	LSB-BSE2: LSBJ Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0151	LSB-BSE2: LSBJ Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0153	LSB-BSE2: LSBJ Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0154	LSB-BSE2: LSBJ Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0164	LSB-BSE2: LSBJ Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0165	LSB-BSE2: LSBJ Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0166	LSB-BSE2: LSBJ Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0167	LSB-BSE2: LSBJ Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0168	LSB-BSE2: LSBJ Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0169	LSB-BSE2: LSBJ Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C016A	LSB-BSE2: LSBJ Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C016B	LSB-BSE2: LSBJ Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C016C	LSB-BSE2: LSBJ Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0350	LSB-BSE2: LSBJ Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0351	LSB-BSE2: LSBJ Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0353	LSB-BSE2: LSBJ Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0354	LSB-BSE2: LSBJ Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0364	LSB-BSE2: LSBJ Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0365	LSB-BSE2: LSBJ Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0366	LSB-BSE2: LSBJ Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0367	LSB-BSE2: LSBJ Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0368	LSB-BSE2: LSBJ Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0369	LSB-BSE2: LSBJ Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C036A	LSB-BSE2: LSBJ Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C036B	LSB-BSE2: LSBJ Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C036C	LSB-BSE2: LSBJ Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0450	LSB-BSE2: LSBJ Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0451	LSB-BSE2: LSBJ Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0453	LSB-BSE2: LSBJ Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0454	LSB-BSE2: LSBJ Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0464	LSB-BSE2: LSBJ Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0465	LSB-BSE2: LSBJ Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0466	LSB-BSE2: LSBJ Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0467	LSB-BSE2: LSBJ Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0468	LSB-BSE2: LSBJ Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0469	LSB-BSE2: LSBJ Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C046A	LSB-BSE2: LSBJ Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C046B	LSB-BSE2: LSBJ Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C046C	LSB-BSE2: LSBJ Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0550	LSB-BSE2: LSBJ Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0551	LSB-BSE2: LSBJ Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0553	LSB-BSE2: LSBJ Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0554	LSB-BSE2: LSBJ Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0564	LSB-BSE2: LSBJ Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0565	LSB-BSE2: LSBJ Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0566	LSB-BSE2: LSBJ Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0567	LSB-BSE2: LSBJ Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0568	LSB-BSE2: LSBJ Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0569	LSB-BSE2: LSBJ Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C056A	LSB-BSE2: LSBJ Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C056B	LSB-BSE2: LSBJ Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C056C	LSB-BSE2: LSBJ Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0650	LSB-BSE2: LSBJ Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0651	LSB-BSE2: LSBJ Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0653	LSB-BSE2: LSBJ Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0654	LSB-BSE2: LSBJ Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0664	LSB-BSE2: LSBJ Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0665	LSB-BSE2: LSBJ Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0666	LSB-BSE2: LSBJ Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0667	LSB-BSE2: LSBJ Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0668	LSB-BSE2: LSBJ Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0669	LSB-BSE2: LSBJ Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C066A	LSB-BSE2: LSBJ Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C066B	LSB-BSE2: LSBJ Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C066C	LSB-BSE2: LSBJ Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0750	LSB-BSE2: LSBJ Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0751	LSB-BSE2: LSBJ Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0753	LSB-BSE2: LSBJ Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0754	LSB-BSE2: LSBJ Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0764	LSB-BSE2: LSBJ Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0765	LSB-BSE2: LSBJ Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0766	LSB-BSE2: LSBJ Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0767	LSB-BSE2: LSBJ Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0768	LSB-BSE2: LSBJ Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0769	LSB-BSE2: LSBJ Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C076A	LSB-BSE2: LSBJ Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C076B	LSB-BSE2: LSBJ Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C076C	LSB-BSE2: LSBJ Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0850	LSB-BSE2: LSBJ Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0851	LSB-BSE2: LSBJ Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0853	LSB-BSE2: LSBJ Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0854	LSB-BSE2: LSBJ Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0864	LSB-BSE2: LSBJ Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0865	LSB-BSE2: LSBJ Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0866	LSB-BSE2: LSBJ Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0867	LSB-BSE2: LSBJ Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0868	LSB-BSE2: LSBJ Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0869	LSB-BSE2: LSBJ Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C086A	LSB-BSE2: LSBJ Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C086B	LSB-BSE2: LSBJ Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C086C	LSB-BSE2: LSBJ Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0950	LSB-BSE2: LSBJ Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0951	LSB-BSE2: LSBJ Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0953	LSB-BSE2: LSBJ Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0954	LSB-BSE2: LSBJ Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0964	LSB-BSE2: LSBJ Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0965	LSB-BSE2: LSBJ Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0966	LSB-BSE2: LSBJ Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0967	LSB-BSE2: LSBJ Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0968	LSB-BSE2: LSBJ Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0969	LSB-BSE2: LSBJ Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C096A	LSB-BSE2: LSBJ Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C096B	LSB-BSE2: LSBJ Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C096C	LSB-BSE2: LSBJ Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0A50	LSB-BSE2: LSBJ Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0A51	LSB-BSE2: LSBJ Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0A53	LSB-BSE2: LSBJ Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0A54	LSB-BSE2: LSBJ Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0A64	LSB-BSE2: LSBJ Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0A65	LSB-BSE2: LSBJ Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0A66	LSB-BSE2: LSBJ Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0A67	LSB-BSE2: LSBJ Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0A68	LSB-BSE2: LSBJ Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0A69	LSB-BSE2: LSBJ Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0A6A	LSB-BSE2: LSBJ Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C0A6B	LSB-BSE2: LSBJ Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C0A6C	LSB-BSE2: LSBJ Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0B50	LSB-BSE2: LSBJ Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0B51	LSB-BSE2: LSBJ Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0B53	LSB-BSE2: LSBJ Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0B54	LSB-BSE2: LSBJ Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0B64	LSB-BSE2: LSBJ Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0B65	LSB-BSE2: LSBJ Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0B66	LSB-BSE2: LSBJ Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0B67	LSB-BSE2: LSBJ Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0B68	LSB-BSE2: LSBJ Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0B69	LSB-BSE2: LSBJ Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C0B6A	LSB-BSE2: LSBJ Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C0B6B	LSB-BSE2: LSBJ Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C0B6C	LSB-BSE2: LSBJ Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0C50	LSB-BSE2: LSBJ Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0C51	LSB-BSE2: LSBJ Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0C53	LSB-BSE2: LSBJ Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0C54	LSB-BSE2: LSBJ Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0C64	LSB-BSE2: LSBJ Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0C65	LSB-BSE2: LSBJ Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0C66	LSB-BSE2: LSBJ Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0C67	LSB-BSE2: LSBJ Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0C68	LSB-BSE2: LSBJ Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0C69	LSB-BSE2: LSBJ Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C0C6A	LSB-BSE2: LSBJ Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C0C6B	LSB-BSE2: LSBJ Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C0C6C	LSB-BSE2: LSBJ Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0D50	LSB-BSE2: LSBJ Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0D51	LSB-BSE2: LSBJ Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0D53	LSB-BSE2: LSBJ Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0D54	LSB-BSE2: LSBJ Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0D64	LSB-BSE2: LSBJ Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0D65	LSB-BSE2: LSBJ Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0D66	LSB-BSE2: LSBJ Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0D67	LSB-BSE2: LSBJ Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0D68	LSB-BSE2: LSBJ Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0D69	LSB-BSE2: LSBJ Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C0D6A	LSB-BSE2: LSBJ Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0D6B	LSB-BSE2: LSBJ Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C0D6C	LSB-BSE2: LSBJ Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0E50	LSB-BSE2: LSBJ Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0E51	LSB-BSE2: LSBJ Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0E53	LSB-BSE2: LSBJ Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0E54	LSB-BSE2: LSBJ Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0E64	LSB-BSE2: LSBJ Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C0E65	LSB-BSE2: LSBJ Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0E66	LSB-BSE2: LSBJ Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0E67	LSB-BSE2: LSBJ Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0E68	LSB-BSE2: LSBJ Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0E69	LSB-BSE2: LSBJ Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C0E6A	LSB-BSE2: LSBJ Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C0E6B	LSB-BSE2: LSBJ Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C0E6C	LSB-BSE2: LSBJ Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C0F50	LSB-BSE2: LSBJ Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C0F51	LSB-BSE2: LSBJ Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C0F53	LSB-BSE2: LSBJ Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C0F54	LSB-BSE2: LSBJ Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C0F64	LSB-BSE2: LSBJ Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C0F65	LSB-BSE2: LSBJ Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C0F66	LSB-BSE2: LSBJ Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C0F67	LSB-BSE2: LSBJ Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C0F68	LSB-BSE2: LSBJ Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C0F69	LSB-BSE2: LSBJ Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C0F6A	LSB-BSE2: LSBJ Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C0F6B	LSB-BSE2: LSBJ Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C0F6C	LSB-BSE2: LSBJ Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1050	LSB-BSE2: LSBJ Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1051	LSB-BSE2: LSBJ Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1053	LSB-BSE2: LSBJ Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1054	LSB-BSE2: LSBJ Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1064	LSB-BSE2: LSBJ Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1065	LSB-BSE2: LSBJ Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1066	LSB-BSE2: LSBJ Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1067	LSB-BSE2: LSBJ Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1068	LSB-BSE2: LSBJ Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1069	LSB-BSE2: LSBJ Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C106A	LSB-BSE2: LSBJ Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C106B	LSB-BSE2: LSBJ Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C106C	LSB-BSE2: LSBJ Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1150	LSB-BSE2: LSBJ Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1151	LSB-BSE2: LSBJ Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1153	LSB-BSE2: LSBJ Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1154	LSB-BSE2: LSBJ Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1164	LSB-BSE2: LSBJ Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1165	LSB-BSE2: LSBJ Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1166	LSB-BSE2: LSBJ Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1167	LSB-BSE2: LSBJ Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1168	LSB-BSE2: LSBJ Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1169	LSB-BSE2: LSBJ Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C116A	LSB-BSE2: LSBJ Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C116B	LSB-BSE2: LSBJ Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C116C	LSB-BSE2: LSBJ Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1250	LSB-BSE2: LSBJ Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1251	LSB-BSE2: LSBJ Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1253	LSB-BSE2: LSBJ Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1254	LSB-BSE2: LSBJ Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1264	LSB-BSE2: LSBJ Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1265	LSB-BSE2: LSBJ Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1266	LSB-BSE2: LSBJ Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1267	LSB-BSE2: LSBJ Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1268	LSB-BSE2: LSBJ Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1269	LSB-BSE2: LSBJ Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C126A	LSB-BSE2: LSBJ Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C126B	LSB-BSE2: LSBJ Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C126C	LSB-BSE2: LSBJ Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1350	LSB-BSE2: LSBJ Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1351	LSB-BSE2: LSBJ Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1353	LSB-BSE2: LSBJ Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1354	LSB-BSE2: LSBJ Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1364	LSB-BSE2: LSBJ Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1365	LSB-BSE2: LSBJ Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1366	LSB-BSE2: LSBJ Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1367	LSB-BSE2: LSBJ Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1368	LSB-BSE2: LSBJ Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1369	LSB-BSE2: LSBJ Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C136A	LSB-BSE2: LSBJ Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C136B	LSB-BSE2: LSBJ Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C136C	LSB-BSE2: LSBJ Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1450	LSB-BSE2: LSBJ Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1451	LSB-BSE2: LSBJ Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1453	LSB-BSE2: LSBJ Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1454	LSB-BSE2: LSBJ Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1464	LSB-BSE2: LSBJ Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1465	LSB-BSE2: LSBJ Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1466	LSB-BSE2: LSBJ Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1467	LSB-BSE2: LSBJ Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1468	LSB-BSE2: LSBJ Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1469	LSB-BSE2: LSBJ Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C146A	LSB-BSE2: LSBJ Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C146B	LSB-BSE2: LSBJ Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C146C	LSB-BSE2: LSBJ Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1550	LSB-BSE2: LSBJ Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1551	LSB-BSE2: LSBJ Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1553	LSB-BSE2: LSBJ Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1554	LSB-BSE2: LSBJ Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1564	LSB-BSE2: LSBJ Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1565	LSB-BSE2: LSBJ Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1566	LSB-BSE2: LSBJ Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1567	LSB-BSE2: LSBJ Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1568	LSB-BSE2: LSBJ Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1569	LSB-BSE2: LSBJ Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C156A	LSB-BSE2: LSBJ Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C156B	LSB-BSE2: LSBJ Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C156C	LSB-BSE2: LSBJ Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1650	LSB-BSE2: LSBJ Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1651	LSB-BSE2: LSBJ Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1653	LSB-BSE2: LSBJ Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1654	LSB-BSE2: LSBJ Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1664	LSB-BSE2: LSBJ Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1665	LSB-BSE2: LSBJ Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1666	LSB-BSE2: LSBJ Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1667	LSB-BSE2: LSBJ Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1668	LSB-BSE2: LSBJ Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1669	LSB-BSE2: LSBJ Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C166A	LSB-BSE2: LSBJ Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C166B	LSB-BSE2: LSBJ Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C166C	LSB-BSE2: LSBJ Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1750	LSB-BSE2: LSBJ Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1751	LSB-BSE2: LSBJ Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1753	LSB-BSE2: LSBJ Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1754	LSB-BSE2: LSBJ Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1764	LSB-BSE2: LSBJ Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1765	LSB-BSE2: LSBJ Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1766	LSB-BSE2: LSBJ Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1767	LSB-BSE2: LSBJ Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1768	LSB-BSE2: LSBJ Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1769	LSB-BSE2: LSBJ Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C176A	LSB-BSE2: LSBJ Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C176B	LSB-BSE2: LSBJ Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C176C	LSB-BSE2: LSBJ Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1850	LSB-BSE2: LSBJ Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1851	LSB-BSE2: LSBJ Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1853	LSB-BSE2: LSBJ Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1854	LSB-BSE2: LSBJ Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1864	LSB-BSE2: LSBJ Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1865	LSB-BSE2: LSBJ Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1866	LSB-BSE2: LSBJ Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1867	LSB-BSE2: LSBJ Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1868	LSB-BSE2: LSBJ Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1869	LSB-BSE2: LSBJ Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C186A	LSB-BSE2: LSBJ Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C186B	LSB-BSE2: LSBJ Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C186C	LSB-BSE2: LSBJ Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1A50	LSB-BSE2: LSBJ Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1A51	LSB-BSE2: LSBJ Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1A53	LSB-BSE2: LSBJ Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1A54	LSB-BSE2: LSBJ Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1A64	LSB-BSE2: LSBJ Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1A65	LSB-BSE2: LSBJ Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1A66	LSB-BSE2: LSBJ Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1A67	LSB-BSE2: LSBJ Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1A68	LSB-BSE2: LSBJ Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1A69	LSB-BSE2: LSBJ Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C1A6A	LSB-BSE2: LSBJ Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C1A6B	LSB-BSE2: LSBJ Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C1A6C	LSB-BSE2: LSBJ Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1B50	LSB-BSE2: LSBJ Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1B51	LSB-BSE2: LSBJ Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1B53	LSB-BSE2: LSBJ Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1B54	LSB-BSE2: LSBJ Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1B64	LSB-BSE2: LSBJ Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1B65	LSB-BSE2: LSBJ Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1B66	LSB-BSE2: LSBJ Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1B67	LSB-BSE2: LSBJ Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1B68	LSB-BSE2: LSBJ Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1B69	LSB-BSE2: LSBJ Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C1B6A	LSB-BSE2: LSBJ Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C1B6B	LSB-BSE2: LSBJ Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1B6C	LSB-BSE2: LSBJ Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1C50	LSB-BSE2: LSBJ Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1C51	LSB-BSE2: LSBJ Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1C53	LSB-BSE2: LSBJ Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1C54	LSB-BSE2: LSBJ Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1C64	LSB-BSE2: LSBJ Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1C65	LSB-BSE2: LSBJ Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1C66	LSB-BSE2: LSBJ Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1C67	LSB-BSE2: LSBJ Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1C68	LSB-BSE2: LSBJ Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1C69	LSB-BSE2: LSBJ Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C1C6A	LSB-BSE2: LSBJ Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C1C6B	LSB-BSE2: LSBJ Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C1C6C	LSB-BSE2: LSBJ Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1D50	LSB-BSE2: LSBJ Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1D51	LSB-BSE2: LSBJ Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1D53	LSB-BSE2: LSBJ Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C1D54	LSB-BSE2: LSBJ Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1D64	LSB-BSE2: LSBJ Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1D65	LSB-BSE2: LSBJ Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1D66	LSB-BSE2: LSBJ Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1D67	LSB-BSE2: LSBJ Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1D68	LSB-BSE2: LSBJ Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1D69	LSB-BSE2: LSBJ Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C1D6A	LSB-BSE2: LSBJ Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C1D6B	LSB-BSE2: LSBJ Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C1D6C	LSB-BSE2: LSBJ Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C1E50	LSB-BSE2: LSBJ Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C1E51	LSB-BSE2: LSBJ Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C1E53	LSB-BSE2: LSBJ Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C1E54	LSB-BSE2: LSBJ Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C1E64	LSB-BSE2: LSBJ Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C1E65	LSB-BSE2: LSBJ Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C1E66	LSB-BSE2: LSBJ Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C1E67	LSB-BSE2: LSBJ Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C1E68	LSB-BSE2: LSBJ Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C1E69	LSB-BSE2: LSBJ Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C1E6A	LSB-BSE2: LSBJ Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C1E6B	LSB-BSE2: LSBJ Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C1E6C	LSB-BSE2: LSBJ Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C2052	LSB-BSE2: Control data transfer LSBJ has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A362		E	0
2C2055	LSB-BSE2: Control data transfer LSBJ Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362		E	2
2C2056	LSB-BSE2: Control data transfer LSBJ Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A362		E	2
2C2057	LSB-BSE2: Control data transfer LSBJ has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A362		E	1
2C2058	LSB-BSE2: Control data transfer LSBJ recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A362		E	0
2C2059	LSB-BSE2: Control data transfer LSBJ recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A362		E	0
2C2060	LSB-BSE2: Control data transfer LSBJ driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A362		E	2
2C2061	LSB-BSE2: Control data transfer LSBJ driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A362		E	2
2C2062	LSB-BSE2: Control data transfer LSBJ Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A362		E	2
2C3050	LSB-BSE2: LSBK Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C3051	LSB-BSE2: LSBK Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C3053	LSB-BSE2: LSBK Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C3054	LSB-BSE2: LSBK Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C3064	LSB-BSE2: LSBK Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C3065	LSB-BSE2: LSBK Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C3066	LSB-BSE2: LSBK Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C3067	LSB-BSE2: LSBK Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C3068	LSB-BSE2: LSBK Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C3069	LSB-BSE2: LSBK Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C306A	LSB-BSE2: LSBK Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C306B	LSB-BSE2: LSBK Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C306C	LSB-BSE2: LSBK Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C6050	LSB-BSE2: LSBL Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C6051	LSB-BSE2: LSBL Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C6053	LSB-BSE2: LSBL Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C6054	LSB-BSE2: LSBL Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C6064	LSB-BSE2: LSBL Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1
2C6065	LSB-BSE2: LSBL Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C6066	LSB-BSE2: LSBL Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C6067	LSB-BSE2: LSBL Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C6068	LSB-BSE2: LSBL Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C6069	LSB-BSE2: LSBL Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C606A	LSB-BSE2: LSBL Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C606B	LSB-BSE2: LSBL Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C606C	LSB-BSE2: LSBL Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2C9050	LSB-BSE2: LSBM Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A362		E	2
2C9051	LSB-BSE2: LSBM Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A362		E	2
2C9053	LSB-BSE2: LSBM Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A362		E	1
2C9054	LSB-BSE2: LSBM Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A362		E	2
2C9064	LSB-BSE2: LSBM Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2C9065	LSB-BSE2: LSBM Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A362		E	2
2C9066	LSB-BSE2: LSBM Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A362		E	2
2C9067	LSB-BSE2: LSBM Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A362		E	1
2C9068	LSB-BSE2: LSBM Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A362		E	1
2C9069	LSB-BSE2: LSBM Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A362		E	1
2C906A	LSB-BSE2: LSBM Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A362		E	2
2C906B	LSB-BSE2: LSBM Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A362		E	2
2C906C	LSB-BSE2: LSBM Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A362		E	2
2D0058	LSB-BSE2: LMB Consistency test between length sensor and track recog. erroneous Only error message Check sensor	A362		E	1
2D006A	LSB-BSE2: LMB Measuring sleeve defective/missing 2 hook weighing poss. inaccurate Error message. 2-hook weighing with pull test bracket poss. inaccurate Check sensor	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D007B	LSB-BSE2: LMB LMB1 not synchronous with LMB2 error report Correct operand on respective BSE	A362		E	1
2D0129	LSB-BSE2: LMB STOP, length indicator derrick counterweight faulty/not present LMB-STOP with error message Check length sensor of ballast sliding cylinder and replace if nec.	A362		E	1
2D0133	LSB-BSE2: LMB fly jib retaining cylinder inferior minimal pressure If main boom is above 10 degrees or relapse cyl. run together on limit switch, shut off occurs When RFP-pressure in test position not in tolerance window, replace RFP, otherwise check job rods	A362		E	1
2D0134	LSB-BSE2: LMB fly jib retaining cylinder exceeds maximum pressure If main boom is above 10 degrees or relapse cyl. run together on limit switch, shut off occurs When RFP-pressure in test position not in tolerance window, replace RFP, otherwise check job rods	A362		E	1
2D014F	LSB-BSE2: LMB STOP, load chart has development status Error message with LMB-Stop Load new load charts or new crane. Disclose all error parameters to customer service	A362		E	1
2D015D	LSB-BSE2: LMB Set up condition defective: manual pinning last telescope Error message with LMB-Stop Check manual pinning, check possible sensor	A362		E	1
2D015E	LSB-BSE2: LMB Set up condition faulty: Main boom not correctly detected. Error message with LMB-Stop Check set up condition	A362		E	1
2D015F	LSB-BSE2: LMB Set up condition faulty: Accessories not correctly detected. Error message with LMB-Stop Check set up condition	A362		E	1
2D0160	LSB-BSE2: LMB Set up condition faulty: Accessory angle not correct. Error message with LMB-Stop Check set up condition, check angle sensor	A362		E	1
2D01A0	LSB-BSE2: LMB Load display in TY-operation incorrect; Y-angle sensor erroneous error report Report all error parameters to Service	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D01AA	LSB-BSE2: LMB Force measuring point accessories implausible LMB-STOP with error message Check measuring point	A362		E	1
2D020C	LSB-BSE2: LMB STOP, Boom nose set up but dummy plug plugged in LMB-Stop Plug in boom nose and remove dummy plug or remove boom nose	A362			
2D0229	LSB-BSE2: LMB STOP, SA-frame assembly cylinder extended too far (limit switch) Error message with LMB-Stop Move assembly cylinder out from block position	A362		B	1
2D022A	LSB-BSE2: LMB Angle sensor SA-bracket deviates from theor. angle impermissible Only error message Check angle sensor SA-frame, replace if nec.; possibly incorrect main boom length set up, therefore incorrect angle valu	A362		E	1
2D022B	LSB-BSE2: LMB Stop, limit switch SA cyl. defect.. Block position is not recognized Error message with LMB-Stop Check SA-inductive switch for block pos.	A362		E	1
2D025A	LSB-BSE2: LMB STOP, pressure sensor, piston surface luffing cyl. different values LMB-Stop Check pressure sensor on luffing cylinder	A362		E	1
2D025B	LSB-BSE2: LMB STOP, Pressure sensor ring surface luffing cyl. uneven values LMB-Stop Check pressure sensor on luffing cylinder	A362		E	1
2D026F	LSB-BSE2: LMB Stop, Ballast weighing not possible since LG defect	A362			
2D0270	LSB-BSE2: LMB Measured ballast weight negative LMB-Stop Check pressure sensor in ballast lift cyl.	A362		E	1
2D0271	LSB-BSE2: LMB Value difference too large in test points for ballast lift cyl. Report to SPS Rerun to match pulled forces in ballast lift cyl.	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D0272	LSB-BSE2: LMB Pulled ballast weight exceeded the equipped ballast LMB-Stop In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A362		E	1
2D0273	LSB-BSE2: LMB STOP, Ballast suspended at insufficiently low pulled ballast weight LMB-Stop In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A362		E	1
2D0274	LSB-BSE2: LMB Force on F1 less than expected Only error message Check test points and pressure sensors for relapse cyl. of derrick	A362		E	1
2D0275	LSB-BSE2: LMB Force on F1 larger than expected Only error message Check test points and pressure sensors for relapse cyl. of derrick	A362		E	1
2D0276	LSB-BSE2: LMB Difference of parallel pull test brackets too large LMB-Stop Check pull test brackets of corr. test point (par. 2); if nec. elim. side pull to guying	A362		E	1
2D0277	LSB-BSE2: LMB Difference of serial pull test brackets too large LMB-Stop Check pull test brackets in the respective test point (Parameter 2)	A362		E	1
2D0278	LSB-BSE2: LMB Difference or pressure sensor on derrick-RFPs exceeded tolerance Only error message Check relapse cyl., as well as their pressure sensors on derrick	A362		E	1
2D0279	LSB-BSE2: LMB Ballast weighing not possible. Hoist cyl. on block or LG not ok. Only error message Retrat or extend ballast hoist cyl. so that there is sufficient distance to block pos. or check length sensor	A362		E	1
2D027A	LSB-BSE2: LMB No derrick momentum calculation, since pulled ballast not determinable Only error message This is most often a subsequent error, therefore fix previous error w/respect to ballast hoist cylinder and susp. ballas	A362		E	1
2D027B	LSB-BSE2: LMB Difference of left/right boom relapse cyl. too large LMB-Stop Check main boom relapse cyl. as well as their pressure sensors and test axles	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D027C	LSB-BSE2: LMB No hoist winch is assigned to main hook Only error message The assignment of winch in config. screen must be checked	A362		E	1
2D027D	LSB-BSE2: LMB Ballast suspended even though set up ballast not yet reached Only error message In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A362		E	1
2D027E	LSB-BSE2: LMB STOP, pressure sensor ad KMA on boom relapse cyl. not ok LMB-Stop Check pressure sensors and force test axles on main boom relapse cyl	A362		E	1
2D027F	LSB-BSE2: LMB Pressure sensor on boom relapse cyl. not ok Only error message Check pressure sensor on main boom relapse cyl	A362		E	1
2D0280	LSB-BSE2: LMB Force test axles on boom relapse cyl. not ok Only error message Check force test axles on main boom relapse cyl	A362		E	1
2D0281	LSB-BSE2: LMB Pressure sensor piston side on ballast lift cyl. defective Only error message Replace pressure sensor	A362		E	1
2D0282	LSB-BSE2: LMB Length sensor ballast lift cyl. defective. Calculation with incline se Only error message Replace length sensor	A362		E	1
2D0283	LSB-BSE2: LMB Guying of rocker too short or too long, check guying! Only error message Check assembly of guying. Possible increased sagging due to assembly procedure	A362		E	1
2D0284	LSB-BSE2: LMB Inner angle accessories not in tolerance range. Incorrect assembly? Only error message Check assembly of guying, possibly increased sag, for ex. due to assembly procedure	A362			
2D0285	LSB-BSE2: LMB Guying main boom too short or too long, check guying Only error message Check assembly of guying, possibly increased sag, for ex. due to assembly procedure	A362			

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D0287	LSB-BSE2: LMB No weighing possible. HA-guying is possible placed in part Only error message possibly luff up Derrick / SA-luffing gear	A362		B	1
2D0288	LSB-BSE2: LMB KMA defective. Pressure sensors are used. Weighing possibly too high.. Only error message Check force test axle in S-relapse cyl., possibly replace force test axle	A362		E	1
2D0289	LSB-BSE2: LMB Sensor of RFP defective. Weighing is increased if RFP engaged Only error message Check pressure sensors in S-relapse cyl., possibly replace pressure sensors	A362		E	1
2D02A0	LSB-BSE2: LMB RFP-Block limit switch HA defect. Weighing in RFP-access pt. too high Only error message Check inductive sensors in S-relapse cyl., poss. replace inductive sensors	A362		E	1
2D02A1	LSB-BSE2: LMB RFP HA on block. Weighing too high? HA above 80 degr on luffing Only error message Main boom luffing up to over 80 degree	A362		E	1
2D02B0	LSB-BSE2: LMB STOP, Ballast recognition: one / sev. sensors not recognized Error message and LMB stop Check sensor, replace if necessary	A362		E	1
2D02B1	LSB-BSE2: LMB STOP, ballast detection: Ballast no.1 missing for set up condition Error message and LMB stop Check ballast coding	A362		B	1
2D02B2	LSB-BSE2: LMB STOP, ballast detection: Ballast no.2 missing for set up condition Error message and LMB stop Check ballast coding	A362		B	1
2D02B3	LSB-BSE2: LMB STOP, ballast detection: Ballast no.3 missing for set up condition Error message and LMB stop Check ballast coding	A362		B	1
2D02B4	LSB-BSE2: LMB STOP, ballast detection: Ballast no.4 missing for set up condition Error message and LMB stop Check ballast coding	A362		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D02B5	LSB-BSE2: LMB STOP, ballast detection: Ballast no.5 missing for set up condition Error message and LMB stop Check ballast coding	A362		B	1
2D02B6	LSB-BSE2: LMB STOP, ballast detection: Ballast no.6 missing for set up condition Error message and LMB stop Check ballast coding	A362		B	1
2D02C0	LSB-BSE2: LMB STOP, ballast detection: ballast not as set up Error message and LMB stop Check ballast radius	A362		B	1
2D02C1	LSB-BSE2: LMB STOP, ballast detection: Ballast no.1 may not be detected Error message and LMB stop Check ballast coding	A362		B	1
2D02C2	LSB-BSE2: LMB STOP, ballast detection: Ballast no.2 may not be detected Error message and LMB stop Check ballast coding	A362		B	1
2D02C3	LSB-BSE2: LMB STOP, ballast detection: Ballast no.3 may not be detected Error message and LMB stop Check ballast coding	A362		B	1
2D02C4	LSB-BSE2: LMB STOP, ballast detection: Ballast no.4 may not be detected Error message and LMB stop Check ballast coding	A362		B	1
2D02C5	LSB-BSE2: LMB STOP, ballast detection: Ballast no.5 may not be detected Error message and LMB stop Check ballast coding	A362		B	1
2D02C6	LSB-BSE2: LMB STOP, ballast detection: Ballast no.6 may not be detected Error message and LMB stop Check ballast coding	A362		B	1
2D0300	LSB-BSE2: LMB STOP save error (Note parameter) LMB-Stop Report all error parameters to Service	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D0301	LSB-BSE2: LMB Save error (Note parameter) error report Report all error parameters to Service	A362		E	1
2D0310	LSB-BSE2: LMB STOP no weighing, reeving insufficient or lever arm cond. LMB-Stop Increase reeving	A362		E	1
2D0311	LSB-BSE2: LMB STOP chart values for SRFP not available Error message and LMB stop Report all error parameters to Service	A362		E	1
2D0312	LSB-BSE2: LMB STOP WG on main boom defective, SRPF nominal value can't be determined Error message and LMB stop Check angle sensor on main boom	A362		E	1
2D0317	LSB-BSE2: LMB STOP, max. superstructure length incline exceeded LMB-Stop Support crane horizontally	A362		E	1
2D0318	LSB-BSE2: LMB STOP, max. superstructure lateral incline exceeded LMB-Stop Support crane horizontally	A362		E	1
2D0319	LSB-BSE2: LMB STOP, max. chassis incline exceeded LMB-Stop Support crane horizontally	A362		E	1
2D031A	LSB-BSE2: LMB STOP, maximum chassis length incline exceeded LMB-Stop Support crane horizontally	A362		E	1
2D031B	LSB-BSE2: LMB STOP, maximum chassis cross incline exceeded LMB-Stop Support crane horizontally	A362		E	1
2D031C	LSB-BSE2: LMB STOP, Number of last activated winch invalid LMB-Stop Initiate momentary movement down with one hoist winch	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D031D	LSB-BSE2: LMB STOP, no winch is assigned to setting LMB-Stop Assignment of winches in geometry must be checked, possible also check in set up screen	A362		E	1
2D0355	LSB-BSE2: LMB STOP at last operation no pin information saved LMB-Stop Place manually or pin in retracted last telescope	A362		E	1
2D0356	LSB-BSE2: LMB STOP pin condition inconsistent, no tele pin hole found LMB-Stop Report all error parameters to Service	A362		E	1
2D0357	LSB-BSE2: LMB STOP pin condition inconsistent, no valid condition loadable LMB-Stop Report all error parameters to Service	A362		E	1
2D0358	LSB-BSE2: LMB STOP pin condition inconsistent, Telescope not reachable LMB-Stop Report all error parameters to Service	A362		E	1
2D0359	LSB-BSE2: LMB STOP Length s. defective to pinning point, tele length not valid LMB-Stop Report all error parameters to Service	A362		E	1
2D035A	LSB-BSE2: LMB STOP Pin condition Tele/cylinder inconsistent or no signal LMB-Stop Report all error parameters to Service	A362		E	1
2D035C	LSB-BSE2: LMB STOP Length sensor tele cyl. larger than max. cyl. stroke LMB-Stop Report all error parameters to Service	A362		E	1
2D035D	LSB-BSE2: LMB STOP Length sensor tele cyl. smaller Null LMB-Stop Report all error parameters to Service	A362		E	1
2D0371	LSB-BSE2: LMB STOP second LMB delivers other result LMB-Stop can occur as follow up error at a LMB-Stop auftreten	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D03A0	LSB-BSE2: LMB Pressure sensor RFP-Main boom does not match force test axle Only error message Check relapse cyl. on main boom	A362		E	1
2D03A1	LSB-BSE2: LMB Difference too large: Derrick angle sensor top and bottom LMB-Stop Check or replace angle sensor on derrick	A362		E	1
2D03A2	LSB-BSE2: LMB STOP, pressure sensor or KMA on boom-RFP not ok LMB-Stop Check main boom relapse cyl., as well as their pressure sensor and test axles	A362			
2D03A3	LSB-BSE2: LMB Difference of boom angle sensors too large LMB-Stop Check angle sensor on main boom	A362		E	1
2D0571	LSB-BSE2: remote control telescoping movement selected in manual operation	A362		B	
2D0612	LSB-BSE2: Data recorder Start: not connected No recording possible! Check data logger in 1 sec. interval Connect data logger, if necessary, check connection from LICCON system to data logger	A362		E	1
2D0620	LSB-BSE2: Data recorder Init: Firmware version incorrect/faulty Has not yet been checked! Report all error parameters to Service	A362		E	1
2D0621	LSB-BSE2: Data recorder Init: ATA-card not initialised STATUS-error: Data recorder software stops - no documentation possible! Initialize ATA-Card with PC-Software 'LICCON Manager'	A362		E	1
2D0622	LSB-BSE2: Data recorder Init: ATA-card contains different crane number STATUS-error: Data recorder software stops - no documentation possible! Use ATA card with correct crane number or newly initialised ATA card	A362		E	1
2D0623	LSB-BSE2: Data recorder Init: Format-File-Transfer faulty Repeat of Format-File transfers in 1 sec. cycles If necessary, correct type and country specific format file 'Lnnttt01vrrr.Q' in EPROM 0	A362		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D0630	LSB-BSE2: Data recorder Transfer: Data transmission faulty Repeat of data transfers in 1 sec. cycles If necessary check connection from LICCON system to data recorder	A362		E	1
2D0631	LSB-BSE2: Data recorder Transfer: CSM-protocol error Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A362		E	1
2D0632	LSB-BSE2: Data recorder Transfer: Transmission error (CRC) Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A362		E	1
2D0633	LSB-BSE2: Data recorder Transfer: STATUS-error Resynchronize depending on STATUS in 1 sec.interval If necessary check connection from LICCON system to data recorder	A362		E	1
2D0634	LSB-BSE2: Data recorder Transfer: TAN-error Synchronise CSM protocol again completely If necessary check connection from LICCON system to data recorder	A362		E	1
2D0635	LSB-BSE2: Data recorder Transfer: Writing error Synchronise CSM protocol again completely If necessary check connection from LICCON-System to data recorder and ATA card	A362		E	1
2D0849	LSB-BSE2: Operating hours counter urgent modul, ZE not available error report Report all error parameters to Service	A362		E	2
2D0878	LSB-BSE2: Operating hours counter impermissible parameter Error message, Parameter is possibly set to min or max Software update required, report all error parameter to Service Dept.	A362		E	2
2D094A	LSB-BSE2: Operating data protection not possible. Module missing, communication to module is erroneous error report In LICCON REMOTE DIAGNOSTICS - LSB DIAGNOSTICS localize missing LSB modules. Disclose all parameters to customer service	A362		E	2
2D0978	LSB-BSE2: Operating data protection impermissible parameter error report Software update required, report all error parameter to Service Dept.	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D1200	LSB-BSE2: LPC No allocation for write cache requirement error report Reprogramming	A362		E	1
2D1201	LSB-BSE2: LPC Variable not available or connected error report Reprogramming	A362		E	1
2D1202	LSB-BSE2: LPC No write buffer release error report Reprogramming	A362		E	1
2D1203	LSB-BSE2: LPC Error at connection of one variable error report Reprogramming	A362		E	1
2D3001	LSB-BSE2: control winch 1 feed pressure supply missing/too low	A362		E	
2D3017	LSB-BSE2: control winch 1 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A362		E	
2D3018	LSB-BSE2: control winch 1 Pressure too high when pump is not actuated operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		E	
2D3101	LSB-BSE2: control winch 2 feed pressure supply missing/too low	A362		E	
2D3117	LSB-BSE2: control winch 2 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A362		E	
2D3118	LSB-BSE2: control winch 2 Pressure too high when pump is not actuated	A362		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D3201	LSB-BSE2: control winch 3 feed pressure supply missing/too low Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		E	
2D3217	LSB-BSE2: control winch 3 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A362		E	
2D3218	LSB-BSE2: control winch 3 Pressure too high when pump is not actuated Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		E	
2D3222	LSB-BSE2: control winch 3 Winch not actuated and brake not completely applied Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D3248	LSB-BSE2: control winch 3 Caution winch gear oil level too low Output of error Add oil. When actual oil level is OK and error is still shown, check sensor for function	A362		E	
2D324B	LSB-BSE2: control winch 3 Notice oil level measurement not possible derrick not in angle window Output of error Set the derrick in the angle window between 112.0° and 116.0°	A362		E	
2D325C	LSB-BSE2: control winch 3 Shutdown monitoring winch brake short circuit to VCC or mass Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D325E	LSB-BSE2: control winch 3 Shutdown winch brake applied with activated pump Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D3301	LSB-BSE2: control winch 4 feed pressure supply missing/too low Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		E	
2D3317	LSB-BSE2: control winch 4 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A362		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D3318	LSB-BSE2: control winch 4 Pressure too high when pump is not actuated Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		E	
2D3322	LSB-BSE2: control winch 4 Winch not actuated and brake not completely applied Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D3349	LSB-BSE2: control winch 4 Caution winch gear oil level left too low Output of error Add oil. When actual oil level is OK and error is still shown, check sensor for function	A362		E	
2D334A	LSB-BSE2: control winch 4 Caution winch gear oil level right too low Output of error Add oil. When actual oil level is OK and error is still shown, check sensor for function	A362		E	
2D335C	LSB-BSE2: control winch 4 Shutdown monitoring winch brake short circuit to VCC or mass Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D335E	LSB-BSE2: control winch 4 Shutdown winch brake applied with activated pump Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D3401	LSB-BSE2: control winch 5 feed pressure supply missing/too low	A362		E	
2D3417	LSB-BSE2: control winch 5 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A362		E	
2D3418	LSB-BSE2: control winch 5 Pressure too high when pump is not actuated operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A362		E	
2D341D	LSB-BSE2: control winch 5 Flap in position at angle threshold fallen below	A362		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D3422	LSB-BSE2: control winch 5 Winch not actuated and brake not completely applied Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D3448	LSB-BSE2: control winch 5 Caution winch gear oil level too low Output of error Add oil. When actual oil level is OK and error is still shown, check sensor for function	A362		E	
2D345C	LSB-BSE2: control winch 5 Shutdown monitoring winch brake short circuit to VCC or mass Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D345E	LSB-BSE2: control winch 5 Shutdown winch brake applied with activated pump Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D3501	LSB-BSE2: control winch 6 feed pressure supply missing/too low	A362		E	
2D3517	LSB-BSE2: control winch 6 Brake pressure exists and brake is not actuated Output of error Check pump or pressure sensor	A362		E	
2D3518	LSB-BSE2: control winch 6 Pressure too high when pump is not actuated operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		E	
2D3522	LSB-BSE2: control winch 6 Winch not actuated and brake not completely applied Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D3548	LSB-BSE2: control winch 6 Caution winch gear oil level too low Output of error Add oil. When actual oil level is OK and error is still shown, check sensor for function	A362		E	
2D355C	LSB-BSE2: control winch 6 Shutdown monitoring winch brake short circuit to VCC or mass Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D355E	LSB-BSE2: control winch 6 Shutdown winch brake applied with activated pump Output of error, crane function is not selected. Check wiring winch brake monitor	A362		E	
2D3820	LSB-BSE2: control slewing Pressure switch Slewing brake reports open even though not actuated	A362		E	1
2D3B00	LSB-BSE2: Control ballasting / counterweight carriage Limit switch "BW bolted" faulty / not present - Shut-down BW active Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Error remedy see corresponding system error.	A362		E	
2D3B01	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and FB inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following earthing or line interruption, checking of inputs.	A362		E	
2D3B02	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted and FB inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A362		E	
2D3B03	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and bolted and FB inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A362		E	
2D3B04	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - B inserted and FB not inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following supply voltage or earthing or line interruption.	A362		E	
2D3B05	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and B inserted Shut-down due to unclear recognition of assembly condition. Check of cabling - short-circuit following supply voltage or earthing or line interruption.	A362		E	
2D3B06	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A362		E	
2D3B07	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - BW inserted and bolted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A362		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D3B08	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - BW bolted FB inserted and B inserted Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A362		E	
2D3B09	LSB-BSE2: Control ballasting / counterweight carriage Invalid assembly condition - entry combination does not make sense Shut-down due to unclear recognition of assembly condition. Checking of cabling - short-circuit following earthing or line interruption or check position of bolting cylinder BW	A362		E	
2D3B20	LSB-BSE2: Control ballasting / counterweight carriage Warning Limit switch Ballast cyl Block left erroneous / missing Issuance of error, crane function is not actuated Check LSB-sensor, check wiring, note system error	A362		E	
2D3B21	LSB-BSE2: Control ballasting / counterweight carriage Warning Limit switch Ballast cyl Block right erroneous / missing Issuance of error, crane function is not actuated Check LSB-sensor, check wiring, note system error	A362		E	
2D3B22	LSB-BSE2: Control ballasting / counterweight carriage Warning length sensor Ballast cyl left erroneous / missing Issuance of error, crane function is not actuated Check LSB-sensor, check wiring, note system error	A362		E	
2D3B23	LSB-BSE2: Control ballasting / counterweight carriage Warning length sensor Ballast cyl right erroneous / missing Issuance of error, crane function is not actuated Check LSB-sensor, check wiring, note system error	A362		E	
2D3C17	LSB-BSE2: Control crawler Pressure switch brake reports pressure with crawler not actuated Operational shut off Bring foot pedal in zero pos., check brake pr. crawler	A362		E	
2D3CA5	LSB-BSE2: Control crawler Signals slewing platform position to front / to rear implausibel Error is shown as system error Check wiring, switch position to rear or front must supply a signal	A362		E	
2D3F09	LSB-BSE2: crane control Pilot contact Derrick installed und LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F0A	LSB-BSE2: crane control Pilot contact Derrick not installed und LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D3F0B	LSB-BSE2: crane control Pilot contact main boom installed und LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F0C	LSB-BSE2: crane control Pilot contact main boom not installed und LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F0D	LSB-BSE2: crane control Pilot contact Ballast installed und LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F0E	LSB-BSE2: crane control Pilot contact Ballast not installed und LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F11	LSB-BSE2: crane control Pilot contact swing installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F12	LSB-BSE2: crane control Pilot contact swing not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F13	LSB-BSE2: crane control Pilot contact boom nose HA not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F14	LSB-BSE2: crane control Pilot contact boom nose HA not installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F15	LSB-BSE2: crane control Warning - Pilot contact Derrick not installed active Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F16	LSB-BSE2: crane control Warning - Pilot contact main boom not installed active Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D3F19	LSB-BSE2: crane control no or invalid operation mode recognized	A362		E	
2D3F1A	LSB-BSE2: crane control Master switch assignment from LSB-TE1 and LSB-TE2 different Movements blocked Check line connections	A362		E	
2D3F1B	LSB-BSE2: crane control MS assignment of LSB-TE1 and LSB-TE2 and LSB-TE3 different Movements blocked Check line connections	A362		E	
2D3F28	LSB-BSE2: crane control Pilot contact boom nose ZUB installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F29	LSB-BSE2: crane control Pilot contact boom nose ZUB not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F2A	LSB-BSE2: crane control Pilot contact accessories installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F2B	LSB-BSE2: crane control Pilot contact accessories not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F2C	LSB-BSE2: crane control Pilot contact WA-bracket installed and LSB-sensor not present Error message BSE System which sensors pulled at run time Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F2D	LSB-BSE2: crane control Pilot contact WA-bracket not installed and LSB-sensor present Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D3F41	LSB-BSE2: crane control Emergency operation switched on, Caution shut-downs ineffective Deactivate plug emerg. operation. Turn down control and restart	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D3F50	LSB-BSE2: crane control Pressure relapse cyl. main boom smaller min. pressure Only error issue	A362		E	
2D3F51	LSB-BSE2: crane control Pressure relapse cyl. main boom larger max. pressure Only error issue	A362		E	
2D3F54	LSB-BSE2: crane control Pressure relapse cyl. Derrick smaller min. pressure Only error issue	A362		E	
2D3F55	LSB-BSE2: crane control Pressure relapse cyl. Derrick larger max. pressure Only error issue	A362		E	
2D3F60	LSB-BSE2: crane control Warning second shut off diagram yields different result Error output	A362		E	
2D3F90	LSB-BSE2: crane control Test systems of test point 8 supply different test values	A362		B	
2D3FF0	LSB-BSE2: crane control System: LMB not active	A362		E	
2D5004	LSB-BSE2: operation winch 1 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A362		B	
2D5005	LSB-BSE2: operation winch 1 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D500B	LSB-BSE2: operation winch 1 Shut-down upper limit angle ULV (geometry, load capacity chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D500C	LSB-BSE2: operation winch 1 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D500F	LSB-BSE2: operation winch 1 Shut off winch, brake not completely released	A362		B	
2D5018	LSB-BSE2: operation winch 1 Shut-down measuring point 1 < F min operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D5019	LSB-BSE2: operation winch 1 no or invalid operation mode shut-down operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A362		B	
2D501F	LSB-BSE2: operation winch 1 Shut off LMB not active operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D5020	LSB-BSE2: operation winch 1 LMB shut-down operational shut down disengage winch 1 in the control screen	A362		B	
2D5021	LSB-BSE2: operation winch 1 Shut-down measuring point 1 > F max - operation	A362		B	
2D5022	LSB-BSE2: operation winch 1 Shut-down measuring point 1 > F max - assembly	A362		B	
2D5024	LSB-BSE2: operation winch 1 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5025	LSB-BSE2: operation winch 1 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5026	LSB-BSE2: operation winch 1 Shut-down upper limit angle derrick OGWD operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A362		B	
2D5027	LSB-BSE2: operation winch 1 Shut-down lower limit angle derrick UGWD operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A362		B	
2D5029	LSB-BSE2: operation winch 1 winch blocked (C-key monitor) operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D502A	LSB-BSE2: operation winch 1 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A362		B	
2D502E	LSB-BSE2: operation winch 1 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D502F	LSB-BSE2: operation winch 1 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A362		B	
2D5030	LSB-BSE2: operation winch 1 master switch 1 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D5033	LSB-BSE2: operation winch 1 Shut-down parallel op. differential path between winches too great Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5037	LSB-BSE2: operation winch 1 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A362		B	
2D5039	LSB-BSE2: operation winch 1 seat contact shut-down operational shut down Actuate seat contact or press deadman	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D503E	LSB-BSE2: operation winch 1 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5044	LSB-BSE2: operation winch 1 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A362		B	
2D5049	LSB-BSE2: operation winch 1 Shut-down hoist limit switch 4 operational shut down	A362		B	
2D504A	LSB-BSE2: operation winch 1 Shut off Hoist limit switch 5 operational shut down	A362		B	
2D504B	LSB-BSE2: operation winch 1 Shut off upper relative limit angle Derrick ORGWD	A362		B	
2D504E	LSB-BSE2: operation winch 1 Shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	
2D504F	LSB-BSE2: operation winch 1 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A362		B	
2D5050	LSB-BSE2: operation winch 1 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5051	LSB-BSE2: operation winch 1 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5052	LSB-BSE2: operation winch 1 end of stroke switch shut-down 3 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5057	LSB-BSE2: operation winch 1 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D505E	LSB-BSE2: operation winch 1 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A362		B	
2D505F	LSB-BSE2: operation winch 1 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5062	LSB-BSE2: operation winch 1 Emerg. shut-off winch-winch rotational sensor interrupts brake control Operation conditional switch off, may not be shunted Operate load hook in single operation winches 1 and 2 horizontally and set winches 1 and 2 in parallel operation.	A362		B	
2D5063	LSB-BSE2: operation winch 1 Crane engine in overspeed operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5064	LSB-BSE2: operation winch 1 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A362		B	
2D507A	LSB-BSE2: operation winch 1 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D507B	LSB-BSE2: operation winch 1 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D507C	LSB-BSE2: operation winch 1 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D507D	LSB-BSE2: operation winch 1 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D507E	LSB-BSE2: operation winch 1 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D5081	LSB-BSE2: operation winch 1 end of stroke switch 1 shut-down defective operational shut down	A362		B	
2D5082	LSB-BSE2: operation winch 1 end of stroke switch 2 shut-down defective operational shut down	A362		B	
2D5083	LSB-BSE2: operation winch 1 end of stroke switch 3 shut-down defective operational shut down	A362		B	
2D5089	LSB-BSE2: operation winch 1 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D508A	LSB-BSE2: operation winch 1 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D508C	LSB-BSE2: operation winch 1 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A362		B	
2D5090	LSB-BSE2: operation winch 1 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A362		B	
2D509A	LSB-BSE2: operation winch 1 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D509B	LSB-BSE2: operation winch 1 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D50A0	LSB-BSE2: operation winch 1 Shut off Parallel op. test systems W1-W2 deviate Operation conditional switch off, may not be shunted	A362		B	
2D50A7	LSB-BSE2: operation winch 1 Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A362		B	
2D50AB	LSB-BSE2: operation winch 1 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D50AC	LSB-BSE2: operation winch 1 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D50AD	LSB-BSE2: operation winch 1 Shut off upper relative limit angle acc. reached / exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D50B2	LSB-BSE2: operation winch 1 Shut off upper relative limit angle HA reached / exceeded	A362		B	
2D50BC	LSB-BSE2: operation winch 1 UGW HA Erection force reached - activate switch boom on ground	A362		B	
2D50BF	LSB-BSE2: operation winch 1 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D50C0	LSB-BSE2: operation winch 1 Shut off test point 3 > F max - Montage	A362		B	
2D50C5	LSB-BSE2: operation winch 1 OGW main boom erection force reached - luff up derrick, lift ballast	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D50C7	LSB-BSE2: operation winch 1 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D50C8	LSB-BSE2: operation winch 1 Shut off test point 2 > F max - assembly	A362		B	
2D50D0	LSB-BSE2: operation winch 1 Shut off since parallel op. set up, press deadman longer Operational shut off, bypassable Set up of parallel op., change over of MS assignment in TE to parallel op. or by pressing deadman	A362		B	
2D50D1	LSB-BSE2: operation winch 1 Shut off Parallel operation Operational shut off Release shut off, for error remedy see respective system error	A362		B	
2D50E6	LSB-BSE2: operation winch 1 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D50E7	LSB-BSE2: operation winch 1 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A362		B	
2D50E8	LSB-BSE2: operation winch 1 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A362		B	
2D5104	LSB-BSE2: operation winch 2 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A362		B	
2D5105	LSB-BSE2: operation winch 2 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D510B	LSB-BSE2: operation winch 2 Shut-down upper limit angle ULV (geometry, load capacity chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D510C	LSB-BSE2: operation winch 2 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D510F	LSB-BSE2: operation winch 2 Shut off winch, brake not completely released	A362		B	
2D5110	LSB-BSE2: operation winch 2 fly jib upper stop shut-down operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5111	LSB-BSE2: operation winch 2 fly jib upper flap shut-down	A362		B	
2D5112	LSB-BSE2: operation winch 2 shut-down as lower fly jib and NA-boom 3 not positioned	A362		B	
2D5113	LSB-BSE2: operation winch 2 shut-down as flap not positioned and angle threshold exceeded	A362		B	
2D5114	LSB-BSE2: operation winch 2 pressure retaining cylinder RFP N shut-down outside set range	A362		B	
2D5115	LSB-BSE2: operation winch 2 adjustable pulley-N on stop shut-down	A362		B	
2D5118	LSB-BSE2: operation winch 2 Shut-down measuring point 1 < F min	A362		B	
2D5119	LSB-BSE2: operation winch 2 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D511F	LSB-BSE2: operation winch 2 Shut off LMB not active operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D5120	LSB-BSE2: operation winch 2 LMB shut-down operational shut down release winch 2 in the control screen	A362		B	
2D5121	LSB-BSE2: operation winch 2 Shut-down measuring point 1 > F max - operation	A362		B	
2D5122	LSB-BSE2: operation winch 2 Shut-down measuring point 1 > F max - assembly	A362		B	
2D5124	LSB-BSE2: operation winch 2 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5125	LSB-BSE2: operation winch 2 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5126	LSB-BSE2: operation winch 2 Shut-down upper limit angle derrick OGWD operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A362		B	
2D5127	LSB-BSE2: operation winch 2 Shut-down lower limit angle derrick UGWD operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A362		B	
2D5129	LSB-BSE2: operation winch 2 winch blocked (C-key monitor) operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D512A	LSB-BSE2: operation winch 2 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D512E	LSB-BSE2: operation winch 2 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D512F	LSB-BSE2: operation winch 2 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A362		B	
2D5130	LSB-BSE2: operation winch 2 master switch 1 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A362		B	
2D5131	LSB-BSE2: operation winch 2 master switch 2 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D5133	LSB-BSE2: operation winch 2 Shut-down parallel op. differential path between winches too great	A362		B	
2D5137	LSB-BSE2: operation winch 2 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A362		B	
2D5139	LSB-BSE2: operation winch 2 seat contact shut-down operational shut down Actuate seat contact or press deadman	A362		B	
2D513E	LSB-BSE2: operation winch 2 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5144	LSB-BSE2: operation winch 2 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A362		B	
2D5149	LSB-BSE2: operation winch 2 Shut-down hoist limit switch 4 operational shut down	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D514A	LSB-BSE2: operation winch 2 Shut off Hoist limit switch 5 operational shut down	A362		B	
2D514B	LSB-BSE2: operation winch 2 Shut off upper relative limit angle Derrick ORGWD	A362		B	
2D514E	LSB-BSE2: operation winch 2 Shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	
2D514F	LSB-BSE2: operation winch 2 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A362		B	
2D5150	LSB-BSE2: operation winch 2 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5151	LSB-BSE2: operation winch 2 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5152	LSB-BSE2: operation winch 2 end of stroke switch shut-down 3 operational shut down	A362		B	
2D5157	LSB-BSE2: operation winch 2 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D515E	LSB-BSE2: operation winch 2 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A362		B	
2D515F	LSB-BSE2: operation winch 2 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5162	LSB-BSE2: operation winch 2 Emerg. shut-off winch-winch rotational sensor interrupts brake control operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5163	LSB-BSE2: operation winch 2 Crane engine in overspeed Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5164	LSB-BSE2: operation winch 2 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A362		B	
2D5170	LSB-BSE2: operation winch 2 shut-down both limit switches "flap in position" defect./missing	A362		B	
2D5171	LSB-BSE2: operation winch 2 shut-down both limit switches "NA-boom 3 pos." defect./missing	A362		B	
2D5173	LSB-BSE2: operation winch 2 shut-down both limit switches "lower fly jib" defective/missing	A362		B	
2D5174	LSB-BSE2: operation winch 2 shut-down both limit switches "upper fly jib flap" defect./missing	A362		B	
2D5175	LSB-BSE2: operation winch 2 shut-down both limit switches "upper fly jib stop"defect./missing	A362		B	
2D5176	LSB-BSE2: operation winch 2 shut-down limit switch adjustable pulley-N defective/missing	A362		B	
2D517A	LSB-BSE2: operation winch 2 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D517B	LSB-BSE2: operation winch 2 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D517C	LSB-BSE2: operation winch 2 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D517D	LSB-BSE2: operation winch 2 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A362		B	
2D517E	LSB-BSE2: operation winch 2 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D5181	LSB-BSE2: operation winch 2 end of stroke switch 1 shut-down defective operational shut down	A362		B	
2D5182	LSB-BSE2: operation winch 2 end of stroke switch 2 shut-down defective operational shut down	A362		B	
2D5183	LSB-BSE2: operation winch 2 end of stroke switch 3 shut-down defective operational shut down	A362		B	
2D5189	LSB-BSE2: operation winch 2 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D518A	LSB-BSE2: operation winch 2 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D518C	LSB-BSE2: operation winch 2 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5190	LSB-BSE2: operation winch 2 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A362		B	
2D519A	LSB-BSE2: operation winch 2 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D519B	LSB-BSE2: operation winch 2 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D51A0	LSB-BSE2: operation winch 2 Shut off Parallel op. test systems W1-W2 deviate Operation conditional switch off, may not be shunted	A362		B	
2D51A7	LSB-BSE2: operation winch 2 Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A362		B	
2D51AB	LSB-BSE2: operation winch 2 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D51AC	LSB-BSE2: operation winch 2 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D51AD	LSB-BSE2: operation winch 2 Shut off upper relative limit angle acc. reached / exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D51B2	LSB-BSE2: operation winch 2 Shut off upper relative limit angle HA reached / exceeded	A362		B	
2D51BC	LSB-BSE2: operation winch 2 UGW HA Erection force reached - activate switch boom on ground	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D51BF	LSB-BSE2: operation winch 2 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D51C0	LSB-BSE2: operation winch 2 Shut off test point 3 > F max - Montage	A362		B	
2D51C5	LSB-BSE2: operation winch 2 OGW main boom erection force reached - luff up derrick, lift ballast	A362		B	
2D51C7	LSB-BSE2: operation winch 2 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D51C8	LSB-BSE2: operation winch 2 Shut off test point 2 > F max - assembly	A362		B	
2D51D0	LSB-BSE2: operation winch 2 Shut off since parallel op. set up, press deadman longer Operational shut off, bypassable Set up of parallel op., change over of MS assignment in TE to parallel op. or by pressing deadman	A362		B	
2D51D1	LSB-BSE2: operation winch 2 Shut off Parallel operation Operational shut off Release shut off, for error remedy see respective system error	A362		B	
2D51E6	LSB-BSE2: operation winch 2 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D51E7	LSB-BSE2: operation winch 2 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A362		B	
2D51E8	LSB-BSE2: operation winch 2 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5203	LSB-BSE2: operation winch 3 Shut-down jib lower	A362		B	
2D5204	LSB-BSE2: operation winch 3 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A362		B	
2D5205	LSB-BSE2: operation winch 3 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D5206	LSB-BSE2: operation winch 3 upper angle limit OGW shut-down Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5207	LSB-BSE2: operation winch 3 lower angle limit UGW shut-down Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5208	LSB-BSE2: operation winch 3 luffing up main boom shut-down working area limitation ABB	A362		B	
2D5209	LSB-BSE2: operation winch 3 luffing down main boom shut-down working area limitation ABB Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D520B	LSB-BSE2: operation winch 3 Shut-down upper limit angle ULV (geometry, load capacity chart) operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A362		B	
2D520C	LSB-BSE2: operation winch 3 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D520D	LSB-BSE2: operation winch 3 Shut off WA-Bock bottom Operation conditional switch off, may not be shunted reel winch in until limit switch is no longer actuated - shut-down cannot be shunted	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D520F	LSB-BSE2: operation winch 3 Shut off winch, brake not completely released	A362		B	
2D5210	LSB-BSE2: operation winch 3 fly jib upper stop shut-down operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D5211	LSB-BSE2: operation winch 3 fly jib upper flap shut-down Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5213	LSB-BSE2: operation winch 3 shut-down as flap not positioned and angle threshold exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5218	LSB-BSE2: operation winch 3 Shut-down measuring point 1 < F min	A362		B	
2D5219	LSB-BSE2: operation winch 3 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D521C	LSB-BSE2: operation winch 3 Shut off angle sensor N top faulty / missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D521F	LSB-BSE2: operation winch 3 Shut off LMB not active operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A362		B	
2D5220	LSB-BSE2: operation winch 3 LMB shut-down operational shut down release winch 3 in control screen	A362		B	
2D5221	LSB-BSE2: operation winch 3 Shut-down measuring point 1 > F max - operation operational shut down reel winch out until crane in working area again - shunting through shutting down of working area limitation	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5222	LSB-BSE2: operation winch 3 Shut-down measuring point 1 > F max - assembly	A362		B	
2D5224	LSB-BSE2: operation winch 3 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5225	LSB-BSE2: operation winch 3 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5226	LSB-BSE2: operation winch 3 Shut-down upper limit angle derrick OGWD operational shut down Move Derrick boom into op. pos. shut off cannot be bypassed	A362		B	
2D5227	LSB-BSE2: operation winch 3 Shut-down lower limit angle derrick UGWD operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D5228	LSB-BSE2: operation winch 3 Shut-down upper limit angle main boom operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D5229	LSB-BSE2: operation winch 3 winch blocked (C-key monitor) operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A362		B	
2D522A	LSB-BSE2: operation winch 3 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A362		B	
2D522C	LSB-BSE2: operation winch 3 Shut off winch 3 spooled up from main boom control	A362		B	
2D522E	LSB-BSE2: operation winch 3 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D522F	LSB-BSE2: operation winch 3 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A362		B	
2D5230	LSB-BSE2: operation winch 3 master switch 1 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A362		B	
2D5232	LSB-BSE2: operation winch 3 master switch 3 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D5234	LSB-BSE2: operation winch 3 Shut-down limit angle main boom - derrick Operation conditional switch off, may not be shunted Wind on winch until limit angle is fallen short of - shut-down may be shunted.	A362		B	
2D5237	LSB-BSE2: operation winch 3 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A362		B	
2D5239	LSB-BSE2: operation winch 3 seat contact shut-down operational shut down Actuate seat contact or press deadman	A362		B	
2D523A	LSB-BSE2: operation winch 3 Shut off Pulley block S/D Block erroneous/missing	A362		B	
2D523B	LSB-BSE2: operation winch 3 Shut off Pulley block S/D Block operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D523C	LSB-BSE2: operation winch 3 Shut off test point 8 > F max Assembly roll	A362		B	
2D523E	LSB-BSE2: operation winch 3 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D523F	LSB-BSE2: operation winch 3 Shut off Test point 8 erroneous / missing	A362		B	
2D5244	LSB-BSE2: operation winch 3 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A362		B	
2D5249	LSB-BSE2: operation winch 3 Shut-down hoist limit switch 4 operational shut down	A362		B	
2D524A	LSB-BSE2: operation winch 3 Shut off Hoist limit switch 5 operational shut down	A362		B	
2D524B	LSB-BSE2: operation winch 3 Shut off upper relative limit angle Derrick ORGWD operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D524E	LSB-BSE2: operation winch 3 Shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	
2D524F	LSB-BSE2: operation winch 3 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A362		B	
2D5250	LSB-BSE2: operation winch 3 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5251	LSB-BSE2: operation winch 3 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5252	LSB-BSE2: operation winch 3 end of stroke switch shut-down 3 operational shut down	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5254	LSB-BSE2: operation winch 3 Shut-down overtopping guard cylinder main boom in bump stop operational shut down reel winch out until the radius is within the load chart again - shut-down can be shunted (danger)	A362		B	
2D5255	LSB-BSE2: operation winch 3 Shut-down overtopping guard cylinder derrick boom in bump stop	A362		B	
2D5257	LSB-BSE2: operation winch 3 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D525C	LSB-BSE2: operation winch 3 Shut off Ballast lateral incline > max value	A362		B	
2D525D	LSB-BSE2: operation winch 3 Shut off Main boom upper limit angle reached/exceeded operational shut down Winch spool out to limit angle fallen below - Shut off with assembly bypassable (danger).	A362		B	
2D525E	LSB-BSE2: operation winch 3 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A362		B	
2D525F	LSB-BSE2: operation winch 3 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5262	LSB-BSE2: operation winch 3 Emerg. shut-off winch-winch rotational sensor interrupts brake control Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5263	LSB-BSE2: operation winch 3 Crane engine in overspeed operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5264	LSB-BSE2: operation winch 3 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5266	LSB-BSE2: operation winch 3 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5267	LSB-BSE2: operation winch 3 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D526B	LSB-BSE2: operation winch 3 Shut off angle sensor S or D erroneous / missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D526C	LSB-BSE2: operation winch 3 Shut off angle between S and D too low Operational shut off Increase angle between main boom and derrick. Move winch 3 down	A362		B	
2D526F	LSB-BSE2: operation winch 3 Shut off both limit switches "WA-Bock bottom" incorrect / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5270	LSB-BSE2: operation winch 3 shut-down both limit switches "flap in position" defect./missing Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A362		B	
2D5272	LSB-BSE2: operation winch 3 shut-down both angle sensors "fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5273	LSB-BSE2: operation winch 3 shut-down both limit switches "lower fly jib" defective/missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5274	LSB-BSE2: operation winch 3 shut-down both limit switches "upper fly jib flap" defect./missing	A362		B	
2D5275	LSB-BSE2: operation winch 3 shut-down both limit switches "upper fly jib stop"defect./missing operational shut down Wind on winch until limit angle is fallen short of - shut-down may be shunted (danger).	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D527A	LSB-BSE2: operation winch 3 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D527B	LSB-BSE2: operation winch 3 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D527C	LSB-BSE2: operation winch 3 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D527D	LSB-BSE2: operation winch 3 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A362		B	
2D527E	LSB-BSE2: operation winch 3 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D5281	LSB-BSE2: operation winch 3 end of stroke switch 1 shut-down defective operational shut down	A362		B	
2D5282	LSB-BSE2: operation winch 3 end of stroke switch 2 shut-down defective operational shut down	A362		B	
2D5283	LSB-BSE2: operation winch 3 end of stroke switch 3 shut-down defective operational shut down	A362		B	
2D5285	LSB-BSE2: operation winch 3 Shut-down limit switch right "RFP main boom" faulty / not present	A362		B	
2D5286	LSB-BSE2: operation winch 3 Shut-down limit switch "RFP Main boom" links faulty / not present Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5287	LSB-BSE2: operation winch 3 Shut-down limit switch right "Overtop guard cyl D" faulty/not pres Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5288	LSB-BSE2: operation winch 3 Shut-down limit switch left "Overtop guard cyl D" faulty/not preS Operation conditional switch off, may not be shunted Luff down derrick boom until limit switch no longer activated - Shut-down may not be shunted	A362		B	
2D5289	LSB-BSE2: operation winch 3 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D528A	LSB-BSE2: operation winch 3 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D528C	LSB-BSE2: operation winch 3 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A362		B	
2D5290	LSB-BSE2: operation winch 3 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A362		B	
2D5298	LSB-BSE2: operation winch 3 Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted	A362		B	
2D5299	LSB-BSE2: operation winch 3 Shut off pressure Relapse cyl. derrick outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D529A	LSB-BSE2: operation winch 3 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D529B	LSB-BSE2: operation winch 3 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D52A7	LSB-BSE2: operation winch 3 Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A362		B	
2D52A9	LSB-BSE2: operation winch 3 Shut off limit switch RFP-S moved out le/ri erroneous/missing Shut off, cannot be bypassed Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D52AB	LSB-BSE2: operation winch 3 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D52AC	LSB-BSE2: operation winch 3 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D52AD	LSB-BSE2: operation winch 3 Shut off upper relative limit angle acc. reached / exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D52AF	LSB-BSE2: operation winch 3 Shut off Danger of collision between support and flap	A362		B	
2D52B2	LSB-BSE2: operation winch 3 Shut off upper relative limit angle HA reached / exceeded	A362		B	
2D52BA	LSB-BSE2: operation winch 3 Winch operating temp. exceeded reduce output !	A362		B	
2D52BB	LSB-BSE2: operation winch 3 Shut off limit angle folded down reached luff accessories up operational shut down With the luffing, luff up winch 5 and drive out of the lower limit angle shut-off	A362		B	
2D52BC	LSB-BSE2: operation winch 3 UGW HA Erection force reached - activate switch boom on ground	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D52BF	LSB-BSE2: operation winch 3 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D52C0	LSB-BSE2: operation winch 3 Shut off test point 3 > F max - Montage	A362		B	
2D52C2	LSB-BSE2: operation winch 3 Shut off Danger of collision Derrick with S-control, F3 too small	A362		B	
2D52C5	LSB-BSE2: operation winch 3 OGW main boom erection force reached - luff up derrick, lift ballast operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D52C7	LSB-BSE2: operation winch 3 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D52C8	LSB-BSE2: operation winch 3 Shut off test point 2 > F max - assembly	A362		B	
2D52C9	LSB-BSE2: operation winch 3 Shut off test point 2 < F min	A362		B	
2D52CF	LSB-BSE2: operation winch 3 Shut off UGW Derrick - in Derrick op. window run possible	A362		B	
2D52E0	LSB-BSE2: operation winch 3 Shut off Flap bottom fixed jib not Position	A362		B	
2D52E1	LSB-BSE2: operation winch 3 Shut off Flap top fixed jib not Position	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D52E2	LSB-BSE2: operation winch 3 Shut off Danger of collision ACC with fixed jib - ACC up possible	A362		B	
2D52E6	LSB-BSE2: operation winch 3 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D52E7	LSB-BSE2: operation winch 3 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A362		B	
2D52E8	LSB-BSE2: operation winch 3 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A362		B	
2D5300	LSB-BSE2: operation winch 4 Shut off pressure sensor "RFP SA-bracket" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5303	LSB-BSE2: operation winch 4 Shut-down jib lower Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A362		B	
2D5304	LSB-BSE2: operation winch 4 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A362		B	
2D5305	LSB-BSE2: operation winch 4 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D5306	LSB-BSE2: operation winch 4 upper angle limit OGW shut-down operational shut down Wind on winch until limit angle is fallen short of - shut-down may be shunted (danger).	A362		B	
2D5307	LSB-BSE2: operation winch 4 lower angle limit UGW shut-down Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5308	LSB-BSE2: operation winch 4 luffing up main boom shut-down working area limitation ABB	A362		B	
2D5309	LSB-BSE2: operation winch 4 luffing down main boom shut-down working area limitation ABB operational shut down Wind off winch until derrick boom is in operating position - shut-down may be shunted (danger).	A362		B	
2D530B	LSB-BSE2: operation winch 4 Shut-down upper limit angle ULV (geometry, load capacity chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D530C	LSB-BSE2: operation winch 4 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D530D	LSB-BSE2: operation winch 4 Shut off WA-Bock bottom Operation conditional switch off, may not be shunted reel winch in until limit switch is no longer actuated - shut-down cannot be shunted	A362		B	
2D530F	LSB-BSE2: operation winch 4 Shut off winch, brake not completely released	A362		B	
2D5310	LSB-BSE2: operation winch 4 fly jib upper stop shut-down	A362		B	
2D5311	LSB-BSE2: operation winch 4 fly jib upper flap shut-down Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A362		B	
2D5313	LSB-BSE2: operation winch 4 shut-down as flap not positioned and angle threshold exceeded	A362		B	
2D5318	LSB-BSE2: operation winch 4 Shut-down measuring point 1 < F min operational shut down Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5319	LSB-BSE2: operation winch 4 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D531F	LSB-BSE2: operation winch 4 Shut off LMB not active operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A362		B	
2D5320	LSB-BSE2: operation winch 4 LMB shut-down operational shut down Winch 4 released in control view	A362		B	
2D5321	LSB-BSE2: operation winch 4 Shut-down measuring point 1 > F max - operation	A362		B	
2D5322	LSB-BSE2: operation winch 4 Shut-down measuring point 1 > F max - assembly	A362		B	
2D5324	LSB-BSE2: operation winch 4 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5325	LSB-BSE2: operation winch 4 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5326	LSB-BSE2: operation winch 4 Shut-down upper limit angle derrick OGWD	A362		B	
2D5327	LSB-BSE2: operation winch 4 Shut-down lower limit angle derrick UGWD Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5328	LSB-BSE2: operation winch 4 Shut-down upper limit angle main boom Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5329	LSB-BSE2: operation winch 4 winch blocked (C-key monitor) operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A362		B	
2D532A	LSB-BSE2: operation winch 4 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A362		B	
2D532D	LSB-BSE2: operation winch 4 Shut off winch 4 spooled up from derrick control Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A362		B	
2D532E	LSB-BSE2: operation winch 4 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D532F	LSB-BSE2: operation winch 4 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A362		B	
2D5330	LSB-BSE2: operation winch 4 master switch 1 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A362		B	
2D5332	LSB-BSE2: operation winch 4 master switch 3 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D5337	LSB-BSE2: operation winch 4 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A362		B	
2D5339	LSB-BSE2: operation winch 4 seat contact shut-down operational shut down Actuate seat contact or press deadman	A362		B	
2D533A	LSB-BSE2: operation winch 4 Shut off Pulley block S/D Block erroneous/missing operational shut down Bring master switch to zero pos., check sensor, lines and plugs	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D533B	LSB-BSE2: operation winch 4 Shut off Pulley block S/D Block operational shut down Bring master switch in zero pos. Move out of shut off in opposite direction with winch	A362		B	
2D533C	LSB-BSE2: operation winch 4 Shut off test point 8 > F max Assembly roll	A362		B	
2D533E	LSB-BSE2: operation winch 4 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D533F	LSB-BSE2: operation winch 4 Shut off Test point 8 erroneous / missing	A362		B	
2D5344	LSB-BSE2: operation winch 4 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A362		B	
2D5349	LSB-BSE2: operation winch 4 Shut-down hoist limit switch 4 operational shut down	A362		B	
2D534A	LSB-BSE2: operation winch 4 Shut off Hoist limit switch 5 operational shut down	A362		B	
2D534B	LSB-BSE2: operation winch 4 Shut off upper relative limit angle Derrick ORGWD	A362		B	
2D534C	LSB-BSE2: operation winch 4 Shut off Difference angle SA-frame - Derrick too large Operation conditional switch off, may not be shunted Release master switch – error remedy via winch 4 move lower	A362		B	
2D534E	LSB-BSE2: operation winch 4 Shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D534F	LSB-BSE2: operation winch 4 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A362		B	
2D5350	LSB-BSE2: operation winch 4 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5351	LSB-BSE2: operation winch 4 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5352	LSB-BSE2: operation winch 4 end of stroke switch shut-down 3 operational shut down	A362		B	
2D5354	LSB-BSE2: operation winch 4 Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5355	LSB-BSE2: operation winch 4 Shut-down overtopping guard cylinder derrick boom in bump stop	A362		B	
2D5356	LSB-BSE2: operation winch 4 Shut-down angle SA-frame < minimal angle Operation conditional switch off, may not be shunted luff main boom up until limit switch is no longer activated - shut-down cannot be shunted	A362		B	
2D5357	LSB-BSE2: operation winch 4 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D5358	LSB-BSE2: operation winch 4 Shut-down guide frame - counterweight bump stop upper Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A362		B	
2D5359	LSB-BSE2: operation winch 4 Shut-down guide frame - counterweight bump stop lower Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D535C	LSB-BSE2: operation winch 4 Shut off Ballast lateral incline > max value	A362		B	
2D535D	LSB-BSE2: operation winch 4 Shut off Main boom upper limit angle reached/exceeded Operational shut off Bring master switch in zero pos. Luff down main boom control winch	A362		B	
2D535E	LSB-BSE2: operation winch 4 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A362		B	
2D535F	LSB-BSE2: operation winch 4 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5362	LSB-BSE2: operation winch 4 Emerg. shut-off winch-winch rotational sensor interrupts brake control operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5363	LSB-BSE2: operation winch 4 Crane engine in overspeed Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5364	LSB-BSE2: operation winch 4 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A362		B	
2D5366	LSB-BSE2: operation winch 4 Shut off pressure sensor "RFP main boom" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5367	LSB-BSE2: operation winch 4 Shut off pressure sensor "RFP Derrick" defective / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D536B	LSB-BSE2: operation winch 4 Shut off angle sensor S or D erroneous / missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D536C	LSB-BSE2: operation winch 4 Shut off angle between S and D too low Operational shut off Increase angle between main boom and derrick. Move winch 3 down	A362		B	
2D536F	LSB-BSE2: operation winch 4 Shut off both limit switches "WA-Bock bottom" incorrect / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5370	LSB-BSE2: operation winch 4 shut-down both limit switches "flap in position" defect./missing Operation conditional switch off, may not be shunted check as to why the flap is not in position - shut-down cannot be shunted	A362		B	
2D5372	LSB-BSE2: operation winch 4 shut-down both angle sensors "fly jib" defective/missing	A362		B	
2D5373	LSB-BSE2: operation winch 4 shut-down both limit switches "lower fly jib" defective/missing Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A362		B	
2D5374	LSB-BSE2: operation winch 4 shut-down both limit switches "upper fly jib flap" defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5375	LSB-BSE2: operation winch 4 shut-down both limit switches "upper fly jib stop"defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D537A	LSB-BSE2: operation winch 4 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D537B	LSB-BSE2: operation winch 4 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D537C	LSB-BSE2: operation winch 4 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D537D	LSB-BSE2: operation winch 4 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A362		B	
2D537E	LSB-BSE2: operation winch 4 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D5381	LSB-BSE2: operation winch 4 end of stroke switch 1 shut-down defective operational shut down	A362		B	
2D5382	LSB-BSE2: operation winch 4 end of stroke switch 2 shut-down defective operational shut down	A362		B	
2D5383	LSB-BSE2: operation winch 4 end of stroke switch 3 shut-down defective operational shut down	A362		B	
2D5385	LSB-BSE2: operation winch 4 Shut-down limit switch right "RFP main boom" faulty / not present Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5386	LSB-BSE2: operation winch 4 Shut-down limit switch "RFP Main boom" links faulty / not present Operation conditional switch off, may not be shunted luff main boom down until limit switch is no longer activated - shut-down cannot be shunted	A362		B	
2D5387	LSB-BSE2: operation winch 4 Shut-down limit switch right "Overtop guard cyl D" faulty/not pres	A362		B	
2D5388	LSB-BSE2: operation winch 4 Shut-down limit switch left "Overtop guard cyl D" faulty/not preS Operation conditional switch off, may not be shunted Luff down derrick boom until limit switch no longer activated - Shut-down may not be shunted	A362		B	
2D5389	LSB-BSE2: operation winch 4 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D538A	LSB-BSE2: operation winch 4 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D538C	LSB-BSE2: operation winch 4 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A362		B	
2D538E	LSB-BSE2: operation winch 4 SA-frame Assembly cylinder shut off Ring surface block	A362		B	
2D538F	LSB-BSE2: operation winch 4 Shut off SA-Bock angle > Max angle Operational shut off, bypassable Release master switch – Error remedy through bridging assembly button	A362		B	
2D5390	LSB-BSE2: operation winch 4 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A362		B	
2D5391	LSB-BSE2: operation winch 4 Shut-down limit switch right "Limit angle SA-frame" faulty/not pres Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5392	LSB-BSE2: operation winch 4 Shut-down limit switch left "Limit angle SA-frame" faulty/not prese Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5393	LSB-BSE2: operation winch 4 Shut-down limit switch right "Lower count. block" faulty/not pre Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D5394	LSB-BSE2: operation winch 4 Shut-down limit switch left "Lower count. block" faulty/not present Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D5395	LSB-BSE2: operation winch 4 Shut-down limit switch right "Upper count. block" faulty/not presen Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5396	LSB-BSE2: operation winch 4 Shut-down limit switch left "Upper count. block" faulty / not prese Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D5397	LSB-BSE2: operation winch 4 Shut off pressure Relapse cyl. SA br. outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5398	LSB-BSE2: operation winch 4 Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5399	LSB-BSE2: operation winch 4 Shut off pressure Relapse cyl. derrick outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D539A	LSB-BSE2: operation winch 4 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D539B	LSB-BSE2: operation winch 4 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D539D	LSB-BSE2: operation winch 4 Shut off angle sensor SA-frame erroneous/missing Operation conditional switch off, may not be shunted Release master switch - error remedy see corr. system error, check sensor	A362		B	
2D539E	LSB-BSE2: operation winch 4 Shut off angle sensor "RFP SA-frame" left erroneous/missing Operation conditional switch off, may not be shunted Release master switch - error remedy see corr. system error, check sensor	A362		B	
2D539F	LSB-BSE2: operation winch 4 Shut off angle sensor "RFP SA-frame" right erroneous/missing Operation conditional switch off, may not be shunted Release master switch - error remedy see corr. system error, check sensor	A362		B	
2D53A1	LSB-BSE2: operation winch 4 Shut off inductive sensor RFP SA-frame left Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D53A2	LSB-BSE2: operation winch 4 Shut off inductive sensor RFP SA-frame right Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D53A7	LSB-BSE2: operation winch 4 Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A362		B	
2D53A9	LSB-BSE2: operation winch 4 Shut off limit switch RFP-S moved out le/ri erroneous/missing Shut off, cannot be bypassed Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D53AB	LSB-BSE2: operation winch 4 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D53AC	LSB-BSE2: operation winch 4 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D53AD	LSB-BSE2: operation winch 4 Shut off upper relative limit angle acc. reached / exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D53AE	LSB-BSE2: operation winch 4 Shut off upper erection derrick angle reached / F3min reached	A362		B	
2D53AF	LSB-BSE2: operation winch 4 Shut off Danger of collision between support and flap	A362		B	
2D53B2	LSB-BSE2: operation winch 4 Shut off upper relative limit angle HA reached / exceeded	A362		B	
2D53BA	LSB-BSE2: operation winch 4 Winch operating temp. exceeded reduce output !	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D53BB	LSB-BSE2: operation winch 4 Shut off limit angle folded down reached luff accessories up operational shut down With the luffing, luff up winch 5 and drive out of the lower limit angle shut-off	A362		B	
2D53BC	LSB-BSE2: operation winch 4 UGW HA Erection force reached - activate switch boom on ground	A362		B	
2D53BF	LSB-BSE2: operation winch 4 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D53C0	LSB-BSE2: operation winch 4 Shut off test point 3 > F max - Montage	A362		B	
2D53C1	LSB-BSE2: operation winch 4 Shut off F1 too large take down main boom	A362		B	
2D53C7	LSB-BSE2: operation winch 4 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D53C8	LSB-BSE2: operation winch 4 Shut off test point 2 > F max - assembly	A362		B	
2D53C9	LSB-BSE2: operation winch 4 Shut off test point 2 < F min	A362		B	
2D53CF	LSB-BSE2: operation winch 4 Shut off UGW Derrick - in Derrick op. window run possible	A362		B	
2D53E0	LSB-BSE2: operation winch 4 Shut off Flap bottom fixed jib not Position	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D53E1	LSB-BSE2: operation winch 4 Shut off Flap top fixed jib not Position	A362		B	
2D53E6	LSB-BSE2: operation winch 4 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D53E7	LSB-BSE2: operation winch 4 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A362		B	
2D53E8	LSB-BSE2: operation winch 4 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A362		B	
2D5403	LSB-BSE2: operation winch 5 Shut-down jib lower	A362		B	
2D5404	LSB-BSE2: operation winch 5 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A362		B	
2D5405	LSB-BSE2: operation winch 5 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D5406	LSB-BSE2: operation winch 5 upper angle limit OGW shut-down Operation conditional switch off, may not be shunted Spool up - out winch 5 is only permitted at main boom positions small limit angle	A362		B	
2D5407	LSB-BSE2: operation winch 5 lower angle limit UGW shut-down Operation conditional switch off, may not be shunted Wind off winch until pressure is once again within the desired range - shut-down may not be shunted .	A362		B	
2D5408	LSB-BSE2: operation winch 5 luffing up main boom shut-down working area limitation ABB Operation conditional switch off, may not be shunted check as to why the flap is not in position - shut-down cannot be shunted	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5409	LSB-BSE2: operation winch 5 luffing down main boom shut-down working area limitation ABB Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D540B	LSB-BSE2: operation winch 5 Shut-down upper limit angle ULV (geometry, load capacity chart) operational shut down reel winch in until crane in working area again - shunting through shutting down of working area limitation	A362		B	
2D540C	LSB-BSE2: operation winch 5 Shut-down lower limit value LLV (geometry, load capacity chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D540D	LSB-BSE2: operation winch 5 Shut off WA-Bock bottom Operation conditional switch off, may not be shunted reel winch in until limit switch is no longer actuated - shut-down cannot be shunted	A362		B	
2D540F	LSB-BSE2: operation winch 5 Shut off winch, brake not completely released	A362		B	
2D5410	LSB-BSE2: operation winch 5 fly jib upper stop shut-down operational shut down reel winch out until crane in working area again - shunting through shutting down of working area limitation	A362		B	
2D5411	LSB-BSE2: operation winch 5 fly jib upper flap shut-down operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5413	LSB-BSE2: operation winch 5 shut-down as flap not positioned and angle threshold exceeded Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5414	LSB-BSE2: operation winch 5 pressure retaining cylinder RFP N shut-down outside set range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5416	LSB-BSE2: operation winch 5 luffing up accessory shut-down working area limitation ABB Operation conditional switch off, may not be shunted Luff up main boom during erection procedure, luff down main boom or accessory during setting down procedure.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5417	LSB-BSE2: operation winch 5 luffing down accessory shut-down working area limitation ABB operational shut down reel winch in until the radius is within the load chart again - shut-down can be shunted (danger)	A362		B	
2D5418	LSB-BSE2: operation winch 5 Shut-down measuring point 1 < F min	A362		B	
2D5419	LSB-BSE2: operation winch 5 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D541C	LSB-BSE2: operation winch 5 Shut off angle sensor N top faulty / missing Operation conditional switch off, may not be shunted Luff down jib until limit switch no longer activated - shut-down may not be activated	A362		B	
2D541F	LSB-BSE2: operation winch 5 Shut off LMB not active operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A362		B	
2D5420	LSB-BSE2: operation winch 5 LMB shut-down operational shut down Winch 5 released in control view	A362		B	
2D5421	LSB-BSE2: operation winch 5 Shut-down measuring point 1 > F max - operation	A362		B	
2D5422	LSB-BSE2: operation winch 5 Shut-down measuring point 1 > F max - assembly operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D5424	LSB-BSE2: operation winch 5 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5425	LSB-BSE2: operation winch 5 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5426	LSB-BSE2: operation winch 5 Shut-down upper limit angle derrick OGWD	A362		B	
2D5427	LSB-BSE2: operation winch 5 Shut-down lower limit angle derrick UGWD Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5428	LSB-BSE2: operation winch 5 Shut-down upper limit angle main boom Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5429	LSB-BSE2: operation winch 5 winch blocked (C-key monitor) operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A362		B	
2D542A	LSB-BSE2: operation winch 5 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A362		B	
2D542E	LSB-BSE2: operation winch 5 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D542F	LSB-BSE2: operation winch 5 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A362		B	
2D5430	LSB-BSE2: operation winch 5 master switch 1 defective/missing operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D5431	LSB-BSE2: operation winch 5 master switch 2 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A362		B	
2D5432	LSB-BSE2: operation winch 5 master switch 3 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5437	LSB-BSE2: operation winch 5 Winch rotational sensor faulty / missing Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A362		B	
2D5438	LSB-BSE2: operation winch 5 Shut-down upper limit angle accessory	A362		B	
2D5439	LSB-BSE2: operation winch 5 seat contact shut-down operational shut down Actuate seat contact or press deadman	A362		B	
2D543E	LSB-BSE2: operation winch 5 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5444	LSB-BSE2: operation winch 5 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A362		B	
2D5449	LSB-BSE2: operation winch 5 Shut-down hoist limit switch 4 operational shut down	A362		B	
2D544A	LSB-BSE2: operation winch 5 Shut off Hoist limit switch 5 operational shut down	A362		B	
2D544B	LSB-BSE2: operation winch 5 Shut off upper relative limit angle Derrick ORGWD operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D544E	LSB-BSE2: operation winch 5 Shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	
2D544F	LSB-BSE2: operation winch 5 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5450	LSB-BSE2: operation winch 5 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5451	LSB-BSE2: operation winch 5 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5452	LSB-BSE2: operation winch 5 end of stroke switch shut-down 3 operational shut down	A362		B	
2D5457	LSB-BSE2: operation winch 5 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D545E	LSB-BSE2: operation winch 5 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A362		B	
2D545F	LSB-BSE2: operation winch 5 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5462	LSB-BSE2: operation winch 5 Emerg. shut-off winch-winch rotational sensor interrupts brake control operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5463	LSB-BSE2: operation winch 5 Crane engine in overspeed Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5464	LSB-BSE2: operation winch 5 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A362		B	
2D546F	LSB-BSE2: operation winch 5 Shut off both limit switches "WA-Bock bottom" incorrect / missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5470	LSB-BSE2: operation winch 5 shut-down both limit switches "flap in position" defect./missing	A362		B	
2D5472	LSB-BSE2: operation winch 5 shut-down both angle sensors "fly jib" defective/missing Operation conditional switch off, may not be shunted Luff down jib until limit switch no longer activated - shut-down may not be activated	A362		B	
2D5473	LSB-BSE2: operation winch 5 shut-down both limit switches "lower fly jib" defective/missing	A362		B	
2D5474	LSB-BSE2: operation winch 5 shut-down both limit switches "upper fly jib flap" defect./missing	A362		B	
2D5475	LSB-BSE2: operation winch 5 shut-down both limit switches "upper fly jib stop"defect./missing Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D547A	LSB-BSE2: operation winch 5 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D547B	LSB-BSE2: operation winch 5 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D547C	LSB-BSE2: operation winch 5 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D547D	LSB-BSE2: operation winch 5 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A362		B	
2D547E	LSB-BSE2: operation winch 5 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5481	LSB-BSE2: operation winch 5 end of stroke switch 1 shut-down defective operational shut down	A362		B	
2D5482	LSB-BSE2: operation winch 5 end of stroke switch 2 shut-down defective operational shut down	A362		B	
2D5483	LSB-BSE2: operation winch 5 end of stroke switch 3 shut-down defective operational shut down	A362		B	
2D5489	LSB-BSE2: operation winch 5 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D548A	LSB-BSE2: operation winch 5 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D548C	LSB-BSE2: operation winch 5 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A362		B	
2D5490	LSB-BSE2: operation winch 5 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A362		B	
2D549A	LSB-BSE2: operation winch 5 Shut off Pressure relapse cyl. Main boom less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D549B	LSB-BSE2: operation winch 5 Shut off Pressure relapse cyl. Derrick less than min. pressure Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D549C	LSB-BSE2: operation winch 5 Shut off pressure sensor RFP-N erroneous / missing	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D54AB	LSB-BSE2: operation winch 5 Shut off Upper limit angle Superstr. access. (geometry load chart) Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D54AC	LSB-BSE2: operation winch 5 Shut off Lower limit angle chassis access. (geometry, load chart) Operational shut off release master switch - error elimination see corresponding system error	A362		B	
2D54AD	LSB-BSE2: operation winch 5 Shut off upper relative limit angle acc. reached / exceeded	A362		B	
2D54AF	LSB-BSE2: operation winch 5 Shut off Danger of collision between support and flap	A362		B	
2D54BA	LSB-BSE2: operation winch 5 Winch operating temp. exceeded reduce output !	A362		B	
2D54BB	LSB-BSE2: operation winch 5 Shut off limit angle folded down reached luff accessories up operational shut down Operate derrick boom in operating position - shut-down may be shunted (danger).	A362		B	
2D54BC	LSB-BSE2: operation winch 5 UGW HA Erection force reached - activate switch boom on ground	A362		B	
2D54BF	LSB-BSE2: operation winch 5 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D54C0	LSB-BSE2: operation winch 5 Shut off test point 3 > F max - Montage	A362		B	
2D54C7	LSB-BSE2: operation winch 5 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D54C8	LSB-BSE2: operation winch 5 Shut off test point 2 > F max - assembly	A362		B	
2D54C9	LSB-BSE2: operation winch 5 Shut off test point 2 < F min	A362		B	
2D54E0	LSB-BSE2: operation winch 5 Shut off Flap bottom fixed jib not Position	A362		B	
2D54E1	LSB-BSE2: operation winch 5 Shut off Flap top fixed jib not Position	A362		B	
2D54E2	LSB-BSE2: operation winch 5 Shut off Danger of collision ACC with fixed jib - ACC up possible	A362		B	
2D54E6	LSB-BSE2: operation winch 5 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D54E7	LSB-BSE2: operation winch 5 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A362		B	
2D54E8	LSB-BSE2: operation winch 5 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A362		B	
2D5504	LSB-BSE2: operation winch 6 unreeled winch shut-down Operation conditional switch off, may not be shunted enter correct operation mode or dismantle accessory parts - shut-down cannot be shunted	A362		B	
2D5505	LSB-BSE2: operation winch 6 reeled winch shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D550F	LSB-BSE2: operation winch 6 Shut off winch, brake not completely released	A362		B	
2D5518	LSB-BSE2: operation winch 6 Shut-down measuring point 1 < F min operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D5519	LSB-BSE2: operation winch 6 no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D551F	LSB-BSE2: operation winch 6 Shut off LMB not active operational shut down check section in the LS-strut, LICCON output, line to short, pressure switch function	A362		B	
2D5520	LSB-BSE2: operation winch 6 LMB shut-down operational shut down Winch 6 released in control view	A362		B	
2D5521	LSB-BSE2: operation winch 6 Shut-down measuring point 1 > F max - operation	A362		B	
2D5522	LSB-BSE2: operation winch 6 Shut-down measuring point 1 > F max - assembly	A362		B	
2D5524	LSB-BSE2: operation winch 6 Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5525	LSB-BSE2: operation winch 6 Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Lower load or set down derrick counterweight if possible or wind off luffing gear if possible.	A362		B	
2D5526	LSB-BSE2: operation winch 6 Shut-down upper limit angle derrick OGWD Operation conditional switch off, may not be shunted Check engine RPM shut off cannot be bypassed	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5527	LSB-BSE2: operation winch 6 Shut-down lower limit angle derrick UGWD	A362		B	
2D5529	LSB-BSE2: operation winch 6 winch blocked (C-key monitor) operational shut down reel in winch until the "winch reeled out" switch is no longer actuated - shut-down cannot be shunted	A362		B	
2D552A	LSB-BSE2: operation winch 6 Winch locked (TE-Module) Operation conditional switch off, may not be shunted Release winch in TE1	A362		B	
2D552E	LSB-BSE2: operation winch 6 Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D552F	LSB-BSE2: operation winch 6 Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A362		B	
2D5531	LSB-BSE2: operation winch 6 master switch 2 defective/missing operational shut down Start crane engine. For testing activate "without engine" bypass (Monitor)	A362		B	
2D5532	LSB-BSE2: operation winch 6 master switch 3 defective/missing Operation conditional switch off, may not be shunted Check: -sensor for function, cables for interruption or short circuit	A362		B	
2D5537	LSB-BSE2: operation winch 6 Winch rotational sensor faulty / missing operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5539	LSB-BSE2: operation winch 6 seat contact shut-down operational shut down Actuate seat contact or press deadman	A362		B	
2D553C	LSB-BSE2: operation winch 6 Shut off test point 8 > F max Assembly roll	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D553E	LSB-BSE2: operation winch 6 Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D553F	LSB-BSE2: operation winch 6 Shut off Test point 8 erroneous / missing	A362		B	
2D5544	LSB-BSE2: operation winch 6 Shut-off crane engine not running Emergency shut-down - raising / lowering winch only possible in emergency operation Check why "Winch wound out" shut-off did not function, lifting/lowering only possible with emergency operation (danger)	A362		B	
2D5549	LSB-BSE2: operation winch 6 Shut-down hoist limit switch 4 operational shut down	A362		B	
2D554A	LSB-BSE2: operation winch 6 Shut off Hoist limit switch 5 operational shut down	A362		B	
2D554B	LSB-BSE2: operation winch 6 Shut off upper relative limit angle Derrick ORGWD operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D554E	LSB-BSE2: operation winch 6 Shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	
2D554F	LSB-BSE2: operation winch 6 Shut off control is off output of error Restart crane monitors and wait until control booted up.	A362		B	
2D5550	LSB-BSE2: operation winch 6 end of stroke switch shut-down 1 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	
2D5551	LSB-BSE2: operation winch 6 end of stroke switch shut-down 2 operational shut down Spool winch out until hoist limit switch is no longer actuated	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5552	LSB-BSE2: operation winch 6 end of stroke switch shut-down 3 operational shut down	A362		B	
2D5557	LSB-BSE2: operation winch 6 Shut-down press. SA-frame overtop guard cylinder < minimal press. Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D555E	LSB-BSE2: operation winch 6 Shut off pressure difference ballast cylinder A/B too large Operational shut off Block ballast cyl. with individual movement cylinder A or B and move into force reducing movement	A362		B	
2D555F	LSB-BSE2: operation winch 6 Shut off Winch, Pressure too high at actuated pump operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5562	LSB-BSE2: operation winch 6 Emerg. shut-off winch-winch rotational sensor interrupts brake control Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5563	LSB-BSE2: operation winch 6 Crane engine in overspeed	A362		B	
2D5564	LSB-BSE2: operation winch 6 Release pressure of brake fallen below Operation conditional switch off, may not be shunted Reestablish charge pressure supply - shut-down may not be shunted	A362		B	
2D557A	LSB-BSE2: operation winch 6 Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D557B	LSB-BSE2: operation winch 6 Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D557C	LSB-BSE2: operation winch 6 Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D557D	LSB-BSE2: operation winch 6 Shut off Radio assembly BTT-E max pulled Ballast exceeded	A362		B	
2D557E	LSB-BSE2: operation winch 6 Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D5581	LSB-BSE2: operation winch 6 end of stroke switch 1 shut-down defective operational shut down	A362		B	
2D5582	LSB-BSE2: operation winch 6 end of stroke switch 2 shut-down defective operational shut down	A362		B	
2D5583	LSB-BSE2: operation winch 6 end of stroke switch 3 shut-down defective operational shut down	A362		B	
2D5589	LSB-BSE2: operation winch 6 Shut-down hoist limit switch 4 faulty operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D558A	LSB-BSE2: operation winch 6 Shut off Hoist limit switch 5 erroneous operational shut down the "STOP" symbol appears in operation screen, the cause can be displayed through an LMB error output	A362		B	
2D558C	LSB-BSE2: operation winch 6 Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A362		B	
2D5590	LSB-BSE2: operation winch 6 hoisting gear pressure switch shut-down operational shut down reel out winch until the "winch reeled in" switch is no longer actuated -shut-down cannot be shunted	A362		B	
2D559A	LSB-BSE2: operation winch 6 Shut off Pressure relapse cyl. Main boom less than min. pressure operational shut down Bring master switch to zero pos., check why pressure is less than expected pressure. LSB	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D559B	LSB-BSE2: operation winch 6 Shut off Pressure relapse cyl. Derrick less than min. pressure operational shut down Bring master switch to zero pos., check why pressure is less than expected pressure. LSB	A362		B	
2D55BA	LSB-BSE2: operation winch 6 Winch operating temp. exceeded reduce output !	A362		B	
2D55BF	LSB-BSE2: operation winch 6 Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D55C7	LSB-BSE2: operation winch 6 Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release master switch – check sensor, lines, check plug	A362		B	
2D55E6	LSB-BSE2: operation winch 6 Shut-off pressure supply relapse cylinder SA-FRAME missing Operation conditional switch off, may not be shunted Re-establish pressure supply SA-frame - shut-down may not be shunted.	A362		B	
2D55E7	LSB-BSE2: operation winch 6 Shut-off pressure supply relapse cylinder main boom missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder main boom - shut-off cannot be bridged.	A362		B	
2D55E8	LSB-BSE2: operation winch 6 Shut-off pressure supply relapse cylinder derrick missing Operation conditional switch off, may not be shunted Reestablish pressure supply relapse cylinder derrick - shut-off cannot be bridged.	A362		B	
2D5601	LSB-BSE2: operation telescoping Shut off TY-frame not in position operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D5602	LSB-BSE2: operation telescoping Shut off TY Latch not open operational shut down Press button "Preselection page A/B" until both pages A and B are preselected	A362		B	
2D5610	LSB-BSE2: operation telescoping fly jib upper stop shut-down	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5611	LSB-BSE2: operation telescoping fly jib upper flap shut-down	A362		B	
2D5612	LSB-BSE2: operation telescoping shut-down as lower fly jib and NA-boom 3 not positioned	A362		B	
2D5614	LSB-BSE2: operation telescoping pressure retaining cylinder RFP N shut-down outside set range	A362		B	
2D5624	LSB-BSE2: operation telescoping Shut-off angle TY-tensioning not within set specification operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D5625	LSB-BSE2: operation telescoping Shut off Pressure switch reports brake TY-winch left closed operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D5626	LSB-BSE2: operation telescoping Shut off Pressure switch reports brake TY-winch right closed operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D5637	LSB-BSE2: operation telescoping Winch turn sensor TY Winch erroneous / missing operational shut down Release master switch - select telescope in function	A362		B	
2D564E	LSB-BSE2: operation telescoping Shut off emerg. off not active	A362		B	
2D564F	LSB-BSE2: operation telescoping Shut off control is off	A362		B	
2D565E	LSB-BSE2: operation telescoping Shut off limit switch "Main boom steep ok" erroneous / missing	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D565F	LSB-BSE2: operation telescoping Shut-down limit switch main boom steep	A362		B	
2D5670	LSB-BSE2: operation telescoping shut-down both limit switches "flap in position" defect./missing	A362		B	
2D5671	LSB-BSE2: operation telescoping shut-down both limit switches "NA-boom 3 pos." defect./missing	A362		B	
2D5672	LSB-BSE2: operation telescoping shut-down both angle sensors "fly jib" defective/missing	A362		B	
2D5673	LSB-BSE2: operation telescoping shut-down both limit switches "lower fly jib" defective/missing operational shut down extend tele cylinder until limit switch no longer activated - shut-down cannot be shunted	A362		B	
2D5674	LSB-BSE2: operation telescoping shut-down both limit switches "upper fly jib flap" defect./missing	A362		B	
2D5675	LSB-BSE2: operation telescoping shut-down both limit switches "upper fly jib stop"defect./missing	A362		B	
2D5677	LSB-BSE2: operation telescoping Shut off Limit switch TY-frame Position right erroneous / missing operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D5678	LSB-BSE2: operation telescoping Shut off Limit switch TY-frame Position left erroneous / missing operational shut down activate "TA-strut luffing up" key until the symbol "TA-strut in position" is displayed	A362		B	
2D5685	LSB-BSE2: operation telescoping Shut-off rotary sensor TY-tensioning left-hand faulty / missing operational shut down Fold in TA-frame to determined angle via key "Fold in TY-tensioning" in the instrument panel	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5686	LSB-BSE2: operation telescoping Shut-off rotary sensor TY-tensioning right-hand faulty / missing operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D5697	LSB-BSE2: operation telescoping Shut off TY Side A not preselected	A362		B	
2D5698	LSB-BSE2: operation telescoping Shut off TY Side B not preselected operational shut down Release master switch - select telescope in function	A362		B	
2D5699	LSB-BSE2: operation telescoping Limit switch "Gear number Winch A" erroneous / missing operational shut down activate "open pawl" key until the symbol "pawl opened" is displayed	A362		B	
2D569A	LSB-BSE2: operation telescoping Limit switch "Gear number Winch B" erroneous / missing operational shut down Press button "Preselection page A/B" until both pages A and B are preselected	A362		B	
2D569B	LSB-BSE2: operation telescoping Shut off TY Winch A is spooled out	A362		B	
2D569C	LSB-BSE2: operation telescoping Shut off TY Winch B is spooled out	A362		B	
2D5747	LSB-BSE2: operation luffing Warning luffing up, dropping of load with reduction of reach	A362		B	
2D5748	LSB-BSE2: operation luffing Shut-down luffing up, dropping of load with reduction of reach	A362		B	
2D574B	LSB-BSE2: operation luffing Reducing erection forces at reduction radius	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D574E	LSB-BSE2: operation luffing Shut off emerg. off not active	A362		B	
2D574F	LSB-BSE2: operation luffing Shut off control is off	A362		B	
2D5801	LSB-BSE2: operation slewing Shut-off ballast not lifted, confirm with key button Operational shut off Lift up ballast and confirm with "Ballast lifted" key button	A362		B	
2D5802	LSB-BSE2: operation slewing Shut-down counterweight on ground Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5803	LSB-BSE2: operation slewing Shut-down support counterweight carriage is not retracted Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5804	LSB-BSE2: operation slewing Shut-down wheels counterweight carriage not in rotary position Operation conditional switch off, may not be shunted With the pre-selection key "Rotary travel BW" turn the wheels of the counterweight carriage (BW) into turning position	A362		B	
2D5806	LSB-BSE2: operation slewing Shutdown slewing gear brake not released	A362		B	
2D5807	LSB-BSE2: operation slewing Shut off Slewing gear coasting not possible, pressure too high	A362		B	
2D5808	LSB-BSE2: operation slewing shut-down slewing right working area limitation ABB Operation conditional switch off, may not be shunted eliminate error see corresponding system error	A362		B	
2D5809	LSB-BSE2: operation slewing shut-down slewing left working area limitation ABB	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D580A	LSB-BSE2: operation slewing Shut off Ballast/Ballast trailer swing Block Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate master switch.	A362		B	
2D5813	LSB-BSE2: operation slewing Shut off slewing gear non-permissible mode operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A362		B	
2D5819	LSB-BSE2: operation slewing no or invalid operation mode shut-down operational shut down slew left until crane is within support area again - shut-down can be shunted (danger)	A362		B	
2D581F	LSB-BSE2: operation slewing Shut off LMB not active operational shut down check why LMB not running. Operating mode OK, sensor defective, read out LMB error	A362		B	
2D5820	LSB-BSE2: operation slewing shut-down slewing right LMB Operation conditional switch off, may not be shunted	A362		B	
2D5821	LSB-BSE2: operation slewing shut-down slewing left LMB Operation conditional switch off, may not be shunted	A362		B	
2D5822	LSB-BSE2: operation slewing Shut-down right-hand swing maximum load exceeded	A362		B	
2D5823	LSB-BSE2: operation slewing Shut-down left-hand swing maximum load exceeded Operation conditional switch off, may not be shunted eliminate error see corresponding system error	A362		B	
2D582F	LSB-BSE2: operation slewing Master switch mode not active operational shut down slew right until crane is in working area again - shunting through shut-down of working area limitation	A362		B	
2D5831	LSB-BSE2: operation slewing Master switch 2 faulty/not present operational shut down Start crane engine. For test purposes actuate bridging "without engine" (control ON without engine).	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5837	LSB-BSE2: operation slewing Selection Turning without selection parking brake slewing gear open Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5839	LSB-BSE2: operation slewing seat contact shut-down report of error, otherwise no reaction	A362		B	
2D583C	LSB-BSE2: operation slewing Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D583E	LSB-BSE2: operation slewing Shut off master switch zero position forced operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5844	LSB-BSE2: operation slewing Shut-off crane engine not running	A362		B	
2D5849	LSB-BSE2: operation slewing Shut off pressure difference ballast cylinder A/B too large Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D584D	LSB-BSE2: operation slewing Shut off radio interruption	A362		B	
2D584E	LSB-BSE2: operation slewing Shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	
2D584F	LSB-BSE2: operation slewing Shut off control is off	A362		B	
2D5852	LSB-BSE2: operation slewing Shut-down measuring point 1 > F max - operation Operational shut off Move out with another gear from shut off. Run F1 force improved function winch 3,4 Ballast cylinder	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5853	LSB-BSE2: operation slewing Shut-down measuring point 1 > F max - assembly Operational shut off Move out with another gear from shut off. Run F1 force improved function winch 3,4 Ballast cylinder	A362		B	
2D5854	LSB-BSE2: operation slewing Shut-down overtopping guard cylinder main boom in bump stop operational shut down Press "A-Stop" key or "B-Stop" key to move only one ballast cylinder to equalize forces in side A/B	A362		B	
2D5855	LSB-BSE2: operation slewing Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5858	LSB-BSE2: operation slewing Shut-down guide frame - counterweight bump stop upper Operation conditional switch off, may not be shunted With the pre-selection key "Rotary travel BW" turn the wheels of the counterweight carriage (BW) into turning position	A362		B	
2D5859	LSB-BSE2: operation slewing Shut-down guide frame - counterweight bump stop lower operational shut down slew left until crane is within support area again - shut-down can be shunted (danger)	A362		B	
2D5870	LSB-BSE2: operation slewing Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5871	LSB-BSE2: operation slewing Shut-down lim switch "Count. on ground" vo. right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5872	LSB-BSE2: operation slewing Shut-down lim switch "Count. on ground" hi. left faulty/not present Operational shut-down, shuntable via raised key switch B/BW - only switch on if B/BW safely raised If possible raise the wheels via lifting the load or reducing the mounted suspended counterweight	A362		B	
2D5873	LSB-BSE2: operation slewing Shut-down lim switch "Count. on ground" hi. right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5874	LSB-BSE2: operation slewing Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Retract support cylinder counterweight carriage completely	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5875	LSB-BSE2: operation slewing Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5876	LSB-BSE2: operation slewing Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D5877	LSB-BSE2: operation slewing Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D5878	LSB-BSE2: operation slewing Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D5879	LSB-BSE2: operation slewing Shut off Radio assembly BTT-E max pulled Ballast exceeded	A362		B	
2D587A	LSB-BSE2: operation slewing Shut off limit switch B/BW swing left front erroneous/missing Operation conditional switch off, may not be shunted	A362		B	
2D587B	LSB-BSE2: operation slewing Shut off limit switch B/BW swing right front erroneous/missing Operation conditional switch off, may not be shunted	A362		B	
2D587C	LSB-BSE2: operation slewing Shut off limit switch B/BW swing left rear erroneous/missing Operation conditional switch off, may not be shunted	A362		B	
2D587D	LSB-BSE2: operation slewing Shut off limit switch B/BW swing right rear erroneous/missing	A362		B	
2D587E	LSB-BSE2: operation slewing Shut off BT swing lateral angle sensor le/ri erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D587F	LSB-BSE2: operation slewing Shut off BT swing max. lateral angle exceeded Operation conditional switch off, may not be shunted With the ballast trailer move from shut off angle in operating angle	A362		B	
2D5880	LSB-BSE2: operation slewing Shut off BT pull force sensor le/ri erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A362		B	
2D5881	LSB-BSE2: operation slewing Shut off BT pull force > Fmax Operation conditional switch off, may not be shunted With ballast trailer move into operating force	A362		B	
2D5882	LSB-BSE2: operation slewing Shut off limit switch "Ballast on ground" not on SPMT Operation conditional switch off, may not be shunted The 4 limit switches "Ballast on ground" must sit on SPMT and be switched. with ballast cylinder or winch	A362		B	
2D5885	LSB-BSE2: operation slewing Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5886	LSB-BSE2: operation slewing Shut-down limit switch "RFP Main boom" links faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5887	LSB-BSE2: operation slewing Shut-down limit switch "Overtop guard cyl D" right faulty/not prese Operation conditional switch off, may not be shunted Wind off main boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A362		B	
2D5888	LSB-BSE2: operation slewing Shut-down limit switch "Overtop guard cyl D" left faulty/not presen Operation conditional switch off, may not be shunted Wind off derrick boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A362		B	
2D5890	LSB-BSE2: operation slewing Slewing platform not bolted or impermissible bolting condition Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5893	LSB-BSE2: operation slewing Shut-down limit switch right "Lower count. block" faulty/not pre Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5894	LSB-BSE2: operation slewing Shut-down limit switch "Lower count. block" left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5895	LSB-BSE2: operation slewing Shut-down limit switch "Upper count. block" right faulty/not present Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A362		B	
2D5896	LSB-BSE2: operation slewing Shut-down limit switch "Upper count. block" left faulty/not present Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A362		B	
2D5897	LSB-BSE2: operation slewing Shut-down limit switch "Count. bolted" right faulty/not present Operational shut-off in BT operation Check wiring, check sensor	A362		B	
2D5898	LSB-BSE2: operation slewing Shut-down limit switch "Count. bolted" left faulty/not present Operational shut-off in BT operation Check wiring, check sensor	A362		B	
2D5899	LSB-BSE2: operation slewing Ballast trailer (BW) is not pinned Operation conditional switch off, may not be shunted Check for installation to suit op. if installed/pinned check signal	A362		B	
2D589A	LSB-BSE2: operation slewing Ballast trailer (BW) is not installed (pilot contact) Operation conditional switch off, may not be shunted Check for installation to suit op. and check signal	A362		B	
2D589B	LSB-BSE2: operation slewing Shut off brake pressure BW drive brake not open Operational shut off Check brake pressure of service brake why it doesn't open	A362		B	
2D58B3	LSB-BSE2: operation slewing Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A362		B	
2D5A4E	LSB-BSE2: operation additional equipment Shut off emerg. off not active	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5A4F	LSB-BSE2: operation additional equipment Shut off control is off	A362		B	
2D5B02	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down counterweight on ground Operational shut-down, shuntable via raised key switch B/BW - only switch on if B/BW safely raised	A362		B	
2D5B03	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down support counterweight carriage is not retracted Operation conditional shut-down, may not be shunted. Retract support cylinder counterweight carriage completely.	A362		B	
2D5B04	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down counterweight carriage telescoping blocked Operational shut-down, shuntable via raised key switch B/BW - only switch on if B/BW safely raised Press "Tow-travel on" key until the wheels are in the travel direction and the indicator lamp remains lit.	A362		B	
2D5B08	LSB-BSE2: Operation ballasting / counterweight carriage Counterweight carriage (BW) is inserted but not yet bolted report of error, otherwise no reaction Bolt or unplug counterweight carriage.	A362		B	
2D5B09	LSB-BSE2: Operation ballasting / counterweight carriage BW is bolted but not inserted - dummy plug is inserted Control op. type with counterweight carriage is switched over to - req.s for operation with BW must be met. Unbolt or plug in counterweight carriage.	A362		B	
2D5B0C	LSB-BSE2: Operation ballasting / counterweight carriage Shut off support ballast trailer is retracted Operation conditional switch off, may not be shunted Move support Ballast trailer in	A362		B	
2D5B0D	LSB-BSE2: Operation ballasting / counterweight carriage Shut off BW steering wheel set not free operational shut down Switch in other permissible BW operating mode and bring BW in permissible pos.	A362		B	
2D5B10	LSB-BSE2: Operation ballasting / counterweight carriage No counterweight inserted or dummy plug not inserted report of error, otherwise no reaction Plug in dummy plug.	A362		B	
2D5B11	LSB-BSE2: Operation ballasting / counterweight carriage Counterweight carriage (BW) is bolted but not inserted Unbolt or plug in counterweight carriage.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B13	LSB-BSE2: Operation ballasting / counterweight carriage Set B-table does not match the installed entries from B/BW Shut-down due to unclear recognition of assembly condition. Set load chart correctly or mount B/BW in accordance with the table setting.	A362		B	
2D5B14	LSB-BSE2: Operation ballasting / counterweight carriage Suspended counterweight (B) mounted but no B-table set Conversion to control operation type with suspended counterweight - requirements for operation with B must be met. Set load chart correctly or mount B/BW in accordance with the table setting.	A362		B	
2D5B16	LSB-BSE2: Operation ballasting / counterweight carriage Ballast trailer is stretched, not pinned and support retracted Error message as well as no release of turn and drive crawler The two BT limit switches not supported may not have switched, support must be extended	A362		B	
2D5B17	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast automatic Operational shut off Manually drive into permissible F1 range or out of shut-off, shut off the spline cylinder or ballast cylinder	A362		B	
2D5B18	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down measuring point 1 < F min	A362		B	
2D5B19	LSB-BSE2: Operation ballasting / counterweight carriage no or invalid operation mode shut-down operational shut down Turn master switch to zero position. Otherwise note system error for defective or missing sensors.	A362		B	
2D5B1A	LSB-BSE2: Operation ballasting / counterweight carriage Shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	
2D5B1B	LSB-BSE2: Operation ballasting / counterweight carriage Shut off control is off output of error Restart crane monitors and wait until control booted up.	A362		B	
2D5B1C	LSB-BSE2: Operation ballasting / counterweight carriage Master switch mode not active operational shut down Sit down (seat limit switch) or deadman (in master switch) or check: - Input UEA, sensor line, sensor	A362		B	
2D5B1D	LSB-BSE2: Operation ballasting / counterweight carriage seat contact shut-down Operational shut off Cancel shut-off, sit on the driver's seat or actuate deadman on the master switch	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B1E	LSB-BSE2: Operation ballasting / counterweight carriage Shut off derrick angle not in op. position Operational shut off, only bypassable when derrick placed down With Derrick move further to rear in op. angle	A362		B	
2D5B1F	LSB-BSE2: Operation ballasting / counterweight carriage Shut off LMB not active operational shut down briefly release master switch, or error elimination see corresponding system error	A362		B	
2D5B20	LSB-BSE2: Operation ballasting / counterweight carriage LMB shut-down Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5B21	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down measuring point 1 > F max - operation Operation conditional switch off, may not be shunted Press button Ballast "Up / down" only if winch 4 is not actuated	A362		B	
2D5B22	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down measuring point 1 > F max - assembly Operation conditional switch off, may not be shunted Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5B24	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down measuring point 1 < F min and count. utilisation > 50% Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	
2D5B25	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down measuring point 1 < F min and count. utilisation > 90% Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	
2D5B29	LSB-BSE2: Operation ballasting / counterweight carriage Shut-off ballast cylinder A-B length difference too large Output of error, crane function is not selected. Move the ballast cylinders together in individual operation. Move the two ballast cylinders to the same length	A362		B	
2D5B2A	LSB-BSE2: Operation ballasting / counterweight carriage Shut off brake pressure BW drive brake not open Operational shut off Check brake pressure of service brake why it doesn't open	A362		B	
2D5B2C	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Drive back into a permissible position	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B2D	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Drive back into a permissible position	A362		B	
2D5B2E	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Drive back into a permissible position	A362		B	
2D5B2F	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Radio assembly BTT-E max pulled Ballast exceeded Operational shut off Drive out of the shut-off in mode without radio with the master switch, only the ballast can be driven	A362		B	
2D5B3A	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast "on" left minimum length reached Issuance of error, crane function is not actuated Run down with ballasting cylinder	A362		B	
2D5B3B	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast "on" right minimum length reached Issuance of error, crane function is not actuated Run down with ballasting cylinder	A362		B	
2D5B3C	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast "off" left maximum length reached Issuance of error, crane function is not actuated Run up with ballasting cyl.	A362		B	
2D5B3D	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast "off" right maximum length reached Issuance of error, crane function is not actuated Run up with ballasting cyl.	A362		B	
2D5B3E	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballasting up / down mandatory zero position operational shut down Bring button to zero pos. and deflect desired movement again	A362		B	
2D5B43	LSB-BSE2: Operation ballasting / counterweight carriage Shut-off wheel set turn sensor erroneous / missing Operation conditional switch off, may not be shunted Check wheel sensor left / right turn sensor on LSB for error or line interruption	A362		B	
2D5B44	LSB-BSE2: Operation ballasting / counterweight carriage Shut-off crane engine not running Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B45	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast "Up / down" due to running winch 4	A362		B	
2D5B49	LSB-BSE2: Operation ballasting / counterweight carriage Shut off pressure difference ballast cylinder A/B too large operational shut down Bypass with key button, in its own responsibility back to good pressure difference with ballast cylinders	A362		B	
2D5B4E	LSB-BSE2: Operation ballasting / counterweight carriage Shut off length sensor ballast cyl. left erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A362		B	
2D5B4F	LSB-BSE2: Operation ballasting / counterweight carriage Shut off length sensor ballast cyl. right erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A362		B	
2D5B50	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast "up / down" due to running winch 3 Issuance of error, crane function is not actuated Do not actuate winch 3 anymore, then ballast can be moved up/down again	A362		B	
2D5B51	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast "In" left block position retracted reached Issuance of error, crane function is not actuated Run down with ballasting cylinder	A362		B	
2D5B52	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast "In" right block position retracted reached Issuance of error, crane function is not actuated Run down with ballasting cylinder	A362		B	
2D5B53	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast on ground lateral incline > max Wert Issuance of error, crane function is not actuated Do not run with stop button A or B into permissible position	A362		B	
2D5B54	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	
2D5B55	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B56	LSB-BSE2: Operation ballasting / counterweight carriage Shut off ballast cylinder A pressure difference A-B too high Issuance of error, crane function is not actuated Move two cyl. via stop button into permissible position to be within pressure difference	A362		B	
2D5B57	LSB-BSE2: Operation ballasting / counterweight carriage Shut off ballast cylinder B pressure difference A-B too high Issuance of error, crane function is not actuated Move two cyl. via stop button into permissible position to be within pressure difference	A362		B	
2D5B58	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down guide frame - counterweight bump stop upper operational shut down Remedy cause of "LMB Stop" see error report LMB - shut-down may be shunted via assembly switch (danger).	A362		B	
2D5B59	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down guide frame - counterweight bump stop lower operational shut down Lower load or raise derrick ballast if possible or lay on additional derrick counterweight if possible.	A362		B	
2D5B5A	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast pallet / BW lateral incline > max side incline Operation conditional switch off, may not be shunted With stop buttons move ballast UP/DOWN/STOP cylinder A / STOP cylinder B knowingly in improved direction	A362		B	
2D5B5B	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast pallet / BW lateral incline < min side incline Operation conditional switch off, may not be shunted With stop buttons move ballast UP/DOWN/STOP cylinder A / STOP cylinder B knowingly in improved direction	A362		B	
2D5B5C	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D5B5D	LSB-BSE2: Operation ballasting / counterweight carriage Shut off test point 1 erroneous / missing Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	
2D5B5E	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Test point 2 erroneous / missing Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	
2D5B5F	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Test point 3 erroneous / missing Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B68	LSB-BSE2: Operation ballasting / counterweight carriage Abschaltung fuer Freigabe Totmann laenger druecken Operational shut off Totmann Taste MS1 fuer 2 sek druecken damit wird Freigabe bestaetigt	A362		B	
2D5B70	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted	A362		B	
2D5B71	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" vo. right faulty/not present Operation conditional switch off, may not be shunted	A362		B	
2D5B72	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" hi. left faulty/not present Operation conditional switch off, may not be shunted	A362		B	
2D5B73	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down lim switch "Count. on ground" hi. right faulty/not present Operation conditional switch off, may not be shunted	A362		B	
2D5B74	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	
2D5B75	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	
2D5B76	LSB-BSE2: Operation ballasting / counterweight carriage Shut off limit switch "Winch frame installed" le. defective/missing Operational shut off Release shut off move into permissible movement	A362		B	
2D5B77	LSB-BSE2: Operation ballasting / counterweight carriage Shut off limit switch "Winch frame installed" ri. defective/missing Operational shut off Release shut off move into permissible movement	A362		B	
2D5B78	LSB-BSE2: Operation ballasting / counterweight carriage Shut-off of both retracted ballast limit switches faulty / missing Operational shut off Release shut off move into permissible movement	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B79	LSB-BSE2: Operation ballasting / counterweight carriage Shut-off of both extended ballast limit switches faulty / missing	A362		B	
2D5B7A	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Limit switch left Ballast retracted erroneous / missing Issuance of error, crane function is not actuated Check wiring, check sensor	A362		B	
2D5B7B	LSB-BSE2: Operation ballasting / counterweight carriage Shut off limit switch right Ballast retracted erroneous/missing Issuance of error, crane function is not actuated Check wiring, check sensor	A362		B	
2D5B7E	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Turn sensor swing B/BW erroneous / missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A362		B	
2D5B7F	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Turn sensor swing B/BW max perm lateral angle exceeded Operation conditional switch off, may not be shunted With ballast trailer / slewing gear move from shut off angle in operating angle	A362		B	
2D5B80	LSB-BSE2: Operation ballasting / counterweight carriage Ballast trailer equipped without swing Issuance of error, crane function is not actuated Install ballast pallet with swing	A362		B	
2D5B85	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Wind off main boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A362		B	
2D5B86	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "RFP Main boom" links faulty/not present operational shut down Press "A-Stop" key or "B-Stop" key to move only one ballast cylinder to equalize forces in side A/B	A362		B	
2D5B87	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Overtop guard cyl D" right faulty/not prese Operation conditional switch off, may not be shunted Wind off derrick boom - adjusting winch until overtopping guard cylinder no longer in bump stop	A362		B	
2D5B88	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Overtop guard cyl D" left faulty/not presen Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B8C	LSB-BSE2: Operation ballasting / counterweight carriage Shut off SA-Operating mode active Operational shut off To move this crane function set up other op. mode which permits this function	A362		B	
2D5B8E	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Length sensor Sliding cyl. erroneous/missing Operational shut off Release shut off by checking LSB Sensor BW-Sliding cyl.	A362		B	
2D5B8F	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Length sensor Sliding cyl. moved out Operational shut off Release shut off by Release shut off move in a perm. movement - sliding cyl. in	A362		B	
2D5B90	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Length sensor Sliding cyl. moved in Operational shut off Release shut off move in a perm. movement – sliding cyl. out	A362		B	
2D5B91	LSB-BSE2: Operation ballasting / counterweight carriage Shut off pressure Relapse cyl. main boom outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5B92	LSB-BSE2: Operation ballasting / counterweight carriage Shut off pressure Relapse cyl. derrick outside nom. range Operation conditional switch off, may not be shunted release master switch - error elimination see corresponding system error	A362		B	
2D5B93	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch right "Lower count. block" faulty/not pre Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A362		B	
2D5B94	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Lower count. block" left faulty/not present Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A362		B	
2D5B95	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Upper count. block" right faulty/not presen Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	
2D5B96	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Upper count. block" left faulty/not present Operation conditional switch off, may not be shunted Release button - for error remedy see corresp. system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5B97	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Count. bolted" right faulty/not present Issuance of error, crane function is not actuated Check LSB-sensor, wiring, pay attention to system error, if nec. Op. mode without BW set up	A362		B	
2D5B98	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down limit switch "Count. bolted" left faulty/not present Issuance of error, crane function is not actuated Check LSB-sensor, wiring, pay attention to system error, if nec. Op. mode without BW set up	A362		B	
2D5B99	LSB-BSE2: Operation ballasting / counterweight carriage Ballast trailer (BW) is not pinned Issuance of error, crane function is not actuated Check LSB-sensor, wiring, pay attention to system error, if nec. Op. mode without BW set up	A362		B	
2D5B9A	LSB-BSE2: Operation ballasting / counterweight carriage Ballast trailer (BW) is not installed (pilot contact) Operation conditional switch off, may not be shunted Check for installation to suit op. and check signal	A362		B	
2D5BB3	LSB-BSE2: Operation ballasting / counterweight carriage Shut off pulled ballast > permissible and pallet not installed operational shut down Insert ballast pallet, sensor monitoring active, or set down ballast pallet, unpin, drive with empty rods	A362		B	
2D5BBC	LSB-BSE2: Operation ballasting / counterweight carriage Shut off lower limit angle HA erection reached luff up HA Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A362		B	
2D5BC0	LSB-BSE2: Operation ballasting / counterweight carriage Shut off test point 3 > F max - Montage Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A362		B	
2D5BC1	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down upper limit angle derrick OGWD Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A362		B	
2D5BC2	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down lower limit angle derrick UGWD Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A362		B	
2D5BC3	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down upper limit angle ULV (geometry, load capacity chart) operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5BC4	LSB-BSE2: Operation ballasting / counterweight carriage Shut-down lower limit value LLV (geometry, load capacity chart) operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A362		B	
2D5BC5	LSB-BSE2: Operation ballasting / counterweight carriage Shut off upper relative limit angle acces. reached / fallen below operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A362		B	
2D5BC6	LSB-BSE2: Operation ballasting / counterweight carriage Shut off upper relative limit angle HA reached / exceeded operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A362		B	
2D5BC7	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Upper limit angle Superstr. access. (geometry load chart) operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A362		B	
2D5BC8	LSB-BSE2: Operation ballasting / counterweight carriage Shut off test point 2 > F max - assembly Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A362		B	
2D5BC9	LSB-BSE2: Operation ballasting / counterweight carriage Shut off test point 2 < F min Output of error, crane function is not selected. Should crane function be required, start engine and re-actuate key.	A362		B	
2D5BCA	LSB-BSE2: Operation ballasting / counterweight carriage Shut off upper relative limit angle OGWD operational shut down Drive out of the shut-off with a permissible crane function into a permissible condition	A362		B	
2D5BCB	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast pressure monitoring not OK	A362		B	
2D5BCC	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast trailer pressure monitoring not OK	A362		B	
2D5BD0	LSB-BSE2: Operation ballasting / counterweight carriage Shut off SPMT control is off	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5BD1	LSB-BSE2: Operation ballasting / counterweight carriage Shut off SPMT turn sensor swing B/BT erroneous/missing operational shut down Plug in bypass plug SPMT, check wiring, check sensor	A362		B	
2D5BD2	LSB-BSE2: Operation ballasting / counterweight carriage Shut off SPMT turn sensor swing B/BT max lateral angle operational shut down Plug in bypass plug SPMT, move with slewing gear out from shut off	A362		B	
2D5BD3	LSB-BSE2: Operation ballasting / counterweight carriage Shut off SPMT limit switch swing front block operational shut down Plug in bypass plug SPMT move with crawler travel gear backward from shut off	A362		B	
2D5BD4	LSB-BSE2: Operation ballasting / counterweight carriage Shut off SPMT limit switch swing rear block operational shut down Plug in bypass plug SPMT move with crawler travel gear forward from shut off	A362		B	
2D5BD5	LSB-BSE2: Operation ballasting / counterweight carriage Shut off SPMT pull force sensor le/ri erroneous/missing operational shut down Plug in bypass plug SPMT, check wiring, check sensor	A362		B	
2D5BD6	LSB-BSE2: Operation ballasting / counterweight carriage Shut off SPMT pull force > Fmax operational shut down Plug in bypass plug SPMT, move with slewing gear out from shut off	A362		B	
2D5BD9	LSB-BSE2: Operation ballasting / counterweight carriage Ballast trailer Emerg. stop chain open since shut off SPMT active operational shut down Plug in bypass plug SPMT	A362		B	
2D5BDF	LSB-BSE2: Operation ballasting / counterweight carriage Shut off Ballast trailer forced zero pos. Operational shut off Release shut off move into permissible movement	A362		B	
2D5BFA	LSB-BSE2: Operation ballasting / counterweight carriage F1 outside perm. Tolerance no selection Ballast automatic Operational shut off Drive into a permissible F1 area in manual mode, drive out of the F1 min or F1 max threshold	A362		B	
2D5BFB	LSB-BSE2: Operation ballasting / counterweight carriage Incline outside perm. Tolerance no selection Ballast automatic Operational shut off Drive into a permissible incline range in manual mode	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5BFD	LSB-BSE2: Operation ballasting / counterweight carriage Releases not present ballast automatic not selectable Operational shut off Sliding cylinder and ballast cylinder releases must be present to activate automatic mode	A362		B	
2D5C01	LSB-BSE2: Operation crawler Shut-off ballast not lifted, confirm with key button Operational shut off Lift up ballast and confirm with "Ballast lifted" key button	A362		B	
2D5C02	LSB-BSE2: Operation crawler Shut-down counterweight on ground Operational shut-down, shunable via raised key switch B/BW - only switch on if B/BW safely raised Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C03	LSB-BSE2: Operation crawler Shut-down support counterweight carriage is not retracted Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C05	LSB-BSE2: Operation crawler Shut-down swing with parallel travel count. carriage not possible Operational shut-down, shunable via raised key switch B/BW - only switch on if B/BW safely raised Press tow-travel key until the wheels are in travel direction and the indicator lamp remains on.	A362		B	
2D5C06	LSB-BSE2: Operation crawler Shut-down swing gear brake has not opened with tow-travel BW Operational shut-down, shunable via raised key switch B/BW - only switch on if B/BW safely raised Check: Brake valve swing gear - electrical selection, short-circuit or interruption, hydraulics.	A362		B	
2D5C07	LSB-BSE2: Operation crawler Shut-down free swing gear is not on with tow-travel BW operational shut down Check: True run or brake swing gear - electrical selection, short-circuit or interruption, hydraulics.	A362		B	
2D5C08	LSB-BSE2: Operation crawler Shut-down swing gear brake has opened with parallel travel BW Operation conditional switch off, may not be shunted Check: Brake valve swing gear - electrical selection, short-circuit following supply voltage, hydraulics.	A362		B	
2D5C09	LSB-BSE2: Operation crawler Shut-down free swing gear is not on with parallel travel BW Operation conditional switch off, may not be shunted Check: True run or brake swing gear - electrical selection, short-circuit or interruption, hydraulics.	A362		B	
2D5C0A	LSB-BSE2: Operation crawler Shut off Ballast/Ballast trailer swing Block	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5C0B	LSB-BSE2: Operation crawler Shut off ballast trailer not lifted off operational shut down Lift off ball. trailer or select ball. trailer oper. mode where crawler driving with ball. trailer not lifted off perm.	A362		B	
2D5C0D	LSB-BSE2: Operation crawler Shutdown slewing gear brake not released	A362		B	
2D5C0E	LSB-BSE2: Operation crawler Shut off Slewing gear coasting not possible, pressure switch not OK	A362		B	
2D5C0F	LSB-BSE2: Operation crawler Shut off drive crawler BW Pull force sensor le/ri erroneous/missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A362		B	
2D5C10	LSB-BSE2: Operation crawler Shut off drive crawler BW Pull force > Fmax Operation conditional switch off, may not be shunted With ballast trailer or slewing gear move into operating force	A362		B	
2D5C12	LSB-BSE2: Operation crawler Shut off drive crawler - Op. mode parallel operation not active operational shut down Activate parallel operation crawler selection TE and parallel driving ballast trailer	A362		B	
2D5C13	LSB-BSE2: Operation crawler Shut-down wheels counterweight carriage not in travel position operational shut down Bring wheels of ballast trailer first into travel pos. or lift off ballast trailer.	A362		B	
2D5C14	LSB-BSE2: Operation crawler Shut-off slewing gear brake closed and freewheeling not free	A362		B	
2D5C18	LSB-BSE2: Operation crawler Shut-off auxiliary support crawler carrier set up Operational shut off Dismantle auxiliary support and set up operating mode without auxiliary support	A362		B	
2D5C19	LSB-BSE2: Operation crawler no or invalid operation mode shut-down Operation conditional switch off, may not be shunted	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5C1A	LSB-BSE2: Operation crawler Shut off BW sliding cylinder movement without actuation Operational shut off Check why sliding cyl. moves or extended without actuation, diagonal pull of ballast trailer	A362		B	
2D5C1F	LSB-BSE2: Operation crawler Shut off LMB not active Operation conditional switch off, may not be shunted check why LMB not running. Operating mode OK, sensor defective, read out LMB error	A362		B	
2D5C28	LSB-BSE2: Operation crawler Drive crawler not possible - crawler not turned on Operation conditional switch off, may not be shunted Activate travel pedals in zero pos. and drive crawler on TE3	A362		B	
2D5C2A	LSB-BSE2: Operation crawler Shut off brake pressure BW drive brake not open Operational shut off Check brake pressure of service brake why it doesn't open	A362		B	
2D5C2D	LSB-BSE2: Operation crawler Master switch mode not active	A362		B	
2D5C33	LSB-BSE2: Operation crawler Parallel operation differential path between crawlers too great Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C39	LSB-BSE2: Operation crawler seat contact shut-down operational shut down Press "A-Stop" key or "B-Stop" key to move only one ballast cylinder to equalize forces in side A/B	A362		B	
2D5C3C	LSB-BSE2: Operation crawler Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D5C3E	LSB-BSE2: Operation crawler Shut off master switch zero position forced Operation conditional switch off, may not be shunted	A362		B	
2D5C40	LSB-BSE2: Operation crawler Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5C41	LSB-BSE2: Operation crawler Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D5C42	LSB-BSE2: Operation crawler Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D5C43	LSB-BSE2: Operation crawler Shut off Radio assembly BTT-E max pulled Ballast exceeded	A362		B	
2D5C44	LSB-BSE2: Operation crawler Shut-off crane engine not running operational shut down Switch off parallel crawler operation and switch on again, parallel operation is thus newly adjusted.	A362		B	
2D5C45	LSB-BSE2: Operation crawler Shut off Brake pressure monitoring Crawler left not OK Operational shut off Bring foot pedal in zero pos., check brake pr. crawler	A362		B	
2D5C46	LSB-BSE2: Operation crawler Shut off Brake pressure monitoring Crawler right not OK Operational shut off Bring foot pedal in zero pos., check brake pr. crawler	A362		B	
2D5C49	LSB-BSE2: Operation crawler Shut off pressure difference ballast cylinder A/B too large Operational shut off Using the key switch, drive the ballast cylinder in individual operation back into a balanced pressure difference	A362		B	
2D5C4D	LSB-BSE2: Operation crawler Shut off radio interruption	A362		B	
2D5C4E	LSB-BSE2: Operation crawler Shut off emerg. off not active	A362		B	
2D5C4F	LSB-BSE2: Operation crawler Shut off control is off	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5C52	LSB-BSE2: Operation crawler Shut-down measuring point 1 > F max - operation Operational shut off Move out with another gear from shut off. Run F1 force improved function winch 3,4 Ballast cylinder	A362		B	
2D5C53	LSB-BSE2: Operation crawler Shut-down measuring point 1 > F max - assembly Operational shut off Move out with another gear from shut off. Run F1 force improved function winch 3,4 Ballast cylinder	A362		B	
2D5C54	LSB-BSE2: Operation crawler Shut-down overtopping guard cylinder main boom in bump stop Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C55	LSB-BSE2: Operation crawler Shut-down overtopping guard cylinder derrick boom in bump stop Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C58	LSB-BSE2: Operation crawler Shut-down guide frame - counterweight bump stop upper operational shut down Bring the master switch to neutral pos. and then deflect the desired movement again	A362		B	
2D5C59	LSB-BSE2: Operation crawler Shut-down guide frame - counterweight bump stop lower operational shut down Using the additional error reports determine which error is present with ballast configuration.	A362		B	
2D5C70	LSB-BSE2: Operation crawler Shut-down lim switch "Count. on ground" vo. left faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C71	LSB-BSE2: Operation crawler Shut-down lim switch "Count. on ground" vo. right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C72	LSB-BSE2: Operation crawler Shut-down lim switch "Count. on ground" hi. left faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C73	LSB-BSE2: Operation crawler Shut-down lim switch "Count. on ground" hi. right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5C74	LSB-BSE2: Operation crawler Shut-down limit switch "Support retracted" vo. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5C75	LSB-BSE2: Operation crawler Shut-down limit switch "Support retracted" hi. faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5C76	LSB-BSE2: Operation crawler Shut off limit switch swing front block Operation conditional switch off, may not be shunted Drive crawler into improved direction possibly until shut off is released again.	A362		B	
2D5C77	LSB-BSE2: Operation crawler Shut off limit switch swing rear block Operation conditional switch off, may not be shunted Drive crawler into improved direction possibly until shut off is released again.	A362		B	
2D5C78	LSB-BSE2: Operation crawler Shut off swing turn sensor front allowance Operation conditional switch off, may not be shunted Drive crawler into improved direction possibly until shut off is released again.	A362		B	
2D5C79	LSB-BSE2: Operation crawler Shut off swing turn sensor rear allowance Operation conditional switch off, may not be shunted Drive crawler into improved direction possibly until shut off is released again.	A362		B	
2D5C7A	LSB-BSE2: Operation crawler Shut off limit switch B/BW swing left front erroneous/missing Operation conditional switch off, may not be shunted	A362		B	
2D5C7B	LSB-BSE2: Operation crawler Shut off limit switch B/BW swing right front erroneous/missing Operation conditional switch off, may not be shunted	A362		B	
2D5C7C	LSB-BSE2: Operation crawler Shut off limit switch B/BW swing left rear erroneous/missing Operation conditional switch off, may not be shunted Control B/BW again into an operational position	A362		B	
2D5C7D	LSB-BSE2: Operation crawler Shut off limit switch B/BW swing right rear erroneous/missing	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5C7E	LSB-BSE2: Operation crawler Shut off Turn sensor swing B/BW erroneous / missing Operation conditional switch off, may not be shunted Check wiring, check sensor	A362		B	
2D5C7F	LSB-BSE2: Operation crawler Shut off Turn sensor swing B/BW max lateral angle Operation conditional switch off, may not be shunted With the ballast trailer move from shut off angle in operating angle	A362		B	
2D5C80	LSB-BSE2: Operation crawler Shut off limit switch "Ballast on ground" not on SPMT Operation conditional switch off, may not be shunted The 4 limit switches "Ballast on ground" must sit on SPMT and be switched. with ballast cylinder or winch	A362		B	
2D5C81	LSB-BSE2: Operation crawler Shut off B/BW lifted off and slewing gear brake open Operation conditional switch off, may not be shunted Slewing gear brake must be applied	A362		B	
2D5C85	LSB-BSE2: Operation crawler Shut-down limit switch "RFP Main boom" right faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C86	LSB-BSE2: Operation crawler Shut-down limit switch "RFP Main boom" links faulty/not present Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C87	LSB-BSE2: Operation crawler Shut-down limit switch "Overtop guard cyl D" right faulty/not prese Operation conditional switch off, may not be shunted Retract support counterweight carriage completely.	A362		B	
2D5C88	LSB-BSE2: Operation crawler Shut-down limit switch "Overtop guard cyl D" left faulty/not presen Operation conditional switch off, may not be shunted Release foot pedal - error remedy see corresponding system error	A362		B	
2D5C93	LSB-BSE2: Operation crawler Shut-down limit switch right "Lower count. block" faulty/not pre Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	
2D5C94	LSB-BSE2: Operation crawler Shut-down limit switch "Lower count. block" left faulty/not present Operation conditional switch off, may not be shunted Release master switch - error remedying see corresponding system error.	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D5C95	LSB-BSE2: Operation crawler Shut-down limit switch "Upper count. block" right faulty/not present Operation conditional switch off, may not be shunted If possible, extend with ballast cylinder, spool up winch 4 or retract support BW move from block position	A362		B	
2D5C96	LSB-BSE2: Operation crawler Shut-down limit switch "Upper count. block" left faulty/not present Operation conditional switch off, may not be shunted If possible, retract with ballast cylinder, spool out winch 4 or extend support BW move from block position	A362		B	
2D5C97	LSB-BSE2: Operation crawler Shut-down limit switch "Count. bolted" right faulty/not present Operational shut-off in BT operation Check wiring, check sensor	A362		B	
2D5C98	LSB-BSE2: Operation crawler Shut-down limit switch "Count. bolted" left faulty/not present Operational shut-off in BT operation Check wiring, check sensor	A362		B	
2D5C99	LSB-BSE2: Operation crawler Ballast trailer (BW) is not pinned Operation conditional switch off, may not be shunted Check for installation to suit op. if installed/pinned check signal	A362		B	
2D5C9A	LSB-BSE2: Operation crawler Ballast trailer (BW) is not installed (pilot contact) Operational shut off Install BW and plug in, also enter one BW Op. mode to allow crawler move	A362		B	
2D5CA2	LSB-BSE2: Operation crawler Shut off: slewing gear turns without actuation Operational shut off When in a BW Op.mode BW drive moves against closed slewing gear br. check b. trailer	A362		B	
2D5CB3	LSB-BSE2: Operation crawler Shut off pulled ballast > permissible and pallet not installed operational shut down Plug in plug for pallet. Then all ballast pallet monitoring is active	A362		B	
2D6109	LSB-BSE2: Operation crane control Movement sel. crane operator s cab at operating mode preheating operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D610A	LSB-BSE2: Operation crane control Movement selection crane op. cab for operating recovery winch	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D6111	LSB-BSE2: Operation crane control Crane motor 2 cannot be added	A362		B	
2D6114	LSB-BSE2: Operation crane control Shut off all crane movements remote loading of software active	A362		E	
2D6117	LSB-BSE2: Operation crane control Shut off Radio BTT-E in crane mode active Operational shut off Crane is in normal op. and cannot be moved with Radio BTT-E. Reload BTT-E	A362		B	
2D611D	LSB-BSE2: Operation crane control Flap bottom in Position at exceeded angle threshold F-jib Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D611E	LSB-BSE2: Operation crane control Flap top in Position at fallen below angle threshold F-jib Error message BSE System which sensors may not be inst. In this op. status Check LSB-sensor for error, incorrect address, connection plug, lines, bridge plug yes/no	A362		E	
2D613E	LSB-BSE2: Operation crane control Shut off master switch zero position forced operational shut down Drive out of the pending shut-off, see operating error for which shut-off is still pending	A362		B	
2D614A	LSB-BSE2: Operation crane control Selection bypass LMB - not permissible for this utilization	A362		B	
2D6155	LSB-BSE2: Operation crane control Selection bypass LMB not permissible for this F1-utilization	A362		B	
2D615A	LSB-BSE2: Operation crane control Shut off Plug emerg. operation active operational shut down release master switch - error elimination see corresponding system error	A362		B	
2D615B	LSB-BSE2: Operation crane control Selection bypass hoist top not possible - no shut off	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D615C	LSB-BSE2: Operation crane control Selection this bypass not possible - sensor defect	A362		B	
2D615D	LSB-BSE2: Operation crane control Bypass LMB not possible - Max. pressure luffing cylinder reached	A362		B	
2D615F	LSB-BSE2: Operation crane control Selection bypass not possible - crane engine still running	A362		B	
2D6160	LSB-BSE2: Operation crane control Selection bypass not possible - seat contact not actuated	A362		B	
2D6161	LSB-BSE2: Operation crane control Selection bypass not possible - radio op. active	A362		B	
2D6162	LSB-BSE2: Operation crane control Selection bypass not possible - zero pos. force required	A362		B	
2D616E	LSB-BSE2: Operation crane control Replenishing pressure - supply Aggregate 1 too small	A362		E	
2D616F	LSB-BSE2: Operation crane control Replenishing pressure - supply Aggregate 2 too small	A362		E	
2D6176	LSB-BSE2: Operation crane control Shut off Radio assembly BTT-E Main boom angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D6177	LSB-BSE2: Operation crane control Shut off Radio assembly BTT-E Derrick angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D6178	LSB-BSE2: Operation crane control Shut off Radio assembly BTT-E Accessory angle exceeded Operational shut off Release shut off move into permissible movement	A362		B	
2D6179	LSB-BSE2: Operation crane control Shut off Radio assembly BTT-E max pulled Ballast exceeded Operational shut off Drive out of the shut-off in mode without radio with the master switch, only the ballast can be driven	A362		B	
2D61A0	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off LMB operational shut down Bring crane into a driveable status / position (drivable gears) without LMB Stop	A362		B	
2D61A1	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off crane engine not running Operation conditional switch off, may not be shunted Release master switch – Error remedy see respective system error	A362		B	
2D61A2	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off LMB not active operational shut down	A362		B	
2D61A3	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off seat contact operational shut down Actuate seat contact or press deadman button	A362		B	
2D61A4	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off no or invalid op. mode operational shut down Check LSB Sensor which are active and assigned for the desired to be driving /Operating mode	A362		B	
2D61A5	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off emerg. off not active operational shut down Check EMERG. OFF	A362		B	
2D61A6	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off control is off operational shut down Turn control ON, turn LICCON on	A362		B	
2D61A7	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off SA-frame not in op. angle operational shut down Move SA-frame with winch 4 in op.window where the assembly cyl. may be moved	A362		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2D61A8	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off Ring surface block operational shut down Move the assembly cyl. up	A362		B	
2D61A9	LSB-BSE2: Operation crane control SA-frame Assembly cylinder shut off pressure monitoring not OK operational shut down Check assembly cylinder pressure sensor for errors, check LSB diagnostics of the sensor, wiring	A362		B	
2D61AA	LSB-BSE2: Operation crane control Assembly Derrick not correct - pin guying on D-end section	A362		B	
2D7210	LSB-BSE2: ABB, working range limitation Programmed edge runs through swing ring center	A362		E	1
2D7280	LSB-BSE2: ABB, working range limitation Operation: Slewing angle outside of the permissible range.	A362		E	1
2DD01E	LSB-BSE2: Supply voltage 15.3 / CPU0 Voltage outside permissible range error report Check voltage, electr. connections and fuse	A362.X1:1		E	2
2DD11E	LSB-BSE2: Supply voltage 30.3 / CPU0 Voltage outside permissible range error report Check battery, electr. connections and fuse	A362.X1:2		E	2
2DDE14	LSB-BSE2: Analog input 0E0 / DSP0 short circuit to supply voltage error report Check DSP0-output A0.0, relay, electr. connections	A362.X4:3		E	2
2DDF14	LSB-BSE2: Analog input 0E1 / DSP0 short circuit to supply voltage error report Check DSP0-output A0.0, relay, electr. connections	A362.X4:4		E	2
2DE012	LSB-BSE2: Analog input 0E2 / DSP0 short circuit to ground error report Check Em. Off switch, voltage, electr. connections	A362.X4:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2DE117	LSB-BSE2: Supply voltage 30.1 / DSP0 voltage below required value error indication on display Check battery, voltage, electr. connections and fuse	A362.X4:7		E	2
2DE217	LSB-BSE2: Supply voltage 15.1 / DSP0 voltage below required value error indication on display Check voltage	A362.X4:8		E	2
2DE317	LSB-BSE2: Supply voltage 24V.1 (0A0-1) / DSP0 voltage below required value error indication on display Check voltage, electr. connections and fuse	A362.X4:15		E	2
2DE614	LSB-BSE2: Analog input 1E0 / DSP1 short circuit to supply voltage error report Check DSP1-output A0.0, relay, electr. connections	A362.X5:3		E	2
2DE714	LSB-BSE2: Analog input 1E1 / DSP1 short circuit to supply voltage error report Check DSP1-output A0.0, relay, electr. connections	A362.X5:4		E	2
2DE812	LSB-BSE2: Analog input 1E2 / DSP1 short circuit to ground error report Check Em. Off switch, voltage, electr. connections	A362.X5:5		E	2
2DE917	LSB-BSE2: Supply voltage 30.1 / DSP1 voltage below required value error indication on display Check battery, voltage, electr. connections and fuse	A362.X5:7		E	2
2DEA17	LSB-BSE2: Supply voltage 15.1 / DSP1 voltage below required value error indication on display Check voltage	A362.X5:8		E	2
2DEB17	LSB-BSE2: Supply voltage 24V.1 (0A0-1) / DSP1 voltage below required value error indication on display Check voltage, electr. connections and fuse	A362.X5:15		E	2
2DEC1B	LSB-BSE2: 2.Shut off channel / DSP0 digital shut off defective Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, fuse, replace module if nec.	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2DEC72	LSB-BSE2: 2.Shut off channel / DSP0 outside source feeding Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, replace module, if nec.	A362		E	2
2DED1B	LSB-BSE2: 2.Shut off channel / DSP1 digital shut off defective Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, fuse, replace module if nec.	A362		E	2
2DED72	LSB-BSE2: 2.Shut off channel / DSP1 outside source feeding Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, replace module, if nec.	A362		E	2
2DF006	LSB-BSE2: System error OS-DSP0 initialising error RAM erroneous Entry in error memory, program is stopped Inform Service of all error parameters and replace module	A362		E	2
2DF013	LSB-BSE2: System error OS-DSP0 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A362		E	2
2DF016	LSB-BSE2: System error OS-DSP0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A362		E	2
2DF050	LSB-BSE2: System error OS-DSP0 file not available error report Reload application software	A362		E	3
2DF073	LSB-BSE2: System error OS-DSP0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A362		E	2
2DF082	LSB-BSE2: System error OS-DSP0 hardware-watchdog erroneous Module reset Replace module	A362		E	2
2DF0A1	LSB-BSE2: System error OS-DSP0 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2DF0A2	LSB-BSE2: System error OS-DSP0 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF0AD	LSB-BSE2: System error OS-DSP0 System voltage V26-Core outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF0B1	LSB-BSE2: System error OS-DSP0 Power-Fail-Status incorrect error report Check voltage	A362		E	2
2DF0C1	LSB-BSE2: System error OS-DSP0 Incorrect or wrong system version for application error report Reload matching system version	A362		E	1
2DF0D3	LSB-BSE2: System error OS-DSP0 Em. drop system is active -> System charge required Emerg. system takes over operation and allows repair of run time system Reestablish the defective DSP system via the 'Load system' menu point in the test system	A362		E	2
2DF106	LSB-BSE2: System error OS-DSP1 initialising error RAM erroneous Entry in error memory, program is stopped Inform Service of all error parameters and replace module	A362		E	2
2DF113	LSB-BSE2: System error OS-DSP1 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A362		E	2
2DF116	LSB-BSE2: System error OS-DSP1 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A362		E	2
2DF150	LSB-BSE2: System error OS-DSP1 file not available error report Reload application software	A362		E	3
2DF173	LSB-BSE2: System error OS-DSP1 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2DF182	LSB-BSE2: System error OS-DSP1 hardware-watchdog erroneous Module reset Replace module	A362		E	2
2DF1A1	LSB-BSE2: System error OS-DSP1 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF1A2	LSB-BSE2: System error OS-DSP1 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF1AD	LSB-BSE2: System error OS-DSP1 System voltage V26-Core outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF1B1	LSB-BSE2: System error OS-DSP1 Power-Fail-Status incorrect error report Check voltage	A362		E	2
2DF1C1	LSB-BSE2: System error OS-DSP1 Incorrect or wrong system version for application error report Reload matching system version	A362		E	1
2DF1D3	LSB-BSE2: System error OS-DSP1 Em. drop system is active -> System charge required Emerg. system takes over operation and allows repair of run time system Reestablish the defective DSP system via the 'Load system' menu point in the test system	A362		E	2
2DF203	LSB-BSE2: System error OS-CPU0 CW Upload to data bank not carried out error report CW Carry out upload in data bank	A362		E	2
2DF280	LSB-BSE2: System error OS-CPU0 Fatal internal error error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF299	LSB-BSE2: System error OS-CPU0 DSP0 erroneous error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2DF29A	LSB-BSE2: System error OS-CPU0 DSP1 erroneous error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF29B	LSB-BSE2: System error OS-CPU0 dsPIC erroneous error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF2A1	LSB-BSE2: System error OS-CPU0 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF2A2	LSB-BSE2: System error OS-CPU0 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF2A3	LSB-BSE2: System error OS-CPU0 Board temp. outside permissible range error indication on display Check coolant supply for monitor	A362		E	2
2DF2A4	LSB-BSE2: System error OS-CPU0 Inside temperature outside permissible range error indication on display Check coolant supply for monitor	A362		E	2
2DF2A5	LSB-BSE2: System error OS-CPU0 System voltage 12V-CCFL outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF2AB	LSB-BSE2: System error OS-CPU0 System voltage 5V-Standby outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF2AC	LSB-BSE2: System error OS-CPU0 Restoration of CW-operandi failed error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF2AE	LSB-BSE2: System error OS-CPU0 System voltage PCMCIA erroneous error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
2DF2AF	LSB-BSE2: System error OS-CPU0 System voltage 3V- cell-RTC too low error report If time is corrupt, replace battery Type CR1225 in monitor	A362		E	2
2DF2B0	LSB-BSE2: System error OS-CPU0 Time RTC erroneous (Low-Voltage) error report Replace battery Type CR1225 in monitor	A362		E	2
2DF2C0	LSB-BSE2: System error OS-CPU0 Hardware / Software erroneous error report If error repeated, repl. comp. group, report error param. to Service	A362		E	2
2DF2FA	LSB-BSE2: System error OS-CPU0 BSE to BSE communication via CAN erroneous error report Replace comp. group, report error parameter to Service	A362		E	2
2DFAC1	LSB-BSE2: Control data transfer CAN-A LSB-BSE1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A362.X1:21/22		E	1
3A0050	LSB-BSE3: LSBA Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0051	LSB-BSE3: LSBA Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0053	LSB-BSE3: LSBA Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0054	LSB-BSE3: LSBA Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0064	LSB-BSE3: LSBA Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0065	LSB-BSE3: LSBA Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0066	LSB-BSE3: LSBA Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0067	LSB-BSE3: LSBA Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0068	LSB-BSE3: LSBA Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0069	LSB-BSE3: LSBA Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A006A	LSB-BSE3: LSBA Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A006B	LSB-BSE3: LSBA Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A006C	LSB-BSE3: LSBA Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0150	LSB-BSE3: LSBA Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0151	LSB-BSE3: LSBA Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0153	LSB-BSE3: LSBA Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0154	LSB-BSE3: LSBA Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0164	LSB-BSE3: LSBA Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0165	LSB-BSE3: LSBA Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0166	LSB-BSE3: LSBA Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0167	LSB-BSE3: LSBA Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0168	LSB-BSE3: LSBA Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0169	LSB-BSE3: LSBA Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A016A	LSB-BSE3: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A016B	LSB-BSE3: LSBA Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A016C	LSB-BSE3: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0250	LSB-BSE3: LSBA Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0251	LSB-BSE3: LSBA Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0253	LSB-BSE3: LSBA Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0254	LSB-BSE3: LSBA Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0264	LSB-BSE3: LSBA Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0265	LSB-BSE3: LSBA Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0266	LSB-BSE3: LSBA Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0267	LSB-BSE3: LSBA Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0268	LSB-BSE3: LSBA Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0269	LSB-BSE3: LSBA Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A026A	LSB-BSE3: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A026B	LSB-BSE3: LSBA Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A026C	LSB-BSE3: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0350	LSB-BSE3: LSBA Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0351	LSB-BSE3: LSBA Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0353	LSB-BSE3: LSBA Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0354	LSB-BSE3: LSBA Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0364	LSB-BSE3: LSBA Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0365	LSB-BSE3: LSBA Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0366	LSB-BSE3: LSBA Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0367	LSB-BSE3: LSBA Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0368	LSB-BSE3: LSBA Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0369	LSB-BSE3: LSBA Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A036A	LSB-BSE3: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A036B	LSB-BSE3: LSBA Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A036C	LSB-BSE3: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0450	LSB-BSE3: LSBA Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0451	LSB-BSE3: LSBA Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0453	LSB-BSE3: LSBA Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0454	LSB-BSE3: LSBA Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0464	LSB-BSE3: LSBA Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0465	LSB-BSE3: LSBA Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0466	LSB-BSE3: LSBA Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0467	LSB-BSE3: LSBA Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0468	LSB-BSE3: LSBA Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0469	LSB-BSE3: LSBA Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A046A	LSB-BSE3: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A046B	LSB-BSE3: LSBA Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A046C	LSB-BSE3: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0550	LSB-BSE3: LSBA Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0551	LSB-BSE3: LSBA Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0553	LSB-BSE3: LSBA Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0554	LSB-BSE3: LSBA Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0564	LSB-BSE3: LSBA Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0565	LSB-BSE3: LSBA Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0566	LSB-BSE3: LSBA Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0567	LSB-BSE3: LSBA Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0568	LSB-BSE3: LSBA Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0569	LSB-BSE3: LSBA Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A056A	LSB-BSE3: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A056B	LSB-BSE3: LSBA Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A056C	LSB-BSE3: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0650	LSB-BSE3: LSBA Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0651	LSB-BSE3: LSBA Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0653	LSB-BSE3: LSBA Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0654	LSB-BSE3: LSBA Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0664	LSB-BSE3: LSBA Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0665	LSB-BSE3: LSBA Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0666	LSB-BSE3: LSBA Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0667	LSB-BSE3: LSBA Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0668	LSB-BSE3: LSBA Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0669	LSB-BSE3: LSBA Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A066A	LSB-BSE3: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A066B	LSB-BSE3: LSBA Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A066C	LSB-BSE3: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0750	LSB-BSE3: LSBA Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0751	LSB-BSE3: LSBA Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0753	LSB-BSE3: LSBA Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0754	LSB-BSE3: LSBA Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0764	LSB-BSE3: LSBA Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0765	LSB-BSE3: LSBA Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0766	LSB-BSE3: LSBA Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0767	LSB-BSE3: LSBA Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0768	LSB-BSE3: LSBA Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0769	LSB-BSE3: LSBA Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A076A	LSB-BSE3: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A076B	LSB-BSE3: LSBA Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A076C	LSB-BSE3: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0B50	LSB-BSE3: LSBA Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0B51	LSB-BSE3: LSBA Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0B53	LSB-BSE3: LSBA Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0B54	LSB-BSE3: LSBA Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0B64	LSB-BSE3: LSBA Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0B65	LSB-BSE3: LSBA Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0B66	LSB-BSE3: LSBA Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0B67	LSB-BSE3: LSBA Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0B68	LSB-BSE3: LSBA Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0B69	LSB-BSE3: LSBA Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A0B6A	LSB-BSE3: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0B6B	LSB-BSE3: LSBA Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A0B6C	LSB-BSE3: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0C50	LSB-BSE3: LSBA Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0C51	LSB-BSE3: LSBA Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0C53	LSB-BSE3: LSBA Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0C54	LSB-BSE3: LSBA Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0C64	LSB-BSE3: LSBA Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0C65	LSB-BSE3: LSBA Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0C66	LSB-BSE3: LSBA Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0C67	LSB-BSE3: LSBA Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0C68	LSB-BSE3: LSBA Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0C69	LSB-BSE3: LSBA Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A0C6A	LSB-BSE3: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A0C6B	LSB-BSE3: LSBA Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A0C6C	LSB-BSE3: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0D50	LSB-BSE3: LSBA Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0D51	LSB-BSE3: LSBA Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0D53	LSB-BSE3: LSBA Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0D54	LSB-BSE3: LSBA Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0D64	LSB-BSE3: LSBA Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0D65	LSB-BSE3: LSBA Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0D66	LSB-BSE3: LSBA Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0D67	LSB-BSE3: LSBA Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0D68	LSB-BSE3: LSBA Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0D69	LSB-BSE3: LSBA Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A0D6A	LSB-BSE3: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A0D6B	LSB-BSE3: LSBA Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A0D6C	LSB-BSE3: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0E50	LSB-BSE3: LSBA Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0E51	LSB-BSE3: LSBA Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0E53	LSB-BSE3: LSBA Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0E54	LSB-BSE3: LSBA Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0E64	LSB-BSE3: LSBA Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0E65	LSB-BSE3: LSBA Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0E66	LSB-BSE3: LSBA Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0E67	LSB-BSE3: LSBA Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0E68	LSB-BSE3: LSBA Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A0E69	LSB-BSE3: LSBA Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A0E6A	LSB-BSE3: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A0E6B	LSB-BSE3: LSBA Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0E6C	LSB-BSE3: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A0F50	LSB-BSE3: LSBA Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A0F51	LSB-BSE3: LSBA Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A0F53	LSB-BSE3: LSBA Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A0F54	LSB-BSE3: LSBA Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A0F64	LSB-BSE3: LSBA Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A0F65	LSB-BSE3: LSBA Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A0F66	LSB-BSE3: LSBA Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A0F67	LSB-BSE3: LSBA Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A0F68	LSB-BSE3: LSBA Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A0F69	LSB-BSE3: LSBA Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A0F6A	LSB-BSE3: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A0F6B	LSB-BSE3: LSBA Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A0F6C	LSB-BSE3: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1050	LSB-BSE3: LSBA Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1051	LSB-BSE3: LSBA Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1053	LSB-BSE3: LSBA Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1054	LSB-BSE3: LSBA Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1064	LSB-BSE3: LSBA Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1065	LSB-BSE3: LSBA Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1066	LSB-BSE3: LSBA Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1067	LSB-BSE3: LSBA Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1068	LSB-BSE3: LSBA Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1069	LSB-BSE3: LSBA Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A106A	LSB-BSE3: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A106B	LSB-BSE3: LSBA Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A106C	LSB-BSE3: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1150	LSB-BSE3: LSBA Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1151	LSB-BSE3: LSBA Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1153	LSB-BSE3: LSBA Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1154	LSB-BSE3: LSBA Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1164	LSB-BSE3: LSBA Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1165	LSB-BSE3: LSBA Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1166	LSB-BSE3: LSBA Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1167	LSB-BSE3: LSBA Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1168	LSB-BSE3: LSBA Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1169	LSB-BSE3: LSBA Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A116A	LSB-BSE3: LSBA Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A116B	LSB-BSE3: LSBA Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A116C	LSB-BSE3: LSBA Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1250	LSB-BSE3: LSBA Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1251	LSB-BSE3: LSBA Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1253	LSB-BSE3: LSBA Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1254	LSB-BSE3: LSBA Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1264	LSB-BSE3: LSBA Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1265	LSB-BSE3: LSBA Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1266	LSB-BSE3: LSBA Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1267	LSB-BSE3: LSBA Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1268	LSB-BSE3: LSBA Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1269	LSB-BSE3: LSBA Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A126A	LSB-BSE3: LSBA Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A126B	LSB-BSE3: LSBA Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A126C	LSB-BSE3: LSBA Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1350	LSB-BSE3: LSBA Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1351	LSB-BSE3: LSBA Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1353	LSB-BSE3: LSBA Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1354	LSB-BSE3: LSBA Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1364	LSB-BSE3: LSBA Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1365	LSB-BSE3: LSBA Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1366	LSB-BSE3: LSBA Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1367	LSB-BSE3: LSBA Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1368	LSB-BSE3: LSBA Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1369	LSB-BSE3: LSBA Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A136A	LSB-BSE3: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A136B	LSB-BSE3: LSBA Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A136C	LSB-BSE3: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1450	LSB-BSE3: LSBA Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1451	LSB-BSE3: LSBA Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1453	LSB-BSE3: LSBA Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1454	LSB-BSE3: LSBA Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1464	LSB-BSE3: LSBA Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1465	LSB-BSE3: LSBA Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1466	LSB-BSE3: LSBA Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1467	LSB-BSE3: LSBA Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1468	LSB-BSE3: LSBA Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1469	LSB-BSE3: LSBA Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A146A	LSB-BSE3: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A146B	LSB-BSE3: LSBA Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A146C	LSB-BSE3: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1650	LSB-BSE3: LSBA Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1651	LSB-BSE3: LSBA Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1653	LSB-BSE3: LSBA Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1654	LSB-BSE3: LSBA Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1664	LSB-BSE3: LSBA Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1665	LSB-BSE3: LSBA Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1666	LSB-BSE3: LSBA Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1667	LSB-BSE3: LSBA Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1668	LSB-BSE3: LSBA Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1669	LSB-BSE3: LSBA Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A166A	LSB-BSE3: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A166B	LSB-BSE3: LSBA Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A166C	LSB-BSE3: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1750	LSB-BSE3: LSBA Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1751	LSB-BSE3: LSBA Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1753	LSB-BSE3: LSBA Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1754	LSB-BSE3: LSBA Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1764	LSB-BSE3: LSBA Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1765	LSB-BSE3: LSBA Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1766	LSB-BSE3: LSBA Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1767	LSB-BSE3: LSBA Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1768	LSB-BSE3: LSBA Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1769	LSB-BSE3: LSBA Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A176A	LSB-BSE3: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A176B	LSB-BSE3: LSBA Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A176C	LSB-BSE3: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1A50	LSB-BSE3: LSBA Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1A51	LSB-BSE3: LSBA Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1A53	LSB-BSE3: LSBA Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1A54	LSB-BSE3: LSBA Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1A64	LSB-BSE3: LSBA Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1A65	LSB-BSE3: LSBA Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1A66	LSB-BSE3: LSBA Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1A67	LSB-BSE3: LSBA Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1A68	LSB-BSE3: LSBA Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1A69	LSB-BSE3: LSBA Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A1A6A	LSB-BSE3: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A1A6B	LSB-BSE3: LSBA Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A1A6C	LSB-BSE3: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1B50	LSB-BSE3: LSBA Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1B51	LSB-BSE3: LSBA Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1B53	LSB-BSE3: LSBA Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1B54	LSB-BSE3: LSBA Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1B64	LSB-BSE3: LSBA Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1B65	LSB-BSE3: LSBA Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1B66	LSB-BSE3: LSBA Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1B67	LSB-BSE3: LSBA Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1B68	LSB-BSE3: LSBA Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1B69	LSB-BSE3: LSBA Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A1B6A	LSB-BSE3: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A1B6B	LSB-BSE3: LSBA Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1B6C	LSB-BSE3: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1C50	LSB-BSE3: LSBA Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1C51	LSB-BSE3: LSBA Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1C53	LSB-BSE3: LSBA Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1C54	LSB-BSE3: LSBA Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1C64	LSB-BSE3: LSBA Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1C65	LSB-BSE3: LSBA Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2
3A1C66	LSB-BSE3: LSBA Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1C67	LSB-BSE3: LSBA Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1C68	LSB-BSE3: LSBA Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1C69	LSB-BSE3: LSBA Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A1C6A	LSB-BSE3: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A1C6B	LSB-BSE3: LSBA Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A1C6C	LSB-BSE3: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A1D50	LSB-BSE3: LSBA Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:9		E	2
3A1D51	LSB-BSE3: LSBA Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:9		E	2
3A1D53	LSB-BSE3: LSBA Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:9		E	1
3A1D54	LSB-BSE3: LSBA Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:9		E	2
3A1D64	LSB-BSE3: LSBA Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:9		E	1
3A1D65	LSB-BSE3: LSBA Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A1D66	LSB-BSE3: LSBA Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:9		E	2
3A1D67	LSB-BSE3: LSBA Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:9		E	1
3A1D68	LSB-BSE3: LSBA Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:9		E	1
3A1D69	LSB-BSE3: LSBA Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:9		E	1
3A1D6A	LSB-BSE3: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:9		E	2
3A1D6B	LSB-BSE3: LSBA Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:9		E	2
3A1D6C	LSB-BSE3: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:9		E	2
3A2052	LSB-BSE3: Control data transfer LSBA has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363.X4:9		E	0
3A2055	LSB-BSE3: Control data transfer LSBA Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X4:9		E	2
3A2056	LSB-BSE3: Control data transfer LSBA Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A2057	LSB-BSE3: Control data transfer LSBA has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363.X4:9		E	1
3A2058	LSB-BSE3: Control data transfer LSBA recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363.X4:9		E	0
3A2059	LSB-BSE3: Control data transfer LSBA recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363.X4:9		E	0
3A2060	LSB-BSE3: Control data transfer LSBA driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363.X4:9		E	2
3A2061	LSB-BSE3: Control data transfer LSBA driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363.X4:9		E	2
3A2062	LSB-BSE3: Control data transfer LSBA Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363.X4:9		E	2
3A3050	LSB-BSE3: LSBB Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3051	LSB-BSE3: LSBB Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3053	LSB-BSE3: LSBB Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3054	LSB-BSE3: LSBB Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3064	LSB-BSE3: LSBB Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3065	LSB-BSE3: LSBB Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3066	LSB-BSE3: LSBB Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3067	LSB-BSE3: LSBB Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3068	LSB-BSE3: LSBB Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3069	LSB-BSE3: LSBB Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A306A	LSB-BSE3: LSBB Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A306B	LSB-BSE3: LSBB Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A306C	LSB-BSE3: LSBB Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3150	LSB-BSE3: LSBB Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3151	LSB-BSE3: LSBB Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3153	LSB-BSE3: LSBB Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3154	LSB-BSE3: LSBB Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3164	LSB-BSE3: LSBB Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3165	LSB-BSE3: LSBB Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3166	LSB-BSE3: LSBB Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3167	LSB-BSE3: LSBB Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3168	LSB-BSE3: LSBB Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3169	LSB-BSE3: LSBB Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A316A	LSB-BSE3: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A316B	LSB-BSE3: LSBB Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A316C	LSB-BSE3: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3250	LSB-BSE3: LSBB Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3251	LSB-BSE3: LSBB Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3253	LSB-BSE3: LSBB Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3254	LSB-BSE3: LSBB Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3264	LSB-BSE3: LSBB Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3265	LSB-BSE3: LSBB Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3266	LSB-BSE3: LSBB Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3267	LSB-BSE3: LSBB Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3268	LSB-BSE3: LSBB Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3269	LSB-BSE3: LSBB Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A326A	LSB-BSE3: LSBB Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A326B	LSB-BSE3: LSBB Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A326C	LSB-BSE3: LSBB Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3550	LSB-BSE3: LSBB Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3551	LSB-BSE3: LSBB Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3553	LSB-BSE3: LSBB Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3554	LSB-BSE3: LSBB Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3564	LSB-BSE3: LSBB Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3565	LSB-BSE3: LSBB Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3566	LSB-BSE3: LSBB Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3567	LSB-BSE3: LSBB Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3568	LSB-BSE3: LSBB Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3569	LSB-BSE3: LSBB Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A356A	LSB-BSE3: LSBB Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A356B	LSB-BSE3: LSBB Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A356C	LSB-BSE3: LSBB Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3650	LSB-BSE3: LSBB Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3651	LSB-BSE3: LSBB Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3653	LSB-BSE3: LSBB Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3654	LSB-BSE3: LSBB Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3664	LSB-BSE3: LSBB Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3665	LSB-BSE3: LSBB Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3666	LSB-BSE3: LSBB Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3667	LSB-BSE3: LSBB Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3668	LSB-BSE3: LSBB Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3669	LSB-BSE3: LSBB Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A366A	LSB-BSE3: LSBB Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A366B	LSB-BSE3: LSBB Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A366C	LSB-BSE3: LSBB Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3850	LSB-BSE3: LSBB Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3851	LSB-BSE3: LSBB Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3853	LSB-BSE3: LSBB Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3854	LSB-BSE3: LSBB Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3864	LSB-BSE3: LSBB Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3865	LSB-BSE3: LSBB Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3866	LSB-BSE3: LSBB Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3867	LSB-BSE3: LSBB Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3868	LSB-BSE3: LSBB Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3869	LSB-BSE3: LSBB Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A386A	LSB-BSE3: LSBB Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A386B	LSB-BSE3: LSBB Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A386C	LSB-BSE3: LSBB Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3A50	LSB-BSE3: LSBB Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3A51	LSB-BSE3: LSBB Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3A53	LSB-BSE3: LSBB Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3A54	LSB-BSE3: LSBB Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3A64	LSB-BSE3: LSBB Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3A65	LSB-BSE3: LSBB Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3A66	LSB-BSE3: LSBB Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3A67	LSB-BSE3: LSBB Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3A68	LSB-BSE3: LSBB Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3A69	LSB-BSE3: LSBB Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A3A6A	LSB-BSE3: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A3A6B	LSB-BSE3: LSBB Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A3A6C	LSB-BSE3: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3B50	LSB-BSE3: LSBB Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3B51	LSB-BSE3: LSBB Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3B53	LSB-BSE3: LSBB Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3B54	LSB-BSE3: LSBB Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3B64	LSB-BSE3: LSBB Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3B65	LSB-BSE3: LSBB Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3B66	LSB-BSE3: LSBB Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3B67	LSB-BSE3: LSBB Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3B68	LSB-BSE3: LSBB Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3B69	LSB-BSE3: LSBB Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A3B6A	LSB-BSE3: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A3B6B	LSB-BSE3: LSBB Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A3B6C	LSB-BSE3: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3C50	LSB-BSE3: LSBB Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3C51	LSB-BSE3: LSBB Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3C53	LSB-BSE3: LSBB Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3C54	LSB-BSE3: LSBB Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3C64	LSB-BSE3: LSBB Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3C65	LSB-BSE3: LSBB Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3C66	LSB-BSE3: LSBB Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3C67	LSB-BSE3: LSBB Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3C68	LSB-BSE3: LSBB Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3C69	LSB-BSE3: LSBB Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3C6A	LSB-BSE3: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A3C6B	LSB-BSE3: LSBB Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A3C6C	LSB-BSE3: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3D50	LSB-BSE3: LSBB Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3D51	LSB-BSE3: LSBB Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3D53	LSB-BSE3: LSBB Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3D54	LSB-BSE3: LSBB Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3D64	LSB-BSE3: LSBB Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3D65	LSB-BSE3: LSBB Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3D66	LSB-BSE3: LSBB Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3D67	LSB-BSE3: LSBB Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3D68	LSB-BSE3: LSBB Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3D69	LSB-BSE3: LSBB Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A3D6A	LSB-BSE3: LSBB Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A3D6B	LSB-BSE3: LSBB Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A3D6C	LSB-BSE3: LSBB Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3E50	LSB-BSE3: LSBB Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A3E51	LSB-BSE3: LSBB Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3E53	LSB-BSE3: LSBB Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3E54	LSB-BSE3: LSBB Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3E64	LSB-BSE3: LSBB Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3E65	LSB-BSE3: LSBB Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3E66	LSB-BSE3: LSBB Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3E67	LSB-BSE3: LSBB Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3E68	LSB-BSE3: LSBB Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3E69	LSB-BSE3: LSBB Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A3E6A	LSB-BSE3: LSBB Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A3E6B	LSB-BSE3: LSBB Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A3E6C	LSB-BSE3: LSBB Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A3F50	LSB-BSE3: LSBB Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3F51	LSB-BSE3: LSBB Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A3F53	LSB-BSE3: LSBB Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A3F54	LSB-BSE3: LSBB Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A3F64	LSB-BSE3: LSBB Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A3F65	LSB-BSE3: LSBB Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A3F66	LSB-BSE3: LSBB Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A3F67	LSB-BSE3: LSBB Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A3F68	LSB-BSE3: LSBB Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A3F69	LSB-BSE3: LSBB Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A3F6A	LSB-BSE3: LSBB Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A3F6B	LSB-BSE3: LSBB Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A3F6C	LSB-BSE3: LSBB Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4050	LSB-BSE3: LSBB Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4051	LSB-BSE3: LSBB Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4053	LSB-BSE3: LSBB Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4054	LSB-BSE3: LSBB Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4064	LSB-BSE3: LSBB Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4065	LSB-BSE3: LSBB Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4066	LSB-BSE3: LSBB Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4067	LSB-BSE3: LSBB Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4068	LSB-BSE3: LSBB Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4069	LSB-BSE3: LSBB Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A406A	LSB-BSE3: LSBB Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A406B	LSB-BSE3: LSBB Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A406C	LSB-BSE3: LSBB Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4150	LSB-BSE3: LSBB Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4151	LSB-BSE3: LSBB Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4153	LSB-BSE3: LSBB Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4154	LSB-BSE3: LSBB Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4164	LSB-BSE3: LSBB Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4165	LSB-BSE3: LSBB Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4166	LSB-BSE3: LSBB Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4167	LSB-BSE3: LSBB Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4168	LSB-BSE3: LSBB Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4169	LSB-BSE3: LSBB Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A416A	LSB-BSE3: LSBB Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A416B	LSB-BSE3: LSBB Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A416C	LSB-BSE3: LSBB Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4250	LSB-BSE3: LSBB Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4251	LSB-BSE3: LSBB Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4253	LSB-BSE3: LSBB Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4254	LSB-BSE3: LSBB Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4264	LSB-BSE3: LSBB Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4265	LSB-BSE3: LSBB Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4266	LSB-BSE3: LSBB Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4267	LSB-BSE3: LSBB Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4268	LSB-BSE3: LSBB Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4269	LSB-BSE3: LSBB Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A426A	LSB-BSE3: LSBB Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A426B	LSB-BSE3: LSBB Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A426C	LSB-BSE3: LSBB Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4350	LSB-BSE3: LSBB Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4351	LSB-BSE3: LSBB Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4353	LSB-BSE3: LSBB Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4354	LSB-BSE3: LSBB Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4364	LSB-BSE3: LSBB Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4365	LSB-BSE3: LSBB Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4366	LSB-BSE3: LSBB Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4367	LSB-BSE3: LSBB Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4368	LSB-BSE3: LSBB Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4369	LSB-BSE3: LSBB Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A436A	LSB-BSE3: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A436B	LSB-BSE3: LSBB Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A436C	LSB-BSE3: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4450	LSB-BSE3: LSBB Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4451	LSB-BSE3: LSBB Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4453	LSB-BSE3: LSBB Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4454	LSB-BSE3: LSBB Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4464	LSB-BSE3: LSBB Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4465	LSB-BSE3: LSBB Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4466	LSB-BSE3: LSBB Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4467	LSB-BSE3: LSBB Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4468	LSB-BSE3: LSBB Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4469	LSB-BSE3: LSBB Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A446A	LSB-BSE3: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A446B	LSB-BSE3: LSBB Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A446C	LSB-BSE3: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4550	LSB-BSE3: LSBB Participant Adr. 21 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4551	LSB-BSE3: LSBB Participant Adr. 21 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4553	LSB-BSE3: LSBB Participant Adr. 21 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4554	LSB-BSE3: LSBB Participant Adr. 21 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4564	LSB-BSE3: LSBB Participant Adr. 21 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4565	LSB-BSE3: LSBB Participant Adr. 21 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4566	LSB-BSE3: LSBB Participant Adr. 21 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4567	LSB-BSE3: LSBB Participant Adr. 21 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4568	LSB-BSE3: LSBB Participant Adr. 21 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4569	LSB-BSE3: LSBB Participant Adr. 21 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A456A	LSB-BSE3: LSBB Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A456B	LSB-BSE3: LSBB Participant Adr. 21 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A456C	LSB-BSE3: LSBB Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4650	LSB-BSE3: LSBB Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4651	LSB-BSE3: LSBB Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4653	LSB-BSE3: LSBB Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4654	LSB-BSE3: LSBB Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4664	LSB-BSE3: LSBB Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4665	LSB-BSE3: LSBB Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4666	LSB-BSE3: LSBB Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4667	LSB-BSE3: LSBB Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4668	LSB-BSE3: LSBB Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4669	LSB-BSE3: LSBB Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A466A	LSB-BSE3: LSBB Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A466B	LSB-BSE3: LSBB Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A466C	LSB-BSE3: LSBB Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4750	LSB-BSE3: LSBB Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4751	LSB-BSE3: LSBB Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4753	LSB-BSE3: LSBB Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4754	LSB-BSE3: LSBB Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4764	LSB-BSE3: LSBB Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4765	LSB-BSE3: LSBB Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4766	LSB-BSE3: LSBB Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4767	LSB-BSE3: LSBB Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4768	LSB-BSE3: LSBB Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4769	LSB-BSE3: LSBB Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A476A	LSB-BSE3: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A476B	LSB-BSE3: LSBB Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A476C	LSB-BSE3: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4950	LSB-BSE3: LSBB Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4951	LSB-BSE3: LSBB Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4953	LSB-BSE3: LSBB Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4954	LSB-BSE3: LSBB Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4964	LSB-BSE3: LSBB Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4965	LSB-BSE3: LSBB Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4966	LSB-BSE3: LSBB Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4967	LSB-BSE3: LSBB Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4968	LSB-BSE3: LSBB Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4969	LSB-BSE3: LSBB Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A496A	LSB-BSE3: LSBB Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A496B	LSB-BSE3: LSBB Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A496C	LSB-BSE3: LSBB Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4A50	LSB-BSE3: LSBB Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4A51	LSB-BSE3: LSBB Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4A53	LSB-BSE3: LSBB Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4A54	LSB-BSE3: LSBB Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4A64	LSB-BSE3: LSBB Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4A65	LSB-BSE3: LSBB Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4A66	LSB-BSE3: LSBB Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4A67	LSB-BSE3: LSBB Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4A68	LSB-BSE3: LSBB Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4A69	LSB-BSE3: LSBB Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A4A6A	LSB-BSE3: LSBB Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4A6B	LSB-BSE3: LSBB Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A4A6C	LSB-BSE3: LSBB Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4B50	LSB-BSE3: LSBB Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4B51	LSB-BSE3: LSBB Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4B53	LSB-BSE3: LSBB Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4B54	LSB-BSE3: LSBB Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4B64	LSB-BSE3: LSBB Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4B65	LSB-BSE3: LSBB Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4B66	LSB-BSE3: LSBB Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4B67	LSB-BSE3: LSBB Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4B68	LSB-BSE3: LSBB Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4B69	LSB-BSE3: LSBB Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A4B6A	LSB-BSE3: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A4B6B	LSB-BSE3: LSBB Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A4B6C	LSB-BSE3: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4C50	LSB-BSE3: LSBB Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4C51	LSB-BSE3: LSBB Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4C53	LSB-BSE3: LSBB Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4C54	LSB-BSE3: LSBB Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4C64	LSB-BSE3: LSBB Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4C65	LSB-BSE3: LSBB Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4C66	LSB-BSE3: LSBB Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4C67	LSB-BSE3: LSBB Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4C68	LSB-BSE3: LSBB Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4C69	LSB-BSE3: LSBB Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A4C6A	LSB-BSE3: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A4C6B	LSB-BSE3: LSBB Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A4C6C	LSB-BSE3: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4D50	LSB-BSE3: LSBB Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4D51	LSB-BSE3: LSBB Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4D53	LSB-BSE3: LSBB Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4D54	LSB-BSE3: LSBB Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4D64	LSB-BSE3: LSBB Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4D65	LSB-BSE3: LSBB Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4D66	LSB-BSE3: LSBB Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4D67	LSB-BSE3: LSBB Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4D68	LSB-BSE3: LSBB Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1
3A4D69	LSB-BSE3: LSBB Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A4D6A	LSB-BSE3: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A4D6B	LSB-BSE3: LSBB Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4D6C	LSB-BSE3: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A4E50	LSB-BSE3: LSBB Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:10		E	2
3A4E51	LSB-BSE3: LSBB Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:10		E	2
3A4E53	LSB-BSE3: LSBB Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:10		E	1
3A4E54	LSB-BSE3: LSBB Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:10		E	2
3A4E64	LSB-BSE3: LSBB Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:10		E	1
3A4E65	LSB-BSE3: LSBB Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:10		E	2
3A4E66	LSB-BSE3: LSBB Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:10		E	2
3A4E67	LSB-BSE3: LSBB Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:10		E	1
3A4E68	LSB-BSE3: LSBB Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A4E69	LSB-BSE3: LSBB Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:10		E	1
3A4E6A	LSB-BSE3: LSBB Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:10		E	2
3A4E6B	LSB-BSE3: LSBB Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:10		E	2
3A4E6C	LSB-BSE3: LSBB Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:10		E	2
3A5052	LSB-BSE3: Control data transfer LSBB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363.X4:10		E	0
3A5055	LSB-BSE3: Control data transfer LSBB Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X4:10		E	2
3A5056	LSB-BSE3: Control data transfer LSBB Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X4:10		E	2
3A5057	LSB-BSE3: Control data transfer LSBB has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363.X4:10		E	1
3A5058	LSB-BSE3: Control data transfer LSBB recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363.X4:10		E	0
3A5059	LSB-BSE3: Control data transfer LSBB recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363.X4:10		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A5060	LSB-BSE3: Control data transfer LSBB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363.X4:10		E	2
3A5061	LSB-BSE3: Control data transfer LSBB driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363.X4:10		E	2
3A5062	LSB-BSE3: Control data transfer LSBB Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363.X4:10		E	2
3A6050	LSB-BSE3: LSBC Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A6051	LSB-BSE3: LSBC Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A6053	LSB-BSE3: LSBC Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A6054	LSB-BSE3: LSBC Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A6064	LSB-BSE3: LSBC Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A6065	LSB-BSE3: LSBC Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A6066	LSB-BSE3: LSBC Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6067	LSB-BSE3: LSBC Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A6068	LSB-BSE3: LSBC Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A6069	LSB-BSE3: LSBC Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A606A	LSB-BSE3: LSBC Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A606B	LSB-BSE3: LSBC Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A606C	LSB-BSE3: LSBC Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A6150	LSB-BSE3: LSBC Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A6151	LSB-BSE3: LSBC Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A6153	LSB-BSE3: LSBC Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A6154	LSB-BSE3: LSBC Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6164	LSB-BSE3: LSBC Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A6165	LSB-BSE3: LSBC Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A6166	LSB-BSE3: LSBC Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A6167	LSB-BSE3: LSBC Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A6168	LSB-BSE3: LSBC Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A6169	LSB-BSE3: LSBC Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A616A	LSB-BSE3: LSBC Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A616B	LSB-BSE3: LSBC Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A616C	LSB-BSE3: LSBC Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A6550	LSB-BSE3: LSBC Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6551	LSB-BSE3: LSBC Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A6553	LSB-BSE3: LSBC Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A6554	LSB-BSE3: LSBC Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A6564	LSB-BSE3: LSBC Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A6565	LSB-BSE3: LSBC Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A6566	LSB-BSE3: LSBC Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A6567	LSB-BSE3: LSBC Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A6568	LSB-BSE3: LSBC Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A6569	LSB-BSE3: LSBC Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A656A	LSB-BSE3: LSBC Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A656B	LSB-BSE3: LSBC Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A656C	LSB-BSE3: LSBC Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A6650	LSB-BSE3: LSBC Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A6651	LSB-BSE3: LSBC Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A6653	LSB-BSE3: LSBC Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A6654	LSB-BSE3: LSBC Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A6664	LSB-BSE3: LSBC Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A6665	LSB-BSE3: LSBC Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A6666	LSB-BSE3: LSBC Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A6667	LSB-BSE3: LSBC Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6668	LSB-BSE3: LSBC Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A6669	LSB-BSE3: LSBC Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A666A	LSB-BSE3: LSBC Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A666B	LSB-BSE3: LSBC Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A666C	LSB-BSE3: LSBC Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A6B50	LSB-BSE3: LSBC Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A6B51	LSB-BSE3: LSBC Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A6B53	LSB-BSE3: LSBC Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A6B54	LSB-BSE3: LSBC Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A6B64	LSB-BSE3: LSBC Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6B65	LSB-BSE3: LSBC Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A6B66	LSB-BSE3: LSBC Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A6B67	LSB-BSE3: LSBC Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A6B68	LSB-BSE3: LSBC Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A6B69	LSB-BSE3: LSBC Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A6B6A	LSB-BSE3: LSBC Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A6B6B	LSB-BSE3: LSBC Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A6B6C	LSB-BSE3: LSBC Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A6C50	LSB-BSE3: LSBC Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A6C51	LSB-BSE3: LSBC Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6C53	LSB-BSE3: LSBC Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A6C54	LSB-BSE3: LSBC Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A6C64	LSB-BSE3: LSBC Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A6C65	LSB-BSE3: LSBC Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A6C66	LSB-BSE3: LSBC Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A6C67	LSB-BSE3: LSBC Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A6C68	LSB-BSE3: LSBC Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A6C69	LSB-BSE3: LSBC Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A6C6A	LSB-BSE3: LSBC Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A6C6B	LSB-BSE3: LSBC Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6C6C	LSB-BSE3: LSBC Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A6D50	LSB-BSE3: LSBC Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A6D51	LSB-BSE3: LSBC Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A6D53	LSB-BSE3: LSBC Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A6D54	LSB-BSE3: LSBC Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A6D64	LSB-BSE3: LSBC Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A6D65	LSB-BSE3: LSBC Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A6D66	LSB-BSE3: LSBC Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A6D67	LSB-BSE3: LSBC Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A6D68	LSB-BSE3: LSBC Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6D69	LSB-BSE3: LSBC Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A6D6A	LSB-BSE3: LSBC Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A6D6B	LSB-BSE3: LSBC Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A6D6C	LSB-BSE3: LSBC Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A6E50	LSB-BSE3: LSBC Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A6E51	LSB-BSE3: LSBC Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A6E53	LSB-BSE3: LSBC Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A6E54	LSB-BSE3: LSBC Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A6E64	LSB-BSE3: LSBC Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A6E65	LSB-BSE3: LSBC Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6E66	LSB-BSE3: LSBC Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A6E67	LSB-BSE3: LSBC Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A6E68	LSB-BSE3: LSBC Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A6E69	LSB-BSE3: LSBC Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A6E6A	LSB-BSE3: LSBC Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A6E6B	LSB-BSE3: LSBC Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A6E6C	LSB-BSE3: LSBC Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A6F50	LSB-BSE3: LSBC Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A6F51	LSB-BSE3: LSBC Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A6F53	LSB-BSE3: LSBC Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A6F54	LSB-BSE3: LSBC Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A6F64	LSB-BSE3: LSBC Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A6F65	LSB-BSE3: LSBC Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A6F66	LSB-BSE3: LSBC Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A6F67	LSB-BSE3: LSBC Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A6F68	LSB-BSE3: LSBC Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A6F69	LSB-BSE3: LSBC Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A6F6A	LSB-BSE3: LSBC Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A6F6B	LSB-BSE3: LSBC Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A6F6C	LSB-BSE3: LSBC Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7050	LSB-BSE3: LSBC Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7051	LSB-BSE3: LSBC Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7053	LSB-BSE3: LSBC Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7054	LSB-BSE3: LSBC Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7064	LSB-BSE3: LSBC Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7065	LSB-BSE3: LSBC Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7066	LSB-BSE3: LSBC Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7067	LSB-BSE3: LSBC Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7068	LSB-BSE3: LSBC Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7069	LSB-BSE3: LSBC Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A706A	LSB-BSE3: LSBC Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A706B	LSB-BSE3: LSBC Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A706C	LSB-BSE3: LSBC Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7150	LSB-BSE3: LSBC Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7151	LSB-BSE3: LSBC Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7153	LSB-BSE3: LSBC Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7154	LSB-BSE3: LSBC Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7164	LSB-BSE3: LSBC Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7165	LSB-BSE3: LSBC Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7166	LSB-BSE3: LSBC Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7167	LSB-BSE3: LSBC Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7168	LSB-BSE3: LSBC Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7169	LSB-BSE3: LSBC Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A716A	LSB-BSE3: LSBC Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A716B	LSB-BSE3: LSBC Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A716C	LSB-BSE3: LSBC Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7250	LSB-BSE3: LSBC Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7251	LSB-BSE3: LSBC Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7253	LSB-BSE3: LSBC Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7254	LSB-BSE3: LSBC Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7264	LSB-BSE3: LSBC Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7265	LSB-BSE3: LSBC Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7266	LSB-BSE3: LSBC Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7267	LSB-BSE3: LSBC Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7268	LSB-BSE3: LSBC Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7269	LSB-BSE3: LSBC Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A726A	LSB-BSE3: LSBC Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A726B	LSB-BSE3: LSBC Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A726C	LSB-BSE3: LSBC Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7650	LSB-BSE3: LSBC Participant Adr. 22 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7651	LSB-BSE3: LSBC Participant Adr. 22 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7653	LSB-BSE3: LSBC Participant Adr. 22 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7654	LSB-BSE3: LSBC Participant Adr. 22 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7664	LSB-BSE3: LSBC Participant Adr. 22 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7665	LSB-BSE3: LSBC Participant Adr. 22 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7666	LSB-BSE3: LSBC Participant Adr. 22 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7667	LSB-BSE3: LSBC Participant Adr. 22 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7668	LSB-BSE3: LSBC Participant Adr. 22 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7669	LSB-BSE3: LSBC Participant Adr. 22 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A766A	LSB-BSE3: LSBC Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A766B	LSB-BSE3: LSBC Participant Adr. 22 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A766C	LSB-BSE3: LSBC Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7750	LSB-BSE3: LSBC Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7751	LSB-BSE3: LSBC Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7753	LSB-BSE3: LSBC Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7754	LSB-BSE3: LSBC Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7764	LSB-BSE3: LSBC Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7765	LSB-BSE3: LSBC Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7766	LSB-BSE3: LSBC Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7767	LSB-BSE3: LSBC Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7768	LSB-BSE3: LSBC Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7769	LSB-BSE3: LSBC Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A776A	LSB-BSE3: LSBC Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A776B	LSB-BSE3: LSBC Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A776C	LSB-BSE3: LSBC Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7850	LSB-BSE3: LSBC Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7851	LSB-BSE3: LSBC Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7853	LSB-BSE3: LSBC Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7854	LSB-BSE3: LSBC Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7864	LSB-BSE3: LSBC Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7865	LSB-BSE3: LSBC Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7866	LSB-BSE3: LSBC Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7867	LSB-BSE3: LSBC Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7868	LSB-BSE3: LSBC Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7869	LSB-BSE3: LSBC Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A786A	LSB-BSE3: LSBC Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A786B	LSB-BSE3: LSBC Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A786C	LSB-BSE3: LSBC Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7950	LSB-BSE3: LSBC Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7951	LSB-BSE3: LSBC Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7953	LSB-BSE3: LSBC Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7954	LSB-BSE3: LSBC Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7964	LSB-BSE3: LSBC Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7965	LSB-BSE3: LSBC Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7966	LSB-BSE3: LSBC Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7967	LSB-BSE3: LSBC Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7968	LSB-BSE3: LSBC Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7969	LSB-BSE3: LSBC Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A796A	LSB-BSE3: LSBC Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A796B	LSB-BSE3: LSBC Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A796C	LSB-BSE3: LSBC Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7A50	LSB-BSE3: LSBC Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7A51	LSB-BSE3: LSBC Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7A53	LSB-BSE3: LSBC Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7A54	LSB-BSE3: LSBC Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7A64	LSB-BSE3: LSBC Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7A65	LSB-BSE3: LSBC Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7A66	LSB-BSE3: LSBC Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7A67	LSB-BSE3: LSBC Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7A68	LSB-BSE3: LSBC Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7A69	LSB-BSE3: LSBC Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A7A6A	LSB-BSE3: LSBC Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A7A6B	LSB-BSE3: LSBC Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A7A6C	LSB-BSE3: LSBC Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7B50	LSB-BSE3: LSBC Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7B51	LSB-BSE3: LSBC Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7B53	LSB-BSE3: LSBC Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7B54	LSB-BSE3: LSBC Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7B64	LSB-BSE3: LSBC Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7B65	LSB-BSE3: LSBC Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7B66	LSB-BSE3: LSBC Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7B67	LSB-BSE3: LSBC Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7B68	LSB-BSE3: LSBC Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7B69	LSB-BSE3: LSBC Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A7B6A	LSB-BSE3: LSBC Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A7B6B	LSB-BSE3: LSBC Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A7B6C	LSB-BSE3: LSBC Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7C50	LSB-BSE3: LSBC Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7C51	LSB-BSE3: LSBC Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7C53	LSB-BSE3: LSBC Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7C54	LSB-BSE3: LSBC Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7C64	LSB-BSE3: LSBC Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7C65	LSB-BSE3: LSBC Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7C66	LSB-BSE3: LSBC Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7C67	LSB-BSE3: LSBC Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7C68	LSB-BSE3: LSBC Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7C69	LSB-BSE3: LSBC Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A7C6A	LSB-BSE3: LSBC Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A7C6B	LSB-BSE3: LSBC Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A7C6C	LSB-BSE3: LSBC Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7D50	LSB-BSE3: LSBC Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7D51	LSB-BSE3: LSBC Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7D53	LSB-BSE3: LSBC Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7D54	LSB-BSE3: LSBC Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7D64	LSB-BSE3: LSBC Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7D65	LSB-BSE3: LSBC Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7D66	LSB-BSE3: LSBC Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2
3A7D67	LSB-BSE3: LSBC Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7D68	LSB-BSE3: LSBC Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7D69	LSB-BSE3: LSBC Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7D6A	LSB-BSE3: LSBC Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A7D6B	LSB-BSE3: LSBC Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A7D6C	LSB-BSE3: LSBC Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A7E50	LSB-BSE3: LSBC Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:11		E	2
3A7E51	LSB-BSE3: LSBC Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:11		E	2
3A7E53	LSB-BSE3: LSBC Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:11		E	1
3A7E54	LSB-BSE3: LSBC Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:11		E	2
3A7E64	LSB-BSE3: LSBC Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:11		E	1
3A7E65	LSB-BSE3: LSBC Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:11		E	2
3A7E66	LSB-BSE3: LSBC Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A7E67	LSB-BSE3: LSBC Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:11		E	1
3A7E68	LSB-BSE3: LSBC Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:11		E	1
3A7E69	LSB-BSE3: LSBC Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:11		E	1
3A7E6A	LSB-BSE3: LSBC Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:11		E	2
3A7E6B	LSB-BSE3: LSBC Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:11		E	2
3A7E6C	LSB-BSE3: LSBC Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:11		E	2
3A8052	LSB-BSE3: Control data transfer LSBC has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363.X4:11		E	0
3A8055	LSB-BSE3: Control data transfer LSBC Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X4:11		E	2
3A8056	LSB-BSE3: Control data transfer LSBC Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X4:11		E	2
3A8057	LSB-BSE3: Control data transfer LSBC has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363.X4:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A8058	LSB-BSE3: Control data transfer LSBC recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363.X4:11		E	0
3A8059	LSB-BSE3: Control data transfer LSBC recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363.X4:11		E	0
3A8060	LSB-BSE3: Control data transfer LSBC driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363.X4:11		E	2
3A8061	LSB-BSE3: Control data transfer LSBC driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363.X4:11		E	2
3A8062	LSB-BSE3: Control data transfer LSBC Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363.X4:11		E	2
3A9050	LSB-BSE3: LSB-D Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:12		E	2
3A9051	LSB-BSE3: LSB-D Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:12		E	2
3A9053	LSB-BSE3: LSB-D Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:12		E	1
3A9054	LSB-BSE3: LSB-D Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:12		E	2
3A9064	LSB-BSE3: LSB-D Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A9065	LSB-BSE3: LSB-D Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:12		E	2
3A9066	LSB-BSE3: LSB-D Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:12		E	2
3A9067	LSB-BSE3: LSB-D Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:12		E	1
3A9068	LSB-BSE3: LSB-D Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:12		E	1
3A9069	LSB-BSE3: LSB-D Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:12		E	1
3A906A	LSB-BSE3: LSB-D Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:12		E	2
3A906B	LSB-BSE3: LSB-D Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:12		E	2
3A906C	LSB-BSE3: LSB-D Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:12		E	2
3A9150	LSB-BSE3: LSB-D Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X4:12		E	2
3A9151	LSB-BSE3: LSB-D Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A9153	LSB-BSE3: LSB-D Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X4:12		E	1
3A9154	LSB-BSE3: LSB-D Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X4:12		E	2
3A9164	LSB-BSE3: LSB-D Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X4:12		E	1
3A9165	LSB-BSE3: LSB-D Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X4:12		E	2
3A9166	LSB-BSE3: LSB-D Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X4:12		E	2
3A9167	LSB-BSE3: LSB-D Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X4:12		E	1
3A9168	LSB-BSE3: LSB-D Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X4:12		E	1
3A9169	LSB-BSE3: LSB-D Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X4:12		E	1
3A916A	LSB-BSE3: LSB-D Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X4:12		E	2
3A916B	LSB-BSE3: LSB-D Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3A916C	LSB-BSE3: LSB-D Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X4:12		E	2
3AB052	LSB-BSE3: Control data transfer LSB-D has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363.X4:12		E	0
3AB055	LSB-BSE3: Control data transfer LSB-D Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X4:12		E	2
3AB056	LSB-BSE3: Control data transfer LSB-D Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X4:12		E	2
3AB057	LSB-BSE3: Control data transfer LSB-D has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363.X4:12		E	1
3AB058	LSB-BSE3: Control data transfer LSB-D recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363.X4:12		E	0
3AB059	LSB-BSE3: Control data transfer LSB-D recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363.X4:12		E	0
3AB060	LSB-BSE3: Control data transfer LSB-D driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363.X4:12		E	2
3AB061	LSB-BSE3: Control data transfer LSB-D driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363.X4:12		E	2
3AB062	LSB-BSE3: Control data transfer LSB-D Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0050	LSB-BSE3: LSBE Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0051	LSB-BSE3: LSBE Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0053	LSB-BSE3: LSBE Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0054	LSB-BSE3: LSBE Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0064	LSB-BSE3: LSBE Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0065	LSB-BSE3: LSBE Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0066	LSB-BSE3: LSBE Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0067	LSB-BSE3: LSBE Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0068	LSB-BSE3: LSBE Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0069	LSB-BSE3: LSBE Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B006A	LSB-BSE3: LSBE Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B006B	LSB-BSE3: LSBE Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B006C	LSB-BSE3: LSBE Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0150	LSB-BSE3: LSBE Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0151	LSB-BSE3: LSBE Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0153	LSB-BSE3: LSBE Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0154	LSB-BSE3: LSBE Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0164	LSB-BSE3: LSBE Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0165	LSB-BSE3: LSBE Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0166	LSB-BSE3: LSBE Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0167	LSB-BSE3: LSBE Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0168	LSB-BSE3: LSBE Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0169	LSB-BSE3: LSBE Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B016A	LSB-BSE3: LSBE Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B016B	LSB-BSE3: LSBE Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B016C	LSB-BSE3: LSBE Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0250	LSB-BSE3: LSBE Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0251	LSB-BSE3: LSBE Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0253	LSB-BSE3: LSBE Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0254	LSB-BSE3: LSBE Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0264	LSB-BSE3: LSBE Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0265	LSB-BSE3: LSBE Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0266	LSB-BSE3: LSBE Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0267	LSB-BSE3: LSBE Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0268	LSB-BSE3: LSBE Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0269	LSB-BSE3: LSBE Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B026A	LSB-BSE3: LSBE Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B026B	LSB-BSE3: LSBE Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B026C	LSB-BSE3: LSBE Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0350	LSB-BSE3: LSBE Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0351	LSB-BSE3: LSBE Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0353	LSB-BSE3: LSBE Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0354	LSB-BSE3: LSBE Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0364	LSB-BSE3: LSBE Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0365	LSB-BSE3: LSBE Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0366	LSB-BSE3: LSBE Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0367	LSB-BSE3: LSBE Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0368	LSB-BSE3: LSBE Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0369	LSB-BSE3: LSBE Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B036A	LSB-BSE3: LSBE Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B036B	LSB-BSE3: LSBE Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B036C	LSB-BSE3: LSBE Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0450	LSB-BSE3: LSBE Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0451	LSB-BSE3: LSBE Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0453	LSB-BSE3: LSBE Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0454	LSB-BSE3: LSBE Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0464	LSB-BSE3: LSBE Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0465	LSB-BSE3: LSBE Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0466	LSB-BSE3: LSBE Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0467	LSB-BSE3: LSBE Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0468	LSB-BSE3: LSBE Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0469	LSB-BSE3: LSBE Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B046A	LSB-BSE3: LSBE Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B046B	LSB-BSE3: LSBE Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B046C	LSB-BSE3: LSBE Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0550	LSB-BSE3: LSBE Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0551	LSB-BSE3: LSBE Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0553	LSB-BSE3: LSBE Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0554	LSB-BSE3: LSBE Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0564	LSB-BSE3: LSBE Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0565	LSB-BSE3: LSBE Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0566	LSB-BSE3: LSBE Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0567	LSB-BSE3: LSBE Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0568	LSB-BSE3: LSBE Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0569	LSB-BSE3: LSBE Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B056A	LSB-BSE3: LSBE Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B056B	LSB-BSE3: LSBE Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B056C	LSB-BSE3: LSBE Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0650	LSB-BSE3: LSBE Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0651	LSB-BSE3: LSBE Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0653	LSB-BSE3: LSBE Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0654	LSB-BSE3: LSBE Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0664	LSB-BSE3: LSBE Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0665	LSB-BSE3: LSBE Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0666	LSB-BSE3: LSBE Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0667	LSB-BSE3: LSBE Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0668	LSB-BSE3: LSBE Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0669	LSB-BSE3: LSBE Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B066A	LSB-BSE3: LSBE Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B066B	LSB-BSE3: LSBE Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B066C	LSB-BSE3: LSBE Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0750	LSB-BSE3: LSBE Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0751	LSB-BSE3: LSBE Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0753	LSB-BSE3: LSBE Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0754	LSB-BSE3: LSBE Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0764	LSB-BSE3: LSBE Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0765	LSB-BSE3: LSBE Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0766	LSB-BSE3: LSBE Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0767	LSB-BSE3: LSBE Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0768	LSB-BSE3: LSBE Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0769	LSB-BSE3: LSBE Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B076A	LSB-BSE3: LSBE Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B076B	LSB-BSE3: LSBE Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B076C	LSB-BSE3: LSBE Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0850	LSB-BSE3: LSBE Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0851	LSB-BSE3: LSBE Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0853	LSB-BSE3: LSBE Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0854	LSB-BSE3: LSBE Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0864	LSB-BSE3: LSBE Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0865	LSB-BSE3: LSBE Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0866	LSB-BSE3: LSBE Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0867	LSB-BSE3: LSBE Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0868	LSB-BSE3: LSBE Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0869	LSB-BSE3: LSBE Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B086A	LSB-BSE3: LSBE Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B086B	LSB-BSE3: LSBE Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B086C	LSB-BSE3: LSBE Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0950	LSB-BSE3: LSBE Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0951	LSB-BSE3: LSBE Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0953	LSB-BSE3: LSBE Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0954	LSB-BSE3: LSBE Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0964	LSB-BSE3: LSBE Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0965	LSB-BSE3: LSBE Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0966	LSB-BSE3: LSBE Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0967	LSB-BSE3: LSBE Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0968	LSB-BSE3: LSBE Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0969	LSB-BSE3: LSBE Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B096A	LSB-BSE3: LSBE Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B096B	LSB-BSE3: LSBE Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B096C	LSB-BSE3: LSBE Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0A50	LSB-BSE3: LSBE Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0A51	LSB-BSE3: LSBE Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0A53	LSB-BSE3: LSBE Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0A54	LSB-BSE3: LSBE Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0A64	LSB-BSE3: LSBE Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0A65	LSB-BSE3: LSBE Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0A66	LSB-BSE3: LSBE Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0A67	LSB-BSE3: LSBE Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0A68	LSB-BSE3: LSBE Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0A69	LSB-BSE3: LSBE Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0A6A	LSB-BSE3: LSBE Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B0A6B	LSB-BSE3: LSBE Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B0A6C	LSB-BSE3: LSBE Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0B50	LSB-BSE3: LSBE Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0B51	LSB-BSE3: LSBE Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0B53	LSB-BSE3: LSBE Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0B54	LSB-BSE3: LSBE Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0B64	LSB-BSE3: LSBE Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0B65	LSB-BSE3: LSBE Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0B66	LSB-BSE3: LSBE Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0B67	LSB-BSE3: LSBE Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0B68	LSB-BSE3: LSBE Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0B69	LSB-BSE3: LSBE Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B0B6A	LSB-BSE3: LSBE Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B0B6B	LSB-BSE3: LSBE Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B0B6C	LSB-BSE3: LSBE Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0C50	LSB-BSE3: LSBE Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0C51	LSB-BSE3: LSBE Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0C53	LSB-BSE3: LSBE Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0C54	LSB-BSE3: LSBE Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0C64	LSB-BSE3: LSBE Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0C65	LSB-BSE3: LSBE Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0C66	LSB-BSE3: LSBE Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0C67	LSB-BSE3: LSBE Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0C68	LSB-BSE3: LSBE Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0C69	LSB-BSE3: LSBE Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B0C6A	LSB-BSE3: LSBE Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B0C6B	LSB-BSE3: LSBE Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B0C6C	LSB-BSE3: LSBE Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0D50	LSB-BSE3: LSBE Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0D51	LSB-BSE3: LSBE Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0D53	LSB-BSE3: LSBE Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0D54	LSB-BSE3: LSBE Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0D64	LSB-BSE3: LSBE Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0D65	LSB-BSE3: LSBE Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0D66	LSB-BSE3: LSBE Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0D67	LSB-BSE3: LSBE Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B0D68	LSB-BSE3: LSBE Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0D69	LSB-BSE3: LSBE Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B0D6A	LSB-BSE3: LSBE Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0D6B	LSB-BSE3: LSBE Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B0D6C	LSB-BSE3: LSBE Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B0E50	LSB-BSE3: LSBE Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B0E51	LSB-BSE3: LSBE Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B0E53	LSB-BSE3: LSBE Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B0E54	LSB-BSE3: LSBE Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B0E64	LSB-BSE3: LSBE Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B0E65	LSB-BSE3: LSBE Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B0E66	LSB-BSE3: LSBE Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B0E67	LSB-BSE3: LSBE Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B0E68	LSB-BSE3: LSBE Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B0E69	LSB-BSE3: LSBE Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B0E6A	LSB-BSE3: LSBE Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B0E6B	LSB-BSE3: LSBE Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B0E6C	LSB-BSE3: LSBE Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B1850	LSB-BSE3: LSBE Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B1851	LSB-BSE3: LSBE Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B1853	LSB-BSE3: LSBE Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B1854	LSB-BSE3: LSBE Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B1864	LSB-BSE3: LSBE Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B1865	LSB-BSE3: LSBE Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B1866	LSB-BSE3: LSBE Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B1867	LSB-BSE3: LSBE Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B1868	LSB-BSE3: LSBE Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B1869	LSB-BSE3: LSBE Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B186A	LSB-BSE3: LSBE Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B186B	LSB-BSE3: LSBE Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B186C	LSB-BSE3: LSBE Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B1950	LSB-BSE3: LSBE Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B1951	LSB-BSE3: LSBE Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B1953	LSB-BSE3: LSBE Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B1954	LSB-BSE3: LSBE Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B1964	LSB-BSE3: LSBE Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B1965	LSB-BSE3: LSBE Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B1966	LSB-BSE3: LSBE Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B1967	LSB-BSE3: LSBE Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B1968	LSB-BSE3: LSBE Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B1969	LSB-BSE3: LSBE Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B196A	LSB-BSE3: LSBE Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B196B	LSB-BSE3: LSBE Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B196C	LSB-BSE3: LSBE Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B1A50	LSB-BSE3: LSBE Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B1A51	LSB-BSE3: LSBE Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B1A53	LSB-BSE3: LSBE Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B1A54	LSB-BSE3: LSBE Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B1A64	LSB-BSE3: LSBE Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B1A65	LSB-BSE3: LSBE Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B1A66	LSB-BSE3: LSBE Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B1A67	LSB-BSE3: LSBE Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B1A68	LSB-BSE3: LSBE Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B1A69	LSB-BSE3: LSBE Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B1A6A	LSB-BSE3: LSBE Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B1A6B	LSB-BSE3: LSBE Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B1A6C	LSB-BSE3: LSBE Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B1B50	LSB-BSE3: LSBE Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B1B51	LSB-BSE3: LSBE Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B1B53	LSB-BSE3: LSBE Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B1B54	LSB-BSE3: LSBE Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B1B64	LSB-BSE3: LSBE Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B1B65	LSB-BSE3: LSBE Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B1B66	LSB-BSE3: LSBE Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B1B67	LSB-BSE3: LSBE Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B1B68	LSB-BSE3: LSBE Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B1B69	LSB-BSE3: LSBE Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B1B6A	LSB-BSE3: LSBE Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B1B6B	LSB-BSE3: LSBE Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B1B6C	LSB-BSE3: LSBE Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B1C50	LSB-BSE3: LSBE Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B1C51	LSB-BSE3: LSBE Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B1C53	LSB-BSE3: LSBE Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B1C54	LSB-BSE3: LSBE Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B1C64	LSB-BSE3: LSBE Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B1C65	LSB-BSE3: LSBE Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B1C66	LSB-BSE3: LSBE Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B1C67	LSB-BSE3: LSBE Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B1C68	LSB-BSE3: LSBE Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B1C69	LSB-BSE3: LSBE Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B1C6A	LSB-BSE3: LSBE Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B1C6B	LSB-BSE3: LSBE Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B1C6C	LSB-BSE3: LSBE Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B1D50	LSB-BSE3: LSBE Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B1D51	LSB-BSE3: LSBE Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B1D53	LSB-BSE3: LSBE Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B1D54	LSB-BSE3: LSBE Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B1D64	LSB-BSE3: LSBE Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B1D65	LSB-BSE3: LSBE Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B1D66	LSB-BSE3: LSBE Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2
3B1D67	LSB-BSE3: LSBE Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B1D68	LSB-BSE3: LSBE Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B1D69	LSB-BSE3: LSBE Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B1D6A	LSB-BSE3: LSBE Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B1D6B	LSB-BSE3: LSBE Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B1D6C	LSB-BSE3: LSBE Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B1E50	LSB-BSE3: LSBE Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:9		E	2
3B1E51	LSB-BSE3: LSBE Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:9		E	2
3B1E53	LSB-BSE3: LSBE Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:9		E	1
3B1E54	LSB-BSE3: LSBE Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:9		E	2
3B1E64	LSB-BSE3: LSBE Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:9		E	1
3B1E65	LSB-BSE3: LSBE Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:9		E	2
3B1E66	LSB-BSE3: LSBE Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B1E67	LSB-BSE3: LSBE Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:9		E	1
3B1E68	LSB-BSE3: LSBE Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:9		E	1
3B1E69	LSB-BSE3: LSBE Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:9		E	1
3B1E6A	LSB-BSE3: LSBE Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:9		E	2
3B1E6B	LSB-BSE3: LSBE Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:9		E	2
3B1E6C	LSB-BSE3: LSBE Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:9		E	2
3B2052	LSB-BSE3: Control data transfer LSBE has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363.X5:9		E	0
3B2055	LSB-BSE3: Control data transfer LSBE Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X5:9		E	2
3B2056	LSB-BSE3: Control data transfer LSBE Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X5:9		E	2
3B2057	LSB-BSE3: Control data transfer LSBE has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363.X5:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B2058	LSB-BSE3: Control data transfer LSBE recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363.X5:9		E	0
3B2059	LSB-BSE3: Control data transfer LSBE recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363.X5:9		E	0
3B2060	LSB-BSE3: Control data transfer LSBE driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363.X5:9		E	2
3B2061	LSB-BSE3: Control data transfer LSBE driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363.X5:9		E	2
3B2062	LSB-BSE3: Control data transfer LSBE Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363.X5:9		E	2
3B3050	LSB-BSE3: LSBF Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3051	LSB-BSE3: LSBF Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3053	LSB-BSE3: LSBF Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3054	LSB-BSE3: LSBF Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3064	LSB-BSE3: LSBF Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3065	LSB-BSE3: LSBF Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3066	LSB-BSE3: LSBF Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3067	LSB-BSE3: LSBF Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3068	LSB-BSE3: LSBF Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3069	LSB-BSE3: LSBF Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B306A	LSB-BSE3: LSBF Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B306B	LSB-BSE3: LSBF Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B306C	LSB-BSE3: LSBF Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3150	LSB-BSE3: LSBF Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3151	LSB-BSE3: LSBF Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3153	LSB-BSE3: LSBF Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3154	LSB-BSE3: LSBF Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3164	LSB-BSE3: LSBF Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3165	LSB-BSE3: LSBF Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3166	LSB-BSE3: LSBF Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3167	LSB-BSE3: LSBF Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3168	LSB-BSE3: LSBF Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3169	LSB-BSE3: LSBF Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B316A	LSB-BSE3: LSBF Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B316B	LSB-BSE3: LSBF Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B316C	LSB-BSE3: LSBF Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3350	LSB-BSE3: LSBF Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3351	LSB-BSE3: LSBF Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3353	LSB-BSE3: LSBF Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3354	LSB-BSE3: LSBF Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3364	LSB-BSE3: LSBF Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3365	LSB-BSE3: LSBF Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3366	LSB-BSE3: LSBF Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3367	LSB-BSE3: LSBF Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3368	LSB-BSE3: LSBF Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3369	LSB-BSE3: LSBF Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B336A	LSB-BSE3: LSBF Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B336B	LSB-BSE3: LSBF Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B336C	LSB-BSE3: LSBF Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3450	LSB-BSE3: LSBF Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3451	LSB-BSE3: LSBF Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3453	LSB-BSE3: LSBF Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3454	LSB-BSE3: LSBF Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3464	LSB-BSE3: LSBF Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3465	LSB-BSE3: LSBF Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3466	LSB-BSE3: LSBF Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3467	LSB-BSE3: LSBF Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3468	LSB-BSE3: LSBF Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3469	LSB-BSE3: LSBF Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B346A	LSB-BSE3: LSBF Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B346B	LSB-BSE3: LSBF Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B346C	LSB-BSE3: LSBF Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3550	LSB-BSE3: LSBF Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3551	LSB-BSE3: LSBF Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3553	LSB-BSE3: LSBF Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3554	LSB-BSE3: LSBF Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3564	LSB-BSE3: LSBF Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3565	LSB-BSE3: LSBF Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3566	LSB-BSE3: LSBF Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3567	LSB-BSE3: LSBF Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3568	LSB-BSE3: LSBF Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3569	LSB-BSE3: LSBF Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B356A	LSB-BSE3: LSBF Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B356B	LSB-BSE3: LSBF Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B356C	LSB-BSE3: LSBF Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3650	LSB-BSE3: LSBF Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3651	LSB-BSE3: LSBF Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3653	LSB-BSE3: LSBF Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3654	LSB-BSE3: LSBF Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3664	LSB-BSE3: LSBF Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3665	LSB-BSE3: LSBF Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3666	LSB-BSE3: LSBF Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3667	LSB-BSE3: LSBF Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3668	LSB-BSE3: LSBF Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3669	LSB-BSE3: LSBF Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B366A	LSB-BSE3: LSBF Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B366B	LSB-BSE3: LSBF Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B366C	LSB-BSE3: LSBF Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3750	LSB-BSE3: LSBF Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3751	LSB-BSE3: LSBF Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3753	LSB-BSE3: LSBF Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3754	LSB-BSE3: LSBF Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3764	LSB-BSE3: LSBF Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3765	LSB-BSE3: LSBF Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3766	LSB-BSE3: LSBF Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3767	LSB-BSE3: LSBF Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3768	LSB-BSE3: LSBF Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3769	LSB-BSE3: LSBF Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B376A	LSB-BSE3: LSBF Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B376B	LSB-BSE3: LSBF Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B376C	LSB-BSE3: LSBF Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3850	LSB-BSE3: LSBF Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3851	LSB-BSE3: LSBF Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3853	LSB-BSE3: LSBF Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3854	LSB-BSE3: LSBF Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3864	LSB-BSE3: LSBF Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3865	LSB-BSE3: LSBF Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3866	LSB-BSE3: LSBF Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3867	LSB-BSE3: LSBF Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3868	LSB-BSE3: LSBF Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3869	LSB-BSE3: LSBF Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B386A	LSB-BSE3: LSBF Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B386B	LSB-BSE3: LSBF Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B386C	LSB-BSE3: LSBF Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3950	LSB-BSE3: LSBF Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3951	LSB-BSE3: LSBF Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3953	LSB-BSE3: LSBF Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3954	LSB-BSE3: LSBF Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3964	LSB-BSE3: LSBF Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3965	LSB-BSE3: LSBF Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3966	LSB-BSE3: LSBF Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3967	LSB-BSE3: LSBF Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3968	LSB-BSE3: LSBF Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3969	LSB-BSE3: LSBF Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B396A	LSB-BSE3: LSBF Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B396B	LSB-BSE3: LSBF Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B396C	LSB-BSE3: LSBF Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3A50	LSB-BSE3: LSBF Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3A51	LSB-BSE3: LSBF Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3A53	LSB-BSE3: LSBF Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3A54	LSB-BSE3: LSBF Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3A64	LSB-BSE3: LSBF Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3A65	LSB-BSE3: LSBF Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3A66	LSB-BSE3: LSBF Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3A67	LSB-BSE3: LSBF Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3A68	LSB-BSE3: LSBF Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3A69	LSB-BSE3: LSBF Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B3A6A	LSB-BSE3: LSBF Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B3A6B	LSB-BSE3: LSBF Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B3A6C	LSB-BSE3: LSBF Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3C50	LSB-BSE3: LSBF Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3C51	LSB-BSE3: LSBF Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3C53	LSB-BSE3: LSBF Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3C54	LSB-BSE3: LSBF Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3C64	LSB-BSE3: LSBF Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3C65	LSB-BSE3: LSBF Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3C66	LSB-BSE3: LSBF Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3C67	LSB-BSE3: LSBF Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3C68	LSB-BSE3: LSBF Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3C69	LSB-BSE3: LSBF Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B3C6A	LSB-BSE3: LSBF Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B3C6B	LSB-BSE3: LSBF Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B3C6C	LSB-BSE3: LSBF Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3D50	LSB-BSE3: LSBF Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3D51	LSB-BSE3: LSBF Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3D53	LSB-BSE3: LSBF Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3D54	LSB-BSE3: LSBF Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3D64	LSB-BSE3: LSBF Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3D65	LSB-BSE3: LSBF Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3D66	LSB-BSE3: LSBF Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3D67	LSB-BSE3: LSBF Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3D68	LSB-BSE3: LSBF Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3D69	LSB-BSE3: LSBF Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B3D6A	LSB-BSE3: LSBF Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B3D6B	LSB-BSE3: LSBF Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3D6C	LSB-BSE3: LSBF Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3E50	LSB-BSE3: LSBF Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3E51	LSB-BSE3: LSBF Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3E53	LSB-BSE3: LSBF Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3E54	LSB-BSE3: LSBF Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3E64	LSB-BSE3: LSBF Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3E65	LSB-BSE3: LSBF Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B3E66	LSB-BSE3: LSBF Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3E67	LSB-BSE3: LSBF Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3E68	LSB-BSE3: LSBF Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3E69	LSB-BSE3: LSBF Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B3E6A	LSB-BSE3: LSBF Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B3E6B	LSB-BSE3: LSBF Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B3E6C	LSB-BSE3: LSBF Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B3F50	LSB-BSE3: LSBF Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B3F51	LSB-BSE3: LSBF Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B3F53	LSB-BSE3: LSBF Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B3F54	LSB-BSE3: LSBF Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B3F64	LSB-BSE3: LSBF Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B3F65	LSB-BSE3: LSBF Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B3F66	LSB-BSE3: LSBF Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B3F67	LSB-BSE3: LSBF Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B3F68	LSB-BSE3: LSBF Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B3F69	LSB-BSE3: LSBF Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B3F6A	LSB-BSE3: LSBF Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B3F6B	LSB-BSE3: LSBF Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B3F6C	LSB-BSE3: LSBF Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B4050	LSB-BSE3: LSBF Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B4051	LSB-BSE3: LSBF Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B4053	LSB-BSE3: LSBF Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4054	LSB-BSE3: LSBF Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B4064	LSB-BSE3: LSBF Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B4065	LSB-BSE3: LSBF Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4066	LSB-BSE3: LSBF Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B4067	LSB-BSE3: LSBF Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B4068	LSB-BSE3: LSBF Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B4069	LSB-BSE3: LSBF Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B406A	LSB-BSE3: LSBF Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B406B	LSB-BSE3: LSBF Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B406C	LSB-BSE3: LSBF Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4150	LSB-BSE3: LSBF Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B4151	LSB-BSE3: LSBF Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B4153	LSB-BSE3: LSBF Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B4154	LSB-BSE3: LSBF Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B4164	LSB-BSE3: LSBF Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B4165	LSB-BSE3: LSBF Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4166	LSB-BSE3: LSBF Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B4167	LSB-BSE3: LSBF Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B4168	LSB-BSE3: LSBF Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B4169	LSB-BSE3: LSBF Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B416A	LSB-BSE3: LSBF Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B416B	LSB-BSE3: LSBF Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B416C	LSB-BSE3: LSBF Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B4250	LSB-BSE3: LSBF Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B4251	LSB-BSE3: LSBF Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B4253	LSB-BSE3: LSBF Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B4254	LSB-BSE3: LSBF Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B4264	LSB-BSE3: LSBF Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B4265	LSB-BSE3: LSBF Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4266	LSB-BSE3: LSBF Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4267	LSB-BSE3: LSBF Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B4268	LSB-BSE3: LSBF Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B4269	LSB-BSE3: LSBF Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B426A	LSB-BSE3: LSBF Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B426B	LSB-BSE3: LSBF Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B426C	LSB-BSE3: LSBF Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B4350	LSB-BSE3: LSBF Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B4351	LSB-BSE3: LSBF Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B4353	LSB-BSE3: LSBF Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B4354	LSB-BSE3: LSBF Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4364	LSB-BSE3: LSBF Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B4365	LSB-BSE3: LSBF Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4366	LSB-BSE3: LSBF Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B4367	LSB-BSE3: LSBF Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B4368	LSB-BSE3: LSBF Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B4369	LSB-BSE3: LSBF Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B436A	LSB-BSE3: LSBF Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B436B	LSB-BSE3: LSBF Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B436C	LSB-BSE3: LSBF Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B4A50	LSB-BSE3: LSBF Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4A51	LSB-BSE3: LSBF Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B4A53	LSB-BSE3: LSBF Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B4A54	LSB-BSE3: LSBF Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B4A64	LSB-BSE3: LSBF Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B4A65	LSB-BSE3: LSBF Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4A66	LSB-BSE3: LSBF Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B4A67	LSB-BSE3: LSBF Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B4A68	LSB-BSE3: LSBF Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B4A69	LSB-BSE3: LSBF Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B4A6A	LSB-BSE3: LSBF Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4A6B	LSB-BSE3: LSBF Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B4A6C	LSB-BSE3: LSBF Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B4B50	LSB-BSE3: LSBF Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B4B51	LSB-BSE3: LSBF Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B4B53	LSB-BSE3: LSBF Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B4B54	LSB-BSE3: LSBF Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B4B64	LSB-BSE3: LSBF Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B4B65	LSB-BSE3: LSBF Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4B66	LSB-BSE3: LSBF Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B4B67	LSB-BSE3: LSBF Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4B68	LSB-BSE3: LSBF Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B4B69	LSB-BSE3: LSBF Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B4B6A	LSB-BSE3: LSBF Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B4B6B	LSB-BSE3: LSBF Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B4B6C	LSB-BSE3: LSBF Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B4C50	LSB-BSE3: LSBF Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B4C51	LSB-BSE3: LSBF Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B4C53	LSB-BSE3: LSBF Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B4C54	LSB-BSE3: LSBF Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B4C64	LSB-BSE3: LSBF Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4C65	LSB-BSE3: LSBF Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4C66	LSB-BSE3: LSBF Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B4C67	LSB-BSE3: LSBF Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B4C68	LSB-BSE3: LSBF Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B4C69	LSB-BSE3: LSBF Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B4C6A	LSB-BSE3: LSBF Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B4C6B	LSB-BSE3: LSBF Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B4C6C	LSB-BSE3: LSBF Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B4D50	LSB-BSE3: LSBF Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B4D51	LSB-BSE3: LSBF Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4D53	LSB-BSE3: LSBF Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B4D54	LSB-BSE3: LSBF Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B4D64	LSB-BSE3: LSBF Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B4D65	LSB-BSE3: LSBF Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4D66	LSB-BSE3: LSBF Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B4D67	LSB-BSE3: LSBF Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B4D68	LSB-BSE3: LSBF Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1
3B4D69	LSB-BSE3: LSBF Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B4D6A	LSB-BSE3: LSBF Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B4D6B	LSB-BSE3: LSBF Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4D6C	LSB-BSE3: LSBF Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B4E50	LSB-BSE3: LSBF Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:10		E	2
3B4E51	LSB-BSE3: LSBF Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:10		E	2
3B4E53	LSB-BSE3: LSBF Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:10		E	1
3B4E54	LSB-BSE3: LSBF Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:10		E	2
3B4E64	LSB-BSE3: LSBF Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:10		E	1
3B4E65	LSB-BSE3: LSBF Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:10		E	2
3B4E66	LSB-BSE3: LSBF Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:10		E	2
3B4E67	LSB-BSE3: LSBF Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:10		E	1
3B4E68	LSB-BSE3: LSBF Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B4E69	LSB-BSE3: LSBF Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:10		E	1
3B4E6A	LSB-BSE3: LSBF Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:10		E	2
3B4E6B	LSB-BSE3: LSBF Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:10		E	2
3B4E6C	LSB-BSE3: LSBF Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:10		E	2
3B5052	LSB-BSE3: Control data transfer LSBF has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363.X5:10		E	0
3B5055	LSB-BSE3: Control data transfer LSBF Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X5:10		E	2
3B5056	LSB-BSE3: Control data transfer LSBF Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X5:10		E	2
3B5057	LSB-BSE3: Control data transfer LSBF has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363.X5:10		E	1
3B5058	LSB-BSE3: Control data transfer LSBF recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363.X5:10		E	0
3B5059	LSB-BSE3: Control data transfer LSBF recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363.X5:10		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B5060	LSB-BSE3: Control data transfer LSBF driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363.X5:10		E	2
3B5061	LSB-BSE3: Control data transfer LSBF driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363.X5:10		E	2
3B5062	LSB-BSE3: Control data transfer LSBF Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363.X5:10		E	2
3B6050	LSB-BSE3: LSBG Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6051	LSB-BSE3: LSBG Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6053	LSB-BSE3: LSBG Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6054	LSB-BSE3: LSBG Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6064	LSB-BSE3: LSBG Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6065	LSB-BSE3: LSBG Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6066	LSB-BSE3: LSBG Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6067	LSB-BSE3: LSBG Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6068	LSB-BSE3: LSBG Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6069	LSB-BSE3: LSBG Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B606A	LSB-BSE3: LSBG Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B606B	LSB-BSE3: LSBG Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B606C	LSB-BSE3: LSBG Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6150	LSB-BSE3: LSBG Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6151	LSB-BSE3: LSBG Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6153	LSB-BSE3: LSBG Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6154	LSB-BSE3: LSBG Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6164	LSB-BSE3: LSBG Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6165	LSB-BSE3: LSBG Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6166	LSB-BSE3: LSBG Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6167	LSB-BSE3: LSBG Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6168	LSB-BSE3: LSBG Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6169	LSB-BSE3: LSBG Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B616A	LSB-BSE3: LSBG Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B616B	LSB-BSE3: LSBG Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B616C	LSB-BSE3: LSBG Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6350	LSB-BSE3: LSBG Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6351	LSB-BSE3: LSBG Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6353	LSB-BSE3: LSBG Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6354	LSB-BSE3: LSBG Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6364	LSB-BSE3: LSBG Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6365	LSB-BSE3: LSBG Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6366	LSB-BSE3: LSBG Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6367	LSB-BSE3: LSBG Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6368	LSB-BSE3: LSBG Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6369	LSB-BSE3: LSBG Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B636A	LSB-BSE3: LSBG Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B636B	LSB-BSE3: LSBG Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B636C	LSB-BSE3: LSBG Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6450	LSB-BSE3: LSBG Participant Adr. 4 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6451	LSB-BSE3: LSBG Participant Adr. 4 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6453	LSB-BSE3: LSBG Participant Adr. 4 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6454	LSB-BSE3: LSBG Participant Adr. 4 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6464	LSB-BSE3: LSBG Participant Adr. 4 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6465	LSB-BSE3: LSBG Participant Adr. 4 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6466	LSB-BSE3: LSBG Participant Adr. 4 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6467	LSB-BSE3: LSBG Participant Adr. 4 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6468	LSB-BSE3: LSBG Participant Adr. 4 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6469	LSB-BSE3: LSBG Participant Adr. 4 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B646A	LSB-BSE3: LSBG Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B646B	LSB-BSE3: LSBG Participant Adr. 4 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B646C	LSB-BSE3: LSBG Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6550	LSB-BSE3: LSBG Participant Adr. 5 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6551	LSB-BSE3: LSBG Participant Adr. 5 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6553	LSB-BSE3: LSBG Participant Adr. 5 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6554	LSB-BSE3: LSBG Participant Adr. 5 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6564	LSB-BSE3: LSBG Participant Adr. 5 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6565	LSB-BSE3: LSBG Participant Adr. 5 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6566	LSB-BSE3: LSBG Participant Adr. 5 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6567	LSB-BSE3: LSBG Participant Adr. 5 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6568	LSB-BSE3: LSBG Participant Adr. 5 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6569	LSB-BSE3: LSBG Participant Adr. 5 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B656A	LSB-BSE3: LSBG Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B656B	LSB-BSE3: LSBG Participant Adr. 5 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B656C	LSB-BSE3: LSBG Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6650	LSB-BSE3: LSBG Participant Adr. 6 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6651	LSB-BSE3: LSBG Participant Adr. 6 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6653	LSB-BSE3: LSBG Participant Adr. 6 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6654	LSB-BSE3: LSBG Participant Adr. 6 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6664	LSB-BSE3: LSBG Participant Adr. 6 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6665	LSB-BSE3: LSBG Participant Adr. 6 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6666	LSB-BSE3: LSBG Participant Adr. 6 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6667	LSB-BSE3: LSBG Participant Adr. 6 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6668	LSB-BSE3: LSBG Participant Adr. 6 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6669	LSB-BSE3: LSBG Participant Adr. 6 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B666A	LSB-BSE3: LSBG Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B666B	LSB-BSE3: LSBG Participant Adr. 6 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B666C	LSB-BSE3: LSBG Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6750	LSB-BSE3: LSBG Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6751	LSB-BSE3: LSBG Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6753	LSB-BSE3: LSBG Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6754	LSB-BSE3: LSBG Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6764	LSB-BSE3: LSBG Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6765	LSB-BSE3: LSBG Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6766	LSB-BSE3: LSBG Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6767	LSB-BSE3: LSBG Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6768	LSB-BSE3: LSBG Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6769	LSB-BSE3: LSBG Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B676A	LSB-BSE3: LSBG Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B676B	LSB-BSE3: LSBG Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B676C	LSB-BSE3: LSBG Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6850	LSB-BSE3: LSBG Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6851	LSB-BSE3: LSBG Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6853	LSB-BSE3: LSBG Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6854	LSB-BSE3: LSBG Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6864	LSB-BSE3: LSBG Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6865	LSB-BSE3: LSBG Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6866	LSB-BSE3: LSBG Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6867	LSB-BSE3: LSBG Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6868	LSB-BSE3: LSBG Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6869	LSB-BSE3: LSBG Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B686A	LSB-BSE3: LSBG Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B686B	LSB-BSE3: LSBG Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B686C	LSB-BSE3: LSBG Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6950	LSB-BSE3: LSBG Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6951	LSB-BSE3: LSBG Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6953	LSB-BSE3: LSBG Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6954	LSB-BSE3: LSBG Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6964	LSB-BSE3: LSBG Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6965	LSB-BSE3: LSBG Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6966	LSB-BSE3: LSBG Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6967	LSB-BSE3: LSBG Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6968	LSB-BSE3: LSBG Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6969	LSB-BSE3: LSBG Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B696A	LSB-BSE3: LSBG Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B696B	LSB-BSE3: LSBG Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B696C	LSB-BSE3: LSBG Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6A50	LSB-BSE3: LSBG Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6A51	LSB-BSE3: LSBG Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6A53	LSB-BSE3: LSBG Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6A54	LSB-BSE3: LSBG Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6A64	LSB-BSE3: LSBG Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6A65	LSB-BSE3: LSBG Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6A66	LSB-BSE3: LSBG Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6A67	LSB-BSE3: LSBG Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6A68	LSB-BSE3: LSBG Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6A69	LSB-BSE3: LSBG Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6A6A	LSB-BSE3: LSBG Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B6A6B	LSB-BSE3: LSBG Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B6A6C	LSB-BSE3: LSBG Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6C50	LSB-BSE3: LSBG Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6C51	LSB-BSE3: LSBG Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6C53	LSB-BSE3: LSBG Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6C54	LSB-BSE3: LSBG Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6C64	LSB-BSE3: LSBG Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6C65	LSB-BSE3: LSBG Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6C66	LSB-BSE3: LSBG Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6C67	LSB-BSE3: LSBG Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6C68	LSB-BSE3: LSBG Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6C69	LSB-BSE3: LSBG Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B6C6A	LSB-BSE3: LSBG Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B6C6B	LSB-BSE3: LSBG Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B6C6C	LSB-BSE3: LSBG Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6D50	LSB-BSE3: LSBG Participant Adr. 13 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6D51	LSB-BSE3: LSBG Participant Adr. 13 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6D53	LSB-BSE3: LSBG Participant Adr. 13 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6D54	LSB-BSE3: LSBG Participant Adr. 13 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6D64	LSB-BSE3: LSBG Participant Adr. 13 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6D65	LSB-BSE3: LSBG Participant Adr. 13 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6D66	LSB-BSE3: LSBG Participant Adr. 13 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6D67	LSB-BSE3: LSBG Participant Adr. 13 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6D68	LSB-BSE3: LSBG Participant Adr. 13 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6D69	LSB-BSE3: LSBG Participant Adr. 13 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B6D6A	LSB-BSE3: LSBG Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B6D6B	LSB-BSE3: LSBG Participant Adr. 13 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B6D6C	LSB-BSE3: LSBG Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6E50	LSB-BSE3: LSBG Participant Adr. 14 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6E51	LSB-BSE3: LSBG Participant Adr. 14 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6E53	LSB-BSE3: LSBG Participant Adr. 14 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6E54	LSB-BSE3: LSBG Participant Adr. 14 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6E64	LSB-BSE3: LSBG Participant Adr. 14 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6E65	LSB-BSE3: LSBG Participant Adr. 14 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6E66	LSB-BSE3: LSBG Participant Adr. 14 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6E67	LSB-BSE3: LSBG Participant Adr. 14 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B6E68	LSB-BSE3: LSBG Participant Adr. 14 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6E69	LSB-BSE3: LSBG Participant Adr. 14 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B6E6A	LSB-BSE3: LSBG Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6E6B	LSB-BSE3: LSBG Participant Adr. 14 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B6E6C	LSB-BSE3: LSBG Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B6F50	LSB-BSE3: LSBG Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B6F51	LSB-BSE3: LSBG Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B6F53	LSB-BSE3: LSBG Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B6F54	LSB-BSE3: LSBG Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B6F64	LSB-BSE3: LSBG Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B6F65	LSB-BSE3: LSBG Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B6F66	LSB-BSE3: LSBG Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B6F67	LSB-BSE3: LSBG Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B6F68	LSB-BSE3: LSBG Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B6F69	LSB-BSE3: LSBG Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B6F6A	LSB-BSE3: LSBG Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B6F6B	LSB-BSE3: LSBG Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B6F6C	LSB-BSE3: LSBG Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B7050	LSB-BSE3: LSBG Participant Adr. 16 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B7051	LSB-BSE3: LSBG Participant Adr. 16 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B7053	LSB-BSE3: LSBG Participant Adr. 16 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B7054	LSB-BSE3: LSBG Participant Adr. 16 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B7064	LSB-BSE3: LSBG Participant Adr. 16 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7065	LSB-BSE3: LSBG Participant Adr. 16 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B7066	LSB-BSE3: LSBG Participant Adr. 16 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B7067	LSB-BSE3: LSBG Participant Adr. 16 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7068	LSB-BSE3: LSBG Participant Adr. 16 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B7069	LSB-BSE3: LSBG Participant Adr. 16 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B706A	LSB-BSE3: LSBG Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B706B	LSB-BSE3: LSBG Participant Adr. 16 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B706C	LSB-BSE3: LSBG Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B7150	LSB-BSE3: LSBG Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B7151	LSB-BSE3: LSBG Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7153	LSB-BSE3: LSBG Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B7154	LSB-BSE3: LSBG Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B7164	LSB-BSE3: LSBG Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B7165	LSB-BSE3: LSBG Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B7166	LSB-BSE3: LSBG Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B7167	LSB-BSE3: LSBG Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7168	LSB-BSE3: LSBG Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B7169	LSB-BSE3: LSBG Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B716A	LSB-BSE3: LSBG Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B716B	LSB-BSE3: LSBG Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B716C	LSB-BSE3: LSBG Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B7250	LSB-BSE3: LSBG Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B7251	LSB-BSE3: LSBG Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B7253	LSB-BSE3: LSBG Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B7254	LSB-BSE3: LSBG Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B7264	LSB-BSE3: LSBG Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B7265	LSB-BSE3: LSBG Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B7266	LSB-BSE3: LSBG Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B7267	LSB-BSE3: LSBG Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7268	LSB-BSE3: LSBG Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7269	LSB-BSE3: LSBG Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B726A	LSB-BSE3: LSBG Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B726B	LSB-BSE3: LSBG Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B726C	LSB-BSE3: LSBG Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B7350	LSB-BSE3: LSBG Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B7351	LSB-BSE3: LSBG Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B7353	LSB-BSE3: LSBG Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B7354	LSB-BSE3: LSBG Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B7364	LSB-BSE3: LSBG Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B7365	LSB-BSE3: LSBG Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7366	LSB-BSE3: LSBG Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B7367	LSB-BSE3: LSBG Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7368	LSB-BSE3: LSBG Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B7369	LSB-BSE3: LSBG Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B736A	LSB-BSE3: LSBG Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B736B	LSB-BSE3: LSBG Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B736C	LSB-BSE3: LSBG Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B7A50	LSB-BSE3: LSBG Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B7A51	LSB-BSE3: LSBG Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B7A53	LSB-BSE3: LSBG Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7A54	LSB-BSE3: LSBG Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B7A64	LSB-BSE3: LSBG Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B7A65	LSB-BSE3: LSBG Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B7A66	LSB-BSE3: LSBG Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B7A67	LSB-BSE3: LSBG Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7A68	LSB-BSE3: LSBG Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B7A69	LSB-BSE3: LSBG Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B7A6A	LSB-BSE3: LSBG Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B7A6B	LSB-BSE3: LSBG Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B7A6C	LSB-BSE3: LSBG Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7B50	LSB-BSE3: LSBG Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B7B51	LSB-BSE3: LSBG Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B7B53	LSB-BSE3: LSBG Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B7B54	LSB-BSE3: LSBG Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B7B64	LSB-BSE3: LSBG Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B7B65	LSB-BSE3: LSBG Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B7B66	LSB-BSE3: LSBG Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B7B67	LSB-BSE3: LSBG Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7B68	LSB-BSE3: LSBG Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B7B69	LSB-BSE3: LSBG Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7B6A	LSB-BSE3: LSBG Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B7B6B	LSB-BSE3: LSBG Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B7B6C	LSB-BSE3: LSBG Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B7C50	LSB-BSE3: LSBG Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B7C51	LSB-BSE3: LSBG Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B7C53	LSB-BSE3: LSBG Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B7C54	LSB-BSE3: LSBG Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B7C64	LSB-BSE3: LSBG Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B7C65	LSB-BSE3: LSBG Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B7C66	LSB-BSE3: LSBG Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7C67	LSB-BSE3: LSBG Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7C68	LSB-BSE3: LSBG Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B7C69	LSB-BSE3: LSBG Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B7C6A	LSB-BSE3: LSBG Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B7C6B	LSB-BSE3: LSBG Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B7C6C	LSB-BSE3: LSBG Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B7D50	LSB-BSE3: LSBG Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2
3B7D51	LSB-BSE3: LSBG Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B7D53	LSB-BSE3: LSBG Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B7D54	LSB-BSE3: LSBG Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7D64	LSB-BSE3: LSBG Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B7D65	LSB-BSE3: LSBG Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B7D66	LSB-BSE3: LSBG Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B7D67	LSB-BSE3: LSBG Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7D68	LSB-BSE3: LSBG Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B7D69	LSB-BSE3: LSBG Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B7D6A	LSB-BSE3: LSBG Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2
3B7D6B	LSB-BSE3: LSBG Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B7D6C	LSB-BSE3: LSBG Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B7E50	LSB-BSE3: LSBG Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7E51	LSB-BSE3: LSBG Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:11		E	2
3B7E53	LSB-BSE3: LSBG Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:11		E	1
3B7E54	LSB-BSE3: LSBG Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:11		E	2
3B7E64	LSB-BSE3: LSBG Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:11		E	1
3B7E65	LSB-BSE3: LSBG Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:11		E	2
3B7E66	LSB-BSE3: LSBG Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:11		E	2
3B7E67	LSB-BSE3: LSBG Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:11		E	1
3B7E68	LSB-BSE3: LSBG Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:11		E	1
3B7E69	LSB-BSE3: LSBG Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:11		E	1
3B7E6A	LSB-BSE3: LSBG Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B7E6B	LSB-BSE3: LSBG Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:11		E	2
3B7E6C	LSB-BSE3: LSBG Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:11		E	2
3B8052	LSB-BSE3: Control data transfer LSBG has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363.X5:11		E	0
3B8055	LSB-BSE3: Control data transfer LSBG Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X5:11		E	2
3B8056	LSB-BSE3: Control data transfer LSBG Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X5:11		E	2
3B8057	LSB-BSE3: Control data transfer LSBG has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363.X5:11		E	1
3B8058	LSB-BSE3: Control data transfer LSBG recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363.X5:11		E	0
3B8059	LSB-BSE3: Control data transfer LSBG recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363.X5:11		E	0
3B8060	LSB-BSE3: Control data transfer LSBG driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363.X5:11		E	2
3B8061	LSB-BSE3: Control data transfer LSBG driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363.X5:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B8062	LSB-BSE3: Control data transfer LSBG Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363.X5:11		E	2
3B9050	LSB-BSE3: LSBH Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:12		E	2
3B9051	LSB-BSE3: LSBH Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:12		E	2
3B9053	LSB-BSE3: LSBH Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:12		E	1
3B9054	LSB-BSE3: LSBH Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:12		E	2
3B9064	LSB-BSE3: LSBH Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:12		E	1
3B9065	LSB-BSE3: LSBH Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:12		E	2
3B9066	LSB-BSE3: LSBH Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:12		E	2
3B9067	LSB-BSE3: LSBH Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:12		E	1
3B9068	LSB-BSE3: LSBH Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B9069	LSB-BSE3: LSBH Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:12		E	1
3B906A	LSB-BSE3: LSBH Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:12		E	2
3B906B	LSB-BSE3: LSBH Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:12		E	2
3B906C	LSB-BSE3: LSBH Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:12		E	2
3B9150	LSB-BSE3: LSBH Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363.X5:12		E	2
3B9151	LSB-BSE3: LSBH Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363.X5:12		E	2
3B9153	LSB-BSE3: LSBH Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363.X5:12		E	1
3B9154	LSB-BSE3: LSBH Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363.X5:12		E	2
3B9164	LSB-BSE3: LSBH Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363.X5:12		E	1
3B9165	LSB-BSE3: LSBH Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3B9166	LSB-BSE3: LSBH Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363.X5:12		E	2
3B9167	LSB-BSE3: LSBH Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363.X5:12		E	1
3B9168	LSB-BSE3: LSBH Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363.X5:12		E	1
3B9169	LSB-BSE3: LSBH Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363.X5:12		E	1
3B916A	LSB-BSE3: LSBH Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363.X5:12		E	2
3B916B	LSB-BSE3: LSBH Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363.X5:12		E	2
3B916C	LSB-BSE3: LSBH Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363.X5:12		E	2
3BB052	LSB-BSE3: Control data transfer LSBH has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363.X5:12		E	0
3BB055	LSB-BSE3: Control data transfer LSBH Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X5:12		E	2
3BB056	LSB-BSE3: Control data transfer LSBH Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363.X5:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3BB057	LSB-BSE3: Control data transfer LSBH has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363.X5:12		E	1
3BB058	LSB-BSE3: Control data transfer LSBH recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363.X5:12		E	0
3BB059	LSB-BSE3: Control data transfer LSBH recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363.X5:12		E	0
3BB060	LSB-BSE3: Control data transfer LSBH driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363.X5:12		E	2
3BB061	LSB-BSE3: Control data transfer LSBH driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363.X5:12		E	2
3BB062	LSB-BSE3: Control data transfer LSBH Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363.X5:12		E	2
3C0050	LSB-BSE3: LSBJ Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363		E	2
3C0051	LSB-BSE3: LSBJ Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363		E	2
3C0053	LSB-BSE3: LSBJ Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363		E	1
3C0054	LSB-BSE3: LSBJ Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3C0064	LSB-BSE3: LSBJ Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363		E	1
3C0065	LSB-BSE3: LSBJ Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363		E	2
3C0066	LSB-BSE3: LSBJ Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363		E	2
3C0067	LSB-BSE3: LSBJ Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363		E	1
3C0068	LSB-BSE3: LSBJ Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363		E	1
3C0069	LSB-BSE3: LSBJ Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363		E	1
3C006A	LSB-BSE3: LSBJ Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363		E	2
3C006B	LSB-BSE3: LSBJ Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363		E	2
3C006C	LSB-BSE3: LSBJ Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363		E	2
3C2052	LSB-BSE3: Control data transfer LSBJ has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A363		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3C2055	LSB-BSE3: Control data transfer LSBJ Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363		E	2
3C2056	LSB-BSE3: Control data transfer LSBJ Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A363		E	2
3C2057	LSB-BSE3: Control data transfer LSBJ has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A363		E	1
3C2058	LSB-BSE3: Control data transfer LSBJ recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A363		E	0
3C2059	LSB-BSE3: Control data transfer LSBJ recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A363		E	0
3C2060	LSB-BSE3: Control data transfer LSBJ driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A363		E	2
3C2061	LSB-BSE3: Control data transfer LSBJ driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A363		E	2
3C2062	LSB-BSE3: Control data transfer LSBJ Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A363		E	2
3C3050	LSB-BSE3: LSBK Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363		E	2
3C3051	LSB-BSE3: LSBK Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3C3053	LSB-BSE3: LSBK Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363		E	1
3C3054	LSB-BSE3: LSBK Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363		E	2
3C3064	LSB-BSE3: LSBK Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363		E	1
3C3065	LSB-BSE3: LSBK Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363		E	2
3C3066	LSB-BSE3: LSBK Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363		E	2
3C3067	LSB-BSE3: LSBK Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363		E	1
3C3068	LSB-BSE3: LSBK Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363		E	1
3C3069	LSB-BSE3: LSBK Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363		E	1
3C306A	LSB-BSE3: LSBK Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363		E	2
3C306B	LSB-BSE3: LSBK Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3C306C	LSB-BSE3: LSBK Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363		E	2
3C6050	LSB-BSE3: LSBL Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363		E	2
3C6051	LSB-BSE3: LSBL Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363		E	2
3C6053	LSB-BSE3: LSBL Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363		E	1
3C6054	LSB-BSE3: LSBL Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363		E	2
3C6064	LSB-BSE3: LSBL Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363		E	1
3C6065	LSB-BSE3: LSBL Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363		E	2
3C6066	LSB-BSE3: LSBL Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363		E	2
3C6067	LSB-BSE3: LSBL Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363		E	1
3C6068	LSB-BSE3: LSBL Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3C6069	LSB-BSE3: LSBL Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363		E	1
3C606A	LSB-BSE3: LSBL Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363		E	2
3C606B	LSB-BSE3: LSBL Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363		E	2
3C606C	LSB-BSE3: LSBL Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363		E	2
3C9050	LSB-BSE3: LSBM Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A363		E	2
3C9051	LSB-BSE3: LSBM Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A363		E	2
3C9053	LSB-BSE3: LSBM Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A363		E	1
3C9054	LSB-BSE3: LSBM Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A363		E	2
3C9064	LSB-BSE3: LSBM Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A363		E	1
3C9065	LSB-BSE3: LSBM Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3C9066	LSB-BSE3: LSBM Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A363		E	2
3C9067	LSB-BSE3: LSBM Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A363		E	1
3C9068	LSB-BSE3: LSBM Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A363		E	1
3C9069	LSB-BSE3: LSBM Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A363		E	1
3C906A	LSB-BSE3: LSBM Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A363		E	2
3C906B	LSB-BSE3: LSBM Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A363		E	2
3C906C	LSB-BSE3: LSBM Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A363		E	2
3D0058	LSB-BSE3: LMB Consistency test between length sensor and track recog. erroneous Only error message Check sensor	A363		E	1
3D006A	LSB-BSE3: LMB Measuring sleeve defective/missing 2 hook weighing poss. inaccurate Error message. 2-hook weighing with pull test bracket poss. inaccurate Check sensor	A363		E	1
3D007B	LSB-BSE3: LMB LMB1 not synchronous with LMB2 error report Correct operand on respective BSE	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D0129	LSB-BSE3: LMB STOP, length indicator derrick counterweight faulty/not present LMB-STOP with error message Check length sensor of ballast sliding cylinder and replace if nec.	A363		E	1
3D0133	LSB-BSE3: LMB fly jib retaining cylinder inferior minimal pressure If main boom is above 10 degrees or relapse cyl. run together on limit switch, shut off occurs When RFP-pressure in test position not in tolerance window, replace RFP, otherwise check job rods	A363		E	1
3D0134	LSB-BSE3: LMB fly jib retaining cylinder exceeds maximum pressure If main boom is above 10 degrees or relapse cyl. run together on limit switch, shut off occurs When RFP-pressure in test position not in tolerance window, replace RFP, otherwise check job rods	A363		E	1
3D014F	LSB-BSE3: LMB STOP, load chart has development status Error message with LMB-Stop Load new load charts or new crane. Disclose all error parameters to customer service	A363		E	1
3D015D	LSB-BSE3: LMB Set up condition defective: manual pinning last telescope Error message with LMB-Stop Check manual pinning, check possible sensor	A363		E	1
3D015E	LSB-BSE3: LMB Set up condition faulty: Main boom not correctly detected. Error message with LMB-Stop Check set up condition	A363		E	1
3D015F	LSB-BSE3: LMB Set up condition faulty: Accessories not correctly detected. Error message with LMB-Stop Check set up condition	A363		E	1
3D0160	LSB-BSE3: LMB Set up condition faulty: Accessory angle not correct. Error message with LMB-Stop Check set up condition, check angle sensor	A363		E	1
3D01A0	LSB-BSE3: LMB Load display in TY-operation incorrect; Y-angle sensor erroneous error report Report all error parameters to Service	A363		E	1
3D01AA	LSB-BSE3: LMB Force measuring point accessories implausible LMB-STOP with error message Check measuring point	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D0229	LSB-BSE3: LMB STOP, SA-frame assembly cylinder extended too far (limit switch) Error message with LMB-Stop Move assembly cylinder out from block position	A363		B	1
3D022A	LSB-BSE3: LMB Angle sensor SA-bracket deviates from theor. angle impermissible Only error message Check angle sensor SA-frame, replace if nec.; possibly incorrect main boom length set up, therefore incorrect angle valu	A363		E	1
3D022B	LSB-BSE3: LMB Stop, limit switch SA cyl. defect.. Block position is not recognized Error message with LMB-Stop Check SA-inductive switch for block pos.	A363		E	1
3D025A	LSB-BSE3: LMB STOP, pressure sensor, piston surface luffing cyl. different values LMB-Stop Check pressure sensor on luffing cylinder	A363		E	1
3D025B	LSB-BSE3: LMB STOP, Pressure sensor ring surface luffing cyl. uneven values LMB-Stop Check pressure sensor on luffing cylinder	A363		E	1
3D0270	LSB-BSE3: LMB Measured ballast weight negative LMB-Stop Check pressure sensor in ballast lift cyl.	A363		E	1
3D0271	LSB-BSE3: LMB Value difference too large in test points for ballast lift cyl. Report to SPS Rerun to match pulled forces in ballast lift cyl.	A363		E	1
3D0272	LSB-BSE3: LMB Pulled ballast weight exceeded the equipped ballast LMB-Stop In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A363		E	1
3D0273	LSB-BSE3: LMB STOP, Ballast suspended at insufficiently low pulled ballast weight LMB-Stop In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A363		E	1
3D0274	LSB-BSE3: LMB Force on F1 less than expected Only error message Check test points and pressure sensors for relapse cyl. of derrick	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D0275	LSB-BSE3: LMB Force on F1 larger than expected Only error message Check test points and pressure sensors for relapse cyl. of derrick	A363		E	1
3D0276	LSB-BSE3: LMB Difference of parallel pull test brackets too large LMB-Stop Check pull test brackets of corr. test point (par. 2); if nec. elim. side pull to guying	A363		E	1
3D0277	LSB-BSE3: LMB Difference of serial pull test brackets too large LMB-Stop Check pull test brackets in the respective test point (Parameter 2)	A363		E	1
3D0278	LSB-BSE3: LMB Difference or pressure sensor on derrick-RFPs exceeded tolerance Only error message Check relapse cyl., as well as their pressure sensors on derrick	A363		E	1
3D0279	LSB-BSE3: LMB Ballast weighing not possible. Hoist cyl. on block or LG not ok. Only error message Retrat or extend ballast hoist cyl. so that there is sufficient distance to block pos. or check length sensor	A363		E	1
3D027A	LSB-BSE3: LMB No derrick momentum calculation, since pulled ballast not determinable Only error message This is most often a subsequent error, therefore fix previous error w/respect to ballast hoist cylinder and susp. ballas	A363		E	1
3D027B	LSB-BSE3: LMB Difference of left/right boom relapse cyl. too large LMB-Stop Check main boom relapse cyl. as well as their pressure sensors and test axles	A363		E	1
3D027C	LSB-BSE3: LMB No hoist winch is assigned to main hook Only error message The assignment of winch in config. screen must be checked	A363		E	1
3D027D	LSB-BSE3: LMB Ballast suspended even though set up ballast not yet reached Only error message In set up screen, correct data of set up ballast and/or check pressure sensor in ballast hoist cylinders	A363		E	1
3D027E	LSB-BSE3: LMB STOP, pressure sensor ad KMA on boom relapse cyl. not ok LMB-Stop Check pressure sensors and force test axles on main boom relapse cyl	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D027F	LSB-BSE3: LMB Pressure sensor on boom relapse cyl. not ok Only error message Check pressure sensor on main boom relapse cyl	A363		E	1
3D0280	LSB-BSE3: LMB Force test axles on boom relapse cyl. not ok Only error message Check force test axles on main boom relapse cyl	A363		E	1
3D0281	LSB-BSE3: LMB Pressure sensor piston side on ballast lift cyl. defective Only error message Replace pressure sensor	A363		E	1
3D0282	LSB-BSE3: LMB Length sensor ballast lift cyl. defective. Calculation with incline se Only error message Replace length sensor	A363		E	1
3D0283	LSB-BSE3: LMB Guying of rocker too short or too long, check guying! Only error message Check assembly of guying. Possible increased sagging due to assembly procedure	A363		E	1
3D0287	LSB-BSE3: LMB No weighing possible. HA-guying is possible placed in part Only error message possibly luff up Derrick / SA-luffing gear	A363		B	1
3D0288	LSB-BSE3: LMB KMA defective. Pressure sensors are used. Weighing possibly too high.. Only error message Check force test axle in S-relapse cyl., possibly replace force test axle	A363		E	1
3D0289	LSB-BSE3: LMB Sensor of RFP defective. Weighing is increased if RFP engaged Only error message Check pressure sensors in S-relapse cyl., possibly replace pressure sensors	A363		E	1
3D02A0	LSB-BSE3: LMB RFP-Block limit switch HA defect. Weighing in RFP-access pt. too high Only error message Check inductive sensors in S-relapse cyl., poss. replace inductive sensors	A363		E	1
3D02A1	LSB-BSE3: LMB RFP HA on block. Weighing too high? HA above 80 degr on luffing Only error message Main boom luffing up to over 80 degree	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D02B0	LSB-BSE3: LMB STOP, Ballast recognition: one / sev. sensors not recognized Error message and LMB stop Check sensor, replace if necessary	A363		E	1
3D02B1	LSB-BSE3: LMB STOP, ballast detection: Ballast no.1 missing for set up condition Error message and LMB stop Check ballast coding	A363		B	1
3D02B2	LSB-BSE3: LMB STOP, ballast detection: Ballast no.2 missing for set up condition Error message and LMB stop Check ballast coding	A363		B	1
3D02B3	LSB-BSE3: LMB STOP, ballast detection: Ballast no.3 missing for set up condition Error message and LMB stop Check ballast coding	A363		B	1
3D02B4	LSB-BSE3: LMB STOP, ballast detection: Ballast no.4 missing for set up condition Error message and LMB stop Check ballast coding	A363		B	1
3D02B5	LSB-BSE3: LMB STOP, ballast detection: Ballast no.5 missing for set up condition Error message and LMB stop Check ballast coding	A363		B	1
3D02B6	LSB-BSE3: LMB STOP, ballast detection: Ballast no.6 missing for set up condition Error message and LMB stop Check ballast coding	A363		B	1
3D02C0	LSB-BSE3: LMB STOP, ballast detection: ballast not as set up Error message and LMB stop Check ballast radius	A363		B	1
3D02C1	LSB-BSE3: LMB STOP, ballast detection: Ballast no.1 may not be detected Error message and LMB stop Check ballast coding	A363		B	1
3D02C2	LSB-BSE3: LMB STOP, ballast detection: Ballast no.2 may not be detected Error message and LMB stop Check ballast coding	A363		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D02C3	LSB-BSE3: LMB STOP, ballast detection: Ballast no.3 may not be detected Error message and LMB stop Check ballast coding	A363		B	1
3D02C4	LSB-BSE3: LMB STOP, ballast detection: Ballast no.4 may not be detected Error message and LMB stop Check ballast coding	A363		B	1
3D02C5	LSB-BSE3: LMB STOP, ballast detection: Ballast no.5 may not be detected Error message and LMB stop Check ballast coding	A363		B	1
3D02C6	LSB-BSE3: LMB STOP, ballast detection: Ballast no.6 may not be detected Error message and LMB stop Check ballast coding	A363		B	1
3D0300	LSB-BSE3: LMB STOP save error (Note parameter) LMB-Stop Report all error parameters to Service	A363		E	1
3D0301	LSB-BSE3: LMB Save error (Note parameter) error report Report all error parameters to Service	A363		E	1
3D0310	LSB-BSE3: LMB STOP no weighing, reeving insufficient or lever arm cond. LMB-Stop Increase reeving	A363		E	1
3D0311	LSB-BSE3: LMB STOP chart values for SRFP not available Error message and LMB stop Report all error parameters to Service	A363		E	1
3D0312	LSB-BSE3: LMB STOP WG on main boom defective, SRPF nominal value can't be determined Error message and LMB stop Check angle sensor on main boom	A363		E	1
3D0317	LSB-BSE3: LMB STOP, max. superstructure length incline exceeded LMB-Stop Support crane horizontally	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D0318	LSB-BSE3: LMB STOP, max. superstructure lateral incline exceeded LMB-Stop Support crane horizontally	A363		E	1
3D0319	LSB-BSE3: LMB STOP, max. chassis incline exceeded LMB-Stop Support crane horizontally	A363		E	1
3D031A	LSB-BSE3: LMB STOP, maximum chassis length incline exceeded LMB-Stop Support crane horizontally	A363		E	1
3D031B	LSB-BSE3: LMB STOP, maximum chassis cross incline exceeded LMB-Stop Support crane horizontally	A363		E	1
3D031C	LSB-BSE3: LMB STOP, Number of last activated winch invalid LMB-Stop Initiate momentary movement down with one hoist winch	A363		E	1
3D031D	LSB-BSE3: LMB STOP, no winch is assigned to setting LMB-Stop Assignment of winches in geometry must be checked, possible also check in set up screen	A363		E	1
3D0355	LSB-BSE3: LMB STOP at last operation no pin information saved LMB-Stop Place manually or pin in retracted last telescope	A363		E	1
3D0356	LSB-BSE3: LMB STOP pin condition inconsistent, no tele pin hole found LMB-Stop Report all error parameters to Service	A363		E	1
3D0357	LSB-BSE3: LMB STOP pin condition inconsistent, no valid condition loadable LMB-Stop Report all error parameters to Service	A363		E	1
3D0358	LSB-BSE3: LMB STOP pin condition inconsistent, Telescope not reachable LMB-Stop Report all error parameters to Service	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D0359	LSB-BSE3: LMB STOP Length s. defective to pinning point, tele length not valid LMB-Stop Report all error parameters to Service	A363		E	1
3D035A	LSB-BSE3: LMB STOP Pin condition Tele/cylinder inconsistent or no signal LMB-Stop Report all error parameters to Service	A363		E	1
3D035C	LSB-BSE3: LMB STOP Length sensor tele cyl. larger than max. cyl. stroke LMB-Stop Report all error parameters to Service	A363		E	1
3D035D	LSB-BSE3: LMB STOP Length sensor tele cyl. smaller Null LMB-Stop Report all error parameters to Service	A363		E	1
3D0371	LSB-BSE3: LMB STOP second LMB delivers other result LMB-Stop can occur as follow up error at a LMB-Stop auftreten	A363		E	1
3D03A0	LSB-BSE3: LMB Pressure sensor RFP-Main boom does not match force test axle Only error message Check relapse cyl. on main boom	A363		E	1
3D03A1	LSB-BSE3: LMB Difference too large: Derrick angle sensor top and bottom LMB-Stop Check or replace angle sensor on derrick	A363		E	1
3D03A3	LSB-BSE3: LMB Difference of boom angle sensors too large LMB-Stop Check angle sensor on main boom	A363		E	1
3D0612	LSB-BSE3: Data recorder Start: not connected No recording possible! Check data logger in 1 sec. interval Connect data logger, if necessary, check connection from LICCON system to data logger	A363		E	1
3D0620	LSB-BSE3: Data recorder Init: Firmware version incorrect/faulty Has not yet been checked! Report all error parameters to Service	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D0621	LSB-BSE3: Data recorder Init: ATA-card not initialised STATUS-error: Data recorder software stops - no documentation possible! Initialize ATA-Card with PC-Software 'LICCON Manager'	A363		E	1
3D0622	LSB-BSE3: Data recorder Init: ATA-card contains different crane number STATUS-error: Data recorder software stops - no documentation possible! Use ATA card with correct crane number or newly initialised ATA card	A363		E	1
3D0623	LSB-BSE3: Data recorder Init: Format-File-Transfer faulty Repeat of Format-File transfers in 1 sec. cycles If necessary, correct type and country specific format file 'Lnnttt01vvr.Q' in EPROM 0	A363		E	1
3D0630	LSB-BSE3: Data recorder Transfer: Data transmission faulty Repeat of data transfers in 1 sec. cycles If necessary check connection from LICCON system to data recorder	A363		E	1
3D0631	LSB-BSE3: Data recorder Transfer: CSM-protocol error Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A363		E	1
3D0632	LSB-BSE3: Data recorder Transfer: Transmission error (CRC) Respective telegram is repeated max. 3x, then synchronise completely anew If necessary check connection from LICCON system to data recorder	A363		E	1
3D0633	LSB-BSE3: Data recorder Transfer: STATUS-error Resynchronize depending on STATUS in 1 sec.interval If necessary check connection from LICCON system to data recorder	A363		E	1
3D0634	LSB-BSE3: Data recorder Transfer: TAN-error Synchronise CSM protocol again completely If necessary check connection from LICCON system to data recorder	A363		E	1
3D0635	LSB-BSE3: Data recorder Transfer: Writing error Synchronise CSM protocol again completely If necessary check connection from LICCON-System to data recorder and ATA card	A363		E	1
3D0849	LSB-BSE3: Operating hours counter urgent modul, ZE not available error report Report all error parameters to Service	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D0878	LSB-BSE3: Operating hours counter impermissible parameter Error message, Parameter is possibly set to min or max Software update required, report all error parameter to Service Dept.	A363		E	2
3D094A	LSB-BSE3: Operating data protection not possible. Module missing, communication to module is erroneous error report In LICCON REMOTE DIAGNOSTICS - LSB DIAGNOSTICS localize missing LSB modules. Disclose all parameters to customer service	A363		E	2
3D0978	LSB-BSE3: Operating data protection impermissible parameter error report Software update required, report all error parameter to Service Dept.	A363		E	2
3D1200	LSB-BSE3: LPC No allocation for write cache requirement error report Reprogramming	A363		E	1
3D1201	LSB-BSE3: LPC Variable not available or connected error report Reprogramming	A363		E	1
3D1202	LSB-BSE3: LPC No write buffer release error report Reprogramming	A363		E	1
3D1203	LSB-BSE3: LPC Error at connection of one variable error report Reprogramming	A363		E	1
3D3B10	LSB-BSE3: Control ballasting / counterweight carriage Module software not compatible to crane -> module needs update	A363		E	1
3D3B11	LSB-BSE3: Control ballasting / counterweight carriage Ball. trailer software not compatible to crane -> update BT applic. Error output and ballast trailer function locked Perform software update (update application) on the modules UEA14, UEA15 and BTB8.	A363		E	1
3D5B0E	LSB-BSE3: Operation ballasting / counterweight carriage Shut off BW steering limit angle turntable exceeded Issuance of error Ballast trailer changes automatically to towing op. Change to towing	A363		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3D5B0F	LSB-BSE3: Operation ballasting / counterweight carriage Shut off BW steering limit angle wheel set left exceeded Issuance of error Turning dir. Which increases angle is stopped Actuate wheel set in another direction	A363		E	1
3D5C10	LSB-BSE3: Operation crawler Shut off drive crawler BW Pull force > Fmax	A363		E	1
3D6170	LSB-BSE3: Operation crane control Key switch of monitor 2 actuated at start or stuck Function blocked Release key switch; check wiring	A363		B	
3DD01E	LSB-BSE3: Supply voltage 15.3 / CPU0 Voltage outside permissible range error report Check voltage, electr. connections and fuse	A363.X1:1		E	2
3DD11E	LSB-BSE3: Supply voltage 30.3 / CPU0 Voltage outside permissible range error report Check battery, electr. connections and fuse	A363.X1:2		E	2
3DDE14	LSB-BSE3: Analog input 0E0 / DSP0 short circuit to supply voltage error report Check DSP0-output A0.0, relay, electr. connections	A363.X4:3		E	2
3DDF14	LSB-BSE3: Analog input 0E1 / DSP0 short circuit to supply voltage error report Check DSP0-output A0.0, relay, electr. connections	A363.X4:4		E	2
3DE012	LSB-BSE3: Analog input 0E2 / DSP0 short circuit to ground error report Check Em. Off switch, voltage, electr. connections	A363.X4:5		E	2
3DE117	LSB-BSE3: Supply voltage 30.1 / DSP0 voltage below required value error indication on display Check battery, voltage, electr. connections and fuse	A363.X4:7		E	2
3DE217	LSB-BSE3: Supply voltage 15.1 / DSP0 voltage below required value error indication on display Check voltage	A363.X4:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3DE317	LSB-BSE3: Supply voltage 24V.1 (0A0-1) / DSP0 voltage below required value error indication on display Check voltage, electr. connections and fuse	A363.X4:15		E	2
3DE614	LSB-BSE3: Analog input 1E0 / DSP1 short circuit to supply voltage error report Check DSP1-output A0.0, relay, electr. connections	A363.X5:3		E	2
3DE714	LSB-BSE3: Analog input 1E1 / DSP1 short circuit to supply voltage error report Check DSP1-output A0.0, relay, electr. connections	A363.X5:4		E	2
3DE812	LSB-BSE3: Analog input 1E2 / DSP1 short circuit to ground error report Check Em. Off switch, voltage, electr. connections	A363.X5:5		E	2
3DE917	LSB-BSE3: Supply voltage 30.1 / DSP1 voltage below required value error indication on display Check battery, voltage, electr. connections and fuse	A363.X5:7		E	2
3DEA17	LSB-BSE3: Supply voltage 15.1 / DSP1 voltage below required value error indication on display Check voltage	A363.X5:8		E	2
3DEB17	LSB-BSE3: Supply voltage 24V.1 (0A0-1) / DSP1 voltage below required value error indication on display Check voltage, electr. connections and fuse	A363.X5:15		E	2
3DEC1B	LSB-BSE3: 2.Shut off channel / DSP0 digital shut off defective Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, fuse, replace module if nec.	A363		E	2
3DEC72	LSB-BSE3: 2.Shut off channel / DSP0 outside source feeding Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, replace module, if nec.	A363		E	2
3DED1B	LSB-BSE3: 2.Shut off channel / DSP1 digital shut off defective Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, fuse, replace module if nec.	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3DED72	LSB-BSE3: 2.Shut off channel / DSP1 outside source feeding Set error message to display, entry in error stack, error status bit in EW5 Check output current, user, replace module, if nec.	A363		E	2
3DF006	LSB-BSE3: System error OS-DSP0 initialising error RAM erroneous Entry in error memory, program is stopped Inform Service of all error parameters and replace module	A363		E	2
3DF013	LSB-BSE3: System error OS-DSP0 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A363		E	2
3DF016	LSB-BSE3: System error OS-DSP0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A363		E	2
3DF050	LSB-BSE3: System error OS-DSP0 file not available error report Reload application software	A363		E	3
3DF073	LSB-BSE3: System error OS-DSP0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A363		E	2
3DF082	LSB-BSE3: System error OS-DSP0 hardware-watchdog erroneous Module reset Replace module	A363		E	2
3DF0A1	LSB-BSE3: System error OS-DSP0 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF0A2	LSB-BSE3: System error OS-DSP0 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF0AD	LSB-BSE3: System error OS-DSP0 System voltage V26-Core outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3DF0B1	LSB-BSE3: System error OS-DSP0 Power-Fail-Status incorrect error report Check voltage	A363		E	2
3DF0C1	LSB-BSE3: System error OS-DSP0 Incorrect or wrong system version for application error report Reload matching system version	A363		E	1
3DF0D3	LSB-BSE3: System error OS-DSP0 Em. drop system is active -> System charge required Emerg. system takes over operation and allows repair of run time system Reestablish the defective DSP system via the 'Load system' menu point in the test system	A363		E	2
3DF106	LSB-BSE3: System error OS-DSP1 initialising error RAM erroneous Entry in error memory, program is stopped Inform Service of all error parameters and replace module	A363		E	2
3DF113	LSB-BSE3: System error OS-DSP1 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A363		E	2
3DF116	LSB-BSE3: System error OS-DSP1 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A363		E	2
3DF150	LSB-BSE3: System error OS-DSP1 file not available error report Reload application software	A363		E	3
3DF173	LSB-BSE3: System error OS-DSP1 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A363		E	2
3DF182	LSB-BSE3: System error OS-DSP1 hardware-watchdog erroneous Module reset Replace module	A363		E	2
3DF1A1	LSB-BSE3: System error OS-DSP1 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3DF1A2	LSB-BSE3: System error OS-DSP1 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF1AD	LSB-BSE3: System error OS-DSP1 System voltage V26-Core outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF1B1	LSB-BSE3: System error OS-DSP1 Power-Fail-Status incorrect error report Check voltage	A363		E	2
3DF1C1	LSB-BSE3: System error OS-DSP1 Incorrect or wrong system version for application error report Reload matching system version	A363		E	1
3DF1D3	LSB-BSE3: System error OS-DSP1 Em. drop system is active -> System charge required Emerg. system takes over operation and allows repair of run time system Reestablish the defective DSP system via the 'Load system' menu point in the test system	A363		E	2
3DF203	LSB-BSE3: System error OS-CPU0 CW Upload to data bank not carried out error report CW Carry out upload in data bank	A363		E	2
3DF280	LSB-BSE3: System error OS-CPU0 Fatal internal error error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF299	LSB-BSE3: System error OS-CPU0 DSP0 erroneous error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF29A	LSB-BSE3: System error OS-CPU0 DSP1 erroneous error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF29B	LSB-BSE3: System error OS-CPU0 dsPIC erroneous error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3DF2A1	LSB-BSE3: System error OS-CPU0 System voltage 3V3-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF2A2	LSB-BSE3: System error OS-CPU0 System voltage 5V-Logic outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF2A3	LSB-BSE3: System error OS-CPU0 Board temp. outside permissible range error indication on display Check coolant supply for monitor	A363		E	2
3DF2A4	LSB-BSE3: System error OS-CPU0 Inside temperature outside permissible range error indication on display Check coolant supply for monitor	A363		E	2
3DF2A5	LSB-BSE3: System error OS-CPU0 System voltage 12V-CCFL outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF2AB	LSB-BSE3: System error OS-CPU0 System voltage 5V-Standby outside permissible range error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF2AC	LSB-BSE3: System error OS-CPU0 Restoration of CW-operandi failed error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF2AE	LSB-BSE3: System error OS-CPU0 System voltage PCMCIA erroneous error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF2AF	LSB-BSE3: System error OS-CPU0 System voltage 3V- cell-RTC too low error report If time is corrupt, replace battery Type CR1225 in monitor	A363		E	2
3DF2B0	LSB-BSE3: System error OS-CPU0 Time RTC erroneous (Low-Voltage) error report Replace battery Type CR1225 in monitor	A363		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
3DF2C0	LSB-BSE3: System error OS-CPU0 Hardware / Software erroneous error report If error repeated, repl. comp. group, report error param. to Service	A363		E	2
3DF2FA	LSB-BSE3: System error OS-CPU0 BSE to BSE communication via CAN erroneous error report Replace comp. group, report error parameter to Service	A363		E	2
710516	2/3-wire converter: LSBA supply excess voltage Entry in error stack Check line connection, on-board voltage, fuse	A74		E	2
710517	2/3-wire converter: LSBA supply voltage below required value Entry in error stack Check line connection, on-board voltage, fuse	A74		E	2
710616	2/3-wire converter: LSBB supply excess voltage Entry in error stack Check line connection, on-board voltage, fuse	A74		E	2
710617	2/3-wire converter: LSBB supply voltage below required value Entry in error stack Check line connection, on-board voltage, fuse	A74		E	2
710716	2/3-wire converter: LSBA and LSBB supply excess voltage Entry in error stack Check on-board voltage	A74		E	2
710717	2/3-wire converter: LSBA and LSBB supply voltage below required value Entry in error stack Check on-board voltage	A74		E	2
710816	2/3-wire converter: Power supply 5 V excess voltage Entry in error stack Replace 2/3-wire converter	A74		E	2
710817	2/3-wire converter: Power supply 5 V voltage below required value Entry in error stack Replace 2/3-wire converter	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
710916	2/3-wire converter: Power supply 3.3 V excess voltage Entry in error stack Replace 2/3-wire converter	A74		E	2
710917	2/3-wire converter: Power supply 3.3 V voltage below required value Entry in error stack Replace 2/3-wire converter	A74		E	2
71D037	2/3-wire converter: LSB1_2W driver - watchdog (program monitoring) Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start Replace 2/3-wire converter	A74		E	2
71D07F	2/3-wire converter: LSB1_2W driver - Data transfer without secured telegram Entry in error stack Correct parameter set, replace LSB-participant	A74		E	2
71D0A6	2/3-wire converter: LSB1_2W driver - Error 6 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D0A7	2/3-wire converter: LSB1_2W driver - Error 7 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D137	2/3-wire converter: LSB2_2W driver - watchdog (program monitoring) Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start Replace 2/3-wire converter	A74		E	2
71D17F	2/3-wire converter: LSB2_2W driver - Data transfer without secured telegram Entry in error stack Correct parameter set, replace LSB-participant	A74		E	2
71D1A6	2/3-wire converter: LSB2_2W driver - Error 6 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D1A7	2/3-wire converter: LSB2_2W driver - Error 7 Entry in error stack Replace 2/3-wire converter	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
71D237	2/3-wire converter: LSB3_2W driver - watchdog (program monitoring) Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start Replace 2/3-wire converter	A74		E	2
71D27F	2/3-wire converter: LSB3_2W driver - Data transfer without secured telegram Entry in error stack Correct parameter set, replace LSB-participant	A74		E	2
71D2A6	2/3-wire converter: LSB3_2W driver - Error 6 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D2A7	2/3-wire converter: LSB3_2W driver - Error 7 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D337	2/3-wire converter: LSB4_2W driver - watchdog (program monitoring) Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start Replace 2/3-wire converter	A74		E	2
71D37F	2/3-wire converter: LSB4_2W driver - Data transfer without secured telegram Entry in error stack Correct parameter set, replace LSB-participant	A74		E	2
71D3A6	2/3-wire converter: LSB4_2W driver - Error 6 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D3A7	2/3-wire converter: LSB4_2W driver - Error 7 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D437	2/3-wire converter: LSBA driver - watchdog (program monitoring) Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start Replace 2/3-wire converter	A74		E	2
71D47F	2/3-wire converter: LSBA driver - Data transfer without secured telegram Entry in error stack Correct parameter set, replace LSB-participant	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
71D4A6	2/3-wire converter: LSBA driver - Error 6 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D4A7	2/3-wire converter: LSBA driver - Error 7 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D537	2/3-wire converter: LSBB driver - watchdog (program monitoring) Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start Replace 2/3-wire converter	A74		E	2
71D57F	2/3-wire converter: LSBB driver - Data transfer without secured telegram Entry in error stack Correct parameter set, replace LSB-participant	A74		E	2
71D5A6	2/3-wire converter: LSBB driver - Error 6 Entry in error stack Replace 2/3-wire converter	A74		E	2
71D5A7	2/3-wire converter: LSBB driver - Error 7 Entry in error stack Replace 2/3-wire converter	A74		E	2
71E052	2/3-wire converter: LSB1_2W has recognised Bus collisions, communication interrupted Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E090	2/3-wire converter: LSB1_2W Bus connection is erroneous, defective, Short circuit after ground Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E091	2/3-wire converter: LSB1_2W Bus connection is erroneous Short circuit after ground, power source d Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E092	2/3-wire converter: LSB1_2W Bus connection has open line Entry in error stack check connection, if connection ok then replace sensor	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
71E093	2/3-wire converter: LSB1_2W Bus connection has Short circuit after ground Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E094	2/3-wire converter: LSB1_2W Bus connection has short circuit after Plus Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E095	2/3-wire converter: LSB1_2W Bus connection has Short circuit after ground before System start Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E096	2/3-wire converter: LSB1_2W Bus connection has short circuit after Plus before System start Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E097	2/3-wire converter: LSB1_2W Current flows to user, but no data exchange is possible Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E099	2/3-wire converter: LSB1_2W Sensor with same bus address recognized Entry in error stack Remedy address conflict by removing one participant. Assign correct addresses via test system	A74		E	2
71E152	2/3-wire converter: LSB2_2W has recognised Bus collisions, communication interrupted Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E190	2/3-wire converter: LSB2_2W Bus connection is erroneous, defective, Short circuit after ground Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E191	2/3-wire converter: LSB2_2W Bus connection is erroneous Short circuit after ground, power source d Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E192	2/3-wire converter: LSB2_2W Bus connection has open line Entry in error stack check connection, if connection ok then replace sensor	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
71E193	2/3-wire converter: LSB2_2W Bus connection has Short circuit after ground Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E194	2/3-wire converter: LSB2_2W Bus connection has short circuit after Plus Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E195	2/3-wire converter: LSB2_2W Bus connection has Short circuit after ground before System start Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E196	2/3-wire converter: LSB2_2W Bus connection has short circuit after Plus before System start Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E197	2/3-wire converter: LSB2_2W Current flows to user, but no data exchange is possible Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E199	2/3-wire converter: LSB2_2W Sensor with same bus address recognized Entry in error stack Remedy address conflict by removing one participant. Assign correct addresses via test system	A74		E	2
71E252	2/3-wire converter: LSB3_2W has recognised Bus collisions, communication interrupted Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E290	2/3-wire converter: LSB3_2W Bus connection is erroneous, defective, Short circuit after ground Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E291	2/3-wire converter: LSB3_2W Bus connection is erroneous Short circuit after ground, power source d Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E292	2/3-wire converter: LSB3_2W Bus connection has open line Entry in error stack check connection, if connection ok then replace sensor	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
71E293	2/3-wire converter: LSB3_2W Bus connection has Short circuit after ground Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E294	2/3-wire converter: LSB3_2W Bus connection has short circuit after Plus Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E295	2/3-wire converter: LSB3_2W Bus connection has Short circuit after ground before System start Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E296	2/3-wire converter: LSB3_2W Bus connection has short circuit after Plus before System start Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E297	2/3-wire converter: LSB3_2W Current flows to user, but no data exchange is possible Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E299	2/3-wire converter: LSB3_2W Sensor with same bus address recognized Entry in error stack Remedy address conflict by removing one participant. Assign correct addresses via test system	A74		E	2
71E352	2/3-wire converter: LSB4_2W has recognised Bus collisions, communication interrupted Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E390	2/3-wire converter: LSB4_2W Bus connection is erroneous, defective, Short circuit after ground Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E391	2/3-wire converter: LSB4_2W Bus connection is erroneous Short circuit after ground, power source d Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E392	2/3-wire converter: LSB4_2W Bus connection has open line Entry in error stack check connection, if connection ok then replace sensor	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
71E393	2/3-wire converter: LSB4_2W Bus connection has Short circuit after ground Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E394	2/3-wire converter: LSB4_2W Bus connection has short circuit after Plus Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E395	2/3-wire converter: LSB4_2W Bus connection has Short circuit after ground before System start Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E396	2/3-wire converter: LSB4_2W Bus connection has short circuit after Plus before System start Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E397	2/3-wire converter: LSB4_2W Current flows to user, but no data exchange is possible Entry in error stack check connection, if connection ok then replace sensor	A74		E	2
71E399	2/3-wire converter: LSB4_2W Sensor with same bus address recognized Entry in error stack Remedy address conflict by removing one participant. Assign correct addresses via test system	A74		E	2
71F137	2/3-wire converter: System watchdog (program monitoring) Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start Replace 2/3-wire converter	A74		E	2
71F180	2/3-wire converter: System Clock, Timer module is erroneous Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1A1	2/3-wire converter: System Error 1 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1A2	2/3-wire converter: System Error 2 Entry in error stack Replace 2/3-wire converter	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
71F1A3	2/3-wire converter: System Error 3 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1A4	2/3-wire converter: System Error 4 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1A5	2/3-wire converter: System Error 5 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1A6	2/3-wire converter: System Error 6 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1A7	2/3-wire converter: System Error 7 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1A8	2/3-wire converter: System Error 8 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1A9	2/3-wire converter: System Error 9 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1AA	2/3-wire converter: System Error 10 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1AB	2/3-wire converter: System Error 11 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1AC	2/3-wire converter: System Error 12 Entry in error stack Replace 2/3-wire converter	A74		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
71F1AD	2/3-wire converter: System Error 13 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1AE	2/3-wire converter: System Error 14 Entry in error stack Replace 2/3-wire converter	A74		E	2
71F1AF	2/3-wire converter: System Error 15 Entry in error stack Replace 2/3-wire converter	A74		E	2
821111	retarder: Output AD1 - re-circulation valve short circuit to ground ECU no longer selects recirculation valve, response time becomes longer RESET; otherwise check wiring between ECU and check accumulator charging valve, check accumulator charging valve (inside	A62.X1:1		E	1
821112	retarder: Output AD1 - re-circulation valve short circuit to supply voltage ECU no longer selects recirculation valve, response time becomes longer INT OFF/ON - check cables between ECU and recirculation valve, ZF 02	A62.X1:1		E	1
821113	retarder: Output AD1 - re-circulation valve interruption ECU no longer selects recirculation valve, response time becomes longer INT OFF/ON - check wiring between ECU and accumulator charging valve, check accumulator charging valve (inside resistanc	A62.X1:1		E	1
821911	retarder: Output AIP- proportional-flow valve short circuit to ground ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, check proportional valve (inner resistance), ZF 25	A62.X1:4		E	1
821912	retarder: Output AIP- proportional-flow valve short circuit to supply voltage ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, ZF 26	A62.X1:4		E	1
821913	retarder: Output AIP- proportional-flow valve interruption ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, check proportional valve (inner resistance), ZF 27	A62.X1:4		E	1
821914	retarder: Output AIP- proportional-flow valve Resistance incorrect ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, check proportional valve (inner resistance), ZF 28	A62.X1:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
822111	retarder: Output ADM1 - Dimensions proportional-flow valve short circuit to ground ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, ZF 29	A62.X1:3		E	1
822112	retarder: Output ADM1 - Dimensions proportional-flow valve short circuit to supply voltage ECU switches off the intarder; Intarder no longer available RESET - check cables between ECU and proportional valve, check proportional valve (inner resistance), ZF 30	A62.X1:3		E	1
822316	retarder: Amperemeter channel proportional-flow valve Malfunction limit fallen short of ECU switches off the intarder; Intarder no longer available RESET - replace ECU, ZF 39	A62.X1:3/4		E	1
822317	retarder: Amperemeter channel proportional-flow valve Malfunction limit exceeded ECU switches off the intarder; Intarder no longer available RESET - replace ECU, ZF 40	A62.X1:3/4		E	1
823211	retarder: Input ER1 - temperature sensor short circuit to ground ECU limits the braking action to 100 kW INT OFF/ON - check cables between ECU and temperature sensor, temperature sensor (resistance), ZF 38	A62.X1:9		E	1
823213	retarder: Input ER1 - temperature sensor interruption ECU limits the braking action to 100 kW INT OFF/ON - check cables between ECU and temperature sensor, check temperature sensor (resistance), ZF 37	A62.X1:9		E	1
823318	retarder: Inputs ED1..ED5 - brake stage switch Check sum / signal(s) implausible ECU reduces the set braking level under certain circumstances INT OFF/ON - check cables between ECU and brake range switch, check brake range switch, ZF 44	A62.X1:15/16/17 /42/43		E	1
824319	retarder: CAN transmission malfunction Data transfer faulty/missing, signal error no reaction RESET - check CAN-Bus line, check terminal resistance, ZF 53	A62.X1:22/49/21 /48		E	1
824415	retarder: CAN-Bus Data transfer faulty/missing, max. cycle time exceeded ECU switches off the intarder; Intarder no longer available RESET - check CAN-Bus line, ZF 54	A62.X1:22/49/21 /48		E	1
824615	retarder: CAN-Bus data transfer Data transfer faulty/missing, max. cycle time exceeded no reaction RESET - check CAN-Bus line, check terminal resistance, ZF 56	A62.X1:22/49/21 /48		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
825819	retarder: CAN-data transfer ABS/ASR (ID 512) Data transfer faulty/missing, signal error ECU switches off the intarder; Intarder no longer available INT OFF/ON - check ABS-ECU, check CAN-Bus line, check terminal resistance, ZF 74	A62.X1:22/49		E	1
825919	retarder: CAN-data transfer engine (ID 592) Data transfer faulty/missing, signal error ECU limits the braking action to 350 kW INT OFF/ON - check FMR-ECU, check CAN-Bus line, check terminal resistance, ZF 75	A62.X1:22/49		E	1
826119	retarder: CAN-data transfer engine (ID 593) Data transfer faulty/missing, signal error ECU limits the braking action to 350 kW INT OFF/ON - check FMR-ECU, check CAN-Bus line, check terminal resistance, ZF 75	A62.X1:22/49		E	1
826219	retarder: CAN-data transfer gears (ID 556) Data transfer faulty/missing, signal error ECU limits the power to 250 mA, the automatic brake (Bremsomat) is not available INT OFF/ON - check TCU-ECU, check CAN-Bus line, check terminal resistance, ZF 80	A62.X1:22/49		E	1
827113	retarder: Supply VPE1/VPE2 Kl.30 interruption no reaction RESET - check supply of ECU (cables), ZF 41	A62.X1:54/55		E	1
827216	retarder: Supply VPI1/VPI2 Kl.15 Malfunction limit fallen short of ECU switches off the intarder; Intarder no longer available RESET - check on-board supply voltage (battery, alternator), ZF 43	A62.X1:53/31		E	1
827217	retarder: Supply VPI1/VPI2 Kl.15 Malfunction limit exceeded ECU switches off the intarder; Intarder no longer available RESET - check on-board supply voltage (battery, alternator), ZF 42	A62.X1:53/31		E	1
828218	retarder: Operating hours counter Check sum / signal(s) implausible ECU resets the operating hour counter back to 0 Replace ECU, ZF 46	A62.X1		E	0
828318	retarder: Error memory Check sum / signal(s) implausible ECU rejects the error memory content Replace ECU, ZF 47	A62.X1		E	0
828415	retarder: System error Data transfer faulty/missing, max. cycle time exceeded ECU switches off the intarder; Intarder no longer available Replace ECU, ZF 51	A62.X1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
843300	heating, air cond.: Aux. heater chassis No function, control unit error / heater lock no reaction check fuses, check battery terminals, replace control device	A130		E	1
843301	heating, air cond.: Aux. heater chassis no start Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A130		E	1
843302	heating, air cond.: Aux. heater chassis repeated glow interruption Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A130		E	1
843303	heating, air cond.: Aux. heater chassis lack of voltage/excess voltage Error message, function of auxiliary heater is problematic check battery, check electrical connections	A130.X8:12		E	1
843304	heating, air cond.: Aux. heater chassis premature glow identification Error message, function of auxiliary heater is problematic replace flame detector	A130		E	1
843305	heating, air cond.: Aux. heater chassis Flame sensor/flame monitor interruption / short circuit Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace flame detector	A130.X6:1		E	1
843306	heating, air cond.: Aux. heater chassis Temperature sensor interruption / short circuit (coolant- for Pro) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace temperature sensor	A130.X5:1		E	1
843307	heating, air cond.: Aux. heater chassis Metering pump/ solenoid valve interruption / short circuit/ defect Error message, function of auxiliary heater is problematic check coolant level, bleed coolant circuit, reset temperature limitation, examine cabling	A130.X3:1		E	1
843308	heating, air cond.: Aux. heater chassis blower motor interruption/short circuit/erroneous speed Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace combustion air ventilator	A130.X1:1		E	1
843309	heating, air cond.: Aux. heater chassis Glow plug interruption / short circuit/ defective (circulation pump Th Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace heater plug	A130.X2:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
843310	heating, air cond.: Aux. heater chassis overheating Error message, function of auxiliary heater is problematic re-fill coolant, press temperature limitation button before switching on, replace temperature limitation	A130		E	1
843311	heating, air cond.: Aux. heater chassis Circulation pump interruption / short circuit (ignition spark sensor T) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace water pump	A130.X4.1		E	1
843312	heating, air cond.: Aux. heater chassis Battery disconnect switch short circuit,(heater lock ThermoS) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace set value transmitter	A130		E	1
843501	heating, air cond.: control heating/air conditioning Excess temperature on heat exchanger heater Entry in error stack as system error, Mixing valve 1 is cycled at 25%, blower at least30%, limited Check wiring, thermo switch function, water level in heating circuit, mixing valve for function, error on aux. heating			E	2
843600	heating, air cond.: Aux. heater Superstr. No function, control unit error / heater lock no reaction check fuses, check battery terminals, replace control device	A330		E	1
843601	heating, air cond.: Aux. heater Superstr. no start Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A330		E	1
843602	heating, air cond.: Aux. heater Superstr. repeated glow interruption Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A330		E	1
843603	heating, air cond.: Aux. heater Superstr. lack of voltage/excess voltage Error message, function of auxiliary heater is problematic check battery, check electrical connections	A330.X8:12		E	1
843604	heating, air cond.: Aux. heater Superstr. premature glow identification Error message, function of auxiliary heater is problematic replace flame detector	A330		E	1
843605	heating, air cond.: Aux. heater Superstr. Flame sensor/flame monitor interruption / short circuit Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace flame detector	A330.X6:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
843606	heating, air cond.: Aux. heater Superstr. Temperature sensor interruption / short circuit (coolant- for Pro) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace temperature sensor	A330.X5:1		E	1
843607	heating, air cond.: Aux. heater Superstr. Metering pump/ solenoid valve interruption / short circuit/ defect Error message, function of auxiliary heater is problematic check coolant level, bleed coolant circuit, reset temperature limitation, examine cabling	A330.X3:1		E	1
843608	heating, air cond.: Aux. heater Superstr. blower motor interruption/short circuit/erroneous speed Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace combustion air ventilator	A330.X1:1		E	1
843609	heating, air cond.: Aux. heater Superstr. Glow plug interruption / short circuit/ defective (circulation pump Th Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace heater plug	A330.X2:1		E	1
843610	heating, air cond.: Aux. heater Superstr. overheating Error message, function of auxiliary heater is problematic re-fill coolant, press temperature limitation button before switching on, replace temperature limitation	A330		E	1
843611	heating, air cond.: Aux. heater Superstr. Circulation pump interruption / short circuit (ignition spark sensor T Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace water pump	A330.X4.1		E	1
843612	heating, air cond.: Aux. heater Superstr. Battery disconnect switch short circuit,(heater lock ThermoS) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace set value transmitter	A330		E	1
843613	heating, air cond.: Aux. heater Superstr. Outlet blower short circuit, (Error nozzle base preheating ThermoS) Error issue function limited Check aux. heater	A330		E	
843614	heating, air cond.: Aux. heater Superstr. Overheat protection defective,(Min. burn time fallen below ThermoS) Error issue function limited Check aux. heater	A330		E	
843615	heating, air cond.: Aux. heater Superstr. Glow plug R Ref. not reached, (rpm signal erroneous ThermoS) Error issue function limited Check aux. heater	A330		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
843616	heating, air cond.: Aux. heater Superstr. Exhaust temperature too high Error issue function limited Check wiring and temperature sensor, clean heater	A330		E	
843617	heating, air cond.: Aux. heater Superstr. Exhaust temperature sensor defective Error issue function limited Check aux. heater	A330		E	
843800	heating, air cond.: Aux. heater preheating engine 1 No function, control unit error / heater lock no reaction check fuses, check battery terminals, replace control device	A510		E	1
843801	heating, air cond.: Aux. heater preheating engine 1 no start Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A510		E	1
843802	heating, air cond.: Aux. heater preheating engine 1 repeated glow interruption Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A510		E	1
843803	heating, air cond.: Aux. heater preheating engine 1 lack of voltage/excess voltage Error message, function of auxiliary heater is problematic check battery, check electrical connections	A510.X8:12		E	1
843804	heating, air cond.: Aux. heater preheating engine 1 premature glow identification Error message, function of auxiliary heater is problematic replace flame detector	A510		E	1
843805	heating, air cond.: Aux. heater preheating engine 1 Flame sensor/flame monitor interruption / short circuit Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace flame detector	A510.X6:1		E	1
843806	heating, air cond.: Aux. heater preheating engine 1 Temperature sensor interruption / short circuit (coolant- for Pro) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace temperature sensor	A510.X5:1		E	1
843807	heating, air cond.: Aux. heater preheating engine 1 Metering pump/ solenoid valve interruption / short circuit/ defect Error message, function of auxiliary heater is problematic check coolant level, bleed coolant circuit, reset temperature limitation, examine cabling	A510.X3:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
843808	heating, air cond.: Aux. heater preheating engine 1 blower motor interruption/short circuit/erroneous speed Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace combustion air ventilator	A510.X1:1		E	1
843809	heating, air cond.: Aux. heater preheating engine 1 Glow plug interruption / short circuit/ defective (circulation pump Th Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace heater plug	A510.X2:1		E	1
843810	heating, air cond.: Aux. heater preheating engine 1 overheating Error message, function of auxiliary heater is problematic re-fill coolant, press temperature limitation button before switching on, replace temperature limitation	A510		E	1
843811	heating, air cond.: Aux. heater preheating engine 1 Circulation pump interruption / short circuit (ignition spark sensor T Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace water pump	A510.X4.1		E	1
843812	heating, air cond.: Aux. heater preheating engine 1 Battery disconnect switch short circuit,(heater lock ThermoS) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace set value transmitter	A510		E	1
843900	heating, air cond.: Aux. heater preheating engine 2 No function, control unit error / heater lock no reaction check fuses, check battery terminals, replace control device	A511		E	1
843901	heating, air cond.: Aux. heater preheating engine 2 no start Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A511		E	1
843902	heating, air cond.: Aux. heater preheating engine 2 repeated glow interruption Error message, function of auxiliary heater is problematic check fuel level and fuel filter, bleed fuel system, clean burner or replace	A511		E	1
843903	heating, air cond.: Aux. heater preheating engine 2 lack of voltage/excess voltage Error message, function of auxiliary heater is problematic check battery, check electrical connections	A511.X8:12		E	1
843904	heating, air cond.: Aux. heater preheating engine 2 premature glow identification Error message, function of auxiliary heater is problematic replace flame detector	A511		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
843905	heating, air cond.: Aux. heater preheating engine 2 Flame sensor/flame monitor interruption / short circuit Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace flame detector	A511.X6:1		E	1
843906	heating, air cond.: Aux. heater preheating engine 2 Temperature sensor interruption / short circuit (coolant- for Pro) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace temperature sensor	A511.X5:1		E	1
843907	heating, air cond.: Aux. heater preheating engine 2 Metering pump/ solenoid valve interruption / short circuit/ defect Error message, function of auxiliary heater is problematic check coolant level, bleed coolant circuit, reset temperature limitation, examine cabling	A511.X3:1		E	1
843908	heating, air cond.: Aux. heater preheating engine 2 blower motor interruption/short circuit/erroneous speed Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace combustion air ventilator	A511.X1:1		E	1
843909	heating, air cond.: Aux. heater preheating engine 2 Glow plug interruption / short circuit/ defective (circulation pump Th Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace heater plug	A511.X2:1		E	1
843910	heating, air cond.: Aux. heater preheating engine 2 overheating Error message, function of auxiliary heater is problematic re-fill coolant, press temperature limitation button before switching on, replace temperature limitation	A511		E	1
843911	heating, air cond.: Aux. heater preheating engine 2 Circulation pump interruption / short circuit (ignition spark sensor T Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace water pump	A511.X4.1		E	1
843912	heating, air cond.: Aux. heater preheating engine 2 Battery disconnect switch short circuit,(heater lock ThermoS) Error message, function of auxiliary heater is problematic check cabling for damage, search for break and short, replace set value transmitter	A511		E	1
847031	heating, air cond.: operation heating/air.conditioning Air cond. operation AUTO not possible Entry in error stack as operating error, selection is reset, no air cond. function AUTO selected / possible Check switching temp. sensors, for short circuit after GND or 24Volt, sensors, 10 V Ref. tension			B	
880100	Engine chassis: Control Travel pedal actuated at selected / active engine brake No acceptance of gases at active engine brake Deactivation of engine brake	A700.X2:34/.X2: 48		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880101	Engine chassis: Control Travel pedal actuated at support / superstructure operation No acceptance of gases at active support operation Deactivation of support operation	A700.X2:34/.X2: 48		B	1
880102	Engine chassis: Control Function "bleeding fuel supply" activated (gas pedal) Breather function of fuel pump and lines to engine on active Engine RPM 800 1/min or turn ignition off / on	A700.X2:34/.X2: 48		B	1
880103	Engine chassis: Control Engine Start prevented, ignition switch actuated after ignition on No engine start Release ignition switch, check ignition switch / wiring	A700.X2:66		B	1
880400	Engine chassis: CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded Emerg. op.: Momentum and RPM limitation of engine Check cable / plug / I/O-Module(s)	A700.X2:		E	1
880401	Engine chassis: CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / coupling module	A700.X2:		E	1
880402	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A700.X2:		E	1
880403	Engine chassis: CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A700.X2:		E	1
880404	Engine chassis: CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / gear module	A700.X2:		E	1
880405	Engine chassis: CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module1	A700.X2:		E	1
880406	Engine chassis: CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module1	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880407	Engine chassis: CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module2	A700.X2:		E	1
880408	Engine chassis: CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / ABS/ASR-Module2	A700.X2:		E	1
880409	Engine chassis: CAN-Data transfer Retarder (ID 772) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / retarder module	A700.X2:		E	1
880410	Engine chassis: CAN-Data transfer WSK (ID 776) erroneous/maximum cycle time exceeded last received value or replacement value Check cable / plug / converter module	A700.X2:		E	1
880411	Engine chassis: CAN-Data transfer Overrun of receiving buffer last received value or replacement value Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700.X2:		E	1
880500	Engine chassis: CAN-engine control unit Time exceeded request global process view Entry in error stack internal error, replace control unit	A700.X2:		E	1
880501	Engine chassis: CAN-engine control unit Time exceeded at receipt of complete output data last received value or replacement value Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700.X2:		E	1
880502	Engine chassis: CAN-engine control unit Data communication failed / interrupted (Sending timeout) last received value or replacement value Check cable / plug / CAN-participant	A700.X2:		E	1
880503	Engine chassis: CAN-engine control unit Data communication interrupted (Passive error) last received value or replacement value Check cable / plug / CAN-participant	A700.X2:		E	1
880504	Engine chassis: CAN-engine control unit Data communication interrupted (BusOff) last received value or replacement value Check cable / plug / CAN-participant	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880600	Engine chassis: CAN constr. machinery Time exceeded request global process view Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880601	Engine chassis: CAN constr. machinery Time exceeded at receipt of complete output data Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880602	Engine chassis: CAN constr. machinery Data communication failed / interrupted (Sending timeout) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880603	Engine chassis: CAN constr. machinery Data communication interrupted (Passive error) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880604	Engine chassis: CAN constr. machinery Data communication interrupted (BusOff) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880605	Engine chassis: CAN constr. machinery Data communication malfunctioning (warning) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880606	Engine chassis: CAN constr. machinery Data communication was malfunctioning (timeout) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880607	Engine chassis: CAN constr. machinery Open asynchronous communication not possible Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880608	Engine chassis: CAN constr. machinery Asynchronous communication not possible Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880609	Engine chassis: CAN constr. machinery Processing of asynchronous data not possible Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880610	Engine chassis: CAN constr. machinery Close asynchronous communication not possible Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880700	Engine chassis: CAN AMET Time exceeded request global process view Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880701	Engine chassis: CAN AMET Time exceeded at receipt of complete output data Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880702	Engine chassis: CAN AMET Data communication failed / interrupted (Sending timeout) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880703	Engine chassis: CAN AMET Data communication interrupted (Passive error) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880704	Engine chassis: CAN AMET Data communication interrupted (BusOff) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880705	Engine chassis: CAN AMET Data communication malfunctioning (warning) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880706	Engine chassis: CAN AMET Data communication was malfunctioning (timeout) Entry in error stack Check cable / plug / CAN-participant	A700.X2:		E	1
880800	Engine chassis: CAN-Data transfer Data communication Tachograph problem Change over to plausible speed source Check cable / plug / tachograph	A700.X2:		E	1
880801	Engine chassis: CAN-Data transfer Data communication TSC1 problem No Check cable / plug / CAN-participant	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880802	Engine chassis: CAN-Data transfer Data communication failed / interrupted (Sending timeout) Change over to plausible speed source Check cable / plug / CAN-participant	A700.X2:		E	1
880803	Engine chassis: CAN-Data transfer Data communication interrupted (Passive error) Change over to plausible speed source Check cable / plug / CAN-participant	A700.X2:		E	1
880804	Engine chassis: CAN-Data transfer Data communication interrupted (BusOff) Change over to plausible speed source Check cable / plug / CAN-participant	A700.X2:		E	1
880900	Engine chassis: CAN-communication status CAN A - Setting Transfer rate 125 KBaud possible No Report all error parameters to Service	A700.X2:		E	1
880901	Engine chassis: CAN-communication status CAN A - Setting Transfer rate 250 KBaud possible No Report all error parameters to Service	A700.X2:		E	1
880902	Engine chassis: CAN-communication status CAN A - Setting Transfer rate 500 KBaud possible No Report all error parameters to Service	A700.X2:		E	1
880903	Engine chassis: CAN-communication status CAN A - Setting Transfer rate 1 MBaud possible No Report all error parameters to Service	A700.X2:		E	1
880904	Engine chassis: CAN-communication status CAN B - Setting Transfer rate 125 KBaud possible No Report all error parameters to Service	A700.X2:		E	1
880905	Engine chassis: CAN-communication status CAN B - Setting Transfer rate 250 KBaud possible No Report all error parameters to Service	A700.X2:		E	1
880906	Engine chassis: CAN-communication status CAN B - Setting Transfer rate 500 KBaud possible No Report all error parameters to Service	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
880907	Engine chassis: CAN-communication status CAN B - Setting Transfer rate 1 MBaud possible No Report all error parameters to Service	A700.X2:		E	1
880908	Engine chassis: CAN-communication status CAN-connection after problem new synchronized No Report all error parameters to Service	A700.X2:		E	1
880909	Engine chassis: CAN-communication status Transfer error stored on CAN No Report all error parameters to Service	A700.X2:		E	1
880910	Engine chassis: CAN-communication status CAN-transfer rate not recognized / is detected No Report all error parameters to Service	A700.X2:		E	1
880911	Engine chassis: CAN-communication status CAN-transfer rate not recognized / is detected No Report all error parameters to Service	A700.X2:		E	1
880912	Engine chassis: CAN-communication status CAN-transfer rate not recognized / is detected Entry in error stack Report all error parameters to Service	A700.X2:		E	1
881000	Engine chassis: Internal error Stack-overflow Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881001	Engine chassis: Internal error Exception Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881002	Engine chassis: Internal error Program test Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881003	Engine chassis: Internal error RAM-Test Engine cannot be started or engine shut off Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
881004	Engine chassis: Internal error Overflow in error stack No Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	0
881005	Engine chassis: Internal error Comp. time error No Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	2
881006	Engine chassis: Internal error Error-Index too large The error cannot be shown Turn ignition of and on; if error not fixable, load new software in MSG or replace control unit	A700		E	0
881100	Engine chassis: Memory error EEPROM Error at EEPROM-access Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	2
881101	Engine chassis: Memory error EEPROM Check sum via parameter memory is erroneous Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	2
881102	Engine chassis: Memory error EEPROM Parameter memory in EEPROM is invalid Engine cannot be started or engine shut off Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	2
881103	Engine chassis: Memory error EEPROM Check sum via ECU-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881104	Engine chassis: Memory error EEPROM Check sum via NMI-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881105	Engine chassis: Memory error EEPROM Check sum via Work data-Page is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881106	Engine chassis: Memory error EEPROM Check sum via load collective is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
881107	Engine chassis: Memory error EEPROM Structure size of load collective has changed No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881108	Engine chassis: Memory error EEPROM EEPROM has insufficient memory for load collective free No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881109	Engine chassis: Memory error EEPROM Check sum via permanent data is erroneous No Turn ignition off and on, if error not fixable, replace engine control unites	A700		E	0
881200	Engine chassis: Power supply Supply voltage too low Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug)	A700.X2:		E	1
881201	Engine chassis: Power supply Supply voltage too high Engine cannot be started or engine shut off; only communication with diagnostics tool Check power supply (battery, alternator, wiring, plug)	A700.X2:		E	1
881202	Engine chassis: Power supply Digital output short circuit after supply voltage Engine shut off; only communication with diagnostics tool Check engine control unit and wiring; if necessary, replace engine control unit or wiring	A700.X2:		E	1
881203	Engine chassis: Power supply Error at release of power outputs Shut off of all digital outlets Wiring, check engine control unit; replace engine control unit if nec.	A700.X2:		E	1
881204	Engine chassis: Power supply Current supply PS1 erroneous/missing Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A700.X2:		E	1
881205	Engine chassis: Power supply Error on 12V-Reference: Voltage too low (<10V) Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A700.X2:		E	1
881206	Engine chassis: Power supply Error on 12V-Reference: Voltage too high (>14V) Engine cannot be started or engine shut off Check power supply (battery, alternator, wiring, plug) in rel. to PS1	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
881500	Engine chassis: Configuration error Fan control The fan control is deactivated. Resulting in maximum vent position New data set, or replace engine control unit	A700		E	1
881501	Engine chassis: Configuration error Full load curve (incorrect Offset) The matching of the performance curve is internally limited New data set, or replace engine control unit	A700		E	1
881502	Engine chassis: Configuration error Monitoring Travel pedal Pedal unit is not monitored New data set, or replace engine control unit	A700		E	1
881503	Engine chassis: Configuration error Incorrect pump code Injector class 3 is used as replacement value Check and change pump coding (via diagnostics or corresponding diagnostics tool)	A700		E	1
881504	Engine chassis: Configuration error Assignment error at high pressure sensors Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A700		E	1
881505	Engine chassis: Configuration error No high pressure pump active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A700		E	1
881506	Engine chassis: Configuration error Current output for high pressure pump 1 not active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A700		E	1
881507	Engine chassis: Configuration error Current output for high pressure pump 2 not active Emerg. op.: Shut off of CR-High pr. pump New data set, or replace engine control unit	A700		E	1
881800	Engine chassis: Active engine protection functions Excess temperature on exhaust turbine Power reduction 304700: WG/EGR-controller, check load pressure sensor	A700		E	1
881900	Engine chassis: Speed recording Maximum difference travel speed Tacho<->Gear exceeded The larger speed value is used Check wiring engine control unit to speed sensor or speed sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
882000	Engine chassis: Alternator Undervoltage at engine start No Check wiring engine control unit to alternator and alternator	A700.X2:		E	1
882001	Engine chassis: Alternator Undervoltage at engine on No Check wiring engine control unit to alternator and alternator	A700.X2:		E	1
882002	Engine chassis: Alternator Undervoltage at engine on No Check wiring engine control unit to alternator and alternator	A700.X2:		E	1
882003	Engine chassis: Alternator Overvoltage at engine on No Check wiring engine control unit to alternator and alternator	A700.X2:		E	1
882004	Engine chassis: Alternator Voltage deviation to supply voltage too low No Check wiring engine control unit to alternator and alternator	A700.X2:		E	1
882005	Engine chassis: Alternator Voltage deviation to supply voltage too high No Check wiring engine control unit to alternator and alternator	A700.X2:		E	1
882100	Engine chassis: Travel pedal No gas switch erroneous Use of low value Check wiring engine control unit to travel pedal. Check travel pedal / replace	A700		E	1
882101	Engine chassis: Travel pedal maximum signal difference channel 1 and 2 exceeded Use of low value Check wiring engine control unit to travel pedal. Check travel pedal / replace	A700		E	1
882700	Engine chassis: Turbocharger 2 Short circuit after ground or broken wire External AGR2 is not actuated Test wiring harness, plugs, solenoid valve Turbocharger, engine control unit	A700.X1:13/27		E	1
882701	Engine chassis: Turbocharger 2 short circuit to supply voltage External AGR2 is not actuated Test wiring harness, plugs, solenoid valve Turbocharger, engine control unit	A700.X1:13/27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
882702	Engine chassis: Turbocharger 2 Hardware error (Transistor defective) External AGR2 is not actuated Test wiring harness, plugs, solenoid valve Turbocharger, engine control unit	A700.X1:13/27		E	1
882703	Engine chassis: Turbocharger 2 Rule deviation negative External AGR2 is not actuated Test wiring harness, plugs, solenoid valve Turbocharger, engine control unit	A700.X1:13/27		E	1
882704	Engine chassis: Turbocharger 2 Rule deviation positive External AGR2 is not actuated Test wiring harness, plugs, solenoid valve Turbocharger, engine control unit	A700.X1:13/27		E	1
882705	Engine chassis: Turbocharger 2 Logic threshold breach in shut off condition External AGR2 is not actuated Test wiring harness, plugs, solenoid valve Turbocharger, engine control unit	A700.X1:13/27		E	1
882706	Engine chassis: Turbocharger 2 Logic threshold breach (Current less than perm. minimum value) External AGR2 is not actuated Test wiring harness, plugs, solenoid valve Turbocharger, engine control unit	A700.X1:13/27		E	1
882707	Engine chassis: Turbocharger 2 Logic threshold breach (Current more than perm. maximum value) External AGR2 is not actuated Test wiring harness, plugs, solenoid valve Turbocharger, engine control unit	A700.X1:13/27		E	1
882800	Engine chassis: Exhaust return (AGR2) Short circuit after ground or broken wire External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882801	Engine chassis: Exhaust return (AGR2) short circuit to supply voltage External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882802	Engine chassis: Exhaust return (AGR2) Hardware error (Transistor defective) External AGR2 is not actuated Check engine control unit	A700.X1:		E	1
882803	Engine chassis: Exhaust return (AGR2) Rule deviation negative External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
882804	Engine chassis: Exhaust return (AGR2) Rule deviation positive External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882805	Engine chassis: Exhaust return (AGR2) Logic threshold breach in shut off condition External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882806	Engine chassis: Exhaust return (AGR2) Logic threshold breach (Current less than perm. minimum value) External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882807	Engine chassis: Exhaust return (AGR2) Logic threshold breach (Current more than perm. maximum value) External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882811	Engine chassis: Exhaust return (AGR2) open without actuation External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882812	Engine chassis: Exhaust return (AGR2) closed despite actuation External AGR2 is not actuated Check wiring harness / plug / AGR2 valve / engine control unit	A700.X1:		E	1
882900	Engine chassis: Air flap Short circuit after ground or broken wire Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882901	Engine chassis: Air flap short circuit to supply voltage Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882902	Engine chassis: Air flap Hardware error (Transistor defective) Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882903	Engine chassis: Air flap Rule deviation negative Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
882904	Engine chassis: Air flap Rule deviation positive Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882905	Engine chassis: Air flap Logic threshold breach in shut off condition Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882906	Engine chassis: Air flap Logic threshold breach (Current less than perm. minimum value) Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882907	Engine chassis: Air flap Logic threshold breach (Current more than perm. maximum value) Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882908	Engine chassis: Air flap Over current LowSide Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882909	Engine chassis: Air flap Over current HighSide Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
882910	Engine chassis: Air flap PWM on maximum Air vent is not actuated Check cable harness / plug / air vent / engine control unit	A700.X2:12/13		E	1
883003	Engine chassis: High pressure pump 1 Rule deviation negative Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883004	Engine chassis: High pressure pump 1 Rule deviation positive Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883005	Engine chassis: High pressure pump 1 Current to high in shut off condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883006	Engine chassis: High pressure pump 1 Current to low in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883007	Engine chassis: High pressure pump 1 Current to high in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883008	Engine chassis: High pressure pump 1 UeberCurrent LowSide (ground switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883009	Engine chassis: High pressure pump 1 UeberCurrent HighSide (Plus-switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883010	Engine chassis: High pressure pump 1 PWM on maximum Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883103	Engine chassis: High pressure pump 2 Rule deviation negative Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883104	Engine chassis: High pressure pump 2 Rule deviation positive Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883105	Engine chassis: High pressure pump 2 Current to high in shut off condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883106	Engine chassis: High pressure pump 2 Current to low in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883107	Engine chassis: High pressure pump 2 Current to high in actuated condition Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883108	Engine chassis: High pressure pump 2 UeberCurrent LowSide (ground switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883109	Engine chassis: High pressure pump 2 UeberCurrent HighSide (Plus-switch) Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883110	Engine chassis: High pressure pump 2 PWM on maximum Emerg. op.: Shut off of CR-High pr. pump Check cable harness / plug / CR-High pr. pump / engine control unit	A700.X1:		E	1
883200	Engine chassis: Starter short circuit to ground Engine start not possible Check cable harness / plug / Starter / engine control unit	A700.X1:29		E	1
883201	Engine chassis: Starter short circuit to supply voltage Engine start not possible Check cable harness / plug / Starter / engine control unit	A700.X1:29		E	1
883300	Engine chassis: Fan control Short circuit after ground or broken wire The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883301	Engine chassis: Fan control short circuit to supply voltage The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883302	Engine chassis: Fan control Hardware error (Transistor defective) The fan control is deactivated. Resulting in maximum vent position Check engine control unit	A700.X2:26/27		E	1
883303	Engine chassis: Fan control Rule deviation negative The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883304	Engine chassis: Fan control Rule deviation positive The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883305	Engine chassis: Fan control Logic threshold breach in shut off condition The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883306	Engine chassis: Fan control Logic threshold breach (Current less than perm. minimum value) The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883307	Engine chassis: Fan control Logic threshold breach (Current more than perm. maximum value) The fan control is deactivated. Resulting in maximum vent position Check wiring harness / plug / fan proportional valve / engine control unit	A700.X2:26/27		E	1
883400	Engine chassis: Engine brake Short circuit after ground or broken wire Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883401	Engine chassis: Engine brake short circuit to supply voltage Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883402	Engine chassis: Engine brake Hardware error (Transistor defective) Engine brake flap is not actuated Check engine control unit	A700.X2:11		E	1
883403	Engine chassis: Engine brake Rule deviation negative Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883404	Engine chassis: Engine brake Rule deviation positive Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883405	Engine chassis: Engine brake Logic threshold breach in shut off condition Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883406	Engine chassis: Engine brake Logic threshold breach (Current less than perm. minimum value) Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883407	Engine chassis: Engine brake Logic threshold breach (Current more than perm. maximum value) Engine brake flap is not actuated Check cable harness / plug / engine brake flap / engine control unit	A700.X2:11		E	1
883500	Engine chassis: Heater flange unit 1 Short circuit after ground or broken wire Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883501	Engine chassis: Heater flange unit 1 short circuit to supply voltage Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883502	Engine chassis: Heater flange unit 1 Hardware error (Transistor defective) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883503	Engine chassis: Heater flange unit 1 Rule deviation negative Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883504	Engine chassis: Heater flange unit 1 Rule deviation positive Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883505	Engine chassis: Heater flange unit 1 Logic threshold breach in shut off condition Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883506	Engine chassis: Heater flange unit 1 Logic threshold breach (Current less than perm. minimum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883507	Engine chassis: Heater flange unit 1 Logic threshold breach (Current more than perm. maximum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883511	Engine chassis: Heater flange unit 1 No voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883512	Engine chassis: Heater flange unit 1 Voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:39/64		E	1
883600	Engine chassis: Heater flange unit 2 Short circuit after ground or broken wire Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883601	Engine chassis: Heater flange unit 2 short circuit to supply voltage Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883602	Engine chassis: Heater flange unit 2 Hardware error (Transistor defective) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883603	Engine chassis: Heater flange unit 2 Rule deviation negative Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883604	Engine chassis: Heater flange unit 2 Rule deviation positive Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883605	Engine chassis: Heater flange unit 2 Logic threshold breach in shut off condition Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883606	Engine chassis: Heater flange unit 2 Logic threshold breach (Current less than perm. minimum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883607	Engine chassis: Heater flange unit 2 Logic threshold breach (Current more than perm. maximum value) Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883611	Engine chassis: Heater flange unit 2 No voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883612	Engine chassis: Heater flange unit 2 Voltage on heater element Failure of pre- and afterheat phase Check wiring harness / plug / heater flange or glow plug unit/ ext. relay / engine control unit	A700.X2:25/65		E	1
883700	Engine chassis: Solenoid valves Short circuit after ground or broken wire Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883701	Engine chassis: Solenoid valves short circuit to supply voltage Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883702	Engine chassis: Solenoid valves Hardware error (Transistor defective) Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883703	Engine chassis: Solenoid valves Rule deviation negative Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883704	Engine chassis: Solenoid valves Rule deviation positive Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883705	Engine chassis: Solenoid valves Logic threshold breach in shut off condition Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883706	Engine chassis: Solenoid valves Logic threshold breach (Current less than perm. minimum value) Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883707	Engine chassis: Solenoid valves Logic threshold breach (Current more than perm. maximum value) Failure of after heat phase Check cable harness / plug / solenoid valve flame start system/ engine control unit	A700.X2:25/65		E	1
883800	Engine chassis: Turbo charger Short circuit after ground or broken wire Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883801	Engine chassis: Turbo charger short circuit to supply voltage Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883802	Engine chassis: Turbo charger Hardware error (Transistor defective) Turbocharger is not actuated Check engine control unit	A700		E	1
883803	Engine chassis: Turbo charger Rule deviation negative Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883804	Engine chassis: Turbo charger Rule deviation positive Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883805	Engine chassis: Turbo charger Logic threshold breach in shut off condition Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883806	Engine chassis: Turbo charger Logic threshold breach (Current less than perm. minimum value) Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883807	Engine chassis: Turbo charger Logic threshold breach (Current more than perm. maximum value) Turbocharger is not actuated Check cable harness / plug / solenoid valve Turbo charger / engine control unit	A700		E	1
883900	Engine chassis: Exhaust return (AGR) Short circuit after ground or broken wire External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883901	Engine chassis: Exhaust return (AGR) short circuit to supply voltage External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883902	Engine chassis: Exhaust return (AGR) Hardware error (Transistor defective) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
883903	Engine chassis: Exhaust return (AGR) Rule deviation negative External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883904	Engine chassis: Exhaust return (AGR) Rule deviation positive External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883905	Engine chassis: Exhaust return (AGR) Logic threshold breach (Current higher than perm. min. value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883906	Engine chassis: Exhaust return (AGR) Logic threshold breach (Current less than perm. minimum value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883907	Engine chassis: Exhaust return (AGR) Logic threshold breach (Current more than perm. maximum value) External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883911	Engine chassis: Exhaust return (AGR) open without actuation External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
883912	Engine chassis: Exhaust return (AGR) closed despite actuation External AGR is not actuated Check cable harness / plug / AGR-valve / engine control unit	A700.X1:		E	1
884000	Engine chassis: Emerg. Op. indicator Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A700.X2:42		E	1
884001	Engine chassis: Emerg. Op. indicator short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A700.X2:42		E	1
884002	Engine chassis: Emerg. Op. indicator Hardware error (Transistor defective) None Check engine control unit	A700.X2:42		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
884100	Engine chassis: Indicator light preglow / start readiness Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A700.X2:28		E	1
884101	Engine chassis: Indicator light preglow / start readiness short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A700.X2:28		E	1
884102	Engine chassis: Indicator light preglow / start readiness Hardware error (Transistor defective) None Check engine control unit	A700.X2:28		E	1
884200	Engine chassis: Charge indicator Alternator Short circuit after ground or broken wire None Check cable harness / plug / warn. light / engine control unit	A700.X2:14		E	1
884201	Engine chassis: Charge indicator Alternator short circuit to supply voltage None Check cable harness / plug / warn. light / engine control unit	A700.X2:14		E	1
884202	Engine chassis: Charge indicator Alternator Hardware error (Transistor defective) None Check engine control unit	A700.X2:14		E	1
884300	Engine chassis: fan control 1 (reversible) Short circuit after ground or broken wire Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884301	Engine chassis: fan control 1 (reversible) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884302	Engine chassis: fan control 1 (reversible) Hardware error (Transistor defective) Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884303	Engine chassis: fan control 1 (reversible) Rule deviation negative Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
884304	Engine chassis: fan control 1 (reversible) Rule deviation positive Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884305	Engine chassis: fan control 1 (reversible) Logic threshold breach in shut off condition Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884306	Engine chassis: fan control 1 (reversible) Logic threshold breach (Current less than perm. minimum value) Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884307	Engine chassis: fan control 1 (reversible) Logic threshold breach (Current more than perm. maximum value) Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884400	Engine chassis: fan control 2 (reversible) Short circuit after ground or broken wire Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884401	Engine chassis: fan control 2 (reversible) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884402	Engine chassis: fan control 2 (reversible) Hardware error (Transistor defective) Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884403	Engine chassis: fan control 2 (reversible) Rule deviation negative Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884404	Engine chassis: fan control 2 (reversible) Rule deviation positive Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884405	Engine chassis: fan control 2 (reversible) Logic threshold breach in shut off condition Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
884406	Engine chassis: fan control 2 (reversible) Logic threshold breach (Current less than perm. minimum value) Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884407	Engine chassis: fan control 2 (reversible) Logic threshold breach (Current more than perm. maximum value) Entry in error stack Report all error parameters to Service	A700.X2:26/27		E	1
884500	Engine chassis: Rail pressure system Pressure relief valve 1 open High pressure regulation emergency operation activated Test Rail circuit 1	A700		E	1
884501	Engine chassis: Rail pressure system Pressure relief valve 2 open High pressure regulation emergency operation activated Test Rail circuit 2	A700		E	1
884502	Engine chassis: Rail pressure system Emergency operation high pressure regulation active Power reduction, high pressure pump control turned off Test Rail circuit 1/2 / wiring harness / plug	A700		E	1
884503	Engine chassis: Rail pressure system Pressure difference between high pressure sensor 1 and 2 No reaction on engine, the higher sensor value is used Test wiring harness/ plug / rail pressure sensors / rail circuit 1/2	A700		E	1
884504	Engine chassis: Rail pressure system Regulation deviation in CR-regulating circuit 1 No Test Rail circuit 1	A700		E	1
884505	Engine chassis: Rail pressure system Regulation deviation in CR-regulating circuit 2 No Test Rail circuit 2	A700		E	1
884700	Engine chassis: Error on air path components Maximum charge pressure exceeded (P3-protection) Power reduction 301800:Check exhaust system for leaks	A700		E	1
884900	Engine chassis: RPM signal output Short circuit after ground or broken wire No Check wiring harness / plug / connected modules	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
884901	Engine chassis: RPM signal output short circuit to supply voltage No Check wiring harness / plug / connected modules	A700		E	1
885000	Engine chassis: Cylinder A1 Current back test erroneous or broken wire No Check wiring harness / plug / connected modules	A700.X1:22/8		E	2
885001	Engine chassis: Cylinder A1 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	2
885002	Engine chassis: Cylinder A1 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	2
885003	Engine chassis: Cylinder A1 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	2
885004	Engine chassis: Cylinder A1 No fly time measured No Replace engine control unit	A700.X1:22/8		E	2
885005	Engine chassis: Cylinder A1 Fly time too small No Replace engine control unit	A700.X1:22/8		E	2
885006	Engine chassis: Cylinder A1 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	1
885007	Engine chassis: Cylinder A1 No increase time measured No Replace engine control unit	A700.X1:22/8		E	2
885008	Engine chassis: Cylinder A1 Increase time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:22/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885100	Engine chassis: Cylinder A2 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	2
885101	Engine chassis: Cylinder A2 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	2
885102	Engine chassis: Cylinder A2 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	2
885103	Engine chassis: Cylinder A2 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	2
885104	Engine chassis: Cylinder A2 No fly time measured No Replace engine control unit	A700.X1:21/7		E	2
885105	Engine chassis: Cylinder A2 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	1
885106	Engine chassis: Cylinder A2 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:21/7		E	1
885107	Engine chassis: Cylinder A2 No increase time measured No Replace engine control unit	A700.X1:21/7		E	2
885108	Engine chassis: Cylinder A2 Increase time too large No New data set, or replace engine control unit	A700.X1:21/7		E	1
885200	Engine chassis: Cylinder A3 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885201	Engine chassis: Cylinder A3 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2
885202	Engine chassis: Cylinder A3 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2
885203	Engine chassis: Cylinder A3 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2
885204	Engine chassis: Cylinder A3 No fly time measured No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	2
885205	Engine chassis: Cylinder A3 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	1
885206	Engine chassis: Cylinder A3 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:20/6		E	1
885207	Engine chassis: Cylinder A3 No increase time measured No Replace engine control unit	A700.X1:20/6		E	2
885208	Engine chassis: Cylinder A3 Increase time too large No New data set, or replace engine control unit	A700.X1:20/6		E	1
885300	Engine chassis: Cylinder A4 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	2
885301	Engine chassis: Cylinder A4 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885302	Engine chassis: Cylinder A4 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	2
885303	Engine chassis: Cylinder A4 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	2
885304	Engine chassis: Cylinder A4 No fly time measured No Replace engine control unit	A700.X1:19/5		E	2
885305	Engine chassis: Cylinder A4 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	1
885306	Engine chassis: Cylinder A4 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:19/5		E	1
885307	Engine chassis: Cylinder A4 No increase time measured No Replace engine control unit	A700.X1:19/5		E	2
885308	Engine chassis: Cylinder A4 Increase time too large No New data set, or replace engine control unit	A700.X1:19/5		E	1
885800	Engine chassis: Cylinder B1 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	2
885801	Engine chassis: Cylinder B1 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	2
885802	Engine chassis: Cylinder B1 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885803	Engine chassis: Cylinder B1 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	2
885804	Engine chassis: Cylinder B1 No fly time measured No Replace engine control unit	A700.X1:18/4		E	2
885805	Engine chassis: Cylinder B1 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	1
885806	Engine chassis: Cylinder B1 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:18/4		E	1
885807	Engine chassis: Cylinder B1 No increase time measured No Replace engine control unit	A700.X1:18/4		E	2
885808	Engine chassis: Cylinder B1 Increase time too large No New data set, or replace engine control unit	A700.X1:18/4		E	1
885900	Engine chassis: Cylinder B2 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	2
885901	Engine chassis: Cylinder B2 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	2
885902	Engine chassis: Cylinder B2 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	2
885903	Engine chassis: Cylinder B2 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
885904	Engine chassis: Cylinder B2 No fly time measured No Replace engine control unit	A700.X1:17/3		E	2
885905	Engine chassis: Cylinder B2 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	1
885906	Engine chassis: Cylinder B2 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:17/3		E	1
885907	Engine chassis: Cylinder B2 No increase time measured No Replace engine control unit	A700.X1:17/3		E	2
885908	Engine chassis: Cylinder B2 Increase time too large No New data set, or replace engine control unit	A700.X1:17/3		E	1
886000	Engine chassis: Cylinder B3 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	2
886001	Engine chassis: Cylinder B3 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	2
886002	Engine chassis: Cylinder B3 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	2
886003	Engine chassis: Cylinder B3 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	2
886004	Engine chassis: Cylinder B3 No fly time measured No Replace engine control unit	A700.X1:16/2		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
886005	Engine chassis: Cylinder B3 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	1
886006	Engine chassis: Cylinder B3 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:16/2		E	1
886007	Engine chassis: Cylinder B3 No increase time measured No Replace engine control unit	A700.X1:16/2		E	2
886008	Engine chassis: Cylinder B3 Increase time too large No New data set, or replace engine control unit	A700.X1:16/2		E	1
886100	Engine chassis: Cylinder B4 Current back test erroneous or broken wire No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	2
886101	Engine chassis: Cylinder B4 UeberCurrent LowSide (ground switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	2
886102	Engine chassis: Cylinder B4 UeberCurrent HighSide (Plus switch) No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	2
886103	Engine chassis: Cylinder B4 Overcurent HighSide (free wheel) No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	2
886104	Engine chassis: Cylinder B4 No fly time measured No Replace engine control unit	A700.X1:15/1		E	2
886105	Engine chassis: Cylinder B4 Fly time too small No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
886106	Engine chassis: Cylinder B4 Fly time too large No Check cable / plug / solenoid valve / engine control unit	A700.X1:15/1		E	1
886107	Engine chassis: Cylinder B4 No increase time measured No Replace engine control unit	A700.X1:15/1		E	2
886108	Engine chassis: Cylinder B4 Increase time too large No New data set, or replace engine control unit	A700.X1:15/1		E	1
886900	Engine chassis: Injection system Cylinder error Engine shut off Check cable / plug / solenoid valve / engine control unit	A700		E	2
886901	Engine chassis: Injection system Overlap of injection on bank A Engine shut off New data set, or replace engine control unit	A700		E	2
886902	Engine chassis: Injection system Overlap of injection on bank B Engine shut off New data set, or replace engine control unit	A700		E	2
886903	Engine chassis: Injection system Short circuit Plus switch after ground on bank A No New data set, or replace engine control unit	A700		E	2
886904	Engine chassis: Injection system Short circuit Plus switch after ground on bank B No Check cable / plug / solenoid valve / engine control unit	A700		E	2
886905	Engine chassis: Injection system Short circuit Plus switch after supply voltage on bank A No Check cable / plug / solenoid valve / engine control unit	A700		E	2
886906	Engine chassis: Injection system Short circuit Plus switch after supply voltage on bank B No Check cable / plug / solenoid valve / engine control unit	A700		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
886907	Engine chassis: Injection system Short circuit Ground switch after ground on bank A at CR-Motor occurs shut off of bank A Check cable / plug / solenoid valve / engine control unit	A700		E	2
886908	Engine chassis: Injection system Short circuit Ground switch after ground on bank B at CR-Motor occurs shut off of bank B Check cable / plug / solenoid valve / engine control unit	A700		E	2
886909	Engine chassis: Injection system Short circuit Ground switch after supply voltage on bank A No Check cable / plug / solenoid valve / engine control unit	A700		E	2
886910	Engine chassis: Injection system Short circuit Ground switch after supply voltage on bank B No Check cable / plug / solenoid valve / engine control unit	A700		E	2
887000	Engine chassis: Overspeed RPM sensor 1 Warning threshold exceeded No Check engine op. (excess. speed due to push op.); engine control unit	A700		E	1
887001	Engine chassis: Overspeed RPM sensor 2 Warning threshold exceeded No Check engine op. (excess. speed due to push op.); engine control unit	A700		E	1
887002	Engine chassis: Overspeed RPM sensor 1 Safety threshold exceeded Engine shut off Check engine op. (excess. speed due to push op.); engine control unit	A700		E	1
887003	Engine chassis: Overspeed RPM sensor 2 Safety threshold exceeded Engine shut off Check engine op. (excess. speed due to push op.); engine control unit	A700		E	1
887100	Engine chassis: Synchronization defective Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1
887101	Engine chassis: Synchronization incorrect distance gap<->Phase sensor Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887102	Engine chassis: Synchronization Tooth number not correct Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1
887103	Engine chassis: Synchronization not possible, RPM is too low Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1
887104	Engine chassis: Synchronization Index counter camshaft gear erroneous Engine start not possible Turn ign. on / off; check RPM and phase sensor	A700		E	1
887200	Engine chassis: RPM sensor 1 failed Emergency shut-off with simultaneous failure of redundant sensor 2. Otherwise rpm recording via redundant sensor Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A700.X1:69/55/4 1		E	1
887201	Engine chassis: RPM sensor 1 does not start Emergency shut-off with simultaneous failure of redundant sensor 2. Otherwise rpm recording via redundant sensor Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A700.X1:69/55/4 1		E	1
887202	Engine chassis: RPM sensor 1 impermissible signal difference (Gradient breach) Emergency shut-off with simultaneous failure of redundant sensor 2. Otherwise rpm recording via redundant sensor Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A700.X1:69/55/4 1		E	1
887203	Engine chassis: RPM sensor 1 Frequency too high Emergency shut-off with simultaneous failure of redundant sensor 2. Otherwise rpm recording via redundant sensor Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A700.X1:69/55/4 1		E	1
887204	Engine chassis: RPM sensor 1 poled Emergency shut-off with simultaneous failure of redundant sensor 2. Otherwise rpm recording via redundant sensor Rpm sensor installation, check engine control unit	A700.X1:69/55/4 1		E	1
887205	Engine chassis: RPM sensor 1 Value implausible/erroneous Emergency shut-off with simultaneous failure of redundant sensor 2. Otherwise rpm recording via redundant sensor Rpm sensor installation, check engine control unit	A700.X1:69/55/4 1		E	1
887300	Engine chassis: RPM sensor 2 failed Emergency shut-off with simultaneous failure of redundant sensor 1. Otherwise rpm recording via redundant sensor Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A700.X1:68/54/4 0		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887301	Engine chassis: RPM sensor 2 does not start Emergency shut-off with simultaneous failure of redundant sensor 1. Otherwise rpm recording via redundant sensor Check: distance of RPM sensor to flywheel (0.5-2.0 mm); Wiring to RPM sensor; RPM sensor	A700.X1:68/54/4 0		E	1
887302	Engine chassis: RPM sensor 2 impermissible signal difference (Gradient breach) Emergency shut-off with simultaneous failure of redundant sensor 1. Otherwise rpm recording via redundant sensor Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A700.X1:68/54/4 0		E	1
887303	Engine chassis: RPM sensor 2 Frequency too high Emergency shut-off with simultaneous failure of redundant sensor 1. Otherwise rpm recording via redundant sensor Test from: distance of RPM sensor to flywheel; flywheel, wiring to RPM sensor; RPM sensor	A700.X1:68/54/4 0		E	1
887304	Engine chassis: RPM sensor 2 poled Emergency shut-off with simultaneous failure of redundant sensor 1. Otherwise rpm recording via redundant sensor Rpm sensor installation, check engine control unit	A700.X1:68/54/4 0		E	1
887305	Engine chassis: RPM sensor 2 Value implausible/erroneous Emergency shut-off with simultaneous failure of redundant sensor 1. Otherwise rpm recording via redundant sensor Rpm sensor installation, check engine control unit	A700.X1:68/54/4 0		E	1
887400	Engine chassis: Sensor Position camshaft failed Engine start, depending on configuration, not possible. No effect when the engine is running Check distance of phase sensor to camshaft gear (0.5-2.0 mm); wiring to phase sensor, phase sensor	A700.X1:70/56/4 2		E	1
887404	Engine chassis: Sensor Position camshaft poled Engine start, depending on configuration, not possible. No effect when the engine is running Check: Phase sensor installation, engine control unit	A700.X1:70/56/4 2		E	1
887405	Engine chassis: Sensor Position camshaft Value implausible/erroneous Em. shut off at simult. failure of redundant sensor (1 or 2). Otherwise RPM deter. via red. sensor Check: Phase sensor installation, engine control unit	A700.X1:70/56/4 2		E	1
887500	Engine chassis: Travel pedal channel 1 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X2:33/34/3 5		E	1
887501	Engine chassis: Travel pedal channel 1 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X2:33/34/3 5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887502	Engine chassis: Travel pedal channel 1 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X2:33/34/3 5		E	1
887503	Engine chassis: Travel pedal channel 1 Supply voltage Short circuit after supply voltage Motor chassis: travel pedal channel 1 Supply voltage short circuit after supply voltage Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:33/34/3 5		E	1
887504	Engine chassis: Travel pedal channel 1 Signal outside permissible range (Limit 1) remains in low idle when both travel pedal sensors have failed Check gas pedal sensor 1 for operating range violation. Remedy possible mechanical problem	A700.X2:33/34/3 5		E	1
887505	Engine chassis: Travel pedal channel 1 Signal outside permissible range (Limit 2) remains in low idle when both travel pedal sensors have failed Check gas pedal sensor 1 for operating range violation. Remedy possible mechanical problem	A700.X2:33/34/3 5		E	1
887506	Engine chassis: Travel pedal channel 1 signal implausible Entry in error stack Check gas pedal sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X2:33/34/3 5		E	1
887600	Engine chassis: Travel pedal channel 2 Short circuit after ground or line interruption Entry in error stack Check gas pedal sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X2:47/48/4 9		E	1
887602	Engine chassis: Travel pedal channel 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:47/48/4 9		E	1
887603	Engine chassis: Travel pedal channel 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:47/48/4 9		E	1
887604	Engine chassis: Travel pedal channel 2 Signal outside permissible range (Limit 1) remains in low idle when both travel pedal sensors have failed Check gas pedal sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X2:47/48/4 9		E	1
887605	Engine chassis: Travel pedal channel 2 Signal outside permissible range (Limit 2) remains in low idle when both travel pedal sensors have failed Check gas pedal sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X2:47/48/4 9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887606	Engine chassis: Travel pedal channel 2 signal implausible Entry in error stack Check gas pedal sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X2:47/48/49		E	1
887700	Engine chassis: Sensor coolant level Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X2:19/20/21		E	2
887701	Engine chassis: Sensor coolant level short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:19/20/21		E	2
887702	Engine chassis: Sensor coolant level Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:19/20/21		E	2
887703	Engine chassis: Sensor coolant level Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:19/20/21		E	2
887704	Engine chassis: Sensor coolant level Signal outside permissible range (Limit 1) no reaction Check coolant level for operating range violation. Remedy possible mechanical problem	A700.X2:19/20/21		E	1
887705	Engine chassis: Sensor coolant level Signal outside permissible range (Limit 2) no reaction Check coolant level for operating range violation. Remedy possible mechanical problem	A700.X2:19/20/21		E	1
887706	Engine chassis: Sensor coolant level signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700.X2:19/20/21		E	2
887800	Engine chassis: Sensor oil level Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700		E	1
887801	Engine chassis: Sensor oil level short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
887802	Engine chassis: Sensor oil level Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
887803	Engine chassis: Sensor oil level Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
887804	Engine chassis: Sensor oil level Signal outside permissible range (Limit 1) no reaction Check oil level for operating range violation. Remedy possible mechanical problem	A700		E	1
887805	Engine chassis: Sensor oil level Signal outside permissible range (Limit 2) no reaction Check oil level for operating range violation. Remedy possible mechanical problem	A700		E	1
887806	Engine chassis: Sensor oil level signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700		E	1
888100	Engine chassis: AGR 1 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700.X1:31/45/5 9		E	1
888101	Engine chassis: AGR 1 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700.X1:31/45/5 9		E	1
888102	Engine chassis: AGR 1 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700.X1:31/45/5 9		E	1
888103	Engine chassis: AGR 1 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700.X1:31/45/5 9		E	1
888104	Engine chassis: AGR 1 Signal outside permissible range (Limit 1) Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700.X1:31/45/5 9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888105	Engine chassis: AGR 1 Signal outside permissible range (Limit 2) Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700.X1:31/45/5 9		E	1
888106	Engine chassis: AGR 1 signal implausible Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700.X1:31/45/5 9		E	1
888200	Engine chassis: AGR 2 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700		E	1
888201	Engine chassis: AGR 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700		E	1
888202	Engine chassis: AGR 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700		E	1
888203	Engine chassis: AGR 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700		E	1
888204	Engine chassis: AGR 2 Signal outside permissible range (Limit 1) Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700		E	1
888205	Engine chassis: AGR 2 Signal outside permissible range (Limit 2) Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700		E	1
888206	Engine chassis: AGR 2 signal implausible Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit/Sensor (broken wire or short circuit after ground)	A700		E	1
888300	Engine chassis: Sensor air filter contamination 2 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:30/44/5 8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888301	Engine chassis: Sensor air filter contamination 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:30/44/5 8		E	1
888302	Engine chassis: Sensor air filter contamination 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:30/44/5 8		E	1
888303	Engine chassis: Sensor air filter contamination 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:30/44/5 8		E	1
888304	Engine chassis: Sensor air filter contamination 2 Signal outside permissible range (Limit 1) no reaction Check air filter pressure sensor 1 for operating range violation. Remedy possible mechanical problem	A700.X1:30/44/5 8		E	1
888305	Engine chassis: Sensor air filter contamination 2 Signal outside permissible range (Limit 2) no reaction Check air filter pressure sensor 1 for operating range violation. Remedy possible mechanical problem	A700.X1:30/44/5 8		E	1
888306	Engine chassis: Sensor air filter contamination 2 signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700.X1:30/44/5 8		E	1
888400	Engine chassis: Sensor charge air pr, Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:61/47/3 3		E	1
888401	Engine chassis: Sensor charge air pr, short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:61/47/3 3		E	1
888402	Engine chassis: Sensor charge air pr, Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:61/47/3 3		E	1
888403	Engine chassis: Sensor charge air pr, Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:61/47/3 3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888404	Engine chassis: Sensor charge air pr, Signal outside permissible range (Limit 1) no reaction Check charge air pressure sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X1:61/47/3 3		E	1
888405	Engine chassis: Sensor charge air pr, Signal outside permissible range (Limit 2) no reaction Check charge air pressure sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X1:61/47/3 3		E	1
888406	Engine chassis: Sensor charge air pr, signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700.X1:61/47/3 3		E	1
888500	Engine chassis: Sensor oil pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:63/49/3 5		E	2
888501	Engine chassis: Sensor oil pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:63/49/3 5		E	2
888502	Engine chassis: Sensor oil pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:63/49/3 5		E	2
888503	Engine chassis: Sensor oil pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:63/49/3 5		E	2
888504	Engine chassis: Sensor oil pr. Signal outside permissible range (Limit 1) no reaction Check oil pressure for operating range violation. Remedy possible mechanical problem	A700.X1:63/49/3 5		E	1
888505	Engine chassis: Sensor oil pr. Signal outside permissible range (Limit 2) no reaction Check oil pressure for operating range violation. Remedy possible mechanical problem	A700.X1:63/49/3 5		E	1
888506	Engine chassis: Sensor oil pr. signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700.X1:63/49/3 5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888600	Engine chassis: Sensor fuel pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:62/48/3 4		E	1
888601	Engine chassis: Sensor fuel pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:62/48/3 4		E	1
888602	Engine chassis: Sensor fuel pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:62/48/3 4		E	1
888603	Engine chassis: Sensor fuel pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:62/48/3 4		E	1
888604	Engine chassis: Sensor fuel pr. Signal outside permissible range (Limit 1) no reaction Check the medium for fuel pressure violation. Remedy possible mechanical problem	A700.X1:62/48/3 4		E	1
888605	Engine chassis: Sensor fuel pr. Signal outside permissible range (Limit 2) no reaction Check the medium for fuel pressure violation. Remedy possible mechanical problem	A700.X1:62/48/3 4		E	1
888606	Engine chassis: Sensor fuel pr. signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700.X1:62/48/3 4		E	1
888700	Engine chassis: Sensor Air filter contamination Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X2:5/6/7		E	1
888701	Engine chassis: Sensor Air filter contamination short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:5/6/7		E	1
888702	Engine chassis: Sensor Air filter contamination Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:5/6/7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888703	Engine chassis: Sensor Air filter contamination Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:5/6/7		E	1
888704	Engine chassis: Sensor Air filter contamination Signal outside permissible range (Limit 1) no reaction Check air filter pressure sensor 1 for operating range violation. Remedy possible mechanical problem	A700.X2:5/6/7		E	1
888705	Engine chassis: Sensor Air filter contamination Signal outside permissible range (Limit 2) no reaction Check air filter pressure sensor 1 for operating range violation. Remedy possible mechanical problem	A700.X2:5/6/7		E	1
888706	Engine chassis: Sensor Air filter contamination signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700.X2:5/6/7		E	1
888800	Engine chassis: Common Rail Pr. sensor 1 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:60/46/3 2		E	1
888801	Engine chassis: Common Rail Pr. sensor 1 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:60/46/3 2		E	1
888802	Engine chassis: Common Rail Pr. sensor 1 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:60/46/3 2		E	1
888803	Engine chassis: Common Rail Pr. sensor 1 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:60/46/3 2		E	1
888804	Engine chassis: Common Rail Pr. sensor 1 Signal outside permissible range (Limit 1) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check common rail pressure sensor 1 for operating range violation. Remedy possible mechanical problem	A700.X1:60/46/3 2		E	1
888805	Engine chassis: Common Rail Pr. sensor 1 Signal outside permissible range (Limit 2) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check common rail pressure sensor 1 for operating range violation. Remedy possible mechanical problem	A700.X1:60/46/3 2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
888806	Engine chassis: Common Rail Pr. sensor 1 signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700.X1:60/46/3 2		E	1
888900	Engine chassis: Common Rail Pr. sensor 2 Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700.X1:59/45/3 1		E	1
888901	Engine chassis: Common Rail Pr. sensor 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:59/45/3 1		E	1
888902	Engine chassis: Common Rail Pr. sensor 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:59/45/3 1		E	1
888903	Engine chassis: Common Rail Pr. sensor 2 Supply voltage Short circuit after supply voltage Error disappears when test values are in defined range again Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:59/45/3 1		E	1
888904	Engine chassis: Common Rail Pr. sensor 2 Signal outside permissible range (Limit 1) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check common rail pressure sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X1:59/45/3 1		E	1
888905	Engine chassis: Common Rail Pr. sensor 2 Signal outside permissible range (Limit 2) Performance reduction at failure of both common rail pressure sensors, otherwise no reaction Check common rail pressure sensor 2 for operating range violation. Remedy possible mechanical problem	A700.X1:59/45/3 1		E	1
888906	Engine chassis: Common Rail Pr. sensor 2 signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700.X1:59/45/3 1		E	1
889000	Engine chassis: Sensor ambient pr. Short circuit after ground or line interruption Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground or broken cable)	A700		E	1
889001	Engine chassis: Sensor ambient pr. short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889002	Engine chassis: Sensor ambient pr. Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889003	Engine chassis: Sensor ambient pr. Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
889004	Engine chassis: Sensor ambient pr. Signal outside permissible range (Limit 1) Entry in error stack Check sensor, wiring, input on control unit	A700		E	1
889005	Engine chassis: Sensor ambient pr. Signal outside permissible range (Limit 2) Entry in error stack Check sensor, wiring, input on control unit	A700		E	1
889006	Engine chassis: Sensor ambient pr. signal implausible Entry in error stack Check sensor, wiring, input on control unit	A700		E	1
889100	Engine chassis: Sensor air filter vacuum pressure status 2 short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889101	Engine chassis: Sensor air filter vacuum pressure status 2 short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700		E	1
889102	Engine chassis: Sensor air filter vacuum pressure status 2 Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889103	Engine chassis: Sensor air filter vacuum pressure status 2 Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
889104	Engine chassis: Sensor air filter vacuum pressure status 2 Signal outside permissible range (Limit 1) no reaction Check air filter pressure switch 2 for operating range violation. Remedy possible mechanical problem	A700		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889105	Engine chassis: Sensor air filter vacuum pressure status 2 Signal outside permissible range (Limit 2) no reaction Check air filter pressure switch 2 for operating range violation. Remedy possible mechanical problem	A700		E	1
889106	Engine chassis: Sensor air filter vacuum pressure status 2 Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700		E	1
889200	Engine chassis: Sensor air filter sub pressure status short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:46/60		E	1
889201	Engine chassis: Sensor air filter sub pressure status short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X2:46/60		E	1
889202	Engine chassis: Sensor air filter sub pressure status Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:46/60		E	1
889203	Engine chassis: Sensor air filter sub pressure status Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:46/60		E	1
889204	Engine chassis: Sensor air filter sub pressure status Signal outside permissible range (Limit 1) no reaction Check air filter pressure switch 1 for operating range violation. Remedy possible mechanical problem	A700.X2:46/60		E	1
889205	Engine chassis: Sensor air filter sub pressure status Signal outside permissible range (Limit 2) no reaction Check air filter pressure switch 1 for operating range violation. Remedy possible mechanical problem	A700.X2:46/60		E	1
889206	Engine chassis: Sensor air filter sub pressure status Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700.X2:46/60		E	1
889300	Engine chassis: Sensor Water in fuel short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889301	Engine chassis: Sensor Water in fuel short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X2:		E	1
889302	Engine chassis: Sensor Water in fuel Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:		E	1
889303	Engine chassis: Sensor Water in fuel Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:		E	1
889304	Engine chassis: Sensor Water in fuel Signal outside permissible range (Limit 1) no reaction Check water level sensor for operating range injury. Fix possible mech. problem	A700.X2:		E	1
889305	Engine chassis: Sensor Water in fuel Signal outside permissible range (Limit 2) no reaction Check water level sensor for operating range injury. Fix possible mech. problem	A700.X2:		E	1
889306	Engine chassis: Sensor Water in fuel Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700.X2:		E	1
889400	Engine chassis: Sensor Intercooler-Temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:		E	1
889401	Engine chassis: Sensor Intercooler-Temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X2:		E	1
889402	Engine chassis: Sensor Intercooler-Temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:		E	1
889403	Engine chassis: Sensor Intercooler-Temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889404	Engine chassis: Sensor Intercooler-Temperature Signal outside permissible range (Limit 1) no reaction Check exhaust temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X2:		E	1
889405	Engine chassis: Sensor Intercooler-Temperature Signal outside permissible range (Limit 2) no reaction Check exhaust temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X2:		E	1
889406	Engine chassis: Sensor Intercooler-Temperature Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700.X2:		E	1
889500	Engine chassis: Oil temperature sensor short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:46/60		E	1
889501	Engine chassis: Oil temperature sensor short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X2:46/60		E	1
889502	Engine chassis: Oil temperature sensor Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X2:46/60		E	1
889503	Engine chassis: Oil temperature sensor Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X2:46/60		E	1
889504	Engine chassis: Oil temperature sensor Signal outside permissible range (Limit 1) no reaction Check oil temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X2:46/60		E	1
889505	Engine chassis: Oil temperature sensor Signal outside permissible range (Limit 2) no reaction Check oil temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X2:46/60		E	1
889506	Engine chassis: Oil temperature sensor Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700.X2:46/60		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889600	Engine chassis: Sensor fuel temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:38/52		E	1
889601	Engine chassis: Sensor fuel temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X1:38/52		E	1
889602	Engine chassis: Sensor fuel temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:38/52		E	1
889603	Engine chassis: Sensor fuel temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:38/52		E	1
889604	Engine chassis: Sensor fuel temperature Signal outside permissible range (Limit 1) Performance reduction Check fuel temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X1:38/52		E	1
889605	Engine chassis: Sensor fuel temperature Signal outside permissible range (Limit 2) Performance reduction Check fuel temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X1:38/52		E	1
889606	Engine chassis: Sensor fuel temperature Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700.X1:38/52		E	1
889700	Engine chassis: Sensor charge air temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:		E	1
889701	Engine chassis: Sensor charge air temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:		E	1
889702	Engine chassis: Sensor charge air temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889703	Engine chassis: Sensor charge air temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:		E	1
889704	Engine chassis: Sensor charge air temperature Signal outside permissible range (Limit 1) Performance reduction Check charge air temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X1:		E	1
889705	Engine chassis: Sensor charge air temperature Signal outside permissible range (Limit 2) Performance reduction Check charge air temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X1:		E	1
889706	Engine chassis: Sensor charge air temperature Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700.X1:		E	1
889800	Engine chassis: Sensor coolant temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:51/37		E	2
889801	Engine chassis: Sensor coolant temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700.X1:51/37		E	2
889802	Engine chassis: Sensor coolant temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700.X1:51/37		E	2
889803	Engine chassis: Sensor coolant temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700.X1:51/37		E	2
889804	Engine chassis: Sensor coolant temperature Signal outside permissible range (Limit 1) Performance reduction Check coolant temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X1:51/37		E	1
889805	Engine chassis: Sensor coolant temperature Signal outside permissible range (Limit 2) Performance reduction Check coolant temperature sensor for operating range violation. Remedy possible mechanical problem	A700.X1:51/37		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
889806	Engine chassis: Sensor coolant temperature Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700.X1:51/37		E	1
889900	Engine chassis: Sensor internal temperature short circuit to ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889901	Engine chassis: Sensor internal temperature short circuit to supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Test wiring engine control unit / sensor (short circuit after battery voltage or broken wire)	A700		E	1
889902	Engine chassis: Sensor internal temperature Supply voltage Short circuit after ground Sensor default value is used. Error disappears, if test values are again in defined range Check wiring engine control unit/Sensor (Short circuit after ground)	A700		E	1
889903	Engine chassis: Sensor internal temperature Supply voltage Short circuit after supply voltage Sensor default value is used. Error disappears, if test values are again in defined range Check wiring of engine control unit/Sensor (Short circuit after battery voltage)	A700		E	1
889904	Engine chassis: Sensor internal temperature Signal outside permissible range (Limit 1) no reaction Check internal temperature for operating range violation. Remedy possible mechanical problem	A700		E	1
889905	Engine chassis: Sensor internal temperature Signal outside permissible range (Limit 2) no reaction Check internal temperature for operating range violation. Remedy possible mechanical problem	A700		E	1
889906	Engine chassis: Sensor internal temperature Test value not plausible at Motor off Entry in error stack Check sensor, wiring, input on control unit	A700		E	1
8B0100	Engine uppercarr. Operating note Travel pedal actuated at selected / active engine brake No acceptance of gases at active engine brake 300100: Deactivation of engine brake	A750		B	0
8B0101	Engine uppercarr. Operating note Travel pedal actuated at support / superstructure operation No acceptance of gases at active engine brake 300101: Deactivation of support operation	A750		B	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0102	Engine uppercarr. Operating note Service function "Vent fuel supply" activated (Gaspedal Increase of injection amount in starting phase 300102: Deactivate after reaching rpm limit or after initialization of engine control unit	A750		B	0
8B0103	Engine uppercarr. Operating note Engine Start prevented, ignition switch actuated after ignition on No engine start until Signal terminal 50 on input was recognized as low 300103: Release ignition switch KI.50 or check signal for short circuit after Ubatt	A750		B	0
8B0104	Engine uppercarr. Operating note Engine Start prevented, Ignition switch to short in zero No engine start until Signal terminal 50 on input was recognized as low 300104: Release ignition switch T.50 or check signal for short circuit after Ubatt	A750		B	0
8B0105	Engine uppercarr. Operating note Engine Start prevented, Ignition switch actuated in Init phase No engine start until Signal terminal 50 on input was recognized as low 300105: Release ignition switch T.50 or check signal for short circuit after Ubatt	A750		B	0
8B0106	Engine uppercarr. Operating note Engine running for long time without load in idling Filter load increases significantly 300106: Increase load/engine rpm	A750		B	0
8B0107	Engine uppercarr. Operating note manual DPF regeneration not possible, charge status too low no reaction 300107: Deactivate manual DPF Regeneration	A750		B	1
8B0108	Engine uppercarr. Operating note manual DPF regeneration not possible, time blockage no reaction 300107: Deactivate manual DPF Regeneration	A750		B	1
8B0109	Engine uppercarr. Operating note Start prevented, no release of emerg. stop function engine start not possible 300109: Release ignition switch, check emerg. stop signal for short circuit after Ubatt	A750		B	1
8B010A	Engine uppercarr. Operating note Time conditions for monitoring test values not met engine start not possible 300110: Check / replace machine control Master 4	A750		B	0
8B010B	Engine uppercarr. Operating note Emerg. op after problem of data transfer on CAN-Bus active engine start not possible 300111: Stop engine and restart, check CAN-wiring	A750		B	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0200	Engine uppercarr. Operating note Travel pedal actuated at selected / active engine brake error report 300200:	A750		B	0
8B0400	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit(meter Sensor 1) faulty Possibly power reduction 300400: Check wiring CAN-Buses, control units	A750		E	1
8B0401	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit(meter Sensor 2) faulty Possibly power reduction 300401: Check wiring CAN-Buses, control units	A750		E	1
8B0402	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2 (Sensors SCR cat.) faulty Possibly power reduction 300402: Check wiring CAN-Buses, control units	A750		E	1
8B0403	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(urea tank sensors) faulty Possibly power reduction 300403: Check wiring CAN-Buses, control units	A750		E	1
8B0404	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(SCR metering status) faulty Possibly power reduction 300404: Check wiring CAN-Buses, control units	A750		E	1
8B0405	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(SCR metering info) faulty Possibly power reduction 300405: Check wiring CAN-Buses, control units	A750		E	1
8B0406	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(NoxUp2 dew-point) faulty Possibly power reduction 300406: Check wiring CAN-Buses, control units	A750		E	1
8B0407	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(NoxDown2 dew-point) faulty Possibly power reduction 300407: Check wiring CAN-Buses, control units	A750		E	1
8B0408	Engine uppercarr. CAN-Data transfer engine CAN 4 Diagnostics of SCR-metering unit 2 erroneous no reaction 300408: Check wiring CAN-Buses, control units	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0409	Engine uppercarr. CAN-Data transfer engine CAN 4 Data transfer SCR Service diagnostics faulty, 2. Pump no reaction 300409: Check wiring CAN-Buses, control units	A750		E	1
8B040A	Engine uppercarr. CAN-Data transfer engine CAN 4 Service diagnostics function SCR 2 not properly completed no reaction 300410: Check wiring CAN-Buses, control units	A750		E	1
8B040B	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(meter Sensor 1) faulty Possibly power reduction 300411: Check wiring CAN-Buses, control units	A750		E	1
8B040C	Engine uppercarr. CAN-Data transfer engine CAN 4 SCR-unit 2(meter Sensor 2) faulty Possibly power reduction 300412: Check wiring CAN-Buses, control units	A750		E	1
8B040D	Engine uppercarr. CAN-Data transfer engine CAN 4 Humidity sensor faulty Possibly power reduction 300413: Check wiring CAN-Buses, control units	A750		E	1
8B0500	Engine uppercarr. CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded Emerg. op.: Momentum and RPM limitation of engine 300500: Check cable / plug / I/O-module(s)	A750		E	1
8B0501	Engine uppercarr. CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded Last received value or replacement value 300501: Check cable / plug / Coupling module	A750		E	1
8B0502	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded Last received value or replacement value 300502: Check cable / plug / Gear module	A750		E	1
8B0503	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded Last received value or replacement value 300503: Check cable / plug / Gear module	A750		E	1
8B0504	Engine uppercarr. CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded Last received value or replacement value 300504: Check cable / plug / Gear module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0505	Engine uppercarr. CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded Last received value or replacement value 300505: Check cable / plug / ABS/ASR-Module1	A750		E	1
8B0506	Engine uppercarr. CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded Last received value or replacement value 300506: Check cable / plug / ABS/ASR-Module1	A750		E	1
8B0507	Engine uppercarr. CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded Last received value or replacement value 300507: Check cable / plug / ABS/ASR-Module2	A750		E	1
8B0508	Engine uppercarr. CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded Last received value or replacement value 300508: Check cable / plug / ABS/ASR-Module2	A750		E	1
8B0509	Engine uppercarr. CAN-Data transfer Retarder (ID 772) erroneous/maximum cycle time exceeded Last received value or replacement value 300509: Check cable / plug / Retarder module	A750		E	1
8B050A	Engine uppercarr. CAN-Data transfer WSK (ID 776) erroneous/maximum cycle time exceeded Last received value or replacement value 300510: Check cable / plug / converter module	A750		E	1
8B050B	Engine uppercarr. CAN-Data transfer Overrun of receiving buffer Last received value or replacement value 300511: Turn ignition off/on, load new software in engine control unit or replace control unit	A750		E	1
8B0600	Engine uppercarr. CAN-Data transfer engine control unit Aborted (Passive error) Last received value or replacement value 300600: Check cable / plug / CAN-participant	A750		E	1
8B0601	Engine uppercarr. CAN-Data transfer engine control unit Aborted (BusOff) Last received value or replacement value 300601: Check cable / plug / CAN-participant	A750		E	1
8B0602	Engine uppercarr. CAN-Data transfer engine control unit Faulty / interrupted (Rx-warning) Last received value or replacement value 300602: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0603	Engine uppercarr. CAN-Data transfer engine control unit Faulty / interrupted (Tx-warning) Last received value or replacement value 300603: Check cable / plug / CAN-participant	A750		E	1
8B0604	Engine uppercarr. CAN-Data transfer engine control unit Faulty / interrupted (send -timeout) Last received value or replacement value 300604: Check cable / plug / CAN-participant	A750		E	1
8B0606	Engine uppercarr. CAN-Data transfer engine control unit Faulty / interrupted (complete transmission data) Last received value or replacement value 300606: Turn ignition off/on, Load new software in engine control unit or replace control unit	A750		E	1
8B0700	Engine uppercarr. CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded no reaction 300700: Check cable / plug / CAN-participant	A750		E	1
8B0701	Engine uppercarr. CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded no reaction 300701: Check cable / plug / CAN-participant	A750		E	1
8B0702	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300702: Check cable / plug / CAN-participant	A750		E	1
8B0703	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300703: Check cable / plug / CAN-participant	A750		E	1
8B0704	Engine uppercarr. CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded no reaction 300704: Check cable / plug / CAN-participant	A750		E	1
8B0705	Engine uppercarr. CAN-Data transfer ABV (ID512) erroneous/maximum cycle time exceeded error report 300705:	A750		E	1
8B0706	Engine uppercarr. CAN-Data transfer ABV (ID513) erroneous/maximum cycle time exceeded error report 300706:	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0707	Engine uppercarr. CAN-Data transfer ABV2 (ID514) erroneous/maximum cycle time exceeded error report 300707:	A750		E	1
8B0708	Engine uppercarr. CAN-Data transfer ABV2 (ID515) erroneous/maximum cycle time exceeded 300708:	A750		E	1
8B0800	Engine uppercarr. CAN-Data transfer I/O-Module (ID90x) erroneous/maximum cycle time exceeded emergency operation 300800: Check cable / plug / CAN-participant	A750		E	1
8B0801	Engine uppercarr. CAN-Data transfer Coupling (ID 556) erroneous/maximum cycle time exceeded emergency operation 300801: Check cable / plug / CAN-participant	A750		E	1
8B0802	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300802: Check cable / plug / CAN-participant	A750		E	1
8B0803	Engine uppercarr. CAN-Data transfer Gear (ID564) erroneous/maximum cycle time exceeded no reaction 300803: Check cable / plug / CAN-participant	A750		E	1
8B0804	Engine uppercarr. CAN-Data transfer Gear (ID668) erroneous/maximum cycle time exceeded emergency operation 300804: Check cable / plug / Master	A750		E	1
8B0900	Engine uppercarr. CAN-Data transfer Aborted (Passive error) Change over to plausible speed source 300900: Check cable / plug / CAN-participant	A750		E	1
8B0901	Engine uppercarr. CAN-Data transfer Aborted (BusOff) Change over to plausible speed source 300901: Check cable / plug / CAN-participant	A750		E	1
8B0902	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx-warning) no reaction 300902: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0903	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx-warning) no reaction 300903: Check cable / plug / CAN-participant	A750		E	1
8B0904	Engine uppercarr. CAN-Data transfer Faulty / interrupted (send -timeout) Change over to plausible speed source 300904: Check cable / plug / CAN-participant	A750		E	1
8B0905	Engine uppercarr. CAN-Data transfer Faulty / interrupted (TSC1) no reaction 300905: Check cable / plug / CAN-participant	A750		E	1
8B0A00	Engine uppercarr. CAN-Data transfer Aborted (Passive error) Change over to plausible speed source 301000: Check cable / plug / CAN-participant	A750		E	1
8B0A01	Engine uppercarr. CAN-Data transfer Aborted (BusOff) Change over to plausible speed source 301001: Check cable / plug / CAN-participant	A750		E	1
8B0A02	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx-warning) no reaction 301002: Check cable / plug / CAN-participant	A750		E	1
8B0A03	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx-warning) no reaction 301003: Check cable / plug / CAN-participant	A750		E	1
8B0A04	Engine uppercarr. CAN-Data transfer Faulty / interrupted (send -timeout) Possibly power reduction 301004: Check cable / plug / CAN-participant	A750		E	1
8B0A05	Engine uppercarr. CAN-Data transfer AGR-Module 1 erroneous/maximum cycle time exceeded Possibly power reduction 301005: Check cable / plug / CAN-participant	A750		E	1
8B0A06	Engine uppercarr. CAN-Data transfer AGR-Module 2 erroneous/maximum cycle time exceeded Possibly power reduction 301006: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0A07	Engine uppercarr. CAN-Data transfer WasteGate-Module 1 erroneous/maximum cycle time exceeded Possibly power reduction 301007: Check cable / plug / CAN-participant	A750		E	1
8B0A08	Engine uppercarr. CAN-Data transfer WasteGate-Module 2 erroneous/maximum cycle time exceeded Possibly power reduction 301008: Check cable / plug / CAN-participant	A750		E	1
8B0A09	Engine uppercarr. CAN-Data transfer Restrictor flap module erroneous/maximum cycle time exceeded Possibly power reduction 301009: Check cable / plug / CAN-participant	A750		E	1
8B0A0A	Engine uppercarr. CAN-Data transfer Tachograph erroneous/maximum cycle time exceeded Change over to plausible speed source 301010: Check cable / plug / CAN-participant	A750		E	1
8B0A0B	Engine uppercarr. CAN-Data transfer NOx-Lambda sensor up1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301011: Check cable / plug / CAN-participant	A750		E	1
8B0A0C	Engine uppercarr. CAN-Data transfer NOx-Lambda sensor down1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301012: Check cable / plug / CAN-participant	A750		E	1
8B0A0D	Engine uppercarr. CAN-Data transfer Mass flow sensor 1 erroneous/maximum cycle time exceeded Change over to 2nd Lambda Signal 301013: Check cable / plug / CAN-participant	A750		E	1
8B0B00	Engine uppercarr. CAN-Data transfer Aborted (Passive error) no reaction 301100: Check cable / plug / CAN-participant	A750		E	1
8B0B01	Engine uppercarr. CAN-Data transfer Aborted (BusOff) no reaction 301101: Check cable / plug / CAN-participant	A750		E	1
8B0B02	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301102: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0B03	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx warning) no reaction 301103: Check cable / plug / CAN-participant	A750		E	1
8B0B04	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301104: Check cable / plug / CAN-participant check Master-Slave recognition-Pin	A750		E	1
8B0B05	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx timeout) No injection on slave modules will occur 301105: Check cable / plug / CAN-participant / Slave recognition Pin	A750		E	1
8B0B06	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx Send buffer overflow) no reaction 301106: Check cable / plug / CAN-participant	A750		E	1
8B0B07	Engine uppercarr. CAN-Data transfer Internal error, Software slave Module incompatible to master No injection on slave modules will occur 301107: Update slave and master module	A750		E	1
8B0B08	Engine uppercarr. CAN-Data transfer Internal error, calibration slave Module incompatible to master No injection on slave modules will occur 301108: Update slave and master module	A750		E	1
8B0C00	Engine uppercarr. CAN-Data transfer Motor CAN 2 HC-dosing unit (PRODPM2) faulty / interrupted Warning light on in operation no regeneration permitted 301200: Check cable / plug / CAN-participant	A750		E	1
8B0C01	Engine uppercarr. CAN-Data transfer Motor CAN 2 HC-dosing unit (HCDI1) faulty / interrupted Warning light on in operation no regeneration permitted 301201: Check cable / plug / CAN-participant	A750		E	1
8B0C02	Engine uppercarr. CAN-Data transfer Motor CAN 2 Mass flow sensor 2 faulty / interrupted Possibly power reduction 301202: Check cable / plug / CAN-participant	A750		E	1
8B0C03	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of mass flow sensor 1 failed Possibly power reduction 301203: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0C04	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of mass flow sensor 2 failed Possibly power reduction 301204: Check cable / plug / CAN-participant	A750		E	1
8B0C05	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of Nox-sensors "Up1" failed Possibly power reduction 301205: Check cable / plug / CAN-participant	A750		E	1
8B0C06	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of Nox-sensors "Down1" failed Possibly power reduction 301206: Check cable / plug / CAN-participant	A750		E	1
8B0C07	Engine uppercarr. CAN-Data transfer Motor CAN 2 Tachograph (Date, time) faulty / interrupted Change over to plausible speed source 301207: Check cable / plug / CAN-participant	A750		E	1
8B0C08	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of "Egr1" failed Power reduction of Diesel engine 301208: Check cable / plug / CAN-participant	A750		E	1
8B0C09	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of "Egr2" failed Power reduction of Diesel engine 301209: Check cable / plug / CAN-participant	A750		E	1
8B0C0A	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of "WG1" failed Power reduction of Diesel engine 301210: Check cable / plug / CAN-participant	A750		E	1
8B0C0B	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of "WG2" failed Power reduction of Diesel engine 301211: Check cable / plug / CAN-participant	A750		E	1
8B0C0C	Engine uppercarr. CAN-Data transfer Motor CAN 2 SCR-unit (SCR Sensors) faulty / interrupted Possibly power reduction 301212: Check cable / plug / CAN-participant	A750		E	1
8B0C0D	Engine uppercarr. CAN-Data transfer Motor CAN 2 Diagnostics of HC-dosing unit failed no reaction 301213: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0D00	Engine uppercarr. CAN-Data transfer Aborted (Passive error) no reaction 301300: Check cable / plug / CAN-participant	A750		E	1
8B0D01	Engine uppercarr. CAN-Data transfer Aborted (BusOff) no reaction 301301: Check cable / plug / CAN-participant	A750		E	1
8B0D02	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx warning) no reaction 301302: Check cable / plug / CAN-participant	A750		E	1
8B0D03	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Tx warning) no reaction 301303: Check cable / plug / CAN-participant	A750		E	1
8B0D04	Engine uppercarr. CAN-Data transfer Faulty / interrupted (Rx warning) No injection on Slave modules 301304: Check cable / plug / CAN-participant	A750		E	1
8B0D05	Engine uppercarr. CAN-Data transfer Incorrect transfer rate recognized No injection on Slave modules 301305: Check cable / plug / CAN-participant / Slave recognition Pin	A750		E	1
8B0D06	Engine uppercarr. CAN-Data transfer Unexpected messages recognized No injection on Slave modules 301306: Check cable / plug / CAN-participant / Slave recognition Pin	A750		E	1
8B0E00	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit (Tank sensors) faulty / interrupted Possibly power reduction 301400: Check cable / plug / CAN-participant	A750		E	1
8B0E01	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, metering status Possibly power reduction 301401: Check cable / plug / CAN-participant	A750		E	1
8B0E02	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, metering information Possibly power reduction 301402: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0E03	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, dew-point recognition "NOxUp1" Possibly power reduction 301403: Check cable / plug / CAN-participant	A750		E	1
8B0E04	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, dew-point recognition "NOxDown1" Possibly power reduction 301404: Check cable / plug / CAN-participant	A750		E	1
8B0E05	Engine uppercarr. CAN-Data transfer Motor CAN 3 Water pump faulty / interrupted (Status report) no reaction 301405: Check cable / plug / CAN-participant	A750		E	1
8B0E06	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, diagnostics not possible no reaction 301406: Check cable / plug / CAN-participant	A750		E	1
8B0E07	Engine uppercarr. CAN-Data transfer Motor CAN 3 Restrictor flap module faulty / interrupted, diagnostics not possible Possibly power reduction 301407: Check cable / plug / CAN-participant	A750		E	1
8B0E08	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty / interrupted, Service diagnostics not possible no reaction 301408: Check cable / plug / CAN-participant	A750		E	1
8B0E09	Engine uppercarr. CAN-Data transfer Motor CAN 3 SCR-unit faulty/interrupted, Service diagnostics not completed no reaction 301409:	A750		E	1
8B0E0A	Engine uppercarr. CAN-Data transfer Motor CAN 3 Nox-Lambda sensor "Up 2" faulty 301410: Check cable / plug / CAN-participant	A750		E	1
8B0E0B	Engine uppercarr. CAN-Data transfer Motor CAN 3 Nox-Lambda sensor "Down 2" faulty 301411: Check cable / plug / CAN-participant	A750		E	1
8B0E0C	Engine uppercarr. CAN-Data transfer Motor CAN 3 Diagnostics of NOx-Sensor "Up 2" failed 301412: Check cable / plug / CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B0E0D	Engine uppercarr. CAN-Data transfer Motor CAN 3 Diagnostics of NOx-Sensor "Down 2" failed 301413: Check cable / plug / CAN-participant	A750		E	1
8B0F06	Engine uppercarr. Actuation coupling engine compartment ventilation Current too low in actuated state error report Output control unit, check wiring, fan coupling	A750		E	1
8B1000	Engine uppercarr. Engine protection function Excess temperature on exhaust turbine active Performance reduction 301600: Check exhaust system for leaks	A750		E	1
8B1200	Engine uppercarr. CAN constr. machines, download Memory error flash 0 301800:	A750		E	1
8B1201	Engine uppercarr. CAN constr. machines, download Memory error flash 0 301801:	A750		E	1
8B1202	Engine uppercarr. CAN constr. machines, download Memory error flash 0 301802:	A750		E	1
8B1203	Engine uppercarr. CAN constr. machines, download memory error EEPROM 0 301803:	A750		E	1
8B1204	Engine uppercarr. CAN constr. machines, download Check sum error 0 301804:	A750		E	1
8B1205	Engine uppercarr. CAN constr. machines, download Incorrect number of data 0 301805:	A750		E	1
8B1206	Engine uppercarr. CAN constr. machines, download Receive buffer overflow 0 301806:	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1207	Engine uppercarr. CAN constr. machines, download download active 0 301807:	A750		E	1
8B1208	Engine uppercarr. CAN constr. machines, download unknown area 0 301808:	A750		E	1
8B1300	Engine uppercarr. Internal error control equipment Stack-overflow Engine cannot be started or engine shut off 301900: Load new software in engine control unit or replace engine control unit	A750		E	1
8B1301	Engine uppercarr. Internal error control equipment Exception error Engine cannot be started or engine shut off 301901: Load new software in engine control unit or replace engine control unit	A750		E	2
8B1302	Engine uppercarr. Internal error control equipment Program test Engine cannot be started or engine shut off 301902: Load new software in engine control unit or replace engine control unit	A750		E	2
8B1303	Engine uppercarr. Internal error control equipment RAM-Test Engine cannot be started or engine shut off 301903: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1304	Engine uppercarr. Internal error control equipment Overflow in error stack no reaction 301904: Load new software in engine control unit or replace engine control unit	A750		E	1
8B1305	Engine uppercarr. Internal error control equipment Comp. time error no reaction 301905: Load new software in engine control unit or replace engine control unit	A750		E	2
8B1306	Engine uppercarr. Internal error control equipment Error-Index too large The error cannot be saved 301906: Load new software in engine control unit or replace engine control unit	A750		E	1
8B1400	Engine uppercarr. Control unit defective (memory EEPROM) Error at EEPROM-access Engine cannot be started or engine shut off 302000: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1401	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error Parameter memory Engine cannot be started or engine shut off 302001: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1402	Engine uppercarr. Control unit defective (memory EEPROM) Parameter memory in EEPROM is invalid Engine cannot be started or engine shut off 302002: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1403	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error ECU-Page No reaction - possibly data sets or operating conditions could not be saved 302003: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1404	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error NMI-Page No reaction - possibly data sets or operating conditions could not be saved 302004: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1405	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error Workdata-Page No reaction - possibly data sets or operating conditions could not be saved 302005: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1406	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error load collective No reaction - possibly load collective data could not be saved 302006: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1407	Engine uppercarr. Control unit defective (memory EEPROM) Structure size of load collective has changed No reaction - possibly load collective data could not be saved 302007: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1408	Engine uppercarr. Control unit defective (memory EEPROM) EEPROM-Memory full (load collective) No reaction - possibly load collective data could not be saved 302008: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1409	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error permanent Data No reaction - possibly data sets or operating conditions could not be saved 302009: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B140A	Engine uppercarr. Control unit defective (memory EEPROM) EEPROM Data inconsistent No reaction - possibly data sets or operating conditions could not be saved 302010: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B140B	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error OBD-Page No reaction - possibly data sets or operating conditions could not be saved 302011: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B140C	Engine uppercarr. Control unit defective (memory EEPROM) Check sum error EEPROM-areas No reaction - possibly data sets or operating conditions could not be saved 302012: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8B1500	Engine uppercarr. Power supply voltage below required value Engine cannot be started or engine shut off 302100: Check on-board power supply (battery, alternator, wiring, plug)	A750		E	2
8B1501	Engine uppercarr. Power supply excess voltage Engine cannot be started or engine shut off 302101: Check on-board power supply (battery, alternator, wiring, plug)	A750		E	2
8B1502	Engine uppercarr. Power supply Digital outlet short circuit after supply voltage Engine shut off 302102: Check wiring, engine control unit, possibly replace engine control unit	A750		E	2
8B1503	Engine uppercarr. Power supply Error release output outlets Engine shut off, shut off of all digital outlets 302103: Check wiring, engine control unit, possibly replace engine control unit	A750		E	2
8B1504	Engine uppercarr. Power supply PS1-Pin erroneous/missing Engine cannot be started or engine shut off 302104: Check on board network in ref. to PS1 (terminal 30/31), engine control unit	A750		E	2
8B1505	Engine uppercarr. Power supply Reference voltage 12V below permissible range Engine shut off 302105: Check supply voltage Rpm sensors, on board network, engine control unit	A750		E	2
8B1506	Engine uppercarr. Power supply Reference voltage 12V above permissible range Engine shut off 302106: Check supply voltage Rpm sensors, on board network, engine control unit	A750		E	2
8B1600	Engine uppercarr. Configuration error Fan control cooler The fan control is deactivated. Resulting in maximum vent position 302200: Load new software in engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1601	Engine uppercarr. Configuration error Offset to full load curve The matching of the performance curve is internally limited 302201: Load new software in engine control unit	A750		E	2
8B1602	Engine uppercarr. Configuration error Monitoring Pedal unit Pedal unit is not monitored 302202: Load new software in engine control unit	A750		E	2
8B1603	Engine uppercarr. Configuration error Incorrect pump code Replacement value is used 302203: Check pump coding and change (via diagnostics or resp. diagnostics tool)	A750		E	2
8B1604	Engine uppercarr. Configuration error Incorrect assignment of high pressure sensors no reaction 302204: Load new software in engine control unit	A750		E	2
8B1605	Engine uppercarr. Configuration error No high pr. pump activated no reaction 302205: Load new software in engine control unit	A750		E	2
8B1606	Engine uppercarr. Configuration error Current output for VCV 1 not active no reaction 302206: Load new software in engine control unit	A750		E	2
8B1607	Engine uppercarr. Configuration error Current output for VCV 2 not active no reaction 302207: Load new software in engine control unit	A750		E	2
8B1608	Engine uppercarr. Configuration error CAN-messages no reaction 302208: Load new software in engine control unit	A750		E	2
8B1609	Engine uppercarr. Configuration error CAN-transfer rate no reaction 302209: Load new software in engine control unit	A750		E	2
8B160A	Engine uppercarr. Configuration error Incorrect assignment of analog sensor no reaction 302210: Load new software in engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B160B	Engine uppercarr. Configuration error Incorrect assignment switch no reaction 302211:	A750		E	2
8B160C	Engine uppercarr. Configuration error Motor configuration erroneous/missing Engine cannot be started or engine shut off 302212: Load new software in engine control unit	A750		E	2
8B160D	Engine uppercarr. Configuration error Parameterization actuator invalid Power reduction of Diesel engine 302213: Load new software in engine control unit	A750		E	2
8B1700	Engine uppercarr. Configuration error Component ID of SCR-unit incorrect no reaction 302300:	A750		E	2
8B1701	Engine uppercarr. Configuration error Component ID of HC-metering unit incorrect The matching of the performance curve is internally limited 302201: Load new software in engine control unit	A750		E	1
8B1702	Engine uppercarr. Configuration error Component ID of restrictor flap incorrect Pedal unit is not monitored 302202: Load new software in engine control unit	A750		E	1
8B1703	Engine uppercarr. Configuration error Current output for PCV1 not active Replacement value is used 302203: Check pump coding and change (via diagnostics or resp. diagnostics tool)	A750		E	1
8B1704	Engine uppercarr. Configuration error Current output for PCV2 not active no reaction 302204: Load new software in engine control unit	A750		E	1
8B1800	Engine uppercarr. Configuration error Fan control cooler no reaction 302400:	A750		E	2
8B1900	Engine uppercarr. Control unit defective (FLASH-memory) Check sum error Parameter memory Engine cannot be started or engine shut off 302500: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1901	Engine uppercarr. Control unit defective (FLASH-memory) Invalid data, default values are used Engine cannot be started or engine shut off 302501: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1902	Engine uppercarr. Control unit defective (FLASH-memory) Error during delete Engine cannot be started or engine shut off 302502: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1903	Engine uppercarr. Control unit defective (FLASH-memory) Error during programming Engine cannot be started or engine shut off 302503: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1904	Engine uppercarr. Control unit defective (FLASH-memory) Error during check Engine cannot be started or engine shut off 302504: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1905	Engine uppercarr. Control unit defective (FLASH-memory) Data inconsistent Engine cannot be started or engine shut off 302505: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	2
8B1A00	Engine uppercarr. Internal error control equipment Program error Engine shut off 302600: Program update to newest software version	A750		E	2
8B1A01	Engine uppercarr. Internal error control equipment Program error Engine shut off 302601: Program update to newest software version	A750		E	2
8B1A02	Engine uppercarr. Internal error control equipment Program error Engine shut off 302602: Program update to newest software version	A750		E	2
8B1A03	Engine uppercarr. Internal error control equipment Program error Engine shut off 302603: Program update to newest software version	A750		E	2
8B1A04	Engine uppercarr. Internal error control equipment Program error Engine shut off 302604: Program update to newest software version	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1A05	Engine uppercarr. Internal error control equipment Program error Engine shut off 302605: Program update to newest software version	A750		E	2
8B1A06	Engine uppercarr. Internal error control equipment Program error Engine shut off 302606: Program Update to newest software bersion	A750		E	2
8B1B00	Engine uppercarr. Speed recording Maximum difference travel speed Tacho<>Gear exceeded The larger speed value is used 302700: Check gear and tachograph	A750		E	1
8B1C00	Engine uppercarr. Actuation engine brake Broken wire or Short circuit after ground Engine brake flap is not actuated 302800: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C01	Engine uppercarr. Actuation engine brake Broken wire or short circuit after supply voltage Engine brake flap is not actuated 302801: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C02	Engine uppercarr. Actuation engine brake Hardware error (control unit defective) Engine brake flap is not actuated 302802: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C03	Engine uppercarr. Actuation engine brake Maximum signal difference to actuation exceeded Engine brake flap is not actuated 302803: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C04	Engine uppercarr. Actuation engine brake Maximum signal difference to actuation exceeded Engine brake flap is not actuated 302804: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C05	Engine uppercarr. Actuation engine brake Current measured without actuation Engine brake flap is not actuated 302805: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C06	Engine uppercarr. Actuation engine brake Current too low in actuated state Engine brake flap is not actuated 302806: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1C07	Engine uppercarr. Actuation engine brake Current too high in actuated state Engine brake flap is not actuated 302807: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C08	Engine uppercarr. Actuation engine brake Ground switch overcurrent Engine brake flap is not actuated 302808: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C09	Engine uppercarr. Actuation engine brake Plus switch overcurrent Engine brake flap is not actuated 302809: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1C0A	Engine uppercarr. Actuation engine brake Maximum analog value exceeded (PWM) Engine brake flap is not actuated 302810: Check wiring harness, plug, engine brake flap, engine control unit	A750		E	1
8B1D00	Engine uppercarr. Alternator Charge control D+ of mass flow sensor no reaction 302900: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D01	Engine uppercarr. Alternator Charge control D+ Overvoltage at engine off no reaction 302901: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D02	Engine uppercarr. Alternator Charge control D+ undervoltage at engine on no reaction 302902: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D03	Engine uppercarr. Alternator Charge control D+ overvoltage at engine on no reaction 302903: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D04	Engine uppercarr. Alternator Charge control D+ voltage deviation to on board current too low no reaction 302904: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1D05	Engine uppercarr. Alternator Charge control D+ voltage deviation to on board current too high no reaction 302905: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B1D06	Engine uppercarr. Alternator Implausibility at test of on board voltage Battery charge voltage regulated to 28.5V 302906: Check inputs of alternator	A750		E	0
8B1E00	Engine uppercarr. Alternator 2 Charge control D+ of mass flow sensor no reaction 303000: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1E01	Engine uppercarr. Alternator 2 Charge control D+ Overvoltage at engine off no reaction 303001: Check wiring engine control unit to alternator (D+), battery to alternator (D+) and alternator	A750		E	1
8B1E02	Engine uppercarr. Alternator 2 Charge control D+ undervoltage at engine on no reaction 303002: Check wiring engine control unit to alternator (D+), alternator and V-belt	A750		E	1
8B1E03	Engine uppercarr. Alternator 2 Charge control D+ overvoltage at engine on no reaction 303003: Check wiring engine control unit to alternator (D+), alternator and V-belt	A750		E	1
8B1E04	Engine uppercarr. Alternator 2 Charge control D+ voltage deviation to on board current too low no reaction 303004: Check wiring alternator (D+) to battery or engine control unit, alternator	A750		E	1
8B1E05	Engine uppercarr. Alternator 2 Charge control D+ voltage deviation to on board current too high no reaction 303005: Check wiring alternator (D+) to battery or engine control unit, alternator	A750		E	1
8B1F00	Engine uppercarr. Travel pedal No gas switch erroneous Use of low value 303100: Check wiring engine control unit to travel pedal, check travel pedal, replace	A750		E	1
8B1F01	Engine uppercarr. Travel pedal maximum signal difference channel 1 and 2 exceeded Use of low value 303101: Check wiring engine control unit to travel pedal, check travel pedal, replace	A750		E	1
8B2000	Engine uppercarr. Plausibility error Charge pressure to atmospheric pressure no reaction 303200: Replace sensor, check intake system for leaks	A750		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2100	Engine uppercarr. Error in Rail pr. system Pressure relief valve 1 has been actuated High pressure regulation emergency operation activated 303300: Check engine Stop/start, Rail circuit, Test unit, wiring Test unit, Rail pr. sensor	A750		E	2
8B2101	Engine uppercarr. Error in Rail pr. system Pressure relief valve 2 has been actuated High pressure regulation emergency operation activated 303301: Check engine Stop/start, Rail circuit, Test unit, wiring Test unit, Rail pr. sensor	A750		E	2
8B2102	Engine uppercarr. Error in Rail pr. system Emerg. op. high pr. regulation activated Power reduction, high pressure pump control turned off 303302: Check rail circuit 1/2, Check wiring harness, plug	A750		E	2
8B2103	Engine uppercarr. Error in Rail pr. system Maximum pressure deviation high pr. sensor 1 and 2 exceeded No reaction on engine, the larger of the high pressure sensor values is used 303303: Check wiring harness, plug, rail pr. sensors, check rail circuit 1/2	A750		E	1
8B2104	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 1 too large deviation (positive) no reaction 303304: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2105	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 2 too large deviation (positive) no reaction 303305: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2106	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 1 too large deviation (negative) no reaction 303306: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2107	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 2 too large deviation (negative) no reaction 303307: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2108	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 1 has leakage no reaction 303308: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2
8B2109	Engine uppercarr. Error in Rail pr. system CR-regulating circuit 2 has leakage no reaction 303309: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B210A	Engine uppercarr. Error in Rail pr. system VCV Plausibility error Pump 1 High pressure regulation emergency operation activated 303310: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	1
8B210B	Engine uppercarr. Error in Rail pr. system VCV Plausibility error Pump 2 no reaction 303311: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	0
8B210C	Engine uppercarr. Error in Rail pr. system common-rail regulating circuit 1 has leakage (CRS-System) no reaction 303312: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	1
8B210D	Engine uppercarr. Error in Rail pr. system common-rail regulating circuit 2 has leakage (CRS-System) no reaction 303313: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	1
8B2200	Engine uppercarr. Current outlet 1 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303400: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2201	Engine uppercarr. Current outlet 1 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303401: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2202	Engine uppercarr. Current outlet 1 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303402: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2203	Engine uppercarr. Current outlet 1 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303403: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2204	Engine uppercarr. Current outlet 1 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303404: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2205	Engine uppercarr. Current outlet 1 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303405: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2206	Engine uppercarr. Current outlet 1 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303406: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2207	Engine uppercarr. Current outlet 1 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303407: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2208	Engine uppercarr. Current outlet 1 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303408: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2209	Engine uppercarr. Current outlet 1 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303409: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B220A	Engine uppercarr. Current outlet 1 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303410: Check wiring harness, plug, CR-components1, engine control unit	A750		E	2
8B2300	Engine uppercarr. Current outlet 2 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303500: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2301	Engine uppercarr. Current outlet 2 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303501: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2302	Engine uppercarr. Current outlet 2 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303502: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2303	Engine uppercarr. Current outlet 2 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303503: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2304	Engine uppercarr. Current outlet 2 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303504: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2305	Engine uppercarr. Current outlet 2 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303505: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2306	Engine uppercarr. Current outlet 2 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303506: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2307	Engine uppercarr. Current outlet 2 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303507: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2308	Engine uppercarr. Current outlet 2 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303508: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2309	Engine uppercarr. Current outlet 2 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303509: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B230A	Engine uppercarr. Current outlet 2 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303510: Check wiring harness, plug, CR-components2, engine control unit	A750		E	2
8B2400	Engine uppercarr. Current outlet 3 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303600: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2401	Engine uppercarr. Current outlet 3 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303601: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2402	Engine uppercarr. Current outlet 3 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303602: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2403	Engine uppercarr. Current outlet 3 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303603: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2404	Engine uppercarr. Current outlet 3 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303604: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2405	Engine uppercarr. Current outlet 3 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303605: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2406	Engine uppercarr. Current outlet 3 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303606: Check wiring harness, plug, CR-comp.3, engine control unit	A750		E	2
8B2407	Engine uppercarr. Current outlet 3 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303607: Check wiring harness, plug, CR-comp.3, engine control unit	A750		E	2
8B2408	Engine uppercarr. Current outlet 3 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303608: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2409	Engine uppercarr. Current outlet 3 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303609: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B240A	Engine uppercarr. Current outlet 3 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303610: Check wiring harness, plug, CR-components3, engine control unit	A750		E	2
8B2500	Engine uppercarr. Current outlet 4 Broken wire or Short circuit after ground Possibly high pr. reg/ emerg. op. activated 303700: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2501	Engine uppercarr. Current outlet 4 Broken wire or short circuit after supply voltage Possibly high pr. reg/ emerg. op. activated 303701: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2502	Engine uppercarr. Current outlet 4 Hardware error (control unit defective) Possibly high pr. reg/ emerg. op. activated 303702: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2503	Engine uppercarr. Current outlet 4 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303703: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2504	Engine uppercarr. Current outlet 4 Maximum signal difference to actuation exceeded Possibly high pr. reg/ emerg. op. activated 303704: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2505	Engine uppercarr. Current outlet 4 Current measured without actuation Possibly high pr. reg/ emerg. op. activated 303705: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2506	Engine uppercarr. Current outlet 4 Current too low in actuated state Possibly high pr. reg/ emerg. op. activated 303706: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2507	Engine uppercarr. Current outlet 4 Current too high in actuated state Possibly high pr. reg/ emerg. op. activated 303707: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2508	Engine uppercarr. Current outlet 4 Ground switch overcurrent Possibly high pr. reg/ emerg. op. activated 303708: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2509	Engine uppercarr. Current outlet 4 Plus switch overcurrent Possibly high pr. reg/ emerg. op. activated 303709: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B250A	Engine uppercarr. Current outlet 4 Maximum analog value exceeded (PWM) Possibly high pr. reg/ emerg. op. activated 303710: Check wiring harness, plug, CR-components4, engine control unit	A750		E	2
8B2600	Engine uppercarr. Actuation Starter Broken wire or Short circuit after ground Engine start not possible 303800: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2601	Engine uppercarr. Actuation Starter Broken wire or short circuit after supply voltage Engine start not possible 303801: Check wiring harness, plug, Starter, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2602	Engine uppercarr. Actuation Starter Hardware error (control unit defective) Engine start not possible 303802: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2603	Engine uppercarr. Actuation Starter Maximum signal difference to actuation exceeded no reaction 303803: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2604	Engine uppercarr. Actuation Starter Maximum signal difference to actuation exceeded no reaction 303804: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2605	Engine uppercarr. Actuation Starter Current measured without actuation no reaction 303805: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2606	Engine uppercarr. Actuation Starter Current too low in actuated state no reaction 303806: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2607	Engine uppercarr. Actuation Starter Current too high in actuated state no reaction 303807: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2608	Engine uppercarr. Actuation Starter Ground switch overcurrent no reaction 303808: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2609	Engine uppercarr. Actuation Starter Plus switch overcurrent no reaction 303809: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B260A	Engine uppercarr. Actuation Starter Maximum analog value exceeded (PWM) no reaction 303810: Check wiring harness, plug, Starter, engine control unit	A750		E	1
8B2700	Engine uppercarr. Actuation fan 1 cooling Broken wire or Short circuit after ground no reaction 303900: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2701	Engine uppercarr. Actuation fan 1 cooling Broken wire or short circuit after supply voltage no reaction 303901: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2702	Engine uppercarr. Actuation fan 1 cooling Hardware error (control unit defective) no reaction 303902: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2703	Engine uppercarr. Actuation fan 1 cooling Maximum signal difference to actuation exceeded no reaction 303903: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2704	Engine uppercarr. Actuation fan 1 cooling Maximum signal difference to actuation exceeded no reaction 303904: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2705	Engine uppercarr. Actuation fan 1 cooling Current measured without actuation no reaction 303905: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2706	Engine uppercarr. Actuation fan 1 cooling Current too low in actuated state no reaction 303906: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2707	Engine uppercarr. Actuation fan 1 cooling Current too high in actuated state no reaction 303907: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2708	Engine uppercarr. Actuation fan 1 cooling Ground switch overcurrent no reaction 303908: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2709	Engine uppercarr. Actuation fan 1 cooling Plus switch overcurrent no reaction 303909: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B270A	Engine uppercarr. Actuation fan 1 cooling Maximum analog value exceeded (PWM) no reaction 303910: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2800	Engine uppercarr. Actuation fan 2 cooling Broken wire or Short circuit after ground no reaction 304000: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2801	Engine uppercarr. Actuation fan 2 cooling Broken wire or short circuit after supply voltage no reaction 304001: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2802	Engine uppercarr. Actuation fan 2 cooling Hardware error (control unit defective) no reaction 304002: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2803	Engine uppercarr. Actuation fan 2 cooling Maximum signal difference to actuation exceeded no reaction 304003: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2804	Engine uppercarr. Actuation fan 2 cooling Maximum signal difference to actuation exceeded no reaction 304004: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2805	Engine uppercarr. Actuation fan 2 cooling Current measured without actuation no reaction 304005: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2806	Engine uppercarr. Actuation fan 2 cooling Current too low in actuated state no reaction 304006: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2807	Engine uppercarr. Actuation fan 2 cooling Current too high in actuated state no reaction 304007: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2808	Engine uppercarr. Actuation fan 2 cooling Ground switch overcurrent no reaction 304008: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2809	Engine uppercarr. Actuation fan 2 cooling Plus switch overcurrent no reaction 304009: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B280A	Engine uppercarr. Actuation fan 2 cooling Maximum analog value exceeded (PWM) no reaction 304010: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2900	Engine uppercarr. Actuation fan 1 inverted cooling Broken wire or Short circuit after ground no reaction 304100: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2901	Engine uppercarr. Actuation fan 1 inverted cooling Broken wire or short circuit after supply voltage no reaction 304101: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2902	Engine uppercarr. Actuation fan 1 inverted cooling Hardware error (control unit defective) no reaction 304102: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2903	Engine uppercarr. Actuation fan 1 inverted cooling Maximum signal difference to actuation exceeded no reaction 304103: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2904	Engine uppercarr. Actuation fan 1 inverted cooling Maximum signal difference to actuation exceeded no reaction 304104: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2905	Engine uppercarr. Actuation fan 1 inverted cooling Current measured without actuation no reaction 304105: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2906	Engine uppercarr. Actuation fan 1 inverted cooling Current too low in actuated state no reaction 304106: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2907	Engine uppercarr. Actuation fan 1 inverted cooling Current too high in actuated state no reaction 304107: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2908	Engine uppercarr. Actuation fan 1 inverted cooling Ground switch overcurrent no reaction 304108: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2909	Engine uppercarr. Actuation fan 1 inverted cooling Plus switch overcurrent no reaction 304109: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B290A	Engine uppercarr. Actuation fan 1 inverted cooling Maximum analog value exceeded (PWM) no reaction 304110: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A00	Engine uppercarr. Actuation fan 2 inverted cooling Broken wire or Short circuit after ground no reaction 304200: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A01	Engine uppercarr. Actuation fan 2 inverted cooling Broken wire or short circuit after supply voltage no reaction 304201: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A02	Engine uppercarr. Actuation fan 2 inverted cooling Hardware error (control unit defective) no reaction 304202: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A03	Engine uppercarr. Actuation fan 2 inverted cooling Maximum signal difference to actuation exceeded no reaction 304203: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A04	Engine uppercarr. Actuation fan 2 inverted cooling Maximum signal difference to actuation exceeded no reaction 304204: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A05	Engine uppercarr. Actuation fan 2 inverted cooling Current measured without actuation no reaction 304205: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A06	Engine uppercarr. Actuation fan 2 inverted cooling Current too low in actuated state no reaction 304206: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A07	Engine uppercarr. Actuation fan 2 inverted cooling Current too high in actuated state no reaction 304207: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2A08	Engine uppercarr. Actuation fan 2 inverted cooling Ground switch overcurrent no reaction 304208: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A09	Engine uppercarr. Actuation fan 2 inverted cooling Plus switch overcurrent no reaction 304209: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2A0A	Engine uppercarr. Actuation fan 2 inverted cooling Maximum analog value exceeded (PWM) no reaction 304210: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B2B00	Engine uppercarr. Actuation Heat flange / Flame start Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304300: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B01	Engine uppercarr. Actuation Heat flange / Flame start Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304301: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B02	Engine uppercarr. Actuation Heat flange / Flame start Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304302: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B03	Engine uppercarr. Actuation Heat flange / Flame start Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304303: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B04	Engine uppercarr. Actuation Heat flange / Flame start Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304304: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B05	Engine uppercarr. Actuation Heat flange / Flame start Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304305: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B06	Engine uppercarr. Actuation Heat flange / Flame start Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304306: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2B07	Engine uppercarr. Actuation Heat flange / Flame start Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304307: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B08	Engine uppercarr. Actuation Heat flange / Flame start Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304308: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B09	Engine uppercarr. Actuation Heat flange / Flame start Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304309: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B0A	Engine uppercarr. Actuation Heat flange / Flame start Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304310: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B0B	Engine uppercarr. Actuation Heat flange / Flame start No voltage measured on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304311: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2B0C	Engine uppercarr. Actuation Heat flange / Flame start Voltage error on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304312: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C00	Engine uppercarr. Actuation Heat flange / Flame start 2 Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304400: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C01	Engine uppercarr. Actuation Heat flange / Flame start 2 Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304401: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C02	Engine uppercarr. Actuation Heat flange / Flame start 2 Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304402: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C03	Engine uppercarr. Actuation Heat flange / Flame start 2 Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304403: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2C04	Engine uppercarr. Actuation Heat flange / Flame start 2 Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304404: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C05	Engine uppercarr. Actuation Heat flange / Flame start 2 Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304405: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C06	Engine uppercarr. Actuation Heat flange / Flame start 2 Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304406: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C07	Engine uppercarr. Actuation Heat flange / Flame start 2 Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304407: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C08	Engine uppercarr. Actuation Heat flange / Flame start 2 Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304408: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C09	Engine uppercarr. Actuation Heat flange / Flame start 2 Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304409: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C0A	Engine uppercarr. Actuation Heat flange / Flame start 2 Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304410: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C0B	Engine uppercarr. Actuation Heat flange / Flame start 2 No voltage measured on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304411: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2C0C	Engine uppercarr. Actuation Heat flange / Flame start 2 Voltage error on heat element Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304412: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D00	Engine uppercarr. Actuation Solenoid valve Broken wire or Short circuit after ground Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304500: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2D01	Engine uppercarr. Actuation Solenoid valve Broken wire or short circuit after supply voltage Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304501: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D02	Engine uppercarr. Actuation Solenoid valve Hardware error (control unit defective) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304502: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D03	Engine uppercarr. Actuation Solenoid valve Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304503: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D04	Engine uppercarr. Actuation Solenoid valve Maximum signal difference to actuation exceeded Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304504: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D05	Engine uppercarr. Actuation Solenoid valve Current measured without actuation Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304505: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D06	Engine uppercarr. Actuation Solenoid valve Current too low in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304506: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D07	Engine uppercarr. Actuation Solenoid valve Current too high in actuated state Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304507: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D08	Engine uppercarr. Actuation Solenoid valve Ground switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304508: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D09	Engine uppercarr. Actuation Solenoid valve Plus switch overcurrent Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304509: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1
8B2D0A	Engine uppercarr. Actuation Solenoid valve Maximum analog value exceeded (PWM) Failure of pre-and after warm up phase only for flame start system, otherwise no reaction 304510: Check wiring harness, plug, heat flange or glow plug unit, external relay, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2E00	Engine uppercarr. Actuation Air flap Broken wire or Short circuit after ground no reaction 304600: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E01	Engine uppercarr. Actuation Air flap Broken wire or short circuit after supply voltage no reaction 304601: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E02	Engine uppercarr. Actuation Air flap Hardware error (control unit defective) no reaction 304602: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E03	Engine uppercarr. Actuation Air flap Maximum signal difference to actuation exceeded no reaction 304603: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E04	Engine uppercarr. Actuation Air flap Maximum signal difference to actuation exceeded no reaction 304604: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E05	Engine uppercarr. Actuation Air flap Current measured without actuation no reaction 304605: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E06	Engine uppercarr. Actuation Air flap Current too low in actuated state no reaction 304606: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E07	Engine uppercarr. Actuation Air flap Current too high in actuated state no reaction 304607: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E08	Engine uppercarr. Actuation Air flap Ground switch overcurrent no reaction 304608: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2E09	Engine uppercarr. Actuation Air flap Plus switch overcurrent no reaction 304609: Check wiring harness, plug, air flap, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2E0A	Engine uppercarr. Actuation Air flap Maximum analog value exceeded (PWM) no reaction 304610: Check wiring harness, plug, air flap, engine control unit	A750		E	1
8B2F00	Engine uppercarr. Actuation Turbocharger Broken wire or Short circuit after ground No reaction, change over to OL 304700: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F01	Engine uppercarr. Actuation Turbocharger Broken wire or short circuit after supply voltage No reaction, change over to OL 304701: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F02	Engine uppercarr. Actuation Turbocharger Hardware error (control unit defective) No reaction, change over to OL 304702: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F03	Engine uppercarr. Actuation Turbocharger Maximum signal difference to actuation exceeded No reaction, change over to OL 304703: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F04	Engine uppercarr. Actuation Turbocharger Maximum signal difference to actuation exceeded No reaction, change over to OL 304704: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F05	Engine uppercarr. Actuation Turbocharger Current measured without actuation No reaction, change over to OL 304705: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F06	Engine uppercarr. Actuation Turbocharger Current too low in actuated state No reaction, change over to OL 304706: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F07	Engine uppercarr. Actuation Turbocharger Current too high in actuated state No reaction, change over to OL 304707: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F08	Engine uppercarr. Actuation Turbocharger Ground switch overcurrent No reaction, change over to OL 304708: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B2F09	Engine uppercarr. Actuation Turbocharger Plus switch overcurrent No reaction, change over to OL 304709: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B2F0A	Engine uppercarr. Actuation Turbocharger Maximum analog value exceeded (PWM) No reaction, change over to OL 304710: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3000	Engine uppercarr. Actuation Turbocharger 2 Broken wire or Short circuit after ground No reaction, change over to OL 304800: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3001	Engine uppercarr. Actuation Turbocharger 2 Broken wire or short circuit after supply voltage No reaction, change over to OL 304801: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3002	Engine uppercarr. Actuation Turbocharger 2 Hardware error (control unit defective) No reaction, change over to OL 304802: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3003	Engine uppercarr. Actuation Turbocharger 2 Maximum signal difference to actuation exceeded No reaction, change over to OL 304803: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3004	Engine uppercarr. Actuation Turbocharger 2 Maximum signal difference to actuation exceeded No reaction, change over to OL 304804: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3005	Engine uppercarr. Actuation Turbocharger 2 Current measured without actuation No reaction, change over to OL 304805: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3006	Engine uppercarr. Actuation Turbocharger 2 Current too low in actuated state No reaction, change over to OL 304806: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3007	Engine uppercarr. Actuation Turbocharger 2 Current too high in actuated state No reaction, change over to OL 304807: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3008	Engine uppercarr. Actuation Turbocharger 2 Ground switch overcurrent No reaction, change over to OL 304808: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3009	Engine uppercarr. Actuation Turbocharger 2 Plus switch overcurrent No reaction, change over to OL 304809: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B300A	Engine uppercarr. Actuation Turbocharger 2 Maximum analog value exceeded (PWM) No reaction, change over to OL 304810: Check wiring harness, plug, solenoid v. turbocharger, engine control unit	A750		E	1
8B3100	Engine uppercarr. Actuation AGR 1 Broken wire or Short circuit after ground Function engine brake flap deactivated 304900: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3101	Engine uppercarr. Actuation AGR 1 Broken wire or short circuit after supply voltage Function engine brake flap deactivated 304901: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3102	Engine uppercarr. Actuation AGR 1 Hardware error (control unit defective) Function engine brake flap deactivated 304902: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3103	Engine uppercarr. Actuation AGR 1 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 304903: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3104	Engine uppercarr. Actuation AGR 1 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 304904: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3105	Engine uppercarr. Actuation AGR 1 Current measured without actuation Function engine brake flap deactivated 304905: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3106	Engine uppercarr. Actuation AGR 1 Current too low in actuated state Function engine brake flap deactivated 304906: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3107	Engine uppercarr. Actuation AGR 1 Current too high in actuated state Function engine brake flap deactivated 304907: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B310B	Engine uppercarr. Actuation AGR 1 Deviation error, AGR open too wide Function engine brake flap deactivated 304911: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B310C	Engine uppercarr. Actuation AGR 1 Deviation error, AGR open too little Function engine brake flap deactivated 304912: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B310D	Engine uppercarr. Actuation AGR 1 Error in CAN-Module AGR Function engine brake flap deactivated 304913: Check wiring harness, plug, AGR1-valve, engine control unit	A750		E	1
8B3200	Engine uppercarr. Actuation AGR 2 Broken wire or Short circuit after ground Function engine brake flap deactivated 305000: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3201	Engine uppercarr. Actuation AGR 2 Broken wire or short circuit after supply voltage Function engine brake flap deactivated 305001: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3202	Engine uppercarr. Actuation AGR 2 Hardware error (control unit defective) Function engine brake flap deactivated 305002: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3203	Engine uppercarr. Actuation AGR 2 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 305003: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3204	Engine uppercarr. Actuation AGR 2 Maximum signal difference to actuation exceeded Function engine brake flap deactivated 305004: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3205	Engine uppercarr. Actuation AGR 2 Current measured without actuation Function engine brake flap deactivated 305005: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3206	Engine uppercarr. Actuation AGR 2 Current too low in actuated state Function engine brake flap deactivated 305006: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3207	Engine uppercarr. Actuation AGR 2 Current too high in actuated state Function engine brake flap deactivated 305007: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B320B	Engine uppercarr. Actuation AGR 2 Deviation error, AGR open too wide Function engine brake flap deactivated 305011: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B320C	Engine uppercarr. Actuation AGR 2 Deviation error, AGR open too little Function engine brake flap deactivated 305012: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B320D	Engine uppercarr. Actuation AGR 2 Error in CAN-Module AGR Function engine brake flap deactivated 305013: Check wiring harness, plug, AGR2-valve, engine control unit	A750		E	1
8B3300	Engine uppercarr. Lamp emerg. oper Broken wire or Short circuit after ground No reaction, status is not shown 305100: Check wiring	A750		E	1
8B3301	Engine uppercarr. Lamp emerg. oper Broken wire or short circuit after supply voltage No reaction, status is not shown 305101: Check wiring	A750		E	1
8B3302	Engine uppercarr. Lamp emerg. oper Hardware error (control unit defective) No reaction, status is not shown 305102: Check wiring	A750		E	1
8B3303	Engine uppercarr. Lamp emerg. oper Maximum signal difference to actuation exceeded No reaction, status is not shown 305103: Check wiring	A750		E	1
8B3304	Engine uppercarr. Lamp emerg. oper Maximum signal difference to actuation exceeded No reaction, status is not shown 305104: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3305	Engine uppercarr. Lamp emerg. oper Current measured without actuation No reaction, status is not shown 305105: Check wiring	A750		E	1
8B3306	Engine uppercarr. Lamp emerg. oper Current too low in actuated state No reaction, status is not shown 305106: Check wiring	A750		E	1
8B3307	Engine uppercarr. Lamp emerg. oper Current too high in actuated state No reaction, status is not shown 305107: Check wiring	A750		E	1
8B3308	Engine uppercarr. Lamp emerg. oper Ground switch overcurrent No reaction, status is not shown 305108: Check wiring	A750		E	1
8B3309	Engine uppercarr. Lamp emerg. oper Plus switch overcurrent No reaction, status is not shown 305109: Check wiring	A750		E	1
8B330A	Engine uppercarr. Lamp emerg. oper Maximum analog value exceeded (PWM) No reaction, status is not shown 305110: Check wiring	A750		E	1
8B3400	Engine uppercarr. Lamp cold start / Start readiness Broken wire or Short circuit after ground No reaction, status is not shown 305200: Check wiring	A750		E	1
8B3401	Engine uppercarr. Lamp cold start / Start readiness Broken wire or short circuit after supply voltage No reaction, status is not shown 305201: Check wiring	A750		E	1
8B3402	Engine uppercarr. Lamp cold start / Start readiness Hardware error (control unit defective) No reaction, status is not shown 305202: Check wiring	A750		E	1
8B3403	Engine uppercarr. Lamp cold start / Start readiness Maximum signal difference to actuation exceeded No reaction, status is not shown 305203: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3404	Engine uppercarr. Lamp cold start / Start readiness Maximum signal difference to actuation exceeded No reaction, status is not shown 305204: Check wiring	A750		E	1
8B3405	Engine uppercarr. Lamp cold start / Start readiness Current measured without actuation No reaction, status is not shown 305205: Check wiring	A750		E	1
8B3406	Engine uppercarr. Lamp cold start / Start readiness Current too low in actuated state No reaction, status is not shown 305206: Check wiring	A750		E	1
8B3407	Engine uppercarr. Lamp cold start / Start readiness Current too high in actuated state No reaction, status is not shown 305207: Check wiring	A750		E	1
8B3408	Engine uppercarr. Lamp cold start / Start readiness Ground switch overcurrent No reaction, status is not shown 305208: Check wiring	A750		E	1
8B3409	Engine uppercarr. Lamp cold start / Start readiness Plus switch overcurrent No reaction, status is not shown 305209: Check wiring	A750		E	1
8B340A	Engine uppercarr. Lamp cold start / Start readiness Maximum analog value exceeded (PWM) No reaction, status is not shown 305210: Check wiring	A750		E	1
8B3500	Engine uppercarr. Request engine stop Broken wire or Short circuit after ground No reaction, status is not shown 305300: Check wiring	A750		E	1
8B3501	Engine uppercarr. Request engine stop Broken wire or short circuit after supply voltage No reaction, status is not shown 305301: Check wiring	A750		E	1
8B3502	Engine uppercarr. Request engine stop Hardware error (control unit defective) No reaction, status is not shown 305302: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3503	Engine uppercarr. Request engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305303: Check wiring	A750		E	1
8B3504	Engine uppercarr. Request engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305304: Check wiring	A750		E	1
8B3505	Engine uppercarr. Request engine stop Current measured without actuation no reaction 305305: Check wiring	A750		E	1
8B3506	Engine uppercarr. Request engine stop Current too low in actuated state No reaction, status is not shown 305306: Check wiring	A750		E	1
8B3507	Engine uppercarr. Request engine stop Current too high in actuated state No reaction, status is not shown 305307: Check wiring	A750		E	1
8B3508	Engine uppercarr. Request engine stop Ground switch overcurrent No reaction, status is not shown 305308: Check wiring	A750		E	1
8B3509	Engine uppercarr. Request engine stop Plus switch overcurrent No reaction, status is not shown 305309: Check wiring	A750		E	1
8B350A	Engine uppercarr. Request engine stop Maximum analog value exceeded (PWM) No reaction, status is not shown 305310: Check wiring	A750		E	1
8B3600	Engine uppercarr. Outlet engine running Broken wire or Short circuit after ground No reaction, status is not shown 305400: Check wiring	A750		E	1
8B3601	Engine uppercarr. Outlet engine running Broken wire or short circuit after supply voltage No reaction, status is not shown 305401: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3602	Engine uppercarr. Outlet engine running Hardware error (control unit defective) No reaction, status is not shown 305402: Check wiring	A750		E	1
8B3603	Engine uppercarr. Outlet engine running Maximum signal difference to actuation exceeded No reaction, status is not shown 305403: Check wiring	A750		E	1
8B3604	Engine uppercarr. Outlet engine running Maximum signal difference to actuation exceeded No reaction, status is not shown 305404: Check wiring	A750		E	1
8B3605	Engine uppercarr. Outlet engine running Current measured without actuation No reaction, status is not shown 305405: Check wiring	A750		E	1
8B3606	Engine uppercarr. Outlet engine running Current too low in actuated state No reaction, status is not shown 305406: Check wiring	A750		E	1
8B3607	Engine uppercarr. Outlet engine running Current too high in actuated state No reaction, status is not shown 305407: Check wiring	A750		E	1
8B3608	Engine uppercarr. Outlet engine running Ground switch overcurrent No reaction, status is not shown 305408: Check wiring	A750		E	1
8B3609	Engine uppercarr. Outlet engine running Plus switch overcurrent No reaction, status is not shown 305409: Check wiring	A750		E	1
8B360A	Engine uppercarr. Outlet engine running Maximum analog value exceeded (PWM) No reaction, status is not shown 305410: Check wiring	A750		E	1
8B3700	Engine uppercarr. Display engine stop Broken wire or Short circuit after ground No reaction, status is not shown 305500: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3701	Engine uppercarr. Display engine stop Broken wire or short circuit after supply voltage No reaction, status is not shown 305501: Check wiring	A750		E	1
8B3702	Engine uppercarr. Display engine stop Hardware error (control unit defective) No reaction, status is not shown 305502: Check wiring	A750		E	1
8B3703	Engine uppercarr. Display engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305503: Check wiring	A750		E	1
8B3704	Engine uppercarr. Display engine stop Maximum signal difference to actuation exceeded No reaction, status is not shown 305504: Check wiring	A750		E	1
8B3705	Engine uppercarr. Display engine stop Current measured without actuation No reaction, status is not shown 305505: Check wiring	A750		E	1
8B3706	Engine uppercarr. Display engine stop Current too low in actuated state No reaction, status is not shown 305506: Check wiring	A750		E	1
8B3707	Engine uppercarr. Display engine stop Current too high in actuated state No reaction, status is not shown 305507: Check wiring	A750		E	1
8B3708	Engine uppercarr. Display engine stop Ground switch overcurrent No reaction, status is not shown 305508: Check wiring	A750		E	1
8B3709	Engine uppercarr. Display engine stop Plus switch overcurrent No reaction, status is not shown 305509: Check wiring	A750		E	1
8B370A	Engine uppercarr. Display engine stop Maximum analog value exceeded (PWM) No reaction, status is not shown 305510: Check wiring	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3800	Engine uppercarr. DAREversible fan Broken wire or Short circuit after ground The reversible fan control 1 is not actuated 305600: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3801	Engine uppercarr. DAREversible fan Broken wire or short circuit after supply voltage The reversible fan control 1 is not actuated 305601: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3802	Engine uppercarr. DAREversible fan Hardware error (control unit defective) The reversible fan control 1 is not actuated 305602: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3803	Engine uppercarr. DAREversible fan Maximum signal difference to actuation exceeded The reversible fan control 1 is not actuated 305603: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3804	Engine uppercarr. DAREversible fan Maximum signal difference to actuation exceeded The reversible fan control 1 is not actuated 305604: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3805	Engine uppercarr. DAREversible fan Current measured without actuation The reversible fan control 1 is not actuated 305605: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3806	Engine uppercarr. DAREversible fan Current too low in actuated state The reversible fan control 1 is not actuated 305606: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3807	Engine uppercarr. DAREversible fan Current too high in actuated state The reversible fan control 1 is not actuated 305607: Check wiring harness, plug, fan prop. valve, engine control unit	A750		E	1
8B3900	Engine uppercarr. Outlet engine rpm Broken wire or Short circuit after ground no reaction 305700:	A750		E	0
8B3901	Engine uppercarr. Outlet engine rpm Broken wire or short circuit after supply voltage no reaction 305701:	A750		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3A00	Engine uppercarr. Outlet engine off Broken wire or Short circuit after ground no reaction 305800: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A01	Engine uppercarr. Outlet engine off Broken wire or short circuit after supply voltage no reaction 305801: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A02	Engine uppercarr. Outlet engine off Error on hardware recognized no reaction 305802: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A03	Engine uppercarr. Outlet engine off Regulating deviation negative too high no reaction 305803: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A04	Engine uppercarr. Outlet engine off Regulating deviation positive too high no reaction 305804: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A05	Engine uppercarr. Outlet engine off Current in shut off status too high no reaction 305805: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A06	Engine uppercarr. Outlet engine off Current too low no reaction 305806: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A07	Engine uppercarr. Outlet engine off Current too high no reaction 305807: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A08	Engine uppercarr. Outlet engine off Current on ground switch too high no reaction 305808: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3A09	Engine uppercarr. Outlet engine off Current on plus switch too high no reaction 305809: Check wiring, engine control unit and unit connected to this unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3A0A	Engine uppercarr. Outlet engine off Pulse width (PWM) on maximum no reaction 305810: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B00	Engine uppercarr. Output warning signal (Amber Warning) Broken wire or Short circuit after ground no reaction 305900: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B01	Engine uppercarr. Output warning signal (Amber Warning) Broken wire or short circuit after supply voltage no reaction 305901: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B02	Engine uppercarr. Output warning signal (Amber Warning) Error on hardware recognized no reaction 305902: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B03	Engine uppercarr. Output warning signal (Amber Warning) Regulating deviation negative too high no reaction 305903: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B04	Engine uppercarr. Output warning signal (Amber Warning) Regulating deviation positive too high no reaction 305904: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B05	Engine uppercarr. Output warning signal (Amber Warning) Current in shut off status too high no reaction 305905: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B06	Engine uppercarr. Output warning signal (Amber Warning) Current too low no reaction 305906: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B07	Engine uppercarr. Output warning signal (Amber Warning) Current too high no reaction 305907: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3B08	Engine uppercarr. Output warning signal (Amber Warning) Current on ground switch too high no reaction 305908: Check wiring, engine control unit and unit connected to this unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3B09	Engine uppercarr. Output warning signal (Amber Warning) Current on plus switch too high no reaction 305909: Check wiring, engine control unit and unit connected to this unit	A750		E	1
8B3C00	Engine uppercarr. Mass flow sensor 1 Temperature sensor erroneous Possibly power reduction 306000: Replace sensor	A750		E	1
8B3C01	Engine uppercarr. Mass flow sensor 1 Absolute pressure sensor erroneous Possibly power reduction 306001: Replace sensor	A750		E	1
8B3C02	Engine uppercarr. Mass flow sensor 1 Differential pressure sensor erroneous Possibly power reduction 306002: Replace sensor	A750		E	1
8B3C03	Engine uppercarr. Mass flow sensor 1 excess temperature Change over to 2nd Lambda Signal 306003: Replace sensor	A750		E	1
8B3C0A	Engine uppercarr. Mass flow sensor 1 Ground current signal 1 implausible, detection at high ground current Warning light on 306010: Clean sensor or replace	A750		E	1
8B3C0B	Engine uppercarr. Mass flow sensor 1 Ground current signal 1 implausible, detection at low ground current Warning light on 306011: Clean sensor or replace	A750		E	1
8B3D00	Engine uppercarr. Mass flow sensor 2 Temperature sensor erroneous Possibly power reduction 306100: Replace sensor	A750		E	1
8B3D01	Engine uppercarr. Mass flow sensor 2 Absolute pressure sensor erroneous Possibly power reduction 306101: Replace sensor	A750		E	1
8B3D02	Engine uppercarr. Mass flow sensor 2 Differential pressure sensor erroneous Possibly power reduction 306102: Replace sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B3D03	Engine uppercarr. Mass flow sensor 2 excess temperature Change over to 2nd Lambda Signal 306103: Replace sensor	A750		E	1
8B3D0A	Engine uppercarr. Mass flow sensor 2 Ground current signal 1 implausible, detection at high ground current Warning light on 306110: Clean sensor or replace	A750		E	1
8B3D0B	Engine uppercarr. Mass flow sensor 2 Ground current signal 1 implausible, detection at low ground current Warning light on 306111: Clean sensor or replace	A750		E	1
8B3E00	Engine uppercarr. NOx sensor "Up 1" Open line No Lambda correction - possibly power reduction 306200: Replace sensor	A750		E	1
8B3E01	Engine uppercarr. NOx sensor "Up 1" Short circuit No Lambda correction - possibly power reduction 306201: Replace sensor	A750		E	1
8B3E0A	Engine uppercarr. NOx sensor "Up 1" Value implausible Warning light on 306210: Replace sensor	A750		E	1
8B3F00	Engine uppercarr. NOx sensor "Down 1" Open line No Lambda correction - possibly power reduction 306300: Replace sensor	A750		E	1
8B3F01	Engine uppercarr. NOx sensor "Down 1" Short circuit No Lambda correction - possibly power reduction 306301: Replace sensor	A750		E	1
8B4000	Engine uppercarr. NOx sensor "Up 2" Open line No Lambda correction - possibly power reduction 306400: Replace sensor	A750		E	1
8B4001	Engine uppercarr. NOx sensor "Up 2" Short circuit No Lambda correction - possibly power reduction 306401: Replace sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4100	Engine uppercarr. NOx sensor "Down 2" Open line No Lambda correction - possibly power reduction 306500: Replace sensor	A750		E	1
8B4101	Engine uppercarr. NOx sensor "Down 2" Short circuit No Lambda correction - possibly power reduction 306501: Replace sensor	A750		E	1
8B4200	Engine uppercarr. Water pump maximum rpm deviation exceeded no reaction 306600: Check wiring harness, plug, conn. Modul	A750		E	1
8B4300	Engine uppercarr. EGR-valve 1 excess temperature Power reduction of Diesel engine 306700: Check cooling module	A750		E	1
8B4301	Engine uppercarr. EGR-valve 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 306701: Check module: linkage, flap	A750		E	1
8B4302	Engine uppercarr. EGR-valve 1 Data communication CAN faulty Power reduction of Diesel engine 306702: Check wiring, Module	A750		E	1
8B4303	Engine uppercarr. EGR-valve 1 Data communication CAN interrupted Power reduction of Diesel engine 306703: Check wiring, Module	A750		E	1
8B4304	Engine uppercarr. EGR-valve 1 Spring erroneous Power reduction of Diesel engine 306704: Replace module	A750		E	1
8B4305	Engine uppercarr. EGR-valve 1 Gear erroneous Power reduction of Diesel engine 306705: Replace module	A750		E	1
8B4306	Engine uppercarr. EGR-valve 1 steering device error Power reduction of Diesel engine 306706: Replace module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4307	Engine uppercarr. EGR-valve 1 Absolute position sensor erroneous Power reduction of Diesel engine 306707: Replace module	A750		E	1
8B4309	Engine uppercarr. EGR-valve 1 Calibration procedure erroneous Power reduction of Diesel engine 306709: Check module: linkage, flap	A750		E	1
8B430A	Engine uppercarr. EGR-valve 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306710: Check module: linkage, flap	A750		E	1
8B430B	Engine uppercarr. EGR-valve 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306711: Check wiring alternator (D+) to battery or engine control unit, alternator	A750		E	1
8B430C	Engine uppercarr. EGR-valve 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306712: Check module: linkage, flap	A750		E	1
8B430D	Engine uppercarr. EGR-valve 1 Reference to zero point erroneous Power reduction of Diesel engine 306713: Check module: linkage, flap	A750		E	1
8B4400	Engine uppercarr. EGR-valve 2 excess temperature Power reduction of Diesel engine 306800: Check cooling module	A750		E	1
8B4401	Engine uppercarr. EGR-valve 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 306801: Check module: linkage, flap	A750		E	1
8B4402	Engine uppercarr. EGR-valve 2 Data communication CAN faulty Power reduction of Diesel engine 306802: Check wiring, Module	A750		E	1
8B4403	Engine uppercarr. EGR-valve 2 Data communication CAN interrupted Power reduction of Diesel engine 306803: Check wiring, Module pruefen	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4404	Engine uppercarr. EGR-valve 2 Spring erroneous Power reduction of Diesel engine 306804: Replace module	A750		E	1
8B4405	Engine uppercarr. EGR-valve 2 Gear erroneous Power reduction of Diesel engine 306805: Replace module	A750		E	1
8B4406	Engine uppercarr. EGR-valve 2 steering device error Power reduction of Diesel engine 306806: Replace module	A750		E	1
8B4407	Engine uppercarr. EGR-valve 2 Absolute position sensor erroneous Power reduction of Diesel engine 306807: Replace module	A750		E	1
8B4409	Engine uppercarr. EGR-valve 2 Calibration procedure erroneous Power reduction of Diesel engine 306809: Check module: linkage, flap	A750		E	1
8B440A	Engine uppercarr. EGR-valve 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306810: Check module: linkage, flap	A750		E	1
8B440B	Engine uppercarr. EGR-valve 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306811: Check wiring alternator (D+) to battery or engine control unit, alternator	A750		E	1
8B440C	Engine uppercarr. EGR-valve 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306812: Check module: linkage, flap	A750		E	1
8B440D	Engine uppercarr. EGR-valve 2 Reference to zero point erroneous Power reduction of Diesel engine 306813: Check module: linkage, flap	A750		E	1
8B4500	Engine uppercarr. WG-valve 1 excess temperature Power reduction of Diesel engine 306900: Check cooling module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4501	Engine uppercarr. WG-valve 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 306901: Check module: linkage, flap	A750		E	1
8B4502	Engine uppercarr. WG-valve 1 Data communication CAN faulty Power reduction of Diesel engine 306902: Check wiring, Module pruefen	A750		E	1
8B4503	Engine uppercarr. WG-valve 1 Data communication CAN interrupted Power reduction of Diesel engine 306903: Check wiring, Module pruefen	A750		E	1
8B4504	Engine uppercarr. WG-valve 1 Spring erroneous Power reduction of Diesel engine 306904: Replace module	A750		E	1
8B4505	Engine uppercarr. WG-valve 1 Gear erroneous Power reduction of Diesel engine 306905: Replace module	A750		E	1
8B4506	Engine uppercarr. WG-valve 1 steering device error Power reduction of Diesel engine 306906: Replace module	A750		E	1
8B4507	Engine uppercarr. WG-valve 1 Absolute position sensor erroneous Power reduction of Diesel engine 306907: Replace module	A750		E	1
8B4509	Engine uppercarr. WG-valve 1 Calibration procedure erroneous Power reduction of Diesel engine 306909: Check module: linkage, flap	A750		E	1
8B450A	Engine uppercarr. WG-valve 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 306910: Check module: linkage, flap	A750		E	1
8B450B	Engine uppercarr. WG-valve 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 306911: Check wiring alternator (D+) to battery or engine control unit, alternator	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B450C	Engine uppercarr. WG-valve 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 306912: Check module: linkage, flap	A750		E	1
8B450D	Engine uppercarr. WG-valve 1 Reference to zero point erroneous Power reduction of Diesel engine 306913: Check module: linkage, flap	A750		E	1
8B4600	Engine uppercarr. WG-valve 2 excess temperature Power reduction of Diesel engine 307000: Check cooling module	A750		E	1
8B4601	Engine uppercarr. WG-valve 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 307001: Check module: linkage, flap	A750		E	1
8B4602	Engine uppercarr. WG-valve 2 Data communication CAN faulty Power reduction of Diesel engine 307002: Check wiring, module	A750		E	1
8B4603	Engine uppercarr. WG-valve 2 Data communication CAN interrupted Power reduction of Diesel engine 307003: Check wiring, Module pruefen	A750		E	1
8B4604	Engine uppercarr. WG-valve 2 Spring erroneous Power reduction of Diesel engine 307004: Replace module	A750		E	1
8B4605	Engine uppercarr. WG-valve 2 Gear erroneous Power reduction of Diesel engine 307005: Replace module	A750		E	1
8B4606	Engine uppercarr. WG-valve 2 steering device error Power reduction of Diesel engine 307006: Replace module	A750		E	1
8B4607	Engine uppercarr. WG-valve 2 Absolute position sensor erroneous Power reduction of Diesel engine 307007: Replace module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4609	Engine uppercarr. WG-valve 2 Calibration procedure erroneous Power reduction of Diesel engine 307009: Check module: linkage, flap	A750		E	1
8B460A	Engine uppercarr. WG-valve 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307010: Check module: linkage, flap	A750		E	1
8B460B	Engine uppercarr. WG-valve 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307011: Check wiring alternator (D+) to battery or engine control unit, alternator	A750		E	1
8B460C	Engine uppercarr. WG-valve 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307012: Check module: linkage, flap	A750		E	1
8B460D	Engine uppercarr. WG-valve 2 Reference to zero point erroneous Power reduction of Diesel engine 307013: Check module: linkage, flap	A750		E	1
8B4700	Engine uppercarr. Restrictor flap 1 excess temperature Power reduction of Diesel engine 307100: Check cooling module	A750		E	1
8B4701	Engine uppercarr. Restrictor flap 1 Permissible regulator deviation exceeded Power reduction of Diesel engine 307101: Check module: linkage, flap	A750		E	1
8B4702	Engine uppercarr. Restrictor flap 1 Data communication CAN faulty Power reduction of Diesel engine 307102: Check wiring, Module pruefen	A750		E	1
8B4703	Engine uppercarr. Restrictor flap 1 Data communication CAN interrupted Power reduction of Diesel engine 307103: Check wiring, Module pruefen	A750		E	1
8B4704	Engine uppercarr. Restrictor flap 1 Spring erroneous Power reduction of Diesel engine 307104: Replace module	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4705	Engine uppercarr. Restrictor flap 1 Gear erroneous Power reduction of Diesel engine 307105: Replace module	A750		E	1
8B4706	Engine uppercarr. Restrictor flap 1 steering device error Power reduction of Diesel engine 307106: Replace module	A750		E	1
8B4707	Engine uppercarr. Restrictor flap 1 Absolute position sensor erroneous Power reduction of Diesel engine 307107: Replace module	A750		E	1
8B4709	Engine uppercarr. Restrictor flap 1 Calibration procedure erroneous Power reduction of Diesel engine 307109: Check module: linkage, flap	A750		E	1
8B470A	Engine uppercarr. Restrictor flap 1 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307110: Check module: linkage, flap	A750		E	1
8B470B	Engine uppercarr. Restrictor flap 1 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307111: Check wiring alternator (D+) to battery or engine control unit, alternator	A750		E	1
8B470C	Engine uppercarr. Restrictor flap 1 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307112: Check module: linkage, flap	A750		E	1
8B470D	Engine uppercarr. Restrictor flap 1 Reference to zero point erroneous Power reduction of Diesel engine 307113: Check module: linkage, flap	A750		E	1
8B4800	Engine uppercarr. Restrictor flap 2 excess temperature Power reduction of Diesel engine 307200: Check cooling module	A750		E	1
8B4801	Engine uppercarr. Restrictor flap 2 Permissible regulator deviation exceeded Power reduction of Diesel engine 307201: Check module: linkage, flap	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4802	Engine uppercarr. Restrictor flap 2 Data communication CAN faulty Power reduction of Diesel engine 307202: Check wiring, modules	A750		E	1
8B4803	Engine uppercarr. Restrictor flap 2 Data communication CAN interrupted Power reduction of Diesel engine 307203: Check wiring, Module pruefen	A750		E	1
8B4804	Engine uppercarr. Restrictor flap 2 Spring erroneous Power reduction of Diesel engine 307204: Replace module	A750		E	1
8B4805	Engine uppercarr. Restrictor flap 2 Gear erroneous Power reduction of Diesel engine 307205: Replace module	A750		E	1
8B4806	Engine uppercarr. Restrictor flap 2 steering device error Power reduction of Diesel engine 307206: Replace module	A750		E	1
8B4807	Engine uppercarr. Restrictor flap 2 Absolute position sensor erroneous Power reduction of Diesel engine 307207: Replace module	A750		E	1
8B4809	Engine uppercarr. Restrictor flap 2 Calibration procedure erroneous Power reduction of Diesel engine 307209: Check module: linkage, flap	A750		E	1
8B480A	Engine uppercarr. Restrictor flap 2 Teach in procedure erroneous (downward) Power reduction of Diesel engine 307210: Check module: linkage, flap	A750		E	1
8B480B	Engine uppercarr. Restrictor flap 2 Supply voltage over / undervoltage recognized Power reduction of Diesel engine 307211: Check wiring alternator (D+) to battery or engine control unit, alternator	A750		E	1
8B480C	Engine uppercarr. Restrictor flap 2 Teach in procedure erroneous (upward) Power reduction of Diesel engine 307212: Check module: linkage, flap	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B480D	Engine uppercarr. Restrictor flap 2 Reference to zero point erroneous Power reduction of Diesel engine 307213: Check module: linkage, flap	A750		E	1
8B4900	Engine uppercarr. Relay outlet, sensors, actuators Line interruption or short circuit after ground 307300: Check wiring and control units	A750		E	1
8B4901	Engine uppercarr. Relay outlet, sensors, actuators Line interruption or short circuit after supply voltage 307301: Check wiring and control units	A750		E	1
8B4905	Engine uppercarr. Relay outlet, sensors, actuators Current too high in turned off status 307305: Check wiring and control units	A750		E	1
8B4906	Engine uppercarr. Relay outlet, sensors, actuators Current too low in turned off status 307306: Check wiring and control units	A750		E	1
8B4907	Engine uppercarr. Relay outlet, sensors, actuators Current too high in actuated status 307307: Check wiring and control units	A750		E	1
8B4A00	Engine uppercarr. Error machine Emerg. stop actuated, line interruption or short circuit after ground Engine stop 307400: Emerg. stop actuated, check wiring and emerg. stop button	A750		E	1
8B4B00	Engine uppercarr. Travel pedal Short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307500: Check wiring engine control unit/travel pedal sensor 1 (broken wire or short circuit after ground)	A750		E	1
8B4B01	Engine uppercarr. Travel pedal Sensor signal short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307501: Check wiring engine control unit/travel pedal sensor 1 (short circuit after batt. volt.)	A750		E	1
8B4B02	Engine uppercarr. Travel pedal Sensor supply voltage short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307502: Check wiring engine control unit/travel pedal sensor 1 (short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4B03	Engine uppercarr. Travel pedal Sensor supply voltage short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307503: Check wiring engine control unit/travel pedal sensor 1 (short circuit after batt. volt.)	A750		E	1
8B4B04	Engine uppercarr. Travel pedal Sensor signal outside permissible range 1 Remains at low idle when both travel pedal sensors failed 307504: Check operational status of engine	A750		E	1
8B4B05	Engine uppercarr. Travel pedal Sensor signal outside permissible range 2 Remains at low idle when both travel pedal sensors failed 307505: Check operational status of engine	A750		E	1
8B4B06	Engine uppercarr. Travel pedal Plausibility error at engine off no reaction 307506: Check wiring engine control unit/sensor	A750		E	1
8B4C00	Engine uppercarr. accelerator 2 Short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307600: Check wiring engine control unit/travel pedal sensor 2 (broken wire or short circuit after ground)	A750		E	1
8B4C01	Engine uppercarr. accelerator 2 Sensor signal short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307601: Check wiring engine control unit/travel pedal sensor 2 (short circuit after batt. volt.)	A750		E	1
8B4C02	Engine uppercarr. accelerator 2 Sensor supply voltage short circuit after ground or broken wire Remains at low idle when both travel pedal sensors failed 307602: Check wiring engine control unit/travel pedal sensor 2 (short circuit after ground)	A750		E	1
8B4C03	Engine uppercarr. accelerator 2 Sensor supply voltage short circuit after supply voltage Remains at low idle when both travel pedal sensors failed 307603: Check wiring engine control unit/travel pedal sensor 2 (short circuit after batt. volt.)	A750		E	1
8B4C04	Engine uppercarr. accelerator 2 Sensor signal outside permissible range 1 Remains at low idle when both travel pedal sensors failed 307604: Check operational status of engine	A750		E	1
8B4C05	Engine uppercarr. accelerator 2 Sensor signal outside permissible range 2 Remains at low idle when both travel pedal sensors failed 307605: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4C06	Engine uppercarr. accelerator 2 Plausibility error at engine off no reaction 307606: Check wiring engine control unit/sensor	A750		E	1
8B4D00	Engine uppercarr. Fill level sensor Urea tank Short circuit after ground or broken wire Use of replacement value 307700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B4D01	Engine uppercarr. Fill level sensor Urea tank Sensor signal short circuit after supply voltage Use of replacement value 307701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4D02	Engine uppercarr. Fill level sensor Urea tank Sensor supply voltage short circuit after ground or broken wire Use of replacement value 307702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B4D03	Engine uppercarr. Fill level sensor Urea tank Sensor supply voltage short circuit after supply voltage Use of replacement value 307703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4D04	Engine uppercarr. Fill level sensor Urea tank Sensor signal outside permissible range 1 no reaction 307704: Ureastand	A750		E	1
8B4D05	Engine uppercarr. Fill level sensor Urea tank Sensor signal outside permissible range 2 no reaction 307705: Ureastand	A750		E	1
8B4D06	Engine uppercarr. Fill level sensor Urea tank Plausibility error at engine off no reaction 307706: Check wiring engine control unit/sensor	A750		E	1
8B4E00	Engine uppercarr. Fill level sensor engine oil Short circuit after ground or broken wire Use of replacement value 307800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B4E01	Engine uppercarr. Fill level sensor engine oil Sensor signal short circuit after supply voltage Use of replacement value 307801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4E02	Engine uppercarr. Fill level sensor engine oil Sensor supply voltage short circuit after ground or broken wire Use of replacement value 307802: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B4E03	Engine uppercarr. Fill level sensor engine oil Sensor supply voltage short circuit after supply voltage Use of replacement value 307803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4E04	Engine uppercarr. Fill level sensor engine oil Sensor signal outside permissible range 1 no reaction 307804: Oil level, oil level sensor	A750		E	1
8B4E05	Engine uppercarr. Fill level sensor engine oil Sensor signal outside permissible range 2 no reaction 307805: Oil level, oil level sensor	A750		E	1
8B4E06	Engine uppercarr. Fill level sensor engine oil Plausibility error at engine off no reaction 307806: Check wiring engine control unit/sensor	A750		E	1
8B4F00	Engine uppercarr. AGR Position sensor 1 Short circuit after ground or broken wire Use of replacement value 307900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B4F01	Engine uppercarr. AGR Position sensor 1 Sensor signal short circuit after supply voltage Use of replacement value 307901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4F02	Engine uppercarr. AGR Position sensor 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 307902: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B4F03	Engine uppercarr. AGR Position sensor 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 307903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B4F04	Engine uppercarr. AGR Position sensor 1 Sensor signal outside permissible range 1 no reaction 307904: AGR 1 Position sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B4F05	Engine uppercarr. AGR Position sensor 1 Sensor signal outside permissible range 2 no reaction 307905: AGR 1 Position sensor	A750		E	1
8B4F06	Engine uppercarr. AGR Position sensor 1 Plausibility error at engine off no reaction 307906: Check wiring engine control unit/sensor	A750		E	1
8B5000	Engine uppercarr. AGR Position sensor 2 Short circuit after ground or broken wire Use replacement value. Output red. in case of failure of both Commonrail pr. sensor, otherwise no reaction 308000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5001	Engine uppercarr. AGR Position sensor 2 Sensor signal short circuit after supply voltage Use of replacement value 308001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5002	Engine uppercarr. AGR Position sensor 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 308002: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5003	Engine uppercarr. AGR Position sensor 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 308003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5004	Engine uppercarr. AGR Position sensor 2 Sensor signal outside permissible range 1 no reaction 308004: AGR 2 Position sensor	A750		E	1
8B5005	Engine uppercarr. AGR Position sensor 2 Sensor signal outside permissible range 2 no reaction 308005: AGR 2 Position sensor	A750		E	1
8B5006	Engine uppercarr. AGR Position sensor 2 Plausibility error at engine off no reaction 308006: Check wiring engine control unit/sensor	A750		E	1
8B5200	Engine uppercarr. Charge air pr. sensor Short circuit after ground or broken wire Use of replacement value 308200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5201	Engine uppercarr. Charge air pr. sensor Sensor signal short circuit after supply voltage Use of replacement value 308201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5202	Engine uppercarr. Charge air pr. sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 308202: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5203	Engine uppercarr. Charge air pr. sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 308203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5204	Engine uppercarr. Charge air pr. sensor Sensor signal outside permissible range 1 no reaction 308204: Check operational status of engine	A750		E	1
8B5205	Engine uppercarr. Charge air pr. sensor Sensor signal outside permissible range 2 no reaction 308205: Check operational status of engine	A750		E	1
8B5206	Engine uppercarr. Charge air pr. sensor Plausibility error at engine off no reaction 308206: Check wiring engine control unit/sensor	A750		E	1
8B5207	Engine uppercarr. Charge air pr. sensor Value implausible Warning light on, replace sensor 308207: Check wiring engine control unit/sensor	A750		E	1
8B5300	Engine uppercarr. Oil pressure sensor Short circuit after ground or broken wire Use of replacement value 308300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5301	Engine uppercarr. Oil pressure sensor Sensor signal short circuit after supply voltage Use of replacement value 308301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5302	Engine uppercarr. Oil pressure sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 308302: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5303	Engine uppercarr. Oil pressure sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 308303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5304	Engine uppercarr. Oil pressure sensor Sensor signal outside permissible range 1 no reaction 308304: Check operational status of engine	A750		E	1
8B5305	Engine uppercarr. Oil pressure sensor Sensor signal outside permissible range 2 no reaction 308305: Check operational status of engine	A750		E	1
8B5306	Engine uppercarr. Oil pressure sensor Plausibility error at engine off no reaction 308306: Check wiring engine control unit/sensor	A750		E	1
8B5400	Engine uppercarr. Fuel pressure sensor Short circuit after ground or broken wire Use of replacement value 308400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5401	Engine uppercarr. Fuel pressure sensor Sensor signal short circuit after supply voltage Use of replacement value 308401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5402	Engine uppercarr. Fuel pressure sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 308402: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5403	Engine uppercarr. Fuel pressure sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 308403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5404	Engine uppercarr. Fuel pressure sensor Sensor signal outside permissible range 1 no reaction 308404: Check operational status of engine	A750		E	1
8B5405	Engine uppercarr. Fuel pressure sensor Sensor signal outside permissible range 2 no reaction 308405: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5406	Engine uppercarr. Fuel pressure sensor Plausibility error at engine off no reaction 308406: Check wiring engine control unit/sensor	A750		E	1
8B5500	Engine uppercarr. Fuel pr. sensor 2 Short circuit after ground or broken wire Use of replacement value 308500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5501	Engine uppercarr. Fuel pr. sensor 2 Sensor signal short circuit after supply voltage Use of replacement value 308501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5502	Engine uppercarr. Fuel pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 308502: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5503	Engine uppercarr. Fuel pr. sensor 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 308503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5504	Engine uppercarr. Fuel pr. sensor 2 Sensor signal outside permissible range 1 no reaction 308504: Check operational status of engine	A750		E	1
8B5505	Engine uppercarr. Fuel pr. sensor 2 Sensor signal outside permissible range 2 no reaction 308505: Check operational status of engine	A750		E	1
8B5506	Engine uppercarr. Fuel pr. sensor 2 Plausibility error at engine off no reaction 308506: Check wiring engine control unit/sensor	A750		E	1
8B5600	Engine uppercarr. Air filter vacuum pr. sensor Short circuit after ground or broken wire Use of replacement value 308600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5601	Engine uppercarr. Air filter vacuum pr. sensor Sensor signal short circuit after supply voltage Use of replacement value 308601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5602	Engine uppercarr. Air filter vacuum pr. sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 308602: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5603	Engine uppercarr. Air filter vacuum pr. sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 308603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5604	Engine uppercarr. Air filter vacuum pr. sensor Sensor signal outside permissible range 1 no reaction 308604: Air filter 1, air pr. sensor 1	A750		E	1
8B5605	Engine uppercarr. Air filter vacuum pr. sensor Sensor signal outside permissible range 2 no reaction 308605: Air filter 1, air pr. sensor 1	A750		E	1
8B5606	Engine uppercarr. Air filter vacuum pr. sensor Plausibility error at engine off no reaction 308606: Check wiring engine control unit/sensor	A750		E	1
8B5700	Engine uppercarr. Air filter vacuum pr. sensor 2 Short circuit after ground or broken wire Use of replacement value 308700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5701	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor signal short circuit after supply voltage Use of replacement value 308701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5702	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 308702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B5703	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 308703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B5704	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor signal outside permissible range 1 no reaction 308704: Air filter 2, air pr. sensor 2	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5705	Engine uppercarr. Air filter vacuum pr. sensor 2 Sensor signal outside permissible range 2 no reaction 308705: Air filter 2, air pr. sensor 2	A750		E	1
8B5706	Engine uppercarr. Air filter vacuum pr. sensor 2 Plausibility error at engine off no reaction 308706: Check wiring engine control unit/sensor	A750		E	1
8B5800	Engine uppercarr. Rail pr. sensor 1 Short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2
8B5801	Engine uppercarr. Rail pr. sensor 1 Sensor signal short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	2
8B5802	Engine uppercarr. Rail pr. sensor 1 Sensor supply voltage short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308802: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	2
8B5803	Engine uppercarr. Rail pr. sensor 1 Sensor supply voltage short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	2
8B5804	Engine uppercarr. Rail pr. sensor 1 Sensor signal outside permissible range 1 no reaction 308804: Check operational status of engine	A750		E	2
8B5805	Engine uppercarr. Rail pr. sensor 1 Sensor signal outside permissible range 2 Engine standstill after delay 308805: Check operational status of engine	A750		E	2
8B5806	Engine uppercarr. Rail pr. sensor 1 Plausibility error at engine off no reaction 308806: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	0
8B5807	Engine uppercarr. Rail pr. sensor 1 Value implausible High pressure regulation emergency operation activated 308807: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5808	Engine uppercarr. Rail pr. sensor 1 Pressure run implausible (Gradient) High pressure regulation emergency operation activated 308808: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2
8B5809	Engine uppercarr. Rail pr. sensor 1 Pressure value implausible to constant no reaction 308809: Nitrogen circuit, Rail sensors, pr. relief valve 1, high pr. pump 1, Cable conn. engine control unit	A750		E	1
8B5900	Engine uppercarr. Rail pr. sensor 2 Short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2
8B5901	Engine uppercarr. Rail pr. sensor 2 Sensor signal short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	2
8B5902	Engine uppercarr. Rail pr. sensor 2 Sensor supply voltage short circuit after ground or broken wire Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308902: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	2
8B5903	Engine uppercarr. Rail pr. sensor 2 Sensor supply voltage short circuit after supply voltage Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	2
8B5904	Engine uppercarr. Rail pr. sensor 2 Sensor signal outside permissible range 1 Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308904: Check operational status of engine	A750		E	2
8B5905	Engine uppercarr. Rail pr. sensor 2 Sensor signal outside permissible range 2 Performance reduction at failure of both common rail pressure sensors, otherwise no reaction 308905: Check operational status of engine	A750		E	2
8B5906	Engine uppercarr. Rail pr. sensor 2 Plausibility error at engine off no reaction 308906: Check wiring engine control unit/sensor	A750		E	0
8B5907	Engine uppercarr. Rail pr. sensor 2 Value implausible High pressure regulation emergency operation activated 308907: Check wiring harness, plug, rail pr. sensors, check rail circuit 1/2	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5908	Engine uppercarr. Rail pr. sensor 2 Pressure run implausible (Gradient) High pressure regulation emergency operation activated 308908: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	2
8B5909	Engine uppercarr. Rail pr. sensor 2 Pressure value implausible to constant no reaction 308909: Nitrogen circuit, Rail sensor 2, pr. relief valve 2, high pr. pump 2, Cable conn. engine control unit	A750		E	1
8B5A00	Engine uppercarr. Atmospheric pressure sensor Short circuit after ground or broken wire Use of replacement value 309000: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B5A01	Engine uppercarr. Atmospheric pressure sensor Sensor signal short circuit after supply voltage Use of replacement value 309001: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B5A02	Engine uppercarr. Atmospheric pressure sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 309002: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B5A03	Engine uppercarr. Atmospheric pressure sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 309003: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B5A04	Engine uppercarr. Atmospheric pressure sensor Sensor signal outside permissible range 1 no reaction 309004: Check operational status of engine	A750		E	1
8B5A05	Engine uppercarr. Atmospheric pressure sensor Sensor signal outside permissible range 2 no reaction 309005: Check operational status of engine	A750		E	1
8B5A06	Engine uppercarr. Atmospheric pressure sensor Plausibility error at engine off no reaction 309006: Check wiring engine control unit/sensor	A750		E	1
8B5A07	Engine uppercarr. Atmospheric pressure sensor Value implausible Warning light on, replace sensor 309007: Replace ECU	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5C00	Engine uppercarr. Exhaust pr. difference sensor Short circuit after ground or broken wire Use of replacement value 309200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5C01	Engine uppercarr. Exhaust pr. difference sensor Sensor signal short circuit after supply voltage Use of replacement value 309201: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5C02	Engine uppercarr. Exhaust pr. difference sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 309202: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5C03	Engine uppercarr. Exhaust pr. difference sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 309203: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5C04	Engine uppercarr. Exhaust pr. difference sensor Sensor signal outside permissible range 1 no reaction 309204: Check operational status of engine	A750		E	1
8B5C05	Engine uppercarr. Exhaust pr. difference sensor Sensor signal outside permissible range 2 no reaction 309205: Check operational status of engine	A750		E	1
8B5C06	Engine uppercarr. Exhaust pr. difference sensor Plausibility error at engine off no reaction 309206: Check wiring engine control unit/sensor	A750		E	1
8B5C07	Engine uppercarr. Exhaust pr. difference sensor Value implausible Warning light on 309207: Replace sensor	A750		E	1
8B5D00	Engine uppercarr. Battery voltage measuring Short circuit after ground or broken wire Use of replacement value 309300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5D01	Engine uppercarr. Battery voltage measuring Sensor signal short circuit after supply voltage Use of replacement value 309301: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5D02	Engine uppercarr. Battery voltage measuring Sensor supply voltage short circuit after ground or broken wire Use of replacement value 309302: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5D03	Engine uppercarr. Battery voltage measuring Sensor supply voltage short circuit after supply voltage Use of replacement value 309303: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5D04	Engine uppercarr. Battery voltage measuring Sensor signal outside permissible range 1 no reaction 309304: Check operational status of engine	A750		E	1
8B5D05	Engine uppercarr. Battery voltage measuring Sensor signal outside permissible range 2 no reaction 309305: Check operational status of engine	A750		E	1
8B5D06	Engine uppercarr. Battery voltage measuring Plausibility error at engine off no reaction 309306: Check wiring engine control unit/sensor	A750		E	1
8B5E00	Engine uppercarr. Pressure sensor InterChargerUp 1 Short circuit after ground or broken wire Use of replacement value 309400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5E01	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor signal short circuit after supply voltage Use of replacement value 309401: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5E02	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 309402: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5E03	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 309403: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5E04	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor signal outside permissible range 1 no reaction 309404: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5E05	Engine uppercarr. Pressure sensor InterChargerUp 1 Sensor signal outside permissible range 2 no reaction 309405: Check operational status of engine	A750		E	1
8B5E06	Engine uppercarr. Pressure sensor InterChargerUp 1 Plausibility error at engine off no reaction 309406: Check wiring engine control unit/sensor	A750		E	1
8B5E07	Engine uppercarr. Pressure sensor InterChargerUp 1 Value implausible Warning light on, replace sensor 309407: Check wiring engine control unit/sensor	A750		E	1
8B5F00	Engine uppercarr. Pressure sensor InterChargerDown 1 Short circuit after ground or broken wire Use of replacement value 309500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5F01	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor signal short circuit after supply voltage Use of replacement value 309501: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5F02	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 309502: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5F03	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 309503: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B5F04	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor signal outside permissible range 1 no reaction 309504: Check operational status of engine	A750		E	1
8B5F05	Engine uppercarr. Pressure sensor InterChargerDown 1 Sensor signal outside permissible range 2 no reaction 309505: Check operational status of engine	A750		E	1
8B5F06	Engine uppercarr. Pressure sensor InterChargerDown 1 Plausibility error at engine off no reaction 309506: Check wiring engine control unit/sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B5F07	Engine uppercarr. Pressure sensor InterChargerDown 1 Value implausible Warning light on, replace sensor 309507: Check wiring engine control unit/sensor	A750		E	1
8B6000	Engine uppercarr. Pressure sensor InterChargerUp 2 Short circuit after ground or broken wire Use of replacement value 309600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6001	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor signal short circuit after supply voltage Use of replacement value 309601: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6002	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 309602: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6003	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 309603: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6004	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor signal outside permissible range 1 no reaction 309604: Check operational status of engine	A750		E	1
8B6005	Engine uppercarr. Pressure sensor InterChargerUp 2 Sensor signal outside permissible range 2 no reaction 309605: Check operational status of engine	A750		E	1
8B6006	Engine uppercarr. Pressure sensor InterChargerUp 2 Plausibility error at engine off no reaction 309606: Check wiring engine control unit/sensor	A750		E	1
8B6100	Engine uppercarr. Pressure sensor InterChargerDown 2 Short circuit after ground or broken wire Use of replacement value 309700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6101	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor signal short circuit after supply voltage Use of replacement value 309701: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6102	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 309702: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6103	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 309703: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6104	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor signal outside permissible range 1 no reaction 309704: Check operational status of engine	A750		E	1
8B6105	Engine uppercarr. Pressure sensor InterChargerDown 2 Sensor signal outside permissible range 2 no reaction 309705: Check operational status of engine	A750		E	1
8B6106	Engine uppercarr. Pressure sensor InterChargerDown 2 Plausibility error at engine off no reaction 309706: Check wiring engine control unit/sensor	A750		E	1
8B6107	Engine uppercarr. Pressure sensor InterChargerDown 2 Value implausible no reaction 309707:	A750		E	1
8B6200	Engine uppercarr. Pressure sensor InterCoolerUp 1 Short circuit after ground or broken wire Use of replacement value 309800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6201	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor signal short circuit after supply voltage Use of replacement value 309801: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6202	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 309802: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6203	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 309803: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6204	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor signal outside permissible range 1 no reaction 309804: Check operational status of engine	A750		E	1
8B6205	Engine uppercarr. Pressure sensor InterCoolerUp 1 Sensor signal outside permissible range 2 no reaction 309805: Check operational status of engine	A750		E	1
8B6206	Engine uppercarr. Pressure sensor InterCoolerUp 1 Plausibility error at engine off no reaction 309806: Check wiring engine control unit/sensor	A750		E	1
8B6207	Engine uppercarr. Pressure sensor InterCoolerUp 1 Value implausible Warning light on, replace sensor 309807: Check wiring engine control unit/sensor	A750		E	1
8B6900	Engine uppercarr. Exhaust temperature sensor 1 Short circuit after ground or broken wire Use of replacement value 310500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6901	Engine uppercarr. Exhaust temperature sensor 1 Sensor signal short circuit after supply voltage Use of replacement value 310501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6902	Engine uppercarr. Exhaust temperature sensor 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 310502: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6903	Engine uppercarr. Exhaust temperature sensor 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 310503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6904	Engine uppercarr. Exhaust temperature sensor 1 Sensor signal outside permissible range 1 no reaction 310504: Check operational status of engine	A750		E	1
8B6905	Engine uppercarr. Exhaust temperature sensor 1 Sensor signal outside permissible range 2 no reaction 310505: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6906	Engine uppercarr. Exhaust temperature sensor 1 Plausibility error at engine off no reaction 310506: Check wiring engine control unit/sensor	A750		E	1
8B6A00	Engine uppercarr. Exhaust temperature sensor 2 Short circuit after ground or broken wire Use of replacement value 310600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6A01	Engine uppercarr. Exhaust temperature sensor 2 Sensor signal short circuit after supply voltage Use of replacement value 310601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6A02	Engine uppercarr. Exhaust temperature sensor 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 310602: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6A03	Engine uppercarr. Exhaust temperature sensor 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 310603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6A04	Engine uppercarr. Exhaust temperature sensor 2 Sensor signal outside permissible range 1 no reaction 310604: Check operational status of engine	A750		E	1
8B6A05	Engine uppercarr. Exhaust temperature sensor 2 Sensor signal outside permissible range 2 no reaction 310605: Check operational status of engine	A750		E	1
8B6A06	Engine uppercarr. Exhaust temperature sensor 2 Plausibility error at engine off no reaction 310606: Check wiring engine control unit/sensor	A750		E	1
8B6B00	Engine uppercarr. Temperature sensor DOCUp 1 Short circuit after ground or broken wire Use of replacement value 310700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6B01	Engine uppercarr. Temperature sensor DOCUp 1 Sensor signal short circuit after supply voltage Use of replacement value 310701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6B02	Engine uppercarr. Temperature sensor DOCUp 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 310702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6B03	Engine uppercarr. Temperature sensor DOCUp 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 310703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6B04	Engine uppercarr. Temperature sensor DOCUp 1 Sensor signal outside permissible range 1 no reaction 310704: Check operational status of engine	A750		E	1
8B6B05	Engine uppercarr. Temperature sensor DOCUp 1 Sensor signal outside permissible range 2 no reaction 310705: Check operational status of engine	A750		E	1
8B6B06	Engine uppercarr. Temperature sensor DOCUp 1 Plausibility error at engine off no reaction 310706: Check wiring engine control unit/sensor	A750		E	1
8B6B07	Engine uppercarr. Temperature sensor DOCUp 1 Value implausible Warning light on 310707: Check wiring engine control unit/sensor	A750		E	1
8B6B0A	Engine uppercarr. Temperature sensor DOCUp 1 Pressure value at engine start too low Warning light on 310710: Check wiring engine control unit/sensor	A750		E	1
8B6C00	Engine uppercarr. Temperature sensor DPFUp 1 Short circuit after ground or broken wire Use of replacement value 310800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6C01	Engine uppercarr. Temperature sensor DPFUp 1 Sensor signal short circuit after supply voltage Use of replacement value 310801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6C02	Engine uppercarr. Temperature sensor DPFUp 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 310802: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6C03	Engine uppercarr. Temperature sensor DPFU1 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 310803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6C04	Engine uppercarr. Temperature sensor DPFU1 1 Sensor signal outside permissible range 1 no reaction 310804: Check operational status of engine	A750		E	1
8B6C05	Engine uppercarr. Temperature sensor DPFU1 1 Sensor signal outside permissible range 2 no reaction 310805: Check operational status of engine	A750		E	1
8B6C06	Engine uppercarr. Temperature sensor DPFU1 1 Plausibility error at engine off no reaction 310806: Check wiring engine control unit/sensor	A750		E	1
8B6C07	Engine uppercarr. Temperature sensor DPFU1 1 Value implausible Warning light on 310807: Replace sensor	A750		E	1
8B6C0A	Engine uppercarr. Temperature sensor DPFU1 1 Pressure value at engine start too low Warning light on 310810: Check wiring engine control unit/sensor	A750		E	1
8B6D00	Engine uppercarr. Temperature sensor DPFD1 1 Short circuit after ground or broken wire Use of replacement value 310900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6D01	Engine uppercarr. Temperature sensor DPFD1 1 Sensor signal short circuit after supply voltage Use of replacement value 310901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6D02	Engine uppercarr. Temperature sensor DPFD1 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 310902: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6D03	Engine uppercarr. Temperature sensor DPFD1 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 310903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6D04	Engine uppercarr. Temperature sensor DPFDow 1 Sensor signal outside permissible range 1 no reaction 310904: Check operational status of engine	A750		E	1
8B6D05	Engine uppercarr. Temperature sensor DPFDow 1 Sensor signal outside permissible range 2 no reaction 310905: Check operational status of engine	A750		E	1
8B6D06	Engine uppercarr. Temperature sensor DPFDow 1 Plausibility error at engine off no reaction 310906: Check wiring engine control unit/sensor	A750		E	1
8B6D07	Engine uppercarr. Temperature sensor DPFDow 1 Value implausible Warning light on 310907: Replace sensor	A750		E	1
8B6D0A	Engine uppercarr. Temperature sensor DPFDow 1 Pressure value at engine start too low Warning light on 310910: Check wiring engine control unit/sensor	A750		E	1
8B6E00	Engine uppercarr. Temperature sensor charge air cooler Short circuit after ground or broken wire Use of replacement value 311000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6E01	Engine uppercarr. Temperature sensor charge air cooler Sensor signal short circuit after supply voltage Use of replacement value 311001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6E02	Engine uppercarr. Temperature sensor charge air cooler Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311002: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6E03	Engine uppercarr. Temperature sensor charge air cooler Sensor supply voltage short circuit after supply voltage Use of replacement value 311003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6E04	Engine uppercarr. Temperature sensor charge air cooler Sensor signal outside permissible range 1 no reaction 311004: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B6E05	Engine uppercarr. Temperature sensor charge air cooler Sensor signal outside permissible range 2 no reaction 311005: Check operational status of engine	A750		E	1
8B6E06	Engine uppercarr. Temperature sensor charge air cooler Plausibility error at engine off no reaction 311006: Check wiring engine control unit/sensor	A750		E	1
8B6E07	Engine uppercarr. Temperature sensor charge air cooler Value implausible Warning light on, replace sensor 311007: Check wiring engine control unit-Sensor check charge air cooler	A750		E	1
8B6F00	Engine uppercarr. Hydraulic oil temperature sensor Short circuit after ground or broken wire Use of replacement value 311100: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B6F01	Engine uppercarr. Hydraulic oil temperature sensor Sensor signal short circuit after supply voltage Use of replacement value 311101: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6F02	Engine uppercarr. Hydraulic oil temperature sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311102: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B6F03	Engine uppercarr. Hydraulic oil temperature sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 311103: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B6F04	Engine uppercarr. Hydraulic oil temperature sensor Sensor signal outside permissible range 1 no reaction 311104: Check operational status of engine	A750		E	1
8B6F05	Engine uppercarr. Hydraulic oil temperature sensor Sensor signal outside permissible range 2 no reaction 311105: Check operational status of engine	A750		E	1
8B6F06	Engine uppercarr. Hydraulic oil temperature sensor Plausibility error at engine off no reaction 311106: Check wiring engine control unit/sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7000	Engine uppercarr. Fuel temperature sensor Short circuit after ground or broken wire Use of replacement value 311200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7001	Engine uppercarr. Fuel temperature sensor Sensor signal short circuit after supply voltage Use of replacement value 311201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7002	Engine uppercarr. Fuel temperature sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311202: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7003	Engine uppercarr. Fuel temperature sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 311203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7004	Engine uppercarr. Fuel temperature sensor Sensor signal outside permissible range 1 no reaction 311204: Check operational status of engine	A750		E	1
8B7005	Engine uppercarr. Fuel temperature sensor Sensor signal outside permissible range 2 no reaction 311205: Check operational status of engine	A750		E	1
8B7006	Engine uppercarr. Fuel temperature sensor Plausibility error at engine off no reaction 311206: Check wiring engine control unit/sensor	A750		E	1
8B7100	Engine uppercarr. Charge air temperature sensor Short circuit after ground or broken wire Use of replacement value 311300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7101	Engine uppercarr. Charge air temperature sensor Sensor signal short circuit after supply voltage Use of replacement value 311301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7102	Engine uppercarr. Charge air temperature sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311302: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7103	Engine uppercarr. Charge air temperature sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 311303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7104	Engine uppercarr. Charge air temperature sensor Sensor signal outside permissible range 1 no reaction 311304: Check operational status of engine	A750		E	1
8B7105	Engine uppercarr. Charge air temperature sensor Sensor signal outside permissible range 2 no reaction 311305: Check operational status of engine	A750		E	1
8B7106	Engine uppercarr. Charge air temperature sensor Plausibility error at engine off no reaction 311306: Check wiring engine control unit/sensor	A750		E	1
8B7107	Engine uppercarr. Charge air temperature sensor Value implausible Warning light on 311307: Replace sensor	A750		E	1
8B7200	Engine uppercarr. Coolant temperature sensor Short circuit after ground or broken wire Use of replacement value 311400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7201	Engine uppercarr. Coolant temperature sensor Sensor signal short circuit after supply voltage Use of replacement value 311401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7202	Engine uppercarr. Coolant temperature sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311402: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7203	Engine uppercarr. Coolant temperature sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 311403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7204	Engine uppercarr. Coolant temperature sensor Sensor signal outside permissible range 1 no reaction 311404: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7205	Engine uppercarr. Coolant temperature sensor Sensor signal outside permissible range 2 no reaction 311405: Check operational status of engine	A750		E	1
8B7206	Engine uppercarr. Coolant temperature sensor Plausibility error at engine off no reaction 311406: Check wiring engine control unit/sensor	A750		E	1
8B7207	Engine uppercarr. Coolant temperature sensor Value implausible Warning light on 311407: Replace sensor	A750		E	1
8B7300	Engine uppercarr. Atmospheric temperature sensor Short circuit after ground or broken wire Use of replacement value 311500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7301	Engine uppercarr. Atmospheric temperature sensor Sensor signal short circuit after supply voltage Use of replacement value 311501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7302	Engine uppercarr. Atmospheric temperature sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311502: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7303	Engine uppercarr. Atmospheric temperature sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 311503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7304	Engine uppercarr. Atmospheric temperature sensor Sensor signal outside permissible range 1 no reaction 311504: Check operational status of engine	A750		E	1
8B7305	Engine uppercarr. Atmospheric temperature sensor Sensor signal outside permissible range 2 no reaction 311505: Check operational status of engine	A750		E	1
8B7306	Engine uppercarr. Atmospheric temperature sensor Plausibility error at engine off no reaction 311506: Check wiring engine control unit/sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7400	Engine uppercarr. Battery temperature sensor Short circuit after ground or broken wire Use of replacement value 311600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7401	Engine uppercarr. Battery temperature sensor Sensor signal short circuit after supply voltage Use of replacement value 311601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7402	Engine uppercarr. Battery temperature sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311602: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7403	Engine uppercarr. Battery temperature sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 311603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7404	Engine uppercarr. Battery temperature sensor Sensor signal outside permissible range 1 no reaction 311604: Check operational status of engine	A750		E	1
8B7405	Engine uppercarr. Battery temperature sensor Sensor signal outside permissible range 2 no reaction 311605: Check operational status of engine	A750		E	1
8B7406	Engine uppercarr. Battery temperature sensor Plausibility error at engine off no reaction 311606: Check wiring engine control unit/sensor	A750		E	1
8B7500	Engine uppercarr. Temperature sensor TransfCasePump Short circuit after ground or broken wire Use of replacement value 311700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7501	Engine uppercarr. Temperature sensor TransfCasePump Sensor signal short circuit after supply voltage Use of replacement value 311701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7502	Engine uppercarr. Temperature sensor TransfCasePump Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7503	Engine uppercarr. Temperature sensor TransfCasePump Sensor supply voltage short circuit after supply voltage Use of replacement value 311703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7504	Engine uppercarr. Temperature sensor TransfCasePump Sensor signal outside permissible range 1 no reaction 311704: Check operational status of engine	A750		E	1
8B7505	Engine uppercarr. Temperature sensor TransfCasePump Sensor signal outside permissible range 2 no reaction 311705: Check operational status of engine	A750		E	1
8B7506	Engine uppercarr. Temperature sensor TransfCasePump Plausibility error at engine off no reaction 311706: Check wiring engine control unit/sensor	A750		E	1
8B7600	Engine uppercarr. Temperature sensor SCRUp 1 Short circuit after ground or broken wire Use of replacement value 311800: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7601	Engine uppercarr. Temperature sensor SCRUp 1 Sensor signal short circuit after supply voltage Use of replacement value 311801: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7602	Engine uppercarr. Temperature sensor SCRUp 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311802: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7603	Engine uppercarr. Temperature sensor SCRUp 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 311803: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7604	Engine uppercarr. Temperature sensor SCRUp 1 Sensor signal outside permissible range 1 no reaction 311804: Check operational status of engine	A750		E	1
8B7605	Engine uppercarr. Temperature sensor SCRUp 1 Sensor signal outside permissible range 2 no reaction 311805: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7606	Engine uppercarr. Temperature sensor SCRUp 1 Plausibility error at engine off no reaction 311806: Check wiring engine control unit/sensor	A750		E	1
8B7700	Engine uppercarr. Temperature sensor SCRDown 1 Short circuit after ground or broken wire Use of replacement value 311900: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7701	Engine uppercarr. Temperature sensor SCRDown 1 Sensor signal short circuit after supply voltage Use of replacement value 311901: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7702	Engine uppercarr. Temperature sensor SCRDown 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 311902: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7703	Engine uppercarr. Temperature sensor SCRDown 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 311903: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7704	Engine uppercarr. Temperature sensor SCRDown 1 Sensor signal outside permissible range 1 no reaction 311904: Check operational status of engine	A750		E	1
8B7705	Engine uppercarr. Temperature sensor SCRDown 1 Sensor signal outside permissible range 2 no reaction 311905: Check operational status of engine	A750		E	1
8B7706	Engine uppercarr. Temperature sensor SCRDown 1 Plausibility error at engine off no reaction 311906: Check wiring engine control unit/sensor	A750		E	1
8B7800	Engine uppercarr. oil temperature sensor Short circuit after ground or broken wire Use of replacement value 312000: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7801	Engine uppercarr. oil temperature sensor Sensor signal short circuit after supply voltage Use of replacement value 312001: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7802	Engine uppercarr. oil temperature sensor Sensor supply voltage short circuit after ground or broken wire Use of replacement value 312002: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7803	Engine uppercarr. oil temperature sensor Sensor supply voltage short circuit after supply voltage Use of replacement value 312003: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7804	Engine uppercarr. oil temperature sensor Sensor signal outside permissible range 1 no reaction 312004: Check operational status of engine	A750		E	1
8B7805	Engine uppercarr. oil temperature sensor Sensor signal outside permissible range 2 no reaction 312005: Check operational status of engine	A750		E	1
8B7806	Engine uppercarr. oil temperature sensor Plausibility error at engine off no reaction 312006: Check wiring engine control unit/sensor	A750		E	1
8B7900	Engine uppercarr. Temperature sensor InterChargerUp 1 Short circuit after ground or broken wire Use of replacement value 312100: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7901	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor signal short circuit after supply voltage Use of replacement value 312101: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7902	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 312102: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7903	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 312103: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7904	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor signal outside permissible range 1 no reaction 312104: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7905	Engine uppercarr. Temperature sensor InterChargerUp 1 Sensor signal outside permissible range 2 no reaction 312105: Check operational status of engine	A750		E	1
8B7906	Engine uppercarr. Temperature sensor InterChargerUp 1 Plausibility error at engine off no reaction 312106: Check wiring engine control unit/sensor	A750		E	1
8B7907	Engine uppercarr. Temperature sensor InterChargerUp 1 Value implausible no reaction 312107:	A750		E	1
8B7A00	Engine uppercarr. Temperature sensor InterChargerDown 1 Short circuit after ground or broken wire Use of replacement value 312200: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7A01	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor signal short circuit after supply voltage Use of replacement value 312201: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7A02	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 312202: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7A03	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 312203: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7A04	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor signal outside permissible range 1 no reaction 312204: Check operational status of engine	A750		E	1
8B7A05	Engine uppercarr. Temperature sensor InterChargerDown 1 Sensor signal outside permissible range 2 no reaction 312205: Check operational status of engine	A750		E	1
8B7A06	Engine uppercarr. Temperature sensor InterChargerDown 1 Plausibility error at engine off no reaction 312206: Check wiring engine control unit/sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7A07	Engine uppercarr. Temperature sensor InterChargerDown 1 Value implausible Warning light on 312207: Replace sensor	A750		E	1
8B7B00	Engine uppercarr. Temperature sensor InterChargerUp 2 Short circuit after ground or broken wire Use of replacement value 312300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7B01	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor signal short circuit after supply voltage Use of replacement value 312301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7B02	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 312302: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7B03	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 312303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7B04	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor signal outside permissible range 1 no reaction 312304: Check operational status of engine	A750		E	1
8B7B05	Engine uppercarr. Temperature sensor InterChargerUp 2 Sensor signal outside permissible range 2 no reaction 312305: Check operational status of engine	A750		E	1
8B7B06	Engine uppercarr. Temperature sensor InterChargerUp 2 Plausibility error at engine off no reaction 312306: Check wiring engine control unit/sensor	A750		E	1
8B7C00	Engine uppercarr. Temperature sensor InterChargerDown 2 Short circuit after ground or broken wire Use of replacement value 312400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7C01	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor signal short circuit after supply voltage Use of replacement value 312401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7C02	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 312402: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7C03	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 312403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7C04	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor signal outside permissible range 1 no reaction 312404: Check operational status of engine	A750		E	1
8B7C05	Engine uppercarr. Temperature sensor InterChargerDown 2 Sensor signal outside permissible range 2 no reaction 312405: Check operational status of engine	A750		E	1
8B7C06	Engine uppercarr. Temperature sensor InterChargerDown 2 Plausibility error at engine off no reaction 312406: Check wiring engine control unit/sensor	A750		E	1
8B7C07	Engine uppercarr. Temperature sensor InterChargerDown 2 Value implausible Warning light on 312407: Replace sensor	A750		E	1
8B7D00	Engine uppercarr. Temperature sensor InterCoolerUp 1 Short circuit after ground or broken wire Use of replacement value 312500: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7D01	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor signal short circuit after supply voltage Use of replacement value 312501: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7D02	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 312502: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7D03	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor supply voltage short circuit after supply voltage Use of replacement value 312503: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7D04	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor signal outside permissible range 1 no reaction 312504: Check operational status of engine	A750		E	1
8B7D05	Engine uppercarr. Temperature sensor InterCoolerUp 1 Sensor signal outside permissible range 2 no reaction 312505: Check operational status of engine	A750		E	1
8B7D06	Engine uppercarr. Temperature sensor InterCoolerUp 1 Plausibility error at engine off no reaction 312506: Check wiring engine control unit/sensor	A750		E	1
8B7D07	Engine uppercarr. Temperature sensor InterCoolerUp 1 Value implausible Warning light on, replace sensor 312507: Check wiring engine control unit/sensor	A750		E	1
8B7E00	Engine uppercarr. Temperature sensor SCRUp 2 Short circuit after ground or broken wire Use of replacement value 312600: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7E01	Engine uppercarr. Temperature sensor SCRUp 2 Sensor signal short circuit after supply voltage Use of replacement value 312601: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7E02	Engine uppercarr. Temperature sensor SCRUp 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 312602: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7E03	Engine uppercarr. Temperature sensor SCRUp 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 312603: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7E04	Engine uppercarr. Temperature sensor SCRUp 2 Sensor signal outside permissible range 1 no reaction 312604: Check operational status of engine	A750		E	1
8B7E05	Engine uppercarr. Temperature sensor SCRUp 2 Sensor signal outside permissible range 2 no reaction 312605: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B7E06	Engine uppercarr. Temperature sensor SCRUp 2 Plausibility error at engine off no reaction 312606: Check wiring engine control unit/sensor	A750		E	1
8B7F00	Engine uppercarr. Temperature sensor SCRDown 2 Short circuit after ground or broken wire Use of replacement value 312700: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B7F01	Engine uppercarr. Temperature sensor SCRDown 2 Sensor signal short circuit after supply voltage Use of replacement value 312701: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7F02	Engine uppercarr. Temperature sensor SCRDown 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 312702: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B7F03	Engine uppercarr. Temperature sensor SCRDown 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 312703: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B7F04	Engine uppercarr. Temperature sensor SCRDown 2 Sensor signal outside permissible range 1 no reaction 312704: Check operational status of engine	A750		E	1
8B7F05	Engine uppercarr. Temperature sensor SCRDown 2 Sensor signal outside permissible range 2 no reaction 312705: Check operational status of engine	A750		E	1
8B7F06	Engine uppercarr. Temperature sensor SCRDown 2 Plausibility error at engine off no reaction 312706: Check wiring engine control unit/sensor	A750		E	1
8B8500	Engine uppercarr. Hardware temperature sensor control unit Short circuit after ground or broken wire Use of replacement value 313300: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B8501	Engine uppercarr. Hardware temperature sensor control unit Sensor signal short circuit after supply voltage Use of replacement value 313301: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8502	Engine uppercarr. Hardware temperature sensor control unit Sensor supply voltage short circuit after ground or broken wire Use of replacement value 313302: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B8503	Engine uppercarr. Hardware temperature sensor control unit Sensor supply voltage short circuit after supply voltage Use of replacement value 313303: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B8504	Engine uppercarr. Hardware temperature sensor control unit Sensor signal outside permissible range 1 no reaction 313304: Check operational status of engine	A750		E	1
8B8505	Engine uppercarr. Hardware temperature sensor control unit Sensor signal outside permissible range 2 no reaction 313305: Check operational status of engine	A750		E	1
8B8506	Engine uppercarr. Hardware temperature sensor control unit Plausibility error at engine off no reaction 313306: Check wiring engine control unit/sensor	A750		E	1
8B8600	Engine uppercarr. Hardware temperature sensor control unit CPU Short circuit after ground or broken wire Use of replacement value 313400: Check wiring engine control unit/sensor (broken wire or short circuit after ground)	A750		E	1
8B8601	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor signal short circuit after supply voltage Use of replacement value 313401: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B8602	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor supply voltage short circuit after ground or broken wire Use of replacement value 313402: Check wiring engine control unit/sensor (short circuit after ground)	A750		E	1
8B8603	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor supply voltage short circuit after supply voltage Use of replacement value 313403: Check wiring engine control unit/sensor (short circuit after batt. volt.)	A750		E	1
8B8604	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor signal outside permissible range 1 no reaction 313404: Check operational status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8605	Engine uppercarr. Hardware temperature sensor control unit CPU Sensor signal outside permissible range 2 no reaction 313405: Check operational status of engine	A750		E	1
8B8606	Engine uppercarr. Hardware temperature sensor control unit CPU Plausibility error at engine off no reaction 313406: Check wiring engine control unit/sensor	A750		E	1
8B8800	Engine uppercarr. Switch signal 1 Alternator short circuit to ground Use of replacement value 313600: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8801	Engine uppercarr. Switch signal 1 Alternator Short circuit after supply voltage or broken wire Use of replacement value 313601: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8802	Engine uppercarr. Switch signal 1 Alternator Short circuit after ground or broken wire Use of replacement value 313602: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8803	Engine uppercarr. Switch signal 1 Alternator short circuit to supply voltage Use of replacement value 313603:	A750		E	1
8B8804	Engine uppercarr. Switch signal 1 Alternator Operating status outside permissible range Use of replacement value 313604: Check operational status of engine	A750		E	1
8B8806	Engine uppercarr. Switch signal 1 Alternator Value implausible at engine standstill no reaction 313606: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8900	Engine uppercarr. Switch signal 2 Alternator short circuit to ground Use of replacement value 313700: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8901	Engine uppercarr. Switch signal 2 Alternator Short circuit after supply voltage or broken wire Use of replacement value 313701: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8902	Engine uppercarr. Switch signal 2 Alternator Short circuit after ground or broken wire Use of replacement value 313702: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8903	Engine uppercarr. Switch signal 2 Alternator short circuit to supply voltage Use of replacement value 313703:	A750		E	1
8B8904	Engine uppercarr. Switch signal 2 Alternator Operating status outside permissible range Use of replacement value 313704: Check operational status of engine	A750		E	1
8B8906	Engine uppercarr. Switch signal 2 Alternator Value implausible at engine standstill no reaction 313706: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A00	Engine uppercarr. Switch signal Heater unit "SupV" 1 short circuit to ground Use of replacement value 313800: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A01	Engine uppercarr. Switch signal Heater unit "SupV" 1 Short circuit after supply voltage or broken wire Use of replacement value 313801: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A02	Engine uppercarr. Switch signal Heater unit "SupV" 1 Short circuit after ground or broken wire Use of replacement value 313802: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A03	Engine uppercarr. Switch signal Heater unit "SupV" 1 short circuit to supply voltage Use of replacement value 313803: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8A04	Engine uppercarr. Switch signal Heater unit "SupV" 1 Operating status outside permissible range Use of replacement value 313804: Check operational status of engine	A750		E	1
8B8A06	Engine uppercarr. Switch signal Heater unit "SupV" 1 Value implausible at engine standstill no reaction 313806: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8B00	Engine uppercarr. Switch signal Heater unit "SupV" 2 short circuit to ground Use of replacement value 313900: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8B01	Engine uppercarr. Switch signal Heater unit "SupV" 2 Short circuit after supply voltage or broken wire Use of replacement value 313901: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8B02	Engine uppercarr. Switch signal Heater unit "SupV" 2 Short circuit after ground or broken wire Use of replacement value 313902: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8B03	Engine uppercarr. Switch signal Heater unit "SupV" 2 short circuit to supply voltage Use of replacement value 313903: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8B04	Engine uppercarr. Switch signal Heater unit "SupV" 2 Operating status outside permissible range Use of replacement value 313904: Check operational status of engine	A750		E	1
8B8B06	Engine uppercarr. Switch signal Heater unit "SupV" 2 Value implausible at engine standstill no reaction 313906: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C00	Engine uppercarr. Switch signal Starter short circuit to ground Use of replacement value 314000: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C01	Engine uppercarr. Switch signal Starter Short circuit after supply voltage or broken wire Use of replacement value 314001: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C02	Engine uppercarr. Switch signal Starter Short circuit after ground or broken wire Use of replacement value 314002: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8C03	Engine uppercarr. Switch signal Starter short circuit to supply voltage Use of replacement value 314003: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8C04	Engine uppercarr. Switch signal Starter Operating status outside permissible range Use of replacement value 314004: Check operational status of engine	A750		E	1
8B8C06	Engine uppercarr. Switch signal Starter Value implausible at engine standstill no reaction 314006: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D00	Engine uppercarr. Idle switch signal short circuit to ground Use of replacement value 314100: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D01	Engine uppercarr. Idle switch signal Short circuit after supply voltage or broken wire Use of replacement value 314101: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D02	Engine uppercarr. Idle switch signal Short circuit after ground or broken wire Use of replacement value 314102: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D03	Engine uppercarr. Idle switch signal short circuit to supply voltage Use of replacement value 314103: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8D04	Engine uppercarr. Idle switch signal Operating status outside permissible range Use of replacement value 314104: Check operational status of engine	A750		E	1
8B8D06	Engine uppercarr. Idle switch signal Value implausible at engine standstill no reaction 314106: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E00	Engine uppercarr. Switch signal Test op. short circuit to ground Use of replacement value 314200: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E01	Engine uppercarr. Switch signal Test op. Short circuit after supply voltage or broken wire Use of replacement value 314201: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B8E02	Engine uppercarr. Switch signal Test op. Short circuit after ground or broken wire Use of replacement value 314202: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E03	Engine uppercarr. Switch signal Test op. short circuit to supply voltage Use of replacement value 314203: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8E04	Engine uppercarr. Switch signal Test op. Operating status outside permissible range Use of replacement value 314204: Check operational status of engine	A750		E	1
8B8E06	Engine uppercarr. Switch signal Test op. Value implausible at engine standstill no reaction 314206: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F00	Engine uppercarr. Switch signal "SupvEgr" 1 short circuit to ground Use of replacement value 314300: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F01	Engine uppercarr. Switch signal "SupvEgr" 1 Short circuit after supply voltage or broken wire Use of replacement value 314301: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F02	Engine uppercarr. Switch signal "SupvEgr" 1 Short circuit after ground or broken wire Use of replacement value 314302: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F03	Engine uppercarr. Switch signal "SupvEgr" 1 short circuit to supply voltage Use of replacement value 314303: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B8F04	Engine uppercarr. Switch signal "SupvEgr" 1 Operating status outside permissible range Use of replacement value 314304: Check operational status of engine	A750		E	1
8B8F06	Engine uppercarr. Switch signal "SupvEgr" 1 Value implausible at engine standstill no reaction 314306: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9000	Engine uppercarr. Switch signal "SupvEgr" 2 short circuit to ground Use of replacement value 314400: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9001	Engine uppercarr. Switch signal "SupvEgr" 2 Short circuit after supply voltage or broken wire Use of replacement value 314401: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9002	Engine uppercarr. Switch signal "SupvEgr" 2 Short circuit after ground or broken wire Use of replacement value 314402: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9003	Engine uppercarr. Switch signal "SupvEgr" 2 short circuit to supply voltage Use of replacement value 314403: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9004	Engine uppercarr. Switch signal "SupvEgr" 2 Operating status outside permissible range Use of replacement value 314404: Check operational status of engine	A750		E	1
8B9006	Engine uppercarr. Switch signal "SupvEgr" 2 Value implausible at engine standstill no reaction 314406: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9100	Engine uppercarr. Switch signal Fixed rpm short circuit to ground Use of replacement value 314500: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9101	Engine uppercarr. Switch signal Fixed rpm Short circuit after supply voltage or broken wire Use of replacement value 314501: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9102	Engine uppercarr. Switch signal Fixed rpm Short circuit after ground or broken wire Use of replacement value 314502: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9103	Engine uppercarr. Switch signal Fixed rpm short circuit to supply voltage Use of replacement value 314503: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9104	Engine uppercarr. Switch signal Fixed rpm Operating status outside permissible range Use of replacement value 314504: Check operational status of engine	A750		E	1
8B9106	Engine uppercarr. Switch signal Fixed rpm Value implausible at engine standstill no reaction 314506: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9200	Engine uppercarr. Empty gas switch signal short circuit to ground Use of replacement value 314600: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9201	Engine uppercarr. Empty gas switch signal Short circuit after supply voltage or broken wire Use of replacement value 314601: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9202	Engine uppercarr. Empty gas switch signal Short circuit after ground or broken wire Use of replacement value 314602: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9203	Engine uppercarr. Empty gas switch signal short circuit to supply voltage Use of replacement value 314603: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9204	Engine uppercarr. Empty gas switch signal Operating status outside permissible range Use of replacement value 314604: Check operational status of engine	A750		E	1
8B9206	Engine uppercarr. Empty gas switch signal Value implausible at engine standstill no reaction 314606: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9300	Engine uppercarr. Switch signal "EcyStart" short circuit to ground Use of replacement value 314700: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9301	Engine uppercarr. Switch signal "EcyStart" Short circuit after supply voltage or broken wire Use of replacement value 314701: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9302	Engine uppercarr. Switch signal "EcyStart" Short circuit after ground or broken wire Use of replacement value 314702: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9303	Engine uppercarr. Switch signal "EcyStart" short circuit to supply voltage Use of replacement value 314703: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9304	Engine uppercarr. Switch signal "EcyStart" Operating status outside permissible range Use of replacement value 314704: Check operational status of engine	A750		E	1
8B9306	Engine uppercarr. Switch signal "EcyStart" Value implausible at engine standstill no reaction 314706: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9400	Engine uppercarr. Switch signal "DelayEcyStart" short circuit to ground Use of replacement value 314800: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9401	Engine uppercarr. Switch signal "DelayEcyStart" Short circuit after supply voltage or broken wire Use of replacement value 314801: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9402	Engine uppercarr. Switch signal "DelayEcyStart" Short circuit after ground or broken wire Use of replacement value 314802: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9403	Engine uppercarr. Switch signal "DelayEcyStart" short circuit to supply voltage Use of replacement value 314803: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9404	Engine uppercarr. Switch signal "DelayEcyStart" Operating status outside permissible range Use of replacement value 314804: Check operational status of engine	A750		E	1
8B9406	Engine uppercarr. Switch signal "DelayEcyStart" Value implausible at engine standstill no reaction 314806: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9500	Engine uppercarr. Switch signal Notstopp short circuit to ground Use of replacement value 314900: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9501	Engine uppercarr. Switch signal Notstopp Short circuit after supply voltage or broken wire Use of replacement value 314901: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9502	Engine uppercarr. Switch signal Notstopp Short circuit after ground or broken wire Use of replacement value 314902: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9503	Engine uppercarr. Switch signal Notstopp short circuit to supply voltage Use of replacement value 314903: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9504	Engine uppercarr. Switch signal Notstopp Operating status outside permissible range Use of replacement value 314904: Check operational status of engine	A750		E	1
8B9506	Engine uppercarr. Switch signal Notstopp Value implausible at engine standstill no reaction 314906: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9600	Engine uppercarr. Switch signal "Slave on" short circuit to ground Use of replacement value 315000: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9601	Engine uppercarr. Switch signal "Slave on" Short circuit after supply voltage or broken wire Use of replacement value 315001: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9602	Engine uppercarr. Switch signal "Slave on" Short circuit after ground or broken wire Use of replacement value 315002: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9603	Engine uppercarr. Switch signal "Slave on" short circuit to supply voltage Use of replacement value 315003: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9604	Engine uppercarr. Switch signal "Slave on" Operating status outside permissible range Use of replacement value 315004: Check operational status of engine	A750		E	1
8B9606	Engine uppercarr. Switch signal "Slave on" Value implausible at engine standstill no reaction 315006: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9700	Engine uppercarr. Switch signal fan reversed short circuit to ground Use of replacement value 315100: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9701	Engine uppercarr. Switch signal fan reversed Short circuit after supply voltage or broken wire Use of replacement value 315101: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9702	Engine uppercarr. Switch signal fan reversed Short circuit after ground or broken wire Use of replacement value 315102: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9703	Engine uppercarr. Switch signal fan reversed short circuit to supply voltage Use of replacement value 315103: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9704	Engine uppercarr. Switch signal fan reversed Operating status outside permissible range Use of replacement value 315104: Check operational status of engine	A750		E	1
8B9706	Engine uppercarr. Switch signal fan reversed Value implausible at engine standstill no reaction 315106: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9800	Engine uppercarr. Switch signal fan reversed manual short circuit to ground Use of replacement value 315200: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9801	Engine uppercarr. Switch signal fan reversed manual Short circuit after supply voltage or broken wire Use of replacement value 315201: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9802	Engine uppercarr. Switch signal fan reversed manual Short circuit after ground or broken wire Use of replacement value 315202: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9803	Engine uppercarr. Switch signal fan reversed manual short circuit to supply voltage Use of replacement value 315203: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9804	Engine uppercarr. Switch signal fan reversed manual Operating status outside permissible range Use of replacement value 315204: Check operational status of engine	A750		E	1
8B9806	Engine uppercarr. Switch signal fan reversed manual Value implausible at engine standstill no reaction 315206: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9900	Engine uppercarr. Air filter vacuum pr. switch 1 short circuit to ground Use of replacement value 315300: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9901	Engine uppercarr. Air filter vacuum pr. switch 1 Short circuit after supply voltage or broken wire Use of replacement value 315301: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9902	Engine uppercarr. Air filter vacuum pr. switch 1 Short circuit after ground or broken wire Use of replacement value 315302: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9903	Engine uppercarr. Air filter vacuum pr. switch 1 short circuit to supply voltage Use of replacement value 315303: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9904	Engine uppercarr. Air filter vacuum pr. switch 1 Operating status outside permissible range Use of replacement value 315304: Check operational status of engine	A750		E	1
8B9906	Engine uppercarr. Air filter vacuum pr. switch 1 Value implausible at engine standstill no reaction 315306: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9A00	Engine uppercarr. Air filter vacuum pr. switch 2 short circuit to ground Use of replacement value 315400: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9A01	Engine uppercarr. Air filter vacuum pr. switch 2 Short circuit after supply voltage or broken wire Use of replacement value 315401: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9A02	Engine uppercarr. Air filter vacuum pr. switch 2 Short circuit after ground or broken wire Use of replacement value 315402: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9A03	Engine uppercarr. Air filter vacuum pr. switch 2 short circuit to supply voltage Use of replacement value 315403: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9A04	Engine uppercarr. Air filter vacuum pr. switch 2 Operating status outside permissible range Use of replacement value 315404: Check operational status of engine	A750		E	1
8B9A06	Engine uppercarr. Air filter vacuum pr. switch 2 Value implausible at engine standstill no reaction 315406: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B00	Engine uppercarr. Sensor Water in fuel short circuit to ground Use of replacement value 315500: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B01	Engine uppercarr. Sensor Water in fuel Short circuit after supply voltage or broken wire Use of replacement value 315501: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B02	Engine uppercarr. Sensor Water in fuel Short circuit after ground or broken wire Use of replacement value 315502: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9B03	Engine uppercarr. Sensor Water in fuel short circuit to supply voltage Use of replacement value 315503: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9B04	Engine uppercarr. Sensor Water in fuel Operating status outside permissible range Use of replacement value 315504: Check operational status of engine	A750		E	1
8B9B06	Engine uppercarr. Sensor Water in fuel Value implausible at engine standstill no reaction 315506: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C00	Engine uppercarr. Coolant level sensor short circuit to ground Use of replacement value 315600: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C01	Engine uppercarr. Coolant level sensor Short circuit after supply voltage or broken wire Use of replacement value 315601: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C02	Engine uppercarr. Coolant level sensor Short circuit after ground or broken wire Use of replacement value 315602: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C03	Engine uppercarr. Coolant level sensor short circuit to supply voltage Use of replacement value 315603: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9C04	Engine uppercarr. Coolant level sensor Operating status outside permissible range Use of replacement value 315604: Check operational status of engine	A750		E	1
8B9C06	Engine uppercarr. Coolant level sensor Value implausible at engine standstill no reaction 315606: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8B9D00	Engine uppercarr. Flame start system short circuit to ground Use of replacement value 315700: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9D01	Engine uppercarr. Flame start system Line interruption or short circuit after supply voltage Use of replacement value 315701: Turn ignition off/on, possibly change engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9D02	Engine uppercarr. Flame start system Line interruption or short circuit after ground Use of replacement value 315702: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9D03	Engine uppercarr. Flame start system short circuit to supply voltage Use of replacement value 315703: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9D04	Engine uppercarr. Flame start system Operating data outside permissible range Use of replacement value 315704: Check op. status of engine	A750		E	1
8B9D06	Engine uppercarr. Flame start system Test values implausible at engine standstill no reaction 315706: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E00	Engine uppercarr. Flame start system 2 short circuit to ground Use of replacement value 315800: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E01	Engine uppercarr. Flame start system 2 Line interruption or short circuit after supply voltage Use of replacement value 315801: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E02	Engine uppercarr. Flame start system 2 Line interruption or short circuit after ground Use of replacement value 315802: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E03	Engine uppercarr. Flame start system 2 short circuit to supply voltage Use of replacement value 315803: Turn ignition off/on, possibly change engine control unit	A750		E	1
8B9E04	Engine uppercarr. Flame start system 2 Operating data outside permissible range Use of replacement value 315804: Check op. status of engine	A750		E	1
8B9E06	Engine uppercarr. Flame start system 2 Test values implausible at engine standstill no reaction 315806: Turn ignition off/on, possibly change engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8B9F00	Engine uppercarr. Input signal request engine brake short circuit to ground Use of replacement value 315900: Check wiring, control unit	A750		E	1
8B9F01	Engine uppercarr. Input signal request engine brake Short circuit after supply voltage or broken wire Use of replacement value 315901: Check wiring, control unit	A750		E	1
8B9F02	Engine uppercarr. Input signal request engine brake Short circuit after ground or broken wire Use of replacement value 315902: Check wiring, control unit	A750		E	1
8B9F03	Engine uppercarr. Input signal request engine brake short circuit to supply voltage Use of replacement value 315903: Check wiring, control unit	A750		E	1
8B9F04	Engine uppercarr. Input signal request engine brake Operating status outside permissible range Use of replacement value 315904: Check wiring, control unit	A750		E	1
8B9F06	Engine uppercarr. Input signal request engine brake Value implausible at engine standstill no reaction 315906: Check wiring, control unit	A750		E	1
8BA000	Engine uppercarr. Input signal water in fuel 2 short circuit to ground Use of replacement value 315900: Check wiring, control unit	A750		E	1
8BA001	Engine uppercarr. Input signal water in fuel 2 Short circuit after supply voltage or broken wire Use of replacement value 315901: Check wiring, control unit	A750		E	1
8BA002	Engine uppercarr. Input signal water in fuel 2 Short circuit after ground or broken wire Use of replacement value 316000: Check wiring, control unit	A750		E	1
8BA003	Engine uppercarr. Input signal water in fuel 2 short circuit to supply voltage Use of replacement value 316001: Check wiring, control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BA004	Engine uppercarr. Input signal water in fuel 2 Operating status outside permissible range Use of replacement value 316002: Check wiring, control unit	A750		E	1
8BA006	Engine uppercarr. Input signal water in fuel 2 Value implausible at engine standstill no reaction 316004: Check wiring, control unit	A750		E	1
8BA100	Engine uppercarr. Input signal rpm increase short circuit to ground Use of replacement value 316005: Check wiring, control unit	A750		E	1
8BA101	Engine uppercarr. Input signal rpm increase Short circuit after supply voltage or broken wire Use of replacement value 316006: Check wiring, control unit	A750		E	1
8BA102	Engine uppercarr. Input signal rpm increase Short circuit after ground or broken wire Use of replacement value 316100: Check wiring, control unit	A750		E	1
8BA103	Engine uppercarr. Input signal rpm increase short circuit to supply voltage Use of replacement value 316101: Check wiring, control unit	A750		E	1
8BA104	Engine uppercarr. Input signal rpm increase Operating status outside permissible range Use of replacement value 316102: Check wiring, control unit	A750		E	1
8BA106	Engine uppercarr. Input signal rpm increase Value implausible at engine standstill no reaction 316103: Check wiring, control unit	A750		E	1
8BA200	Engine uppercarr. Input signal rpm decrease short circuit to ground Use of replacement value 316106: Check wiring, control unit	A750		E	1
8BA201	Engine uppercarr. Input signal rpm decrease Short circuit after supply voltage or broken wire Use of replacement value 316200: Check wiring, control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BA202	Engine uppercarr. Input signal rpm decrease Short circuit after ground or broken wire Use of replacement value 316201: Check wiring, control unit	A750		E	1
8BA203	Engine uppercarr. Input signal rpm decrease short circuit to supply voltage Use of replacement value 316202: Check wiring, control unit	A750		E	1
8BA204	Engine uppercarr. Input signal rpm decrease Operating status outside permissible range Use of replacement value 316203: Check wiring, control unit	A750		E	1
8BA206	Engine uppercarr. Input signal rpm decrease Value implausible at engine standstill no reaction 316206: Check wiring, control unit	A750		E	1
8BA300	Engine uppercarr. Input signal fixed rpm short circuit to ground 319500	A750		E	1
8BA301	Engine uppercarr. Input signal fixed rpm Line interruption or short circuit after supply voltage 319501	A750		E	1
8BA302	Engine uppercarr. Input signal fixed rpm Line interruption or short circuit after ground 319502	A750		E	1
8BA303	Engine uppercarr. Input signal fixed rpm short circuit to supply voltage 319503	A750		E	1
8BA306	Engine uppercarr. Input signal fixed rpm Test values implausible at engine standstill 319504	A750		E	1
8BC300	Engine uppercarr. Actuation Injection Cyl. 1 Interruption or current remeasuring erroneous no reaction 319500: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC301	Engine uppercarr. Actuation Injection Cyl. 1 Maximum current ground switch exceeded Injector unit is not energized 319501: Check cable, plug, injector, engine control unit	A750		E	1
8BC302	Engine uppercarr. Actuation Injection Cyl. 1 Maximum current Plus switch exceeded Injector unit is not energized 319502: Check cable, plug, injector, engine control unit	A750		E	1
8BC303	Engine uppercarr. Actuation Injection Cyl. 1 No increase time measured no reaction 319503: Check cable, plug, injector, engine control unit	A750		E	1
8BC304	Engine uppercarr. Actuation Injection Cyl. 1 Increase time too large no reaction 319504: Check cable, plug, injector, engine control unit	A750		E	1
8BC305	Engine uppercarr. Actuation Injection Cyl. 1 Cyl. Overlap Engine shut off 319505: Load new software in engine control unit	A750		E	1
8BC306	Engine uppercarr. Actuation Injection Cyl. 1 No fly time measured no reaction 319506: Check cable, plug, injector, engine control unit	A750		E	1
8BC307	Engine uppercarr. Actuation Injection Cyl. 1 Fly time too small no reaction 319507: Check cable, plug, injector, engine control unit	A750		E	1
8BC308	Engine uppercarr. Actuation Injection Cyl. 1 Fly time too large no reaction 319508: Check cable, plug, injector, engine control unit	A750		E	1
8BC400	Engine uppercarr. Actuation Injection Cyl. 2 Interruption or current remeasuring erroneous no reaction 319600: Check cable, plug, injector, engine control unit	A750		E	1
8BC401	Engine uppercarr. Actuation Injection Cyl. 2 Maximum current ground switch exceeded Injector unit is not energized 319601: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC402	Engine uppercarr. Actuation Injection Cyl. 2 Maximum current Plus switch exceeded Injector unit is not energized 319602: Check cable, plug, injector, engine control unit	A750		E	1
8BC403	Engine uppercarr. Actuation Injection Cyl. 2 No increase time measured no reaction 319603: Check cable, plug, injector, engine control unit	A750		E	1
8BC404	Engine uppercarr. Actuation Injection Cyl. 2 Increase time too large no reaction 319604: Check cable, plug, injector, engine control unit	A750		E	1
8BC405	Engine uppercarr. Actuation Injection Cyl. 2 Cyl. Overlap Engine shut off 319605: Load new software in engine control unit	A750		E	1
8BC406	Engine uppercarr. Actuation Injection Cyl. 2 No fly time measured no reaction 319606: Check cable, plug, injector, engine control unit	A750		E	1
8BC407	Engine uppercarr. Actuation Injection Cyl. 2 Fly time too small no reaction 319607: Check cable, plug, injector, engine control unit	A750		E	1
8BC408	Engine uppercarr. Actuation Injection Cyl. 2 Fly time too large no reaction 319608: Check cable, plug, injector, engine control unit	A750		E	1
8BC500	Engine uppercarr. Actuation Injection Cyl. 3 Interruption or current remeasuring erroneous no reaction 319700: Check cable, plug, injector, engine control unit	A750		E	1
8BC501	Engine uppercarr. Actuation Injection Cyl. 3 Maximum current ground switch exceeded Injector unit is not energized 319701: Check cable, plug, injector, engine control unit	A750		E	1
8BC502	Engine uppercarr. Actuation Injection Cyl. 3 Maximum current Plus switch exceeded Injector unit is not energized 319702: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC503	Engine uppercarr. Actuation Injection Cyl. 3 No increase time measured no reaction 319703: Check cable, plug, injector, engine control unit	A750		E	1
8BC504	Engine uppercarr. Actuation Injection Cyl. 3 Increase time too large no reaction 319704: Check cable, plug, injector, engine control unit	A750		E	1
8BC505	Engine uppercarr. Actuation Injection Cyl. 3 Cyl. Overlap Engine shut off 319705: Load new software in engine control unit	A750		E	1
8BC506	Engine uppercarr. Actuation Injection Cyl. 3 No fly time measured no reaction 319706: Check cable, plug, injector, engine control unit	A750		E	1
8BC507	Engine uppercarr. Actuation Injection Cyl. 3 Fly time too small no reaction 319707: Check cable, plug, injector, engine control unit	A750		E	1
8BC508	Engine uppercarr. Actuation Injection Cyl. 3 Fly time too large no reaction 319708: Check cable, plug, injector, engine control unit	A750		E	1
8BC600	Engine uppercarr. Actuation Injection Cyl. 4 Interruption or current remeasuring erroneous no reaction 319800: Check cable, plug, injector, engine control unit	A750		E	1
8BC601	Engine uppercarr. Actuation Injection Cyl. 4 Maximum current ground switch exceeded Injector unit is not energized 319801: Check cable, plug, injector, engine control unit	A750		E	1
8BC602	Engine uppercarr. Actuation Injection Cyl. 4 Maximum current Plus switch exceeded Injector unit is not energized 319802: Check cable, plug, injector, engine control unit	A750		E	1
8BC603	Engine uppercarr. Actuation Injection Cyl. 4 No increase time measured no reaction 319803: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC604	Engine uppercarr. Actuation Injection Cyl. 4 Increase time too large no reaction 319804: Check cable, plug, injector, engine control unit	A750		E	1
8BC605	Engine uppercarr. Actuation Injection Cyl. 4 Cyl. Overlap Engine shut off 319805: Load new software in engine control unit	A750		E	1
8BC606	Engine uppercarr. Actuation Injection Cyl. 4 No fly time measured no reaction 319806: Check cable, plug, injector, engine control unit	A750		E	1
8BC607	Engine uppercarr. Actuation Injection Cyl. 4 Fly time too small no reaction 319807: Check cable, plug, injector, engine control unit	A750		E	1
8BC608	Engine uppercarr. Actuation Injection Cyl. 4 Fly time too large no reaction 319808: Check cable, plug, injector, engine control unit	A750		E	1
8BC700	Engine uppercarr. Actuation Injection Cyl. 5 Interruption or current remeasuring erroneous no reaction 319900: Check cable, plug, injector, engine control unit	A750		E	1
8BC701	Engine uppercarr. Actuation Injection Cyl. 5 Maximum current ground switch exceeded Injector unit is not energized 319901: Check cable, plug, injector, engine control unit	A750		E	1
8BC702	Engine uppercarr. Actuation Injection Cyl. 5 Maximum current Plus switch exceeded Injector unit is not energized 319902: Check cable, plug, injector, engine control unit	A750		E	1
8BC703	Engine uppercarr. Actuation Injection Cyl. 5 No increase time measured no reaction 319903: Check cable, plug, injector, engine control unit	A750		E	1
8BC704	Engine uppercarr. Actuation Injection Cyl. 5 Increase time too large no reaction 319904: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC705	Engine uppercarr. Actuation Injection Cyl. 5 Cyl. Overlap Engine shut off 319905: Load new software in engine control unit	A750		E	1
8BC706	Engine uppercarr. Actuation Injection Cyl. 5 No fly time measured no reaction 319906: Check cable, plug, injector, engine control unit	A750		E	1
8BC707	Engine uppercarr. Actuation Injection Cyl. 5 Fly time too small no reaction 319907: Check cable, plug, injector, engine control unit	A750		E	1
8BC708	Engine uppercarr. Actuation Injection Cyl. 5 Fly time too large no reaction 319908: Check cable, plug, injector, engine control unit	A750		E	1
8BC800	Engine uppercarr. Actuation Injection Cyl. 6 Interruption or current remeasuring erroneous no reaction 320000: Check cable, plug, injector, engine control unit	A750		E	1
8BC801	Engine uppercarr. Actuation Injection Cyl. 6 Maximum current ground switch exceeded Injector unit is not energized 320001: Check cable, plug, injector, engine control unit	A750		E	1
8BC802	Engine uppercarr. Actuation Injection Cyl. 6 Maximum current Plus switch exceeded Injector unit is not energized 320002: Check cable, plug, injector, engine control unit	A750		E	1
8BC803	Engine uppercarr. Actuation Injection Cyl. 6 No increase time measured no reaction 320003: Check cable, plug, injector, engine control unit	A750		E	1
8BC804	Engine uppercarr. Actuation Injection Cyl. 6 Increase time too large no reaction 320004: Check cable, plug, injector, engine control unit	A750		E	1
8BC805	Engine uppercarr. Actuation Injection Cyl. 6 Cyl. Overlap Engine shut off 320005: Load new software in engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC806	Engine uppercarr. Actuation Injection Cyl. 6 No fly time measured no reaction 320006: Check cable, plug, injector, engine control unit	A750		E	1
8BC807	Engine uppercarr. Actuation Injection Cyl. 6 Fly time too small no reaction 320007: Check cable, plug, injector, engine control unit	A750		E	1
8BC808	Engine uppercarr. Actuation Injection Cyl. 6 Fly time too large no reaction 320008: Check cable, plug, injector, engine control unit	A750		E	1
8BC900	Engine uppercarr. Actuation Injection Cyl. 7 Interruption or current remeasuring erroneous no reaction 320100: Check cable, plug, injector, engine control unit	A750		E	1
8BC901	Engine uppercarr. Actuation Injection Cyl. 7 Maximum current ground switch exceeded Injector unit is not energized 320101: Check cable, plug, injector, engine control unit	A750		E	1
8BC902	Engine uppercarr. Actuation Injection Cyl. 7 Maximum current Plus switch exceeded Injector unit is not energized 320102: Check cable, plug, injector, engine control unit	A750		E	1
8BC903	Engine uppercarr. Actuation Injection Cyl. 7 No increase time measured no reaction 320103: Check cable, plug, injector, engine control unit	A750		E	1
8BC904	Engine uppercarr. Actuation Injection Cyl. 7 Increase time too large no reaction 320104: Check cable, plug, injector, engine control unit	A750		E	1
8BC905	Engine uppercarr. Actuation Injection Cyl. 7 Cyl. Overlap Engine shut off 320105: Load new software in engine control unit	A750		E	1
8BC906	Engine uppercarr. Actuation Injection Cyl. 7 No fly time measured no reaction 320106: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BC907	Engine uppercarr. Actuation Injection Cyl. 7 Fly time too small no reaction 320107: Check cable, plug, injector, engine control unit	A750		E	1
8BC908	Engine uppercarr. Actuation Injection Cyl. 7 Fly time too large no reaction 320108: Check cable, plug, injector, engine control unit	A750		E	1
8BCA00	Engine uppercarr. Actuation Injection Cyl. 8 Interruption or current remeasuring erroneous no reaction 320200: Check cable, plug, injector, engine control unit	A750		E	1
8BCA01	Engine uppercarr. Actuation Injection Cyl. 8 Maximum current ground switch exceeded Injector unit is not energized 320201: Check cable, plug, injector, engine control unit	A750		E	1
8BCA02	Engine uppercarr. Actuation Injection Cyl. 8 Maximum current Plus switch exceeded Injector unit is not energized 320202: Check cable, plug, injector, engine control unit	A750		E	1
8BCA03	Engine uppercarr. Actuation Injection Cyl. 8 No increase time measured no reaction 320203: Check cable, plug, injector, engine control unit	A750		E	1
8BCA04	Engine uppercarr. Actuation Injection Cyl. 8 Increase time too large no reaction 320204: Check cable, plug, injector, engine control unit	A750		E	1
8BCA05	Engine uppercarr. Actuation Injection Cyl. 8 Cyl. Overlap Engine shut off 320205: Load new software in engine control unit	A750		E	1
8BCA06	Engine uppercarr. Actuation Injection Cyl. 8 No fly time measured no reaction 320206: Check cable, plug, injector, engine control unit	A750		E	1
8BCA07	Engine uppercarr. Actuation Injection Cyl. 8 Fly time too small no reaction 320207: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCA08	Engine uppercarr. Actuation Injection Cyl. 8 Fly time too large no reaction 320208: Check cable, plug, injector, engine control unit	A750		E	1
8BCB00	Engine uppercarr. Actuation Injection Cyl. 9 Interruption or current remeasuring erroneous no reaction 320300: Check cable, plug, injector, engine control unit	A750		E	1
8BCB01	Engine uppercarr. Actuation Injection Cyl. 9 Maximum current ground switch exceeded Injector unit is not energized 320301: Check cable, plug, injector, engine control unit	A750		E	1
8BCB02	Engine uppercarr. Actuation Injection Cyl. 9 Maximum current Plus switch exceeded Injector unit is not energized 320302: Check cable, plug, injector, engine control unit	A750		E	1
8BCB03	Engine uppercarr. Actuation Injection Cyl. 9 No increase time measured no reaction 320303: Check cable, plug, injector, engine control unit	A750		E	1
8BCB04	Engine uppercarr. Actuation Injection Cyl. 9 Increase time too large no reaction 320304: Check cable, plug, injector, engine control unit	A750		E	1
8BCB05	Engine uppercarr. Actuation Injection Cyl. 9 Cyl. Overlap Engine shut off 320305: Load new software in engine control unit	A750		E	1
8BCB06	Engine uppercarr. Actuation Injection Cyl. 9 No fly time measured no reaction 320306: Check cable, plug, injector, engine control unit	A750		E	1
8BCB07	Engine uppercarr. Actuation Injection Cyl. 9 Fly time too small no reaction 320307: Check cable, plug, injector, engine control unit	A750		E	1
8BCB08	Engine uppercarr. Actuation Injection Cyl. 9 Fly time too large no reaction 320308: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCC00	Engine uppercarr. Actuation Injection Cyl. 10 Interruption or current remeasuring erroneous no reaction 320400: Check cable, plug, injector, engine control unit	A750		E	1
8BCC01	Engine uppercarr. Actuation Injection Cyl. 10 Maximum current ground switch exceeded Injector unit is not energized 320401: Check cable, plug, injector, engine control unit	A750		E	1
8BCC02	Engine uppercarr. Actuation Injection Cyl. 10 Maximum current Plus switch exceeded Injector unit is not energized 320402: Check cable, plug, injector, engine control unit	A750		E	1
8BCC03	Engine uppercarr. Actuation Injection Cyl. 10 No increase time measured no reaction 320403: Check cable, plug, injector, engine control unit	A750		E	1
8BCC04	Engine uppercarr. Actuation Injection Cyl. 10 Increase time too large no reaction 320404: Check cable, plug, injector, engine control unit	A750		E	1
8BCC05	Engine uppercarr. Actuation Injection Cyl. 10 Cyl. Overlap Engine shut off 320405: Load new software in engine control unit	A750		E	1
8BCC06	Engine uppercarr. Actuation Injection Cyl. 10 No fly time measured no reaction 320406: Check cable, plug, injector, engine control unit	A750		E	1
8BCC07	Engine uppercarr. Actuation Injection Cyl. 10 Fly time too small no reaction 320407: Check cable, plug, injector, engine control unit	A750		E	1
8BCC08	Engine uppercarr. Actuation Injection Cyl. 10 Fly time too large no reaction 320408: Check cable, plug, injector, engine control unit	A750		E	1
8BCD00	Engine uppercarr. Actuation Injection Cyl. 11 Interruption or current remeasuring erroneous no reaction 320500: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCD01	Engine uppercarr. Actuation Injection Cyl. 11 Maximum current ground switch exceeded Injector unit is not energized 320501: Check cable, plug, injector, engine control unit	A750		E	1
8BCD02	Engine uppercarr. Actuation Injection Cyl. 11 Maximum current Plus switch exceeded Injector unit is not energized 320502: Check cable, plug, injector, engine control unit	A750		E	1
8BCD03	Engine uppercarr. Actuation Injection Cyl. 11 No increase time measured no reaction 320503: Check cable, plug, injector, engine control unit	A750		E	1
8BCD04	Engine uppercarr. Actuation Injection Cyl. 11 Increase time too large no reaction 320504: Check cable, plug, injector, engine control unit	A750		E	1
8BCD05	Engine uppercarr. Actuation Injection Cyl. 11 Cyl. Overlap Engine shut off 320505: Load new software in engine control unit	A750		E	1
8BCD06	Engine uppercarr. Actuation Injection Cyl. 11 No fly time measured no reaction 320506: Check cable, plug, injector, engine control unit	A750		E	1
8BCD07	Engine uppercarr. Actuation Injection Cyl. 11 Fly time too small no reaction 320507: Check cable, plug, injector, engine control unit	A750		E	1
8BCD08	Engine uppercarr. Actuation Injection Cyl. 11 Fly time too large no reaction 320508: Check cable, plug, injector, engine control unit	A750		E	1
8BCE00	Engine uppercarr. Actuation Injection Cyl. 12 Interruption or current remeasuring erroneous no reaction 320600: Check cable, plug, injector, engine control unit	A750		E	1
8BCE01	Engine uppercarr. Actuation Injection Cyl. 12 Maximum current ground switch exceeded Injector unit is not energized 320601: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCE02	Engine uppercarr. Actuation Injection Cyl. 12 Maximum current Plus switch exceeded Injector unit is not energized 320602: Check cable, plug, injector, engine control unit	A750		E	1
8BCE03	Engine uppercarr. Actuation Injection Cyl. 12 No increase time measured no reaction 320603: Check cable, plug, injector, engine control unit	A750		E	1
8BCE04	Engine uppercarr. Actuation Injection Cyl. 12 Increase time too large no reaction 320604: Check cable, plug, injector, engine control unit	A750		E	1
8BCE05	Engine uppercarr. Actuation Injection Cyl. 12 Cyl. Overlap Engine shut off 320605: Load new software in engine control unit	A750		E	1
8BCE06	Engine uppercarr. Actuation Injection Cyl. 12 No fly time measured no reaction 320606: Check cable, plug, injector, engine control unit	A750		E	1
8BCE07	Engine uppercarr. Actuation Injection Cyl. 12 Fly time too small no reaction 320607: Check cable, plug, injector, engine control unit	A750		E	1
8BCE08	Engine uppercarr. Actuation Injection Cyl. 12 Fly time too large no reaction 320608: Check cable, plug, injector, engine control unit	A750		E	1
8BCF00	Engine uppercarr. Actuation injection cylinder 13 Interruption or current remeasuring erroneous no reaction 320700: Check cable, plug, injector, engine control unit	A750		E	1
8BCF01	Engine uppercarr. Actuation injection cylinder 13 Maximum current ground switch exceeded Injector unit is not energized 320701: Check cable, plug, injector, engine control unit	A750		E	1
8BCF02	Engine uppercarr. Actuation injection cylinder 13 Maximum current Plus switch exceeded Injector unit is not energized 320702: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BCF03	Engine uppercarr. Actuation injection cylinder 13 No increase time measured no reaction 320703: Check cable, plug, injector, engine control unit	A750		E	1
8BCF04	Engine uppercarr. Actuation injection cylinder 13 Increase time too large no reaction 320704: Check cable, plug, injector, engine control unit	A750		E	1
8BCF05	Engine uppercarr. Actuation injection cylinder 13 Cyl. Overlap Engine shut off 320705: Load new software in engine control unit	A750		E	1
8BCF06	Engine uppercarr. Actuation injection cylinder 13 No fly time measured no reaction 320706: Check cable, plug, injector, engine control unit	A750		E	1
8BCF07	Engine uppercarr. Actuation injection cylinder 13 Fly time too small no reaction 320707: Check cable, plug, injector, engine control unit	A750		E	1
8BCF08	Engine uppercarr. Actuation injection cylinder 13 Fly time too large no reaction 320708: Check cable, plug, injector, engine control unit	A750		E	1
8BD000	Engine uppercarr. Actuation injection cylinder 14 Interruption or current remeasuring erroneous no reaction 320800: Check cable, plug, injector, engine control unit	A750		E	1
8BD001	Engine uppercarr. Actuation injection cylinder 14 Maximum current ground switch exceeded Injector unit is not energized 320801: Check cable, plug, injector, engine control unit	A750		E	1
8BD002	Engine uppercarr. Actuation injection cylinder 14 Maximum current Plus switch exceeded Injector unit is not energized 320802: Check cable, plug, injector, engine control unit	A750		E	1
8BD003	Engine uppercarr. Actuation injection cylinder 14 No increase time measured no reaction 320803: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD004	Engine uppercarr. Actuation injection cylinder 14 Increase time too large no reaction 320804: Check cable, plug, injector, engine control unit	A750		E	1
8BD005	Engine uppercarr. Actuation injection cylinder 14 Cyl. Overlap Engine shut off 320805: Load new software in engine control unit	A750		E	1
8BD006	Engine uppercarr. Actuation injection cylinder 14 No fly time measured no reaction 320806: Check cable, plug, injector, engine control unit	A750		E	1
8BD007	Engine uppercarr. Actuation injection cylinder 14 Fly time too small no reaction 320807: Check cable, plug, injector, engine control unit	A750		E	1
8BD008	Engine uppercarr. Actuation injection cylinder 14 Fly time too large no reaction 320808: Check cable, plug, injector, engine control unit	A750		E	1
8BD100	Engine uppercarr. Actuation injection cylinder 15 Interruption or current remeasuring erroneous no reaction 320900: Check cable, plug, injector, engine control unit	A750		E	1
8BD101	Engine uppercarr. Actuation injection cylinder 15 Maximum current ground switch exceeded Injector unit is not energized 320901: Check cable, plug, injector, engine control unit	A750		E	1
8BD102	Engine uppercarr. Actuation injection cylinder 15 Maximum current Plus switch exceeded Injector unit is not energized 320902: Check cable, plug, injector, engine control unit	A750		E	1
8BD103	Engine uppercarr. Actuation injection cylinder 15 No increase time measured no reaction 320903: Check cable, plug, injector, engine control unit	A750		E	1
8BD104	Engine uppercarr. Actuation injection cylinder 15 Increase time too large no reaction 320904: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD105	Engine uppercarr. Actuation injection cylinder 15 Cyl. Overlap Engine shut off 320905: Load new software in engine control unit	A750		E	1
8BD106	Engine uppercarr. Actuation injection cylinder 15 No fly time measured no reaction 320906: Check cable, plug, injector, engine control unit	A750		E	1
8BD107	Engine uppercarr. Actuation injection cylinder 15 Fly time too small no reaction 320907: Check cable, plug, injector, engine control unit	A750		E	1
8BD108	Engine uppercarr. Actuation injection cylinder 15 Fly time too large no reaction 320908: Check cable, plug, injector, engine control unit	A750		E	1
8BD200	Engine uppercarr. Actuation injection cylinder 16 Interruption or current remeasuring erroneous no reaction 321000: Check cable, plug, injector, engine control unit	A750		E	1
8BD201	Engine uppercarr. Actuation injection cylinder 16 Maximum current ground switch exceeded Injector unit is not energized 321001: Check cable, plug, injector, engine control unit	A750		E	1
8BD202	Engine uppercarr. Actuation injection cylinder 16 Maximum current Plus switch exceeded Injector unit is not energized 321002: Check cable, plug, injector, engine control unit	A750		E	1
8BD203	Engine uppercarr. Actuation injection cylinder 16 No increase time measured no reaction 321003: Check cable, plug, injector, engine control unit	A750		E	1
8BD204	Engine uppercarr. Actuation injection cylinder 16 Increase time too large no reaction 321004: Check cable, plug, injector, engine control unit	A750		E	1
8BD205	Engine uppercarr. Actuation injection cylinder 16 Cyl. Overlap Engine shut off 321005: Load new software in engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD206	Engine uppercarr. Actuation injection cylinder 16 No fly time measured no reaction 321006: Check cable, plug, injector, engine control unit	A750		E	1
8BD207	Engine uppercarr. Actuation injection cylinder 16 Fly time too small no reaction 321007: Check cable, plug, injector, engine control unit	A750		E	1
8BD208	Engine uppercarr. Actuation injection cylinder 16 Fly time too large no reaction 321008: Check cable, plug, injector, engine control unit	A750		E	1
8BD400	Engine uppercarr. Injection system Cylinder error Engine shut off 321200: Check cable, plug, injector, engine control unit	A750		E	1
8BD401	Engine uppercarr. Injection system Overlap of injection on cyl. bank A Engine shut off 321201: Load new software in engine control unit	A750		E	1
8BD402	Engine uppercarr. Injection system Overlap of injection on cyl. bank B Engine shut off 321202: Load new software in engine control unit	A750		E	1
8BD403	Engine uppercarr. Injection system Overlap of injection on cyl. bank C Engine shut off 321203: Load new software in engine control unit	A750		E	1
8BD404	Engine uppercarr. Injection system Overlap of injection on cyl. bank D Engine shut off 321204: Load new software in engine control unit	A750		E	1
8BD500	Engine uppercarr. Rpm monitoring Rpm sensor 1 has warning threshold exceeded no reaction 321300: Check engine op.(overspeed due to push op.)	A750		E	1
8BD501	Engine uppercarr. Rpm monitoring Rpm sensor 2 has warning threshold exceeded no reaction 321301: Check engine op.(overspeed due to push op.)	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD502	Engine uppercarr. Rpm monitoring Rpm sensor 1 has safety threshold exceeded Engine shut off 321302: Check engine op.(overspeed due to push op.)	A750		E	1
8BD503	Engine uppercarr. Rpm monitoring Rpm sensor 2 has safety threshold exceeded Engine shut off 321303: Check engine op.(overspeed due to push op.)	A750		E	1
8BD504	Engine uppercarr. Rpm monitoring Warning threshold exceeded no reaction 321304: Check engine op.(overspeed due to push op.)	A750		E	2
8BD505	Engine uppercarr. Rpm monitoring Safety threshold exceeded Engine shut off 321305: Check engine op.(overspeed due to push op.)	A750		E	2
8BD600	Engine uppercarr. Synchronization Rpm signals No synchronization no reaction 321400: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BD601	Engine uppercarr. Synchronization Rpm signals Incorrect distance gap <> Phase sensor no reaction 321401: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BD602	Engine uppercarr. Synchronization Rpm signals Tooth number (Impulse number) wrong Engine start not possible 321402: Turn ignition off/on, check teeth on flywheel, check rpm sensor	A750		E	1
8BD603	Engine uppercarr. Synchronization Rpm signals not possible, Rpm too low no reaction 321403: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BD604	Engine uppercarr. Synchronization Rpm signals Index counter cam shaft gear erroneous no reaction 321404: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BD700	Engine uppercarr. RPM sensor 1 Signal lost Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321500: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD701	Engine uppercarr. RPM sensor 1 No signal Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321501: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD702	Engine uppercarr. RPM sensor 1 Permissible signal difference within test interval exceeded Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321502: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD703	Engine uppercarr. RPM sensor 1 Limit frequency exceeded Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321503: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD704	Engine uppercarr. RPM sensor 1 Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321504: Rpm sensor installation, check engine control unit	A750		E	1
8BD705	Engine uppercarr. RPM sensor 1 Measurement erroneous Engine output reduced. Rpm recording via redundant sensor, otherwise em. shut off 321505: Rpm sensor installation, check engine control unit	A750		E	1
8BD800	Engine uppercarr. RPM sensor 2 Signal lost Em. Shut off at simult. failure of both Rpm sensors 321600: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD801	Engine uppercarr. RPM sensor 2 No signal Em. Shut off at simult. failure of both Rpm sensors 321601: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD802	Engine uppercarr. RPM sensor 2 Permissible signal difference within test interval exceeded Em. Shut off at simult. failure of both Rpm sensors 321602: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD803	Engine uppercarr. RPM sensor 2 Limit frequency exceeded Em. Shut off at simult. failure of both Rpm sensors 321603: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD804	Engine uppercarr. RPM sensor 2 Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321604: Rpm sensor installation, check sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BD805	Engine uppercarr. RPM sensor 2 Measurement erroneous Rpm recording via functioning sensor 321605: Rpm sensor installation, check sensor	A750		E	1
8BD900	Engine uppercarr. Index sensor Signal lost Em. Shut off at simult. failure of both Rpm sensors 321700: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD901	Engine uppercarr. Index sensor No signal Em. Shut off at simult. failure of both Rpm sensors 321701: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BD902	Engine uppercarr. Index sensor Permissible signal difference within test interval exceeded Em. Shut off at simult. failure of both Rpm sensors 321702: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD903	Engine uppercarr. Index sensor Limit frequency exceeded Em. Shut off at simult. failure of both Rpm sensors 321703: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BD904	Engine uppercarr. Index sensor Sensor not polarized Em. Shut off at simult. failure of both Rpm sensors 321704: Rpm sensor installation, check sensor	A750		E	1
8BD905	Engine uppercarr. Index sensor Measurement erroneous Rpm recording via functioning sensor 321705: Rpm sensor installation, check sensor	A750		E	1
8BDA04	Engine uppercarr. Lambda-Measurement Regulation deviation, Lambda value too low Warning light on 321804: - Ground current sensor - Lambda Sensor - exhaust return	A750		E	1
8BDA05	Engine uppercarr. Lambda-Measurement Regulation deviation, Lambda value too high Warning light on 321805: - Ground current sensor - Lambda Sensor - exhaust return	A750		E	1
8BDA07	Engine uppercarr. Lambda-Measurement EGR Flow between Bank 1 and Bank 2 very asymmetric Warning light on 321807: Clean / replace actuator, check lines/linkage	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BDB04	Engine uppercarr. Lambda-Measurement Permanent regulation deviation, Lambda value too low Warning light on 321904: - Ground current sensor - Lambda Sensor - exhaust return	A750		E	1
8BDB05	Engine uppercarr. Lambda-Measurement Permanent regulation deviation, Lambda value too high Warning light on 321905: - Ground current sensor - Lambda Sensor - exhaust return	A750		E	1
8BDC04	Engine uppercarr. charge air pressure minimum limit value fallen below Warning light on 322004: Check intake system for leaks	A750		E	1
8BDC05	Engine uppercarr. charge air pressure maximum limit value exceeded Warning light on 322005: Check for stuck Wastegate	A750		E	1
8BE200	Engine uppercarr. Injection system 2 Cylinder error Slave Modules not running (there will be no injection on this module) 322600: Check cable, plug, injector, engine control unit	A750		E	1
8BE201	Engine uppercarr. Injection system 2 Overlap of injection on cyl. bank A Slave Modules not running (there will be no injection on this module) 322601: Load new software in engine control unit	A750		E	1
8BE202	Engine uppercarr. Injection system 2 Overlap of injection on cyl. bank B Slave Modules not running (there will be no injection on this module) 322602: Load new software in engine control unit	A750		E	1
8BE203	Engine uppercarr. Injection system 2 Overlap of injection on cyl. bank C Slave Modules not running (there will be no injection on this module) 322603: Load new software in engine control unit	A750		E	1
8BE204	Engine uppercarr. Injection system 2 Overlap of injection on cyl. bank D Slave Modules not running (there will be no injection on this module) 322604: Load new software in engine control unit	A750		E	1
8BE205	Engine uppercarr. Injection system 2 Plus switch cyl. bank A Short circuit after ground no reaction 322605: Check cable, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE206	Engine uppercarr. Injection system 2 Plus switch cyl. bank B Short circuit after ground no reaction 322606: Check cable, plug, injector, engine control unit	A750		E	1
8BE207	Engine uppercarr. Injection system 2 Plus switch cyl. bank A short circuit after supply voltage no reaction 322607: Check cable, plug, injector, engine control unit	A750		E	1
8BE208	Engine uppercarr. Injection system 2 Plus switch cyl. bank B short circuit after supply voltage no reaction 322608: Check cable, plug, injector, engine control unit	A750		E	1
8BE209	Engine uppercarr. Injection system 2 Ground switch cyl. bank A Short circuit after ground At CR-Motor Shut off of Bank A on Slave Module 322609: Check cable, plug, injector, engine control unit	A750		E	1
8BE20A	Engine uppercarr. Injection system 2 Ground switch cyl. bank B Short circuit after ground At CR-Motor Shut off of Bank B on Slave Module 322610: Check cable, plug, injector, engine control unit	A750		E	1
8BE20B	Engine uppercarr. Injection system 2 Ground switch cyl. bank A short circuit after supply voltage no reaction 322611: Check cable, plug, injector, engine control unit	A750		E	1
8BE20C	Engine uppercarr. Injection system 2 Ground switch cyl. bank B short circuit after supply voltage no reaction 322612: Check cable, plug, injector, engine control unit	A750		E	1
8BE300	Engine uppercarr. Synchronization Rpm signals System 2 No synchronization no reaction 322700: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BE301	Engine uppercarr. Synchronization Rpm signals System 2 Incorrect distance gap <-> Phase sensor no reaction 322701: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BE302	Engine uppercarr. Synchronization Rpm signals System 2 Tooth number (Impulse number) wrong Slave Modules not running (there will be no injection on this module) 322702: Turn ignition off/on, check teeth on flywheel, rpm sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE303	Engine uppercarr. Synchronization Rpm signals System 2 not possible, Rpm too low no reaction 322703: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BE304	Engine uppercarr. Synchronization Rpm signals System 2 Index counter cam shaft gear erroneous no reaction 322704: Turn ignition off/on, check rpm and camshaft sensor	A750		E	1
8BE400	Engine uppercarr. Rpm sensor 1 System 2 Signal lost Engine output reduced. Rpm recording via camshaft sensor provided that o.k. 322800: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE401	Engine uppercarr. Rpm sensor 1 System 2 No signal Engine output reduced. Rpm recording via camshaft sensor provided that o.k. 322801: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE402	Engine uppercarr. Rpm sensor 1 System 2 Permissible signal difference within test interval exceeded Engine output reduced. Rpm recording via camshaft sensor provided that o.k. 322802: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE403	Engine uppercarr. Rpm sensor 1 System 2 Limit frequency exceeded Engine output reduced. Rpm recording via camshaft sensor provided that o.k. 322803: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE404	Engine uppercarr. Rpm sensor 1 System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322804: Rpm sensor installation, check engine control unit	A750		E	1
8BE405	Engine uppercarr. Rpm sensor 1 System 2 Measurement erroneous Engine output reduced. Rpm recording via camshaft sensor provided that o.k. 322805: Rpm sensor installation, check engine control unit	A750		E	1
8BE500	Engine uppercarr. Rpm sensor 2 System 2 Signal lost Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322900: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE501	Engine uppercarr. Rpm sensor 2 System 2 No signal Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322901: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE502	Engine uppercarr. Rpm sensor 2 System 2 Permissible signal difference within test interval exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322902: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE503	Engine uppercarr. Rpm sensor 2 System 2 Limit frequency exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322903: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE504	Engine uppercarr. Rpm sensor 2 System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 322904: Rpm sensor installation, check sensor	A750		E	1
8BE505	Engine uppercarr. Rpm sensor 2 System 2 Measurement erroneous Rpm recording via functioning sensor 322905: Rpm sensor installation, check sensor	A750		E	1
8BE600	Engine uppercarr. Index sensor System 2 Signal lost Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323000: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE601	Engine uppercarr. Index sensor System 2 No signal Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323001: Distance of rpm sensor to flywheel (0.5-2.0 mm), wiring to rpm sensor, rpm sensor	A750		E	1
8BE602	Engine uppercarr. Index sensor System 2 Permissible signal difference within test interval exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323002: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE603	Engine uppercarr. Index sensor System 2 Limit frequency exceeded Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323003: Distance of rpm sensor to flywheel (0.5-2.0 mm), flywheel, wiring to rpm sensor, rpm sensor	A750		E	1
8BE604	Engine uppercarr. Index sensor System 2 Sensor not polarized Emerg. Shut off of Slave-Module only with simult. failure of both Rpm sensors 323004: Rpm sensor installation, check sensor	A750		E	1
8BE605	Engine uppercarr. Index sensor System 2 Measurement erroneous Rpm recording via functioning sensor 323005: Rpm sensor installation, check sensor	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE700	Engine uppercarr. Hardware temperature sensor control unit 2 Short circuit after ground or broken wire Use of replacement value 323100: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE701	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor signal short circuit after supply voltage Use of replacement value 323101: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE702	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor supply voltage short circuit after ground or broken wire Use of replacement value 323102: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE703	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor supply voltage short circuit after supply voltage Use of replacement value 323103: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE704	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor signal outside permissible range 1 Use of replacement value 323104: Check operational status of engine	A750		E	1
8BE705	Engine uppercarr. Hardware temperature sensor control unit 2 Sensor signal outside permissible range 2 Use of replacement value 323105: Check operational status of engine	A750		E	1
8BE706	Engine uppercarr. Hardware temperature sensor control unit 2 Plausibility error at engine off no reaction 323106: Check operational status of engine	A750		E	1
8BE800	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Short circuit after ground or broken wire Use of replacement value 323200: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE801	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor signal short circuit after supply voltage Use of replacement value 323201: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE802	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor supply voltage short circuit after ground or broken wir Use of replacement value 323202: Turn ignition off/on, possibly replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE803	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor supply voltage short circuit after supply voltage Use of replacement value 323203: Turn ignition off/on, possibly replace engine control unit	A750		E	1
8BE804	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor signal outside permissible range 1 Use of replacement value 323204: Check operational status of engine	A750		E	1
8BE805	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Sensor signal outside permissible range 2 Use of replacement value 323205: Check operational status of engine	A750		E	1
8BE806	Engine uppercarr. Hardware temperature sensor control unit 2 CPU Plausibility error at engine off no reaction 323206: Check operational status of engine	A750		E	1
8BE900	Engine uppercarr. Internal error control unit 2 Stack-overflow Slave Modules not running (there will be no injection on this module) 323300: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE901	Engine uppercarr. Internal error control unit 2 Exception error Slave Modules not running (there will be no injection on this module) 323301: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE902	Engine uppercarr. Internal error control unit 2 Program test Slave Modules not running (there will be no injection on this module) 323302: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE903	Engine uppercarr. Internal error control unit 2 RAM-Test Slave Modules not running (there will be no injection on this module) 323303: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BE904	Engine uppercarr. Internal error control unit 2 Overflow in error stack no reaction 323304: Load new software in engine control unit or replace engine control unit	A750		E	1
8BE905	Engine uppercarr. Internal error control unit 2 Comp. time error no reaction 323305: Load new software in engine control unit or replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BE906	Engine uppercarr. Internal error control unit 2 Error-Index too large The error cannot be saved 323306: Load new software in engine control unit or replace engine control unit	A750		E	1
8BEA00	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Error at EEPROM-access Slave Modules not running (there will be no injection on this module) 323400: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA01	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error Parameter memory Slave Modules not running (there will be no injection on this module) 323401: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA02	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Parameter memory in EEPROM is invalid Slave Modules not running (there will be no injection on this module) 323402: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA03	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error ECU-Page No reaction - possibly data sets or operating conditions could not be saved 323403: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA04	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error NMI-Page No reaction - possibly data sets or operating conditions could not be saved 323404: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA05	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error Workdata-Page No reaction - possibly data sets or operating conditions could not be saved 323405: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA06	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error load collective No reaction - possibly load collective data could not be saved 323406: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA07	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Structure size of load collective has changed No reaction - possibly load collective data could not be saved 323407: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEA08	Engine uppercarr. Control unit 2 defective (Memory EEPROM) EEPROM-Memory full (load collective) No reaction - possibly load collective data could not be saved 323408: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEA09	Engine uppercarr. Control unit 2 defective (Memory EEPROM) Check sum error permanent Data No reaction - possibly data sets or operating conditions could not be saved 323409: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEB00	Engine uppercarr. Voltage supply System 2 voltage below required value Slave Modules not running (there will be no injection on this module) 323500: Check on-board power supply (battery, alternator, wiring, plug)	A750		E	1
8BEB01	Engine uppercarr. Voltage supply System 2 excess voltage Slave Modules not running (there will be no injection on this module) 323501: Check on-board power supply (battery, alternator, wiring, plug)	A750		E	1
8BEB02	Engine uppercarr. Voltage supply System 2 Digital outlet short circuit after supply voltage Slave Modules not running (there will be no injection on this module) 323502: Check wiring, engine control unit, possibly replace engine control unit	A750		E	1
8BEB03	Engine uppercarr. Voltage supply System 2 Error release output outlets Slave Modules not running (there will be no injection on this module) 323503: Check wiring, engine control unit, possibly replace engine control unit	A750		E	1
8BEB04	Engine uppercarr. Voltage supply System 2 PS1-Pin erroneous/missing Slave Modules not running (there will be no injection on this module) 323504: Check on board network in ref. to PS1 (terminal 30/31), engine control unit	A750		E	1
8BEB05	Engine uppercarr. Voltage supply System 2 Reference voltage 12V below permissible range Slave Modules not running (there will be no injection on this module) 323505: Check supply voltage Rpm sensors, on board network, engine control unit	A750		E	1
8BEB06	Engine uppercarr. Voltage supply System 2 Reference voltage 12V above permissible range Slave Modules not running (there will be no injection on this module) 323506: Check supply voltage Rpm sensors, on board network, engine control unit	A750		E	1
8BEC00	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Check sum error Parameter memory Slave Modules not running (there will be no injection on this module) 323600: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEC01	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Invalid data, default values are used Slave Modules not running (there will be no injection on this module) 323601: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEC02	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Error during delete Slave Modules not running (there will be no injection on this module) 323602: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEC03	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Error during programming Slave Modules not running (there will be no injection on this module) 323603: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEC04	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Error during check Slave Modules not running (there will be no injection on this module) 323604: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BEC05	Engine uppercarr. Control unit 2 defective (FLASH-Memory) Data inconsistent Slave Modules not running (there will be no injection on this module) 323605: Turn ignition off/on, if error not remedied, replace engine control unit	A750		E	1
8BED00	Engine uppercarr. Outlet engine rpm System 2 Broken wire or Short circuit after ground no reaction 323700: Check wiring harness, plug, conn. Modul	A750		E	1
8BED01	Engine uppercarr. Outlet engine rpm System 2 Broken wire or short circuit after supply voltage no reaction 323701: Check wiring harness, plug, conn. Modul	A750		E	1
8BEE00	Engine uppercarr. Safety checks (SIL) Access error Data memory Engine stop, Start lock 323800: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE01	Engine uppercarr. Safety checks (SIL) Access error Data memory Engine stop, Start lock 323801: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE02	Engine uppercarr. Safety checks (SIL) Access error Data memory Engine stop, Start lock 323802: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE03	Engine uppercarr. Safety checks (SIL) Emerg. shut off (DI6) Engine stop, Start lock 323803: Turn ignition on / off, Update or replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEE04	Engine uppercarr. Safety checks (SIL) Emerg. shut off (Level DI6) Engine stop, Start lock 323804: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE05	Engine uppercarr. Safety checks (SIL) Plausibility error status KI.15 <=> emerg. stop Engine stop, Start lock 323805: Deactivate emerg. stop and turn ignition on / off	A750		E	2
8BEE06	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring KI.15 Engine stop, Start lock 323806: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE07	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring KI.15 Engine stop, Start lock 323807: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE08	Engine uppercarr. Safety checks (SIL) Reference voltage 1.5 V ADC/DMA erroneous Engine stop, Start lock 323808: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE09	Engine uppercarr. Safety checks (SIL) Error in program run control Engine stop, Start lock 323809: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE0A	Engine uppercarr. Safety checks (SIL) Error in program run control Engine stop, Start lock 323810: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE0B	Engine uppercarr. Safety checks (SIL) Error in program run control Engine stop, Start lock 323811: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEE0D	Engine uppercarr. Safety checks (SIL) Internal error data memory (checksum flash) Engine stop, Start lock 323813: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF00	Engine uppercarr. Safety checks (SIL) Internal error data memory (checksum Parameter) Engine stop, Start lock 323900: Load valid data set	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEF01	Engine uppercarr. Safety checks (SIL) Internal error data memory (Safety buffer) Engine stop, Start lock 323901: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF02	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring PS1-Pin Engine stop, Start lock 323902: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF03	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring PS1-Pin Engine stop, Start lock 323903: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF04	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring KI.50 Engine stop, Start lock 323904: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF05	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring air flap Engine stop, Start lock 323905: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF06	Engine uppercarr. Safety checks (SIL) Injector Bank A permanently energized Engine stop, Start lock 323906: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF07	Engine uppercarr. Safety checks (SIL) Injector Bank B permanently energized Engine stop, Start lock 323907: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF08	Engine uppercarr. Safety checks (SIL) Injector Bank C permanently energized Engine stop, Start lock 323908: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF09	Engine uppercarr. Safety checks (SIL) Injector Bank D permanently energized Engine stop, Start lock 323909: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF0A	Engine uppercarr. Safety checks (SIL) Injector excessive current Engine stop, Start lock 323910: Turn ignition on / off, Update or replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BEF0B	Engine uppercarr. Safety checks (SIL) Plausibility error Monitoring PS2-Pin Engine stop, Start lock 323911: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF0C	Engine uppercarr. Safety checks (SIL) Max. temperature injector exceeded Engine stop, Start lock 323912: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BEF0D	Engine uppercarr. Safety checks (SIL) Internal error CPU (excessive temperature) Engine stop, Start lock 323913: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF000	Engine uppercarr. Safety checks (SIL) Plausibility error rpm monitoring Engine stop, Start lock 324000: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF001	Engine uppercarr. Safety checks (SIL) all rpm signals erroneous/missing Engine stop, Start lock 324001: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF002	Engine uppercarr. Safety checks (SIL) Crankshaft signals erroneous/implausible (Signal sample) Engine stop, Start lock 324002: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF003	Engine uppercarr. Safety checks (SIL) Crankshaft signals erroneous/implausible (failure) Engine stop, Start lock 324003: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF004	Engine uppercarr. Safety checks (SIL) Crankshaft signals erroneous/implausible (difference) Engine stop, Start lock 324004: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF005	Engine uppercarr. Safety checks (SIL) Nockenwellensignale erroneous/implausible (Signal sample) Engine stop, Start lock 324005: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF006	Engine uppercarr. Safety checks (SIL) Nockenwellensignale erroneous/implausible (failure) Engine stop, Start lock 324006: Turn ignition on / off, Update or replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF007	Engine uppercarr. Safety checks (SIL) Nockenwellensignale erroneous/implausible (difference) Engine stop, Start lock 324007: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF008	Engine uppercarr. Safety checks (SIL) Reference voltage 12V outside permissible range Engine stop, Start lock 324008: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF009	Engine uppercarr. Safety checks (SIL) Incorrect software or hardware version (not SIL-able) Engine stop, Start lock 324009: Replace control unit	A750		E	2
8BF00A	Engine uppercarr. Safety checks (SIL) Incorrect hardware version (not SIL-able) Engine stop, Start lock 324010: Replace control unit	A750		E	2
8BF00B	Engine uppercarr. Safety checks (SIL) Temperature difference between injector / end stage too high Engine stop, Start lock 324011: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF100	Engine uppercarr. Safety checks (SIL) Internal software error (incorrect Parameter) Engine stop, Start lock 324100: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF105	Engine uppercarr. Safety checks (SIL) Starter turns without actuation Engine stop, Start lock 324105: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF106	Engine uppercarr. Safety checks (SIL) Injectors do not turn off Engine stop, Start lock 324106: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF107	Engine uppercarr. Safety checks (SIL) Fatal internal error (Monitoring Status machine) Engine stop, Start lock 324107: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF108	Engine uppercarr. Safety checks (SIL) Configuration error Vehicle-CAN Engine stop, Start lock 324108: Turn ignition on / off, Update or replace engine control unit	A750		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF109	Engine uppercarr. Safety checks (SIL) Dateneübertragung Vehicle -CAN gestoert Engine stop, Start lock 324109: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF10A	Engine uppercarr. Safety checks (SIL) Plausibility error Signals Vehicle -CAN Engine stop, Start lock 324110: Turn ignition on / off, Update or replace engine control unit	A750		E	2
8BF200	Engine uppercarr. SCR-control unit Hardware error metering unit No measures or pump is in off mode 324200:	A750		E	1
8BF201	Engine uppercarr. SCR-control unit Metering unit outside permissible limits Pump is in off mode 324201: No measures, error due to environmental cond.	A750		E	1
8BF202	Engine uppercarr. SCR-control unit mechanical error metering unit Pump is in off mode 324202: Check meter	A750		E	1
8BF203	Engine uppercarr. SCR-control unit Memory error metering unit Pump is in off mode 324203: Calibrate meter, if error present always, flash meters	A750		E	1
8BF204	Engine uppercarr. SCR-control unit Urea pressure, output line no reaction 324204: Check outgoing line and its conn.	A750		E	1
8BF205	Engine uppercarr. SCR-control unit Urea pressure, input line No measures or pump is in off mode 324205: Check input line and its connections	A750		E	1
8BF206	Engine uppercarr. SCR-control unit Urea pressure, nozzle no reaction 324206: Check the spray on nozzle	A750		E	1
8BF207	Engine uppercarr. SCR-control unit Urea pressure, injector Pump is in off mode 324207: Check plug and cable; if no short circuit present, then replace device	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF208	Engine uppercarr. SCR-control unit Control unit error, CAN-communication, display No measures or pump is in off mode 324208: Check CAN-connections	A750		E	1
8BF209	Engine uppercarr. SCR-control unit Battery voltage outside permissible limits Pump is in off mode 324209: Check supply voltage	A750		E	1
8BF20A	Engine uppercarr. SCR-control unit Temperature CAT, Sensor inflow outside permissible limits Pump is in off mode 324210: No measures, error due to environmental cond.	A750		E	1
8BF20B	Engine uppercarr. SCR-control unit Temperature CAT, Sensor inflow erroneous Pump is in off mode 324211: Check plug and cable; if no short circuit present, then replace device	A750		E	1
8BF20C	Engine uppercarr. SCR-control unit TemperatureCAT, Sensor outflow outside permissible limits Pump is in off mode 324212: No measures, error due to environmental cond.	A750		E	1
8BF20D	Engine uppercarr. SCR-control unit Temperature CAT, Sensor outflow erroneous Pump is in off mode 324213: Check plug and cable; if no short circuit present, then replace device	A750		E	1
8BF300	Engine uppercarr. SCR-control unit Tank sensor erroneous No measures or pump is in off mode 324300: Check plug and cable; if no short circuit present, then replace device	A750		E	1
8BF301	Engine uppercarr. SCR-control unit Tank sensor outside permissible range no reaction 324301: No measures, error due to environmental cond.	A750		E	1
8BF302	Engine uppercarr. SCR-control unit Line heating erroneous No measures, error due to environmental cond. 324302: Check plug and cable; if no short circuit present, then replace device	A750		E	1
8BF303	Engine uppercarr. SCR-control unit Line heating, temperature outside permissible range Pump is in off mode 324303: No measures, error due to environmental cond.	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF304	Engine uppercarr. SCR-control unit Valve heat pump erroneous Pump is in off mode 324304: Defrost system	A750		E	1
8BF305	Engine uppercarr. SCR-control unit Communcation error NOx-Sensor inflow Pump is in off mode 324305: Check electr. conn. of SCR System	A750		E	1
8BF306	Engine uppercarr. SCR-control unit Heater and O2 NOx-Sensor inflow erroneous No measures or pump is in off mode 324306: Replace Upstream NOx Sensor	A750		E	1
8BF307	Engine uppercarr. SCR-control unit NOx-Sensor inflow erroneous No measures or pump is in off mode 324307: Check plug and cable; if no short circuit present, then replace device	A750		E	1
8BF308	Engine uppercarr. SCR-control unit Communcation error NOx-Sensor outflow Pump is in off mode 324308: Check electr. conn. of SCR System	A750		E	1
8BF309	Engine uppercarr. SCR-control unit Heater and O2 NOx-Sensor outflow erroneous No measures or pump is in off mode 324309: Replace downstream NOx Sensor	A750		E	1
8BF30A	Engine uppercarr. SCR-control unit NOx-Sensor outflow erroneous No measures or pump is in off mode 324310: Check plug and cable; if no short circuit present, then replace device	A750		E	1
8BF500	Engine uppercarr. Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324500: Check for plugged/ damaged nitrogen line or IV is closed blocked	A750		E	1
8BF501	Engine uppercarr. Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324501: Check of fuel line for leaks or IV blocked in open position	A750		E	1
8BF502	Engine uppercarr. Dosing unit 1 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324502: Check of fuel supply	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF503	Engine uppercarr. Dosing unit 1 Urea "DEF" Data transfer on CAN erroneous/missing Possibly regeneration not possible 324503: Check the fuel line for leaks or blockage, check fuel pump	A750		E	1
8BF504	Engine uppercarr. Dosing unit 1 Urea "DEF" Electric defect on shut off valve Possibly regeneration not possible 324504: Broken line DCU 17 to measuring unit, visual check, moisture, wiring	A750		E	1
8BF505	Engine uppercarr. Dosing unit 1 Urea "DEF" System error control shut off valve Possibly regeneration not possible 324505: Shutoff valve blocked: - Replace MU, bleed system	A750		E	1
8BF506	Engine uppercarr. Dosing unit 1 Urea "DEF" Back flow error on sensor pressure+temperature Possibly regeneration not possible 324506: Check of fuel line for leaks or IV blocked in open position	A750		E	1
8BF507	Engine uppercarr. Dosing unit 1 Urea "DEF" Back flow error on sensor pressure+temperature Possibly regeneration not possible 324507: Broken line DCU 17 to test unit, visual check, moisture, wiring	A750		E	1
8BF508	Engine uppercarr. Dosing unit 1 Urea "DEF" Electric defect on Dosing valve Possibly regeneration not possible 324508: Broken line DCU 17 to test unit, visual check, moisture, wiring	A750		E	1
8BF509	Engine uppercarr. Dosing unit 1 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324509: Changer MU, System Entlueften	A750		E	1
8BF50A	Engine uppercarr. Dosing unit 1 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324510: Metering valve opens too slow: Check power supply, restart system, change MU, vent	A750		E	1
8BF50B	Engine uppercarr. Dosing unit 1 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324511: Broken line DCU 17 to pressure sensor, visual check, moisture, wiring	A750		E	1
8BF50C	Engine uppercarr. Dosing unit 1 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324512: Downstream pressure sensor signal not plausible: - change MU, bleed system	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF50D	Engine uppercarr. Dosing unit 1 Urea "DEF" Control unit injection system erroneous Possibly regeneration not possible 324513: Change U, bleed system	A750		E	1
8BF600	Engine uppercarr. Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324600: DCU17 wechseln	A750		E	1
8BF601	Engine uppercarr. Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324601: Check power supply of DCU17, replace control unit	A750		E	1
8BF602	Engine uppercarr. Dosing unit 2 Urea "DEF" Depatronic fuel pressure Possibly regeneration not possible 324602: Check Can connection lines incl. connections of connections	A750		E	1
8BF603	Engine uppercarr. Dosing unit 2 Urea "DEF" Data transfer on CAN erroneous/missing Possibly regeneration not possible 324603: Data from LIDEC is incorrect, not available or not the right data. Check LIDEC error memory	A750		E	1
8BF604	Engine uppercarr. Dosing unit 2 Urea "DEF" Electric defect on shut off valve Possibly regeneration not possible 324604: Voltage supply of DCU17 is too high, check electr. Lines of DCU17 for short circuit	A750		E	1
8BF605	Engine uppercarr. Dosing unit 2 Urea "DEF" System error control shut off valve Possibly regeneration not possible 324605: Problem during System, check DCU17 error stack trouble shooting dep. failure	A750		E	1
8BF60A	Engine uppercarr. Dosing unit 2 Urea "DEF" System error control Dosing valve Possibly regeneration not possible 324610: Reset des HC-meters (KeyOff- wait 5 sec. - KeyOn)	A750		E	1
8BF60B	Engine uppercarr. Dosing unit 2 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324611: Check application dating - check Software Version of HC-meter	A750		E	1
8BF60C	Engine uppercarr. Dosing unit 2 Urea "DEF" Outflow error Pressure sensor Possibly regeneration not possible 324612: Turn HC-meter off (wait 5 sec.), turn on, check Software version, replace HC-meter	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF60D	Engine uppercarr. Dosing unit 2 Urea "DEF" Control unit injection system erroneous Possibly regeneration not possible 324613:	A750		E	1
8BF704	Engine uppercarr. Temperature monitoring "DOC" Minimum temperature fallen below Warning light on in operation no regeneration permitted 324704: Check HC meter, DOC, then carry out Service Regeneration	A750		E	1
8BF705	Engine uppercarr. Temperature monitoring "DOC" Maximum temperature exceeded Warning light on - in operation no regeneration permitted - power reduction 324705: Check HC meter, DOC, then carry out Service Regeneration	A750		E	1
8BF800	Engine uppercarr. Monitoring Particle filter "DPF" Oil in exhaust system Warning light on in operation no regeneration permitted 324800: Check: - DOC (possibly replace or turn over and service regeneration)	A750		E	1
8BF801	Engine uppercarr. Monitoring Particle filter "DPF" Maximum ash load reached Warning light on in operation no regeneration permitted 324801: Clean DPF or replace	A750		E	1
8BF802	Engine uppercarr. Monitoring Particle filter "DPF" Differnce pressure filter too high Warning light on- in operation no regeneration permitted possible power reduction 324802: Clean DPF or replace	A750		E	1
8BF803	Engine uppercarr. Monitoring Particle filter "DPF" Differnce pressure filter too low Warning light on - in operation no regeneration permitted - power reduction 324803: Replace DPF	A750		E	1
8BF804	Engine uppercarr. Monitoring Particle filter "DPF" Maximum number aborted heat phases exceeded Warning light on- in operation no regeneration permitted possible power reduction 324804: Request Service regeneration	A750		E	1
8BF805	Engine uppercarr. Monitoring Particle filter "DPF" Maximum number aborted regeneration phases exceeded Warning light on- in operation no regeneration permitted possible power reduction 324805: Request Service regeneration	A750		E	1
8BF806	Engine uppercarr. Monitoring Particle filter "DPF" Maximum temperature increase and max. temperature exceeded Warning light on 324806: Replace DPF	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF807	Engine uppercarr. Monitoring Particle filter "DPF" Maximum temperature limit exceeded Warning light on 324807: Replace DPF	A750		E	1
8BF900	Engine uppercarr. OBD Error Ambient pressure sensor Error Use replacement value, no reaction 324900: Check op. status of engine, replace engine control unit	A750		E	1
8BF901	Engine uppercarr. OBD Error Ambient temperature sensor Error Use replacement value, no reaction 324901: Check wiring, control units, sensors	A750		E	1
8BF902	Engine uppercarr. OBD Error ChargeAir Temperature sensor Error Use replacement value, no reaction 324902: Check wiring, control units, sensors	A750		E	1
8BF903	Engine uppercarr. OBD Error Charge air pressure sensor error Use replacement value, no reaction 324903: Check wiring, control units, sensors	A750		E	1
8BF904	Engine uppercarr. OBD Error Error Pressure deviation charge air pr. regulator Warning light on 324904: Check intake system for leaks, Wastegate	A750		E	1
8BF905	Engine uppercarr. OBD Error Error restrictor flap Power reduction of Diesel engine 324905: Check wiring, control units, sensors	A750		E	1
8BF906	Engine uppercarr. OBD Error Rail pressure sensor 1 Error Power red. in case of failure of both Commonrail pr.sensors, otherwise no reaction, engine standstill after delay 324906: Check wiring, control units, sensors	A750		E	1
8BF907	Engine uppercarr. OBD Error Rail pressure sensor 2 Error Power red. in case of failure of both Commonrail pr.sensors, otherwise no reaction, engine standstill after delay 324907: Check wiring, control units, sensors	A750		E	1
8BF908	Engine uppercarr. OBD Error Pressure reg. valve (PCV) Error Possibly high pr. reg/ emerg. op. activated 324908: Check wiring harness, plug, CR-components2, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BF909	Engine uppercarr. OBD Error Rail pressure reg. 1 Error no reaction 324909: Nitrogen circuit,Rail sensor,DBV,high pr. pump,wiring	A750		E	1
8BF90A	Engine uppercarr. OBD Error Rail pressure reg. 2 Error no reaction 324910: Nitrogen circuit,Rail sensor,DBV,high pr. pump,wiring	A750		E	1
8BF90B	Engine uppercarr. OBD Error Metering unit (VCV) Error Possibly high pr. reg/ emerg. op. activated 324911: Check wiring harness, plug, CR-components1, engine control unit	A750		E	1
8BF90C	Engine uppercarr. OBD Error Error Injector 1 Injector is not energized, no reaction 324912: Check wiring, plug, injector, engine control unit	A750		E	1
8BF90D	Engine uppercarr. OBD Error Error Injector 2 Injector is not energized, no reaction 324913: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA00	Engine uppercarr. OBD Error Error Injector 3 Injector is not energized, no reaction 325000: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA01	Engine uppercarr. OBD Error Error Injector 4 Injector is not energized, no reaction 325001: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA02	Engine uppercarr. OBD Error Error Injector 5 Injector is not energized, no reaction 325002: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA03	Engine uppercarr. OBD Error Error Injector 6 Injector is not energized, no reaction 325003: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA04	Engine uppercarr. OBD Error Error Injector 7 Injector is not energized, no reaction 325004: Check wiring, plug, injector, engine control unit	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFA05	Engine uppercarr. OBD Error Error Injector 8 Injector is not energized, no reaction 325005: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA06	Engine uppercarr. OBD Error Error fuel temperature sensor Use replacement value, no reaction 325006: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA07	Engine uppercarr. OBD Error Error coolant temperature sensor Use replacement value, no reaction 325007: Check wiring, plug, injector, engine control unit	A750		E	1
8BFA08	Engine uppercarr. OBD Error Error crankshaft rpm sensor Emerg. shut off only at sim. Failure of both Rpm sensors 325008: Check rpm sensor, distance sensor to flywheel	A750		E	1
8BFA09	Engine uppercarr. OBD Error Error Index sensor camshaft Emerg. shut off only at sim. Failure of both Rpm sensors 325009: Check rpm sensor, distance sensor to flywheel	A750		E	1
8BFA0A	Engine uppercarr. OBD Error SCR catalytic converter inflow temp. sensor error Pump is in off mode 325010: No measures, error due to environmental conditions	A750		E	1
8BFA0B	Engine uppercarr. OBD Error SCR catalytic converter inflow temp. sensor error - OOR MIN Pump is in off mode 325011: No measures, error due to environmental cond.	A750		E	1
8BFA0C	Engine uppercarr. OBD Error SCR catalytic converter outflow temp. sensor error Pump is in off mode 325012: No measures, error due to environmental cond.	A750		E	1
8BFA0D	Engine uppercarr. OBD Error SCR catalytic converter Efficiency error (DEF-Quality, defective cat.) Actuation error lights, possible momentum reduction 325013: Check SCR-control unit, System for leaks, DEF-Quality	A750		E	1
8BFB00	Engine uppercarr. OBD Error SCR catalytic converter Efficiency error (Monitor 2) Actuation warning lights, possible momentum limitation 325100: Check SCR-control unit, System for leaks, DEF-Quality	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFB01	Engine uppercarr. OBD Error SCR catalytic converter Efficiency error (incorrect medium, Monitor 2) Actuation warning lights, possible momentum limitation 325101: Check SCR-control unit, System for leaks, DEF-Quality	A750		E	1
8BFB02	Engine uppercarr. OBD Error NOx (Upstream) - Error Sensor communication Pump is in off mode 325102: Check electr. conn. from SCR System	A750		E	1
8BFB03	Engine uppercarr. OBD Error NOx (Upstream) - Error Sensor No measures or pump is in off mode 325103: Check plug, wiring, control units	A750		E	1
8BFB04	Engine uppercarr. OBD Error NOx (Downstream) - Error Sensor communication Pump is in off mode 325104: Check electr. conn. from SCR System	A750		E	1
8BFB05	Engine uppercarr. OBD Error NOx (Downstream) - Error Sensor No measures or pump is in off mode 325105: Check plug, wiring, control units	A750		E	1
8BFB06	Engine uppercarr. OBD Error Urea Injector Error - short circuit Pump is in off mode 325106: Check plug, wiring, control units	A750		E	1
8BFB07	Engine uppercarr. OBD Error Urea Injector Error open line Pump is in off mode 325107: Check plug, wiring, control units	A750		E	1
8BFB08	Engine uppercarr. OBD Error Urea pressure Error Pump is in Off mode, no measures or pump is in Off mode 325108: Check plug, wiring, control units	A750		E	1
8BFB09	Engine uppercarr. OBD Error Urea pressure Error - OOR MIN No measures or pump is in off mode 325109:	A750		E	1
8BFB0A	Engine uppercarr. OBD Error Urea pressure mechanical error 1 no reaction 325110: Check the spray on nozzle	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFB0B	Engine uppercarr. OBD Error Urea pressure mechanical error 3 no reaction 325111: Check the spray on nozzle	A750		E	1
8BFB0C	Engine uppercarr. OBD Error Metering error Pump is in off mode 325112: check meter, replace if nec.	A750		E	1
8BFB0D	Engine uppercarr. OBD Error Pump temperature and heater error Pump is in Off mode, no measures or pump is in Off mode 325113: No measures, error due to environmental cond.	A750		E	1
8BFC00	Engine uppercarr. OBD Error Urea tank Heater erroneous (driver) No measures or pump is in off mode 325200: Check plug, wiring, control units	A750		E	1
8BFC01	Engine uppercarr. OBD Error Line heating Urea erroneous (driver) No measures, error due to environmental cond. 325201: Check plug, wiring, control units	A750		E	1
8BFC02	Engine uppercarr. OBD Error Pump heater Urea erroneous (driver) No measures or pump is in off mode 325202:	A750		E	1
8BFC03	Engine uppercarr. OBD Error Urea tank Temperature sensor erroneous No measures, error due to environmental cond. 325203: No measures, error due to environmental cond.	A750		E	1
8BFC04	Engine uppercarr. OBD Error Urea tank Temperature sensor erroneous (OOR MIN) no reaction 325204: No measures, error due to environmental cond.	A750		E	1
8BFC05	Engine uppercarr. OBD Error Urea tank fill level sensor erroneous No measures or pump is in off mode 325205: Check plug, wiring, control units	A750		E	1
8BFC06	Engine uppercarr. OBD Error Urea tank fill level sensor erroneous no reaction 325206: No measure	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFC07	Engine uppercarr. OBD Error Fill level urea tank threshold 3 Actuation warning lights, possible momentum limitation 325207: Refill urea tank	A750		E	1
8BFC08	Engine uppercarr. OBD Error Fill level urea tank threshold 2 Actuation warning lights, possible momentum limitation 325208: Refill urea tank	A750		E	1
8BFC09	Engine uppercarr. OBD Error Fill level urea tank threshold 1 Actuation warning lights, possible momentum limitation 325209: Refill urea tank	A750		E	1
8BFC0A	Engine uppercarr. OBD Error Fill level urea tank threshold 0 Actuation warning lights, possible momentum limitation 325210: Refill urea tank	A750		E	1
8BFC0B	Engine uppercarr. OBD Error SCR ECM Error power supply Pump is in Off-mode, no measure or - pump is in off-mode 325211: Check supply voltage	A750		E	1
8BFC0C	Engine uppercarr. OBD Error SCR ECM Error Temperature Pump is in off mode 325212: No measures, error due to environmental cond.	A750		E	1
8BFC0D	Engine uppercarr. OBD Error SCR ECM CAN communication erroneous No measures or Pump is in off-mode 325213: Check CAN-connections	A750		E	1
8BFD00	Engine uppercarr. Error Exhaust treatment "AGN" Particle filter "DPF" load status threshold 4 reached Exhaust back pressure/DPF Temperature high 325300: Activate manual regeneration	A750		E	1
8BFD01	Engine uppercarr. Error Exhaust treatment "AGN" Particle filter "DPF" load status threshold 5 reached Exhaust back pressure/DPF Temperature high 325301: Activate Service Regeneration	A750		E	2
8BFE00	Engine uppercarr. OBD Error SCR power supply, Sensor error Engine cannot be started or engine shut off 325400: Check on board network	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8BFE01	Engine uppercarr. OBD Error ECM internal error control unit Engine cannot be started or engine shut off 325401: Load current software, replace engine control unit	A750		E	1
8BFE02	Engine uppercarr. OBD Error CAN-communication (J1939) interrupted Change over to plausible speed source 325402: Check cable / plug / CAN-participant	A750		E	1
8BFE03	Engine uppercarr. OBD Error CAN-communication (J1939) maximum transmission cycle exceeded Possibly power reduction 325403: Check cable / plug / CAN-participant	A750		E	1
8BFE04	Engine uppercarr. OBD Error Injector 9 erroneous Injector unit is not energized 325404: Check cable, plug, injection unit, engine control unit	A750		E	1
8BFE0D	Engine uppercarr. OBD Error Start block, problem exhaust aftertreatment/fill level urea tank Start lock 325413: Check wiring, exhaust system; check fill level urea, add urea	A750		E	1
8D0116	Engine uppercarr. Environmental pressure sensor Plausibility error no reaction Check control unit	A750		E	1
8D0164	Engine uppercarr. Environmental pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D0307	Engine uppercarr. Air filter Combi sensor (pressure) Value below warning threshold Engine derating 25% (Mach-FL) Check air filter	A750		E	1
8D0416	Engine uppercarr. Air filter Combi sensor (temperature) Plausibility error no reaction Check components	A750		E	1
8D0505	Engine uppercarr. Air filter Combi sensor Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A750.X1:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0603	Engine uppercarr. Charge air temperature sensor suction pipe short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X3:37		E	1
8D0604	Engine uppercarr. Charge air temperature sensor suction pipe short circuit to ground no reaction Check wiring between control unit and components	A750.X3:37		E	1
8D0608	Engine uppercarr. Charge air temperature sensor suction pipe Line interruption no reaction Check wiring between control unit and components	A750.X3:37		E	1
8D0609	Engine uppercarr. Charge air temperature sensor suction pipe Value above warning threshold no reaction Check operation status of engine	A750.X3:37		E	1
8D060A	Engine uppercarr. Charge air temperature sensor suction pipe Value above critical threshold no reaction Check operation status of engine	A750.X3:37		E	1
8D0616	Engine uppercarr. Charge air temperature sensor suction pipe Plausibility error no reaction Check components	A750.X3:37		E	1
8D0664	Engine uppercarr. Charge air temperature sensor suction pipe Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X3:37		E	1
8D0703	Engine uppercarr. charge air pressure sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:14		E	1
8D0709	Engine uppercarr. charge air pressure sensor Value above warning threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750.X3:14		E	1
8D070A	Engine uppercarr. charge air pressure sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750.X3:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D070B	Engine uppercarr. charge air pressure sensor Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:14		E	1
8D0714	Engine uppercarr. charge air pressure sensor Signal remains below nominal value no reaction Air intake manifold, check wastegate	A750.X3:14		E	1
8D0715	Engine uppercarr. charge air pressure sensor Signal remains above nominal value no reaction Air intake manifold, check wastegate	A750.X3:14		E	1
8D0716	Engine uppercarr. charge air pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:14		E	1
8D0764	Engine uppercarr. charge air pressure sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:14		E	1
8D0774	Engine uppercarr. charge air pressure sensor Lower limit value for regulation reached no reaction Air intake manifold, check wastegate	A750.X3:14		E	1
8D0775	Engine uppercarr. charge air pressure sensor Upper limit value for regulation reached no reaction Air intake manifold, check wastegate	A750.X3:14		E	1
8D0803	Engine uppercarr. Ambient temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:40		E	1
8D0804	Engine uppercarr. Ambient temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A750.X1:40		E	1
8D0808	Engine uppercarr. Ambient temperature sensor Line interruption no reaction Check wiring between control unit and components	A750.X1:40		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0816	Engine uppercarr. Ambient temperature sensor Plausibility error no reaction Check components	A750.X1:40		E	1
8D0864	Engine uppercarr. Ambient temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:40		E	1
8D0903	Engine uppercarr. coolant temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:45		E	1
8D0904	Engine uppercarr. coolant temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:45		E	1
8D0908	Engine uppercarr. coolant temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:45		E	1
8D0909	Engine uppercarr. coolant temperature sensor Value above warning threshold no reaction Check operation status of engine	A750.X3:45		E	1
8D090A	Engine uppercarr. coolant temperature sensor Value above critical threshold no reaction Check operation status of engine	A750.X3:45		E	1
8D0916	Engine uppercarr. coolant temperature sensor Plausibility error no reaction Check components	A750.X3:45		E	1
8D0964	Engine uppercarr. coolant temperature sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:45		E	1
8D0A03	Engine uppercarr. Coolant level sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:19		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0A07	Engine uppercarr. Coolant level sensor Value below warning threshold no reaction Check coolant level	A750.X2:19		E	1
8D0A0B	Engine uppercarr. Coolant level sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X2:19		E	1
8D0A21	Engine uppercarr. Coolant level sensor Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:19		E	1
8D0A64	Engine uppercarr. Coolant level sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X2:19		E	1
8D0B04	Engine uppercarr. Rail pressure sensor short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:26		E	1
8D0B09	Engine uppercarr. Rail pressure sensor Value above warning threshold no reaction Check operation status of engine	A750.X3:26		E	1
8D0B0A	Engine uppercarr. Rail pressure sensor Value above critical threshold Engine derating 50% (Mach-FL) Check operation status of engine	A750.X3:26		E	1
8D0B0D	Engine uppercarr. Rail pressure sensor Short circuit after supply voltage or line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:26		E	1
8D0B0E	Engine uppercarr. Rail pressure sensor Signal increases too fast no reaction Check wiring between control unit and components	A750.X3:26		E	1
8D0B0F	Engine uppercarr. Rail pressure sensor Signal decreases too fast no reaction Check wiring between control unit and components	A750.X3:26		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0B10	Engine uppercarr. Rail pressure sensor Start pressure too low no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750.X3:26		E	1
8D0B11	Engine uppercarr. Rail pressure sensor Signal noise too high no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750.X3:26		E	1
8D0B12	Engine uppercarr. Rail pressure sensor No signal dynamics Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:26		E	1
8D0B13	Engine uppercarr. Rail pressure sensor Leakage no reaction Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750.X3:26		E	1
8D0B14	Engine uppercarr. Rail pressure sensor Signal remains below nominal value Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750.X3:26		E	1
8D0B15	Engine uppercarr. Rail pressure sensor Signal remains above nominal value Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750.X3:26		E	1
8D0B64	Engine uppercarr. Rail pressure sensor Error supply voltage sensors Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:26		E	1
8D0C14	Engine uppercarr. Fuel supply valve (VCV) flow regulation Signal remains below nominal value no reaction Check wiring, components, control unit	A750.X3:28		E	1
8D0C15	Engine uppercarr. Fuel supply valve (VCV) flow regulation Signal remains above nominal value no reaction Check wiring, components, control unit	A750.X3:28		E	1
8D0C16	Engine uppercarr. Fuel supply valve (VCV) flow regulation Plausibility error Engine derating 50% (Mach-FL) Check fuel circuit, rail sensors, pressure relief valve 1, high pressure pump, wiring	A750.X3:28		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0D03	Engine uppercarr. Fuel pressure sensor (low pressure system) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D0D07	Engine uppercarr. Fuel pressure sensor (low pressure system) Value below warning threshold no reaction Check operation status of engine	A750		E	1
8D0D09	Engine uppercarr. Fuel pressure sensor (low pressure system) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D0D0A	Engine uppercarr. Fuel pressure sensor (low pressure system) Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D0D0B	Engine uppercarr. Fuel pressure sensor (low pressure system) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8D0D0C	Engine uppercarr. Fuel pressure sensor (low pressure system) Value below critical threshold no reaction Check operation status of engine	A750		E	1
8D0D64	Engine uppercarr. Fuel pressure sensor (low pressure system) Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8D0E03	Engine uppercarr. Fuel temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:41		E	1
8D0E04	Engine uppercarr. Fuel temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:41		E	1
8D0E08	Engine uppercarr. Fuel temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:41		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D0E09	Engine uppercarr. Fuel temperature sensor Value above warning threshold no reaction Check operation status of engine	A750.X3:41		E	1
8D0E0A	Engine uppercarr. Fuel temperature sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750.X3:41		E	1
8D0E16	Engine uppercarr. Fuel temperature sensor Plausibility error no reaction Check components	A750.X3:41		E	1
8D0E64	Engine uppercarr. Fuel temperature sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:41		E	1
8D0F03	Engine uppercarr. Oil level sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X4:37		E	1
8D0F07	Engine uppercarr. Oil level sensor Value below warning threshold no reaction Check oil level, oil level sensor, engine must be at an incline of 0°	A750.X4:37		E	1
8D0F09	Engine uppercarr. Oil level sensor Value above warning threshold no reaction Check operation status of engine	A750.X4:37		E	1
8D0F0B	Engine uppercarr. Oil level sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X4:37		E	1
8D0F0C	Engine uppercarr. Oil level sensor Value below critical threshold no reaction Check oil level, oil level sensor, engine must be at an incline of 0°	A750.X4:37		E	1
8D0F64	Engine uppercarr. Oil level sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X4:37		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1003	Engine uppercarr. oil pressure sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:10		E	1
8D1007	Engine uppercarr. oil pressure sensor Value below warning threshold no reaction Check operation status of engine	A750.X3:10		E	1
8D100B	Engine uppercarr. oil pressure sensor Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:10		E	1
8D100C	Engine uppercarr. oil pressure sensor Value below critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750.X3:10		E	1
8D1016	Engine uppercarr. oil pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check operation status of engine	A750.X3:10		E	1
8D1064	Engine uppercarr. oil pressure sensor Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:10		E	1
8D1103	Engine uppercarr. oil temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X4:38		E	1
8D1104	Engine uppercarr. oil temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A750.X4:38		E	1
8D1108	Engine uppercarr. oil temperature sensor Line interruption no reaction Check wiring between control unit and components	A750.X4:38		E	1
8D1109	Engine uppercarr. oil temperature sensor Value above warning threshold no reaction Check operation status of engine	A750.X4:38		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D110A	Engine uppercarr. oil temperature sensor Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750.X4:38		E	1
8D110B	Engine uppercarr. oil temperature sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X4:38		E	1
8D1164	Engine uppercarr. oil temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X4:38		E	1
8D1203	Engine uppercarr. Water level probe fuel filter short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:40		E	1
8D1204	Engine uppercarr. Water level probe fuel filter short circuit to ground no reaction Check wiring between control unit and components	A750.X1:40		E	1
8D1208	Engine uppercarr. Water level probe fuel filter Line interruption no reaction Check wiring between control unit and components	A750.X1:40		E	1
8D120A	Engine uppercarr. Water level probe fuel filter Value above critical threshold Engine derating 25% (Mach-FL) Check operation status of engine	A750.X1:40		E	1
8D1221	Engine uppercarr. Water level probe fuel filter Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X1:40		E	1
8D1264	Engine uppercarr. Water level probe fuel filter Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:40		E	1
8D1303	Engine uppercarr. Rpm sensor camshaft short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X4:51		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1304	Engine uppercarr. Rpm sensor camshaft short circuit to ground no reaction Check wiring between control unit and components	A750.X4:51		E	1
8D1308	Engine uppercarr. Rpm sensor camshaft Line interruption no reaction Check wiring between control unit and components	A750.X4:51		E	1
8D1316	Engine uppercarr. Rpm sensor camshaft Plausibility error no reaction Check rpm sensors	A750.X4:51		E	1
8D1403	Engine uppercarr. Rpm sensor crankshaft short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:52		E	1
8D1404	Engine uppercarr. Rpm sensor crankshaft short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:52		E	1
8D1408	Engine uppercarr. Rpm sensor crankshaft Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:52		E	1
8D1416	Engine uppercarr. Rpm sensor crankshaft Plausibility error Engine derating 25% (Mach-FL) Check rpm sensors	A750.X4:52		E	1
8D1509	Engine uppercarr. Engine speed Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D150A	Engine uppercarr. Engine speed Value above critical threshold no reaction Check operation status of engine	A750		E	1
8D1603	Engine uppercarr. Status Heat flange 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:38		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1604	Engine uppercarr. Status Heat flange 1 short circuit to ground no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D1608	Engine uppercarr. Status Heat flange 1 Line interruption no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D166D	Engine uppercarr. Status Heat flange 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D166E	Engine uppercarr. Status Heat flange 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D166F	Engine uppercarr. Status Heat flange 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D1670	Engine uppercarr. Status Heat flange 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D1703	Engine uppercarr. Heat flange 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D1704	Engine uppercarr. Heat flange 1 short circuit to ground no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D1708	Engine uppercarr. Heat flange 1 Line interruption no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D176C	Engine uppercarr. Heat flange 1 Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:38		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D176D	Engine uppercarr. Heat flange 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D176E	Engine uppercarr. Heat flange 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D176F	Engine uppercarr. Heat flange 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D1770	Engine uppercarr. Heat flange 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:38		E	1
8D1803	Engine uppercarr. Status Heat flange 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D1804	Engine uppercarr. Status Heat flange 2 short circuit to ground no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D1808	Engine uppercarr. Status Heat flange 2 Line interruption no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D186D	Engine uppercarr. Status Heat flange 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D186E	Engine uppercarr. Status Heat flange 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D186F	Engine uppercarr. Status Heat flange 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:42		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1870	Engine uppercarr. Status Heat flange 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D1903	Engine uppercarr. Heat flange 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D1904	Engine uppercarr. Heat flange 2 short circuit to ground no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D1908	Engine uppercarr. Heat flange 2 Line interruption no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D196C	Engine uppercarr. Heat flange 2 Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:42		E	1
8D196D	Engine uppercarr. Heat flange 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D196E	Engine uppercarr. Heat flange 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D196F	Engine uppercarr. Heat flange 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D1970	Engine uppercarr. Heat flange 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:42		E	1
8D1A03	Engine uppercarr. Urea (AdBlue) Tank heater valve short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1A04	Engine uppercarr. Urea (AdBlue) Tank heater valve short circuit to ground no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D1A08	Engine uppercarr. Urea (AdBlue) Tank heater valve Line interruption no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D1A49	Engine uppercarr. Urea (AdBlue) Tank heater valve Error blocked open no reaction Check components	A750.X2:9		E	1
8D1A4A	Engine uppercarr. Urea (AdBlue) Tank heater valve Error blocked closed no reaction Check components	A750.X2:9		E	1
8D1A6C	Engine uppercarr. Urea (AdBlue) Tank heater valve Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:9		E	1
8D1A6D	Engine uppercarr. Urea (AdBlue) Tank heater valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D1A6E	Engine uppercarr. Urea (AdBlue) Tank heater valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D1A6F	Engine uppercarr. Urea (AdBlue) Tank heater valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D1A70	Engine uppercarr. Urea (AdBlue) Tank heater valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D1B03	Engine uppercarr. Urea (AdBlue) Pump heater valve short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:33		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1B04	Engine uppercarr. Urea (AdBlue) Pump heater valve short circuit to ground no reaction Check wiring between control unit and components	A750.X2:33		E	1
8D1B08	Engine uppercarr. Urea (AdBlue) Pump heater valve Line interruption no reaction Check wiring between control unit and components	A750.X2:33		E	1
8D1B49	Engine uppercarr. Urea (AdBlue) Pump heater valve Error blocked open no reaction Check components	A750.X2:33		E	1
8D1B4A	Engine uppercarr. Urea (AdBlue) Pump heater valve Error blocked closed no reaction Check components	A750.X2:33		E	1
8D1B6C	Engine uppercarr. Urea (AdBlue) Pump heater valve Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:33		E	1
8D1B6D	Engine uppercarr. Urea (AdBlue) Pump heater valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:33		E	1
8D1B6E	Engine uppercarr. Urea (AdBlue) Pump heater valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:33		E	1
8D1B6F	Engine uppercarr. Urea (AdBlue) Pump heater valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:33		E	1
8D1B70	Engine uppercarr. Urea (AdBlue) Pump heater valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:33		E	1
8D1C03	Engine uppercarr. Urea (AdBlue) Hose heater 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:41		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1C04	Engine uppercarr. Urea (AdBlue) Hose heater 1 short circuit to ground no reaction Check wiring between control unit and components	A750.X2:41		E	1
8D1C08	Engine uppercarr. Urea (AdBlue) Hose heater 1 Line interruption no reaction Check wiring between control unit and components	A750.X2:41		E	1
8D1C6C	Engine uppercarr. Urea (AdBlue) Hose heater 1 Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:41		E	1
8D1C6D	Engine uppercarr. Urea (AdBlue) Hose heater 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:41		E	1
8D1C6E	Engine uppercarr. Urea (AdBlue) Hose heater 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:41		E	1
8D1C6F	Engine uppercarr. Urea (AdBlue) Hose heater 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:41		E	1
8D1C70	Engine uppercarr. Urea (AdBlue) Hose heater 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:41		E	1
8D1D03	Engine uppercarr. Urea (AdBlue) Hose heater 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:49		E	1
8D1D04	Engine uppercarr. Urea (AdBlue) Hose heater 2 short circuit to ground no reaction Check wiring between control unit and components	A750.X2:49		E	1
8D1D08	Engine uppercarr. Urea (AdBlue) Hose heater 2 Line interruption no reaction Check wiring between control unit and components	A750.X2:49		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1D6C	Engine uppercarr. Urea (AdBlue) Hose heater 2 Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:49		E	1
8D1D6D	Engine uppercarr. Urea (AdBlue) Hose heater 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:49		E	1
8D1D6E	Engine uppercarr. Urea (AdBlue) Hose heater 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:49		E	1
8D1D6F	Engine uppercarr. Urea (AdBlue) Hose heater 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:49		E	1
8D1D70	Engine uppercarr. Urea (AdBlue) Hose heater 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:49		E	1
8D1E03	Engine uppercarr. SCR Urea (AdBlue) pressure sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:10		E	1
8D1E0B	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X1:10		E	1
8D1E14	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Signal remains below nominal value no reaction Check SCR-System	A750.X1:10		E	1
8D1E16	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Plausibility error no reaction Check components	A750.X1:10		E	1
8D1E26	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Urea (AdBlue) line filling failed Inducement system activation (Mach-FL) Check SCR-System	A750.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D1E2B	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Urea pressure too low (Plausibility vent valve open) Inducement system activation (Mach-FL) Check urea pump, turn ignition off / on	A750.X1:10		E	1
8D1E64	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:10		E	1
8D1E75	Engine uppercarr. SCR Urea (AdBlue) pressure sensor Upper limit value for regulation reached no reaction Check SCR System	A750.X1:10		E	1
8D1F03	Engine uppercarr. SCR Urea (AdBlue) temperature sensor short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:52		E	1
8D1F04	Engine uppercarr. SCR Urea (AdBlue) temperature sensor short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:52		E	1
8D1F08	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:52		E	1
8D1F09	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Value above warning threshold no reaction Check operation status of engine	A750.X1:52		E	1
8D1F0A	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Value above critical threshold no reaction Check operation status of engine	A750.X1:52		E	1
8D1F16	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Plausibility error no reaction Check components	A750.X1:52		E	1
8D1F64	Engine uppercarr. SCR Urea (AdBlue) temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:52		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2003	Engine uppercarr. SCR Urea (AdBlue) pump short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:25		E	1
8D2004	Engine uppercarr. SCR Urea (AdBlue) pump short circuit to ground no reaction Check wiring between control unit and components	A750.X1:25		E	1
8D2008	Engine uppercarr. SCR Urea (AdBlue) pump Line interruption no reaction Check wiring between control unit and components	A750.X1:25		E	1
8D2017	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit of load no reaction Check wiring between control unit and components	A750.X1:25		E	1
8D206C	Engine uppercarr. SCR Urea (AdBlue) pump Reg. deviation current value no reaction Report all error parameters to Service	A750.X1:25		E	1
8D206D	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X1:25		E	1
8D206E	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X1:25		E	1
8D206F	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X1:25		E	1
8D2070	Engine uppercarr. SCR Urea (AdBlue) pump Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X1:25		E	1
8D2103	Engine uppercarr. SCR vent valve short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:62		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2104	Engine uppercarr. SCR vent valve short circuit to ground no reaction Check wiring between control unit and components	A750.X1:62		E	1
8D2108	Engine uppercarr. SCR vent valve Line interruption no reaction Check wiring between control unit and components	A750.X1:62		E	1
8D216C	Engine uppercarr. SCR vent valve Reg. deviation current value no reaction Report all error parameters to Service	A750.X1:62		E	1
8D216D	Engine uppercarr. SCR vent valve Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X1:62		E	1
8D216E	Engine uppercarr. SCR vent valve Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X1:62		E	1
8D216F	Engine uppercarr. SCR vent valve Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X1:62		E	1
8D2170	Engine uppercarr. SCR vent valve Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X1:62		E	1
8D2203	Engine uppercarr. SCR connection compressed air short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D2204	Engine uppercarr. SCR connection compressed air short circuit to ground no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D2208	Engine uppercarr. SCR connection compressed air Line interruption no reaction Check wiring between control unit and components	A750.X2:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2217	Engine uppercarr. SCR connection compressed air Short circuit of load no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D226C	Engine uppercarr. SCR connection compressed air Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:13		E	1
8D226D	Engine uppercarr. SCR connection compressed air Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D226E	Engine uppercarr. SCR connection compressed air Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D226F	Engine uppercarr. SCR connection compressed air Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D2270	Engine uppercarr. SCR connection compressed air Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D2303	Engine uppercarr. SCR Air pressure sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:6		E	1
8D230B	Engine uppercarr. SCR Air pressure sensor Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X1:6		E	1
8D2316	Engine uppercarr. SCR Air pressure sensor Plausibility error no reaction Check components	A750.X1:6		E	1
8D2328	Engine uppercarr. SCR Air pressure sensor Pressure too high when connecting compressed air Inducement system activation (Mach-FL) Check SCR-System	A750.X1:6		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2329	Engine uppercarr. SCR Air pressure sensor Pressure too low when connecting compressed air Inducement system activation (Mach-FL) Check connections, air pump, urea pump, injector, replace components	A750.X1:6		E	1
8D2364	Engine uppercarr. SCR Air pressure sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:6		E	1
8D2401	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Value above max. test range no reaction Check wiring between control unit and components	A750.X1:4		E	1
8D2402	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Value below min. test range no reaction Check wiring between control unit and components	A750.X1:4		E	1
8D2408	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Line interruption no reaction Check wiring between control unit and components	A750.X1:4		E	1
8D2409	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Value above warning threshold no reaction Check operation status of engine	A750.X1:4		E	1
8D2416	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Plausibility error no reaction Check components	A750.X1:4		E	1
8D2418	Engine uppercarr. Urea (AdBlue)-Tank Temperature sensor Short circuit no reaction Check wiring between control unit and components	A750.X1:4		E	1
8D2501	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Value above max. test range no reaction Check wiring between control unit and components	A750.X1:4		E	1
8D2502	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Value below min. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2508	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1
8D2518	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1
8D2519	Engine uppercarr. Urea (AdBlue)-Tank Fill level sensor Fill level low Inducement system activation (Mach-FL) Refill urea tank	A750.X1:4		E	1
8D2605	Engine uppercarr. Urea (AdBlue)-Tank Sampling unit Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750.X1:4		E	1
8D2701	Engine uppercarr. Urea (AdBlue)-Tank Quality sensor Value above max. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1
8D2702	Engine uppercarr. Urea (AdBlue)-Tank Quality sensor Value below min. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1
8D2746	Engine uppercarr. Urea (AdBlue)-Tank Quality sensor Optical error Inducement system activation (Mach-FL) Check components	A750.X1:4		E	1
8D2803	Engine uppercarr. Battery temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:48		E	1
8D2804	Engine uppercarr. Battery temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A750.X1:48		E	1
8D2808	Engine uppercarr. Battery temperature sensor Line interruption no reaction Check wiring between control unit and components	A750.X1:48		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2816	Engine uppercarr. Battery temperature sensor Plausibility error no reaction Check components	A750.X1:48		E	1
8D2864	Engine uppercarr. Battery temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:48		E	1
8D2901	Engine uppercarr. Exhaust temperature sensor (before SCR) Value above max. test range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:28		E	1
8D2903	Engine uppercarr. Exhaust temperature sensor (before SCR) short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:28		E	1
8D2904	Engine uppercarr. Exhaust temperature sensor (before SCR) short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:28		E	1
8D2908	Engine uppercarr. Exhaust temperature sensor (before SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:28		E	1
8D2909	Engine uppercarr. Exhaust temperature sensor (before SCR) Value above warning threshold no reaction Check operation status of engine	A750.X1:28		E	1
8D290A	Engine uppercarr. Exhaust temperature sensor (before SCR) Value above critical threshold no reaction Check operation status of engine	A750.X1:28		E	1
8D2916	Engine uppercarr. Exhaust temperature sensor (before SCR) Plausibility error Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:28		E	1
8D2964	Engine uppercarr. Exhaust temperature sensor (before SCR) Error supply voltage sensors Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:28		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2A01	Engine uppercarr. Exhaust temperature sensor (after SCR) Value above max. test range no reaction Check wiring between control unit and components	A750.X1:32		E	1
8D2A02	Engine uppercarr. Exhaust temperature sensor (after SCR) Value below min. test range no reaction Check wiring between control unit and components	A750.X1:32		E	1
8D2A03	Engine uppercarr. Exhaust temperature sensor (after SCR) short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:32		E	1
8D2A04	Engine uppercarr. Exhaust temperature sensor (after SCR) short circuit to ground no reaction Check wiring between control unit and components	A750.X1:32		E	1
8D2A08	Engine uppercarr. Exhaust temperature sensor (after SCR) Line interruption no reaction Check wiring between control unit and components	A750.X1:32		E	1
8D2A09	Engine uppercarr. Exhaust temperature sensor (after SCR) Value above warning threshold no reaction Check operation status of engine	A750.X1:32		E	1
8D2A0A	Engine uppercarr. Exhaust temperature sensor (after SCR) Value above critical threshold no reaction Check operation status of engine	A750.X1:32		E	1
8D2A16	Engine uppercarr. Exhaust temperature sensor (after SCR) Plausibility error no reaction Check wiring between control unit and components	A750.X1:32		E	1
8D2A64	Engine uppercarr. Exhaust temperature sensor (after SCR) Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:32		E	1
8D2B03	Engine uppercarr. Hydraulic oil temperature sensor short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:36		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2B04	Engine uppercarr. Hydraulic oil temperature sensor short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:36		E	1
8D2B08	Engine uppercarr. Hydraulic oil temperature sensor Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:36		E	1
8D2B09	Engine uppercarr. Hydraulic oil temperature sensor Value above warning threshold no reaction Check operation status of engine	A750.X1:36		E	1
8D2B0A	Engine uppercarr. Hydraulic oil temperature sensor Value above critical threshold no reaction Check operation status of engine	A750.X1:36		E	1
8D2B64	Engine uppercarr. Hydraulic oil temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:36		E	1
8D2C03	Engine uppercarr. Starter short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X4:62		E	1
8D2C04	Engine uppercarr. Starter short circuit to ground no reaction Check wiring between control unit and components	A750.X4:62		E	1
8D2C08	Engine uppercarr. Starter Line interruption no reaction Check wiring between control unit and components	A750.X4:62		E	1
8D2C6C	Engine uppercarr. Starter Reg. deviation current value no reaction Report all error parameters to Service	A750.X4:62		E	1
8D2C6D	Engine uppercarr. Starter Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X4:62		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2C6E	Engine uppercarr. Starter Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X4:62		E	1
8D2C6F	Engine uppercarr. Starter Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X4:62		E	1
8D2C70	Engine uppercarr. Starter Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X4:62		E	1
8D2E03	Engine uppercarr. Wastegate flap 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:48		E	1
8D2E04	Engine uppercarr. Wastegate flap 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:48		E	1
8D2E08	Engine uppercarr. Wastegate flap 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:48		E	1
8D2E6C	Engine uppercarr. Wastegate flap 1 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A750.X3:48		E	1
8D2E6D	Engine uppercarr. Wastegate flap 1 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:48		E	1
8D2E6E	Engine uppercarr. Wastegate flap 1 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:48		E	1
8D2E6F	Engine uppercarr. Wastegate flap 1 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:48		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2E70	Engine uppercarr. Wastegate flap 1 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:48		E	1
8D2F03	Engine uppercarr. Fuel supply valve 1 (VCV) short circuit to supply voltage Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:28		E	1
8D2F04	Engine uppercarr. Fuel supply valve 1 (VCV) short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:28		E	1
8D2F08	Engine uppercarr. Fuel supply valve 1 (VCV) Line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:28		E	1
8D2F0A	Engine uppercarr. Fuel supply valve 1 (VCV) Value above critical threshold no reaction Check operation status of engine	A750.X3:28		E	1
8D2F0C	Engine uppercarr. Fuel supply valve 1 (VCV) Value below critical threshold no reaction Check operation status of engine	A750.X3:28		E	1
8D2F15	Engine uppercarr. Fuel supply valve 1 (VCV) Signal remains above nominal value no reaction Check wiring, components, control unit	A750.X3:28		E	1
8D2F17	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit of load Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:28		E	1
8D2F52	Engine uppercarr. Fuel supply valve 1 (VCV) PWM plausibility no reaction Check components	A750.X3:28		E	1
8D2F6C	Engine uppercarr. Fuel supply valve 1 (VCV) Reg. deviation current value Engine derating 50% (Mach-FL) Report all error parameters to Service	A750.X3:28		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D2F6D	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit after supply voltage Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:28		E	1
8D2F6E	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit after supply voltage ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:28		E	1
8D2F6F	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit after ground Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:28		E	1
8D2F70	Engine uppercarr. Fuel supply valve 1 (VCV) Short circuit after ground, ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:28		E	1
8D2F74	Engine uppercarr. Fuel supply valve 1 (VCV) Lower limit value for regulation reached no reaction No measure required	A750.X3:28		E	1
8D3003	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) short circuit to supply voltage Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:36		E	1
8D3004	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) short circuit to ground Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:36		E	1
8D3008	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Line interruption Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:36		E	1
8D300A	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Value above critical threshold no reaction Check operation status of engine	A750.X3:36		E	1
8D300C	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Value below critical threshold no reaction Check operation status of engine	A750.X3:36		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D300E	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Signal increases too fast no reaction Check components	A750.X3:36		E	1
8D300F	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Signal decreases too fast no reaction Check components	A750.X3:36		E	1
8D3015	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Signal remains above nominal value no reaction Check wiring, components, control unit	A750.X3:36		E	1
8D3017	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit of load Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:36		E	1
8D301D	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) PCV Flow regulation upper stop no reaction Check components	A750.X3:36		E	1
8D301E	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) PCV Flow regulation lower stop no reaction Check components	A750.X3:36		E	1
8D3052	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) PWM plausibility no reaction Check components	A750.X3:36		E	1
8D305D	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) PCV open due to excess pressure no reaction Check operation status of engine	A750.X3:36		E	1
8D306C	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Reg. deviation current value Engine derating 50% (Mach-FL) Report all error parameters to Service	A750.X3:36		E	1
8D306D	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit after supply voltage Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:36		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D306E	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit after supply voltage ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:36		E	1
8D306F	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit after ground Plus switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:36		E	1
8D3070	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Short circuit after ground, ground switch Engine derating 50% (Mach-FL) Check wiring between control unit and components	A750.X3:36		E	1
8D3074	Engine uppercarr. Fuel high pressure regulating valve 1 (PCV) Lower limit value for regulation reached no reaction No measure required	A750.X3:36		E	1
8D3105	Engine uppercarr. Exhaust return valve 1 Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A750.X3:4		E	1
8D3121	Engine uppercarr. Exhaust return valve 1 Voltage outside permissible range Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X3:4		E	1
8D3133	Engine uppercarr. Exhaust return valve 1 Data transfer CAN problematic Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A750.X3:4		E	1
8D3134	Engine uppercarr. Exhaust return valve 1 Hardware Error Engine derating 25% (Mach-FL) Check module	A750.X3:4		E	1
8D3135	Engine uppercarr. Exhaust return valve 1 Excess temperature error Engine derating 25% (Mach-FL) Check cooling of module	A750.X3:4		E	1
8D3136	Engine uppercarr. Exhaust return valve 1 Calibration error Engine derating 25% (Mach-FL) Check module	A750.X3:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3137	Engine uppercarr. Exhaust return valve 1 Error Reference position Engine derating 25% (Mach-FL) Check module	A750.X3:4		E	1
8D3138	Engine uppercarr. Exhaust return valve 1 Error Regulation deviation Engine derating 25% (Mach-FL) Check components	A750.X3:4		E	1
8D3139	Engine uppercarr. Exhaust return valve 1 Error Absolute position Engine derating 25% (Mach-FL) Check module	A750.X3:4		E	1
8D3303	Engine uppercarr. Injector 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:29		E	1
8D3304	Engine uppercarr. Injector 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:29		E	1
8D3308	Engine uppercarr. Injector 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:29		E	1
8D331F	Engine uppercarr. Injector 1 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:29		E	1
8D3320	Engine uppercarr. Injector 1 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:29		E	1
8D3403	Engine uppercarr. Injector 2 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:25		E	1
8D3404	Engine uppercarr. Injector 2 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:25		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3408	Engine uppercarr. Injector 2 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:25		E	1
8D341F	Engine uppercarr. Injector 2 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:25		E	1
8D3420	Engine uppercarr. Injector 2 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:25		E	1
8D3503	Engine uppercarr. Injector 3 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:21		E	1
8D3504	Engine uppercarr. Injector 3 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:21		E	1
8D3508	Engine uppercarr. Injector 3 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:21		E	1
8D351F	Engine uppercarr. Injector 3 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:21		E	1
8D3520	Engine uppercarr. Injector 3 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:21		E	1
8D3603	Engine uppercarr. Injector 4 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:17		E	1
8D3604	Engine uppercarr. Injector 4 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3608	Engine uppercarr. Injector 4 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:17		E	1
8D361F	Engine uppercarr. Injector 4 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:17		E	1
8D3620	Engine uppercarr. Injector 4 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:17		E	1
8D3703	Engine uppercarr. Injector 5 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:13		E	1
8D3704	Engine uppercarr. Injector 5 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:13		E	1
8D3708	Engine uppercarr. Injector 5 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:13		E	1
8D371F	Engine uppercarr. Injector 5 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:13		E	1
8D3720	Engine uppercarr. Injector 5 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:13		E	1
8D3803	Engine uppercarr. Injector 6 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:9		E	1
8D3804	Engine uppercarr. Injector 6 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3808	Engine uppercarr. Injector 6 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:9		E	1
8D381F	Engine uppercarr. Injector 6 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:9		E	1
8D3820	Engine uppercarr. Injector 6 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:9		E	1
8D3903	Engine uppercarr. Injector 7 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:5		E	1
8D3904	Engine uppercarr. Injector 7 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:5		E	1
8D3908	Engine uppercarr. Injector 7 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:5		E	1
8D391F	Engine uppercarr. Injector 7 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:5		E	1
8D3920	Engine uppercarr. Injector 7 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:5		E	1
8D3A03	Engine uppercarr. Injector 8 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:1		E	1
8D3A04	Engine uppercarr. Injector 8 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3A08	Engine uppercarr. Injector 8 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X4:1		E	1
8D3A1F	Engine uppercarr. Injector 8 No current increase time measureable Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:1		E	1
8D3A20	Engine uppercarr. Injector 8 Current increase time too long Engine derating 25% (Mach-FL) Check wiring, components, control unit	A750.X4:1		E	1
8D3B03	Engine uppercarr. Travel pedal sensor 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:7		E	1
8D3B0B	Engine uppercarr. Travel pedal sensor 1 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X2:7		E	1
8D3C03	Engine uppercarr. Travel pedal sensor 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:11		E	1
8D3C0B	Engine uppercarr. Travel pedal sensor 2 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X2:11		E	1
8D3D16	Engine uppercarr. Travel pedal sensor Plausibility error no reaction Check wiring between control unit and components	A750.X4:7		E	1
8D3E03	Engine uppercarr. Fan 1 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:60		E	1
8D3E04	Engine uppercarr. Fan 1 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:60		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3E08	Engine uppercarr. Fan 1 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:60		E	1
8D3E17	Engine uppercarr. Fan 1 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:60		E	1
8D3E6C	Engine uppercarr. Fan 1 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A750.X1:60		E	1
8D3E6D	Engine uppercarr. Fan 1 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:60		E	1
8D3E6E	Engine uppercarr. Fan 1 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:60		E	1
8D3E6F	Engine uppercarr. Fan 1 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:60		E	1
8D3E70	Engine uppercarr. Fan 1 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:60		E	1
8D3F03	Engine uppercarr. Fan 2 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:61		E	1
8D3F04	Engine uppercarr. Fan 2 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:61		E	1
8D3F08	Engine uppercarr. Fan 2 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D3F17	Engine uppercarr. Fan 2 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:61		E	1
8D3F6C	Engine uppercarr. Fan 2 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A750.X1:61		E	1
8D3F6D	Engine uppercarr. Fan 2 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:61		E	1
8D3F6E	Engine uppercarr. Fan 2 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:61		E	1
8D3F6F	Engine uppercarr. Fan 2 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:61		E	1
8D3F70	Engine uppercarr. Fan 2 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:61		E	1
8D4003	Engine uppercarr. Alternator 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X3:57		E	1
8D4004	Engine uppercarr. Alternator 1 short circuit to ground no reaction Check wiring between control unit and components	A750.X3:57		E	1
8D4221	Engine uppercarr. Motor Sensor supply U_VCC-M1 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X3:9		E	1
8D4321	Engine uppercarr. Motor Sensor supply U_VCC-M2 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X3:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D4421	Engine uppercarr. Motor Sensor supply U_VCC-M3 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X3:25		E	1
8D4521	Engine uppercarr. Motor Sensor supply U_VCC-M4 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X4:41		E	1
8D4621	Engine uppercarr. Motor Sensor supply U_VCC-M5 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X4:42		E	1
8D4721	Engine uppercarr. Motor Sensor supply U_VCC-M6 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X4:43		E	1
8D4821	Engine uppercarr. Motor Sensor supply U_VCC-M7 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X4:44		E	1
8D4921	Engine uppercarr. Machine Sensor supply U_VCC-G1 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X1:1		E	1
8D4A21	Engine uppercarr. Machine Sensor supply U_VCC-G2 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X1:9		E	1
8D4B21	Engine uppercarr. Machine Sensor supply U_VCC-G3 (5V) Voltage outside permissible range no reaction Check control unit, supplies	A750.X2:16		E	1
8D4C21	Engine uppercarr. Motor Sensor supply U_UBATT-M1 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D4D21	Engine uppercarr. Motor Sensor supply U_UBATT-M2 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D4E21	Engine uppercarr. Machine Sensor supply U_UBATT-G1 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750.X2:8		E	1
8D4F21	Engine uppercarr. Machine Sensor supply U_UBATT-G2 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750.X2:12		E	1
8D5021	Engine uppercarr. Machine Sensor supply U_UBATT-G3 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750.X2:46		E	1
8D5121	Engine uppercarr. Machine Sensor supply U_UBATT-G4 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750.X1:17		E	1
8D5221	Engine uppercarr. Machine Sensor supply U_UBATT-G5 (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750.X1_42		E	1
8D5321	Engine uppercarr. Internal Sensor supply U_VCC_SENSOR 1 Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5421	Engine uppercarr. Internal Sensor supply U_VDD_SENSOR 2 Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5521	Engine uppercarr. Internal Sensor supply U_BATT_SENSOR (Battery) Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5621	Engine uppercarr. Temperature sensor supply U_TI_VCC_5V Voltage outside permissible range no reaction Check control unit, supplies, battery voltage	A750		E	1
8D5722	Engine uppercarr. Injection time Pre-injection before injection too close to pre-injection no reaction 0	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D5723	Engine uppercarr. Injection time Pre-injecton too close to main injection no reaction 0	A750		E	1
8D5724	Engine uppercarr. Injection time Post-injection too close to main injection no reaction 0	A750		E	1
8D5725	Engine uppercarr. Injection time Late post-injection too close to post-injection no reaction 0	A750		E	1
8D5814	Engine uppercarr. SCR System (pressure air pump) Signal remains below nominal value Inducement system activation (Mach-FL) Check SCR-System	A750		E	1
8D582C	Engine uppercarr. SCR System (pressure air pump) Status erroneous Inducement system activation (Mach-FL) 1) check lines for air supply 2) check fuse for air pump 3) check air supply system	A750		E	1
8D5927	Engine uppercarr. SCR System Urea (AdBlue) nozzle plugged Inducement system activation (Mach-FL) Check SCR-System	A750		E	1
8D592A	Engine uppercarr. SCR System Interruption of ventilation procedure no reaction Check components	A750		E	1
8D5931	Engine uppercarr. SCR System Bad efficiency of NOX-reduction no reaction Check SCR-System	A750		E	1
8D5932	Engine uppercarr. SCR System Very bad efficiency of NOX-reduction Inducement system activation (Mach-FL) Check SCR-System	A750		E	1
8D596B	Engine uppercarr. SCR System Last venting of AdBlue line interrupted no reaction Report all error parameters to Service	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D5A08	Engine uppercarr. NOX Sensor (before SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1
8D5A18	Engine uppercarr. NOX Sensor (before SCR) Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1
8D5A1B	Engine uppercarr. NOX Sensor (before SCR) Invalid data Inducement system activation (Mach-FL) Check operation status of engine	A750.X1:4		E	1
8D5A2E	Engine uppercarr. NOX Sensor (before SCR) Sensor removed from exhaust line Inducement system activation (Mach-FL) Check components	A750.X1:4		E	1
8D5A2F	Engine uppercarr. NOX Sensor (before SCR) Heating element broken Inducement system activation (Mach-FL) Check wiring, replace components	A750.X1:4		E	1
8D5A30	Engine uppercarr. NOX Sensor (before SCR) Offset Error Inducement system activation (Mach-FL) Check operation status of engine	A750.X1:4		E	1
8D5B05	Engine uppercarr. NOX Sensor (after SCR) Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750.X1:4		E	1
8D5B08	Engine uppercarr. NOX Sensor (after SCR) Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1
8D5B18	Engine uppercarr. NOX Sensor (after SCR) Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1
8D5B1B	Engine uppercarr. NOX Sensor (after SCR) Invalid data Inducement system activation (Mach-FL) Check operation status of engine	A750.X1:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D5B2E	Engine uppercarr. NOX Sensor (after SCR) Sensor removed from exhaust line Inducement system activation (Mach-FL) Check wiring, replace components	A750.X1:4		E	1
8D5B2F	Engine uppercarr. NOX Sensor (after SCR) Heating element broken Inducement system activation (Mach-FL) Check wiring, replace components	A750.X1:4		E	1
8D5B30	Engine uppercarr. NOX Sensor (after SCR) Offset Error Inducement system activation (Mach-FL) Check operation status of engine	A750.X1:4		E	1
8D5C01	Engine uppercarr. Regulation alternator (voltage signal) Value above max. test range no reaction Check wiring between control unit and components	A750.X3:57		E	1
8D5C06	Engine uppercarr. Regulation alternator (voltage signal) internal error no reaction Check components	A750.X3:57		E	1
8D5C38	Engine uppercarr. Regulation alternator (voltage signal) Error Regulation deviation no reaction Check components	A750.X3:57		E	1
8D5C4E	Engine uppercarr. Regulation alternator (voltage signal) Overload no reaction Check components	A750.X3:57		E	1
8D5C4F	Engine uppercarr. Regulation alternator (voltage signal) Error when engine running no reaction Check components	A750.X3:57		E	1
8D5C50	Engine uppercarr. Regulation alternator (voltage signal) Error intelligent alternator no reaction Check components	A750.X3:57		E	1
8D5C51	Engine uppercarr. Regulation alternator (voltage signal) Fuse defective no reaction Check components	A750.X3:57		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D5D16	Engine uppercarr. Air filter monitor pressure sensor Plausibility error Engine derating 25% (Mach-FL) Check components	A750		E	1
8D5F05	Engine uppercarr. NOX Sensor Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750.X1:4		E	1
8D5F2D	Engine uppercarr. NOX Sensor Installation error Inducement system activation (Mach-FL) Check installation, position of sensors	A750.X1:4		E	1
8D6003	Engine uppercarr. Distributor gear temperature sensor short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X4:53		E	1
8D6004	Engine uppercarr. Distributor gear temperature sensor short circuit to ground no reaction Check wiring between control unit and components	A750.X4:53		E	1
8D6008	Engine uppercarr. Distributor gear temperature sensor Line interruption no reaction Check wiring between control unit and components	A750.X4:53		E	1
8D6009	Engine uppercarr. Distributor gear temperature sensor Value above warning threshold no reaction Check operation status of engine	A750.X4:53		E	1
8D600A	Engine uppercarr. Distributor gear temperature sensor Value above critical threshold no reaction Check operation status of engine	A750.X4:53		E	1
8D6064	Engine uppercarr. Distributor gear temperature sensor Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X4:53		E	1
8D6103	Engine uppercarr. Supply relay Engine sensory short circuit to supply voltage Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:25		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D6104	Engine uppercarr. Supply relay Engine sensory short circuit to ground Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:25		E	1
8D6108	Engine uppercarr. Supply relay Engine sensory Line interruption Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:25		E	1
8D616C	Engine uppercarr. Supply relay Engine sensory Reg. deviation current value Inducement system activation (Mach-FL) Report all error parameters to Service	A750.X2:25		E	1
8D616D	Engine uppercarr. Supply relay Engine sensory Short circuit after supply voltage Plus switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:25		E	1
8D616E	Engine uppercarr. Supply relay Engine sensory Short circuit after supply voltage ground switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:25		E	1
8D616F	Engine uppercarr. Supply relay Engine sensory Short circuit after ground Plus switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:25		E	1
8D6170	Engine uppercarr. Supply relay Engine sensory Short circuit after ground, ground switch Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:25		E	1
8D6233	Engine uppercarr. AMET CAN (CAN ID 585) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6333	Engine uppercarr. AMET CAN (CAN ID 594) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6433	Engine uppercarr. BAUMA CAN Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D647E	Engine uppercarr. BAUMA CAN invalid I/O configuration, master file no reaction Check I/O-Config file on Master Flash card	A750		E	1
8D6533	Engine uppercarr. ABS Control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6633	Engine uppercarr. ABS Control unit 2 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6733	Engine uppercarr. Coupling regulation Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6833	Engine uppercarr. CAN-Signals Gear control unit (ID 564) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6933	Engine uppercarr. CAN-Signals Gear control unit (ID 565) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6A33	Engine uppercarr. CAN-Signals Gear control unit (ID 668) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6B33	Engine uppercarr. Retarder control unit Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6C33	Engine uppercarr. CAN-Signals I/O Module (ID 900) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6D33	Engine uppercarr. CAN-Signals I/O Module (ID 901) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D6E33	Engine uppercarr. CAN-Signals I/O Module (ID 902) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D6F07	Engine uppercarr. Supply voltage Value below warning threshold no reaction Check control unit, supplies, battery voltage	A750		E	1
8D6F09	Engine uppercarr. Supply voltage Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D7005	Engine uppercarr. Exhaust flap 1 Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750.X3:4		E	1
8D7033	Engine uppercarr. Exhaust flap 1 Data transfer CAN problematic Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750.X3:4		E	1
8D7034	Engine uppercarr. Exhaust flap 1 Hardware Error Inducement system activation (Mach-FL) Check module	A750.X3:4		E	1
8D7035	Engine uppercarr. Exhaust flap 1 Excess temperature error Inducement system activation (Mach-FL) Check cooling of module	A750.X3:4		E	1
8D7036	Engine uppercarr. Exhaust flap 1 Calibration error Inducement system activation (Mach-FL) Check module	A750.X3:4		E	1
8D7037	Engine uppercarr. Exhaust flap 1 Error Reference position Inducement system activation (Mach-FL) Check module	A750.X3:4		E	1
8D7038	Engine uppercarr. Exhaust flap 1 Error Regulation deviation Engine derating 50% (Mach-FL) Check components	A750.X3:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7039	Engine uppercarr. Exhaust flap 1 Error Absolute position Inducement system activation (Mach-FL) Check module	A750.X3:4		E	1
8D7121	Engine uppercarr. Supply voltage exhaust flap 1 Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D7203	Engine uppercarr. Exhaust temperature sensor (before DOC) short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:24		E	1
8D7204	Engine uppercarr. Exhaust temperature sensor (before DOC) short circuit to ground no reaction Check wiring between control unit and components	A750.X1:24		E	1
8D7208	Engine uppercarr. Exhaust temperature sensor (before DOC) Line interruption no reaction Check wiring between control unit and components	A750.X1:24		E	1
8D7209	Engine uppercarr. Exhaust temperature sensor (before DOC) Value above warning threshold no reaction Check operation status of engine	A750.X1:24		E	1
8D720A	Engine uppercarr. Exhaust temperature sensor (before DOC) Value above critical threshold no reaction Check operation status of engine	A750.X1:24		E	1
8D7216	Engine uppercarr. Exhaust temperature sensor (before DOC) Plausibility error no reaction Check wiring between control unit and components	A750.X1:24		E	1
8D7264	Engine uppercarr. Exhaust temperature sensor (before DOC) Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:24		E	1
8D7303	Engine uppercarr. Actuation central lubrication system short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7304	Engine uppercarr. Actuation central lubrication system short circuit to ground no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D7308	Engine uppercarr. Actuation central lubrication system Line interruption no reaction Check wiring, wiring harness	A750.X2:9		E	1
8D736C	Engine uppercarr. Actuation central lubrication system Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:9		E	1
8D736D	Engine uppercarr. Actuation central lubrication system Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D736E	Engine uppercarr. Actuation central lubrication system Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D736F	Engine uppercarr. Actuation central lubrication system Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D7370	Engine uppercarr. Actuation central lubrication system Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:9		E	1
8D7403	Engine uppercarr. Actuation Air flap short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D7404	Engine uppercarr. Actuation Air flap short circuit to ground no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D7408	Engine uppercarr. Actuation Air flap Line interruption no reaction Check wiring, wiring harness	A750.X2:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D746C	Engine uppercarr. Actuation Air flap Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:13		E	1
8D746D	Engine uppercarr. Actuation Air flap Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D746E	Engine uppercarr. Actuation Air flap Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D746F	Engine uppercarr. Actuation Air flap Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D7470	Engine uppercarr. Actuation Air flap Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:13		E	1
8D7503	Engine uppercarr. Machine configurable lamp outlet 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:1		E	1
8D7504	Engine uppercarr. Machine configurable lamp outlet 1 short circuit to ground no reaction Check wiring between control unit and components	A750.X2:1		E	1
8D7508	Engine uppercarr. Machine configurable lamp outlet 1 Line interruption no reaction Check wiring, wiring harness	A750.X2:1		E	1
8D756C	Engine uppercarr. Machine configurable lamp outlet 1 Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:1		E	1
8D756D	Engine uppercarr. Machine configurable lamp outlet 1 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D756E	Engine uppercarr. Machine configurable lamp outlet 1 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:1		E	1
8D756F	Engine uppercarr. Machine configurable lamp outlet 1 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:1		E	1
8D7570	Engine uppercarr. Machine configurable lamp outlet 1 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:1		E	1
8D7603	Engine uppercarr. Machine configurable lamp outlet 2 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:5		E	1
8D7604	Engine uppercarr. Machine configurable lamp outlet 2 short circuit to ground no reaction Check wiring between control unit and components	A750.X2:5		E	1
8D7608	Engine uppercarr. Machine configurable lamp outlet 2 Line interruption no reaction Check wiring, wiring harness	A750.X2:5		E	1
8D766C	Engine uppercarr. Machine configurable lamp outlet 2 Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:5		E	1
8D766D	Engine uppercarr. Machine configurable lamp outlet 2 Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:5		E	1
8D766E	Engine uppercarr. Machine configurable lamp outlet 2 Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:5		E	1
8D766F	Engine uppercarr. Machine configurable lamp outlet 2 Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7670	Engine uppercarr. Machine configurable lamp outlet 2 Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:5		E	1
8D7705	Engine uppercarr. Ammonia sensor Communication error Engine derating 25% (Mach-FL) Check wiring, CAN-participant	A750.X1:4		E	1
8D7706	Engine uppercarr. Ammonia sensor internal error Engine derating 25% (Mach-FL) Check components	A750.X1:4		E	1
8D7709	Engine uppercarr. Ammonia sensor Value above warning threshold no reaction Check operation status of engine	A750.X1:4		E	1
8D773A	Engine uppercarr. Ammonia sensor Error Heater element Engine derating 25% (Mach-FL) Check wiring, replace components	A750.X1:4		E	1
8D773B	Engine uppercarr. Ammonia sensor Error Resistance Engine derating 25% (Mach-FL) Check components	A750.X1:4		E	1
8D773C	Engine uppercarr. Ammonia sensor Error Trim calibration Engine derating 25% (Mach-FL) Check wiring between module and sensor, replace sensor	A750.X1:4		E	1
8D773D	Engine uppercarr. Ammonia sensor Electric error Engine derating 25% (Mach-FL) Check components	A750.X1:4		E	1
8D774B	Engine uppercarr. Ammonia sensor Error supply heating element Engine derating 25% (Mach-FL) Check wiring, replace components	A750.X1:4		E	1
8D7805	Engine uppercarr. Water pump Communication error no reaction Check wiring, CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D783E	Engine uppercarr. Water pump Rpm nominal value cannot be reached no reaction Check components	A750		E	1
8D7857	Engine uppercarr. Water pump Engine error no reaction Check components	A750		E	1
8D793F	Engine uppercarr. Injector supply voltage Up converter cannot reach nominal current no reaction Check control unit	A750		E	1
8D7A40	Engine uppercarr. Emergency stop Signal Kl.15 on during active emerg. stop no reaction Check emerg. stop, Turn ignition off/on	A750		E	1
8D7B09	Engine uppercarr. Alternator 1 (Output voltage) Value above warning threshold no reaction Check operation status of engine	A750.X3:12		E	1
8D7B0A	Engine uppercarr. Alternator 1 (Output voltage) Value above critical threshold no reaction Check operation status of engine	A750.X3:12		E	1
8D7B0B	Engine uppercarr. Alternator 1 (Output voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X3:12		E	1
8D7C03	Engine uppercarr. Temperature sensor after charge air cooler short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X3:33		E	1
8D7C04	Engine uppercarr. Temperature sensor after charge air cooler short circuit to ground no reaction Check wiring between control unit and components	A750.X3:33		E	1
8D7C08	Engine uppercarr. Temperature sensor after charge air cooler Line interruption no reaction Check wiring between control unit and components	A750.X3:33		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7C09	Engine uppercarr. Temperature sensor after charge air cooler Value above warning threshold no reaction Check operation status of engine	A750.X3:33		E	1
8D7C0A	Engine uppercarr. Temperature sensor after charge air cooler Value above critical threshold no reaction Check operation status of engine	A750.X3:33		E	1
8D7C64	Engine uppercarr. Temperature sensor after charge air cooler Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X3:33		E	1
8D7D03	Engine uppercarr. Alternator 1 (Frequency input) short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X3:53		E	1
8D7E03	Engine uppercarr. Alternator 2 (Output voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X4:45		E	1
8D7E04	Engine uppercarr. Alternator 2 (Output voltage) short circuit to ground no reaction Check wiring between control unit and components	A750.X4:45		E	1
8D7E08	Engine uppercarr. Alternator 2 (Output voltage) Line interruption no reaction Check wiring between control unit and components	A750.X4:45		E	1
8D7E09	Engine uppercarr. Alternator 2 (Output voltage) Value above warning threshold no reaction Check operation status of engine	A750.X4:45		E	1
8D7E0A	Engine uppercarr. Alternator 2 (Output voltage) Value above critical threshold no reaction Check operation status of engine	A750.X4:45		E	1
8D7E64	Engine uppercarr. Alternator 2 (Output voltage) Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X4:45		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D7F03	Engine uppercarr. Alternator 2 (Lamp) short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X4:40		E	1
8D7F09	Engine uppercarr. Alternator 2 (Lamp) Value above warning threshold no reaction Check operation status of engine	A750.X4:40		E	1
8D7F0A	Engine uppercarr. Alternator 2 (Lamp) Value above critical threshold no reaction Check operation status of engine	A750.X4:40		E	1
8D7F0B	Engine uppercarr. Alternator 2 (Lamp) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X4:40		E	1
8D7F64	Engine uppercarr. Alternator 2 (Lamp) Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X4:40		E	1
8D8014	Engine uppercarr. SCR metering regulator Signal remains below nominal value no reaction Check components	A750		E	1
8D8015	Engine uppercarr. SCR metering regulator Signal remains above nominal value no reaction Check components	A750		E	1
8D8074	Engine uppercarr. SCR metering regulator Lower limit value for regulation reached no reaction No measure required	A750		E	1
8D8075	Engine uppercarr. SCR metering regulator Upper limit value for regulation reached no reaction No measure required	A750		E	1
8D8105	Engine uppercarr. Exhaust flap 2 Communication error Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750.X3:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8133	Engine uppercarr. Exhaust flap 2 Data transfer CAN problematic Inducement system activation (Mach-FL) Check wiring, CAN-participant	A750.X3:4		E	1
8D8134	Engine uppercarr. Exhaust flap 2 Hardware Error Inducement system activation (Mach-FL) Check module	A750.X3:4		E	1
8D8135	Engine uppercarr. Exhaust flap 2 Excess temperature error Inducement system activation (Mach-FL) Check cooling of module	A750.X3:4		E	1
8D8136	Engine uppercarr. Exhaust flap 2 Calibration error Inducement system activation (Mach-FL) Check module	A750.X3:4		E	1
8D8137	Engine uppercarr. Exhaust flap 2 Error Reference position Inducement system activation (Mach-FL) Check module	A750.X3:4		E	1
8D8138	Engine uppercarr. Exhaust flap 2 Error Regulation deviation Engine derating 50% (Mach-FL) Check components	A750.X3:4		E	1
8D8139	Engine uppercarr. Exhaust flap 2 Error Absolute position Inducement system activation (Mach-FL) Check module	A750.X3:4		E	1
8D8221	Engine uppercarr. Supply voltage exhaust flap 2 Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D8304	Engine uppercarr. Digital input Starter signal short circuit to ground no reaction Check wiring between control unit and components	A750.X2:24		E	1
8D8308	Engine uppercarr. Digital input Starter signal Line interruption no reaction Check wiring, wiring harness	A750.X2:24		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8321	Engine uppercarr. Digital input Starter signal Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:24		E	1
8D835B	Engine uppercarr. Digital input Starter signal Start block due to a short circuit no reaction Check wiring, components, control unit	A750.X2:24		E	1
8D8364	Engine uppercarr. Digital input Starter signal Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X2:24		E	1
8D8408	Engine uppercarr. Digital input emerg. off Line interruption no reaction Check wiring between control unit and components	A750.X2:26		E	1
8D8421	Engine uppercarr. Digital input emerg. off Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:26		E	1
8D8464	Engine uppercarr. Digital input emerg. off Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X2:26		E	1
8D8508	Engine uppercarr. Digital input test bench operation Line interruption no reaction Check wiring, wiring harness	A750.X2:27		E	1
8D8521	Engine uppercarr. Digital input test bench operation Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:27		E	1
8D8564	Engine uppercarr. Digital input test bench operation Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X2:27		E	1
8D8608	Engine uppercarr. Digital input emerg. run rpm Line interruption no reaction Check wiring, wiring harness	A750.X2:23		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8621	Engine uppercarr. Digital input emerg. run rpm Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:23		E	1
8D8664	Engine uppercarr. Digital input emerg. run rpm Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X2:23		E	1
8D8708	Engine uppercarr. Digital input LWE emerg. Op. Line interruption no reaction Check wiring, wiring harness	A750.X2:24		E	1
8D8721	Engine uppercarr. Digital input LWE emerg. Op. Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:24		E	1
8D8764	Engine uppercarr. Digital input LWE emerg. Op. Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X2:24		E	1
8D8808	Engine uppercarr. Digital input Slave Line interruption no reaction Check wiring, wiring harness	A750.X2:22		E	1
8D8821	Engine uppercarr. Digital input Slave Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:22		E	1
8D8864	Engine uppercarr. Digital input Slave Error supply voltage sensors Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:22		E	1
8D8907	Engine uppercarr. Reductions because of exhaust quality Value below warning threshold no reaction Read out error stack and note other system errors	A750		E	1
8D8941	Engine uppercarr. Reductions because of exhaust quality Power or speed limitation active no reaction Read out error stack and note other system errors	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8942	Engine uppercarr. Reductions because of exhaust quality Increased power or speed limitation active no reaction Read out error stack and note other system errors	A750		E	1
8D8943	Engine uppercarr. Reductions because of exhaust quality Blocked in increased power or speed limitation no reaction Read out error stack and note other system errors	A750		E	1
8D8944	Engine uppercarr. Reductions because of exhaust quality Engine start block due to empty urea tank no reaction Read out error stack and note other system errors	A750		E	1
8D8A38	Engine uppercarr. Signals vehicle speed Error Regulation deviation no reaction Check components	A750		E	1
8D8B21	Engine uppercarr. Urea (AdBlue) Quality Voltage outside permissible range Inducement system activation (Mach-FL) Check wiring between control unit and components	A750		E	1
8D8B76	Engine uppercarr. Urea (AdBlue) Quality Urea quality outside tolerance range Inducement system activation (Mach-FL) 1) Empty, clean AdBlue tank, replace contents 2) check AdBlue sampling module, clean	A750		E	1
8D8C08	Engine uppercarr. Data transfer CAN 1 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A750.X2:39		E	1
8D8C18	Engine uppercarr. Data transfer CAN 1 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:39		E	1
8D8D08	Engine uppercarr. Data transfer CAN 2 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A750.X1:4		E	1
8D8D18	Engine uppercarr. Data transfer CAN 2 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X1:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D8E08	Engine uppercarr. Data transfer CAN 3 Line interruption Inducement system activation (Mach-FL) Check wiring, wiring harness	A750.X2:52		E	1
8D8E18	Engine uppercarr. Data transfer CAN 3 Short circuit Inducement system activation (Mach-FL) Check wiring between control unit and components	A750.X2:52		E	1
8D8F03	Engine uppercarr. Injector 9 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D8F04	Engine uppercarr. Injector 9 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D8F08	Engine uppercarr. Injector 9 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D8F1F	Engine uppercarr. Injector 9 No current increase time measureable no reaction Check wiring, components, control unit	A750		E	1
8D8F20	Engine uppercarr. Injector 9 Current increase time too long no reaction Check wiring, components, control unit	A750		E	1
8D9003	Engine uppercarr. Injector 10 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D9004	Engine uppercarr. Injector 10 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D9008	Engine uppercarr. Injector 10 Line interruption no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D901F	Engine uppercarr. Injector 10 No current increase time measureable no reaction Check wiring, components, control unit	A750		E	1
8D9020	Engine uppercarr. Injector 10 Current increase time too long no reaction Check wiring, components, control unit	A750		E	1
8D9103	Engine uppercarr. Injector 11 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D9104	Engine uppercarr. Injector 11 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D9108	Engine uppercarr. Injector 11 Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D911F	Engine uppercarr. Injector 11 No current increase time measureable no reaction Check wiring, components, control unit	A750		E	1
8D9120	Engine uppercarr. Injector 11 Current increase time too long no reaction Check wiring, components, control unit	A750		E	1
8D9203	Engine uppercarr. Injector 12 short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8D9204	Engine uppercarr. Injector 12 short circuit to ground no reaction Check wiring between control unit and components	A750		E	1
8D9208	Engine uppercarr. Injector 12 Line interruption no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D921F	Engine uppercarr. Injector 12 No current increase time measureable no reaction Check wiring, components, control unit	A750		E	1
8D9220	Engine uppercarr. Injector 12 Current increase time too long no reaction Check wiring, components, control unit	A750		E	1
8D9533	Engine uppercarr. CAN-message machine control (TSC1) Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8D9603	Engine uppercarr. Fan 3 short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X2:61		E	1
8D9604	Engine uppercarr. Fan 3 short circuit to ground Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X2:61		E	1
8D9608	Engine uppercarr. Fan 3 Line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X2:61		E	1
8D9617	Engine uppercarr. Fan 3 Short circuit of load Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X2:61		E	1
8D966C	Engine uppercarr. Fan 3 Reg. deviation current value Engine derating 25% (Mach-FL) Report all error parameters to Service	A750.X2:61		E	1
8D966D	Engine uppercarr. Fan 3 Short circuit after supply voltage Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X2:61		E	1
8D966E	Engine uppercarr. Fan 3 Short circuit after supply voltage ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X2:61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D966F	Engine uppercarr. Fan 3 Short circuit after ground Plus switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X2:61		E	1
8D9670	Engine uppercarr. Fan 3 Short circuit after ground, ground switch Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X2:61		E	1
8D9B14	Engine uppercarr. Fuel high pressure regulating valve (PCV) flow reg Signal remains below nominal value no reaction Check wiring, components, control unit	A750		E	1
8D9B15	Engine uppercarr. Fuel high pressure regulating valve (PCV) flow reg Signal remains above nominal value no reaction Check wiring, components, control unit	A750		E	1
8D9C03	Engine uppercarr. Actuation after run relay short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X2:22		E	1
8D9C04	Engine uppercarr. Actuation after run relay short circuit to ground no reaction Check wiring between control unit and components	A750.X2:22		E	1
8D9C08	Engine uppercarr. Actuation after run relay Line interruption no reaction Check wiring, wiring harness	A750.X2:22		E	1
8D9C6C	Engine uppercarr. Actuation after run relay Reg. deviation current value no reaction Report all error parameters to Service	A750.X2:22		E	1
8D9C6D	Engine uppercarr. Actuation after run relay Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750.X2:22		E	1
8D9C6E	Engine uppercarr. Actuation after run relay Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750.X2:22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9C6F	Engine uppercarr. Actuation after run relay Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750.X2:22		E	1
8D9C70	Engine uppercarr. Actuation after run relay Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750.X2:22		E	1
8D9D01	Engine uppercarr. Urea tank (temperature at suction point) Value above max. test range no reaction Check wiring between control unit and components	A750		E	1
8D9D02	Engine uppercarr. Urea tank (temperature at suction point) Value below min. test range no reaction Check wiring between control unit and components	A750		E	1
8D9D08	Engine uppercarr. Urea tank (temperature at suction point) Line interruption no reaction Check wiring between control unit and components	A750		E	1
8D9D09	Engine uppercarr. Urea tank (temperature at suction point) Value above warning threshold no reaction Check operation status of engine	A750		E	1
8D9D16	Engine uppercarr. Urea tank (temperature at suction point) Plausibility error no reaction Check components	A750		E	1
8D9D18	Engine uppercarr. Urea tank (temperature at suction point) Short circuit no reaction Check wiring between control unit and components	A750		E	1
8D9F03	Engine uppercarr. Particle filter pressure sensor 1 short circuit to supply voltage no reaction Check wiring between control unit and components	A750.X1:2		E	1
8D9F0B	Engine uppercarr. Particle filter pressure sensor 1 Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750.X1:2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8D9F16	Engine uppercarr. Particle filter pressure sensor 1 Plausibility error no reaction Check components	A750.X1:2		E	1
8D9F64	Engine uppercarr. Particle filter pressure sensor 1 Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X1:2		E	1
8DA103	Engine uppercarr. Air filter pressure switch short circuit to supply voltage Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:18		E	1
8DA10B	Engine uppercarr. Air filter pressure switch Short circuit after ground or line interruption Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:18		E	1
8DA121	Engine uppercarr. Air filter pressure switch Voltage outside permissible range Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:18		E	1
8DA164	Engine uppercarr. Air filter pressure switch Error supply voltage sensors Engine derating 25% (Mach-FL) Check wiring between control unit and components	A750.X1:18		E	1
8DA221	Engine uppercarr. Terminal 15 digital input Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:2		E	1
8DA264	Engine uppercarr. Terminal 15 digital input Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X2:2		E	1
8DA348	Engine uppercarr. Urea thawing procedure Efficiency error no reaction Check operation status of engine	A750		E	1
8DA44C	Engine uppercarr. Urea heater system Actuator error Inducement system activation (Mach-FL) Read out error stack and note other system errors	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DA44D	Engine uppercarr. Urea heater system Sensor error Inducement system activation (Mach-FL) Read out error stack and note other system errors	A750		E	1
8DB653	Engine uppercarr. Monitoring system Error plausibility starter actutation no reaction Check control unit	A750		E	1
8DB654	Engine uppercarr. Monitoring system Ecu internal error no reaction Check components	A750		E	1
8DB65F	Engine uppercarr. Monitoring system Error emerg. stop no reaction Check control unit	A750		E	1
8DB660	Engine uppercarr. Monitoring system PME CAN Error no reaction Check control unit	A750		E	1
8DB665	Engine uppercarr. Monitoring system Plausibility error injecetor no reaction Check control unit	A750		E	1
8DB671	Engine uppercarr. Monitoring system Plausibility injection no reaction Check control unit	A750		E	1
8DB709	Engine uppercarr. Control unit temperature Value above warning threshold no reaction Check operation status of engine	A750		E	1
8DB70A	Engine uppercarr. Control unit temperature Value above critical threshold no reaction Check operation status of engine	A750		E	1
8DB855	Engine uppercarr. Pressure relief valve high pressure injection syst Too many activations no reaction Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DB856	Engine uppercarr. Pressure relief valve high pressure injection syst Valve open Engine derating 25% (Mach-FL) Check operation status of engine	A750		E	1
8DB908	Engine uppercarr. Digital input emerg. start Line interruption no reaction Check wiring between control unit and components	A750.X2:24		E	1
8DB921	Engine uppercarr. Digital input emerg. start Voltage outside permissible range no reaction Check wiring between control unit and components	A750.X2:24		E	1
8DB964	Engine uppercarr. Digital input emerg. start Error supply voltage sensors no reaction Check wiring between control unit and components	A750.X2:24		E	1
8DBE08	Engine uppercarr. Data transfer CAN 4 Line interruption no reaction Check wiring, wiring harness	A750		E	1
8DBE18	Engine uppercarr. Data transfer CAN 4 Short circuit no reaction Check wiring between control unit and components	A750		E	1
8DC558	Engine uppercarr. Exhaust return regulation Error auto calibration no reaction Check mechanics	A750		E	1
8DC559	Engine uppercarr. Exhaust return regulation Error teach in procedure no reaction Check mechanics	A750		E	1
8DC55A	Engine uppercarr. Exhaust return regulation Learned value lost in operation no reaction Check mechanics	A750		E	1
8DC75C	Engine uppercarr. SCR urea Temperature Temperature measurement urea too high Inducement system activation (Mach-FL) Check AdBlue Heating system	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DC858	Engine uppercarr. Exhaust flap regulation Error auto calibration Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC859	Engine uppercarr. Exhaust flap regulation Error teach in procedure Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC85A	Engine uppercarr. Exhaust flap regulation Learned value lost in operation Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC958	Engine uppercarr. Exhaust flap regulation 2 Error auto calibration Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC959	Engine uppercarr. Exhaust flap regulation 2 Error teach in procedure Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DC95A	Engine uppercarr. Exhaust flap regulation 2 Learned value lost in operation Inducement system activation (Mach-FL) Check mechanics	A750		E	1
8DCA21	Engine uppercarr. Battle Switch Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8DCA5E	Engine uppercarr. Battle Switch activated no reaction Report all error parameters to Service	A750		E	1
8DCA64	Engine uppercarr. Battle Switch Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8DCC05	Engine uppercarr. Safety system PME CAN Communication error no reaction Check wiring, CAN-participant	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DCE33	Engine uppercarr. J1939 Prop0 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8DCF03	Engine uppercarr. Input display alternator short circuit to supply voltage no reaction Check wiring, wiring harness	A750		E	1
8DCF0B	Engine uppercarr. Input display alternator Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DCF21	Engine uppercarr. Input display alternator Voltage outside permissible range no reaction Check wiring, wiring harness	A750		E	1
8DCF64	Engine uppercarr. Input display alternator Error supply voltage sensors no reaction Check wiring between control unit and components	A750		E	1
8DD061	Engine uppercarr. Particle filter Regeneration failed no reaction Check operation status of engine	A750		E	1
8DD062	Engine uppercarr. Particle filter Regeneration stopped (temp. too low) no reaction Check operation status of engine	A750		E	1
8DD063	Engine uppercarr. Particle filter Regeneration stopped (temp. too low) no reaction Check operation status of engine	A750		E	1
8DD068	Engine uppercarr. Particle filter Estimation of ash load not plausible (too high) no reaction Check operation status of engine	A750		E	1
8DD069	Engine uppercarr. Particle filter Estimation of ash load not plausible (too low) no reaction Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DD077	Engine uppercarr. Particle filter Particle load above warning threshold no reaction Report all error parameters to Service	A750		E	1
8DD078	Engine uppercarr. Particle filter Particle load above critical threshold no reaction Report all error parameters to Service	A750		E	1
8DD079	Engine uppercarr. Particle filter Ash load above warning threshold no reaction Report all error parameters to Service	A750		E	1
8DD07A	Engine uppercarr. Particle filter Ash load above critical threshold no reaction Report all error parameters to Service	A750		E	1
8DD103	Engine uppercarr. Travel pedal sensor 1 (voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8DD10B	Engine uppercarr. Travel pedal sensor 1 (voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DD203	Engine uppercarr. Travel pedal sensor 1 (current) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8DD20B	Engine uppercarr. Travel pedal sensor 1 (current) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DD303	Engine uppercarr. Travel pedal sensor 2 (voltage) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8DD30B	Engine uppercarr. Travel pedal sensor 2 (voltage) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DD403	Engine uppercarr. Travel pedal sensor 2 (current) short circuit to supply voltage no reaction Check wiring between control unit and components	A750		E	1
8DD40B	Engine uppercarr. Travel pedal sensor 2 (current) Short circuit after ground or line interruption no reaction Check wiring between control unit and components	A750		E	1
8DD921	Engine uppercarr. Switch idle rpm specification Voltage outside permissible range no reaction Check wiring between control unit and components	A750		E	1
8DDB33	Engine uppercarr. J1939 Prop3 Data transfer CAN problematic no reaction Check wiring, CAN-participant	A750		E	1
8DDC66	Engine uppercarr. Engine run turbulant Injection qty. correction of a cyl. too high no reaction Report all error parameters to Service	A750		E	1
8DDC67	Engine uppercarr. Engine run turbulant Deviation segment rpm of a cyl. too high no reaction Report all error parameters to Service	A750		E	1
8DDD6A	Engine uppercarr. Engine protection power reduction Air intake manifold temperature no reaction Check operation status of engine	A750		E	1
8DDD72	Engine uppercarr. Engine protection power reduction Charge air pr. too high no reaction Report all error parameters to Service	A750		E	1
8DDD73	Engine uppercarr. Engine protection power reduction Charge air pr. too low no reaction Report all error parameters to Service	A750		E	1
8DDF16	Engine uppercarr. Rpm sensor signal camshaft (voltage) Plausibility error no reaction Check operation status of engine	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DE016	Engine uppercarr. Rpm sensor signal crankshaft (voltage) Plausibility error no reaction Check operation status of engine	A750		E	1
8DE15B	Engine uppercarr. Digital input Starter signal 2 Start block due to a short circuit no reaction Report all error parameters to Service	A750		E	1
8DE235	Engine uppercarr. Power reduction to protect AGN-Systems Excess temperature error no reaction Report all error parameters to Service	A750		E	1
8DEA08	Engine uppercarr. Alrernator (voltage regulated) Line interruption no reaction Check wiring between control unit and components	A750		E	1
8DEA6C	Engine uppercarr. Alrernator (voltage regulated) Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8DEA6D	Engine uppercarr. Alrernator (voltage regulated) Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DEA6E	Engine uppercarr. Alrernator (voltage regulated) Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8DEA6F	Engine uppercarr. Alrernator (voltage regulated) Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DEA70	Engine uppercarr. Alrernator (voltage regulated) Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8DEB08	Engine uppercarr. Alternator (Shut off) Line interruption no reaction Check wiring between control unit and components	A750		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
8DEB6C	Engine uppercarr. Alternator (Shut off) Reg. deviation current value no reaction Report all error parameters to Service	A750		E	1
8DEB6D	Engine uppercarr. Alternator (Shut off) Short circuit after supply voltage Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DEB6E	Engine uppercarr. Alternator (Shut off) Short circuit after supply voltage ground switch no reaction Check wiring between control unit and components	A750		E	1
8DEB6F	Engine uppercarr. Alternator (Shut off) Short circuit after ground Plus switch no reaction Check wiring between control unit and components	A750		E	1
8DEB70	Engine uppercarr. Alternator (Shut off) Short circuit after ground, ground switch no reaction Check wiring between control unit and components	A750		E	1
8DF97D	Engine uppercarr. Injection system Comp. factors qty. match outside tol. range no reaction Report all error parameters to Service	A750		E	1
970000	gear ASTRONIC: System error recognized Note additional system errors Report all error parameters to Service	A61		E	2
971020	gear ASTRONIC: Main cut-off valve Y10 short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching blocked - automatic blocked RESET - otherwise replace gear-change	A61		E	1
971021	gear ASTRONIC: Main cut-off valve Y10 short circuit to supply voltage Switching blocked RESET - otherwise replace gear-change	A61		E	1
971022	gear ASTRONIC: Main cut-off valve Y10 interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
971120	gear ASTRONIC: Solenoid valve Y1 gear brake short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear-change	A61		E	1
971121	gear ASTRONIC: Solenoid valve Y1 gear brake short circuit to supply voltage Switching blocked RESET - otherwise replace gear-change	A61		E	1
971122	gear ASTRONIC: Solenoid valve Y1 gear brake interruption Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear-change	A61		E	1
971220	gear ASTRONIC: Solenoid valve Y2 splitter short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971222	gear ASTRONIC: Solenoid valve Y2 splitter interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971320	gear ASTRONIC: Solenoid valve Y3 splitter short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971321	gear ASTRONIC: Solenoid valve Y3 splitter short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971420	gear ASTRONIC: Solenoid valve Y4 gap short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971421	gear ASTRONIC: Solenoid valve Y4 gap short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971422	gear ASTRONIC: Solenoid valve Y4 gap interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
971520	gear ASTRONIC: Solenoid valve Y5 gap short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971521	gear ASTRONIC: Solenoid valve Y5 gap short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971522	gear ASTRONIC: Solenoid valve Y5 gap interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971620	gear ASTRONIC: Solenoid valve Y6 switching short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971621	gear ASTRONIC: Solenoid valve Y6 switching short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971622	gear ASTRONIC: Solenoid valve Y6 switching interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971720	gear ASTRONIC: Solenoid valve Y7 switching short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971721	gear ASTRONIC: Solenoid valve Y7 switching short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971722	gear ASTRONIC: Solenoid valve Y7 switching interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971820	gear ASTRONIC: Solenoid valve Y8 group short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
971821	gear ASTRONIC: Solenoid valve Y8 group short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971822	gear ASTRONIC: Solenoid valve Y8 group interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971920	gear ASTRONIC: Solenoid valve Y9 group short circuit to ground Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971921	gear ASTRONIC: Solenoid valve Y9 group short circuit to supply voltage Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
971922	gear ASTRONIC: Solenoid valve Y9 group interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
972033	gear ASTRONIC: Pressure reduction valve Mechanical error No function limitation RESET - otherwise replace pressure limitation valve	A61		E	1
972330	gear ASTRONIC: Splitter Switching error Only certain gears switchable - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972331	gear ASTRONIC: Splitter Activation error System not available RESET - otherwise replace gear-change	A61		E	1
972332	gear ASTRONIC: Splitter Deactivation error Only certain gears switchable - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972430	gear ASTRONIC: Gap Switching error Only certain gears switchable, automatic neutral switching - automatic blocked RESET - otherwise replace gear-change	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
972431	gear ASTRONIC: Gap Activation error Automatic neutral switching - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972432	gear ASTRONIC: Gap Deactivation error Only certain gears switchable, automatic neutral switching - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972530	gear ASTRONIC: Group Switching error Only certain gears switchable - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972531	gear ASTRONIC: Group Activation error Only certain gears switchable - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972532	gear ASTRONIC: Group Deactivation error Only certain gears switchable - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972630	gear ASTRONIC: Main gear Switching error Automatic neutral switching. Gear engagement conditionally possible - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972631	gear ASTRONIC: Main gear Activation error Automatic neutral switching. Gear engagement conditionally possible - automatic blocked RESET - otherwise replace gear-change	A61		E	1
972632	gear ASTRONIC: Main gear Deactivation error Travel: No gear shift status: Only certain gears can be shifted - automatic locked RESET - otherwise replace gear-change	A61		E	1
972742	gear ASTRONIC: Pressure sensor faulty/not present Output AL on display - no functional limitation if air pressure high enough - automatic locked RESET - otherwise replace pressure limitation valve	A61		E	1
972842	gear ASTRONIC: Temperature sensor TCU faulty/not present No function limitation RESET - otherwise replace gear-change	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
972942	gear ASTRONIC: Temperature sensor gear oil faulty/not present No function limitation RESET - otherwise replace gear-change	A61		E	1
973020	gear ASTRONIC: Sensor switching short circuit to ground Travel: Gear switching blocked - condition: Start-up gears can be switched RESET - otherwise replace gear-change	A61		E	1
973021	gear ASTRONIC: Sensor switching short circuit to supply voltage Travel: Gear switching blocked - condition: Start-up gears can be switched RESET - otherwise replace gear-change	A61		E	1
973022	gear ASTRONIC: Sensor switching interruption Travel: Gear switching blocked - condition: Start-up gears can be switched RESET - otherwise replace gear-change	A61		E	1
973025	gear ASTRONIC: Sensor switching Self-adjustment Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
973042	gear ASTRONIC: Sensor switching faulty/not present Automatic neutral switching. Gear engagement conditionally possible - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973120	gear ASTRONIC: Sensor gap short circuit to ground Only certain gears switchable - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973121	gear ASTRONIC: Sensor gap short circuit to supply voltage Only certain gears switchable - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973122	gear ASTRONIC: Sensor gap interruption Only certain gears switchable - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973125	gear ASTRONIC: Sensor gap Self-adjustment Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
973220	gear ASTRONIC: Sensor group short circuit to ground Only certain gears switchable - automatic blocked Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available	A61		E	1
973221	gear ASTRONIC: Sensor group short circuit to supply voltage Only certain gears switchable - automatic blocked Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available	A61		E	1
973222	gear ASTRONIC: Sensor group interruption Only certain gears switchable - automatic blocked Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available	A61		E	1
973225	gear ASTRONIC: Sensor group Self-adjustment Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available	A61		E	2
973242	gear ASTRONIC: Sensor group faulty/not present Automatic neutral switching. Gear engagement conditionally possible - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973320	gear ASTRONIC: Sensor splitter short circuit to ground Only every 2nd gear can be engaged, switch delay - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973321	gear ASTRONIC: Sensor splitter short circuit to supply voltage Only every 2nd gear can be engaged, switch delay - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973322	gear ASTRONIC: Sensor splitter interruption Only every 2nd gear can be engaged, switch delay - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973325	gear ASTRONIC: Sensor splitter Self-adjustment Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61		E	2
973342	gear ASTRONIC: Sensor splitter faulty/not present Automatic neutral switching. Gear engagement conditionally possible - automatic blocked RESET - otherwise replace gear-change	A61		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
973441	gear ASTRONIC: Sensor gear input speed Signal(s) implausible Travel: Switching blocked - cond.: Clutch opens, neut. switching blocked -system gear dep. conditionally available RESET - Check tachometers 1 and 2	A61		E	1
973442	gear ASTRONIC: Sensor gear input speed faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace gear-change	A61		E	1
973520	gear ASTRONIC: Sensor gear input speed 1 short circuit to ground Travel: Switching blocked - Automatic blocked RESET – otherwise replace sensor, wiring harness or gear controller	A61.X2:6/11/18		E	1
973521	gear ASTRONIC: Sensor gear input speed 1 short circuit to supply voltage No function limitation - Automatic blocked RESET – otherwise replace sensor, wiring harness or gear controller	A61.X2:6/11/18		E	1
973522	gear ASTRONIC: Sensor gear input speed 1 interruption Travel: Switching blocked - Automatic blocked RESET – otherwise replace sensor, wiring harness or gear controller	A61.X2:6/11/18		E	1
973542	gear ASTRONIC: Sensor gear input speed 1 faulty/not present Travel: switching blocked; Standstill: Clutch open; neutral: system not available Check sensor, wiring, control unit	A61.X2:6/11/18		E	1
973642	gear ASTRONIC: Gear output rpm 2,travel speed CAN faulty/not present No function limitation RESET - Check tachosystem	A61		E	1
973742	gear ASTRONIC: Sensor gear input speed 1/2 faulty/not present Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check tachometers 1 and 2	A61		E	2
973831	gear ASTRONIC: TCU cut-off relay Activation error System not available RESET - Check KI 30 ECU - otherwise replace gear-change	A61		E	2
973832	gear ASTRONIC: TCU cut-off relay Deactivation error System not available RESET - otherwise replace gear-change	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
974020	gear ASTRONIC: Solenoid valve Y15 "Clutch closes slowly" short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear-change	A61.X2:7		E	1
974021	gear ASTRONIC: Solenoid valve Y15 "Clutch closes slowly" short circuit to supply voltage Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace cable form clutch-change or clutch-change	A61.X2:7		E	2
974022	gear ASTRONIC: Solenoid valve Y15 "Clutch closes slowly" interruption Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable form clutch-change or clutch-change	A61.X2:7		E	1
974033	gear ASTRONIC: Solenoid valve Y15 "Clutch closes slowly" Mechanical error Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace clutch-change	A61.X2:7		E	1
974120	gear ASTRONIC: Solenoid valve Y14 "Clutch closes quickly" short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear-change	A61.X2:8		E	1
974121	gear ASTRONIC: Solenoid valve Y14 "Clutch closes quickly" short circuit to supply voltage Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace cable form clutch-change or clutch-change	A61.X2:8		E	2
974122	gear ASTRONIC: Solenoid valve Y14 "Clutch closes quickly" interruption Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable form clutch-change or clutch-change	A61.X2:8		E	1
974133	gear ASTRONIC: Solenoid valve Y14 "Clutch closes quickly" Mechanical error Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace clutch-change	A61.X2:8		E	1
974220	gear ASTRONIC: Solenoid valve Y17 "Clutch opens slowly" short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear-change	A61.X2:9		E	1
974221	gear ASTRONIC: Solenoid valve Y17 "Clutch opens slowly" short circuit to supply voltage Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace cable form clutch-change or clutch-change	A61.X2:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
974222	gear ASTRONIC: Solenoid valve Y17 "Clutch opens slowly" interruption Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable form clutch-change or clutch-change	A61.X2:9		E	1
974233	gear ASTRONIC: Solenoid valve Y17 "Clutch opens slowly" Mechanical error Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace clutch-change	A61.X2:9		E	1
974320	gear ASTRONIC: Solenoid valve Y16 "Clutch opens quickly" short circuit to ground Increased switch times - sporadic upshift locking - automatic blocked RESET - otherwise replace gear-change	A61.X2:12		E	1
974321	gear ASTRONIC: Solenoid valve Y16 "Clutch opens quickly" short circuit to supply voltage Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace cable form clutch-change or clutch-change	A61.X2:12		E	2
974322	gear ASTRONIC: Solenoid valve Y16 "Clutch opens quickly" interruption Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace cable form clutch-change or clutch-change	A61.X2:12		E	1
974333	gear ASTRONIC: Solenoid valve Y16 "Clutch opens quickly" Mechanical error Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace clutch-change	A61.X2:12		E	1
974424	gear ASTRONIC: Sensor clutch voltage below required value Travel: Loss of comfort during start-up - no ranging poss. - automatic time-controlled neutral switching - automatic RESET - Replace gear-change or clutch-change	A61.X2:10/15		E	1
974425	gear ASTRONIC: Sensor clutch Self-adjustment System not avilable RESET - otherwise replace gear-change, clutch-change, clutch	A61.X2:10/15		E	2
974442	gear ASTRONIC: Sensor clutch faulty/not present Travel: Loss of comfort during start-up - no ranging poss. - automatic time-controlled neutral switching - automatic RESET - otherwise replace clutch-change	A61.X2:10/15		E	1
974525	gear ASTRONIC: Clutch Self-adjustment System not avilable RESET - otherwise replace gear-change, clutch-change, clutch	A61		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
974531	gear ASTRONIC: Clutch Activation error Travel: Gear switching blocked - cond.: Engine stalled - automatic neutral switching - system not available RESET - otherwise replace gear-change, clutch-change, clutch	A61		E	2
974532	gear ASTRONIC: Clutch Deactivation error Switching blocked - clutch function limited - condition: Neutral switching - system not available RESET - otherwise replace gear-change, clutch-change, clutch	A61		E	2
975421	gear ASTRONIC: TCU power supply short circuit to supply voltage No function limitation RESET - otherwise replace sensor or cabling or gear-change	A61.X1:1/4/5		E	1
975422	gear ASTRONIC: TCU power supply interruption Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace sensor or cabling or gear-change	A61.X1:1/4/5		E	1
975923	gear ASTRONIC: On-board supply excess voltage No function limitation RESET - Check mains voltage	A61		E	1
975924	gear ASTRONIC: On-board supply voltage below required value Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check mains voltage	A61		E	2
976031	gear ASTRONIC: Ignition ON Kl.15 Activation error Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check CAN-communication ECU - MOT	A61		E	1
976241	gear ASTRONIC: Idle switch Signal(s) implausible Condition: No ranging and start-up possible - automatic blocked RESET - Check CAN-communication ECU - MOT (travel pedal)	A61		E	1
976401	gear ASTRONIC: CAN-interface system Permanent error, Bus communication interrupted Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check cabling CAN-communication	A61.X1:8/12		E	2
976404	gear ASTRONIC: CAN-interface system Memory error (queue overrun) Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check cabling CAN-communication	A61.X1:8/12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
976503	gear ASTRONIC: CAN-interface ZF Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: automat. Engagement of last start-up gear - reverse gear blocked RESET - otherwise replace gear-change, clutch-change, clutch	A61.X1:8/12		E	1
976610	gear ASTRONIC: Internal error TCU Incorrect interrupt triggered Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Replay software - otherwise replace gear-change	A61.X1		E	2
976611	gear ASTRONIC: Internal error TCU Memory error (stack watch) Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Replay software - otherwise replace gear-change	A61.X1		E	2
976612	gear ASTRONIC: Internal error TCU Parameter faulty Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Replay EOL parameter	A61.X1		E	2
976613	gear ASTRONIC: Internal error TCU EEPROM parameter check sum Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Replay EOL parameter	A61.X1		E	2
976614	gear ASTRONIC: Internal error TCU EEPROM access faulty Loss of comfort during start-up, switching and ranging - automatic blocked RESET - otherwise replace gear-change	A61.X1		E	1
976640	gear ASTRONIC: Internal error TCU Communication faulty/not present Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - otherwise replace gear-change	A61.X1		E	2
976644	gear ASTRONIC: Internal error TCU excess temperature Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check cooling system gear - otherwise replace gear-change	A61.X1		E	2
976703	gear ASTRONIC: CAN-data transfer ABS/ASR (ID 512) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check CAN-communication ECU - ABS	A61.X1:8/12		E	2
976803	gear ASTRONIC: CAN-data transfer ABS/ASR (ID 513) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check CAN-communication ECU - ABS	A61.X1:8/12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
976903	gear ASTRONIC: CAN-data transfer E/A-module (ID 588) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check CAN-communication ECU - EA-Modul	A61.X1:8/12		E	2
977003	gear ASTRONIC: CAN-data transfer engine (ID 592) Faulty/missing, max. cycle time exceeded Travel: Switching blocked - condition: Clutch opens, neutral switching - system not available RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	2
977103	gear ASTRONIC: CAN-data transfer engine (ID 593) Faulty/missing, max. cycle time exceeded Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	2
977203	gear ASTRONIC: CAN-data transfer retarder (ID 772) Faulty/missing, max. cycle time exceeded Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - INT	A61.X1:8/12		E	1
977301	gear ASTRONIC: CAN-message ID 1024 Permanent error, Bus communication interrupted Condition: No ranging and start-up possible - automatic blocked RESET - Check CAN-communication	A61.X1:8/12		E	1
977603	gear ASTRONIC: CAN-data transfer Intarder (12xx) Faulty/missing, max. cycle time exceeded Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - INT	A61.X1:8/12		E	1
977703	gear ASTRONIC: CAN-data transfer engine (ID 1360) Faulty/missing, max. cycle time exceeded Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	2
978042	gear ASTRONIC: CAN-signal travel speed faulty/not present No start-up gear calculation - no travel resistance calculation - travel strategy only operates conditionally RESET - Checking CAN-signals ECU/ABS/ASR	A61.X1:8/12		E	1
978142	gear ASTRONIC: CAN-signal average speed front axle faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - ABS	A61.X1:8/12		E	1
978242	gear ASTRONIC: CAN-signal differential speed front axle faulty/not present No function limitation RESET - Check CAN-communication ECU - ABS	A61.X1:8/12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
978342	gear ASTRONIC: CAN-signal intarder actual moment faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - INT	A61.X1:8/12		E	1
978442	gear ASTRONIC: CAN-signal intarder shift-in faulty/not present No shift-in requirements with retarder operation - loss of cooling output RESET - Check CAN-communication ECU - INT	A61.X1:8/12		E	1
978502	gear ASTRONIC: CAN-signal Telma actual moment Signal on CAN faulty/not present No function limitation RESET - Check CAN-communication ECU - EA-Modul	A61.X1:8/12		E	1
979042	gear ASTRONIC: CAN-signal engine speed faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	1
979140	gear ASTRONIC: CAN-signal drive moment Soll Communication faulty/not present Travel: Gear switching blocked - condition: Start-up gears can be switched - automatic blocked RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	1
979242	gear ASTRONIC: CAN-signal drive moment Ist faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	1
979342	gear ASTRONIC: CAN-signal engine moment dynamic faulty/not present No function limitation RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	1
979442	gear ASTRONIC: CAN-signal engine break moment faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	1
979542	gear ASTRONIC: CAN-signal travel pedal faulty/not present Loss of comfort during start-up, switching and ranging - automatic blocked RESET - Check CAN-communication ECU - MOT	A61.X1:8/12		E	1
979642	gear ASTRONIC: CAN-signal idle switch faulty/not present No function limitation RESET - Check CAN-communication ECU - MOT (travel pedal)	A61.X1:8/12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
979742	gear ASTRONIC: CAN-signal brake switch faulty/not present Comfort impeded when braking - automatic blocked RESET - Check CAN-communication ECU - MOT (brake switch)	A61.X1:8/12		E	1
979942	gear ASTRONIC: CAN-signal Tempomat faulty/not present No function limitation RESET - Check CAN-communication ECU - MOT (Tempomat)	A61.X1:8/12		E	0
981113	WSK: Outlet recirculation valve Disconnection/wire break WSK-ECU no longer controls the outlet (recirculation valve), retarder response time increases Check cables, recirculation valve (inner res. approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 03	A63		E	1
981211	WSK: Outlet WK-valve short circuit to ground WSK-ECU no longer controls the outlet (WK-valve), only converter operation possible Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 04	A63		E	1
981212	WSK: Outlet WK-valve short circuit to supply voltage WSK-ECU no longer controls the outlet (WK-valve), no converter operation possible: line permanently active Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 05	A63		E	1
981213	WSK: Outlet WK-valve Disconnection/wire break WSK-ECU no longer controls the outlet (WK-valve), only converter operation possible Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 06	A63		E	1
981911	WSK: Outlet proportional valve retarder short circuit to ground WSK-ECU no longer controls prop. valve; no retarder moment available Check cables, prop.-valve; replace WSK-ECU, ZF 10	A63		E	1
981912	WSK: Outlet proportional valve retarder short circuit to supply voltage WSK-ECU no longer controls prop. V.; (line perm. active; when no ground shut off path - retarder) Check cables, prop.-valve; replace WSK-ECU, ZF 11	A63		E	1
981913	WSK: Outlet proportional valve retarder Disconnection/wire break WSK-ECU no longer controls prop. valve; no retarder moment available Check cables, prop.-valve; replace WSK-ECU, ZF 12	A63		E	1
981914	WSK: Outlet proportional valve retarder Error in component/element/transmission WSK-ECU no longer controls prop. valve; no retarder moment available Check cables, prop.-valve; replace WSK-ECU, ZF 13	A63		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
982111	WSK: Outlet earth switching proportional valve retarder short circuit to ground WSK-ECU shuts down the retarder; retarder no longer available. (line permanently active) Check cables, prop.-valve; replace WSK-ECU, ZF 14	A63		E	1
982112	WSK: Outlet earth switching proportional valve retarder short circuit to supply voltage WSK-ECU shuts down the retarder; retarder no longer available Check cables, prop.-valve; replace WSK-ECU, ZF 15	A63		E	1
982211	WSK: Outlet earth switching WK-valve short circuit to ground WSK-ECU no longer controls outlet (WK-valve), only converter operation possible (depending on status output WK-valve) Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 16	A63		E	1
982212	WSK: Outlet earth switching WK-valve short circuit to supply voltage WSK-ECU no longer controls outlet (WK-valve), only converter operation possible (depending on status output WK-valve) Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 17	A63		E	1
982213	WSK: Outlet earth switching WK-valve Disconnection/wire break WSK-ECU no longer controls the outlet (WK-valve), only converter operation possible Check cables, WK-valve (inner resistance approx. 120 Ohm; measure the WSK-ECU at the plug); replace WSK-ECU, ZF 18	A63		E	1
982316	WSK: Current sensing proportional valve retarder Permissible signal range fallen short of WSK-ECU shuts down the retarder; retarder no longer available Replace WSK-ECU, ZF 24	A63		E	1
982317	WSK: Current sensing proportional valve retarder Permissible signal range exceeded WSK-ECU shuts down the retarder; retarder no longer available Replace WSK-ECU, ZF 25	A63		E	1
983119	WSK: Turbine speed Signal faulty/lacking Turbine speed interrupted: Limitation retarder power to 250mA; opened WK does not close; no active diagnosis Check CAN-Bus system, Bus subscriber, ZF 19	A63		E	1
983211	WSK: Oil temperature sensor short circuit to ground WSK-ECU limits the maximum permissible braking action to 100kW Check cables, temperature sensor; replace WSK-ECU, ZF 23	A63		E	1
983213	WSK: Oil temperature sensor Disconnection/wire break WSK-ECU limits the maximum permissible braking action to 100kW Check cables, temperature sensor; replace WSK-ECU, ZF 22	A63		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
983217	WSK: Oil temperature sensor Permissible signal range exceeded Warning information End converter operation; end or reduce retarder operation, ZF 20	A63		E	1
983419	WSK: Engine speed Signal faulty/lacking Engine speed interrupted: WK only closes at KD-threshold; no active diagnosis Check CAN-Bus system, Bus subscriber, ZF 34	A63		E	1
984319	WSK: CAN-transmission error Signal faulty/lacking No direct error reaction Check CAN-Bus system, Bus subscriber, ZF 37	A63		E	1
984415	WSK: CAN-bus system Error in component/element/transmission No direct error reaction Check CAN-Bus system, Bus subscriber, ZF 38	A63		E	1
984615	WSK: CAN-Bus transmission Error in component/element/transmission No direct error reaction Check CAN-Bus system, Bus subscriber, ZF 40	A63		E	1
985919	WSK: CAN-communication with engine (FMR1) Signal faulty/lacking Error reaction is dependent on the signals read in the message Check CAN-Bus system, Bus subscriber, ZF 48	A63		E	1
986119	WSK: CAN-communication with gear (EPS) Signal faulty/lacking Error reaction is dependent on the signals read in the message Check CAN-Bus system, Bus subscriber, ZF 50	A63		E	1
986219	WSK: CAN-communication with engine (FMR2) Signal faulty/lacking Error reaction is dependent on the signals read in the message Check CAN-Bus system, Bus subscriber, ZF 49	A63		E	1
986319	WSK: CAN-communication with gear (EPS) Signal faulty/lacking Error reaction is dependent on the signals read in the message CAN-Bus system, check bus participant, ZF 41	A63		E	1
986519	WSK: CAN-communication with gear (MKR) Signal faulty/lacking Error reaction is dependent on the signals read in the message Check CAN-Bus system, Bus subscriber, ZF 47	A63		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
987113	WSK: Terminal 30 Disconnection/wire break In operation: no reaction; with ignition OFF:no after-run operation Check supply of WSK-ECU (cables), check fuse terminal 30, ZF 26	A63		E	1
987216	WSK: Terminal 15 Permissible signal range fallen short of WSK-ECU shuts down the retarder; no retarder availability; digital outlets switched off; WK will not be closed Check on-board supply voltage (battery, alternator), ZF 28	A63		E	1
987217	WSK: Terminal 15 Permissible signal range exceeded WSK-ECU shuts down retarder; retarder no longer available Check on-board supply voltage (battery, alternator), ZF 27	A63		E	1
988218	WSK: Operating hours counter Plausibility error Operating hour meter can not be read from EEPROM, WSK-ECU resets operating hour meter to 0 Switch ignition on and off, if error is active again replace WSK-ECU, ZF 31	A63		E	0
988318	WSK: Error memory Plausibility error Error stack cannot be read from EEPROM, WSK-ECU throws the 'old' Error stack contents out Delete error memory, then switch ignition on and off, if error is active again replace WSK-ECU, ZF 32	A63		E	0
988415	WSK: System error Error in component/element/transmission Replace WSK-ECU, ZF 35	A63		E	1
988618	WSK: Internal data memory (EEPROM) Plausibility error No direct error reaction Error Statistic memory, ignition off=>on, replace control unit WSK	A63		E	1
A17F34	LSB-EA 1: Signals speed recordation Travel speed Tachograph missing Error message, larger of two signals is used as travel speed Check tachograph, Gear output RPM, reports from distributor gear	A41		E	1
A17F36	LSB-EA 1: Signals speed recordation Travel speed Tachograph <> Gear output RPM not plausible Error message, larger of two signals is used as travel speed Check tachograph, Gear output RPM, reports from distributor gear	A41		E	1
A180FA	LSB-EA 1: control engine Configuration Engine type missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A41		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A180FB	LSB-EA 1: control engine Configuration Exhaust stage missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A41		E	1
A180FC	LSB-EA 1: control engine Configuration Engine type implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A41		E	1
A180FD	LSB-EA 1: control engine Configuration Exhaust stage implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A41		E	1
A18110	LSB-EA 1: control transmission long-term disruption shift selector operation unit <-> gears Placing gear prevented Check CAN-Network, control units	A41		E	1
A18111	LSB-EA 1: control transmission long-term disruption shift selector crane op. cab<-> E/A-Modul Placing gear prevented, after timeout, Neutral is given Check LSB-connection superstructure<->chassis, control units	A41		E	1
A18112	LSB-EA 1: control transmission long-term disruption connection E/A-Modul <-> operation unit Placing gear prevented, after timeout, Neutral is given Check SPI-connection, control unit, operating unit(Test program)	A41		E	1
A18122	LSB-EA 1: control transmission Dry coupling worn Error after dir.selection reported for approx. 10s, clutch light blinks 2Hz Check clutch pad or possible replace clutch immediately	A41		E	1
A1851A	LSB-EA 1: control axle suspension/level Signals from sensor blocked and suspended implausible Control retains last valid value check blocked limit switch and buffered limit switch	A41		E	1
A18970	LSB-EA 1: control brakes/pneumatic system Brake force reduction prevented,Sensor Ballast mon. erroneous No or continuous brake force reduction Check control unit, wiring, valve	A41		E	1
A18971	LSB-EA 1: control brakes/pneumatic system Brake force reduction prevented, Error Data transfer (SPI) No brake force reduction Check sensor, LSB	A41		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A18E55	LSB-EA 1: control lighting amperage indicator erroneous function is not carried out use original incandescent lamps, check indicator system for short to supply voltage	A41		E	1
A18E56	LSB-EA 1: control lighting vehicle indicator defective function is not carried out check indicator system	A41		E	1
A18F00	LSB-EA 1: control heating/air conditioning servo-motor heating, circulated/fresh air or screen/foot erroneous servo motor relays a high signal to the diagnosis output check water valve and air flaps of the heating or check servo motor	A41		E	1
A19127	LSB-EA 1: Control splitterbox, road/off-road Feedback signal road/off-road faulty/lacking Check limit switch, wiring, mechanics of limit switch	A41		E	1
A19413	LSB-EA 1: Control active rear axle steering Hydraulic oil temperature too high error report Check hydraulic, oil temp. (steering pumps) AHL	A41		E	1
A19483	LSB-EA 1: Control active rear axle steering Return report steering status right/left implausible Check CAN-Bus connection, steering comp., steering	A41		E	1
A194A0	LSB-EA 1: Control active rear axle steering CAN-Signal steering program from LSB-EA3 erroneous/missing Check CAN-Bus connection, steering comp., steering	A41		E	1
A194A1	LSB-EA 1: Control active rear axle steering CAN-Signal steering program from LSB-EA4 erroneous/missing Check CAN-Bus connection, steering comp., steering	A41		E	1
A19C02	LSB-EA 1: control diagnosis system error in diagnosis requirement CAN-participant ABS Error diagnostics, diagnostics routines prevented Check CAN-Network, control units; vehicle condition prevented Diagnostics (system error)	A41		E	1
A19F51	LSB-EA 1: operation transmission CAN-connection shift selector <-> gear electronics malfunctioning	A41		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A19F52	LSB-EA 1: operation transmission connection shift selector <-> keyboard unit malfunctioning	A41		B	
A19F61	LSB-EA 1: operation transmission shift selector out of order: key sticking	A41		B	
A19F70	LSB-EA 1: operation transmission Travel direction selection prevented, travel speed too high	A41		B	
A19F71	LSB-EA 1: operation transmission Travel direction selection hindered, splitterbox in neutral	A41		B	
A19F72	LSB-EA 1: operation transmission selection of travel direction prevented, op. type not recognized	A41		B	
A19F74	LSB-EA 1: operation transmission shift selector out of order when engine OFF	A41		B	
A19F76	LSB-EA 1: operation transmission selection of travel direction prevented, operation brake not active	A41		B	
A19F78	LSB-EA 1: operation transmission Travel direction selection prevented, crane cab not lowered D/R prevented Lower cab to transport position	A41		B	
A19F7A	LSB-EA 1: operation transmission Neutral control, travel direction selection prevented by gear Travel direction is continuously not like nominal, neutral control at standstill, pre-warning of rolling vehicle	A41		B	
A19F86	LSB-EA 1: operation transmission Preselection gear prevented at current travel speed	A41		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A19F8F	LSB-EA 1: operation transmission Change over travel program only with distributor gear in on-road gear	A41		B	
A19F91	LSB-EA 1: operation transmission Change-over travel program only in D possible	A41		B	
A19FA3	LSB-EA 1: operation transmission Change over prevents distr. gear in off-road gear	A41		B	
A1A301	LSB-EA 1: operation axle suspension operation of 2-hand-function without activation of 2-hand-key function is not carried out Press 2-Hand key (or deadman)	A41		B	
A1A302	LSB-EA 1: operation axle suspension operation from upper-carriage without operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A41		B	
A1A303	LSB-EA 1: operation axle suspension operation from under-carriage without operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A41		B	
A1A30F	LSB-EA 1: operation axle suspension Function prevented, deadman not actuated	A41		B	
A1A325	LSB-EA 1: operation axle suspension function with actual travel speed blocked	A41		B	
A1A33F	LSB-EA 1: operation axle suspension Function locked at blocked axle suspension	A41		B	
A1AA0A	LSB-EA 1: operation steering rear axle simultaneous operation of superstructure and chassis function is not carried out	A41		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A1AA4A	LSB-EA 1: operation steering rear axle Function prevented at current travel speed function is not carried out	A41		B	
A1AA61	LSB-EA 1: operation steering rear axle Control rear axle steering when locked function is not carried out	A41		B	
A1B230	LSB-EA 1: operation heating/air.conditioning switching on air-conditioning only possible with engine running function is not carried out start engine and repeat operation	A41		B	
A1B380	LSB-EA 1: operation lighting Turn on parking light on keyboard unit Report parking light on keyboard panel blinks Turn on parking light on keyboard unit	A41		B	
A1B381	LSB-EA 1: operation lighting Parking light still turned on Turn parking light off on keyboard unit	A41		B	
A1B386	LSB-EA 1: operation lighting rear fog lamp only with light function is not carried out switch on full beam, dipped light or fog light	A41		B	
A1B401	LSB-EA 1: Control length / cross lock operation of 2-hand-function without activation of 2-hand-key	A41		B	
A1B403	LSB-EA 1: Control length / cross lock operation from under-carriage without operation mode	A41		B	
A1B40B	LSB-EA 1: Control length / cross lock Control point incorrect for set operating mode	A41		B	
A1B44A	LSB-EA 1: Control length / cross lock Function prevented at current travel speed	A41		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A1B44B	LSB-EA 1: Control length / cross lock prevented, switch sequence incorrect	A41		B	
A1B458	LSB-EA 1: Control length / cross lock Critical steering angle at placed shut off, overload possible	A41		B	
A1B493	LSB-EA 1: Control length / cross lock function not available/no customisation	A41		B	
A1B5A0	LSB-EA 1: Control distributor gear, road / off road Change over prevented at distributor gear in neutral position	A41		B	
A1B5A1	LSB-EA 1: Control distributor gear, road / off road Change over prevented at current travel speed	A41		B	
A1B5A2	LSB-EA 1: Control distributor gear, road / off road Change over prevented at gear not in neutral (N)	A41		B	
A1BC01	LSB-EA 1: Operation active rear axle steering 2-Hand-Function without actuation of 2-Hand-Key	A41		B	
A1BC07	LSB-EA 1: Operation active rear axle steering Prevents: steering/operation type not initialised	A41		B	
A1BC08	LSB-EA 1: Operation active rear axle steering Prevented in error condition	A41		B	
A1BC29	LSB-EA 1: Operation active rear axle steering Change-over operat. type prevented:several keys actuated / key jamming Check buttons on control unit, button pressed after ignition?	A41		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A1BC2F	LSB-EA 1: Operation active rear axle steering Automatic alignment of steering axles only in active steering prog. 5	A41		B	
A1BC30	LSB-EA 1: Operation active rear axle steering Switch-over operation type prevented: Travel speed too high	A41		B	
A1BC33	LSB-EA 1: Operation active rear axle steering Function prevented: Keyboard blocked in OW-operation	A41		B	
A1BC39	LSB-EA 1: Operation active rear axle steering Function prevented: keypad blocked in chassis op.	A41		B	
A1BC3A	LSB-EA 1: Operation active rear axle steering Function prevented: Keypad blocked, no op. mode recognized	A41		B	
A1BC3B	LSB-EA 1: Operation active rear axle steering Steering program not present or locked	A41		B	
A1C02E	LSB-EA 1: Diagnostics syst. band end/adj. program Test program stop - air pressure reserves outside permissible range Test program is not started or aborted Air pressure accum. 1..4 fill / empty, pressure range 4.5 bar to 6.5 bar	A41		B	
A1C03B	LSB-EA 1: Diagnostics syst. band end/adj. program Test program not executable since ignition off Test program is not started or aborted	A41		B	
A1C03C	LSB-EA 1: Diagnostics syst. band end/adj. program Test program not executable since brake pedal not actuated Test program is not started or aborted	A41		B	
A1C03D	LSB-EA 1: Diagnostics syst. band end/adj. program Test program not executable since air pressure reserve not sufficient Test program is not started or aborted Fill accumulator 1..4 , min. pressure for test programs each 6.0 bar	A41		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A1C03F	LSB-EA 1: Diagnostics syst. band end/adj. program Test program not executable since brake pedal actuated Test program is not started or aborted	A41		B	
A1C041	LSB-EA 1: Diagnostics syst. band end/adj. program Test program not executable since gear not in N Test program is not started or aborted	A41		B	
A1C043	LSB-EA 1: Diagnostics syst. band end/adj. program Test program not executable at current travel speed Test program is not started or aborted	A41		B	
A1C044	LSB-EA 1: Diagnostics syst. band end/adj. program Test program not executable since motor not off Test program is not started or aborted	A41		B	
A1C084	LSB-EA 1: Diagnostics syst. band end/adj. program Test program ABS-sensor not yet carried out error report Carry out Test/Band end program error free	A41		E	1
A1C085	LSB-EA 1: Diagnostics syst. band end/adj. program Test program ABS-valves not yet carried out error report Carry out Test/Band end program error free	A41		E	1
A1C087	LSB-EA 1: Diagnostics syst. band end/adj. program Test program ASR-valve not executed error report Carry out Test/Band end program error free	A41		E	1
A1C0C0	LSB-EA 1: Diagnostics syst. band end/adj. program Test program: Baud rate to SPI-unit erroneous error report Check Bus connection	A41		E	1
A1C0C1	LSB-EA 1: Diagnostics syst. band end/adj. program Test program: Error on a control motor error report Check control motors	A41		E	1
A1C193	LSB-EA 1: operation optional device function not available/no customisation function is not carried out on customers request	A41		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A27F34	LSB-EA 2: Signals speed recordation Travel speed Tachograph missing Error message, larger of two signals is used as travel speed Check tachograph, Gear output RPM, reports from distributor gear	A42		E	1
A27F35	LSB-EA 2: Signals speed recordation Travel speed Tachograph incorrect Error message, larger of two signals is used as travel speed Check tachograph, Gear output RPM, reports from distributor gear	A42		E	1
A27F36	LSB-EA 2: Signals speed recordation Travel speed Tachograph <> Gear output RPM not plausible Error message, larger of two signals is used as travel speed Check tachograph, Gear output RPM, reports from distributor gear	A42		E	1
A28003	LSB-EA 2: control engine no signal from gas pedal crane operator's cab Input nominal RPM = Low idle Check gas pedal, LSB, wiring	A42		E	1
A280FA	LSB-EA 2: control engine Configuration Engine type missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A42		E	1
A280FB	LSB-EA 2: control engine Configuration Exhaust stage missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A42		E	1
A280FC	LSB-EA 2: control engine Configuration Engine type implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A42		E	1
A280FD	LSB-EA 2: control engine Configuration Exhaust stage implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A42		E	1
A287E0	LSB-EA 2: control steering Steering motor front axle steering actual current too low error indication on display Check outlets on control units, wiring, electric motor	A42		E	1
A287E1	LSB-EA 2: control steering Steering motor front axle steering actual current too high Steering is saved and shut off Check outlets on control units, wiring, electric motor	A42		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A2882F	LSB-EA 2: control supports Cross comparison channel 1 and channel 2 incorrect support functions are blocked Check speed signals and bus transfer on LSB-EA2, LSB-EA3 and LSB-EA4	A42		E	1
A2890C	LSB-EA 2: control brakes/pneumatic system Data transfer CAN 1 (travel drive) faulty Shut off of valve for superstructure parking brake Check control unit(s), Bus system(s)	A42		E	1
A2890D	LSB-EA 2: control brakes/pneumatic system Data transfer CAN 3 (vehicle) faulty Shut off of valve for superstructure parking brake Check control unit(s), Bus system(s)	A42		E	2
A2890E	LSB-EA 2: control brakes/pneumatic system Data transfer LSB (control platform crane operator s cab) faulty Shut off of valve for superstructure parking brake Check control unit(s), Bus system(s)	A42		E	1
A2894C	LSB-EA 2: control brakes/pneumatic system Valve change over parking brake chassis short circuit after ground Change over switch remains in previous position Check wiring, valve, control unit	A42		E	1
A2894D	LSB-EA 2: control brakes/pneumatic system Valve change over parking brake chassis short circuit after Vcc Change over switch cannot be brought into other position Check wiring, valve, control unit	A42		E	2
A2894E	LSB-EA 2: control brakes/pneumatic system Valve change over parking brake superstr short circuit after ground Change over switch remains in previous position Check wiring, valve, control unit	A42		E	1
A2894F	LSB-EA 2: control brakes/pneumatic system Valve change over parking brake superstr. short circuit after Vcc Change over switch cannot be brought into other position Check wiring, valve, control unit	A42		E	2
A28957	LSB-EA 2: control brakes/pneumatic system brake pressure switch 0.5 bar signal "op. brakes active" missing Signal service brake is deduced from analog pressure sensors Check wiring, sensor, supply of sensor	A42		E	1
A28959	LSB-EA 2: control brakes/pneumatic system Brake pressure switch actuated after ignition on / short circuit after Signal set after ignition on, key-down Release brake at ignition on; check wiring, sensor	A42		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A2895A	LSB-EA 2: control brakes/pneumatic system Brake pads worn Error message in superstr. op. at actuated brake, warn. light in chassis Check brake pads, sensors, wiring	A42		E	1
A2895B	LSB-EA 2: control brakes/pneumatic system Pr. switch parking brake seizes / short circuit Vcc, valve seizes Check parking brake valve, outlet on control unit, wiring, sensor	A42		E	1
A2895C	LSB-EA 2: control brakes/pneumatic system Pr. switch Parking brake does not close, valve seizes Shut off of valve for superstructure parking brake, shut off of pressure supply Check parking brake valve, outlet on control unit, wiring, sensor	A42		E	2
A2895D	LSB-EA 2: control brakes/pneumatic system Pr. switch Parking brake faulty Shut off of valve for superstructure parking brake Check wiring, sensor	A42		E	1
A28971	LSB-EA 2: control brakes/pneumatic system Brake force reduction prevented, Error Data transfer (SPI) No brake force reduction Check sensor, LSB	A42		E	1
A28A3E	LSB-EA 2: control hydraulic/second. power outputs Actuation engage crane pump does not turn on, short circuit ground error report Check control unit, wiring, valve	A42		E	2
A28A3F	LSB-EA 2: control hydraulic/second. power outputs Actuation engage crane pump does not turn off, short circuit VCC Error message, 2. shut off channel outlets is turned off Check control unit, wiring, valve	A42		E	1
A28A40	LSB-EA 2: control hydraulic/second. power outputs feedback crane hydr. pump active in crane op. missing in case of error limit switch no restriction, if pump not on crane operation (LS) is not possible	A42		E	1
A28A41	LSB-EA 2: control hydraulic/second. power outputs feedback crane hydr. pump inactive in travel op. missing Engine RPM limited Wiring limit switch valves, valves engage/disengage, check limit switch	A42		E	1
A28B6A	LSB-EA 2: instruments operators cab Signals from lever auxiliary brakes not plausible	A42		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A28B75	LSB-EA 2: instruments operators cab Tempomat lever no signal or supply voltage missing Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B76	LSB-EA 2: instruments operators cab Tempomat lever signal SET+ no signal or short to ground Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B77	LSB-EA 2: instruments operators cab Tempomat lever signal SET- no signal or short to ground Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B78	LSB-EA 2: instruments operators cab Tempomat lever signal OFF no signal or short to ground Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B79	LSB-EA 2: instruments operators cab Tempomat lever signal QUIT short to supply voltage Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B80	LSB-EA 2: instruments operators cab Tempomat lever signal TEMPOSET short to supply voltage Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B81	LSB-EA 2: instruments operators cab Tempomat lever signal TEMPOMAT SET+ without returning (QUIT) Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B82	LSB-EA 2: instruments operators cab Tempomat lever signal TEMPOMAT SET- without returning (QUIT) Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B83	LSB-EA 2: instruments operators cab Tempomat lever signal OFF without returning (QUIT) Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1
A28B84	LSB-EA 2: instruments operators cab Tempomat lever signals SET+, SET-, OFF erroneous combination Lever is signaled as incorrect (s.n.v.) Check lever, wiring, inputs	A42		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A29483	LSB-EA 2: Control active rear axle steering Return report steering status right/left implausible Check CAN-Bus connection, steering comp., steering	A42		E	1
A294A0	LSB-EA 2: Control active rear axle steering CAN-Signal steering program from LSB-EA3 erroneous/missing Check CAN-Bus connection, steering comp., steering	A42		E	1
A294A1	LSB-EA 2: Control active rear axle steering CAN-Signal steering program from LSB-EA4 erroneous/missing Check CAN-Bus connection, steering comp., steering	A42		E	1
A29E78	LSB-EA 2: operation engine Gas pedal crane operator's cab actuated after problem Input nominal RPM = Low idle One time pedal input 0%	A42		E	1
A2AB02	LSB-EA 2: operation steering front axle operation from upper-carriage without operation mode function is not carried out	A42		B	
A2AB0D	LSB-EA 2: operation steering front axle Function locked if engine not on function is not carried out	A42		B	
A2AB0E	LSB-EA 2: operation steering front axle No signal master switch assignment Crane op. cab error indication on display	A42		B	
A2AB0F	LSB-EA 2: operation steering front axle Function prevented, deadman not actuated error indication on display	A42		B	
A2AB1B	LSB-EA 2: operation steering front axle No signal from slewing platform direction function is not carried out	A42		B	
A2AB1C	LSB-EA 2: operation steering front axle Signal active steering program missing error indication on display	A42		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A2AB1D	LSB-EA 2: operation steering front axle Function Locked since error recognized on outlet function is not carried out	A42		B	
A2AB1E	LSB-EA 2: operation steering front axle Function prevented, both master switches deflected Steering blocked Both master switches in neutral pos.	A42		B	
A2AB1F	LSB-EA 2: operation steering front axle Function prevented, neither deadman nor seat contact actuated Steering blocked Both master switches in neutral pos., then actuate deadman or seat contact	A42		B	
A2AB67	LSB-EA 2: operation steering front axle Steering motor not engaged(Parking brake not released function is not carried out	A42		B	
A2AD71	LSB-EA 2: operation brakes/pneumatics system Release parking brake prevented, lack of compressed air Check air pr. reserves, fill reservoir	A42		B	
A2AD72	LSB-EA 2: operation brakes/pneumatics system Release parking brake prevented, error condition Remedy system error	A42		B	
A2AD73	LSB-EA 2: operation brakes/pneumatics system Release parking brake prevented, motor is not running Start engine	A42		B	
A2AD7B	LSB-EA 2: operation brakes/pneumatics system Release parking brake prevented, operating mode incorrect Check air pr. reserves, fill reservoir	A42		B	
A2AE66	LSB-EA 2: operation hydraulics/second. power outputs hyd. crane system pump not engaged as compr. air supply too low Fill air pressure reserves 1-3 (engine on), then engine stop, then restart	A42		B	
A2AE67	LSB-EA 2: operation hydraulics/second. power outputs Pump crane hydr. not engages, error condition in actuation Wiring limit switch valves, valves engage/disengage, check limit switch	A42		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A2C03B	LSB-EA 2: Diagnostics syst. band end/adj. program Test program not executable since ignition off Test program is not started or aborted	A42		B	
A2C041	LSB-EA 2: Diagnostics syst. band end/adj. program Test program not executable since gear not in N Test program is not started or aborted	A42		B	
A2C043	LSB-EA 2: Diagnostics syst. band end/adj. program Test program not executable at current travel speed Test program is not started or aborted	A42		B	
A2C044	LSB-EA 2: Diagnostics syst. band end/adj. program Test program not executable since motor not off Test program is not started or aborted	A42		B	
A2C0C0	LSB-EA 2: Diagnostics syst. band end/adj. program Test program: Baud rate to SPI-unit erroneous error report Check Bus connection	A42		E	1
A2FA5F	LSB-EA 2: Control data transfer CAN-A Malfunction, all participants missing Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:2/3		E	1
A2FB5F	LSB-EA 2: Control data transfer CAN-B Malfunction, all participants missing Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:4/5		E	1
A2FB60	LSB-EA 2: Control data transfer CAN-B Motor erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:4/5		E	1
A2FB61	LSB-EA 2: Control data transfer CAN-B Gear erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:4/5		E	1
A2FB62	LSB-EA 2: Control data transfer CAN-B ABV erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A2FB65	LSB-EA 2: Control data transfer CAN-B Retarder erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:4/5		E	1
A2FB67	LSB-EA 2: Control data transfer CAN-B WSK erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:4/5		E	1
A2FBA0	LSB-EA 2: Control data transfer CAN-B LSB-EA1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:4/5		E	1
A2FBA1	LSB-EA 2: Control data transfer CAN-B LSB-EA2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A42.X4:4/5		E	1
A37111	LSB-EA 3: Proportional valve steering axle LA1 CAN-communication with E/A-module faulty/lacking (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A43		E	1
A37112	LSB-EA 3: Proportional valve steering axle LA1 CAN-communication with E/A-module faulty/lacking (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A43		E	1
A37113	LSB-EA 3: Proportional valve steering axle LA1 CAN-communication with E/A-module implausible (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A43		E	1
A37114	LSB-EA 3: Proportional valve steering axle LA1 CAN-communication with E/A-module implausible (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A43		E	1
A37115	LSB-EA 3: Proportional valve steering axle LA1 Voltage supply/PWM-control faulty Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37116	LSB-EA 3: Proportional valve steering axle LA1 Internal error, EEPROM-memory inconsistent Valve is not controlled (neutral position), secondary measures possibly required Check valve configuration, replace valve	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A37117	LSB-EA 3: Proportional valve steering axle LA1 Reference value valve not neutral due to continuous error Valve is not controlled (neutral position), secondary measures possibly required Remedy fault, activate/deactivate ignition	A43		E	1
A37121	LSB-EA 3: Proportional valve steering axle LA1 Voltage supply below permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37122	LSB-EA 3: Proportional valve steering axle LA1 Voltage supply above permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37123	LSB-EA 3: Proportional valve steering axle LA1 Slide deflected too short; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve; replace valve; errors may be resulted from engine stalling	A43		E	1
A37124	LSB-EA 3: Proportional valve steering axle LA1 Slide deflected too far; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A43		E	1
A37125	LSB-EA 3: Proportional valve steering axle LA1 Valve float position not reached Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A43		E	1
A37126	LSB-EA 3: Proportional valve steering axle LA1 Manual actuation With fault-free valve and neutral set value, error report only No manual operation possible, check valve and replace if necessary; valve shifted mechanically out of neutral?	A43		E	1
A37131	LSB-EA 3: Proportional valve steering axle LA1 Voltage supply below 8V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37132	LSB-EA 3: Proportional valve steering axle LA1 Voltage supply above 36..45V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37141	LSB-EA 3: Proportional valve steering axle LA1 Voltage supply above 45V, internal emergency shut-down Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A37142	LSB-EA 3: Proportional valve steering axle LA1 Power amplifier error solenoid valve servo-control Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A43		E	1
A37143	LSB-EA 3: Proportional valve steering axle LA1 Distance converter valve stroke faulty Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A43		E	1
A37181	LSB-EA 3: Proportional valve steering axle LA1 Slide valve can not be shifted into neutral position Internal emergency shut-down, possible valve can not switch to neutral, secondary measures possibly required Check hydraulic supply, valve; replace valve	A43		E	1
A37182	LSB-EA 3: Proportional valve steering axle LA1 Slide valve not in neutral position upon activation Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve and replace if necessary; valve shifted mechanically out of neutral?	A43		E	1
A37311	LSB-EA 3: Proportional valve steering axle LA3 CAN-communication with E/A-module faulty/lacking (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A43		E	1
A37312	LSB-EA 3: Proportional valve steering axle LA3 CAN-communication with E/A-module faulty/lacking (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A43		E	1
A37313	LSB-EA 3: Proportional valve steering axle LA3 CAN-communication with E/A-module implausible (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A43		E	1
A37314	LSB-EA 3: Proportional valve steering axle LA3 CAN-communication with E/A-module implausible (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A43		E	1
A37315	LSB-EA 3: Proportional valve steering axle LA3 Voltage supply/PWM-control faulty Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37316	LSB-EA 3: Proportional valve steering axle LA3 Internal error, EEPROM-memory inconsistent Valve is not controlled (neutral position), secondary measures possibly required Check valve configuration, replace valve	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A37317	LSB-EA 3: Proportional valve steering axle LA3 Reference value valve not neutral due to continuous error Valve is not controlled (neutral position), secondary measures possibly required Remedy fault, activate/deactivate ignition	A43		E	1
A37321	LSB-EA 3: Proportional valve steering axle LA3 Voltage supply below permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37322	LSB-EA 3: Proportional valve steering axle LA3 Voltage supply above permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37323	LSB-EA 3: Proportional valve steering axle LA3 Slide deflected too short; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve; replace valve; errors may be resulted from engine stalling	A43		E	1
A37324	LSB-EA 3: Proportional valve steering axle LA3 Slide deflected too far; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A43		E	1
A37325	LSB-EA 3: Proportional valve steering axle LA3 Valve float position not reached Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A43		E	1
A37326	LSB-EA 3: Proportional valve steering axle LA3 Manual actuation With fault-free valve and neutral set value, error report only No manual operation possible, check valve and replace if necessary; valve shifted mechanically out of neutral?	A43		E	1
A37331	LSB-EA 3: Proportional valve steering axle LA3 Voltage supply below 8V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37332	LSB-EA 3: Proportional valve steering axle LA3 Voltage supply above 36..45V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1
A37341	LSB-EA 3: Proportional valve steering axle LA3 Voltage supply above 45V, internal emergency shut-down Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A37342	LSB-EA 3: Proportional valve steering axle LA3 Power amplifier error solenoid valve servo-control Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A43		E	1
A37343	LSB-EA 3: Proportional valve steering axle LA3 Distance converter valve stroke faulty Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A43		E	1
A37381	LSB-EA 3: Proportional valve steering axle LA3 Slide valve can not be shifted into neutral position Internal emergency shut-down, possible valve can not switch to neutral, secondary measures possibly required Check hydraulic supply, valve; replace valve	A43		E	1
A37382	LSB-EA 3: Proportional valve steering axle LA3 Slide valve not in neutral position upon activation Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve and replace if necessary; valve shifted mechanically out of neutral?	A43		E	1
A37F34	LSB-EA 3: Signals speed recordation Travel speed Tachograph missing Safety measure is initiated Check Tachograph, CAN-Busses	A43		E	1
A37F36	LSB-EA 3: Signals speed recordation Travel speed Tachograph <> Gear output RPM not plausible Check tachograph, Gear output RPM, reports from distributor gear	A43		E	1
A37F37	LSB-EA 3: Signals speed recordation Travel speed gear output missing Safety measure is initiated Check gear output RPM, CAN-Busses	A43		E	1
A3872B	LSB-EA 3: control steering Ventil rear axle release ground switch does not open No Check wiring valve rear axle release (Y200)	A43		E	1
A3872C	LSB-EA 3: control steering Rear axle steering left / right channel 1 und 2 unequal error indication on display Note other error codes	A43		E	1
A3872D	LSB-EA 3: control steering Rear axle release float position channel 1 und 2 unequal error indication on display Note other error codes	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A3872E	LSB-EA 3: control steering Valve rear axle release plus switch and ground switch unequal error indication on display Note other error codes	A43		E	1
A3882F	LSB-EA 3: control supports Cross comparison channel 1 and channel 2 incorrect support functions are blocked Check speed signals and bus transfer on LSB-EA2, LSB-EA3 and LSB-EA4	A43		E	1
A38830	LSB-EA 3: control supports location coding for right support unit erroneous (set value = 0) support functions are blocked check line connection to E/A-Modul, check ground connection from signal, replace E/A-Modul	A43		E	1
A39403	LSB-EA 3: Control active rear axle steering Signal from angle sensor front axle faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A39404	LSB-EA 3: Control active rear axle steering Signals from channel A/B angle sensor front axle implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A3940A	LSB-EA 3: Control active rear axle steering Run time sensor values from other steering comp. too high Safety measure is initiated check cable/plugs for UB- or shorts to ground	A43		E	1
A3940B	LSB-EA 3: Control active rear axle steering Actualization of local sensor values is defective Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A43		E	1
A39410	LSB-EA 3: Control active rear axle steering Signal from angle sensor steering axle 1 faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A39411	LSB-EA 3: Control active rear axle steering Signals from channel A/B angle sensor steering axle 1 implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A39417	LSB-EA 3: Control active rear axle steering Signal from angle sensor steering axle 2 faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A39418	LSB-EA 3: Control active rear axle steering Signals from channel A/B angle sensor steering axle 2 implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A39424	LSB-EA 3: Control active rear axle steering Signal from angle sensor steering axle 3 faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A39425	LSB-EA 3: Control active rear axle steering Signals from channel A/B angle sensor steering axle 3 implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A39431	LSB-EA 3: Control active rear axle steering Signal from angle sensor steering axle 4 faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A39432	LSB-EA 3: Control active rear axle steering Signals from channel A/B angle sensor steering axle 4 implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A43		E	1
A39435	LSB-EA 3: Control active rear axle steering Steering axle 1 not corresponding with angle set value Safety measure is initiated Check hydr. rear axle steering, temperature sensor in valve possibly becomes faulty at temp. < -10°C (see special fig.)	A43		E	1
A39436	LSB-EA 3: Control active rear axle steering Steering axle 2 not corresponding with angle set value Safety measure is initiated Check hydr. rear axle steering, temperature sensor in valve possibly becomes faulty at temp. < -10°C (see special fig.)	A43		E	1
A39437	LSB-EA 3: Control active rear axle steering Steering axle 3 not corresponding with angle set value Safety measure is initiated Check hydr. rear axle steering, temperature sensor in valve possibly becomes faulty at temp. < -10°C (see special fig.)	A43		E	1
A39438	LSB-EA 3: Control active rear axle steering Steering axle 4 not corresponding with angle set value Safety measure is initiated Check hydr. rear axle steering, temperature sensor in valve possibly becomes faulty at temp. < -10°C (see special fig.)	A43		E	1
A39440	LSB-EA 3: Control active rear axle steering Pressure supply centring circuit too low with speed > 10 km/h Safety measure is initiated Measure input signals on LSB-EA, check pressure switch or hydr. supply	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A39441	LSB-EA 3: Control active rear axle steering Pressure supply centring circuit too high after ignition ON Safety measure is initiated Measure input signals on LSB-EA, check pressure switch or hydr. supply	A43		E	1
A39442	LSB-EA 3: Control active rear axle steering Signals press. switch centr. circuit both ON / short circuit to Vcc Safety measure is initiated Measure input signals on LSB-EA or check pressure switch	A43		E	1
A39443	LSB-EA 3: Control active rear axle steering Sig. press. switch centr. circle both OFF/wire break/short circ. earth Safety measure is initiated Measure input signals on LSB-EA or check pressure switch	A43		E	1
A39452	LSB-EA 3: Control active rear axle steering Checksum faulty Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A43		E	1
A39453	LSB-EA 3: Control active rear axle steering Signal flow sensor pre-tensioning centring cyl.: Oil supply too low Safety measure is initiated Check input signals on LSB-EA, flow switch or hydr. supply	A43		E	1
A39456	LSB-EA 3: Control active rear axle steering Signal flow sensor pretension centring cylinder: line break Safety measure is initiated Check input signals on LSB-EA, flow switch or hydr. supply	A43		E	1
A39459	LSB-EA 3: Control active rear axle steering Actuator values difference with opposite side too great Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A43		E	1
A39463	LSB-EA 3: Control active rear axle steering Pressure supply emergency supply centering circuit too low error report on display Check pressure supply emergency supply centering and pressure switch	A43		E	1
A39466	LSB-EA 3: Control active rear axle steering Outlet locking valve 2 trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on LSB-EA, power supply, fuse of LSB-EA	A43		E	1
A39468	LSB-EA 3: Control active rear axle steering Outlet centring valves transistor faulty or short circ. following VCC Safety measure is initiated Check outlet switching on LSB-EA, power supply, fuse of LSB-EA	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A39469	LSB-EA 3: Control active rear axle steering Outlet coasting valve transistor defective or short circuit after VCC Safety measure is initiated Check outlet switching on LSB-EA, power supply, fuse of LSB-EA	A43		E	1
A3946A	LSB-EA 3: Control active rear axle steering Outlet locking valve 1 trans. faulty or short circ. following VCC Safety measure is initiated Check outlet switching on LSB-EA, power supply, fuse of LSB-EA	A43		E	1
A39473	LSB-EA 3: Control active rear axle steering Signal engine speed diesel engine faulty/missing Check engine RPM, CAN-Busses	A43		E	1
A39475	LSB-EA 3: Control active rear axle steering Steering axle 1 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A43		E	1
A39476	LSB-EA 3: Control active rear axle steering Steering axle 2 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A43		E	1
A39477	LSB-EA 3: Control active rear axle steering Steering axle 3 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A43		E	1
A39478	LSB-EA 3: Control active rear axle steering Steering axle 4 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A43		E	1
A39485	LSB-EA 3: Control active rear axle steering Error in computer at opposite side Safety measure is initiated Read error code on other module and remedy error	A43		E	1
A39490	LSB-EA 3: Control active rear axle steering Diagnosis centring valve: steering axle 1 not centring error report on display Check whether valve is mechanically jammed	A43		E	1
A39491	LSB-EA 3: Control active rear axle steering Diagnosis centring valve: steering axle 2 not centring error report on display Check whether valve is mechanically jammed	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A39492	LSB-EA 3: Control active rear axle steering Diagnosis centring valve: steering axle 3 not centring error report on display Check whether valve is mechanically jammed	A43		E	1
A39493	LSB-EA 3: Control active rear axle steering Diagnosis freewheel valve: steering axle 4 not freewheeling error report on display Check whether valve is mechanically jammed	A43		E	1
A39494	LSB-EA 3: Control active rear axle steering Diagnosis locking valve: steering axle 1 not locking error report on display Check if valve is seized mechanically, check centering cyl.	A43		E	1
A39495	LSB-EA 3: Control active rear axle steering Diagnosis locking valve: steering axle 2 not locking error report on display Check if valve is seized mechanically, check centering cyl.	A43		E	1
A39496	LSB-EA 3: Control active rear axle steering Diagnosis locking valve: steering axle 3 not locking error report on display Check if valve is seized mechanically, check centering cyl.	A43		E	1
A39497	LSB-EA 3: Control active rear axle steering Diagnostics coasting valve: steering axle 3 without coasting error report on display Check whether valve is mechanically jammed	A43		E	1
A39498	LSB-EA 3: Control active rear axle steering Diagnostics centering valve: steering axle 4 does not center error report on display Check whether valve is mechanically jammed	A43		E	1
A39499	LSB-EA 3: Control active rear axle steering Diagnostics blocking valve: steering axle 4 does not block error report on display Check if valve is seized mechanically, check centering cyl.	A43		E	1
A3949A	LSB-EA 3: Control active rear axle steering Diagnostics free wheel valve: steering axle 1 without free wheel error report on display Check whether valve is mechanically jammed	A43		E	1
A3949B	LSB-EA 3: Control active rear axle steering Diagnostics coasting valve: steering axle 2 without coasting error report on display Check whether valve is mechanically jammed	A43		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A394A1	LSB-EA 3: Control active rear axle steering CAN-Signal steering program from LSB-EA4 erroneous/missing Check CAN-Bus connection, steering comp., steering	A43		E	1
A394A2	LSB-EA 3: Control active rear axle steering CAN-Signal steering program from oper / control unit erroneous/missing Check CAN-Bus connection, steering comp., control	A43		E	1
A394B0	LSB-EA 3: Control active rear axle steering CAN-data transfer to other steering calc.defective Check steering -CAN, control unit steering, steering valves	A43		E	1
A394B1	LSB-EA 3: Control active rear axle steering CAN-data transfer from other steering calc.defective Check steering -CAN, control unit steering, steering valves	A43		E	1
A394B2	LSB-EA 3: Control active rear axle steering CAN-data transfer steering valve 1 defective Check steering -CAN, control unit steering, steering valves	A43		E	1
A394B4	LSB-EA 3: Control active rear axle steering CAN-data transfer steering valve 3 defective Check steering -CAN, control unit steering, steering valves	A43		E	1
A3A960	LSB-EA 3: operation unlocking rear axle undefined condition: simultaneously locked and unlocked function is not carried out check unlocking condition, Check locking limit switch and unlocking limit switch	A43		B	
A3AC4A	LSB-EA 3: operation supports Function prevented at current travel speed support functions are blocked	A43		B	
A3BC28	LSB-EA 3: Operation active rear axle steering Wheel collision last mech. steered and 1st electr. steered axle error report on display Turn the steering wheel in the other direction	A43		B	
A3C02F	LSB-EA 3: Diagnostics syst. band end/adj. program Test program stop because incorrect steering program placed Test program is not started or aborted	A43		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A3C032	LSB-EA 3: Diagnostics syst. band end/adj. program Test program stop since steering actuated Test program is not started or aborted	A43		B	
A3C033	LSB-EA 3: Diagnostics syst. band end/adj. program Test program not executable since error in steering Test program is not started or aborted	A43		B	
A3C034	LSB-EA 3: Diagnostics syst. band end/adj. program Test program stop since test value outside permissible range Test program is not started or aborted	A43		B	
A3C035	LSB-EA 3: Diagnostics syst. band end/adj. program Test program not executable since sensor error is present Test program is not started or aborted	A43		B	
A3C036	LSB-EA 3: Diagnostics syst. band end/adj. program Test program stop since angle steering axle 1 outside permissible rang Test program is not started or aborted	A43		B	
A3C037	LSB-EA 3: Diagnostics syst. band end/adj. program Test program stop since angle steering axle 2 outside permissible rang Test program is not started or aborted	A43		B	
A3C038	LSB-EA 3: Diagnostics syst. band end/adj. program Test program stop since angle steering axle 3 outside permissible rang Test program is not started or aborted	A43		B	
A3C039	LSB-EA 3: Diagnostics syst. band end/adj. program Test program stop since angle steering axle 4 outside permissible rang Test program is not started or aborted	A43		B	
A3C03A	LSB-EA 3: Diagnostics syst. band end/adj. program Test program not executable since axle suspension active actuated Test program is not started or aborted	A43		B	
A3C03B	LSB-EA 3: Diagnostics syst. band end/adj. program Test program not executable since ignition off Test program is not started or aborted	A43		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A3C03E	LSB-EA 3: Diagnostics syst. band end/adj. program Function locked at blocked axle suspension Test program is not started or aborted	A43		B	
A3C041	LSB-EA 3: Diagnostics syst. band end/adj. program Test program not executable since gear not in N Test program is not started or aborted	A43		B	
A3C043	LSB-EA 3: Diagnostics syst. band end/adj. program Test program not executable at current travel speed Test program is not started or aborted	A43		B	
A3C044	LSB-EA 3: Diagnostics syst. band end/adj. program Test program not executable since motor not off Test program is not started or aborted	A43		B	
A3C045	LSB-EA 3: Diagnostics syst. band end/adj. program Test program not executable since motor not on Test program is not started or aborted	A43		B	
A3C088	LSB-EA 3: Diagnostics syst. band end/adj. program Test program angle sensor zeroing (AHL) not yet carried out error report Carry out test program until error free end	A43		E	1
A3C0C0	LSB-EA 3: Diagnostics syst. band end/adj. program Test program: Baud rate to SPI-unit erroneous error report Check Bus connection	A43		E	1
A3F08A	LSB-EA 3: System error OS-CPU0 Software test on target active error report on display Contact Service	A43		E	1
A3FAE2	LSB-EA 3: Control data transfer CAN-A LSB-EA3 reports no synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A43.X4:2/3		E	1
A3FAE3	LSB-EA 3: Control data transfer CAN-A LSB-EA4 reports no synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A43.X4:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A3FAFE	LSB-EA 3: Control data transfer CAN-A Synchronization malfunctioning CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A43.X4:2/3		E	1
A3FAFF	LSB-EA 3: Control data transfer CAN-A Time exceeded at synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A43.X4:2/3		E	1
A3FBE2	LSB-EA 3: Control data transfer CAN-B LSB-EA3 reports no synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A43.X4:4/5		E	1
A3FBE3	LSB-EA 3: Control data transfer CAN-B LSB-EA4 reports no synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A43.X4:4/5		E	1
A3FBFE	LSB-EA 3: Control data transfer CAN-B Synchronization malfunctioning CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A43.X4:4/5		E	1
A3FBFF	LSB-EA 3: Control data transfer CAN-B Time exceeded at synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A43.X4:4/5		E	1
A47211	LSB-EA 4: Proportional valve steering axle LA2 CAN-communication with E/A-module faulty/lacking (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A44		E	1
A47212	LSB-EA 4: Proportional valve steering axle LA2 CAN-communication with E/A-module faulty/lacking (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A44		E	1
A47213	LSB-EA 4: Proportional valve steering axle LA2 CAN-communication with E/A-module implausible (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A44		E	1
A47214	LSB-EA 4: Proportional valve steering axle LA2 CAN-communication with E/A-module implausible (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A47215	LSB-EA 4: Proportional valve steering axle LA2 Voltage supply/PWM-control faulty Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47216	LSB-EA 4: Proportional valve steering axle LA2 Internal error, EEPROM-memory inconsistent Valve is not controlled (neutral position), secondary measures possibly required Check valve configuration, replace valve	A44		E	1
A47217	LSB-EA 4: Proportional valve steering axle LA2 Reference value valve not neutral due to continuous error Valve is not controlled (neutral position), secondary measures possibly required Remedy fault, activate/deactivate ignition	A44		E	1
A47221	LSB-EA 4: Proportional valve steering axle LA2 Voltage supply below permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47222	LSB-EA 4: Proportional valve steering axle LA2 Voltage supply above permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47223	LSB-EA 4: Proportional valve steering axle LA2 Slide deflected too short; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve; replace valve; errors may be resulted from engine stalling	A44		E	1
A47224	LSB-EA 4: Proportional valve steering axle LA2 Slide deflected too far; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A44		E	1
A47225	LSB-EA 4: Proportional valve steering axle LA2 Valve float position not reached Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A44		E	1
A47226	LSB-EA 4: Proportional valve steering axle LA2 Manual actuation With fault-free valve and neutral set value, error report only No manual operation possible, check valve and replace if necessary; valve shifted mechanically out of neutral?	A44		E	1
A47231	LSB-EA 4: Proportional valve steering axle LA2 Voltage supply below 8V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A47232	LSB-EA 4: Proportional valve steering axle LA2 Voltage supply above 36..45V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47241	LSB-EA 4: Proportional valve steering axle LA2 Voltage supply above 45V, internal emergency shut-down Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47242	LSB-EA 4: Proportional valve steering axle LA2 Power amplifier error solenoid valve servo-control Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A44		E	1
A47243	LSB-EA 4: Proportional valve steering axle LA2 Distance converter valve stroke faulty Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A44		E	1
A47281	LSB-EA 4: Proportional valve steering axle LA2 Slide valve can not be shifted into neutral position Internal emergency shut-down, possible valve can not switch to neutral, secondary measures possibly required Check hydraulic supply, valve; replace valve	A44		E	1
A47282	LSB-EA 4: Proportional valve steering axle LA2 Slide valve not in neutral position upon activation Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve and replace if necessary; valve shifted mechanically out of neutral?	A44		E	1
A47411	LSB-EA 4: Proportional valve steering axle LA4 CAN-communication with E/A-module faulty/lacking (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A44		E	1
A47412	LSB-EA 4: Proportional valve steering axle LA4 CAN-communication with E/A-module faulty/lacking (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A44		E	1
A47413	LSB-EA 4: Proportional valve steering axle LA4 CAN-communication with E/A-module implausible (set value signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A44		E	1
A47414	LSB-EA 4: Proportional valve steering axle LA4 CAN-communication with E/A-module implausible (config.-signal) Valve is not controlled (neutral position), secondary measures possibly required Check CAN-network, valve, E/A-module	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A47415	LSB-EA 4: Proportional valve steering axle LA4 Voltage supply/PWM-control faulty Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47416	LSB-EA 4: Proportional valve steering axle LA4 Internal error, EEPROM-memory inconsistent Valve is not controlled (neutral position), secondary measures possibly required Check valve configuration, replace valve	A44		E	1
A47417	LSB-EA 4: Proportional valve steering axle LA4 Reference value valve not neutral due to continuous error Valve is not controlled (neutral position), secondary measures possibly required Remedy fault, activate/deactivate ignition	A44		E	1
A47421	LSB-EA 4: Proportional valve steering axle LA4 Voltage supply below permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47422	LSB-EA 4: Proportional valve steering axle LA4 Voltage supply above permissible range Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47423	LSB-EA 4: Proportional valve steering axle LA4 Slide deflected too short; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve; replace valve; errors may be resulted from engine stalling	A44		E	1
A47424	LSB-EA 4: Proportional valve steering axle LA4 Slide deflected too far; jammed or control pressure too low Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A44		E	1
A47425	LSB-EA 4: Proportional valve steering axle LA4 Valve float position not reached Valve is not controlled (neutral position), secondary measures possibly required Check hydraulic supply, valve; replace valve	A44		E	1
A47426	LSB-EA 4: Proportional valve steering axle LA4 Manual actuation With fault-free valve and neutral set value, error report only No manual operation possible, check valve and replace if necessary; valve shifted mechanically out of neutral?	A44		E	1
A47431	LSB-EA 4: Proportional valve steering axle LA4 Voltage supply below 8V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A47432	LSB-EA 4: Proportional valve steering axle LA4 Voltage supply above 36..45V, power amplifier switched off Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47441	LSB-EA 4: Proportional valve steering axle LA4 Voltage supply above 45V, internal emergency shut-down Valve is not controlled (neutral position), secondary measures possibly required Check on-board supply, replace valve	A44		E	1
A47442	LSB-EA 4: Proportional valve steering axle LA4 Power amplifier error solenoid valve servo-control Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A44		E	1
A47443	LSB-EA 4: Proportional valve steering axle LA4 Distance converter valve stroke faulty Valve is not controlled (neutral position), secondary measures possibly required Replace valve	A44		E	1
A47481	LSB-EA 4: Proportional valve steering axle LA4 Slide valve can not be shifted into neutral position Internal emergency shut-down, possible valve can not switch to neutral, secondary measures possibly required Check hydraulic supply, valve; replace valve	A44		E	1
A47482	LSB-EA 4: Proportional valve steering axle LA4 Slide valve not in neutral position upon activation Valve is not controlled (neutral position), secondary measures possibly required Hydraulic supply, check valve and replace if necessary; valve shifted mechanically out of neutral?	A44		E	1
A47F34	LSB-EA 4: Signals speed recordation Travel speed Tachograph missing Safety measure is initiated Check Tachograph, CAN-Busses	A44		E	1
A47F36	LSB-EA 4: Signals speed recordation Travel speed Tachograph <> Gear output RPM not plausible Check tachograph, Gear output RPM, reports from distributor gear	A44		E	1
A47F37	LSB-EA 4: Signals speed recordation Travel speed gear output missing Safety measure is initiated Check gear output RPM, CAN-Busses	A44		E	1
A4872A	LSB-EA 4: control steering Valve rear axle release Plus switch does not open No Check wiring valve rear axle release (Y200)	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A4872C	LSB-EA 4: control steering Rear axle steering left / right channel 1 und 2 unequal error indication on display Note other error codes	A44		E	1
A4872D	LSB-EA 4: control steering Rear axle release float position channel 1 und 2 unequal error indication on display Note other error codes	A44		E	1
A4882F	LSB-EA 4: control supports Cross comparison channel 1 and channel 2 incorrect support functions are blocked Check speed signals and bus transfer on LSB-EA2, LSB-EA3 and LSB-EA4	A44		E	1
A48831	LSB-EA 4: control supports location coding for left support unit erroneous (set value = 1) support functions are blocked check line connection to E/A-Modul, check power supply from signal, replace E/A-Modul	A44		E	1
A49403	LSB-EA 4: Control active rear axle steering Signal from angle sensor front axle faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A49404	LSB-EA 4: Control active rear axle steering Signals from channel A/B angle sensor front axle implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A4940A	LSB-EA 4: Control active rear axle steering Run time sensor values from other steering comp. too high Safety measure is initiated check cable/plugs for UB- or shorts to ground	A44		E	1
A4940B	LSB-EA 4: Control active rear axle steering Actualization of local sensor values is defective Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A44		E	1
A49410	LSB-EA 4: Control active rear axle steering Signal from angle sensor steering axle 1 faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A49411	LSB-EA 4: Control active rear axle steering Signals from channel A/B angle sensor steering axle 1 implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A49417	LSB-EA 4: Control active rear axle steering Signal from angle sensor steering axle 2 faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A49418	LSB-EA 4: Control active rear axle steering Signals from channel A/B angle sensor steering axle 2 implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A49424	LSB-EA 4: Control active rear axle steering Signal from angle sensor steering axle 3 faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A49425	LSB-EA 4: Control active rear axle steering Signals from channel A/B angle sensor steering axle 3 implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A49431	LSB-EA 4: Control active rear axle steering Signal from angle sensor steering axle 4 faulty, tolerance too great Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A49432	LSB-EA 4: Control active rear axle steering Signals from channel A/B angle sensor steering axle 4 implausible Safety measure is initiated Check wiring to angle sensor, check power supply angle sensor	A44		E	1
A49435	LSB-EA 4: Control active rear axle steering Steering axle 1 not corresponding with angle set value Safety measure is initiated Check hydr. rear axle steering, temperature sensor in valve possibly becomes faulty at temp. < -10°C (see special fig.)	A44		E	1
A49436	LSB-EA 4: Control active rear axle steering Steering axle 2 not corresponding with angle set value Safety measure is initiated Check hydr. rear axle steering, temperature sensor in valve possibly becomes faulty at temp. < -10°C (see special fig.)	A44		E	1
A49437	LSB-EA 4: Control active rear axle steering Steering axle 3 not corresponding with angle set value Safety measure is initiated Check hydr. rear axle steering, temperature sensor in valve possibly becomes faulty at temp. < -10°C (see special fig.)	A44		E	1
A49438	LSB-EA 4: Control active rear axle steering Steering axle 4 not corresponding with angle set value Safety measure is initiated Check hydr. rear axle steering, temperature sensor in valve possibly becomes faulty at temp. < -10°C (see special fig.)	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A49440	LSB-EA 4: Control active rear axle steering Pressure supply centring circuit too low with speed > 10 km/h Safety measure is initiated Measure input signals on LSB-EA, check pressure switch or hydr. supply	A44		E	1
A49441	LSB-EA 4: Control active rear axle steering Pressure supply centring circuit too high after ignition ON Safety measure is initiated Measure input signals on LSB-EA, check pressure switch or hydr. supply	A44		E	1
A49442	LSB-EA 4: Control active rear axle steering Signals press. switch centr. circuit both ON / short circuit to Vcc Safety measure is initiated Measure input signals on LSB-EA or check pressure switch	A44		E	1
A49443	LSB-EA 4: Control active rear axle steering Sig. press. switch centr. circle both OFF/wire break/short circ. earth Safety measure is initiated Measure input signals on LSB-EA or check pressure switch	A44		E	1
A49445	LSB-EA 4: Control active rear axle steering Signal flow sensor steering pump: Oil supply too low Check steering pump, sensor	A44		E	1
A49446	LSB-EA 4: Control active rear axle steering Signal flow sensor steering pump: Sensor faulty/missing Check sensor, wiring	A44		E	1
A49449	LSB-EA 4: Control active rear axle steering Signal flow sensor auxiliary steering pump: Oil supply too low Check steering pump, sensor	A44		E	1
A49450	LSB-EA 4: Control active rear axle steering Signal flow sensor auxiliary steering pump: Sensor faulty/missing Check sensor, wiring	A44		E	1
A49452	LSB-EA 4: Control active rear axle steering Checksum faulty Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A44		E	1
A49459	LSB-EA 4: Control active rear axle steering Actuator values difference with opposite side too great Safety measure is initiated note error report, ignition ON/OFF, with repeated occurrence --> inform after-sales service	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A49462	LSB-EA 4: Control active rear axle steering Outlet centring valves trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on LSB-EA, power supply, fuse of LSB-EA	A44		E	1
A49464	LSB-EA 4: Control active rear axle steering Outlet locking valve 1 trans. faulty or short circ. following earth Safety measure is initiated Check outlet switching on LSB-EA, power supply, fuse of LSB-EA	A44		E	1
A49465	LSB-EA 4: Control active rear axle steering Output free-wheeling rectifier trans. faulty or short circuit to earth Safety measure is initiated Check outlet switching on LSB-EA, power supply, fuse of LSB-EA	A44		E	1
A4946B	LSB-EA 4: Control active rear axle steering Outlet locking valve 2 trans. faulty or short circ. following VCC Safety measure is initiated Check outlet switching on LSB-EA, power supply, fuse of LSB-EA	A44		E	1
A49473	LSB-EA 4: Control active rear axle steering Signal engine speed diesel engine faulty/missing Check engine RPM, CAN-Busses	A44		E	1
A49475	LSB-EA 4: Control active rear axle steering Steering axle 1 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A44		E	1
A49476	LSB-EA 4: Control active rear axle steering Steering axle 2 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A44		E	1
A49477	LSB-EA 4: Control active rear axle steering Steering axle 3 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A44		E	1
A49478	LSB-EA 4: Control active rear axle steering Steering axle 4 not corresponding with angle set value Safety measure is initiated Note other error codes, check hydraulic rear axle steering	A44		E	1
A49485	LSB-EA 4: Control active rear axle steering Error in computer at opposite side Safety measure is initiated Read error code on other module and remedy error	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A49490	LSB-EA 4: Control active rear axle steering Diagnosis centring valve: steering axle 1 not centring error report on display Check whether valve is mechanically jammed	A44		E	1
A49491	LSB-EA 4: Control active rear axle steering Diagnosis centring valve: steering axle 2 not centring error report on display Check whether valve is mechanically jammed	A44		E	1
A49492	LSB-EA 4: Control active rear axle steering Diagnosis centring valve: steering axle 3 not centring error report on display Check whether valve is mechanically jammed	A44		E	1
A49493	LSB-EA 4: Control active rear axle steering Diagnosis freewheel valve: steering axle 4 not freewheeling error report on display Check whether valve is mechanically jammed	A44		E	1
A49494	LSB-EA 4: Control active rear axle steering Diagnosis locking valve: steering axle 1 not locking error report on display Check if valve is seized mechanically, check centering cyl.	A44		E	1
A49495	LSB-EA 4: Control active rear axle steering Diagnosis locking valve: steering axle 2 not locking error report on display Check if valve is seized mechanically, check centering cyl.	A44		E	1
A49496	LSB-EA 4: Control active rear axle steering Diagnosis locking valve: steering axle 3 not locking error report on display Check if valve is seized mechanically, check centering cyl.	A44		E	1
A49497	LSB-EA 4: Control active rear axle steering Diagnostics coasting valve: steering axle 3 without coasting error report on display Check whether valve is mechanically jammed	A44		E	1
A49498	LSB-EA 4: Control active rear axle steering Diagnostics centering valve: steering axle 4 does not center error report on display Check whether valve is mechanically jammed	A44		E	1
A49499	LSB-EA 4: Control active rear axle steering Diagnostics blocking valve: steering axle 4 does not block error report on display Check if valve is seized mechanically, check centering cyl.	A44		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A4949A	LSB-EA 4: Control active rear axle steering Diagnostics free wheel valve: steering axle 1 without free wheel error report on display Check whether valve is mechanically jammed	A44		E	1
A4949B	LSB-EA 4: Control active rear axle steering Diagnostics coasting valve: steering axle 2 without coasting error report on display Check whether valve is mechanically jammed	A44		E	1
A494A0	LSB-EA 4: Control active rear axle steering CAN-Signal steering program from LSB-EA3 erroneous/missing Check CAN-Bus connection, steering comp., steering	A44		E	1
A494A2	LSB-EA 4: Control active rear axle steering CAN-Signal steering program from oper / control unit erroneous/missing Check CAN-Bus connection, steering comp., control	A44		E	1
A494B0	LSB-EA 4: Control active rear axle steering CAN-data transfer to other steering calc.defective Check steering -CAN, control unit steering, steering valves	A44		E	1
A494B1	LSB-EA 4: Control active rear axle steering CAN-data transfer from other steering calc.defective Check steering -CAN, control unit steering, steering valves	A44		E	1
A494B3	LSB-EA 4: Control active rear axle steering CAN-data transfer steering valve 2 defective Check steering -CAN, control unit steering, steering valves	A44		E	1
A494B5	LSB-EA 4: Control active rear axle steering CAN-data transfer steering valve 4 defective Check steering -CAN, control unit steering, steering valves	A44		E	1
A4AC4A	LSB-EA 4: operation supports Function prevented at current travel speed support functions are blocked	A44		B	
A4BC28	LSB-EA 4: Operation active rear axle steering Wheel collision last mech. steered and 1st electr. steered axle error report on display Turn the steering wheel in the other direction	A44		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A4C02F	LSB-EA 4: Diagnostics syst. band end/adj. program Test program stop because incorrect steering program placed Test program is not started or aborted	A44		B	
A4C034	LSB-EA 4: Diagnostics syst. band end/adj. program Test program stop since test value outside permissible range Test program is not started or aborted	A44		B	
A4C035	LSB-EA 4: Diagnostics syst. band end/adj. program Test program not executable since sensor error is present Test program is not started or aborted	A44		B	
A4C036	LSB-EA 4: Diagnostics syst. band end/adj. program Test program stop since angle steering axle 1 outside permissible rang Test program is not started or aborted	A44		B	
A4C037	LSB-EA 4: Diagnostics syst. band end/adj. program Test program stop since angle steering axle 2 outside permissible rang Test program is not started or aborted	A44		B	
A4C038	LSB-EA 4: Diagnostics syst. band end/adj. program Test program stop since angle steering axle 3 outside permissible rang Test program is not started or aborted	A44		B	
A4C039	LSB-EA 4: Diagnostics syst. band end/adj. program Test program stop since angle steering axle 4 outside permissible rang Test program is not started or aborted	A44		B	
A4C03A	LSB-EA 4: Diagnostics syst. band end/adj. program Test program not executable since axle suspension active actuated Test program is not started or aborted	A44		B	
A4C03B	LSB-EA 4: Diagnostics syst. band end/adj. program Test program not executable since ignition off Test program is not started or aborted	A44		B	
A4C03E	LSB-EA 4: Diagnostics syst. band end/adj. program Function locked at blocked axle suspension Test program is not started or aborted	A44		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A4C041	LSB-EA 4: Diagnostics syst. band end/adj. program Test program not executable since gear not in N Test program is not started or aborted	A44		B	
A4C043	LSB-EA 4: Diagnostics syst. band end/adj. program Test program not executable at current travel speed Test program is not started or aborted	A44		B	
A4C044	LSB-EA 4: Diagnostics syst. band end/adj. program Test program not executable since motor not off Test program is not started or aborted	A44		B	
A4C045	LSB-EA 4: Diagnostics syst. band end/adj. program Test program not executable since motor not on Test program is not started or aborted	A44		B	
A4C088	LSB-EA 4: Diagnostics syst. band end/adj. program Test program angle sensor zeroing (AHL) not yet carried out error report Carry out test program until error free end	A44		E	1
A4C0C0	LSB-EA 4: Diagnostics syst. band end/adj. program Test program: Baud rate to SPI-unit erroneous error report Check Bus connection	A44		E	1
A4F08A	LSB-EA 4: System error OS-CPU0 Software test on target active error report on display Contact Service	A44		E	1
A4FAE2	LSB-EA 4: Control data transfer CAN-A LSB-EA3 reports no synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A44.X4:2/3		E	1
A4FAE3	LSB-EA 4: Control data transfer CAN-A LSB-EA4 reports no synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A44.X4:2/3		E	1
A4FAFE	LSB-EA 4: Control data transfer CAN-A Synchronization malfunctioning CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A44.X4:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
A4FAFF	LSB-EA 4: Control data transfer CAN-A Time exceeded at synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A44.X4:2/3		E	1
A4FBE2	LSB-EA 4: Control data transfer CAN-B LSB-EA3 reports no synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A44.X4:4/5		E	1
A4FBE3	LSB-EA 4: Control data transfer CAN-B LSB-EA4 reports no synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A44.X4:4/5		E	1
A4FBFE	LSB-EA 4: Control data transfer CAN-B Synchronization malfunctioning CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A44.X4:4/5		E	1
A4FBFF	LSB-EA 4: Control data transfer CAN-B Time exceeded at synchronization CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A44.X4:4/5		E	1
B1016A	LSB-TE1: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1016C	LSB-TE1: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1026A	LSB-TE1: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1026C	LSB-TE1: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1046A	LSB-TE1: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1046C	LSB-TE1: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1056A	LSB-TE1: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1056C	LSB-TE1: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1066A	LSB-TE1: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1066C	LSB-TE1: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1076A	LSB-TE1: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1076C	LSB-TE1: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1086A	LSB-TE1: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1086C	LSB-TE1: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1096A	LSB-TE1: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1096C	LSB-TE1: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B10A6A	LSB-TE1: LSBA Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B10A6C	LSB-TE1: LSBA Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B10B6A	LSB-TE1: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B10B6C	LSB-TE1: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B10C6A	LSB-TE1: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B10C6C	LSB-TE1: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B10D6A	LSB-TE1: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B10D6C	LSB-TE1: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B10E6A	LSB-TE1: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B10E6C	LSB-TE1: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B10F6A	LSB-TE1: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B10F6C	LSB-TE1: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1106A	LSB-TE1: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1106C	LSB-TE1: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1116A	LSB-TE1: LSBA Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1116C	LSB-TE1: LSBA Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1126A	LSB-TE1: LSBA Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1126C	LSB-TE1: LSBA Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1136A	LSB-TE1: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1136C	LSB-TE1: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1146A	LSB-TE1: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1146C	LSB-TE1: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1156A	LSB-TE1: LSBA Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1156C	LSB-TE1: LSBA Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1166A	LSB-TE1: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1166C	LSB-TE1: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1176A	LSB-TE1: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1176C	LSB-TE1: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1186A	LSB-TE1: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1186C	LSB-TE1: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1196A	LSB-TE1: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B1196C	LSB-TE1: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B11A6A	LSB-TE1: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B11A6C	LSB-TE1: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B11B6A	LSB-TE1: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B11B6C	LSB-TE1: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B11C6A	LSB-TE1: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B11C6C	LSB-TE1: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B11D6A	LSB-TE1: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B11D6C	LSB-TE1: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B11E6A	LSB-TE1: LSBA Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A81.X3:8		E	2
B11E6C	LSB-TE1: LSBA Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A81.X3:8		E	2
B1205B	LSB-TE1: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A81.X3:8		E	2
B1381C	LSB-TE1: control slewing Interruption bus connection(s)Actuation / release, zero force Shut off of all turning movements Check LSB and CAN Bus, Master switch in zero position	A81		E	1
B13BA4	LSB-TE1: Control ballasting / counterweight carriage Limit switch Ballast bottom short circuit against Supply voltage Check sensor, wiring, input contro unit	A81		E	1
B13BA5	LSB-TE1: Control ballasting / counterweight carriage Limit switch Ballast top short circuit against Supply voltage Check sensor, wiring, input contro unit	A81		E	1
B13BA6	LSB-TE1: Control ballasting / counterweight carriage Signals from limit switches Ballast postion implausible/contact stuck Check sensor, wiring, input contro unit	A81		E	1
B15A9A	LSB-TE1: operation additional equipment Change over prevented, incorrect or missing equipment config.	A81		B	
B162A0	LSB-TE1: operation instruments crane operators cab Funktion blocked: button actuation without release Issue of error prevention of activation of aux. user	A81		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B164AA	LSB-TE1: operation instruments armrest right Change over master switch mode prevented, MS not in zero	A81		B	
B164AB	LSB-TE1: operation instruments armrest right Change over master switch mode prevented, MS not in zero	A81		B	
B164AC	LSB-TE1: operation instruments armrest right Hydraulic oil preheating on prevented, MS1 or MS2 not in zero	A81		B	
B164AD	LSB-TE1: operation instruments armrest right Change over master switch mode prevented, MS3 not in zero	A81		B	
B164AE	LSB-TE1: operation instruments armrest right Change over master switch mode prevented, ass. winch active	A81		B	
B17007	LSB-TE1: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A81		B	
B17019	LSB-TE1: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A81		E	
B17090	LSB-TE1: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A81		E	
B1807A	LSB-TE1: control engine Diesel tank sensor short circuit after Vcc or sensor excess voltage Entry in error stack Check wiring and sensor	A81		E	1
B1807B	LSB-TE1: control engine Diesel tank sensor short circuit after ground or sensor undervoltage Entry in error stack Check wiring and sensor	A81		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B18AA0	LSB-TE1: control hydraulic/second. power outputs Temperature sensor Hydraulic oil erroneous/missing	A81		E	
B19900	LSB-TE1: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A81.X3:3/4/6/7		E	2
B19901	LSB-TE1: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A81.X3:3/4/6/7		E	2
B19902	LSB-TE1: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A81.X3:3/4/6/7		E	1
B19904	LSB-TE1: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A81.X3:3/4/6/7		E	1
B19905	LSB-TE1: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A81.X3:3/4/6/7		E	1
B19906	LSB-TE1: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A81.X3:3/4/6/7		E	2
B19907	LSB-TE1: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A81.X3:3/4/6/7		E	1
B19911	LSB-TE1: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4/6/7		E	2
B19F99	LSB-TE1: operation transmission Travel direction button D/R continuous actuation Placing gear prevented, after timeout, Neutral is given Inadvertent actuation?Check control unit, Touch-Display	A81		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1B44B	LSB-TE1: Control length / cross lock prevented, switch sequence incorrect	A81		B	
B1D004	LSB-TE1: Analog input E0 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:20		E	1
B1D005	LSB-TE1: Analog input E0 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:20		E	1
B1D104	LSB-TE1: Analog input E1 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:21		E	1
B1D105	LSB-TE1: Analog input E1 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:21		E	1
B1D204	LSB-TE1: Analog input E2 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:22		E	1
B1D205	LSB-TE1: Analog input E2 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:22		E	1
B1D304	LSB-TE1: Analog input E3 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:23		E	1
B1D305	LSB-TE1: Analog input E3 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:23		E	1
B1D404	LSB-TE1: Analog input E4 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:24		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1D405	LSB-TE1: Analog input E4 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:24		E	1
B1D504	LSB-TE1: Analog input E5 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:25		E	1
B1D505	LSB-TE1: Analog input E5 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A81.X1:25		E	1
B1DC54	LSB-TE1: Switching output A0 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:18		E	1
B1DC55	LSB-TE1: Switching output A0 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:18		E	1
B1DD54	LSB-TE1: Switching output A1 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:17		E	1
B1DD55	LSB-TE1: Switching output A1 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:17		E	1
B1DE54	LSB-TE1: Switching output A2 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:16		E	1
B1DE55	LSB-TE1: Switching output A2 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:16		E	1
B1DF54	LSB-TE1: Switching output A3 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1DF55	LSB-TE1: Switching output A3 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:15		E	1
B1E054	LSB-TE1: Switching output A4 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:3		E	1
B1E055	LSB-TE1: Switching output A4 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:3		E	1
B1E154	LSB-TE1: Switching output A5 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:4		E	1
B1E155	LSB-TE1: Switching output A5 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:4		E	1
B1E254	LSB-TE1: Switching output A6 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:5		E	1
B1E255	LSB-TE1: Switching output A6 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:5		E	1
B1E354	LSB-TE1: Switching output A7 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:6		E	1
B1E355	LSB-TE1: Switching output A7 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:6		E	1
B1E454	LSB-TE1: Switching output A8 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1E455	LSB-TE1: Switching output A8 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:7		E	1
B1E554	LSB-TE1: Switching output A9 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:8		E	1
B1E555	LSB-TE1: Switching output A9 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:8		E	1
B1E650	LSB-TE1: Switching output A10 short circuit to ground, junction not supplied Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:14		E	1
B1E654	LSB-TE1: Switching output A10 short circuit to supply voltage Entry in error stack, set error status bit in EW4 Check initial switching, replace module, if necessary	A81.X1:14		E	2
B1E655	LSB-TE1: Switching output A10 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check outlet switching	A81.X1:14		E	1
B1E65A	LSB-TE1: Switching output A10 Ground switching transistor defective Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:14		E	1
B1E750	LSB-TE1: Switching output A11 short circuit to ground, junction not supplied Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:1		E	1
B1E754	LSB-TE1: Switching output A11 short circuit to supply voltage Entry in error stack, set error status bit in EW4 Check initial switching, replace module, if necessary	A81.X1:1		E	2
B1E755	LSB-TE1: Switching output A11 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check outlet switching	A81.X1:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1E75A	LSB-TE1: Switching output A11 Ground switching transistor defective Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A81.X1:1		E	1
B1F001	LSB-TE1: System error OS-CPU initialising error processor-register erroneous Module reset Replace module	A81		E	2
B1F006	LSB-TE1: System error OS-CPU initialising error RAM erroneous Module reset Replace module	A81		E	2
B1F013	LSB-TE1: System error OS-CPU Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A81		E	2
B1F016	LSB-TE1: System error OS-CPU system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A81		E	2
B1F050	LSB-TE1: System error OS-CPU file not available error report Reload application software	A81		E	2
B1F068	LSB-TE1: System error OS-CPU impermissible interrupt Module reset Replace module	A81		E	2
B1F070	LSB-TE1: System error OS-CPU various structure versions error indication on display Inform Service of all error parameters and replace module	A81		E	2
B1F071	LSB-TE1: System error OS-CPU Structure file missing or faulty error indication on display Replace module	A81		E	2
B1F073	LSB-TE1: System error OS-CPU interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A81		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1F075	LSB-TE1: System error OS-CPU SPI-error error indication on display Inform Service of all error parameters and replace module	A81		E	2
B1F078	LSB-TE1: System error OS-CPU impermissible parameter Module reset Report all error parameters to Service	A81		E	1
B1F080	LSB-TE1: System error OS-CPU Fatal internal error Module reset Inform Service of all error parameters and replace module	A81		E	2
B1F082	LSB-TE1: System error OS-CPU hardware-watchdog erroneous Module reset Replace module	A81		E	2
B1F088	LSB-TE1: System error OS-CPU Configuration does not match software condition error indication on display Load correct software onto module	A81		E	2
B1F089	LSB-TE1: System error OS-CPU Incorrect version of firmware installed Entry in error stack Replace module	A81		E	2
B1F090	LSB-TE1: System error OS-CPU Incorrect hardware version recognised Entry in error stack Replace module	A81		E	2
B1F0A3	LSB-TE1: System error OS-CPU Board temp. outside permissible range error indication on display Cool off module, if error continues, replace module	A81		E	2
B1F0C1	LSB-TE1: System error OS-CPU Incorrect or wrong system version for application error report Reload matching system version	A81		E	1
B1FA00	LSB-TE1: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A81.X3:6/7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1FA01	LSB-TE1: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A81.X3:6/7		E	1
B1FA02	LSB-TE1: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A81.X3:6/7		E	1
B1FA04	LSB-TE1: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A81.X3:6/7		E	1
B1FA05	LSB-TE1: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A81.X3:6/7		E	1
B1FA06	LSB-TE1: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A81.X3:6/7		E	2
B1FA11	LSB-TE1: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1
B1FA32	LSB-TE1: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A81.X3:6/7		E	1
B1FA40	LSB-TE1: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A81.X3:6/7		E	1
B1FA41	LSB-TE1: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A81.X3:6/7		E	1
B1FA5F	LSB-TE1: Control data transfer CAN-A Malfunction, all participants missing Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1FA60	LSB-TE1: Control data transfer CAN-A Motor erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1
B1FA80	LSB-TE1: Control data transfer CAN-A LSB-UEA1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1
B1FA90	LSB-TE1: Control data transfer CAN-A LSB-TE1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1
B1FA91	LSB-TE1: Control data transfer CAN-A LSB-TE2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1
B1FA92	LSB-TE1: Control data transfer CAN-A LSB-TE3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1
B1FAAB	LSB-TE1: Control data transfer CAN-A LSB-BTB2 erroneous error report Check CAN-Network, control units	A81.X3:6/7		E	1
B1FAB0	LSB-TE1: Control data transfer CAN-A LSB-AMS1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1
B1FAB1	LSB-TE1: Control data transfer CAN-A LSB-AMS2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:6/7		E	1
B1FB00	LSB-TE1: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A81.X3:3/4		E	1
B1FB01	LSB-TE1: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A81.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1FB02	LSB-TE1: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A81.X3:3/4		E	1
B1FB04	LSB-TE1: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A81.X3:3/4		E	1
B1FB05	LSB-TE1: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A81.X3:3/4		E	1
B1FB06	LSB-TE1: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A81.X3:3/4		E	2
B1FB11	LSB-TE1: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1
B1FB32	LSB-TE1: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A81.X3:3/4		E	1
B1FB40	LSB-TE1: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A81.X3:3/4		E	1
B1FB41	LSB-TE1: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A81.X3:3/4		E	1
B1FB5F	LSB-TE1: Control data transfer CAN-B Malfunction, all participants missing Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1
B1FB60	LSB-TE1: Control data transfer CAN-B Motor erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B1FB80	LSB-TE1: Control data transfer CAN-B LSB-UEA1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1
B1FB90	LSB-TE1: Control data transfer CAN-B LSB-TE1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1
B1FB91	LSB-TE1: Control data transfer CAN-B LSB-TE2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1
B1FB92	LSB-TE1: Control data transfer CAN-B LSB-TE3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1
B1FBAB	LSB-TE1: Control data transfer CAN-B LSB-BTB2 erroneous error report Check CAN-Network, control units	A81.X3:3/4		E	1
B1FBB0	LSB-TE1: Control data transfer CAN-B LSB-AMS1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1
B1FBB1	LSB-TE1: Control data transfer CAN-B LSB-AMS2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A81.X3:3/4		E	1
B2016A	LSB-TE2: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2016C	LSB-TE2: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2026A	LSB-TE2: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2026C	LSB-TE2: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2046A	LSB-TE2: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2046C	LSB-TE2: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2056A	LSB-TE2: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2056C	LSB-TE2: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2066A	LSB-TE2: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2066C	LSB-TE2: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2076A	LSB-TE2: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2076C	LSB-TE2: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2086A	LSB-TE2: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2086C	LSB-TE2: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2096A	LSB-TE2: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2096C	LSB-TE2: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B20A6A	LSB-TE2: LSBA Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B20A6C	LSB-TE2: LSBA Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B20B6A	LSB-TE2: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B20B6C	LSB-TE2: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B20C6A	LSB-TE2: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B20C6C	LSB-TE2: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B20D6A	LSB-TE2: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B20D6C	LSB-TE2: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B20E6A	LSB-TE2: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B20E6C	LSB-TE2: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B20F6A	LSB-TE2: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B20F6C	LSB-TE2: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2106A	LSB-TE2: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2106C	LSB-TE2: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2116A	LSB-TE2: LSBA Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2116C	LSB-TE2: LSBA Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2126A	LSB-TE2: LSBA Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2126C	LSB-TE2: LSBA Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2136A	LSB-TE2: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2136C	LSB-TE2: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2146A	LSB-TE2: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2146C	LSB-TE2: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2156A	LSB-TE2: LSBA Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2156C	LSB-TE2: LSBA Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2166A	LSB-TE2: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2166C	LSB-TE2: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2176A	LSB-TE2: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2176C	LSB-TE2: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2186A	LSB-TE2: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2186C	LSB-TE2: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2196A	LSB-TE2: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B2196C	LSB-TE2: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B21A6A	LSB-TE2: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B21A6C	LSB-TE2: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B21B6A	LSB-TE2: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B21B6C	LSB-TE2: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B21C6A	LSB-TE2: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B21C6C	LSB-TE2: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B21D6A	LSB-TE2: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B21D6C	LSB-TE2: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B21E6A	LSB-TE2: LSBA Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A82.X3:8		E	2
B21E6C	LSB-TE2: LSBA Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A82.X3:8		E	2
B2205B	LSB-TE2: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A82.X3:8		E	2
B262A0	LSB-TE2: operation instruments crane operators cab Funktion blocked: button actuation without release Issue of error prevention of activation of aux. user	A82		B	
B265A9	LSB-TE2: operation instruments armrest left Changeover Master switch mode prevented, PG not in zero Output of error, otherwise no reaction. Bring master switch in zero position	A82		B	
B265AA	LSB-TE2: operation instruments armrest left Change over master switch mode prevented, MS not in zero Output of error, otherwise no reaction. Bring master switch in zero position	A82		B	
B265AB	LSB-TE2: operation instruments armrest left Change over master switch mode prevented, MS not in zero Output of error, otherwise no reaction. Bring master switch in zero position	A82		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B265AC	LSB-TE2: operation instruments armrest left Hydraulic oil preheating on prevented, MS1 or MS2 not in zero Output of error, otherwise no reaction. Bring master switch in zero position	A82		B	
B265AD	LSB-TE2: operation instruments armrest left Change over master switch mode prevented, MS3 not in zero Output of error, otherwise no reaction. Bring master switch in zero position	A82		B	
B265AF	LSB-TE2: operation instruments armrest left Hydr. oil preheating on prevented, not all MS in zero Output of error, otherwise no reaction. Bring master switch in zero position	A82		B	
B280FA	LSB-TE2: control engine Configuration Engine type missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A82		E	1
B280FB	LSB-TE2: control engine Configuration Exhaust stage missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A82		E	1
B280FC	LSB-TE2: control engine Configuration Engine type implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A82		E	1
B280FD	LSB-TE2: control engine Configuration Exhaust stage implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A82		E	1
B28FA0	LSB-TE2: control heating/air conditioning Set air circ./ no fresh air ground/back measure short circuit VCC	A82		E	1
B28FA1	LSB-TE2: control heating/air conditioning Set air circ. / no fresh air VCC / back measure short circuit ground	A82		E	1
B28FA2	LSB-TE2: control heating/air conditioning Set air circ. / fresh air flap blocked	A82		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B28FA3	LSB-TE2: control heating/air conditioning Set air circ. / fresh air left interruption / short circuit ground	A82		E	1
B28FA4	LSB-TE2: control heating/air conditioning Set air circ. / fresh air right interruption / short circuit ground	A82		E	1
B28FA5	LSB-TE2: control heating/air conditioning Set air foot / window ground missing / back measure short circuit VCC	A82		E	1
B28FA6	LSB-TE2: control heating/air conditioning Set air foot / window VCC missing / back measure short circuit ground	A82		E	1
B28FA7	LSB-TE2: control heating/air conditioning Set air foot / window flap blocked	A82		E	1
B28FA8	LSB-TE2: control heating/air conditioning Set air foot / window left interruption / short circuit ground	A82		E	1
B28FA9	LSB-TE2: control heating/air conditioning Set air foot / window right interruption / short circuit ground	A82		E	1
B29900	LSB-TE2: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A82.X3:3/4/6/7		E	2
B29901	LSB-TE2: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A82.X3:3/4/6/7		E	2
B29902	LSB-TE2: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A82.X3:3/4/6/7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B29904	LSB-TE2: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A82.X3:3/4/6/7		E	1
B29905	LSB-TE2: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A82.X3:3/4/6/7		E	1
B29906	LSB-TE2: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A82.X3:3/4/6/7		E	2
B29907	LSB-TE2: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A82.X3:3/4/6/7		E	1
B29911	LSB-TE2: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:3/4/6/7		E	2
B2D004	LSB-TE2: Analog input E0 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:20		E	1
B2D005	LSB-TE2: Analog input E0 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:20		E	1
B2D104	LSB-TE2: Analog input E1 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:21		E	1
B2D105	LSB-TE2: Analog input E1 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:21		E	1
B2D204	LSB-TE2: Analog input E2 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2D205	LSB-TE2: Analog input E2 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:22		E	1
B2D304	LSB-TE2: Analog input E3 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:23		E	1
B2D305	LSB-TE2: Analog input E3 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:23		E	1
B2D404	LSB-TE2: Analog input E4 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:24		E	1
B2D405	LSB-TE2: Analog input E4 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:24		E	1
B2D504	LSB-TE2: Analog input E5 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:25		E	1
B2D505	LSB-TE2: Analog input E5 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A82.X1:25		E	1
B2DC54	LSB-TE2: Switching output A0 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:18		E	1
B2DC55	LSB-TE2: Switching output A0 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:18		E	1
B2DD54	LSB-TE2: Switching output A1 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2DD55	LSB-TE2: Switching output A1 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:17		E	1
B2DE54	LSB-TE2: Switching output A2 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:16		E	1
B2DE55	LSB-TE2: Switching output A2 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:16		E	1
B2DF54	LSB-TE2: Switching output A3 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:15		E	1
B2DF55	LSB-TE2: Switching output A3 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:15		E	1
B2E054	LSB-TE2: Switching output A4 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:3		E	1
B2E055	LSB-TE2: Switching output A4 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:3		E	1
B2E154	LSB-TE2: Switching output A5 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:4		E	1
B2E155	LSB-TE2: Switching output A5 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:4		E	1
B2E254	LSB-TE2: Switching output A6 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2E255	LSB-TE2: Switching output A6 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:5		E	1
B2E354	LSB-TE2: Switching output A7 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:6		E	1
B2E355	LSB-TE2: Switching output A7 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:6		E	1
B2E454	LSB-TE2: Switching output A8 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:7		E	1
B2E455	LSB-TE2: Switching output A8 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:7		E	1
B2E554	LSB-TE2: Switching output A9 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:8		E	1
B2E555	LSB-TE2: Switching output A9 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:8		E	1
B2E650	LSB-TE2: Switching output A10 short circuit to ground, junction not supplied Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:14		E	1
B2E654	LSB-TE2: Switching output A10 short circuit to supply voltage Entry in error stack, set error status bit in EW4 Check initial switching, replace module, if necessary	A82.X1:14		E	2
B2E655	LSB-TE2: Switching output A10 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check outlet switching	A82.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2E65A	LSB-TE2: Switching output A10 Ground switching transistor defective Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:14		E	1
B2E750	LSB-TE2: Switching output A11 short circuit to ground, junction not supplied Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:1		E	1
B2E754	LSB-TE2: Switching output A11 short circuit to supply voltage Entry in error stack, set error status bit in EW4 Check initial switching, replace module, if necessary	A82.X1:1		E	2
B2E755	LSB-TE2: Switching output A11 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check outlet switching	A82.X1:1		E	1
B2E75A	LSB-TE2: Switching output A11 Ground switching transistor defective Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A82.X1:1		E	1
B2F001	LSB-TE2: System error OS-CPU initialising error processor-register erroneous Module reset Replace module	A82		E	2
B2F006	LSB-TE2: System error OS-CPU initialising error RAM erroneous Module reset Replace module	A82		E	2
B2F013	LSB-TE2: System error OS-CPU Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A82		E	2
B2F016	LSB-TE2: System error OS-CPU system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A82		E	2
B2F050	LSB-TE2: System error OS-CPU file not available error report Reload application software	A82		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2F068	LSB-TE2: System error OS-CPU impermissible interrupt Module reset Replace module	A82		E	2
B2F070	LSB-TE2: System error OS-CPU various structure versions error indication on display Inform Service of all error parameters and replace module	A82		E	2
B2F071	LSB-TE2: System error OS-CPU Structure file missing or faulty error indication on display Replace module	A82		E	2
B2F073	LSB-TE2: System error OS-CPU interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A82		E	2
B2F075	LSB-TE2: System error OS-CPU SPI-error error indication on display Inform Service of all error parameters and replace module	A82		E	2
B2F078	LSB-TE2: System error OS-CPU impermissible parameter Module reset Report all error parameters to Service	A82		E	1
B2F080	LSB-TE2: System error OS-CPU Fatal internal error Module reset Inform Service of all error parameters and replace module	A82		E	2
B2F082	LSB-TE2: System error OS-CPU hardware-watchdog erroneous Module reset Replace module	A82		E	2
B2F088	LSB-TE2: System error OS-CPU Configuration does not match software condition error indication on display Load correct software onto module	A82		E	2
B2F089	LSB-TE2: System error OS-CPU Incorrect version of firmware installed Entry in error stack Replace module	A82		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2F090	LSB-TE2: System error OS-CPU Incorrect hardware version recognised Entry in error stack Replace module	A82		E	2
B2F0A3	LSB-TE2: System error OS-CPU Board temp. outside permissible range error indication on display Cool off module, if error continues, replace module	A82		E	2
B2F0C1	LSB-TE2: System error OS-CPU Incorrect or wrong system version for application error report Reload matching system version	A82		E	1
B2FA00	LSB-TE2: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A82.X3:6/7		E	1
B2FA01	LSB-TE2: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A82.X3:6/7		E	1
B2FA02	LSB-TE2: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A82.X3:6/7		E	1
B2FA04	LSB-TE2: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A82.X3:6/7		E	1
B2FA05	LSB-TE2: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A82.X3:6/7		E	1
B2FA06	LSB-TE2: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A82.X3:6/7		E	2
B2FA11	LSB-TE2: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:6/7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2FA32	LSB-TE2: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A82.X3:6/7		E	1
B2FA40	LSB-TE2: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A82.X3:6/7		E	1
B2FA41	LSB-TE2: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A82.X3:6/7		E	1
B2FA5F	LSB-TE2: Control data transfer CAN-A Malfunction, all participants missing Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:6/7		E	1
B2FA90	LSB-TE2: Control data transfer CAN-A LSB-TE1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:6/7		E	1
B2FA91	LSB-TE2: Control data transfer CAN-A LSB-TE2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:6/7		E	1
B2FA92	LSB-TE2: Control data transfer CAN-A LSB-TE3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:6/7		E	1
B2FAB0	LSB-TE2: Control data transfer CAN-A LSB-AMS1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:6/7		E	1
B2FAB1	LSB-TE2: Control data transfer CAN-A LSB-AMS2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:6/7		E	1
B2FB00	LSB-TE2: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A82.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2FB01	LSB-TE2: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A82.X3:3/4		E	1
B2FB02	LSB-TE2: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A82.X3:3/4		E	1
B2FB04	LSB-TE2: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A82.X3:3/4		E	1
B2FB05	LSB-TE2: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A82.X3:3/4		E	1
B2FB06	LSB-TE2: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A82.X3:3/4		E	2
B2FB11	LSB-TE2: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:3/4		E	1
B2FB32	LSB-TE2: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A82.X3:3/4		E	1
B2FB40	LSB-TE2: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A82.X3:3/4		E	1
B2FB41	LSB-TE2: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A82.X3:3/4		E	1
B2FB5F	LSB-TE2: Control data transfer CAN-B Malfunction, all participants missing Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B2FB90	LSB-TE2: Control data transfer CAN-B LSB-TE1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:3/4		E	1
B2FB91	LSB-TE2: Control data transfer CAN-B LSB-TE2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:3/4		E	1
B2FB92	LSB-TE2: Control data transfer CAN-B LSB-TE3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:3/4		E	1
B2FBB0	LSB-TE2: Control data transfer CAN-B LSB-AMS1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:3/4		E	1
B2FBB1	LSB-TE2: Control data transfer CAN-B LSB-AMS2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A82.X3:3/4		E	1
B3016A	LSB-TE3: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3016C	LSB-TE3: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3026A	LSB-TE3: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3026C	LSB-TE3: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3036A	LSB-TE3: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3036C	LSB-TE3: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3046A	LSB-TE3: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3046C	LSB-TE3: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3056A	LSB-TE3: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3056C	LSB-TE3: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3066A	LSB-TE3: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3066C	LSB-TE3: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3076A	LSB-TE3: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3076C	LSB-TE3: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3086A	LSB-TE3: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3086C	LSB-TE3: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3096A	LSB-TE3: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3096C	LSB-TE3: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B30A6A	LSB-TE3: LSBA Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B30A6C	LSB-TE3: LSBA Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B30B6A	LSB-TE3: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B30B6C	LSB-TE3: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B30C6A	LSB-TE3: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B30C6C	LSB-TE3: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B30D6A	LSB-TE3: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B30D6C	LSB-TE3: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B30E6A	LSB-TE3: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B30E6C	LSB-TE3: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3186A	LSB-TE3: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3186C	LSB-TE3: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3196A	LSB-TE3: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B3196C	LSB-TE3: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B31A6A	LSB-TE3: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B31A6C	LSB-TE3: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B31B6A	LSB-TE3: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B31B6C	LSB-TE3: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B31C6A	LSB-TE3: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B31C6C	LSB-TE3: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B31D6A	LSB-TE3: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B31D6C	LSB-TE3: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B31E6A	LSB-TE3: LSBA Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A83.X3:8		E	2
B31E6C	LSB-TE3: LSBA Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A83.X3:8		E	2
B3205B	LSB-TE3: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A83.X3:8		E	2
B35C1B	LSB-TE3: Operation crawler Rapid gear crawler is not possible suspended ballast is installed Output of error Select op. mode without susp. ballast	A83		B	
B35C1C	LSB-TE3: Operation crawler Parallel operation crawler not selectable rapid gear crawler is ON Output of error Turn off crawler rapid gear function select drive crawler turn on again	A83		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B35C1D	LSB-TE3: Operation crawler Parallel operation crawler not selectable since crawler is ON Output of error Turn off drive crawler function select drive crawler turn on again	A83		B	
B35C1E	LSB-TE3: Operation crawler Rapid gear crawler not selectable since crawler is ON Output of error Turn off drive crawler function select drive crawler turn on again	A83		B	
B35C20	LSB-TE3: Operation crawler High-speed gear crawler is not poss. - parallel op. crawler is on Output of error Turn parallel op. off, select rapid gear	A83		B	
B35C23	LSB-TE3: Operation crawler Parallel operation crawler cannot be selected Output of error Turn rapid gear off, select parallel op.	A83		B	
B35C29	LSB-TE3: Operation crawler Fast speed of crawler not possible - LMB utilisation > 80 percent Output of error Reduce LMB utilisation to less than 80 percent	A83		B	
B35C2C	LSB-TE3: Operation crawler Rapid gear crawler not poss. - Parallel op. ballast tr. is on	A83		E	1
B35C61	LSB-TE3: Operation crawler Change-over crawler on / off with running winches Output of error Return winches to neutral position	A83		B	
B3613A	LSB-TE3: Operation crane control Selection Assembly winch from several op. positions simultaneous Function blocked Actuate only from one op. location	A83		B	
B3613B	LSB-TE3: Operation crane control Selection Assembly winch spool up and out simultaneous Issue of error / winch is not actuated Select only one direction	A83		B	
B364AA	LSB-TE3: operation instruments armrest right Change over master switch mode prevented, MS not in zero	A83		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B364AB	LSB-TE3: operation instruments armrest right Change over master switch mode prevented, MS not in zero	A83		E	1
B364AD	LSB-TE3: operation instruments armrest right Change over master switch mode prevented, MS3 not in zero	A83		E	1
B37007	LSB-TE3: remote control Zero position compulsion on radio MS	A83		E	1
B37019	LSB-TE3: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A83		E	1
B37090	LSB-TE3: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A83		E	1
B38A6E	LSB-TE3: control hydraulic/second. power outputs Hydraulic tank sensor short circuit after Vcc or sensor overvoltage Entry in error stack Check wiring and sensor	A83		E	1
B38A6F	LSB-TE3: control hydraulic/second. power outputs Hydrauliktankgeber short circuit after ground or sensor low voltage Entry in error stack Check wiring and sensor	A83		E	1
B38AA0	LSB-TE3: control hydraulic/second. power outputs Temperature sensor Hydraulic oil erroneous/missing Issue of error display engine values BSE1 Icon is red check wiring	A83		E	
B39900	LSB-TE3: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A83.X3:3/4/6/7		E	2
B39901	LSB-TE3: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A83.X3:3/4/6/7		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B39902	LSB-TE3: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A83.X3:3/4/6/7		E	1
B39904	LSB-TE3: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A83.X3:3/4/6/7		E	1
B39905	LSB-TE3: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A83.X3:3/4/6/7		E	1
B39906	LSB-TE3: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A83.X3:3/4/6/7		E	2
B39907	LSB-TE3: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A83.X3:3/4/6/7		E	1
B39911	LSB-TE3: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:3/4/6/7		E	2
B39991	LSB-TE3: Control data transfer CAN LSB-TE2 erroneous error report Check CAN-Network, control units	A83.X3:3/4/6/7		E	
B3D004	LSB-TE3: Analog input E0 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:20		E	1
B3D005	LSB-TE3: Analog input E0 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:20		E	1
B3D104	LSB-TE3: Analog input E1 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:21		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3D105	LSB-TE3: Analog input E1 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:21		E	1
B3D204	LSB-TE3: Analog input E2 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:22		E	1
B3D205	LSB-TE3: Analog input E2 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:22		E	1
B3D304	LSB-TE3: Analog input E3 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:23		E	1
B3D305	LSB-TE3: Analog input E3 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:23		E	1
B3D404	LSB-TE3: Analog input E4 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:24		E	1
B3D405	LSB-TE3: Analog input E4 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:24		E	1
B3D504	LSB-TE3: Analog input E5 level exceeded Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:25		E	1
B3D505	LSB-TE3: Analog input E5 below minimum level Entry in error stack, set error status bit in EW4 Measure voltage on module, compare with projected threshold	A83.X1:25		E	1
B3DC54	LSB-TE3: Switching output A0 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:18		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3DC55	LSB-TE3: Switching output A0 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:18		E	1
B3DD54	LSB-TE3: Switching output A1 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:17		E	1
B3DD55	LSB-TE3: Switching output A1 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:17		E	1
B3DE54	LSB-TE3: Switching output A2 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:16		E	1
B3DE55	LSB-TE3: Switching output A2 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:16		E	1
B3DF54	LSB-TE3: Switching output A3 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:15		E	1
B3DF55	LSB-TE3: Switching output A3 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:15		E	1
B3E054	LSB-TE3: Switching output A4 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:3		E	1
B3E055	LSB-TE3: Switching output A4 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:3		E	1
B3E154	LSB-TE3: Switching output A5 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3E155	LSB-TE3: Switching output A5 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:4		E	1
B3E254	LSB-TE3: Switching output A6 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:5		E	1
B3E255	LSB-TE3: Switching output A6 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:5		E	1
B3E354	LSB-TE3: Switching output A7 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:6		E	1
B3E355	LSB-TE3: Switching output A7 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:6		E	1
B3E454	LSB-TE3: Switching output A8 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:7		E	1
B3E455	LSB-TE3: Switching output A8 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:7		E	1
B3E554	LSB-TE3: Switching output A9 short circuit to supply voltage Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:8		E	1
B3E555	LSB-TE3: Switching output A9 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:8		E	1
B3E650	LSB-TE3: Switching output A10 short circuit to ground, junction not supplied Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3E654	LSB-TE3: Switching output A10 short circuit to supply voltage Entry in error stack, set error status bit in EW4 Check initial switching, replace module, if necessary	A83.X1:14		E	2
B3E655	LSB-TE3: Switching output A10 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check outlet switching	A83.X1:14		E	1
B3E65A	LSB-TE3: Switching output A10 Ground switching transistor defective Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:14		E	1
B3E750	LSB-TE3: Switching output A11 short circuit to ground, junction not supplied Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:1		E	1
B3E754	LSB-TE3: Switching output A11 short circuit to supply voltage Entry in error stack, set error status bit in EW4 Check initial switching, replace module, if necessary	A83.X1:1		E	2
B3E755	LSB-TE3: Switching output A11 excessive temperature, short circuit to ground or overload Entry in error stack, set error status bit EW5 Check outlet switching	A83.X1:1		E	1
B3E75A	LSB-TE3: Switching output A11 Ground switching transistor defective Entry in error stack, set error status bit EW5 Check initial switching, replace module, if necessary	A83.X1:1		E	1
B3F001	LSB-TE3: System error OS-CPU initialising error processor-register erroneous Module reset Replace module	A83		E	2
B3F006	LSB-TE3: System error OS-CPU initialising error RAM erroneous Module reset Replace module	A83		E	2
B3F013	LSB-TE3: System error OS-CPU Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A83		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3F016	LSB-TE3: System error OS-CPU system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A83		E	2
B3F050	LSB-TE3: System error OS-CPU file not available error report Reload application software	A83		E	2
B3F068	LSB-TE3: System error OS-CPU impermissible interrupt Module reset Replace module	A83		E	2
B3F070	LSB-TE3: System error OS-CPU various structure versions error indication on display Inform Service of all error parameters and replace module	A83		E	2
B3F071	LSB-TE3: System error OS-CPU Structure file missing or faulty error indication on display Replace module	A83		E	2
B3F073	LSB-TE3: System error OS-CPU interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A83		E	2
B3F075	LSB-TE3: System error OS-CPU SPI-error error indication on display Inform Service of all error parameters and replace module	A83		E	2
B3F078	LSB-TE3: System error OS-CPU impermissible parameter Module reset Report all error parameters to Service	A83		E	1
B3F080	LSB-TE3: System error OS-CPU Fatal internal error Module reset Inform Service of all error parameters and replace module	A83		E	2
B3F082	LSB-TE3: System error OS-CPU hardware-watchdog erroneous Module reset Replace module	A83		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3F088	LSB-TE3: System error OS-CPU Configuration does not match software condition error indication on display Load correct software onto module	A83		E	2
B3F089	LSB-TE3: System error OS-CPU Incorrect version of firmware installed Entry in error stack Replace module	A83		E	2
B3F090	LSB-TE3: System error OS-CPU Incorrect hardware version recognised Entry in error stack Replace module	A83		E	2
B3F0A3	LSB-TE3: System error OS-CPU Board temp. outside permissible range error indication on display Cool off module, if error continues, replace module	A83		E	2
B3F0C1	LSB-TE3: System error OS-CPU Incorrect or wrong system version for application error report Reload matching system version	A83		E	1
B3FA00	LSB-TE3: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A83.X3:6/7		E	1
B3FA01	LSB-TE3: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A83.X3:6/7		E	1
B3FA02	LSB-TE3: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A83.X3:6/7		E	1
B3FA04	LSB-TE3: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A83.X3:6/7		E	1
B3FA05	LSB-TE3: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A83.X3:6/7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3FA06	LSB-TE3: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A83.X3:6/7		E	2
B3FA11	LSB-TE3: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:6/7		E	1
B3FA32	LSB-TE3: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A83.X3:6/7		E	1
B3FA40	LSB-TE3: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A83.X3:6/7		E	1
B3FA41	LSB-TE3: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A83.X3:6/7		E	1
B3FA90	LSB-TE3: Control data transfer CAN-A LSB-TE1 erroneous	A83.X3:6/7		E	1
B3FA91	LSB-TE3: Control data transfer CAN-A LSB-TE2 erroneous	A83.X3:6/7		E	1
B3FAB2	LSB-TE3: Control data transfer CAN-A LSB-AMS3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:6/7		E	1
B3FB00	LSB-TE3: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A83.X3:3/4		E	1
B3FB01	LSB-TE3: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A83.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3FB02	LSB-TE3: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A83.X3:3/4		E	1
B3FB04	LSB-TE3: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A83.X3:3/4		E	1
B3FB05	LSB-TE3: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A83.X3:3/4		E	1
B3FB06	LSB-TE3: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A83.X3:3/4		E	2
B3FB11	LSB-TE3: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:3/4		E	1
B3FB32	LSB-TE3: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A83.X3:3/4		E	1
B3FB40	LSB-TE3: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A83.X3:3/4		E	1
B3FB41	LSB-TE3: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A83.X3:3/4		E	1
B3FB8A	LSB-TE3: Control data transfer CAN-B LSB-UEA11 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:3/4		E	1
B3FB90	LSB-TE3: Control data transfer CAN-B LSB-TE1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
B3FB91	LSB-TE3: Control data transfer CAN-B LSB-TE2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:3/4		E	1
B3FB92	LSB-TE3: Control data transfer CAN-B LSB-TE3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:3/4		E	1
B3FBAB	LSB-TE3: Control data transfer CAN-B LSB-BTB2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:3/4		E	1
B3FBB2	LSB-TE3: Control data transfer CAN-B LSB-AMS3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A83.X3:3/4		E	1
C13002	LSB-UEA1: control winch 1 hydraulic circuit pressure sensor defective/missing No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A21		E	
C1300A	LSB-UEA1: control winch 1 Pressure too high when pump is not actuated No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A21		E	
C1300B	LSB-UEA1: control winch 1 Winch turn sensor erroneous / missing No actuation of pump and no act. of winch brake Check winch turn sensor. Check LSB-Bus	A21		E	
C1300C	LSB-UEA1: control winch 1 Repl. pressure supply missing / too low during winch movement Stop winch Check signal. Check pr. switch. Check hydr, replen. pressure supply	A21		E	
C1300D	LSB-UEA1: control winch 1 Winch brake, ground switch open during winch movement Stop winch Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A21		E	
C1300E	LSB-UEA1: control winch 1 Winch brake, ground switch does not close / closes too late Delayed actuation of winch. No actuation of winch. Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A21		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1300F	LSB-UEA1: control winch 1 Winch brake, ground switch report short circuit after ground (Start) No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A21		E	
C13016	LSB-UEA1: control winch 1 Winch brake, ground switch report short circuit after Plus (Start) No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A21		E	
C1301C	LSB-UEA1: control winch 1 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A21		B	
C13020	LSB-UEA1: control winch 1 Winch brake, ground switch report has short circuit after ground Error message: second shut off channel ineffective Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A21		E	
C13021	LSB-UEA1: control winch 1 Emerg. shut off active No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A21		E	
C13023	LSB-UEA1: control winch 1 Outlet error control outlet winch, read out system error (inactive) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A21		E	
C13024	LSB-UEA1: control winch 1 Monitoring release brake pressure, short circuit after Plus Active act. of emerg. valve only at master switch deflection. Error message Check signal line for short circuit. Check wiring, switch on valve	A21		E	
C13025	LSB-UEA1: control winch 1 Monitoring release brake pressure interruption/short circuit after gro Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A21		E	
C13026	LSB-UEA1: control winch 1 Rotational speed too low, current nominal value fallen below error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A21		E	
C13027	LSB-UEA1: control winch 1 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A21		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C13028	LSB-UEA1: control winch 1 Permissible rotational speed exceeded, emergency shut off Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A21		E	
C13029	LSB-UEA1: control winch 1 Monitoring rotational speed not possible, winch turn sensor missing Error message. Shut down winch by closing winch brake Check winch turn sensor. Check LSB-Bus	A21		E	
C1302D	LSB-UEA1: control winch 1 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A21		E	
C1302E	LSB-UEA1: control winch 1 Repl. pressure switch implausible to pressure sensor signal (analog) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A21		E	
C13041	LSB-UEA1: control winch 1 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A21		E	
C13042	LSB-UEA1: control winch 1 Rotation movement at non-actuated winch brake Error message. Check winch brake. Check winch turn sensor(installation)	A21		E	
C13046	LSB-UEA1: control winch 1 Signal Replenishing pr. sensor short circuit after ground or interrupt Operation conditional switch off, may not be shunted replace sensor through new part	A21		E	
C13047	LSB-UEA1: control winch 1 Signal Brake pr. sensor short circuit after ground or interruption	A21		E	
C1305F	LSB-UEA1: control winch 1 Shut off master switch zero position forced Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A21		B	
C13060	LSB-UEA1: control winch 1 Path regulation parallel op., Difference path WDG too large Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A21		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C13061	LSB-UEA1: control winch 1 Path regulation parallel op., no/invalid relative zero point WDG Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A21		E	
C13062	LSB-UEA1: control winch 1 Monitoring spool out length parallel op., difference length too large Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A21		E	
C13063	LSB-UEA1: control winch 1 Monitoring spool out length parallel op., no saved zero point Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A21		E	
C13070	LSB-UEA1: control winch 1 Path regulation parallel op., Difference path pulley too large Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A21		E	
C13071	LSB-UEA1: control winch 1 Path regulation parallel op., no/invalid relative zero point pulley Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A21		E	
C13072	LSB-UEA1: control winch 1 Path regulation parallel op., incremental sensor roll erroneous signal Length sensor deviation of length signal of incremental sensor compared to winch turn sensor Check signal line of incr. sensor for interruption. Check wiring. Supply (VCC,GND), Prox	A21		E	
C13F03	LSB-UEA1: crane control CAN-connection to MS1 Channel-A problematic / not present No crane movement which is controlled via Master switch -1 (right) or Master switch -2 (left) Check CAN-connection	A21		E	
C13F04	LSB-UEA1: crane control CAN-connection to MS1 Channel-B problematic / not present No crane movement which is controlled via Master switch -1 (right) or Master switch -2 (left) Check CAN-connection	A21		E	
C13F05	LSB-UEA1: crane control CAN-connection to MS2 Channel-A problematic / not present	A21		E	
C13F06	LSB-UEA1: crane control CAN-connection to MS2 Channel-B problematic / not present Module reset Replace module	A21		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C16108	LSB-UEA1: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A21		E	
C17007	LSB-UEA1: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A21		B	
C17019	LSB-UEA1: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A21		E	
C17090	LSB-UEA1: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A21		E	
C19900	LSB-UEA1: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A21		E	2
C19901	LSB-UEA1: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A21		E	2
C19902	LSB-UEA1: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A21		E	1
C19904	LSB-UEA1: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A21		E	1
C19905	LSB-UEA1: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A21		E	1
C19906	LSB-UEA1: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A21		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C19907	LSB-UEA1: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A21		E	1
C19911	LSB-UEA1: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A21		E	2
C1C089	LSB-UEA1: Diagnostics syst. band end/adj. program Test program winch brake current not yet carried out Adj. program is interrupted, all movements turned off Set pump currents	A21		B	
C1C098	LSB-UEA1: Diagnostics syst. band end/adj. program F76: Var. motor currents not completely set Settings program is interrupted CWs are not correctly taken over Set Trimot currents	A21		B	
C1C0C3	LSB-UEA1: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A21		B	
C1C0C4	LSB-UEA1: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A21		B	
C1C0C5	LSB-UEA1: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A21		B	
C1C0C6	LSB-UEA1: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A21		B	
C1C0C8	LSB-UEA1: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low Adj. program is interrupted, all movements turned off Increase Qmin Pump (See Specification Pump)	A21		B	
C1C0C9	LSB-UEA1: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high Adj. program is interrupted, all movements turned off Decrease Qmin Pump (See Specification Pump)	A21		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1C0CA	LSB-UEA1: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded Adj. program is interrupted, all movements turned off Pressure threshold was not recognized, try again (consult)	A21		B	
C1C0CB	LSB-UEA1: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range Adj. program is interrupted, all movements turned off No adj. value was found within current limits. Check hydraulic	A21		B	
C1C0CC	LSB-UEA1: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100% Adj. program is interrupted, all movements turned off Deflect master switch during adj. phase 100%	A21		B	
C1C0CF	LSB-UEA1: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A21		B	
C1C0D0	LSB-UEA1: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A21		B	
C1C0D1	LSB-UEA1: Diagnostics syst. band end/adj. program F15: Angle sensor placement section: Lower limit angle reached Adj. program is interrupted, all movements turned off Carry out luff up movement until perm. tele angle is reached	A21		B	
C1C0DA	LSB-UEA1: Diagnostics syst. band end/adj. program F24: Pump flows not completely set Adj. program is interrupted, all movements turned off Set pump currents	A21		B	
C1D502	LSB-UEA1: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A21.X2:1		E	1
C1D503	LSB-UEA1: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A21.X2:1		E	1
C1D513	LSB-UEA1: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	A21.X2:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1D602	LSB-UEA1: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A21.X2:2		E	1
C1D603	LSB-UEA1: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A21.X2:2		E	1
C1D613	LSB-UEA1: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	A21.X2:2		E	1
C1D702	LSB-UEA1: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A21.X2:4		E	1
C1D703	LSB-UEA1: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A21.X2:4		E	1
C1D713	LSB-UEA1: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	A21.X2:4		E	1
C1D802	LSB-UEA1: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A21.X2:5		E	1
C1D803	LSB-UEA1: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A21.X2:5		E	1
C1D813	LSB-UEA1: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	A21.X2:5		E	1
C1D902	LSB-UEA1: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A21.X2:7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1D903	LSB-UEA1: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A21.X2:7		E	1
C1D913	LSB-UEA1: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	A21.X2:7		E	1
C1DA02	LSB-UEA1: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A21.X2:8		E	1
C1DA03	LSB-UEA1: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A21.X2:8		E	1
C1DA13	LSB-UEA1: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	A21.X2:8		E	1
C1DB02	LSB-UEA1: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A21.X2:10		E	1
C1DB03	LSB-UEA1: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A21.X2:10		E	1
C1DB13	LSB-UEA1: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	A21.X2:10		E	1
C1DC02	LSB-UEA1: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A21.X2:11		E	1
C1DC03	LSB-UEA1: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A21.X2:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1DC13	LSB-UEA1: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	A21.X2:11		E	1
C1DD6F	LSB-UEA1: Digital input E8 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A21.X2:18		E	1
C1DE6F	LSB-UEA1: Digital input E9 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A21.X2:19		E	1
C1DF6F	LSB-UEA1: Digital input E10 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A21.X2:20		E	1
C1E06F	LSB-UEA1: Digital input E11 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A21.X2:21		E	1
C1E112	LSB-UEA1: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A21.X1:10		E	1
C1E11A	LSB-UEA1: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	A21.X1:10		E	1
C1E11B	LSB-UEA1: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	A21.X1:10		E	1
C1E11C	LSB-UEA1: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A21.X1:10		E	1
C1E11D	LSB-UEA1: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	A21.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1E121	LSB-UEA1: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	A21.X1:10		E	1
C1E154	LSB-UEA1: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	A21.X1:10		E	1
C1E157	LSB-UEA1: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A21.X1:10		E	1
C1E159	LSB-UEA1: Switching output A0 supply voltage missing error indication on display Check line and fuse	A21.X1:10		E	1
C1E172	LSB-UEA1: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A21.X1:10		E	1
C1E212	LSB-UEA1: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A21.X1:11		E	1
C1E21A	LSB-UEA1: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	A21.X1:11		E	1
C1E21B	LSB-UEA1: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	A21.X1:11		E	1
C1E21C	LSB-UEA1: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A21.X1:11		E	1
C1E21D	LSB-UEA1: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	A21.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1E221	LSB-UEA1: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	A21.X1:11		E	1
C1E254	LSB-UEA1: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	A21.X1:11		E	1
C1E257	LSB-UEA1: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A21.X1:11		E	1
C1E259	LSB-UEA1: Switching output A1 supply voltage missing error indication on display Check line and fuse	A21.X1:11		E	1
C1E272	LSB-UEA1: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A21.X1:11		E	1
C1E312	LSB-UEA1: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A21.X1:12		E	1
C1E31A	LSB-UEA1: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	A21.X1:12		E	1
C1E31B	LSB-UEA1: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	A21.X1:12		E	1
C1E31C	LSB-UEA1: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A21.X1:12		E	1
C1E31D	LSB-UEA1: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	A21.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1E321	LSB-UEA1: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	A21.X1:12		E	1
C1E354	LSB-UEA1: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	A21.X1:12		E	1
C1E357	LSB-UEA1: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A21.X1:12		E	1
C1E359	LSB-UEA1: Switching output A2 supply voltage missing error indication on display Check line and fuse	A21.X1:12		E	1
C1E372	LSB-UEA1: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A21.X1:12		E	1
C1E412	LSB-UEA1: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A21.X1:13		E	1
C1E41A	LSB-UEA1: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	A21.X1:13		E	1
C1E41B	LSB-UEA1: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	A21.X1:13		E	1
C1E41C	LSB-UEA1: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A21.X1:13		E	1
C1E41D	LSB-UEA1: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	A21.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1E421	LSB-UEA1: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	A21.X1:13		E	1
C1E454	LSB-UEA1: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	A21.X1:13		E	1
C1E457	LSB-UEA1: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A21.X1:13		E	1
C1E459	LSB-UEA1: Switching output A3 supply voltage missing error indication on display Check line and fuse	A21.X1:13		E	1
C1E472	LSB-UEA1: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A21.X1:13		E	1
C1E512	LSB-UEA1: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A21.X1:14		E	1
C1E51A	LSB-UEA1: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	A21.X1:14		E	1
C1E51B	LSB-UEA1: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	A21.X1:14		E	1
C1E51C	LSB-UEA1: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A21.X1:14		E	1
C1E51D	LSB-UEA1: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	A21.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1E521	LSB-UEA1: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	A21.X1:14		E	1
C1E554	LSB-UEA1: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	A21.X1:14		E	1
C1E557	LSB-UEA1: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A21.X1:14		E	1
C1E559	LSB-UEA1: Switching output A4 supply voltage missing error indication on display Check line and fuse	A21.X1:14		E	1
C1E572	LSB-UEA1: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A21.X1:14		E	1
C1E612	LSB-UEA1: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A21.X1:15		E	1
C1E61A	LSB-UEA1: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	A21.X1:15		E	1
C1E61B	LSB-UEA1: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	A21.X1:15		E	1
C1E61C	LSB-UEA1: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A21.X1:15		E	1
C1E61D	LSB-UEA1: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	A21.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1E621	LSB-UEA1: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	A21.X1:15		E	1
C1E654	LSB-UEA1: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	A21.X1:15		E	1
C1E657	LSB-UEA1: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A21.X1:15		E	1
C1E659	LSB-UEA1: Switching output A5 supply voltage missing error indication on display Check line and fuse	A21.X1:15		E	1
C1E672	LSB-UEA1: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A21.X1:15		E	1
C1E712	LSB-UEA1: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A21.X1:16		E	1
C1E71A	LSB-UEA1: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	A21.X1:16		E	1
C1E71B	LSB-UEA1: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	A21.X1:16		E	1
C1E71C	LSB-UEA1: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A21.X1:16		E	1
C1E71D	LSB-UEA1: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	A21.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1E721	LSB-UEA1: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	A21.X1:16		E	1
C1E754	LSB-UEA1: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	A21.X1:16		E	1
C1E757	LSB-UEA1: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A21.X1:16		E	1
C1E759	LSB-UEA1: Switching output A6 supply voltage missing error indication on display Check line and fuse	A21.X1:16		E	1
C1E772	LSB-UEA1: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A21.X1:16		E	1
C1E812	LSB-UEA1: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A21.X1:17		E	1
C1E81A	LSB-UEA1: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	A21.X1:17		E	1
C1E81B	LSB-UEA1: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	A21.X1:17		E	1
C1E81C	LSB-UEA1: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A21.X1:17		E	1
C1E81D	LSB-UEA1: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	A21.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1E821	LSB-UEA1: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	A21.X1:17		E	1
C1E854	LSB-UEA1: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	A21.X1:17		E	1
C1E857	LSB-UEA1: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A21.X1:17		E	1
C1E859	LSB-UEA1: Switching output A7 supply voltage missing error indication on display Check line and fuse	A21.X1:17		E	1
C1E872	LSB-UEA1: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A21.X1:17		E	1
C1F001	LSB-UEA1: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module	A21		E	2
C1F006	LSB-UEA1: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module	A21		E	2
C1F013	LSB-UEA1: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A21		E	2
C1F016	LSB-UEA1: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A21		E	2
C1F031	LSB-UEA1: System error OS-CPU0 CPU-test faulty Module reset Replace module	A21		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1F050	LSB-UEA1: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software	A21		E	2
C1F068	LSB-UEA1: System error OS-CPU0 impermissible interrupt Module reset Replace module	A21		E	2
C1F070	LSB-UEA1: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module	A21		E	2
C1F071	LSB-UEA1: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module	A21		E	2
C1F073	LSB-UEA1: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A21		E	2
C1F075	LSB-UEA1: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module	A21		E	2
C1F078	LSB-UEA1: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service	A21		E	1
C1F080	LSB-UEA1: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module	A21		E	2
C1F082	LSB-UEA1: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A21		E	2
C1F088	LSB-UEA1: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module	A21		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1F089	LSB-UEA1: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module	A21		E	2
C1F090	LSB-UEA1: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module	A21		E	2
C1F0C1	LSB-UEA1: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A21		E	1
C1F113	LSB-UEA1: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A21		E	2
C1F15A	LSB-UEA1: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module	A21		E	2
C1F15B	LSB-UEA1: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane	A21		E	2
C1F170	LSB-UEA1: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors	A21		E	2
C1F175	LSB-UEA1: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit	A21		E	2
C1F1AC	LSB-UEA1: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)	A21		E	2
C1FA00	LSB-UEA1: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A21.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1FA01	LSB-UEA1: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A21.X3:2/3		E	1
C1FA02	LSB-UEA1: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A21.X3:2/3		E	1
C1FA04	LSB-UEA1: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A21.X3:2/3		E	1
C1FA05	LSB-UEA1: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A21.X3:2/3		E	1
C1FA06	LSB-UEA1: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A21.X3:2/3		E	2
C1FA11	LSB-UEA1: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A21.X3:2/3		E	1
C1FA32	LSB-UEA1: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A21.X3:2/3		E	1
C1FA40	LSB-UEA1: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A21.X3:2/3		E	1
C1FA41	LSB-UEA1: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A21.X3:2/3		E	1
C1FB00	LSB-UEA1: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A21.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C1FB01	LSB-UEA1: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A21.X3:4/5		E	1
C1FB02	LSB-UEA1: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A21.X3:4/5		E	1
C1FB04	LSB-UEA1: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A21.X3:4/5		E	1
C1FB05	LSB-UEA1: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A21.X3:4/5		E	1
C1FB06	LSB-UEA1: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A21.X3:4/5		E	2
C1FB11	LSB-UEA1: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A21.X3:4/5		E	1
C1FB32	LSB-UEA1: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A21.X3:4/5		E	1
C1FB40	LSB-UEA1: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A21.X3:4/5		E	1
C1FB41	LSB-UEA1: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A21.X3:4/5		E	1
C23102	LSB-UEA2: control winch 2 hydraulic circuit pressure sensor defective/missing No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A22		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2310A	LSB-UEA2: control winch 2 Pressure too high when pump is not actuated No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A22		E	
C2310B	LSB-UEA2: control winch 2 Winch turn sensor erroneous / missing No actuation of pump and no act. of winch brake Check winch turn sensor. Check LSB-Bus	A22		E	
C2310C	LSB-UEA2: control winch 2 Repl. pressure supply missing / too low during winch movement Stop winch Check signal. Check pr. switch. Check hydr, replen. pressure supply	A22		E	
C2310D	LSB-UEA2: control winch 2 Winch brake, ground switch open during winch movement Stop winch Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A22		E	
C2310E	LSB-UEA2: control winch 2 Winch brake, ground switch does not close / closes too late Delayed actuation of winch. No actuation of winch. Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A22		E	
C2310F	LSB-UEA2: control winch 2 Winch brake, ground switch report short circuit after ground (Start) No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A22		E	
C23116	LSB-UEA2: control winch 2 Winch brake, ground switch report short circuit after Plus (Start) No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A22		E	
C2311C	LSB-UEA2: control winch 2 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A22		B	
C23120	LSB-UEA2: control winch 2 Winch brake, ground switch report has short circuit after ground Error message: second shut off channel ineffective Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A22		E	
C23121	LSB-UEA2: control winch 2 Emerg. shut off active No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A22		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C23123	LSB-UEA2: control winch 2 Outlet error control outlet winch, read out system error (inactive) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A22		E	
C23124	LSB-UEA2: control winch 2 Monitoring release brake pressure, short circuit after Plus Active act. of emerg. valve only at master switch deflection. Error message Check signal line for short circuit. Check wiring, switch on valve	A22		E	
C23125	LSB-UEA2: control winch 2 Monitoring release brake pressure interruption/short circuit after gro Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A22		E	
C23126	LSB-UEA2: control winch 2 Rotational speed too low, current nominal value fallen below error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A22		E	
C23127	LSB-UEA2: control winch 2 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A22		E	
C23128	LSB-UEA2: control winch 2 Permissible rotational speed exceeded, emergency shut off Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A22		E	
C23129	LSB-UEA2: control winch 2 Monitoring rotational speed not possible, winch turn sensor missing Error message. Shut down winch by closing winch brake Check winch turn sensor. Check LSB-Bus	A22		E	
C2312D	LSB-UEA2: control winch 2 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A22		E	
C2312E	LSB-UEA2: control winch 2 Repl. pressure switch implausible to pressure sensor signal (analog) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A22		E	
C23141	LSB-UEA2: control winch 2 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A22		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C23142	LSB-UEA2: control winch 2 Rotation movement at non-actuated winch brake Error message. Check winch brake. Check winch turn sensor(installation)	A22		E	
C23146	LSB-UEA2: control winch 2 Signal Replenishing pr. sensor short circuit after ground or interrupt Operation conditional switch off, may not be shunted replace sensor through new part	A22		E	
C23147	LSB-UEA2: control winch 2 Signal Brake pr. sensor short circuit after ground or interruption	A22		E	
C2315F	LSB-UEA2: control winch 2 Shut off master switch zero position forced Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A22		B	
C23160	LSB-UEA2: control winch 2 Path regulation parallel op., Difference path WDG too large Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A22		E	
C23161	LSB-UEA2: control winch 2 Path regulation parallel op., no/invalid relative zero point WDG Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A22		E	
C23162	LSB-UEA2: control winch 2 Monitoring spool out length parallel op., difference length too large Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A22		E	
C23163	LSB-UEA2: control winch 2 Monitoring spool out length parallel op., no saved zero point Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A22		E	
C23170	LSB-UEA2: control winch 2 Path regulation parallel op., Difference path pulley too large Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A22		E	
C23171	LSB-UEA2: control winch 2 Path regulation parallel op., no/invalid relative zero point pulley Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A22		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C23172	LSB-UEA2: control winch 2 Path regulation parallel op., incremental sensor roll erroneous signal Length sensor deviation of length signal of incremental sensor compared to winch turn sensor Check signal line of incr. sensor for interruption. Check wiring. Supply (VCC,GND), Prox	A22		E	
C26108	LSB-UEA2: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A22		E	
C27007	LSB-UEA2: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A22		B	
C27019	LSB-UEA2: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A22		E	
C27090	LSB-UEA2: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A22		E	
C29900	LSB-UEA2: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A22		E	2
C29901	LSB-UEA2: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A22		E	2
C29902	LSB-UEA2: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A22		E	1
C29904	LSB-UEA2: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A22		E	1
C29905	LSB-UEA2: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A22		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C29906	LSB-UEA2: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A22		E	2
C29907	LSB-UEA2: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A22		E	1
C29911	LSB-UEA2: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A22		E	2
C2C089	LSB-UEA2: Diagnostics syst. band end/adj. program Test program winch brake current not yet carried out Adj. program is interrupted, all movements turned off Set pump currents	A22		B	
C2C0C3	LSB-UEA2: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A22		B	
C2C0C4	LSB-UEA2: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A22		B	
C2C0C5	LSB-UEA2: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A22		B	
C2C0C6	LSB-UEA2: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A22		B	
C2C0C8	LSB-UEA2: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low Adj. program is interrupted, all movements turned off Increase Qmin Pump (See Specification Pump)	A22		B	
C2C0C9	LSB-UEA2: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high Adj. program is interrupted, all movements turned off Decrease Qmin Pump (See Specification Pump)	A22		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2C0CA	LSB-UEA2: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded Adj. program is interrupted, all movements turned off Pressure threshold was not recognized, try again (consult)	A22		B	
C2C0CB	LSB-UEA2: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range Adj. program is interrupted, all movements turned off No adj. value was found within current limits. Check hydraulic	A22		B	
C2C0CC	LSB-UEA2: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100% Adj. program is interrupted, all movements turned off Deflect master switch during adj. phase 100%	A22		B	
C2C0CF	LSB-UEA2: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A22		B	
C2C0D0	LSB-UEA2: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A22		B	
C2C0D1	LSB-UEA2: Diagnostics syst. band end/adj. program F15: Angle sensor placement section: Lower limit angle reached Adj. program is interrupted, all movements turned off Carry out luff up movement until perm. tele angle is reached	A22		B	
C2C0DA	LSB-UEA2: Diagnostics syst. band end/adj. program F24: Pump flows not completely set Adj. program is interrupted, all movements turned off Set pump currents	A22		B	
C2D502	LSB-UEA2: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A22.X2:1		E	1
C2D503	LSB-UEA2: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A22.X2:1		E	1
C2D513	LSB-UEA2: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	A22.X2:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2D602	LSB-UEA2: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A22.X2:2		E	1
C2D603	LSB-UEA2: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A22.X2:2		E	1
C2D613	LSB-UEA2: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	A22.X2:2		E	1
C2D702	LSB-UEA2: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A22.X2:4		E	1
C2D703	LSB-UEA2: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A22.X2:4		E	1
C2D713	LSB-UEA2: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	A22.X2:4		E	1
C2D802	LSB-UEA2: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A22.X2:5		E	1
C2D803	LSB-UEA2: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A22.X2:5		E	1
C2D813	LSB-UEA2: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	A22.X2:5		E	1
C2D902	LSB-UEA2: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A22.X2:7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2D903	LSB-UEA2: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A22.X2:7		E	1
C2D913	LSB-UEA2: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	A22.X2:7		E	1
C2DA02	LSB-UEA2: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A22.X2:8		E	1
C2DA03	LSB-UEA2: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A22.X2:8		E	1
C2DA13	LSB-UEA2: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	A22.X2:8		E	1
C2DB02	LSB-UEA2: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A22.X2:10		E	1
C2DB03	LSB-UEA2: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A22.X2:10		E	1
C2DB13	LSB-UEA2: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	A22.X2:10		E	1
C2DC02	LSB-UEA2: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A22.X2:11		E	1
C2DC03	LSB-UEA2: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A22.X2:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2DC13	LSB-UEA2: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	A22.X2:11		E	1
C2DD6F	LSB-UEA2: Digital input E8 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A22.X2:18		E	1
C2DE6F	LSB-UEA2: Digital input E9 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A22.X2:19		E	1
C2DF6F	LSB-UEA2: Digital input E10 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A22.X2:20		E	1
C2E06F	LSB-UEA2: Digital input E11 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A22.X2:21		E	1
C2E112	LSB-UEA2: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A22.X1:10		E	1
C2E11A	LSB-UEA2: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	A22.X1:10		E	1
C2E11B	LSB-UEA2: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	A22.X1:10		E	1
C2E11C	LSB-UEA2: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A22.X1:10		E	1
C2E11D	LSB-UEA2: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	A22.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2E121	LSB-UEA2: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	A22.X1:10		E	1
C2E154	LSB-UEA2: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	A22.X1:10		E	1
C2E157	LSB-UEA2: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A22.X1:10		E	1
C2E159	LSB-UEA2: Switching output A0 supply voltage missing error indication on display Check line and fuse	A22.X1:10		E	1
C2E172	LSB-UEA2: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A22.X1:10		E	1
C2E212	LSB-UEA2: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A22.X1:11		E	1
C2E21A	LSB-UEA2: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	A22.X1:11		E	1
C2E21B	LSB-UEA2: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	A22.X1:11		E	1
C2E21C	LSB-UEA2: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A22.X1:11		E	1
C2E21D	LSB-UEA2: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	A22.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2E221	LSB-UEA2: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	A22.X1:11		E	1
C2E254	LSB-UEA2: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	A22.X1:11		E	1
C2E257	LSB-UEA2: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A22.X1:11		E	1
C2E259	LSB-UEA2: Switching output A1 supply voltage missing error indication on display Check line and fuse	A22.X1:11		E	1
C2E272	LSB-UEA2: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A22.X1:11		E	1
C2E312	LSB-UEA2: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A22.X1:12		E	1
C2E31A	LSB-UEA2: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	A22.X1:12		E	1
C2E31B	LSB-UEA2: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	A22.X1:12		E	1
C2E31C	LSB-UEA2: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A22.X1:12		E	1
C2E31D	LSB-UEA2: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	A22.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2E321	LSB-UEA2: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	A22.X1:12		E	1
C2E354	LSB-UEA2: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	A22.X1:12		E	1
C2E357	LSB-UEA2: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A22.X1:12		E	1
C2E359	LSB-UEA2: Switching output A2 supply voltage missing error indication on display Check line and fuse	A22.X1:12		E	1
C2E372	LSB-UEA2: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A22.X1:12		E	1
C2E412	LSB-UEA2: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A22.X1:13		E	1
C2E41A	LSB-UEA2: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	A22.X1:13		E	1
C2E41B	LSB-UEA2: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	A22.X1:13		E	1
C2E41C	LSB-UEA2: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A22.X1:13		E	1
C2E41D	LSB-UEA2: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	A22.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2E421	LSB-UEA2: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	A22.X1:13		E	1
C2E454	LSB-UEA2: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	A22.X1:13		E	1
C2E457	LSB-UEA2: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A22.X1:13		E	1
C2E459	LSB-UEA2: Switching output A3 supply voltage missing error indication on display Check line and fuse	A22.X1:13		E	1
C2E472	LSB-UEA2: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A22.X1:13		E	1
C2E512	LSB-UEA2: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A22.X1:14		E	1
C2E51A	LSB-UEA2: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	A22.X1:14		E	1
C2E51B	LSB-UEA2: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	A22.X1:14		E	1
C2E51C	LSB-UEA2: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A22.X1:14		E	1
C2E51D	LSB-UEA2: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	A22.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2E521	LSB-UEA2: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	A22.X1:14		E	1
C2E554	LSB-UEA2: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	A22.X1:14		E	1
C2E557	LSB-UEA2: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A22.X1:14		E	1
C2E559	LSB-UEA2: Switching output A4 supply voltage missing error indication on display Check line and fuse	A22.X1:14		E	1
C2E572	LSB-UEA2: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A22.X1:14		E	1
C2E612	LSB-UEA2: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A22.X1:15		E	1
C2E61A	LSB-UEA2: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	A22.X1:15		E	1
C2E61B	LSB-UEA2: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	A22.X1:15		E	1
C2E61C	LSB-UEA2: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A22.X1:15		E	1
C2E61D	LSB-UEA2: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	A22.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2E621	LSB-UEA2: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	A22.X1:15		E	1
C2E654	LSB-UEA2: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	A22.X1:15		E	1
C2E657	LSB-UEA2: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A22.X1:15		E	1
C2E659	LSB-UEA2: Switching output A5 supply voltage missing error indication on display Check line and fuse	A22.X1:15		E	1
C2E672	LSB-UEA2: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A22.X1:15		E	1
C2E712	LSB-UEA2: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A22.X1:16		E	1
C2E71A	LSB-UEA2: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	A22.X1:16		E	1
C2E71B	LSB-UEA2: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	A22.X1:16		E	1
C2E71C	LSB-UEA2: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A22.X1:16		E	1
C2E71D	LSB-UEA2: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	A22.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2E721	LSB-UEA2: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	A22.X1:16		E	1
C2E754	LSB-UEA2: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	A22.X1:16		E	1
C2E757	LSB-UEA2: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A22.X1:16		E	1
C2E759	LSB-UEA2: Switching output A6 supply voltage missing error indication on display Check line and fuse	A22.X1:16		E	1
C2E772	LSB-UEA2: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A22.X1:16		E	1
C2E812	LSB-UEA2: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A22.X1:17		E	1
C2E81A	LSB-UEA2: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	A22.X1:17		E	1
C2E81B	LSB-UEA2: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	A22.X1:17		E	1
C2E81C	LSB-UEA2: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A22.X1:17		E	1
C2E81D	LSB-UEA2: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	A22.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2E821	LSB-UEA2: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	A22.X1:17		E	1
C2E854	LSB-UEA2: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	A22.X1:17		E	1
C2E857	LSB-UEA2: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A22.X1:17		E	1
C2E859	LSB-UEA2: Switching output A7 supply voltage missing error indication on display Check line and fuse	A22.X1:17		E	1
C2E872	LSB-UEA2: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A22.X1:17		E	1
C2F001	LSB-UEA2: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module	A22		E	2
C2F006	LSB-UEA2: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module	A22		E	2
C2F013	LSB-UEA2: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A22		E	2
C2F016	LSB-UEA2: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A22		E	2
C2F031	LSB-UEA2: System error OS-CPU0 CPU-test faulty Module reset Replace module	A22		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2F050	LSB-UEA2: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software	A22		E	2
C2F068	LSB-UEA2: System error OS-CPU0 impermissible interrupt Module reset Replace module	A22		E	2
C2F070	LSB-UEA2: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module	A22		E	2
C2F071	LSB-UEA2: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module	A22		E	2
C2F073	LSB-UEA2: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A22		E	2
C2F075	LSB-UEA2: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module	A22		E	2
C2F078	LSB-UEA2: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service	A22		E	1
C2F080	LSB-UEA2: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module	A22		E	2
C2F082	LSB-UEA2: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A22		E	2
C2F088	LSB-UEA2: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module	A22		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2F089	LSB-UEA2: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module	A22		E	2
C2F090	LSB-UEA2: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module	A22		E	2
C2F0C1	LSB-UEA2: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A22		E	1
C2F113	LSB-UEA2: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A22		E	2
C2F15A	LSB-UEA2: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module	A22		E	2
C2F15B	LSB-UEA2: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane	A22		E	2
C2F170	LSB-UEA2: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors	A22		E	2
C2F175	LSB-UEA2: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit	A22		E	2
C2F1AC	LSB-UEA2: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)	A22		E	2
C2FA00	LSB-UEA2: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A22.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2FA01	LSB-UEA2: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A22.X3:2/3		E	1
C2FA02	LSB-UEA2: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A22.X3:2/3		E	1
C2FA04	LSB-UEA2: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A22.X3:2/3		E	1
C2FA05	LSB-UEA2: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A22.X3:2/3		E	1
C2FA06	LSB-UEA2: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A22.X3:2/3		E	2
C2FA11	LSB-UEA2: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A22.X3:2/3		E	1
C2FA32	LSB-UEA2: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A22.X3:2/3		E	1
C2FA40	LSB-UEA2: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A22.X3:2/3		E	1
C2FA41	LSB-UEA2: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A22.X3:2/3		E	1
C2FB00	LSB-UEA2: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A22.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C2FB01	LSB-UEA2: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A22.X3:4/5		E	1
C2FB02	LSB-UEA2: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A22.X3:4/5		E	1
C2FB04	LSB-UEA2: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A22.X3:4/5		E	1
C2FB05	LSB-UEA2: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A22.X3:4/5		E	1
C2FB06	LSB-UEA2: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A22.X3:4/5		E	2
C2FB11	LSB-UEA2: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A22.X3:4/5		E	1
C2FB32	LSB-UEA2: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A22.X3:4/5		E	1
C2FB40	LSB-UEA2: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A22.X3:4/5		E	1
C2FB41	LSB-UEA2: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A22.X3:4/5		E	1
C3301A	LSB-UEA3: control winch 1 Winch brake, release switch winch turn sensor short circuit after grou No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A23		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3301B	LSB-UEA3: control winch 1 Winch brake, release winch turn sensor has short circuit after Plus No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A23		E	
C3301C	LSB-UEA3: control winch 1 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A23		B	
C3311A	LSB-UEA3: control winch 2 Winch brake, release switch winch turn sensor short circuit after grou No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A23		E	
C3311B	LSB-UEA3: control winch 2 Winch brake, release winch turn sensor has short circuit after Plus No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A23		E	
C3311C	LSB-UEA3: control winch 2 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A23		B	
C3321A	LSB-UEA3: control winch 3 Winch brake, release switch winch turn sensor short circuit after grou No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A23		E	
C3321B	LSB-UEA3: control winch 3 Winch brake, release winch turn sensor has short circuit after Plus No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A23		E	
C3321C	LSB-UEA3: control winch 3 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A23		B	
C3331A	LSB-UEA3: control winch 4 Winch brake, release switch winch turn sensor short circuit after grou No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A23		E	
C3331B	LSB-UEA3: control winch 4 Winch brake, release winch turn sensor has short circuit after Plus No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A23		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3331C	LSB-UEA3: control winch 4 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A23		B	
C3341A	LSB-UEA3: control winch 5 Winch brake, release switch winch turn sensor short circuit after grou No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A23		E	
C3341B	LSB-UEA3: control winch 5 Winch brake, release winch turn sensor has short circuit after Plus No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A23		E	
C3341C	LSB-UEA3: control winch 5 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A23		B	
C3351A	LSB-UEA3: control winch 6 Winch brake, release switch winch turn sensor short circuit after grou No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A23		E	
C3351B	LSB-UEA3: control winch 6 Winch brake, release winch turn sensor has short circuit after Plus No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A23		E	
C3351C	LSB-UEA3: control winch 6 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A23		B	
C33800	LSB-UEA3: control slewing No swing movement recognised with selected swing gear Error is shown as system error Check incremental sensor, possibly check hydr. and slewing gear motors	A23		E	1
C3381C	LSB-UEA3: control slewing Interruption bus connection(s)Actuation / release, zero force Shut off of all turning movements Check LSB and CAN Bus, Master switch in zero position	A23		E	1
C33825	LSB-UEA3: control slewing Modification of counter value slewing gear with brake applied Error is shown as system error Check incremental sensor, possibly check hydr. and slewing gear motors	A23		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C33852	LSB-UEA3: control slewing Shut off turning due to initial diagnostics Error is shown as system error	A23		E	1
C33853	LSB-UEA3: control slewing Shut off coasting due to initial diagnostics Error is shown as system error	A23		E	1
C33854	LSB-UEA3: control slewing Monitoring E1, Diagnostics for slewing brake has interruption Slewing brake cannot be released Check wiring. If slewing brake applied selected then < 2V must be present on input	A23		E	1
C33855	LSB-UEA3: control slewing Valve line slewing brake to TE1 has short circuit after ground Error is shown as system error check wiring	A23		E	1
C33856	LSB-UEA3: control slewing Valve line slewing brake to A3 has short circuit after Ubatt Error is shown as system error check wiring	A23		E	1
C33857	LSB-UEA3: control slewing Button "Slewing coasting" has short circuit after supply voltage Error is shown as system error check wiring	A23		E	1
C33880	LSB-UEA3: control slewing Modification of counter value, speed < set value, check slewing gear Error is shown as system error Check incremental sensor, possibly check hydr. and slewing gear motors	A23		E	1
C33881	LSB-UEA3: control slewing Modification of counter value, speed > set value, check slewing gear Error is shown as system error Check incremental sensor, possibly check hydr. and slewing gear motors	A23		E	1
C35825	LSB-UEA3: operation slewing Shut-off free-swing swing gear crane engine not functioning operational shut down Start crane engine. For test purposes actuate bridging "without engine" (control ON without engine).	A23		B	
C35826	LSB-UEA3: operation slewing Switch-off foot switch swing gear free-sw. stick./actuated with start Freewheel not permitted Release foot button (on input must be a "0")	A23		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C35827	LSB-UEA3: operation slewing Shut off coasting slewing gear seat contact operational shut down sit down (seat limit switch) or dead man (in master switch) or check LICCON input, sensor lines, sensor	A23		B	
C3582A	LSB-UEA3: operation slewing Shut off Turning - Freewheel active No turning with master switch possible Release foot button on floor of superstructure cab (do not press)	A23		B	
C3582D	LSB-UEA3: operation slewing Shut off Freewheel slewing gear radio operation Freewheel is deactivated change in crane mode	A23		B	
C3583F	LSB-UEA3: operation slewing Shut off Coasting button mandatory zero position Shut off coasting Release foot button on floor of superstructure cab (do not press)	A23		B	
C36108	LSB-UEA3: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A23		E	
C37007	LSB-UEA3: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A23		B	
C37019	LSB-UEA3: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A23		E	
C37090	LSB-UEA3: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A23		E	
C39900	LSB-UEA3: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A23		E	2
C39901	LSB-UEA3: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A23		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C39902	LSB-UEA3: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A23		E	1
C39904	LSB-UEA3: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A23		E	1
C39905	LSB-UEA3: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A23		E	1
C39906	LSB-UEA3: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A23		E	2
C39907	LSB-UEA3: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A23		E	1
C39911	LSB-UEA3: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A23		E	2
C3C0C3	LSB-UEA3: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A23		B	
C3C0C4	LSB-UEA3: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A23		B	
C3C0C5	LSB-UEA3: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A23		B	
C3C0C6	LSB-UEA3: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A23		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3C0C7	LSB-UEA3: Diagnostics syst. band end/adj. program F5: Slewing brake is still open Adj. program is interrupted, all movements turned off Release slewing gear brake by act. F3-Button on key pad 2	A23		B	
C3C0CF	LSB-UEA3: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A23		B	
C3C0D0	LSB-UEA3: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A23		B	
C3D502	LSB-UEA3: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A23.X2:1		E	1
C3D503	LSB-UEA3: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A23.X2:1		E	1
C3D513	LSB-UEA3: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	A23.X2:1		E	1
C3D602	LSB-UEA3: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A23.X2:2		E	1
C3D603	LSB-UEA3: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A23.X2:2		E	1
C3D613	LSB-UEA3: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	A23.X2:2		E	1
C3D702	LSB-UEA3: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A23.X2:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3D703	LSB-UEA3: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A23.X2:4		E	1
C3D713	LSB-UEA3: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	A23.X2:4		E	1
C3D802	LSB-UEA3: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A23.X2:5		E	1
C3D803	LSB-UEA3: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A23.X2:5		E	1
C3D813	LSB-UEA3: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	A23.X2:5		E	1
C3D902	LSB-UEA3: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A23.X2:7		E	1
C3D903	LSB-UEA3: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A23.X2:7		E	1
C3D913	LSB-UEA3: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	A23.X2:7		E	1
C3DA02	LSB-UEA3: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A23.X2:8		E	1
C3DA03	LSB-UEA3: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A23.X2:8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3DA13	LSB-UEA3: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	A23.X2:8		E	1
C3DB02	LSB-UEA3: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A23.X2:10		E	1
C3DB03	LSB-UEA3: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A23.X2:10		E	1
C3DB13	LSB-UEA3: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	A23.X2:10		E	1
C3DC02	LSB-UEA3: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A23.X2:11		E	1
C3DC03	LSB-UEA3: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A23.X2:11		E	1
C3DC13	LSB-UEA3: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	A23.X2:11		E	1
C3DD6F	LSB-UEA3: Digital input E8 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A23.X2:18		E	1
C3DE6F	LSB-UEA3: Digital input E9 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A23.X2:19		E	1
C3DF6F	LSB-UEA3: Digital input E10 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A23.X2:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E06F	LSB-UEA3: Digital input E11 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A23.X2:21		E	1
C3E112	LSB-UEA3: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A23.X1:10		E	1
C3E11A	LSB-UEA3: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	A23.X1:10		E	1
C3E11B	LSB-UEA3: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	A23.X1:10		E	1
C3E11C	LSB-UEA3: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A23.X1:10		E	1
C3E11D	LSB-UEA3: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	A23.X1:10		E	1
C3E121	LSB-UEA3: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	A23.X1:10		E	1
C3E154	LSB-UEA3: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	A23.X1:10		E	1
C3E157	LSB-UEA3: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A23.X1:10		E	1
C3E159	LSB-UEA3: Switching output A0 supply voltage missing error indication on display Check line and fuse	A23.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E172	LSB-UEA3: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A23.X1:10		E	1
C3E212	LSB-UEA3: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A23.X1:11		E	1
C3E21A	LSB-UEA3: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	A23.X1:11		E	1
C3E21B	LSB-UEA3: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	A23.X1:11		E	1
C3E21C	LSB-UEA3: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A23.X1:11		E	1
C3E21D	LSB-UEA3: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	A23.X1:11		E	1
C3E221	LSB-UEA3: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	A23.X1:11		E	1
C3E254	LSB-UEA3: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	A23.X1:11		E	1
C3E257	LSB-UEA3: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A23.X1:11		E	1
C3E259	LSB-UEA3: Switching output A1 supply voltage missing error indication on display Check line and fuse	A23.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E272	LSB-UEA3: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A23.X1:11		E	1
C3E312	LSB-UEA3: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A23.X1:12		E	1
C3E31A	LSB-UEA3: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	A23.X1:12		E	1
C3E31B	LSB-UEA3: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	A23.X1:12		E	1
C3E31C	LSB-UEA3: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A23.X1:12		E	1
C3E31D	LSB-UEA3: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	A23.X1:12		E	1
C3E321	LSB-UEA3: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	A23.X1:12		E	1
C3E354	LSB-UEA3: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	A23.X1:12		E	1
C3E357	LSB-UEA3: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A23.X1:12		E	1
C3E359	LSB-UEA3: Switching output A2 supply voltage missing error indication on display Check line and fuse	A23.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E372	LSB-UEA3: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A23.X1:12		E	1
C3E412	LSB-UEA3: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A23.X1:13		E	1
C3E41A	LSB-UEA3: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	A23.X1:13		E	1
C3E41B	LSB-UEA3: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	A23.X1:13		E	1
C3E41C	LSB-UEA3: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A23.X1:13		E	1
C3E41D	LSB-UEA3: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	A23.X1:13		E	1
C3E421	LSB-UEA3: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	A23.X1:13		E	1
C3E454	LSB-UEA3: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	A23.X1:13		E	1
C3E457	LSB-UEA3: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A23.X1:13		E	1
C3E459	LSB-UEA3: Switching output A3 supply voltage missing error indication on display Check line and fuse	A23.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E472	LSB-UEA3: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A23.X1:13		E	1
C3E512	LSB-UEA3: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A23.X1:14		E	1
C3E51A	LSB-UEA3: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	A23.X1:14		E	1
C3E51B	LSB-UEA3: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	A23.X1:14		E	1
C3E51C	LSB-UEA3: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A23.X1:14		E	1
C3E51D	LSB-UEA3: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	A23.X1:14		E	1
C3E521	LSB-UEA3: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	A23.X1:14		E	1
C3E554	LSB-UEA3: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	A23.X1:14		E	1
C3E557	LSB-UEA3: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A23.X1:14		E	1
C3E559	LSB-UEA3: Switching output A4 supply voltage missing error indication on display Check line and fuse	A23.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E572	LSB-UEA3: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A23.X1:14		E	1
C3E612	LSB-UEA3: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A23.X1:15		E	1
C3E61A	LSB-UEA3: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	A23.X1:15		E	1
C3E61B	LSB-UEA3: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	A23.X1:15		E	1
C3E61C	LSB-UEA3: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A23.X1:15		E	1
C3E61D	LSB-UEA3: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	A23.X1:15		E	1
C3E621	LSB-UEA3: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	A23.X1:15		E	1
C3E654	LSB-UEA3: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	A23.X1:15		E	1
C3E657	LSB-UEA3: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A23.X1:15		E	1
C3E659	LSB-UEA3: Switching output A5 supply voltage missing error indication on display Check line and fuse	A23.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E672	LSB-UEA3: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A23.X1:15		E	1
C3E712	LSB-UEA3: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A23.X1:16		E	1
C3E71A	LSB-UEA3: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	A23.X1:16		E	1
C3E71B	LSB-UEA3: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	A23.X1:16		E	1
C3E71C	LSB-UEA3: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A23.X1:16		E	1
C3E71D	LSB-UEA3: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	A23.X1:16		E	1
C3E721	LSB-UEA3: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	A23.X1:16		E	1
C3E754	LSB-UEA3: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	A23.X1:16		E	1
C3E757	LSB-UEA3: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A23.X1:16		E	1
C3E759	LSB-UEA3: Switching output A6 supply voltage missing error indication on display Check line and fuse	A23.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E772	LSB-UEA3: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A23.X1:16		E	1
C3E812	LSB-UEA3: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A23.X1:17		E	1
C3E81A	LSB-UEA3: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	A23.X1:17		E	1
C3E81B	LSB-UEA3: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	A23.X1:17		E	1
C3E81C	LSB-UEA3: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A23.X1:17		E	1
C3E81D	LSB-UEA3: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	A23.X1:17		E	1
C3E821	LSB-UEA3: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	A23.X1:17		E	1
C3E854	LSB-UEA3: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	A23.X1:17		E	1
C3E857	LSB-UEA3: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A23.X1:17		E	1
C3E859	LSB-UEA3: Switching output A7 supply voltage missing error indication on display Check line and fuse	A23.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3E872	LSB-UEA3: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A23.X1:17		E	1
C3F001	LSB-UEA3: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module	A23		E	2
C3F006	LSB-UEA3: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module	A23		E	2
C3F013	LSB-UEA3: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A23		E	2
C3F016	LSB-UEA3: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A23		E	2
C3F031	LSB-UEA3: System error OS-CPU0 CPU-test faulty Module reset Replace module	A23		E	2
C3F050	LSB-UEA3: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software	A23		E	2
C3F068	LSB-UEA3: System error OS-CPU0 impermissible interrupt Module reset Replace module	A23		E	2
C3F070	LSB-UEA3: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module	A23		E	2
C3F071	LSB-UEA3: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module	A23		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3F073	LSB-UEA3: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A23		E	2
C3F075	LSB-UEA3: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module	A23		E	2
C3F078	LSB-UEA3: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service	A23		E	1
C3F080	LSB-UEA3: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module	A23		E	2
C3F082	LSB-UEA3: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A23		E	2
C3F088	LSB-UEA3: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module	A23		E	2
C3F089	LSB-UEA3: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module	A23		E	2
C3F090	LSB-UEA3: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module	A23		E	2
C3F0C1	LSB-UEA3: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A23		E	1
C3F113	LSB-UEA3: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A23		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3F15A	LSB-UEA3: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module	A23		E	2
C3F15B	LSB-UEA3: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane	A23		E	2
C3F170	LSB-UEA3: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors	A23		E	2
C3F175	LSB-UEA3: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit	A23		E	2
C3F1AC	LSB-UEA3: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)	A23		E	2
C3FA00	LSB-UEA3: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A23.X3:2/3		E	1
C3FA01	LSB-UEA3: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A23.X3:2/3		E	1
C3FA02	LSB-UEA3: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A23.X3:2/3		E	1
C3FA04	LSB-UEA3: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A23.X3:2/3		E	1
C3FA05	LSB-UEA3: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A23.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3FA06	LSB-UEA3: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A23.X3:2/3		E	2
C3FA11	LSB-UEA3: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A23.X3:2/3		E	1
C3FA32	LSB-UEA3: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A23.X3:2/3		E	1
C3FA40	LSB-UEA3: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A23.X3:2/3		E	1
C3FA41	LSB-UEA3: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A23.X3:2/3		E	1
C3FB00	LSB-UEA3: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A23.X3:4/5		E	1
C3FB01	LSB-UEA3: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A23.X3:4/5		E	1
C3FB02	LSB-UEA3: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A23.X3:4/5		E	1
C3FB04	LSB-UEA3: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A23.X3:4/5		E	1
C3FB05	LSB-UEA3: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A23.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C3FB06	LSB-UEA3: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A23.X3:4/5		E	2
C3FB11	LSB-UEA3: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A23.X3:4/5		E	1
C3FB32	LSB-UEA3: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A23.X3:4/5		E	1
C3FB40	LSB-UEA3: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A23.X3:4/5		E	1
C3FB41	LSB-UEA3: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A23.X3:4/5		E	1
C47007	LSB-UEA4: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A24		B	
C47019	LSB-UEA4: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A24		E	
C47090	LSB-UEA4: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A24		E	
C73202	LSB-UEA7: control winch 3 hydraulic circuit pressure sensor defective/missing No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A27		E	
C7320A	LSB-UEA7: control winch 3 Pressure too high when pump is not actuated No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A27		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7320B	LSB-UEA7: control winch 3 Winch turn sensor erroneous / missing No actuation of pump and no act. of winch brake Check winch turn sensor. Check LSB-Bus	A27		E	
C7320C	LSB-UEA7: control winch 3 Repl. pressure supply missing / too low during winch movement Stop winch Check signal. Check pr. switch. Check hydr, replen. pressure supply	A27		E	
C7320D	LSB-UEA7: control winch 3 Winch brake, ground switch open during winch movement Stop winch Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A27		E	
C7320E	LSB-UEA7: control winch 3 Winch brake, ground switch does not close / closes too late Delayed actuation of winch. No actuation of winch. Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A27		E	
C7320F	LSB-UEA7: control winch 3 Winch brake, ground switch report short circuit after ground (Start) No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A27		E	
C73216	LSB-UEA7: control winch 3 Winch brake, ground switch report short circuit after Plus (Start) No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A27		E	
C7321C	LSB-UEA7: control winch 3 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A27		B	
C73220	LSB-UEA7: control winch 3 Winch brake, ground switch report has short circuit after ground Error message: second shut off channel ineffective Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A27		E	
C73221	LSB-UEA7: control winch 3 Emerg. shut off active No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A27		E	
C73223	LSB-UEA7: control winch 3 Outlet error control outlet winch, read out system error (inactive) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A27		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C73224	LSB-UEA7: control winch 3 Monitoring release brake pressure, short circuit after Plus Active act. of emerg. valve only at master switch deflection. Error message Check signal line for short circuit. Check wiring, switch on valve	A27		E	
C73225	LSB-UEA7: control winch 3 Monitoring release brake pressure interruption/short circuit after gro Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A27		E	
C73226	LSB-UEA7: control winch 3 Rotational speed too low, current nominal value fallen below error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A27		E	
C73227	LSB-UEA7: control winch 3 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A27		E	
C73228	LSB-UEA7: control winch 3 Permissible rotational speed exceeded, emergency shut off Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A27		E	
C73229	LSB-UEA7: control winch 3 Monitoring rotational speed not possible, winch turn sensor missing Error message. Shut down winch by closing winch brake Check winch turn sensor. Check LSB-Bus	A27		E	
C7322B	LSB-UEA7: control winch 3 Check valve for pump 23 jamming, interruption or short circuit to mass Output of error Check valves for switchover from winch to crawler	A27		E	
C7322C	LSB-UEA7: control winch 3 Check valve for pump 23 jamming or short circuit to VCC Issue of error, pump 23 not conveying oil Check check valve for pump 23, check wiring	A27		E	1
C7322D	LSB-UEA7: control winch 3 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A27		E	
C7322E	LSB-UEA7: control winch 3 Repl. pressure switch implausible to pressure sensor signal (analog) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A27		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C73241	LSB-UEA7: control winch 3 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A27		E	
C73242	LSB-UEA7: control winch 3 Rotation movement at non-actuated winch brake Error message. Check winch brake. Check winch turn sensor(installation)	A27		E	
C73246	LSB-UEA7: control winch 3 Signal Replenishing pr. sensor short circuit after ground or interrupt Operation conditional switch off, may not be shunted replace sensor through new part	A27		E	
C73247	LSB-UEA7: control winch 3 Signal Brake pr. sensor short circuit after ground or interruption	A27		E	
C7325F	LSB-UEA7: control winch 3 Shut off master switch zero position forced Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A27		B	
C73621	LSB-UEA7: control telescoping Emerg. shut off active	A27		B	
C73C0A	LSB-UEA7: Control crawler Pressure hydr. circuit crawler left too high if pump is not actuated	A27		E	
C73C0B	LSB-UEA7: Control crawler Pressure hydr. circuit crawler right too high if pump is not actuated	A27		E	
C73C1C	LSB-UEA7: Control crawler Interruption bus connection(s)Actuation / release, zero force Output of error, crane function is not selected. Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A27		E	1
C73C2B	LSB-UEA7: Control crawler Check valve for pump 23 jamming, interruption or short circuit to mass Issue of error, pressure at winch 3 with crawler selected Check check valve for pump 23, check wiring	A27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C73C59	LSB-UEA7: Control crawler No report (diagnostics line) ground switch travel gear brake	A27		E	1
C73C5A	LSB-UEA7: Control crawler No report ground switch travel gear brake at actuation	A27		E	1
C76108	LSB-UEA7: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A27		E	
C762B0	LSB-UEA7: operation instruments crane operators cab Button Check winch gear oil level stuck or actuated at start Output of error Release button or check wiring	A27		E	
C77007	LSB-UEA7: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A27		E	1
C77019	LSB-UEA7: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A27		E	1
C77090	LSB-UEA7: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A27		E	1
C79900	LSB-UEA7: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A27		E	2
C79901	LSB-UEA7: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A27		E	2
C79902	LSB-UEA7: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A27		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C79904	LSB-UEA7: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A27		E	1
C79905	LSB-UEA7: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A27		E	1
C79906	LSB-UEA7: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A27		E	2
C79907	LSB-UEA7: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A27		E	1
C79911	LSB-UEA7: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A27		E	2
C7C089	LSB-UEA7: Diagnostics syst. band end/adj. program Test program winch brake current not yet carried out Adj. program is interrupted, all movements turned off Set pump currents	A27		B	
C7C092	LSB-UEA7: Diagnostics syst. band end/adj. program F57: Rapid gear crawler selected	A27		B	
C7C093	LSB-UEA7: Diagnostics syst. band end/adj. program F58: Parallel op. crawler selected	A27		B	
C7C094	LSB-UEA7: Diagnostics syst. band end/adj. program F59: Max. speed crawler not determined - carry out Test 678	A27		B	
C7C095	LSB-UEA7: Diagnostics syst. band end/adj. program F60: Min. speed crawler not reached	A27		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7C096	LSB-UEA7: Diagnostics syst. band end/adj. program F74: Rapid gear crawler not selected	A27		B	
C7C0C3	LSB-UEA7: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A27		B	
C7C0C4	LSB-UEA7: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A27		B	
C7C0C5	LSB-UEA7: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A27		B	
C7C0C6	LSB-UEA7: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A27		B	
C7C0C8	LSB-UEA7: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low Adj. program is interrupted, all movements turned off Increase Qmin Pump (See Specification Pump)	A27		B	
C7C0C9	LSB-UEA7: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high Adj. program is interrupted, all movements turned off Decrease Qmin Pump (See Specification Pump)	A27		B	
C7C0CA	LSB-UEA7: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded Adj. program is interrupted, all movements turned off Pressure threshold was not recognized, try again (consult)	A27		B	
C7C0CB	LSB-UEA7: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range Adj. program is interrupted, all movements turned off No adj. value was found within current limits. Check hydraulic	A27		B	
C7C0CC	LSB-UEA7: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100% Adj. program is interrupted, all movements turned off Deflect master switch during adj. phase 100%	A27		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7C0CF	LSB-UEA7: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A27		B	
C7C0D0	LSB-UEA7: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A27		B	
C7C0D1	LSB-UEA7: Diagnostics syst. band end/adj. program F15: Angle sensor placement section: Lower limit angle reached Adj. program is interrupted, all movements turned off Carry out luff up movement until perm. tele angle is reached	A27		B	
C7C0DA	LSB-UEA7: Diagnostics syst. band end/adj. program F24: Pump flows not completely set Adj. program is interrupted, all movements turned off Set pump currents	A27		B	
C7C0E8	LSB-UEA7: Diagnostics syst. band end/adj. program F38: Direction change over / steering change over active	A27		B	
C7D502	LSB-UEA7: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A27.X2:1		E	1
C7D503	LSB-UEA7: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A27.X2:1		E	1
C7D513	LSB-UEA7: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	A27.X2:1		E	1
C7D602	LSB-UEA7: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A27.X2:2		E	1
C7D603	LSB-UEA7: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A27.X2:2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7D613	LSB-UEA7: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	A27.X2:2		E	1
C7D702	LSB-UEA7: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A27.X2:4		E	1
C7D703	LSB-UEA7: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A27.X2:4		E	1
C7D713	LSB-UEA7: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	A27.X2:4		E	1
C7D802	LSB-UEA7: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A27.X2:5		E	1
C7D803	LSB-UEA7: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A27.X2:5		E	1
C7D813	LSB-UEA7: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	A27.X2:5		E	1
C7D902	LSB-UEA7: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A27.X2:7		E	1
C7D903	LSB-UEA7: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A27.X2:7		E	1
C7D913	LSB-UEA7: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	A27.X2:7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7DA02	LSB-UEA7: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A27.X2:8		E	1
C7DA03	LSB-UEA7: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A27.X2:8		E	1
C7DA13	LSB-UEA7: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	A27.X2:8		E	1
C7DB02	LSB-UEA7: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A27.X2:10		E	1
C7DB03	LSB-UEA7: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A27.X2:10		E	1
C7DB13	LSB-UEA7: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	A27.X2:10		E	1
C7DC02	LSB-UEA7: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A27.X2:11		E	1
C7DC03	LSB-UEA7: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A27.X2:11		E	1
C7DC13	LSB-UEA7: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	A27.X2:11		E	1
C7E112	LSB-UEA7: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A27.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7E11A	LSB-UEA7: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	A27.X1:10		E	1
C7E11B	LSB-UEA7: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	A27.X1:10		E	1
C7E11C	LSB-UEA7: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A27.X1:10		E	1
C7E11D	LSB-UEA7: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	A27.X1:10		E	1
C7E121	LSB-UEA7: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	A27.X1:10		E	1
C7E154	LSB-UEA7: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	A27.X1:10		E	1
C7E157	LSB-UEA7: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A27.X1:10		E	1
C7E159	LSB-UEA7: Switching output A0 supply voltage missing error indication on display Check line and fuse	A27.X1:10		E	1
C7E172	LSB-UEA7: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A27.X1:10		E	1
C7E212	LSB-UEA7: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A27.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7E21A	LSB-UEA7: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	A27.X1:11		E	1
C7E21B	LSB-UEA7: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	A27.X1:11		E	1
C7E21C	LSB-UEA7: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A27.X1:11		E	1
C7E21D	LSB-UEA7: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	A27.X1:11		E	1
C7E221	LSB-UEA7: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	A27.X1:11		E	1
C7E254	LSB-UEA7: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	A27.X1:11		E	1
C7E257	LSB-UEA7: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A27.X1:11		E	1
C7E259	LSB-UEA7: Switching output A1 supply voltage missing error indication on display Check line and fuse	A27.X1:11		E	1
C7E272	LSB-UEA7: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A27.X1:11		E	1
C7E312	LSB-UEA7: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A27.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7E31A	LSB-UEA7: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	A27.X1:12		E	1
C7E31B	LSB-UEA7: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	A27.X1:12		E	1
C7E31C	LSB-UEA7: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A27.X1:12		E	1
C7E31D	LSB-UEA7: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	A27.X1:12		E	1
C7E321	LSB-UEA7: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	A27.X1:12		E	1
C7E354	LSB-UEA7: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	A27.X1:12		E	1
C7E357	LSB-UEA7: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A27.X1:12		E	1
C7E359	LSB-UEA7: Switching output A2 supply voltage missing error indication on display Check line and fuse	A27.X1:12		E	1
C7E372	LSB-UEA7: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A27.X1:12		E	1
C7E412	LSB-UEA7: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A27.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7E41A	LSB-UEA7: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	A27.X1:13		E	1
C7E41B	LSB-UEA7: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	A27.X1:13		E	1
C7E41C	LSB-UEA7: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A27.X1:13		E	1
C7E41D	LSB-UEA7: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	A27.X1:13		E	1
C7E421	LSB-UEA7: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	A27.X1:13		E	1
C7E454	LSB-UEA7: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	A27.X1:13		E	1
C7E457	LSB-UEA7: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A27.X1:13		E	1
C7E459	LSB-UEA7: Switching output A3 supply voltage missing error indication on display Check line and fuse	A27.X1:13		E	1
C7E472	LSB-UEA7: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A27.X1:13		E	1
C7E512	LSB-UEA7: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A27.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7E51A	LSB-UEA7: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	A27.X1:14		E	1
C7E51B	LSB-UEA7: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	A27.X1:14		E	1
C7E51C	LSB-UEA7: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A27.X1:14		E	1
C7E51D	LSB-UEA7: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	A27.X1:14		E	1
C7E521	LSB-UEA7: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	A27.X1:14		E	1
C7E554	LSB-UEA7: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	A27.X1:14		E	1
C7E557	LSB-UEA7: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A27.X1:14		E	1
C7E559	LSB-UEA7: Switching output A4 supply voltage missing error indication on display Check line and fuse	A27.X1:14		E	1
C7E572	LSB-UEA7: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A27.X1:14		E	1
C7E612	LSB-UEA7: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A27.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7E61A	LSB-UEA7: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	A27.X1:15		E	1
C7E61B	LSB-UEA7: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	A27.X1:15		E	1
C7E61C	LSB-UEA7: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A27.X1:15		E	1
C7E61D	LSB-UEA7: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	A27.X1:15		E	1
C7E621	LSB-UEA7: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	A27.X1:15		E	1
C7E654	LSB-UEA7: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	A27.X1:15		E	1
C7E657	LSB-UEA7: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A27.X1:15		E	1
C7E659	LSB-UEA7: Switching output A5 supply voltage missing error indication on display Check line and fuse	A27.X1:15		E	1
C7E672	LSB-UEA7: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A27.X1:15		E	1
C7E712	LSB-UEA7: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A27.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7E71A	LSB-UEA7: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	A27.X1:16		E	1
C7E71B	LSB-UEA7: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	A27.X1:16		E	1
C7E71C	LSB-UEA7: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A27.X1:16		E	1
C7E71D	LSB-UEA7: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	A27.X1:16		E	1
C7E721	LSB-UEA7: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	A27.X1:16		E	1
C7E754	LSB-UEA7: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	A27.X1:16		E	1
C7E757	LSB-UEA7: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A27.X1:16		E	1
C7E759	LSB-UEA7: Switching output A6 supply voltage missing error indication on display Check line and fuse	A27.X1:16		E	1
C7E772	LSB-UEA7: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A27.X1:16		E	1
C7E812	LSB-UEA7: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A27.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7E81A	LSB-UEA7: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	A27.X1:17		E	1
C7E81B	LSB-UEA7: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	A27.X1:17		E	1
C7E81C	LSB-UEA7: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A27.X1:17		E	1
C7E81D	LSB-UEA7: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	A27.X1:17		E	1
C7E821	LSB-UEA7: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	A27.X1:17		E	1
C7E854	LSB-UEA7: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	A27.X1:17		E	1
C7E857	LSB-UEA7: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A27.X1:17		E	1
C7E859	LSB-UEA7: Switching output A7 supply voltage missing error indication on display Check line and fuse	A27.X1:17		E	1
C7E872	LSB-UEA7: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A27.X1:17		E	1
C7F001	LSB-UEA7: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module	A27		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7F006	LSB-UEA7: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module	A27		E	2
C7F013	LSB-UEA7: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A27		E	2
C7F016	LSB-UEA7: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A27		E	2
C7F031	LSB-UEA7: System error OS-CPU0 CPU-test faulty Module reset Replace module	A27		E	2
C7F050	LSB-UEA7: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software	A27		E	2
C7F068	LSB-UEA7: System error OS-CPU0 impermissible interrupt Module reset Replace module	A27		E	2
C7F070	LSB-UEA7: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module	A27		E	2
C7F071	LSB-UEA7: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module	A27		E	2
C7F073	LSB-UEA7: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A27		E	2
C7F075	LSB-UEA7: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module	A27		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7F078	LSB-UEA7: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service	A27		E	1
C7F080	LSB-UEA7: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module	A27		E	2
C7F082	LSB-UEA7: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A27		E	2
C7F088	LSB-UEA7: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module	A27		E	2
C7F089	LSB-UEA7: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module	A27		E	2
C7F090	LSB-UEA7: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module	A27		E	2
C7F0C1	LSB-UEA7: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A27		E	1
C7F113	LSB-UEA7: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A27		E	2
C7F15A	LSB-UEA7: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module	A27		E	2
C7F15B	LSB-UEA7: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane	A27		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7F170	LSB-UEA7: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors	A27		E	2
C7F175	LSB-UEA7: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit	A27		E	2
C7F1AC	LSB-UEA7: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)	A27		E	2
C7FA00	LSB-UEA7: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A27.X3:2/3		E	1
C7FA01	LSB-UEA7: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A27.X3:2/3		E	1
C7FA02	LSB-UEA7: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A27.X3:2/3		E	1
C7FA04	LSB-UEA7: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A27.X3:2/3		E	1
C7FA05	LSB-UEA7: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A27.X3:2/3		E	1
C7FA06	LSB-UEA7: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A27.X3:2/3		E	2
C7FA11	LSB-UEA7: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A27.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7FA32	LSB-UEA7: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A27.X3:2/3		E	1
C7FA40	LSB-UEA7: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A27.X3:2/3		E	1
C7FA41	LSB-UEA7: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A27.X3:2/3		E	1
C7FB00	LSB-UEA7: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A27.X3:4/5		E	1
C7FB01	LSB-UEA7: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A27.X3:4/5		E	1
C7FB02	LSB-UEA7: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A27.X3:4/5		E	1
C7FB04	LSB-UEA7: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A27.X3:4/5		E	1
C7FB05	LSB-UEA7: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A27.X3:4/5		E	1
C7FB06	LSB-UEA7: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A27.X3:4/5		E	2
C7FB11	LSB-UEA7: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A27.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C7FB32	LSB-UEA7: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A27.X3:4/5		E	1
C7FB40	LSB-UEA7: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A27.X3:4/5		E	1
C7FB41	LSB-UEA7: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A27.X3:4/5		E	1
C83302	LSB-UEA8: control winch 4 hydraulic circuit pressure sensor defective/missing No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A28		E	
C8330A	LSB-UEA8: control winch 4 Pressure too high when pump is not actuated No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A28		E	
C8330B	LSB-UEA8: control winch 4 Winch turn sensor erroneous / missing No actuation of pump and no act. of winch brake Check winch turn sensor. Check LSB-Bus	A28		E	
C8330C	LSB-UEA8: control winch 4 Repl. pressure supply missing / too low during winch movement Stop winch Check signal. Check pr. switch. Check hydr, replen. pressure supply	A28		E	
C8330D	LSB-UEA8: control winch 4 Winch brake, ground switch open during winch movement Stop winch Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A28		E	
C8330E	LSB-UEA8: control winch 4 Winch brake, ground switch does not close / closes too late Delayed actuation of winch. No actuation of winch. Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A28		E	
C8330F	LSB-UEA8: control winch 4 Winch brake, ground switch report short circuit after ground (Start No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A28		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C83316	LSB-UEA8: control winch 4 Winch brake, ground switch report short circuit after Plus (Start) No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A28		E	
C8331C	LSB-UEA8: control winch 4 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A28		B	
C83320	LSB-UEA8: control winch 4 Winch brake, ground switch report has short circuit after ground Error message: second shut off channel ineffective Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A28		E	
C83321	LSB-UEA8: control winch 4 Emerg. shut off active No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A28		E	
C83323	LSB-UEA8: control winch 4 Outlet error control outlet winch, read out system error (inactive) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A28		E	
C83324	LSB-UEA8: control winch 4 Monitoring release brake pressure, short circuit after Plus Active act. of emerg. valve only at master switch deflection. Error message Check signal line for short circuit. Check wiring, switch on valve	A28		E	
C83325	LSB-UEA8: control winch 4 Monitoring release brake pressure interruption/short circuit after gro Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A28		E	
C83326	LSB-UEA8: control winch 4 Rotational speed too low, current nominal value fallen below error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A28		E	
C83327	LSB-UEA8: control winch 4 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A28		E	
C83328	LSB-UEA8: control winch 4 Permissible rotational speed exceeded, emergency shut off Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A28		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C83329	LSB-UEA8: control winch 4 Monitoring rotational speed not possible, winch turn sensor missing Error message. Shut down winch by closing winch brake Check winch turn sensor. Check LSB-Bus	A28		E	
C8332D	LSB-UEA8: control winch 4 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A28		E	
C8332E	LSB-UEA8: control winch 4 Repl. pressure switch implausible to pressure sensor signal (analog) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A28		E	
C83341	LSB-UEA8: control winch 4 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A28		E	
C83342	LSB-UEA8: control winch 4 Rotation movement at non-actuated winch brake Error message. Check winch brake. Check winch turn sensor(installation)	A28		E	
C83346	LSB-UEA8: control winch 4 Signal Replenishing pr. sensor short circuit after ground or interrupt Operation conditional switch off, may not be shunted replace sensor through new part	A28		E	
C83347	LSB-UEA8: control winch 4 Signal Brake pr. sensor short circuit after ground or interruption	A28		E	
C8335F	LSB-UEA8: control winch 4 Shut off master switch zero position forced Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A28		B	
C83C0A	LSB-UEA8: Control crawler Pressure hydr. circuit crawler left too high if pump is not actuated	A28		E	
C83C0B	LSB-UEA8: Control crawler Pressure hydr. circuit crawler right too high if pump is not actuated	A28		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C83C1C	LSB-UEA8: Control crawler Interruption bus connection(s)Actuation / release, zero force Output of error, crane function is not selected. Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A28		E	1
C83C59	LSB-UEA8: Control crawler No report (diagnostics line) ground switch travel gear brake	A28		E	1
C83C5A	LSB-UEA8: Control crawler No report ground switch travel gear brake at actuation	A28		E	1
C86108	LSB-UEA8: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A28		E	
C87007	LSB-UEA8: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A28		E	1
C87019	LSB-UEA8: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A28		E	1
C87090	LSB-UEA8: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A28		E	1
C89900	LSB-UEA8: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A28		E	2
C89901	LSB-UEA8: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A28		E	2
C89902	LSB-UEA8: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A28		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C89904	LSB-UEA8: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A28		E	1
C89905	LSB-UEA8: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A28		E	1
C89906	LSB-UEA8: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A28		E	2
C89907	LSB-UEA8: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A28		E	1
C89911	LSB-UEA8: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A28		E	2
C8C089	LSB-UEA8: Diagnostics syst. band end/adj. program Test program winch brake current not yet carried out Adj. program is interrupted, all movements turned off Set pump currents	A28		B	
C8C092	LSB-UEA8: Diagnostics syst. band end/adj. program F57: Rapid gear crawler selected	A28		B	
C8C093	LSB-UEA8: Diagnostics syst. band end/adj. program F58: Parallel op. crawler selected	A28		B	
C8C094	LSB-UEA8: Diagnostics syst. band end/adj. program F59: Max. speed crawler not determined - carry out Test 678	A28		B	
C8C095	LSB-UEA8: Diagnostics syst. band end/adj. program F60: Min. speed crawler not reached	A28		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8C096	LSB-UEA8: Diagnostics syst. band end/adj. program F74: Rapid gear crawler not selected	A28		B	
C8C0C3	LSB-UEA8: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A28		B	
C8C0C4	LSB-UEA8: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A28		B	
C8C0C5	LSB-UEA8: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A28		B	
C8C0C6	LSB-UEA8: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A28		B	
C8C0C8	LSB-UEA8: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low Adj. program is interrupted, all movements turned off Increase Qmin Pump (See Specification Pump)	A28		B	
C8C0C9	LSB-UEA8: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high Adj. program is interrupted, all movements turned off Decrease Qmin Pump (See Specification Pump)	A28		B	
C8C0CA	LSB-UEA8: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded Adj. program is interrupted, all movements turned off Pressure threshold was not recognized, try again (consult)	A28		B	
C8C0CB	LSB-UEA8: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range Adj. program is interrupted, all movements turned off No adj. value was found within current limits. Check hydraulic	A28		B	
C8C0CC	LSB-UEA8: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100% Adj. program is interrupted, all movements turned off Deflect master switch during adj. phase 100%	A28		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8C0CF	LSB-UEA8: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A28		B	
C8C0D0	LSB-UEA8: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A28		B	
C8C0D1	LSB-UEA8: Diagnostics syst. band end/adj. program F15: Angle sensor placement section: Lower limit angle reached Adj. program is interrupted, all movements turned off Carry out luff up movement until perm. tele angle is reached	A28		B	
C8C0DA	LSB-UEA8: Diagnostics syst. band end/adj. program F24: Pump flows not completely set Adj. program is interrupted, all movements turned off Set pump currents	A28		B	
C8C0E8	LSB-UEA8: Diagnostics syst. band end/adj. program F38: Direction change over / steering change over active	A28		B	
C8D502	LSB-UEA8: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A28.X2:1		E	1
C8D503	LSB-UEA8: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A28.X2:1		E	1
C8D513	LSB-UEA8: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	A28.X2:1		E	1
C8D602	LSB-UEA8: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A28.X2:2		E	1
C8D603	LSB-UEA8: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A28.X2:2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8D613	LSB-UEA8: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	A28.X2:2		E	1
C8D702	LSB-UEA8: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A28.X2:4		E	1
C8D703	LSB-UEA8: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A28.X2:4		E	1
C8D713	LSB-UEA8: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	A28.X2:4		E	1
C8D802	LSB-UEA8: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A28.X2:5		E	1
C8D803	LSB-UEA8: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A28.X2:5		E	1
C8D813	LSB-UEA8: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	A28.X2:5		E	1
C8D902	LSB-UEA8: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A28.X2:7		E	1
C8D903	LSB-UEA8: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A28.X2:7		E	1
C8D913	LSB-UEA8: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	A28.X2:7		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8DA02	LSB-UEA8: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A28.X2:8		E	1
C8DA03	LSB-UEA8: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A28.X2:8		E	1
C8DA13	LSB-UEA8: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	A28.X2:8		E	1
C8DB02	LSB-UEA8: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A28.X2:10		E	1
C8DB03	LSB-UEA8: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A28.X2:10		E	1
C8DB13	LSB-UEA8: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	A28.X2:10		E	1
C8DC02	LSB-UEA8: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A28.X2:11		E	1
C8DC03	LSB-UEA8: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A28.X2:11		E	1
C8DC13	LSB-UEA8: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	A28.X2:11		E	1
C8E112	LSB-UEA8: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A28.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8E11A	LSB-UEA8: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	A28.X1:10		E	1
C8E11B	LSB-UEA8: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	A28.X1:10		E	1
C8E11C	LSB-UEA8: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A28.X1:10		E	1
C8E11D	LSB-UEA8: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	A28.X1:10		E	1
C8E121	LSB-UEA8: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	A28.X1:10		E	1
C8E154	LSB-UEA8: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	A28.X1:10		E	1
C8E157	LSB-UEA8: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A28.X1:10		E	1
C8E159	LSB-UEA8: Switching output A0 supply voltage missing error indication on display Check line and fuse	A28.X1:10		E	1
C8E172	LSB-UEA8: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A28.X1:10		E	1
C8E212	LSB-UEA8: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A28.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8E21A	LSB-UEA8: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	A28.X1:11		E	1
C8E21B	LSB-UEA8: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	A28.X1:11		E	1
C8E21C	LSB-UEA8: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A28.X1:11		E	1
C8E21D	LSB-UEA8: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	A28.X1:11		E	1
C8E221	LSB-UEA8: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	A28.X1:11		E	1
C8E254	LSB-UEA8: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	A28.X1:11		E	1
C8E257	LSB-UEA8: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A28.X1:11		E	1
C8E259	LSB-UEA8: Switching output A1 supply voltage missing error indication on display Check line and fuse	A28.X1:11		E	1
C8E272	LSB-UEA8: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A28.X1:11		E	1
C8E312	LSB-UEA8: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A28.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8E31A	LSB-UEA8: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	A28.X1:12		E	1
C8E31B	LSB-UEA8: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	A28.X1:12		E	1
C8E31C	LSB-UEA8: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A28.X1:12		E	1
C8E31D	LSB-UEA8: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	A28.X1:12		E	1
C8E321	LSB-UEA8: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	A28.X1:12		E	1
C8E354	LSB-UEA8: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	A28.X1:12		E	1
C8E357	LSB-UEA8: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A28.X1:12		E	1
C8E359	LSB-UEA8: Switching output A2 supply voltage missing error indication on display Check line and fuse	A28.X1:12		E	1
C8E372	LSB-UEA8: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A28.X1:12		E	1
C8E412	LSB-UEA8: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A28.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8E41A	LSB-UEA8: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	A28.X1:13		E	1
C8E41B	LSB-UEA8: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	A28.X1:13		E	1
C8E41C	LSB-UEA8: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A28.X1:13		E	1
C8E41D	LSB-UEA8: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	A28.X1:13		E	1
C8E421	LSB-UEA8: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	A28.X1:13		E	1
C8E454	LSB-UEA8: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	A28.X1:13		E	1
C8E457	LSB-UEA8: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A28.X1:13		E	1
C8E459	LSB-UEA8: Switching output A3 supply voltage missing error indication on display Check line and fuse	A28.X1:13		E	1
C8E472	LSB-UEA8: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A28.X1:13		E	1
C8E512	LSB-UEA8: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A28.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8E51A	LSB-UEA8: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	A28.X1:14		E	1
C8E51B	LSB-UEA8: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	A28.X1:14		E	1
C8E51C	LSB-UEA8: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A28.X1:14		E	1
C8E51D	LSB-UEA8: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	A28.X1:14		E	1
C8E521	LSB-UEA8: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	A28.X1:14		E	1
C8E554	LSB-UEA8: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	A28.X1:14		E	1
C8E557	LSB-UEA8: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A28.X1:14		E	1
C8E559	LSB-UEA8: Switching output A4 supply voltage missing error indication on display Check line and fuse	A28.X1:14		E	1
C8E572	LSB-UEA8: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A28.X1:14		E	1
C8E612	LSB-UEA8: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A28.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8E61A	LSB-UEA8: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	A28.X1:15		E	1
C8E61B	LSB-UEA8: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	A28.X1:15		E	1
C8E61C	LSB-UEA8: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A28.X1:15		E	1
C8E61D	LSB-UEA8: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	A28.X1:15		E	1
C8E621	LSB-UEA8: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	A28.X1:15		E	1
C8E654	LSB-UEA8: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	A28.X1:15		E	1
C8E657	LSB-UEA8: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A28.X1:15		E	1
C8E659	LSB-UEA8: Switching output A5 supply voltage missing error indication on display Check line and fuse	A28.X1:15		E	1
C8E672	LSB-UEA8: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A28.X1:15		E	1
C8E712	LSB-UEA8: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A28.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8E71A	LSB-UEA8: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	A28.X1:16		E	1
C8E71B	LSB-UEA8: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	A28.X1:16		E	1
C8E71C	LSB-UEA8: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A28.X1:16		E	1
C8E71D	LSB-UEA8: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	A28.X1:16		E	1
C8E721	LSB-UEA8: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	A28.X1:16		E	1
C8E754	LSB-UEA8: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	A28.X1:16		E	1
C8E757	LSB-UEA8: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A28.X1:16		E	1
C8E759	LSB-UEA8: Switching output A6 supply voltage missing error indication on display Check line and fuse	A28.X1:16		E	1
C8E772	LSB-UEA8: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A28.X1:16		E	1
C8E812	LSB-UEA8: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A28.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8E81A	LSB-UEA8: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	A28.X1:17		E	1
C8E81B	LSB-UEA8: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	A28.X1:17		E	1
C8E81C	LSB-UEA8: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A28.X1:17		E	1
C8E81D	LSB-UEA8: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	A28.X1:17		E	1
C8E821	LSB-UEA8: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	A28.X1:17		E	1
C8E854	LSB-UEA8: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	A28.X1:17		E	1
C8E857	LSB-UEA8: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A28.X1:17		E	1
C8E859	LSB-UEA8: Switching output A7 supply voltage missing error indication on display Check line and fuse	A28.X1:17		E	1
C8E872	LSB-UEA8: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A28.X1:17		E	1
C8F001	LSB-UEA8: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module	A28		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8F006	LSB-UEA8: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module	A28		E	2
C8F013	LSB-UEA8: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A28		E	2
C8F016	LSB-UEA8: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A28		E	2
C8F031	LSB-UEA8: System error OS-CPU0 CPU-test faulty Module reset Replace module	A28		E	2
C8F050	LSB-UEA8: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software	A28		E	2
C8F068	LSB-UEA8: System error OS-CPU0 impermissible interrupt Module reset Replace module	A28		E	2
C8F070	LSB-UEA8: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module	A28		E	2
C8F071	LSB-UEA8: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module	A28		E	2
C8F073	LSB-UEA8: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A28		E	2
C8F075	LSB-UEA8: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module	A28		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8F078	LSB-UEA8: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service	A28		E	1
C8F080	LSB-UEA8: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module	A28		E	2
C8F082	LSB-UEA8: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A28		E	2
C8F088	LSB-UEA8: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module	A28		E	2
C8F089	LSB-UEA8: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module	A28		E	2
C8F090	LSB-UEA8: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module	A28		E	2
C8F0C1	LSB-UEA8: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A28		E	1
C8F113	LSB-UEA8: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A28		E	2
C8F15A	LSB-UEA8: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module	A28		E	2
C8F15B	LSB-UEA8: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane	A28		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8F170	LSB-UEA8: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors	A28		E	2
C8F175	LSB-UEA8: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit	A28		E	2
C8F1AC	LSB-UEA8: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)	A28		E	2
C8FA00	LSB-UEA8: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A28.X3:2/3		E	1
C8FA01	LSB-UEA8: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A28.X3:2/3		E	1
C8FA02	LSB-UEA8: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A28.X3:2/3		E	1
C8FA04	LSB-UEA8: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A28.X3:2/3		E	1
C8FA05	LSB-UEA8: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A28.X3:2/3		E	1
C8FA06	LSB-UEA8: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A28.X3:2/3		E	2
C8FA11	LSB-UEA8: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A28.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8FA32	LSB-UEA8: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A28.X3:2/3		E	1
C8FA40	LSB-UEA8: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A28.X3:2/3		E	1
C8FA41	LSB-UEA8: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A28.X3:2/3		E	1
C8FB00	LSB-UEA8: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A28.X3:4/5		E	1
C8FB01	LSB-UEA8: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A28.X3:4/5		E	1
C8FB02	LSB-UEA8: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A28.X3:4/5		E	1
C8FB04	LSB-UEA8: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A28.X3:4/5		E	1
C8FB05	LSB-UEA8: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A28.X3:4/5		E	1
C8FB06	LSB-UEA8: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A28.X3:4/5		E	2
C8FB11	LSB-UEA8: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A28.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C8FB32	LSB-UEA8: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A28.X3:4/5		E	1
C8FB40	LSB-UEA8: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A28.X3:4/5		E	1
C8FB41	LSB-UEA8: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A28.X3:4/5		E	1
C93402	LSB-UEA9: control winch 5 hydraulic circuit pressure sensor defective/missing No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A29		E	
C9340A	LSB-UEA9: control winch 5 Pressure too high when pump is not actuated No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A29		E	
C9340B	LSB-UEA9: control winch 5 Winch turn sensor erroneous / missing No actuation of pump and no act. of winch brake Check winch turn sensor. Check LSB-Bus	A29		E	
C9340C	LSB-UEA9: control winch 5 Repl. pressure supply missing / too low during winch movement Stop winch Check signal. Check pr. switch. Check hydr, replen. pressure supply	A29		E	
C9340D	LSB-UEA9: control winch 5 Winch brake, ground switch open during winch movement Stop winch Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A29		E	
C9340E	LSB-UEA9: control winch 5 Winch brake, ground switch does not close / closes too late Delayed actuation of winch. No actuation of winch. Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A29		E	
C9340F	LSB-UEA9: control winch 5 Winch brake, ground switch report short circuit after ground (Start No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A29		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C93416	LSB-UEA9: control winch 5 Winch brake, ground switch report short circuit after Plus (Start) No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A29		E	
C9341C	LSB-UEA9: control winch 5 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A29		B	
C93420	LSB-UEA9: control winch 5 Winch brake, ground switch report has short circuit after ground Error message: second shut off channel ineffective Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A29		E	
C93421	LSB-UEA9: control winch 5 Emerg. shut off active No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A29		E	
C93423	LSB-UEA9: control winch 5 Outlet error control outlet winch, read out system error (inactive) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A29		E	
C93424	LSB-UEA9: control winch 5 Monitoring release brake pressure, short circuit after Plus Active act. of emerg. valve only at master switch deflection. Error message Check signal line for short circuit. Check wiring, switch on valve	A29		E	
C93425	LSB-UEA9: control winch 5 Monitoring release brake pressure interruption/short circuit after gro Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A29		E	
C93426	LSB-UEA9: control winch 5 Rotational speed too low, current nominal value fallen below error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A29		E	
C93427	LSB-UEA9: control winch 5 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A29		E	
C93428	LSB-UEA9: control winch 5 Permissible rotational speed exceeded, emergency shut off Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A29		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C93429	LSB-UEA9: control winch 5 Monitoring rotational speed not possible, winch turn sensor missing Error message. Shut down winch by closing winch brake Check winch turn sensor. Check LSB-Bus	A29		E	
C9342D	LSB-UEA9: control winch 5 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A29		E	
C9342E	LSB-UEA9: control winch 5 Repl. pressure switch implausible to pressure sensor signal (analog) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A29		E	
C93441	LSB-UEA9: control winch 5 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A29		E	
C93442	LSB-UEA9: control winch 5 Rotation movement at non-actuated winch brake Error message. Check winch brake. Check winch turn sensor(installation)	A29		E	
C93446	LSB-UEA9: control winch 5 Signal Replenishing pr. sensor short circuit after ground or interrupt Operation conditional switch off, may not be shunted replace sensor through new part	A29		E	
C93447	LSB-UEA9: control winch 5 Signal Brake pr. sensor short circuit after ground or interruption	A29		E	
C9345F	LSB-UEA9: control winch 5 Shut off master switch zero position forced Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A29		B	
C96108	LSB-UEA9: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A29		E	
C97007	LSB-UEA9: remote control Zero position compulsion on radio MS	A29		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C97019	LSB-UEA9: remote control No radio release (electrical signal not available)	A29		E	1
C97090	LSB-UEA9: remote control Short circuit after supply voltage on radio input UEA	A29		E	1
C99900	LSB-UEA9: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A29		E	2
C99901	LSB-UEA9: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A29		E	2
C99902	LSB-UEA9: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A29		E	1
C99904	LSB-UEA9: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A29		E	1
C99905	LSB-UEA9: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A29		E	1
C99906	LSB-UEA9: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A29		E	2
C99907	LSB-UEA9: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A29		E	1
C99911	LSB-UEA9: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A29		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9C089	LSB-UEA9: Diagnostics syst. band end/adj. program Test program winch brake current not yet carried out Adj. program is interrupted, all movements turned off Set pump currents	A29		B	
C9C0C3	LSB-UEA9: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A29		B	
C9C0C4	LSB-UEA9: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A29		B	
C9C0C5	LSB-UEA9: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A29		B	
C9C0C6	LSB-UEA9: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A29		B	
C9C0C8	LSB-UEA9: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low Adj. program is interrupted, all movements turned off Increase Qmin Pump (See Specification Pump)	A29		B	
C9C0C9	LSB-UEA9: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high Adj. program is interrupted, all movements turned off Decrease Qmin Pump (See Specification Pump)	A29		B	
C9C0CA	LSB-UEA9: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded Adj. program is interrupted, all movements turned off Pressure threshold was not recognized, try again (consult)	A29		B	
C9C0CB	LSB-UEA9: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range Adj. program is interrupted, all movements turned off No adj. value was found within current limits. Check hydraulic	A29		B	
C9C0CC	LSB-UEA9: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100% Adj. program is interrupted, all movements turned off Deflect master switch during adj. phase 100%	A29		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9C0CF	LSB-UEA9: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A29		B	
C9C0D0	LSB-UEA9: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A29		B	
C9C0D1	LSB-UEA9: Diagnostics syst. band end/adj. program F15: Angle sensor placement section: Lower limit angle reached Adj. program is interrupted, all movements turned off Carry out luff up movement until perm. tele angle is reached	A29		B	
C9C0DA	LSB-UEA9: Diagnostics syst. band end/adj. program F24: Pump flows not completely set Adj. program is interrupted, all movements turned off Set pump currents	A29		B	
C9D502	LSB-UEA9: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A29.X2:1		E	1
C9D503	LSB-UEA9: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A29.X2:1		E	1
C9D513	LSB-UEA9: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	A29.X2:1		E	1
C9D602	LSB-UEA9: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A29.X2:2		E	1
C9D603	LSB-UEA9: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A29.X2:2		E	1
C9D613	LSB-UEA9: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	A29.X2:2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9D702	LSB-UEA9: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A29.X2:4		E	1
C9D703	LSB-UEA9: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A29.X2:4		E	1
C9D713	LSB-UEA9: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	A29.X2:4		E	1
C9D802	LSB-UEA9: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A29.X2:5		E	1
C9D803	LSB-UEA9: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A29.X2:5		E	1
C9D813	LSB-UEA9: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	A29.X2:5		E	1
C9D902	LSB-UEA9: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A29.X2:7		E	1
C9D903	LSB-UEA9: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A29.X2:7		E	1
C9D913	LSB-UEA9: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	A29.X2:7		E	1
C9DA02	LSB-UEA9: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A29.X2:8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9DA03	LSB-UEA9: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A29.X2:8		E	1
C9DA13	LSB-UEA9: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	A29.X2:8		E	1
C9DB02	LSB-UEA9: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A29.X2:10		E	1
C9DB03	LSB-UEA9: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A29.X2:10		E	1
C9DB13	LSB-UEA9: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	A29.X2:10		E	1
C9DC02	LSB-UEA9: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A29.X2:11		E	1
C9DC03	LSB-UEA9: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A29.X2:11		E	1
C9DC13	LSB-UEA9: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	A29.X2:11		E	1
C9E112	LSB-UEA9: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A29.X1:10		E	1
C9E11A	LSB-UEA9: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	A29.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9E11B	LSB-UEA9: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	A29.X1:10		E	1
C9E11C	LSB-UEA9: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A29.X1:10		E	1
C9E11D	LSB-UEA9: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	A29.X1:10		E	1
C9E121	LSB-UEA9: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	A29.X1:10		E	1
C9E154	LSB-UEA9: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	A29.X1:10		E	1
C9E157	LSB-UEA9: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A29.X1:10		E	1
C9E159	LSB-UEA9: Switching output A0 supply voltage missing error indication on display Check line and fuse	A29.X1:10		E	1
C9E172	LSB-UEA9: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A29.X1:10		E	1
C9E212	LSB-UEA9: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A29.X1:11		E	1
C9E21A	LSB-UEA9: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	A29.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9E21B	LSB-UEA9: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	A29.X1:11		E	1
C9E21C	LSB-UEA9: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A29.X1:11		E	1
C9E21D	LSB-UEA9: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	A29.X1:11		E	1
C9E221	LSB-UEA9: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	A29.X1:11		E	1
C9E254	LSB-UEA9: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	A29.X1:11		E	1
C9E257	LSB-UEA9: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A29.X1:11		E	1
C9E259	LSB-UEA9: Switching output A1 supply voltage missing error indication on display Check line and fuse	A29.X1:11		E	1
C9E272	LSB-UEA9: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A29.X1:11		E	1
C9E312	LSB-UEA9: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A29.X1:12		E	1
C9E31A	LSB-UEA9: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	A29.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9E31B	LSB-UEA9: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	A29.X1:12		E	1
C9E31C	LSB-UEA9: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A29.X1:12		E	1
C9E31D	LSB-UEA9: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	A29.X1:12		E	1
C9E321	LSB-UEA9: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	A29.X1:12		E	1
C9E354	LSB-UEA9: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	A29.X1:12		E	1
C9E357	LSB-UEA9: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A29.X1:12		E	1
C9E359	LSB-UEA9: Switching output A2 supply voltage missing error indication on display Check line and fuse	A29.X1:12		E	1
C9E372	LSB-UEA9: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A29.X1:12		E	1
C9E412	LSB-UEA9: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A29.X1:13		E	1
C9E41A	LSB-UEA9: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	A29.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9E41B	LSB-UEA9: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	A29.X1:13		E	1
C9E41C	LSB-UEA9: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A29.X1:13		E	1
C9E41D	LSB-UEA9: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	A29.X1:13		E	1
C9E421	LSB-UEA9: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	A29.X1:13		E	1
C9E454	LSB-UEA9: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	A29.X1:13		E	1
C9E457	LSB-UEA9: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A29.X1:13		E	1
C9E459	LSB-UEA9: Switching output A3 supply voltage missing error indication on display Check line and fuse	A29.X1:13		E	1
C9E472	LSB-UEA9: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A29.X1:13		E	1
C9E512	LSB-UEA9: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A29.X1:14		E	1
C9E51A	LSB-UEA9: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	A29.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9E51B	LSB-UEA9: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	A29.X1:14		E	1
C9E51C	LSB-UEA9: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A29.X1:14		E	1
C9E51D	LSB-UEA9: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	A29.X1:14		E	1
C9E521	LSB-UEA9: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	A29.X1:14		E	1
C9E554	LSB-UEA9: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	A29.X1:14		E	1
C9E557	LSB-UEA9: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A29.X1:14		E	1
C9E559	LSB-UEA9: Switching output A4 supply voltage missing error indication on display Check line and fuse	A29.X1:14		E	1
C9E572	LSB-UEA9: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A29.X1:14		E	1
C9E612	LSB-UEA9: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A29.X1:15		E	1
C9E61A	LSB-UEA9: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	A29.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9E61B	LSB-UEA9: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	A29.X1:15		E	1
C9E61C	LSB-UEA9: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A29.X1:15		E	1
C9E61D	LSB-UEA9: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	A29.X1:15		E	1
C9E621	LSB-UEA9: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	A29.X1:15		E	1
C9E654	LSB-UEA9: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	A29.X1:15		E	1
C9E657	LSB-UEA9: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A29.X1:15		E	1
C9E659	LSB-UEA9: Switching output A5 supply voltage missing error indication on display Check line and fuse	A29.X1:15		E	1
C9E672	LSB-UEA9: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A29.X1:15		E	1
C9E712	LSB-UEA9: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A29.X1:16		E	1
C9E71A	LSB-UEA9: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	A29.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9E71B	LSB-UEA9: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	A29.X1:16		E	1
C9E71C	LSB-UEA9: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A29.X1:16		E	1
C9E71D	LSB-UEA9: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	A29.X1:16		E	1
C9E721	LSB-UEA9: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	A29.X1:16		E	1
C9E754	LSB-UEA9: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	A29.X1:16		E	1
C9E757	LSB-UEA9: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A29.X1:16		E	1
C9E759	LSB-UEA9: Switching output A6 supply voltage missing error indication on display Check line and fuse	A29.X1:16		E	1
C9E772	LSB-UEA9: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A29.X1:16		E	1
C9E812	LSB-UEA9: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A29.X1:17		E	1
C9E81A	LSB-UEA9: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	A29.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9E81B	LSB-UEA9: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	A29.X1:17		E	1
C9E81C	LSB-UEA9: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A29.X1:17		E	1
C9E81D	LSB-UEA9: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	A29.X1:17		E	1
C9E821	LSB-UEA9: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	A29.X1:17		E	1
C9E854	LSB-UEA9: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	A29.X1:17		E	1
C9E857	LSB-UEA9: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A29.X1:17		E	1
C9E859	LSB-UEA9: Switching output A7 supply voltage missing error indication on display Check line and fuse	A29.X1:17		E	1
C9E872	LSB-UEA9: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A29.X1:17		E	1
C9F001	LSB-UEA9: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module	A29		E	2
C9F006	LSB-UEA9: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module	A29		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9F013	LSB-UEA9: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A29		E	2
C9F016	LSB-UEA9: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A29		E	2
C9F031	LSB-UEA9: System error OS-CPU0 CPU-test faulty Module reset Replace module	A29		E	2
C9F050	LSB-UEA9: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software	A29		E	2
C9F068	LSB-UEA9: System error OS-CPU0 impermissible interrupt Module reset Replace module	A29		E	2
C9F070	LSB-UEA9: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module	A29		E	2
C9F071	LSB-UEA9: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module	A29		E	2
C9F073	LSB-UEA9: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A29		E	2
C9F075	LSB-UEA9: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module	A29		E	2
C9F078	LSB-UEA9: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service	A29		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9F080	LSB-UEA9: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module	A29		E	2
C9F082	LSB-UEA9: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A29		E	2
C9F088	LSB-UEA9: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module	A29		E	2
C9F089	LSB-UEA9: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module	A29		E	2
C9F090	LSB-UEA9: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module	A29		E	2
C9F0C1	LSB-UEA9: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A29		E	1
C9F113	LSB-UEA9: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A29		E	2
C9F15A	LSB-UEA9: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module	A29		E	2
C9F15B	LSB-UEA9: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane	A29		E	2
C9F170	LSB-UEA9: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors	A29		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9F175	LSB-UEA9: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit	A29		E	2
C9F1AC	LSB-UEA9: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)	A29		E	2
C9FA00	LSB-UEA9: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A29.X3:2/3		E	1
C9FA01	LSB-UEA9: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A29.X3:2/3		E	1
C9FA02	LSB-UEA9: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A29.X3:2/3		E	1
C9FA04	LSB-UEA9: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A29.X3:2/3		E	1
C9FA05	LSB-UEA9: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A29.X3:2/3		E	1
C9FA06	LSB-UEA9: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A29.X3:2/3		E	2
C9FA11	LSB-UEA9: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A29.X3:2/3		E	1
C9FA32	LSB-UEA9: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A29.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9FA40	LSB-UEA9: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A29.X3:2/3		E	1
C9FA41	LSB-UEA9: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A29.X3:2/3		E	1
C9FB00	LSB-UEA9: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A29.X3:4/5		E	1
C9FB01	LSB-UEA9: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A29.X3:4/5		E	1
C9FB02	LSB-UEA9: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A29.X3:4/5		E	1
C9FB04	LSB-UEA9: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A29.X3:4/5		E	1
C9FB05	LSB-UEA9: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A29.X3:4/5		E	1
C9FB06	LSB-UEA9: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A29.X3:4/5		E	2
C9FB11	LSB-UEA9: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A29.X3:4/5		E	1
C9FB32	LSB-UEA9: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A29.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
C9FB40	LSB-UEA9: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A29.X3:4/5		E	1
C9FB41	LSB-UEA9: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A29.X3:4/5		E	1
CA3502	LSB-UEA10: control winch 6 hydraulic circuit pressure sensor defective/missing No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A30		E	
CA350A	LSB-UEA10: control winch 6 Pressure too high when pump is not actuated No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A30		E	
CA350B	LSB-UEA10: control winch 6 Winch turn sensor erroneous / missing No actuation of pump and no act. of winch brake Check winch turn sensor. Check LSB-Bus	A30		E	
CA350C	LSB-UEA10: control winch 6 Repl. pressure supply missing / too low during winch movement Stop winch Check signal. Check pr. switch. Check hydr, replen. pressure supply	A30		E	
CA350D	LSB-UEA10: control winch 6 Winch brake, ground switch open during winch movement Stop winch Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A30		E	
CA350E	LSB-UEA10: control winch 6 Winch brake, ground switch does not close / closes too late Delayed actuation of winch. No actuation of winch. Check signal. Check winch turn sensor. Act. winch turn sensor via second channel of master switch	A30		E	
CA350F	LSB-UEA10: control winch 6 Winch brake, ground switch report short circuit after ground (Start No act. of winch. NO act. of winch brake Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A30		E	
CA3516	LSB-UEA10: control winch 6 Winch brake, ground switch report short circuit after Plus (Start) No act. of winch. NO act. of winch brake Check signal line for short circuit. Check wiring	A30		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CA351C	LSB-UEA10: control winch 6 Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A30		B	
CA3520	LSB-UEA10: control winch 6 Winch brake, ground switch report has short circuit after ground Error message: second shut off channel ineffective Check signal line for ground short circuit. Check current source on UEA-Input and wiring	A30		E	
CA3521	LSB-UEA10: control winch 6 Emerg. shut off active No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A30		E	
CA3523	LSB-UEA10: control winch 6 Outlet error control outlet winch, read out system error (inactive) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A30		E	
CA3524	LSB-UEA10: control winch 6 Monitoring release brake pressure, short circuit after Plus Active act. of emerg. valve only at master switch deflection. Error message Check signal line for short circuit. Check wiring, switch on valve	A30		E	
CA3525	LSB-UEA10: control winch 6 Monitoring release brake pressure interruption/short circuit after gro Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A30		E	
CA3526	LSB-UEA10: control winch 6 Rotational speed too low, current nominal value fallen below error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A30		E	
CA3527	LSB-UEA10: control winch 6 Rotational speed too high, current nominal value exceeded error report Check initial current and end current of pump and control motor, adj. if nec. Check hydraulic (espe.	A30		E	
CA3528	LSB-UEA10: control winch 6 Permissible rotational speed exceeded, emergency shut off Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A30		E	
CA3529	LSB-UEA10: control winch 6 Monitoring rotational speed not possible, winch turn sensor missing Error message. Shut down winch by closing winch brake Check winch turn sensor. Check LSB-Bus	A30		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CA352D	LSB-UEA10: control winch 6 Impermissible rotation movement in lowering direction Error message. Shut down winch by closing winch brake Broken drive shaft. Hydraulic short circuit between LIFT and LOWER conn. Motor. Hose breakage. Hydraulic	A30		E	
CA352E	LSB-UEA10: control winch 6 Repl. pressure switch implausible to pressure sensor signal (analog) No actuation of pump and no act. of winch brake Check pressure sensor. Check pressure sensor on UEA-Input (Input signal, Bus signal). Check wiring	A30		E	
CA3541	LSB-UEA10: control winch 6 Rotation movement against selected movement direction Error message. Shut down winch by closing winch brake Check actuation of crane pump. Check winch turn sensor (count direction), check winch turn sensor(Anba	A30		E	
CA3542	LSB-UEA10: control winch 6 Rotation movement at non-actuated winch brake Error message. Check winch brake. Check winch turn sensor(installation)	A30		E	
CA3546	LSB-UEA10: control winch 6 Signal Replenishing pr. sensor short circuit after ground or interrupt Operation conditional switch off, may not be shunted replace sensor through new part	A30		E	
CA3547	LSB-UEA10: control winch 6 Signal Brake pr. sensor short circuit after ground or interruption	A30		E	
CA355F	LSB-UEA10: control winch 6 Shut off master switch zero position forced Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A30		B	
CA6108	LSB-UEA10: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A30		E	
CAC089	LSB-UEA10: Diagnostics syst. band end/adj. program Test program winch brake current not yet carried out Adj. program is interrupted, all movements turned off Set pump currents	A30		B	
CAC0C3	LSB-UEA10: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A30		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CAC0C4	LSB-UEA10: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A30		B	
CAC0C5	LSB-UEA10: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A30		B	
CAC0C6	LSB-UEA10: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A30		B	
CAC0C8	LSB-UEA10: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low Adj. program is interrupted, all movements turned off Increase Qmin Pump (See Specification Pump)	A30		B	
CAC0C9	LSB-UEA10: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high Adj. program is interrupted, all movements turned off Decrease Qmin Pump (See Specification Pump)	A30		B	
CAC0CA	LSB-UEA10: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded Adj. program is interrupted, all movements turned off Pressure threshold was not recognized, try again (consult)	A30		B	
CAC0CB	LSB-UEA10: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range Adj. program is interrupted, all movements turned off No adj. value was found within current limits. Check hydraulic	A30		B	
CAC0CC	LSB-UEA10: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100% Adj. program is interrupted, all movements turned off Deflect master switch during adj. phase 100%	A30		B	
CAC0CF	LSB-UEA10: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A30		B	
CAC0D0	LSB-UEA10: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A30		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CAC0D1	LSB-UEA10: Diagnostics syst. band end/adj. program F15: Angle sensor placement section: Lower limit angle reached Adj. program is interrupted, all movements turned off Carry out luff up movement until perm. tele angle is reached	A30		B	
CAC0DA	LSB-UEA10: Diagnostics syst. band end/adj. program F24: Pump flows not completely set Adj. program is interrupted, all movements turned off Set pump currents	A30		B	
CAD902	LSB-UEA10: Analog input E4 sensor deficiency data short circuit to supply voltage Operation conditional switch off, may not be shunted replace sensor through new part	A30.X2:7		E	
CAD903	LSB-UEA10: Analog input E4 sensor deficiency data short circuit to ground	A30.X2:7		E	
CADA02	LSB-UEA10: Analog input E5 sensor deficiency data short circuit to supply voltage Operation conditional switch off, may not be shunted replace sensor through new part	A30.X2:8		E	
CADA03	LSB-UEA10: Analog input E5 sensor deficiency data short circuit to ground	A30.X2:8		E	
CAFA32	LSB-UEA10: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A30.X3:2/3		E	1
CAFB32	LSB-UEA10: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A30.X3:4/5		E	1
CB355F	LSB-UEA11: control winch 6 Shut off master switch zero position forced	A50		E	
CB3C00	LSB-UEA11: Control crawler Pedal sensor crawler left, electr. signal not plausible to LSB Signal Operational shut off. Crawler cannot be controlled with this pedal Check: voltage an analog input, approx.2V at deflection to rear, approx. 10V at deflection to front, check wiring	A50		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CB3C01	LSB-UEA11: Control crawler Pedal sensor crawler right, electr. signal plausible LSB Signal Operational shut off. Crawler cannot be controlled with this pedal Check: voltage an analog input, approx.2V at deflection to rear,approx. 10V at deflection to front, check wiring	A50		E	1
CB3C02	LSB-UEA11: Control crawler Pedal sensor crawler left, elect. not in zero pos. Operational shut off. Crawler cannot be controlled with this pedal Check: voltage on analog input must be >5.5V and <6.5V, then pedal in zero pos., check wiring	A50		E	1
CB3C03	LSB-UEA11: Control crawler Pedal sensor crawler right, elect. not in zero pos. Operational shut off. Crawler cannot be controlled with this pedal Check: voltage on analog input must be >5.5V and <6.5V, then pedal in zero pos., check wiring	A50		E	1
CB3C1C	LSB-UEA11: Control crawler Interruption bus connection(s)Actuation / release, zero force Output of error, crane function is not selected. Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A50		E	1
CB3C25	LSB-UEA11: Control crawler Modification of counter value crawler track carrier left with brake ap Error is shown as system error Check incremental sensor, possibly check hydraulic and travel brake	A50		E	1
CB3C26	LSB-UEA11: Control crawler Modification of counter value crawler track carrier right with brake a Error is shown as system error Check incremental sensor, possibly check hydraulic and travel brake	A50		E	1
CB3C29	LSB-UEA11: Control crawler Contact Monitor Pump on winch / crawler erroneous Winch or crawler not selectable Check relay for switch over winch/crawler	A50		E	1
CB3C52	LSB-UEA11: Control crawler Shut off travel gear due to initial diagnostics Error is shown as system error	A50		E	1
CB3C54	LSB-UEA11: Control crawler Report (diagnostics line) travel gear brake has interruption Error is shown as system error check wiring	A50		E	1
CB3C55	LSB-UEA11: Control crawler Current circuit valve travel gear brake has short circuit after ground Error is shown as system error check wiring	A50		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CB3C56	LSB-UEA11: Control crawler Current circuit valve travel gear brake has short circuit after plus Error is shown as system error check wiring	A50		E	1
CB3C60	LSB-UEA11: Control crawler Position control parallel operation, movement differential too great Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A50		E	1
CB3C61	LSB-UEA11: Control crawler Path reg. Parallel operation, no/invalid saved zero point Active act. of emerg. valve only at master switch deflection. Error message Check signal line for interruption, check wiring, switch on valve. Replace valve	A50		E	1
CB3C80	LSB-UEA11: Control crawler Modification of counter value, speed < set value, check crawler left Error is shown as system error Check incremental sensor, possibly check hydraulic and travel brake	A50		E	1
CB3C81	LSB-UEA11: Control crawler Modification of counter value, speed > set value, check crawler left Error is shown as system error Check incremental sensor, possibly check hydraulic and travel brake	A50		E	1
CB3C82	LSB-UEA11: Control crawler Modification of counter value, speed < set value, check crawler right Error is shown as system error Check incremental sensor, possibly check hydraulic and travel brake	A50		E	1
CB3C83	LSB-UEA11: Control crawler Modification of counter value, speed > set value, check crawler right Error is shown as system error Check incremental sensor, possibly check hydraulic and travel brake	A50		E	1
CB3C84	LSB-UEA11: Control crawler No travel movement detected with controlled crawler left Error is shown as system error Check incremental sensor, possibly check hydraulic and travel brake	A50		E	1
CB3C85	LSB-UEA11: Control crawler No travel movement detected with controlled crawler right Error is shown as system error Check incremental sensor, possibly check hydraulic and travel brake	A50		E	1
CB3CA5	LSB-UEA11: Control crawler Signals slewing platform position to front / to rear implausibel Direction change not possible, last command remains valid Check switch for steering changeover +-90°, check wiring	A50		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CB3F1C	LSB-UEA11: crane control Interruption bus connection(s)Actuation / release, zero force Output of error, crane function is not selected. Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A50		E	1
CB5C28	LSB-UEA11: Operation crawler Drive crawler not possible - crawler not turned on Output of error, crane function is not selected. On TE3 switch to crawler	A50		B	
CB5C3F	LSB-UEA11: Operation crawler In parallel op., selection only possible with one master switch no reaction Bring all master switches to zero pos., then deflect desired movement again	A50		B	
CB6108	LSB-UEA11: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A50		E	
CB611C	LSB-UEA11: Operation crane control Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A50		B	
CB6134	LSB-UEA11: Operation crane control Output error, aux. brake sys. / aux. user Mot.1 not available Issue of error deleting the available brake power of pump Check line for error. After fixing the error, restart system	A50		E	
CB6135	LSB-UEA11: Operation crane control Output error, aux. brake sys. / aux. user Mot.2 not available Issue of error deleting the available brake power of pump Check line for error. After fixing the error, restart system	A50		E	
CB613F	LSB-UEA11: Operation crane control Selection of several aux. users error report Remove all selections aux. user	A50		B	
CB62A6	LSB-UEA11: operation instruments crane operators cab Function blocked: Brake pumps are active Function is blocked Stop lower winch then power for aux. users is free	A50		B	
CB7007	LSB-UEA11: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A50		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CB7019	LSB-UEA11: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A50		E	1
CB7090	LSB-UEA11: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A50		E	1
CB9900	LSB-UEA11: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A50		E	2
CB9901	LSB-UEA11: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A50		E	2
CB9902	LSB-UEA11: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A50		E	1
CB9904	LSB-UEA11: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A50		E	1
CB9905	LSB-UEA11: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A50		E	1
CB9906	LSB-UEA11: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A50		E	2
CB9907	LSB-UEA11: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A50		E	1
CB9911	LSB-UEA11: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A50		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBC092	LSB-UEA11: Diagnostics syst. band end/adj. program F57: Rapid gear crawler selected	A50		B	
CBC093	LSB-UEA11: Diagnostics syst. band end/adj. program F58: Parallel op. crawler selected	A50		B	
CBC094	LSB-UEA11: Diagnostics syst. band end/adj. program F59: Max. speed crawler not determined - carry out Test 678	A50		B	
CBC095	LSB-UEA11: Diagnostics syst. band end/adj. program F60: Min. speed crawler not reached	A50		B	
CBC096	LSB-UEA11: Diagnostics syst. band end/adj. program F74: Rapid gear crawler not selected	A50		B	
CBC0C3	LSB-UEA11: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A50		B	
CBC0C4	LSB-UEA11: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A50		B	
CBC0C5	LSB-UEA11: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A50		B	
CBC0C6	LSB-UEA11: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A50		B	
CBC0C8	LSB-UEA11: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low Adj. program is interrupted, all movements turned off Increase Qmin Pump (See Specification Pump)	A50		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBC0C9	LSB-UEA11: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high Adj. program is interrupted, all movements turned off Decrease Qmin Pump (See Specification Pump)	A50		B	
CBC0CA	LSB-UEA11: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded Adj. program is interrupted, all movements turned off Pressure threshold was not recognized, try again (consult)	A50		B	
CBC0CB	LSB-UEA11: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range Adj. program is interrupted, all movements turned off No adj. value was found within current limits. Check hydraulic	A50		B	
CBC0CC	LSB-UEA11: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100% Adj. program is interrupted, all movements turned off Deflect master switch during adj. phase 100%	A50		B	
CBC0CF	LSB-UEA11: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A50		B	
CBC0D0	LSB-UEA11: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A50		B	
CBC0D1	LSB-UEA11: Diagnostics syst. band end/adj. program F15: Angle sensor placement section: Lower limit angle reached Adj. program is interrupted, all movements turned off Carry out luff up movement until perm. tele angle is reached	A50		B	
CBC0DA	LSB-UEA11: Diagnostics syst. band end/adj. program F24: Pump flows not completely set Adj. program is interrupted, all movements turned off Set pump currents	A50		B	
CBC0E8	LSB-UEA11: Diagnostics syst. band end/adj. program F38: Direction change over / steering change over active	A50		B	
CBD502	LSB-UEA11: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A50.X2:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBD503	LSB-UEA11: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A50.X2:1		E	1
CBD513	LSB-UEA11: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	A50.X2:1		E	1
CBD573	LSB-UEA11: Analog input E0 open circuit or short circuit to supply voltage/ground Operational shut off. Crawler cannot be controlled with this pedal Check: voltage an analog input, approx.2V at deflection to rear,approx. 10V at deflection to front, check wiring	A50.X2:1		E	1
CBD602	LSB-UEA11: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A50.X2:2		E	1
CBD603	LSB-UEA11: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A50.X2:2		E	1
CBD613	LSB-UEA11: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	A50.X2:2		E	1
CBD673	LSB-UEA11: Analog input E1 open circuit or short circuit to supply voltage/ground Operational shut off. Crawler cannot be controlled with this pedal Check: voltage an analog input, approx.2V at deflection to rear,approx. 10V at deflection to front, check wiring	A50.X2:2		E	1
CBD702	LSB-UEA11: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A50.X2:4		E	1
CBD703	LSB-UEA11: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A50.X2:4		E	1
CBD713	LSB-UEA11: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	A50.X2:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBD773	LSB-UEA11: Analog input E2 open circuit or short circuit to supply voltage/ground Operational shut off. Crawler cannot be controlled with this pedal Check: voltage an analog input, approx.2V at deflection to rear,approx. 10V at deflection to front, check wiring	A50.X2:4		E	1
CBD802	LSB-UEA11: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A50.X2:5		E	1
CBD803	LSB-UEA11: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A50.X2:5		E	1
CBD813	LSB-UEA11: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	A50.X2:5		E	1
CBD873	LSB-UEA11: Analog input E3 open circuit or short circuit to supply voltage/ground Operational shut off. Crawler cannot be controlled with this pedal Check: voltage an analog input, approx.2V at deflection to rear,approx. 10V at deflection to front, check wiring	A50.X2:5		E	1
CBD902	LSB-UEA11: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A50.X2:7		E	1
CBD903	LSB-UEA11: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A50.X2:7		E	1
CBD913	LSB-UEA11: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	A50.X2:7		E	1
CBDA02	LSB-UEA11: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A50.X2:8		E	1
CBDA03	LSB-UEA11: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A50.X2:8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBDA13	LSB-UEA11: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	A50.X2:8		E	1
CBDB02	LSB-UEA11: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A50.X2:10		E	1
CBDB03	LSB-UEA11: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A50.X2:10		E	1
CBDB13	LSB-UEA11: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	A50.X2:10		E	1
CBDC02	LSB-UEA11: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A50.X2:11		E	1
CBDC03	LSB-UEA11: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A50.X2:11		E	1
CBDC13	LSB-UEA11: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	A50.X2:11		E	1
CBDD6F	LSB-UEA11: Digital input E8 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A50.X2:18		E	1
CBDE6F	LSB-UEA11: Digital input E9 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A50.X2:19		E	1
CBDF6F	LSB-UEA11: Digital input E10 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A50.X2:20		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE06F	LSB-UEA11: Digital input E11 No status change on input recognizable, check sensor Incremental counter no longer counts Check connected sensor	A50.X2:21		E	1
CBE112	LSB-UEA11: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A50.X1:10		E	1
CBE11A	LSB-UEA11: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	A50.X1:10		E	1
CBE11B	LSB-UEA11: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	A50.X1:10		E	1
CBE11C	LSB-UEA11: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A50.X1:10		E	1
CBE11D	LSB-UEA11: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	A50.X1:10		E	1
CBE121	LSB-UEA11: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	A50.X1:10		E	1
CBE154	LSB-UEA11: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	A50.X1:10		E	1
CBE157	LSB-UEA11: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A50.X1:10		E	1
CBE159	LSB-UEA11: Switching output A0 supply voltage missing error indication on display Check line and fuse	A50.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE172	LSB-UEA11: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A50.X1:10		E	1
CBE212	LSB-UEA11: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A50.X1:11		E	1
CBE21A	LSB-UEA11: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	A50.X1:11		E	1
CBE21B	LSB-UEA11: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	A50.X1:11		E	1
CBE21C	LSB-UEA11: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A50.X1:11		E	1
CBE21D	LSB-UEA11: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	A50.X1:11		E	1
CBE221	LSB-UEA11: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	A50.X1:11		E	1
CBE254	LSB-UEA11: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	A50.X1:11		E	1
CBE257	LSB-UEA11: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A50.X1:11		E	1
CBE259	LSB-UEA11: Switching output A1 supply voltage missing error indication on display Check line and fuse	A50.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE272	LSB-UEA11: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A50.X1:11		E	1
CBE312	LSB-UEA11: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A50.X1:12		E	1
CBE31A	LSB-UEA11: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	A50.X1:12		E	1
CBE31B	LSB-UEA11: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	A50.X1:12		E	1
CBE31C	LSB-UEA11: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A50.X1:12		E	1
CBE31D	LSB-UEA11: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	A50.X1:12		E	1
CBE321	LSB-UEA11: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	A50.X1:12		E	1
CBE354	LSB-UEA11: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	A50.X1:12		E	1
CBE357	LSB-UEA11: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A50.X1:12		E	1
CBE359	LSB-UEA11: Switching output A2 supply voltage missing error indication on display Check line and fuse	A50.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE372	LSB-UEA11: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A50.X1:12		E	1
CBE412	LSB-UEA11: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A50.X1:13		E	1
CBE41A	LSB-UEA11: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	A50.X1:13		E	1
CBE41B	LSB-UEA11: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	A50.X1:13		E	1
CBE41C	LSB-UEA11: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A50.X1:13		E	1
CBE41D	LSB-UEA11: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	A50.X1:13		E	1
CBE421	LSB-UEA11: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	A50.X1:13		E	1
CBE454	LSB-UEA11: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	A50.X1:13		E	1
CBE457	LSB-UEA11: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A50.X1:13		E	1
CBE459	LSB-UEA11: Switching output A3 supply voltage missing error indication on display Check line and fuse	A50.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE472	LSB-UEA11: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A50.X1:13		E	1
CBE512	LSB-UEA11: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A50.X1:14		E	1
CBE51A	LSB-UEA11: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	A50.X1:14		E	1
CBE51B	LSB-UEA11: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	A50.X1:14		E	1
CBE51C	LSB-UEA11: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A50.X1:14		E	1
CBE51D	LSB-UEA11: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	A50.X1:14		E	1
CBE521	LSB-UEA11: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	A50.X1:14		E	1
CBE554	LSB-UEA11: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	A50.X1:14		E	1
CBE557	LSB-UEA11: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A50.X1:14		E	1
CBE559	LSB-UEA11: Switching output A4 supply voltage missing error indication on display Check line and fuse	A50.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE572	LSB-UEA11: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A50.X1:14		E	1
CBE612	LSB-UEA11: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A50.X1:15		E	1
CBE61A	LSB-UEA11: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	A50.X1:15		E	1
CBE61B	LSB-UEA11: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	A50.X1:15		E	1
CBE61C	LSB-UEA11: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A50.X1:15		E	1
CBE61D	LSB-UEA11: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	A50.X1:15		E	1
CBE621	LSB-UEA11: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	A50.X1:15		E	1
CBE654	LSB-UEA11: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	A50.X1:15		E	1
CBE657	LSB-UEA11: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A50.X1:15		E	1
CBE659	LSB-UEA11: Switching output A5 supply voltage missing error indication on display Check line and fuse	A50.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE672	LSB-UEA11: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A50.X1:15		E	1
CBE712	LSB-UEA11: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A50.X1:16		E	1
CBE71A	LSB-UEA11: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	A50.X1:16		E	1
CBE71B	LSB-UEA11: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	A50.X1:16		E	1
CBE71C	LSB-UEA11: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A50.X1:16		E	1
CBE71D	LSB-UEA11: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	A50.X1:16		E	1
CBE721	LSB-UEA11: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	A50.X1:16		E	1
CBE754	LSB-UEA11: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	A50.X1:16		E	1
CBE757	LSB-UEA11: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A50.X1:16		E	1
CBE759	LSB-UEA11: Switching output A6 supply voltage missing error indication on display Check line and fuse	A50.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE772	LSB-UEA11: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A50.X1:16		E	1
CBE812	LSB-UEA11: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A50.X1:17		E	1
CBE81A	LSB-UEA11: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	A50.X1:17		E	1
CBE81B	LSB-UEA11: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	A50.X1:17		E	1
CBE81C	LSB-UEA11: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A50.X1:17		E	1
CBE81D	LSB-UEA11: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	A50.X1:17		E	1
CBE821	LSB-UEA11: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	A50.X1:17		E	1
CBE854	LSB-UEA11: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	A50.X1:17		E	1
CBE857	LSB-UEA11: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A50.X1:17		E	1
CBE859	LSB-UEA11: Switching output A7 supply voltage missing error indication on display Check line and fuse	A50.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBE872	LSB-UEA11: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A50.X1:17		E	1
CBF001	LSB-UEA11: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module	A50		E	2
CBF006	LSB-UEA11: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module	A50		E	2
CBF013	LSB-UEA11: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A50		E	2
CBF016	LSB-UEA11: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A50		E	2
CBF031	LSB-UEA11: System error OS-CPU0 CPU-test faulty Module reset Replace module	A50		E	2
CBF050	LSB-UEA11: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software	A50		E	2
CBF068	LSB-UEA11: System error OS-CPU0 impermissible interrupt Module reset Replace module	A50		E	2
CBF070	LSB-UEA11: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module	A50		E	2
CBF071	LSB-UEA11: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module	A50		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBF073	LSB-UEA11: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A50		E	2
CBF075	LSB-UEA11: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module	A50		E	2
CBF078	LSB-UEA11: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service	A50		E	1
CBF080	LSB-UEA11: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module	A50		E	2
CBF082	LSB-UEA11: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A50		E	2
CBF088	LSB-UEA11: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module	A50		E	2
CBF089	LSB-UEA11: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module	A50		E	2
CBF090	LSB-UEA11: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module	A50		E	2
CBF0C1	LSB-UEA11: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A50		E	1
CBF113	LSB-UEA11: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A50		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBF15A	LSB-UEA11: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module	A50		E	2
CBF15B	LSB-UEA11: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane	A50		E	2
CBF170	LSB-UEA11: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors	A50		E	2
CBF175	LSB-UEA11: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit	A50		E	2
CBF1AC	LSB-UEA11: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)	A50		E	2
CBFA00	LSB-UEA11: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A50.X3:2/3		E	1
CBFA01	LSB-UEA11: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A50.X3:2/3		E	1
CBFA02	LSB-UEA11: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A50.X3:2/3		E	1
CBFA04	LSB-UEA11: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A50.X3:2/3		E	1
CBFA05	LSB-UEA11: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A50.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBFA06	LSB-UEA11: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A50.X3:2/3		E	2
CBFA11	LSB-UEA11: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A50.X3:2/3		E	1
CBFA32	LSB-UEA11: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A50.X3:2/3		E	1
CBFA40	LSB-UEA11: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A50.X3:2/3		E	1
CBFA41	LSB-UEA11: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A50.X3:2/3		E	1
CBFAB7	LSB-UEA11: Control data transfer CAN-A LSB-BTB11 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A50.X3:2/3		E	1
CBFB00	LSB-UEA11: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A50.X3:4/5		E	1
CBFB01	LSB-UEA11: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A50.X3:4/5		E	1
CBFB02	LSB-UEA11: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A50.X3:4/5		E	1
CBFB04	LSB-UEA11: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A50.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CBFB05	LSB-UEA11: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A50.X3:4/5		E	1
CBFB06	LSB-UEA11: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A50.X3:4/5		E	2
CBFB11	LSB-UEA11: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A50.X3:4/5		E	1
CBFB32	LSB-UEA11: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A50.X3:4/5		E	1
CBFB40	LSB-UEA11: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A50.X3:4/5		E	1
CBFB41	LSB-UEA11: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A50.X3:4/5		E	1
CC3824	LSB-UEA12: control slewing Slewing gear pressure sensor short circuit after ground or interruptio	A51		E	
CC3B1C	LSB-UEA12: Control ballasting / counterweight carriage Interruption bus connection(s)Actuation / release, zero force No release of coasting check wiring	A51		E	
CC3B1D	LSB-UEA12: Control ballasting / counterweight carriage Caution 2. shut off channel Ballast lowering brake permanent actuation	A51		E	
CC3B20	LSB-UEA12: Control ballasting / counterweight carriage Warning Limit switch Ballast cyl Block left erroneous / missing Output of error Check sensor on LSB for error or line interruption	A51		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CC3B21	LSB-UEA12: Control ballasting / counterweight carriage Warning Limit switch Ballast cyl Block right erroneous / missing Output of error Check sensor on LSB for error or line interruption	A51		E	
CC3B22	LSB-UEA12: Control ballasting / counterweight carriage Warning length sensor Ballast cyl left erroneous / missing Output of error Check sensor on LSB for error or line interruption	A51		E	
CC3B23	LSB-UEA12: Control ballasting / counterweight carriage Warning length sensor Ballast cyl right erroneous / missing Output of error Check sensor on LSB for error or line interruption	A51		E	
CC3B24	LSB-UEA12: Control ballasting / counterweight carriage Warning length sensor Ballast cyl. left defekt Output of error Check sensor on LSB for error or line interruption	A51		E	
CC3B25	LSB-UEA12: Control ballasting / counterweight carriage Warning length sensor Ballast cyl. right defek Output of error Check sensor on LSB for error or line interruption	A51		E	
CC3B26	LSB-UEA12: Control ballasting / counterweight carriage Leveling (B/BW)without function level sensor(B/BW) erroneous/missing Output of error Check sensor on LSB for error or line interruption	A51		E	
CC3B27	LSB-UEA12: Control ballasting / counterweight carriage Leveling(B/BW) no function -length sensor(B/BW) erroneous/missing Output of error Check sensor on LSB for error or line interruption	A51		E	
CC3B28	LSB-UEA12: Control ballasting / counterweight carriage Incline sensor ballast erroneous/missing, no shut off lateral incline Output of error Check sensor on LSB for error or line interruption	A51		E	
CC3B2F	LSB-UEA12: Control ballasting / counterweight carriage Caution Ballast Pallet outside perm. lateral incline operational shut down Drive ballast pallet in permissible direction with the lock buttons so that the pallet is at approx. 0 degrees	A51		E	
CC3B37	LSB-UEA12: Control ballasting / counterweight carriage Notice ext. cyl. moves IN/OUT without actuation	A51		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CC3B3A	LSB-UEA12: Control ballasting / counterweight carriage Caution, Ballast cyl. A moves down without actuation Output of error Check ballast cylinder, lowering brake for movement without actuation, set down load on ballast cylinder	A51		E	
CC3B3B	LSB-UEA12: Control ballasting / counterweight carriage Caution, Ballast cyl. B moves down without actuation Output of error Check ballast cylinder, lowering brake for movement without actuation, set down load on ballast cylinder	A51		E	
CC3B3C	LSB-UEA12: Control ballasting / counterweight carriage Caution, Ballast cyl. A moves up without actuation Output of error Check ballast cylinder, lowering brake for movement without actuation, set down load on ballast cylinder	A51		E	
CC3B3D	LSB-UEA12: Control ballasting / counterweight carriage Caution, Ballast cyl. B moves up without actuation Output of error Check ballast cylinder, lowering brake for movement without actuation, set down load on ballast cylinder	A51		E	
CC3B3E	LSB-UEA12: Control ballasting / counterweight carriage Shut off Ballasting up / down mandatory zero position Output of error Remedy shut-off, see operating error	A51		E	
CC3B3F	LSB-UEA12: Control ballasting / counterweight carriage Pressure supply B/BW short circuit after ground or interruption	A51		E	1
CC3C27	LSB-UEA12: Control crawler Brake pressure sensor Crawler left Short circuit after ground or inter Operational shut off Check sensor Brake pressure, check input in EA Diagnostics	A51		E	
CC3C28	LSB-UEA12: Control crawler Brake pressure sensor Crawler right Short circuit after ground or inte Operational shut off Check sensor Brake pressure, check input in EA Diagnostics	A51		E	
CC3F4A	LSB-UEA12: crane control Pressure supply HV short circuit after ground or interruption	A51		E	1
CC5B0A	LSB-UEA12: Operation ballasting / counterweight carriage Shut off button steering corr. BW left /right act. same time Error issue function blocked check wiring	A51		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CC5BAF	LSB-UEA12: Operation ballasting / counterweight carriage Simultaneous actuation in crane cab and extern Error issue function blocked Operate only from one op. location	A51		B	1
CC5BE0	LSB-UEA12: Operation ballasting / counterweight carriage Shut off button signal on inputs not two-channel Function blocked Release all buttons; check buttons, wiring	A51		E	
CC5BE1	LSB-UEA12: Operation ballasting / counterweight carriage Button steering correction BW turn left actuated at start or stuck Error issue function blocked check wiring	A51		B	1
CC5BE2	LSB-UEA12: Operation ballasting / counterweight carriage Button steering correction BW turn right actuated at start or klebt Error issue function blocked check wiring	A51		B	1
CC5BFC	LSB-UEA12: Operation ballasting / counterweight carriage No op. ballast cyl. possible since ballast automatic is active Output of error, crane function is not selected. Turn ballast autom. off TE1 Master sw. ass. changes, b. cyl. are w. master sw.	A51		B	
CC6108	LSB-UEA12: Operation crane control Caution adjustment program is active Program run acc. to selected set-up program End the set-up program properly via the stop button	A51		B	
CC613C	LSB-UEA12: Operation crane control Notice! Unplug control panel during crane operation! error report Unplug control panel, plug in dummy plug or check wiring	A51		E	
CC7007	LSB-UEA12: remote control Zero position compulsion on radio MS	A51		E	1
CC7019	LSB-UEA12: remote control No radio release (electrical signal not available)	A51		E	1
CC7090	LSB-UEA12: remote control Short circuit after supply voltage on radio input UEA	A51		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CC927C	LSB-UEA12: Control hydraulic Warning pressure supply B/BW < pmin with actuation Error issue function blocked Check sensor, check wiring	A51		E	1
CC927D	LSB-UEA12: Control hydraulic Warning pressure supply B/BW > pmin without actuation Error issue function blocked Check sensor, check wiring	A51		E	1
CC927E	LSB-UEA12: Control hydraulic Warning pressure supply HV < pmin with actuation Error issue function blocked Check sensor, check wiring	A51		E	1
CC927F	LSB-UEA12: Control hydraulic Warning pressure supply HV > pmin without actuation Error issue function blocked Check sensor, check wiring	A51		E	1
CC92D5	LSB-UEA12: Control hydraulic Warning Monitoring Pressure supply HV < pmin with actuation Error issue function blocked Check sensor, check wiring	A51		E	1
CC92D6	LSB-UEA12: Control hydraulic Warning Monitoring Pressure supply HV > pmin without actuation Error issue function blocked Check sensor, check wiring	A51		E	1
CC9900	LSB-UEA12: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A51		E	2
CC9901	LSB-UEA12: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A51		E	2
CC9902	LSB-UEA12: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A51		E	1
CC9904	LSB-UEA12: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A51		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CC9905	LSB-UEA12: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A51		E	1
CC9906	LSB-UEA12: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A51		E	2
CC9907	LSB-UEA12: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A51		E	1
CC9911	LSB-UEA12: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A51		E	2
CCC02A	LSB-UEA12: Diagnostics syst. band end/adj. program Length sensor min. length too small in currentless status	A51		B	
CCC02B	LSB-UEA12: Diagnostics syst. band end/adj. program Length sensor max. length too large in currentless status	A51		B	
CCC02C	LSB-UEA12: Diagnostics syst. band end/adj. program Length sensor max. length was exceeded during setting phase	A51		B	
CCC0C3	LSB-UEA12: Diagnostics syst. band end/adj. program F1: Engine RPM too low Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A51		B	
CCC0C4	LSB-UEA12: Diagnostics syst. band end/adj. program F2: Engine RPM too high Adj. program is interrupted, all movements turned off Engine RPM is autom. set at program start	A51		B	
CCC0C5	LSB-UEA12: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low Adj. program is interrupted, all movements turned off Increase hydr. oil temp. by carrying out a movement (Hoist gear)	A51		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCC0C6	LSB-UEA12: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high Adj. program is interrupted, all movements turned off Let hydraulic oil cool off	A51		B	
CCC0C8	LSB-UEA12: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low Adj. program is interrupted, all movements turned off Increase Qmin Pump (See Specification Pump)	A51		B	
CCC0C9	LSB-UEA12: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high Adj. program is interrupted, all movements turned off Decrease Qmin Pump (See Specification Pump)	A51		B	
CCC0CA	LSB-UEA12: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded Adj. program is interrupted, all movements turned off Pressure threshold was not recognized, try again (consult)	A51		B	
CCC0CB	LSB-UEA12: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range Adj. program is interrupted, all movements turned off No adj. value was found within current limits. Check hydraulic	A51		B	
CCC0CC	LSB-UEA12: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100% Adj. program is interrupted, all movements turned off Deflect master switch during adj. phase 100%	A51		B	
CCC0CF	LSB-UEA12: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out Adj. program is interrupted, all movements turned off Do not deflect both master switches for short time	A51		B	
CCC0D0	LSB-UEA12: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection Adj. program is interrupted, all movements turned off Change movement by act. F4-Button on keypad 1	A51		B	
CCC0D1	LSB-UEA12: Diagnostics syst. band end/adj. program F15: Angle sensor placement section: Lower limit angle reached Adj. program is interrupted, all movements turned off Carry out luff up movement until perm. tele angle is reached	A51		B	
CCC0DA	LSB-UEA12: Diagnostics syst. band end/adj. program F24: Pump flows not completely set Adj. program is interrupted, all movements turned off Set pump currents	A51		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCD502	LSB-UEA12: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A51.X2:1		E	1
CCD503	LSB-UEA12: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A51.X2:1		E	1
CCD513	LSB-UEA12: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	A51.X2:1		E	1
CCD602	LSB-UEA12: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A51.X2:2		E	1
CCD603	LSB-UEA12: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A51.X2:2		E	1
CCD613	LSB-UEA12: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	A51.X2:2		E	1
CCD702	LSB-UEA12: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A51.X2:4		E	1
CCD703	LSB-UEA12: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A51.X2:4		E	1
CCD713	LSB-UEA12: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	A51.X2:4		E	1
CCD802	LSB-UEA12: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A51.X2:5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCD803	LSB-UEA12: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A51.X2:5		E	1
CCD813	LSB-UEA12: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	A51.X2:5		E	1
CCD902	LSB-UEA12: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A51.X2:7		E	1
CCD903	LSB-UEA12: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A51.X2:7		E	1
CCD913	LSB-UEA12: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	A51.X2:7		E	1
CCDA02	LSB-UEA12: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A51.X2:8		E	1
CCDA03	LSB-UEA12: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A51.X2:8		E	1
CCDA13	LSB-UEA12: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	A51.X2:8		E	1
CCDB02	LSB-UEA12: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A51.X2:10		E	1
CCDB03	LSB-UEA12: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A51.X2:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCDB13	LSB-UEA12: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	A51.X2:10		E	1
CCDC02	LSB-UEA12: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	A51.X2:11		E	1
CCDC03	LSB-UEA12: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	A51.X2:11		E	1
CCDC13	LSB-UEA12: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	A51.X2:11		E	1
CCE112	LSB-UEA12: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A51.X1:10		E	1
CCE11A	LSB-UEA12: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	A51.X1:10		E	1
CCE11B	LSB-UEA12: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	A51.X1:10		E	1
CCE11C	LSB-UEA12: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A51.X1:10		E	1
CCE11D	LSB-UEA12: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	A51.X1:10		E	1
CCE121	LSB-UEA12: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	A51.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCE154	LSB-UEA12: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	A51.X1:10		E	1
CCE157	LSB-UEA12: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A51.X1:10		E	1
CCE159	LSB-UEA12: Switching output A0 supply voltage missing error indication on display Check line and fuse	A51.X1:10		E	1
CCE172	LSB-UEA12: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A51.X1:10		E	1
CCE212	LSB-UEA12: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A51.X1:11		E	1
CCE21A	LSB-UEA12: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	A51.X1:11		E	1
CCE21B	LSB-UEA12: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	A51.X1:11		E	1
CCE21C	LSB-UEA12: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A51.X1:11		E	1
CCE21D	LSB-UEA12: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	A51.X1:11		E	1
CCE221	LSB-UEA12: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	A51.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCE254	LSB-UEA12: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	A51.X1:11		E	1
CCE257	LSB-UEA12: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A51.X1:11		E	1
CCE259	LSB-UEA12: Switching output A1 supply voltage missing error indication on display Check line and fuse	A51.X1:11		E	1
CCE272	LSB-UEA12: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A51.X1:11		E	1
CCE312	LSB-UEA12: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A51.X1:12		E	1
CCE31A	LSB-UEA12: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	A51.X1:12		E	1
CCE31B	LSB-UEA12: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	A51.X1:12		E	1
CCE31C	LSB-UEA12: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A51.X1:12		E	1
CCE31D	LSB-UEA12: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	A51.X1:12		E	1
CCE321	LSB-UEA12: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	A51.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCE354	LSB-UEA12: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	A51.X1:12		E	1
CCE357	LSB-UEA12: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A51.X1:12		E	1
CCE359	LSB-UEA12: Switching output A2 supply voltage missing error indication on display Check line and fuse	A51.X1:12		E	1
CCE372	LSB-UEA12: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A51.X1:12		E	1
CCE412	LSB-UEA12: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A51.X1:13		E	1
CCE41A	LSB-UEA12: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	A51.X1:13		E	1
CCE41B	LSB-UEA12: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	A51.X1:13		E	1
CCE41C	LSB-UEA12: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A51.X1:13		E	1
CCE41D	LSB-UEA12: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	A51.X1:13		E	1
CCE421	LSB-UEA12: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	A51.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCE454	LSB-UEA12: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	A51.X1:13		E	1
CCE457	LSB-UEA12: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A51.X1:13		E	1
CCE459	LSB-UEA12: Switching output A3 supply voltage missing error indication on display Check line and fuse	A51.X1:13		E	1
CCE472	LSB-UEA12: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A51.X1:13		E	1
CCE512	LSB-UEA12: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A51.X1:14		E	1
CCE51A	LSB-UEA12: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	A51.X1:14		E	1
CCE51B	LSB-UEA12: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	A51.X1:14		E	1
CCE51C	LSB-UEA12: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A51.X1:14		E	1
CCE51D	LSB-UEA12: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	A51.X1:14		E	1
CCE521	LSB-UEA12: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	A51.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCE554	LSB-UEA12: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	A51.X1:14		E	1
CCE557	LSB-UEA12: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A51.X1:14		E	1
CCE559	LSB-UEA12: Switching output A4 supply voltage missing error indication on display Check line and fuse	A51.X1:14		E	1
CCE572	LSB-UEA12: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A51.X1:14		E	1
CCE612	LSB-UEA12: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A51.X1:15		E	1
CCE61A	LSB-UEA12: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	A51.X1:15		E	1
CCE61B	LSB-UEA12: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	A51.X1:15		E	1
CCE61C	LSB-UEA12: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A51.X1:15		E	1
CCE61D	LSB-UEA12: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	A51.X1:15		E	1
CCE621	LSB-UEA12: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	A51.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCE654	LSB-UEA12: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	A51.X1:15		E	1
CCE657	LSB-UEA12: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A51.X1:15		E	1
CCE659	LSB-UEA12: Switching output A5 supply voltage missing error indication on display Check line and fuse	A51.X1:15		E	1
CCE672	LSB-UEA12: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A51.X1:15		E	1
CCE712	LSB-UEA12: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A51.X1:16		E	1
CCE71A	LSB-UEA12: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	A51.X1:16		E	1
CCE71B	LSB-UEA12: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	A51.X1:16		E	1
CCE71C	LSB-UEA12: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A51.X1:16		E	1
CCE71D	LSB-UEA12: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	A51.X1:16		E	1
CCE721	LSB-UEA12: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	A51.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCE754	LSB-UEA12: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	A51.X1:16		E	1
CCE757	LSB-UEA12: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A51.X1:16		E	1
CCE759	LSB-UEA12: Switching output A6 supply voltage missing error indication on display Check line and fuse	A51.X1:16		E	1
CCE772	LSB-UEA12: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A51.X1:16		E	1
CCE812	LSB-UEA12: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	A51.X1:17		E	1
CCE81A	LSB-UEA12: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	A51.X1:17		E	1
CCE81B	LSB-UEA12: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	A51.X1:17		E	1
CCE81C	LSB-UEA12: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	A51.X1:17		E	1
CCE81D	LSB-UEA12: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	A51.X1:17		E	1
CCE821	LSB-UEA12: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	A51.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCE854	LSB-UEA12: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	A51.X1:17		E	1
CCE857	LSB-UEA12: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	A51.X1:17		E	1
CCE859	LSB-UEA12: Switching output A7 supply voltage missing error indication on display Check line and fuse	A51.X1:17		E	1
CCE872	LSB-UEA12: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	A51.X1:17		E	1
CCF001	LSB-UEA12: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module	A51		E	2
CCF006	LSB-UEA12: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module	A51		E	2
CCF013	LSB-UEA12: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A51		E	2
CCF016	LSB-UEA12: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A51		E	2
CCF031	LSB-UEA12: System error OS-CPU0 CPU-test faulty Module reset Replace module	A51		E	2
CCF050	LSB-UEA12: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software	A51		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCF068	LSB-UEA12: System error OS-CPU0 impermissible interrupt Module reset Replace module	A51		E	2
CCF070	LSB-UEA12: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module	A51		E	2
CCF071	LSB-UEA12: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module	A51		E	2
CCF073	LSB-UEA12: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download	A51		E	2
CCF075	LSB-UEA12: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module	A51		E	2
CCF078	LSB-UEA12: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service	A51		E	1
CCF080	LSB-UEA12: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module	A51		E	2
CCF082	LSB-UEA12: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A51		E	2
CCF088	LSB-UEA12: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module	A51		E	2
CCF089	LSB-UEA12: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module	A51		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCF090	LSB-UEA12: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module	A51		E	2
CCF0C1	LSB-UEA12: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A51		E	1
CCF113	LSB-UEA12: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A51		E	2
CCF15A	LSB-UEA12: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module	A51		E	2
CCF15B	LSB-UEA12: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane	A51		E	2
CCF170	LSB-UEA12: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors	A51		E	2
CCF175	LSB-UEA12: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit	A51		E	2
CCF1AC	LSB-UEA12: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)	A51		E	2
CCFA00	LSB-UEA12: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A51.X3:2/3		E	1
CCFA01	LSB-UEA12: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A51.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCFA02	LSB-UEA12: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A51.X3:2/3		E	1
CCFA04	LSB-UEA12: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A51.X3:2/3		E	1
CCFA05	LSB-UEA12: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A51.X3:2/3		E	1
CCFA06	LSB-UEA12: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A51.X3:2/3		E	2
CCFA11	LSB-UEA12: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A51.X3:2/3		E	1
CCFA32	LSB-UEA12: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A51.X3:2/3		E	1
CCFA40	LSB-UEA12: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A51.X3:2/3		E	1
CCFA41	LSB-UEA12: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A51.X3:2/3		E	1
CCFB00	LSB-UEA12: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A51.X3:4/5		E	1
CCFB01	LSB-UEA12: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A51.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CCFB02	LSB-UEA12: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A51.X3:4/5		E	1
CCFB04	LSB-UEA12: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A51.X3:4/5		E	1
CCFB05	LSB-UEA12: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A51.X3:4/5		E	1
CCFB06	LSB-UEA12: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A51.X3:4/5		E	2
CCFB11	LSB-UEA12: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A51.X3:4/5		E	1
CCFB32	LSB-UEA12: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A51.X3:4/5		E	1
CCFB40	LSB-UEA12: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	A51.X3:4/5		E	1
CCFB41	LSB-UEA12: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A51.X3:4/5		E	1
CE3B10	LSB-UEA14: Control ballasting / counterweight carriage Module software not compatible to crane -> module needs update Error output and ballast trailer function locked Perform software update (update application) on the module UEA14.			E	1
CE3B11	LSB-UEA14: Control ballasting / counterweight carriage Ball. trailer software not compatible to crane -> update BT applic.			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CE3B1C	LSB-UEA14: Control ballasting / counterweight carriage Interruption bus connection(s)Actuation / release, zero force No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error			B	1
CE3B38	LSB-UEA14: Control ballasting / counterweight carriage Notice Wheel set left turns without actuation Error output Check valve and wiring			E	
CE3B39	LSB-UEA14: Control ballasting / counterweight carriage Notice Wheel set right turns without actuation Error output Check valve and wiring			E	
CE3B40	LSB-UEA14: Control ballasting / counterweight carriage Monitoring E0, Diagnostics for wheel set brake interrupted Error issue function blocked check wiring			E	1
CE3B41	LSB-UEA14: Control ballasting / counterweight carriage Valve line wheel set brake has short circuit after ground Error issue function blocked check wiring			E	1
CE3B42	LSB-UEA14: Control ballasting / counterweight carriage Valve line wheel set brake has short circuit after Ubatt Error issue function blocked check wiring			E	1
CE5B69	LSB-UEA14: Operation ballasting / counterweight carriage Shut off T. wheel set le. turn le. stuck or actuated at start Error issue function blocked check wiring			B	1
CE5B6A	LSB-UEA14: Operation ballasting / counterweight carriage Shut off T. wheel set le. turn ri. stuck or actuated at start Error issue function blocked check wiring			B	1
CE5B6B	LSB-UEA14: Operation ballasting / counterweight carriage Shut off T. wheel set ri. turn le. stuck or actuated at start Error issue function blocked check wiring			B	1
CE5B6C	LSB-UEA14: Operation ballasting / counterweight carriage Shut off T. wheel set ri. turn ri. stuck or actuated at start Error issue function blocked check wiring			B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CE5C10	LSB-UEA14: Operation crawler Shut off drive crawler BW Pull force > Fmax			E	1
CE6108	LSB-UEA14: Operation crane control Caution adjustment program is active			E	1
CE9900	LSB-UEA14: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device			E	2
CE9901	LSB-UEA14: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device			E	2
CE9902	LSB-UEA14: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software			E	1
CE9904	LSB-UEA14: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software			E	1
CE9905	LSB-UEA14: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software			E	1
CE9906	LSB-UEA14: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device			E	2
CE9907	LSB-UEA14: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service			E	1
CE9911	LSB-UEA14: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEC098	LSB-UEA14: Diagnostics syst. band end/adj. program F76: Var. motor currents not completely set			E	1
CEC0C3	LSB-UEA14: Diagnostics syst. band end/adj. program F1: Engine RPM too low			E	1
CEC0C4	LSB-UEA14: Diagnostics syst. band end/adj. program F2: Engine RPM too high			E	1
CEC0C5	LSB-UEA14: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low			E	1
CEC0C6	LSB-UEA14: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high			E	1
CEC0C8	LSB-UEA14: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low			E	1
CEC0C9	LSB-UEA14: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high			E	1
CEC0CA	LSB-UEA14: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded			E	1
CEC0CB	LSB-UEA14: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range			E	1
CEC0CC	LSB-UEA14: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100%			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEC0CF	LSB-UEA14: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out			E	1
CEC0D0	LSB-UEA14: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection			E	1
CEC0DA	LSB-UEA14: Diagnostics syst. band end/adj. program F24: Pump flows not completely set			E	1
CED502	LSB-UEA14: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:1		E	1
CED503	LSB-UEA14: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:1		E	1
CED513	LSB-UEA14: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:1		E	1
CED602	LSB-UEA14: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:2		E	1
CED603	LSB-UEA14: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:2		E	1
CED613	LSB-UEA14: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:2		E	1
CED702	LSB-UEA14: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CED703	LSB-UEA14: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:4		E	1
CED713	LSB-UEA14: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:4		E	1
CED802	LSB-UEA14: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:5		E	1
CED803	LSB-UEA14: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:5		E	1
CED813	LSB-UEA14: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:5		E	1
CED902	LSB-UEA14: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:7		E	1
CED903	LSB-UEA14: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:7		E	1
CED913	LSB-UEA14: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:7		E	1
CEDA02	LSB-UEA14: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:8		E	1
CEDA03	LSB-UEA14: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEDA13	LSB-UEA14: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:8		E	1
CEDB02	LSB-UEA14: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:10		E	1
CEDB03	LSB-UEA14: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:10		E	1
CEDB13	LSB-UEA14: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:10		E	1
CEDC02	LSB-UEA14: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:11		E	1
CEDC03	LSB-UEA14: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:11		E	1
CEDC13	LSB-UEA14: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:11		E	1
CEE112	LSB-UEA14: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:10		E	1
CEE11A	LSB-UEA14: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	.X1:10		E	1
CEE11B	LSB-UEA14: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEE11C	LSB-UEA14: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:10		E	1
CEE11D	LSB-UEA14: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	.X1:10		E	1
CEE121	LSB-UEA14: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	.X1:10		E	1
CEE154	LSB-UEA14: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	.X1:10		E	1
CEE157	LSB-UEA14: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:10		E	1
CEE159	LSB-UEA14: Switching output A0 supply voltage missing error indication on display Check line and fuse	.X1:10		E	1
CEE172	LSB-UEA14: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:10		E	1
CEE212	LSB-UEA14: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:11		E	1
CEE21A	LSB-UEA14: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	.X1:11		E	1
CEE21B	LSB-UEA14: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEE21C	LSB-UEA14: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:11		E	1
CEE21D	LSB-UEA14: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	.X1:11		E	1
CEE221	LSB-UEA14: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	.X1:11		E	1
CEE254	LSB-UEA14: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	.X1:11		E	1
CEE257	LSB-UEA14: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:11		E	1
CEE259	LSB-UEA14: Switching output A1 supply voltage missing error indication on display Check line and fuse	.X1:11		E	1
CEE272	LSB-UEA14: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:11		E	1
CEE312	LSB-UEA14: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:12		E	1
CEE31A	LSB-UEA14: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	.X1:12		E	1
CEE31B	LSB-UEA14: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEE31C	LSB-UEA14: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:12		E	1
CEE31D	LSB-UEA14: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	.X1:12		E	1
CEE321	LSB-UEA14: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	.X1:12		E	1
CEE354	LSB-UEA14: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	.X1:12		E	1
CEE357	LSB-UEA14: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:12		E	1
CEE359	LSB-UEA14: Switching output A2 supply voltage missing error indication on display Check line and fuse	.X1:12		E	1
CEE372	LSB-UEA14: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:12		E	1
CEE412	LSB-UEA14: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:13		E	1
CEE41A	LSB-UEA14: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	.X1:13		E	1
CEE41B	LSB-UEA14: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEE41C	LSB-UEA14: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:13		E	1
CEE41D	LSB-UEA14: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	.X1:13		E	1
CEE421	LSB-UEA14: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	.X1:13		E	1
CEE454	LSB-UEA14: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	.X1:13		E	1
CEE457	LSB-UEA14: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:13		E	1
CEE459	LSB-UEA14: Switching output A3 supply voltage missing error indication on display Check line and fuse	.X1:13		E	1
CEE472	LSB-UEA14: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:13		E	1
CEE512	LSB-UEA14: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:14		E	1
CEE51A	LSB-UEA14: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	.X1:14		E	1
CEE51B	LSB-UEA14: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEE51C	LSB-UEA14: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:14		E	1
CEE51D	LSB-UEA14: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	.X1:14		E	1
CEE521	LSB-UEA14: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	.X1:14		E	1
CEE554	LSB-UEA14: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	.X1:14		E	1
CEE557	LSB-UEA14: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:14		E	1
CEE559	LSB-UEA14: Switching output A4 supply voltage missing error indication on display Check line and fuse	.X1:14		E	1
CEE572	LSB-UEA14: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:14		E	1
CEE612	LSB-UEA14: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:15		E	1
CEE61A	LSB-UEA14: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	.X1:15		E	1
CEE61B	LSB-UEA14: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEE61C	LSB-UEA14: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:15		E	1
CEE61D	LSB-UEA14: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	.X1:15		E	1
CEE621	LSB-UEA14: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	.X1:15		E	1
CEE654	LSB-UEA14: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	.X1:15		E	1
CEE657	LSB-UEA14: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:15		E	1
CEE659	LSB-UEA14: Switching output A5 supply voltage missing error indication on display Check line and fuse	.X1:15		E	1
CEE672	LSB-UEA14: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:15		E	1
CEE712	LSB-UEA14: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:16		E	1
CEE71A	LSB-UEA14: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	.X1:16		E	1
CEE71B	LSB-UEA14: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEE71C	LSB-UEA14: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:16		E	1
CEE71D	LSB-UEA14: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	.X1:16		E	1
CEE721	LSB-UEA14: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	.X1:16		E	1
CEE754	LSB-UEA14: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	.X1:16		E	1
CEE757	LSB-UEA14: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:16		E	1
CEE759	LSB-UEA14: Switching output A6 supply voltage missing error indication on display Check line and fuse	.X1:16		E	1
CEE772	LSB-UEA14: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:16		E	1
CEE812	LSB-UEA14: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:17		E	1
CEE81A	LSB-UEA14: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	.X1:17		E	1
CEE81B	LSB-UEA14: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEE81C	LSB-UEA14: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:17		E	1
CEE81D	LSB-UEA14: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	.X1:17		E	1
CEE821	LSB-UEA14: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	.X1:17		E	1
CEE854	LSB-UEA14: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	.X1:17		E	1
CEE857	LSB-UEA14: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:17		E	1
CEE859	LSB-UEA14: Switching output A7 supply voltage missing error indication on display Check line and fuse	.X1:17		E	1
CEE872	LSB-UEA14: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:17		E	1
CEF001	LSB-UEA14: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module			E	2
CEF006	LSB-UEA14: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module			E	2
CEF013	LSB-UEA14: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEF016	LSB-UEA14: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module			E	2
CEF031	LSB-UEA14: System error OS-CPU0 CPU-test faulty Module reset Replace module			E	2
CEF050	LSB-UEA14: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software			E	2
CEF068	LSB-UEA14: System error OS-CPU0 impermissible interrupt Module reset Replace module			E	2
CEF070	LSB-UEA14: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module			E	2
CEF071	LSB-UEA14: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module			E	2
CEF073	LSB-UEA14: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download			E	2
CEF075	LSB-UEA14: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module			E	2
CEF078	LSB-UEA14: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service			E	1
CEF080	LSB-UEA14: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEF082	LSB-UEA14: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module			E	2
CEF088	LSB-UEA14: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module			E	2
CEF089	LSB-UEA14: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module			E	2
CEF090	LSB-UEA14: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module			E	2
CEF0C1	LSB-UEA14: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version			E	1
CEF113	LSB-UEA14: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module			E	2
CEF15A	LSB-UEA14: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module			E	2
CEF15B	LSB-UEA14: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane			E	2
CEF170	LSB-UEA14: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors			E	2
CEF175	LSB-UEA14: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEF1AC	LSB-UEA14: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)			E	2
CEFA00	LSB-UEA14: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	.X3:2/3		E	1
CEFA01	LSB-UEA14: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	.X3:2/3		E	1
CEFA02	LSB-UEA14: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	.X3:2/3		E	1
CEFA04	LSB-UEA14: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	.X3:2/3		E	1
CEFA05	LSB-UEA14: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	.X3:2/3		E	1
CEFA06	LSB-UEA14: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	.X3:2/3		E	2
CEFA11	LSB-UEA14: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	.X3:2/3		E	1
CEFA32	LSB-UEA14: Control data transfer CAN-A Data transfer erroneous/missing check wiring	.X3:2/3		E	1
CEFA40	LSB-UEA14: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	.X3:2/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEFA41	LSB-UEA14: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	.X3:2/3		E	1
CEFB00	LSB-UEA14: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	.X3:4/5		E	1
CEFB01	LSB-UEA14: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	.X3:4/5		E	1
CEFB02	LSB-UEA14: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	.X3:4/5		E	1
CEFB04	LSB-UEA14: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	.X3:4/5		E	1
CEFB05	LSB-UEA14: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	.X3:4/5		E	1
CEFB06	LSB-UEA14: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	.X3:4/5		E	2
CEFB11	LSB-UEA14: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	.X3:4/5		E	1
CEFB32	LSB-UEA14: Control data transfer CAN-B Data transfer erroneous/missing check wiring	.X3:4/5		E	1
CEFB40	LSB-UEA14: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	.X3:4/5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CEFB41	LSB-UEA14: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	.X3:4/5		E	1
CF3B10	LSB-UEA15: Control ballasting / counterweight carriage Module software not compatible to crane -> module needs update Error output and ballast trailer function locked Perform software update (update application) on the module UEA15.			E	1
CF3B11	LSB-UEA15: Control ballasting / counterweight carriage Ball. trailer software not compatible to crane -> update BT applic.			E	1
CF3B14	LSB-UEA15: Control ballasting / counterweight carriage Data trans (LSB) between crane and counte. carriage interrupted Error issue function blocked check wiring			E	1
CF3B1A	LSB-UEA15: Control ballasting / counterweight carriage Data transfer (CAN) between crane and ballast trailer faulty Error issue function blocked check wiring			E	1
CF3B43	LSB-UEA15: Control ballasting / counterweight carriage Valve drive Wheel set left forward stuck error report Check wiring and valves			E	
CF3B44	LSB-UEA15: Control ballasting / counterweight carriage Valve drive Wheel set left reverse stuck error report Check wiring and valves			E	
CF3B45	LSB-UEA15: Control ballasting / counterweight carriage Valve drive Wheel set right forward stuck error report Check wiring and valves			E	
CF3B46	LSB-UEA15: Control ballasting / counterweight carriage Valve drive Wheel set right reverse stuck error report Check wiring and valves			E	
CF3B47	LSB-UEA15: Control ballasting / counterweight carriage Valve support ballast trailer UP / DOWN stuck error report Check wiring and valves			E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CF3B48	LSB-UEA15: Control ballasting / counterweight carriage Flow switch Support does not switch at movement selection			E	1
CF3B49	LSB-UEA15: Control ballasting / counterweight carriage Valve drive left forward does not switch when selected			E	1
CF3B4A	LSB-UEA15: Control ballasting / counterweight carriage Valve drive left reverse does not switch when selected			E	1
CF3B4B	LSB-UEA15: Control ballasting / counterweight carriage Valve drive right forward does not switch when selected			E	1
CF3B4C	LSB-UEA15: Control ballasting / counterweight carriage Valve drive right reverse does not switch when selected			E	1
CF3B50	LSB-UEA15: Control ballasting / counterweight carriage Signal Brake pr. sensor short circuit after ground or interruption			E	1
CF5B42	LSB-UEA15: Operation ballasting / counterweight carriage Brakes of wheel drive blocked – rotation speed to high Error issue function blocked Reduce slewing speed			B	1
CF5C10	LSB-UEA15: Operation crawler Shut off drive crawler BW Pull force > Fmax			E	1
CF6108	LSB-UEA15: Operation crane control Caution adjustment program is active			E	1
CF9900	LSB-UEA15: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CF9901	LSB-UEA15: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device			E	2
CF9902	LSB-UEA15: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software			E	1
CF9904	LSB-UEA15: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software			E	1
CF9905	LSB-UEA15: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software			E	1
CF9906	LSB-UEA15: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device			E	2
CF9907	LSB-UEA15: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service			E	1
CF9911	LSB-UEA15: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus			E	2
CFC08F	LSB-UEA15: Diagnostics syst. band end/adj. program F79: Supply voltage outside permissible range			E	1
CFC098	LSB-UEA15: Diagnostics syst. band end/adj. program F76: Var. motor currents not completely set			E	1
CFC0C3	LSB-UEA15: Diagnostics syst. band end/adj. program F1: Engine RPM too low			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFC0C4	LSB-UEA15: Diagnostics syst. band end/adj. program F2: Engine RPM too high			E	1
CFC0C5	LSB-UEA15: Diagnostics syst. band end/adj. program F3: Hydraulic oil temperature too low			E	1
CFC0C6	LSB-UEA15: Diagnostics syst. band end/adj. program F4: Hydraulic oil temperature too high			E	1
CFC0C8	LSB-UEA15: Diagnostics syst. band end/adj. program F6: Pump pressure Qmin in no current cond. too low			E	1
CFC0C9	LSB-UEA15: Diagnostics syst. band end/adj. program F7: Pump pressure Qmin in no current cond. too high			E	1
CFC0CA	LSB-UEA15: Diagnostics syst. band end/adj. program F8: Max. pump pressure during adjustment phase exceeded			E	1
CFC0CB	LSB-UEA15: Diagnostics syst. band end/adj. program F9: New adjustment value not in permissible range			E	1
CFC0CC	LSB-UEA15: Diagnostics syst. band end/adj. program F10: Master switch during adjustment phase not deflected by 100%			E	1
CFC0CF	LSB-UEA15: Diagnostics syst. band end/adj. program F13: Zero pos. mandatory master switch not carried out			E	1
CFC0D0	LSB-UEA15: Diagnostics syst. band end/adj. program F14: Incorrect movement is on Master switch selection			E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFC0DA	LSB-UEA15: Diagnostics syst. band end/adj. program F24: Pump flows not completely set			E	1
CFC0F6	LSB-UEA15: Diagnostics syst. band end/adj. program F52: Motor is not turned off			E	1
CFD502	LSB-UEA15: Analog input E0 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:1		E	1
CFD503	LSB-UEA15: Analog input E0 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:1		E	1
CFD513	LSB-UEA15: Analog input E0 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:1		E	1
CFD602	LSB-UEA15: Analog input E1 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:2		E	1
CFD603	LSB-UEA15: Analog input E1 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:2		E	1
CFD613	LSB-UEA15: Analog input E1 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:2		E	1
CFD702	LSB-UEA15: Analog input E2 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:4		E	1
CFD703	LSB-UEA15: Analog input E2 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFD713	LSB-UEA15: Analog input E2 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:4		E	1
CFD802	LSB-UEA15: Analog input E3 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:5		E	1
CFD803	LSB-UEA15: Analog input E3 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:5		E	1
CFD813	LSB-UEA15: Analog input E3 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:5		E	1
CFD902	LSB-UEA15: Analog input E4 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:7		E	1
CFD903	LSB-UEA15: Analog input E4 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:7		E	1
CFD913	LSB-UEA15: Analog input E4 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:7		E	1
CFDA02	LSB-UEA15: Analog input E5 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:8		E	1
CFDA03	LSB-UEA15: Analog input E5 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:8		E	1
CFDA13	LSB-UEA15: Analog input E5 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFDB02	LSB-UEA15: Analog input E6 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:10		E	1
CFDB03	LSB-UEA15: Analog input E6 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:10		E	1
CFDB13	LSB-UEA15: Analog input E6 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:10		E	1
CFDC02	LSB-UEA15: Analog input E7 sensor deficiency data short circuit to supply voltage error indication on display Input voltage outside of permissible value range	.X2:11		E	1
CFDC03	LSB-UEA15: Analog input E7 sensor deficiency data short circuit to ground error indication on display Input voltage outside of permissible value range	.X2:11		E	1
CFDC13	LSB-UEA15: Analog input E7 open signal circuits error indication on display Input voltage outside of permissible value range	.X2:11		E	1
CFDD03	LSB-UEA15: Digital input E8 sensor deficiency data short circuit to ground error report Check wiring	.X2:18		E	
CFDE03	LSB-UEA15: Digital input E9 sensor deficiency data short circuit to ground error report Check wiring	.X2:19		E	
CFDF03	LSB-UEA15: Digital input E10 sensor deficiency data short circuit to ground error report Check wiring	.X2:20		E	
CFE003	LSB-UEA15: Digital input E11 sensor deficiency data short circuit to ground error report Check wiring	.X2:21		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFE112	LSB-UEA15: Switching output A0 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:10		E	1
CFE11A	LSB-UEA15: Switching output A0 User incorrect or erroneous error indication on display Check user resistance and line	.X1:10		E	1
CFE11B	LSB-UEA15: Switching output A0 digital shut off defective error indication on display Replace LSB_UEA	.X1:10		E	1
CFE11C	LSB-UEA15: Switching output A0 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:10		E	1
CFE11D	LSB-UEA15: Switching output A0 Initial current outside permissible range error indication on display Check line connection and user	.X1:10		E	1
CFE121	LSB-UEA15: Switching output A0 invalid data record error indication on display Inform customer service Software-Update required	.X1:10		E	1
CFE154	LSB-UEA15: Switching output A0 short circuit to supply voltage error indication on display Check line connection and user	.X1:10		E	1
CFE157	LSB-UEA15: Switching output A0 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:10		E	1
CFE159	LSB-UEA15: Switching output A0 supply voltage missing error indication on display Check line and fuse	.X1:10		E	1
CFE172	LSB-UEA15: Switching output A0 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:10		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFE212	LSB-UEA15: Switching output A1 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:11		E	1
CFE21A	LSB-UEA15: Switching output A1 User incorrect or erroneous error indication on display Check user resistance and line	.X1:11		E	1
CFE21B	LSB-UEA15: Switching output A1 digital shut off defective error indication on display Replace LSB_UEA	.X1:11		E	1
CFE21C	LSB-UEA15: Switching output A1 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:11		E	1
CFE21D	LSB-UEA15: Switching output A1 Initial current outside permissible range error indication on display Check line connection and user	.X1:11		E	1
CFE221	LSB-UEA15: Switching output A1 invalid data record error indication on display Inform customer service Software-Update required	.X1:11		E	1
CFE254	LSB-UEA15: Switching output A1 short circuit to supply voltage error indication on display Check line connection and user	.X1:11		E	1
CFE257	LSB-UEA15: Switching output A1 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:11		E	1
CFE259	LSB-UEA15: Switching output A1 supply voltage missing error indication on display Check line and fuse	.X1:11		E	1
CFE272	LSB-UEA15: Switching output A1 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:11		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFE312	LSB-UEA15: Switching output A2 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:12		E	1
CFE31A	LSB-UEA15: Switching output A2 User incorrect or erroneous error indication on display Check user resistance and line	.X1:12		E	1
CFE31B	LSB-UEA15: Switching output A2 digital shut off defective error indication on display Replace LSB_UEA	.X1:12		E	1
CFE31C	LSB-UEA15: Switching output A2 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:12		E	1
CFE31D	LSB-UEA15: Switching output A2 Initial current outside permissible range error indication on display Check line connection and user	.X1:12		E	1
CFE321	LSB-UEA15: Switching output A2 invalid data record error indication on display Inform customer service Software-Update required	.X1:12		E	1
CFE354	LSB-UEA15: Switching output A2 short circuit to supply voltage error indication on display Check line connection and user	.X1:12		E	1
CFE357	LSB-UEA15: Switching output A2 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:12		E	1
CFE359	LSB-UEA15: Switching output A2 supply voltage missing error indication on display Check line and fuse	.X1:12		E	1
CFE372	LSB-UEA15: Switching output A2 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFE412	LSB-UEA15: Switching output A3 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:13		E	1
CFE41A	LSB-UEA15: Switching output A3 User incorrect or erroneous error indication on display Check user resistance and line	.X1:13		E	1
CFE41B	LSB-UEA15: Switching output A3 digital shut off defective error indication on display Replace LSB_UEA	.X1:13		E	1
CFE41C	LSB-UEA15: Switching output A3 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:13		E	1
CFE41D	LSB-UEA15: Switching output A3 Initial current outside permissible range error indication on display Check line connection and user	.X1:13		E	1
CFE421	LSB-UEA15: Switching output A3 invalid data record error indication on display Inform customer service Software-Update required	.X1:13		E	1
CFE454	LSB-UEA15: Switching output A3 short circuit to supply voltage error indication on display Check line connection and user	.X1:13		E	1
CFE457	LSB-UEA15: Switching output A3 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:13		E	1
CFE459	LSB-UEA15: Switching output A3 supply voltage missing error indication on display Check line and fuse	.X1:13		E	1
CFE472	LSB-UEA15: Switching output A3 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFE512	LSB-UEA15: Switching output A4 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:14		E	1
CFE51A	LSB-UEA15: Switching output A4 User incorrect or erroneous error indication on display Check user resistance and line	.X1:14		E	1
CFE51B	LSB-UEA15: Switching output A4 digital shut off defective error indication on display Replace LSB_UEA	.X1:14		E	1
CFE51C	LSB-UEA15: Switching output A4 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:14		E	1
CFE51D	LSB-UEA15: Switching output A4 Initial current outside permissible range error indication on display Check line connection and user	.X1:14		E	1
CFE521	LSB-UEA15: Switching output A4 invalid data record error indication on display Inform customer service Software-Update required	.X1:14		E	1
CFE554	LSB-UEA15: Switching output A4 short circuit to supply voltage error indication on display Check line connection and user	.X1:14		E	1
CFE557	LSB-UEA15: Switching output A4 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:14		E	1
CFE559	LSB-UEA15: Switching output A4 supply voltage missing error indication on display Check line and fuse	.X1:14		E	1
CFE572	LSB-UEA15: Switching output A4 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:14		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFE612	LSB-UEA15: Switching output A5 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:15		E	1
CFE61A	LSB-UEA15: Switching output A5 User incorrect or erroneous error indication on display Check user resistance and line	.X1:15		E	1
CFE61B	LSB-UEA15: Switching output A5 digital shut off defective error indication on display Replace LSB_UEA	.X1:15		E	1
CFE61C	LSB-UEA15: Switching output A5 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:15		E	1
CFE61D	LSB-UEA15: Switching output A5 Initial current outside permissible range error indication on display Check line connection and user	.X1:15		E	1
CFE621	LSB-UEA15: Switching output A5 invalid data record error indication on display Inform customer service Software-Update required	.X1:15		E	1
CFE654	LSB-UEA15: Switching output A5 short circuit to supply voltage error indication on display Check line connection and user	.X1:15		E	1
CFE657	LSB-UEA15: Switching output A5 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:15		E	1
CFE659	LSB-UEA15: Switching output A5 supply voltage missing error indication on display Check line and fuse	.X1:15		E	1
CFE672	LSB-UEA15: Switching output A5 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFE712	LSB-UEA15: Switching output A6 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:16		E	1
CFE71A	LSB-UEA15: Switching output A6 User incorrect or erroneous error indication on display Check user resistance and line	.X1:16		E	1
CFE71B	LSB-UEA15: Switching output A6 digital shut off defective error indication on display Replace LSB_UEA	.X1:16		E	1
CFE71C	LSB-UEA15: Switching output A6 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:16		E	1
CFE71D	LSB-UEA15: Switching output A6 Initial current outside permissible range error indication on display Check line connection and user	.X1:16		E	1
CFE721	LSB-UEA15: Switching output A6 invalid data record error indication on display Inform customer service Software-Update required	.X1:16		E	1
CFE754	LSB-UEA15: Switching output A6 short circuit to supply voltage error indication on display Check line connection and user	.X1:16		E	1
CFE757	LSB-UEA15: Switching output A6 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:16		E	1
CFE759	LSB-UEA15: Switching output A6 supply voltage missing error indication on display Check line and fuse	.X1:16		E	1
CFE772	LSB-UEA15: Switching output A6 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:16		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFE812	LSB-UEA15: Switching output A7 short circuit to ground Limitation short circuit current by 2. shut off channel error indication on display Check connection to user and user	.X1:17		E	1
CFE81A	LSB-UEA15: Switching output A7 User incorrect or erroneous error indication on display Check user resistance and line	.X1:17		E	1
CFE81B	LSB-UEA15: Switching output A7 digital shut off defective error indication on display Replace LSB_UEA	.X1:17		E	1
CFE81C	LSB-UEA15: Switching output A7 Current regulator defective Shut off of defective channel error indication on display Replace LSB_UEA	.X1:17		E	1
CFE81D	LSB-UEA15: Switching output A7 Initial current outside permissible range error indication on display Check line connection and user	.X1:17		E	1
CFE821	LSB-UEA15: Switching output A7 invalid data record error indication on display Inform customer service Software-Update required	.X1:17		E	1
CFE854	LSB-UEA15: Switching output A7 short circuit to supply voltage error indication on display Check line connection and user	.X1:17		E	1
CFE857	LSB-UEA15: Switching output A7 open circuit or short circuit to supply voltage error indication on display Check line connection and user	.X1:17		E	1
CFE859	LSB-UEA15: Switching output A7 supply voltage missing error indication on display Check line and fuse	.X1:17		E	1
CFE872	LSB-UEA15: Switching output A7 outside source feeding error indication on display Shut off outlet shows initial voltage of > 2,5V	.X1:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFF001	LSB-UEA15: System error OS-CPU0 initialising error processor-register erroneous Module reset Replace module			E	2
CFF006	LSB-UEA15: System error OS-CPU0 initialising error RAM erroneous Module reset Replace module			E	2
CFF013	LSB-UEA15: System error OS-CPU0 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module			E	2
CFF016	LSB-UEA15: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module			E	2
CFF031	LSB-UEA15: System error OS-CPU0 CPU-test faulty Module reset Replace module			E	2
CFF050	LSB-UEA15: System error OS-CPU0 Correction with synchronisation > 1ms, although already synchronised error report Reload application software			E	2
CFF068	LSB-UEA15: System error OS-CPU0 impermissible interrupt Module reset Replace module			E	2
CFF070	LSB-UEA15: System error OS-CPU0 WContradiction in structures error indication on display Inform Service of all error parameters and replace module			E	2
CFF071	LSB-UEA15: System error OS-CPU0 Invalid configuration or Firmware error indication on display Replace module			E	2
CFF073	LSB-UEA15: System error OS-CPU0 interpreter error error indication on display Report all error parameter to Service and replace module. At P0=00000013 carry out download			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFF075	LSB-UEA15: System error OS-CPU0 SPI -Error, data transfer erroneous error indication on display Inform Service of all error parameters and replace module			E	2
CFF078	LSB-UEA15: System error OS-CPU0 impermissible parameter Module reset Report all error parameters to Service			E	1
CFF080	LSB-UEA15: System error OS-CPU0 fatal internal software error Module reset Inform Service of all error parameters and replace module			E	2
CFF082	LSB-UEA15: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module			E	2
CFF088	LSB-UEA15: System error OS-CPU0 Configuration does not match software condition error indication on display Load correct software onto module			E	2
CFF089	LSB-UEA15: System error OS-CPU0 Incorrect version of firmware installed Entry in error stack Replace module			E	2
CFF090	LSB-UEA15: System error OS-CPU0 Incorrect hardware version recognised Entry in error stack Replace module			E	2
CFF0C1	LSB-UEA15: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version			E	1
CFF113	LSB-UEA15: System error OS-CPU1 test total in EPROM/FLASH erroneous error indication on display Inform Service of all error parameters and replace module			E	2
CFF15A	LSB-UEA15: System error OS-CPU1 LSB-Parameter block has erroneous test sum Entry in error stack Assign via test system LSB-Default parameter to module			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFF15B	LSB-UEA15: System error OS-CPU1 Test sum via incremental counter erroneous Entry in error stack Set via test system a IZW of module to 0. Restart crane			E	2
CFF170	LSB-UEA15: System error OS-CPU1 WContradiction in structures error report Load systems again on both processors			E	2
CFF175	LSB-UEA15: System error OS-CPU1 SPI -Error, data transfer erroneous error report Load systems again on both processors, if error not remedied, replace unit			E	2
CFF1AC	LSB-UEA15: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Restore via test system the CWs of module (load CWs)			E	2
CFFA00	LSB-UEA15: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	.X3:2/3		E	1
CFFA01	LSB-UEA15: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	.X3:2/3		E	1
CFFA02	LSB-UEA15: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	.X3:2/3		E	1
CFFA04	LSB-UEA15: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	.X3:2/3		E	1
CFFA05	LSB-UEA15: Control data transfer CAN-A Configuration error IOX-gateway AEW-gateway already active or not configured Check software	.X3:2/3		E	1
CFFA06	LSB-UEA15: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	.X3:2/3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFFA11	LSB-UEA15: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	.X3:2/3		E	1
CFFA32	LSB-UEA15: Control data transfer CAN-A Data transfer erroneous/missing check wiring	.X3:2/3		E	1
CFFA40	LSB-UEA15: Control data transfer CAN-A Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	.X3:2/3		E	1
CFFA41	LSB-UEA15: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	.X3:2/3		E	1
CFFB00	LSB-UEA15: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	.X3:4/5		E	1
CFFB01	LSB-UEA15: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	.X3:4/5		E	1
CFFB02	LSB-UEA15: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	.X3:4/5		E	1
CFFB04	LSB-UEA15: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	.X3:4/5		E	1
CFFB05	LSB-UEA15: Control data transfer CAN-B Configuration error IOX-gateway AEW-gateway already active or not configured Check software	.X3:4/5		E	1
CFFB06	LSB-UEA15: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	.X3:4/5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
CFFB11	LSB-UEA15: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	.X3:4/5		E	1
CFFB32	LSB-UEA15: Control data transfer CAN-B Data transfer erroneous/missing check wiring	.X3:4/5		E	1
CFFB40	LSB-UEA15: Control data transfer CAN-B Undefined error code (J1939, SPN) Associated error text cannot be called up Report all error parameters to Service	.X3:4/5		E	1
CFFB41	LSB-UEA15: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	.X3:4/5		E	1
D0D061	Winch turn sensor1: Supply measuring system defect Output of error Voltage supply sensor too high, check voltage, if volt. ok, then replace sensor	B501.X1:1		E	2
D0D568	Winch turn sensor1: Input E0 open circuit or short circuit to supply voltage/ground Output of error Check pressure sensor-analog signal line, if nec. replace pressure sensor or winch turn sensor	B501.X1:7		E	2
D0F060	Winch turn sensor1: Operating error Sensor wrong / not adjusted Variable overflow Output of error Readjust sensor with button or parameter P6 and P7 (coils, layers)	B501		B	2
D0F110	Winch turn sensor1: System error inadmissible signal difference Operation conditional switch off, may not be shunted replace sensor through new part	B501		E	2
D0F113	Winch turn sensor1: System error test total in EPROM/FLASH erroneous Operation conditional switch off, may not be shunted In LSB-sensor screen of test system: take over default values, or replace sensor	B501		E	2
D0F11B	Winch turn sensor1: System error digital shut off defective Issue of error, 2. Shut off 'winch spooled out' not working replace sensor through new part	B501		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
D0F120	Winch turn sensor1: System error saving error Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	B501		E	2
D0F124	Winch turn sensor1: System error pre-warning disruption limit 1 Output of error Replace external EEPROM	B501		E	2
D0F15D	Winch turn sensor1: System error Load collective counter too high / Prewarning Output of error Check winch	B501		E	2
D0F161	Winch turn sensor1: System error measuring system defect Operation conditional switch off, may not be shunted replace sensor through new part	B501		E	2
D0F180	Winch turn sensor1: System error fatal internal software error Operation conditional switch off, may not be shunted replace sensor through new part	B501		E	2
D0F1FF	Winch turn sensor1: System error Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B501		E	2
D0FC1B	Winch turn sensor1: Control data transfer LSB-A digital shut off defective Operation conditional switch off, may not be shunted replace sensor through new part	B501.X1:3		E	2
D0FCFF	Winch turn sensor1: Control data transfer LSB-A Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B501.X1:3		E	2
D1D061	Winch turn sensor2: Supply measuring system defect Output of error Voltage supply sensor too high, check voltage, if volt. ok, then replace sensor	B502.X1:1		E	2
D1D568	Winch turn sensor2: Input E0 open circuit or short circuit to supply voltage/ground Output of error Check pressure sensor-analog signal line, if nec. replace pressure sensor or winch turn sensor	B502.X1:7		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
D1F060	Winch turn sensor2: Operating error Sensor wrong / not adjusted Variable overflow Output of error Readjust sensor with button or parameter P6 and P7 (coils, layers)	B502		B	2
D1F110	Winch turn sensor2: System error inadmissible signal difference Operation conditional switch off, may not be shunted replace sensor through new part	B502		E	2
D1F113	Winch turn sensor2: System error test total in EPROM/FLASH erroneous Operation conditional switch off, may not be shunted In LSB-sensor screen of test system: take over default values, or replace sensor	B502		E	2
D1F11B	Winch turn sensor2: System error digital shut off defective Issue of error, 2. Shut off 'winch spooled out' not working replace sensor through new part	B502		E	2
D1F120	Winch turn sensor2: System error saving error Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	B502		E	2
D1F124	Winch turn sensor2: System error pre-warning disruption limit 1 Output of error Replace external EEPROM	B502		E	2
D1F15D	Winch turn sensor2: System error Load collective counter too high / Prewarning Output of error Check winch	B502		E	2
D1F161	Winch turn sensor2: System error measuring system defect Operation conditional switch off, may not be shunted replace sensor through new part	B502		E	2
D1F180	Winch turn sensor2: System error fatal internal software error Operation conditional switch off, may not be shunted replace sensor through new part	B502		E	2
D1F1FF	Winch turn sensor2: System error Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B502		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
D1FC1B	Winch turn sensor2: Control data transfer LSB-A digital shut off defective Operation conditional switch off, may not be shunted replace sensor through new part	B502.X1:3		E	2
D1FCFF	Winch turn sensor2: Control data transfer LSB-A Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B502.X1:3		E	2
D3D061	Winch turn sensor4: Supply measuring system defect Output of error Voltage supply sensor too high, check voltage, if volt. ok, then replace sensor	B504.X1:1		E	2
D3D568	Winch turn sensor4: Input E0 open circuit or short circuit to supply voltage/ground Output of error Check pressure sensor-analog signal line, if nec. replace pressure sensor or winch turn sensor	B504.X1:7		E	2
D3F060	Winch turn sensor4: Operating error Sensor wrong / not adjusted Variable overflow Output of error Readjust sensor with button or parameter P6 and P7 (coils, layers)	B504		B	2
D3F110	Winch turn sensor4: System error inadmissible signal difference Operation conditional switch off, may not be shunted replace sensor through new part	B504		E	2
D3F113	Winch turn sensor4: System error test total in EPROM/FLASH erroneous Operation conditional switch off, may not be shunted In LSB-sensor screen of test system: take over default values, or replace sensor	B504		E	2
D3F11B	Winch turn sensor4: System error digital shut off defective Issue of error, 2. Shut off 'winch spooled out' not working replace sensor through new part	B504		E	2
D3F120	Winch turn sensor4: System error saving error Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	B504		E	2
D3F124	Winch turn sensor4: System error pre-warning disruption limit 1 Output of error Replace external EEPROM	B504		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
D3F15D	Winch turn sensor4: System error Load collective counter too high / Prewarning Output of error Check winch	B504		E	2
D3F161	Winch turn sensor4: System error measuring system defect Operation conditional switch off, may not be shunted replace sensor through new part	B504		E	2
D3F180	Winch turn sensor4: System error fatal internal software error Operation conditional switch off, may not be shunted replace sensor through new part	B504		E	2
D3F1FF	Winch turn sensor4: System error Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B504		E	2
D3FC1B	Winch turn sensor4: Control data transfer LSB-A digital shut off defective Operation conditional switch off, may not be shunted replace sensor through new part	B504.X1:3		E	2
D3FCFF	Winch turn sensor4: Control data transfer LSB-A Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B504.X1:3		E	2
D4D061	Winch turn sensor5: Supply measuring system defect Output of error Voltage supply sensor too high, check voltage, if volt. ok, then replace sensor	B1905.X1:1		E	2
D4D568	Winch turn sensor5: Input E0 open circuit or short circuit to supply voltage/ground Output of error Check pressure sensor-analog signal line, if nec. replace pressure sensor or winch turn sensor	B1905.X1:7		E	2
D4F060	Winch turn sensor5: Operating error Sensor wrong / not adjusted Variable overflow Output of error Readjust sensor with button or parameter P6 and P7 (coils, layers)	B1905		B	2
D4F110	Winch turn sensor5: System error inadmissable signal difference Operation conditional switch off, may not be shunted replace sensor through new part	B1905		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
D4F113	Winch turn sensor5: System error test total in EPROM/FLASH erroneous Operation conditional switch off, may not be shunted In LSB-sensor screen of test system: take over default values, or replace sensor	B1905		E	2
D4F11B	Winch turn sensor5: System error digital shut off defective Issue of error, 2. Shut off 'winch spooled out' not working replace sensor through new part	B1905		E	2
D4F120	Winch turn sensor5: System error saving error Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	B1905		E	2
D4F124	Winch turn sensor5: System error pre-warning disruption limit 1 Output of error Replace external EEPROM	B1905		E	2
D4F15D	Winch turn sensor5: System error Load collective counter too high / Prewarning Output of error Check winch	B1905		E	2
D4F161	Winch turn sensor5: System error measuring system defect Operation conditional switch off, may not be shunted replace sensor through new part	B1905		E	2
D4F180	Winch turn sensor5: System error fatal internal software error Operation conditional switch off, may not be shunted replace sensor through new part	B1905		E	2
D4F1FF	Winch turn sensor5: System error Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B1905		E	2
D4FC1B	Winch turn sensor5: Control data transfer LSB-A digital shut off defective Operation conditional switch off, may not be shunted replace sensor through new part	B1905.X1:3		E	2
D4FCFF	Winch turn sensor5: Control data transfer LSB-A Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B1905.X1:3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
D9D061	Winch turn sensor3: Supply measuring system defect Output of error Voltage supply sensor too high, check voltage, if volt. ok, then replace sensor	B2063.X1:1		E	2
D9D568	Winch turn sensor3: Input E0 open circuit or short circuit to supply voltage/ground Output of error Check pressure sensor-analog signal line, if nec. replace pressure sensor or winch turn sensor	B2063.X1:7		E	2
D9F060	Winch turn sensor3: Operating error Sensor wrong / not adjusted Variable overflow Output of error Readjust sensor with button or parameter P6 and P7 (coils, layers)	B2063		B	2
D9F110	Winch turn sensor3: System error inadmissible signal difference Operation conditional switch off, may not be shunted replace sensor through new part	B2063		E	2
D9F113	Winch turn sensor3: System error test total in EPROM/FLASH erroneous Operation conditional switch off, may not be shunted In LSB-sensor screen of test system: take over default values, or replace sensor	B2063		E	2
D9F11B	Winch turn sensor3: System error digital shut off defective Issue of error, 2. Shut off 'winch spooled out' not working replace sensor through new part	B2063		E	2
D9F120	Winch turn sensor3: System error saving error Operation conditional switch off, may not be shunted Reload data on external EEPROM, otherwise replace external EEPROM	B2063		E	2
D9F124	Winch turn sensor3: System error pre-warning disruption limit 1 Output of error Replace external EEPROM	B2063		E	2
D9F15D	Winch turn sensor3: System error Load collective counter too high / Prewarning Output of error Check winch	B2063		E	2
D9F161	Winch turn sensor3: System error measuring system defect Operation conditional switch off, may not be shunted replace sensor through new part	B2063		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
D9F180	Winch turn sensor3: System error fatal internal software error Operation conditional switch off, may not be shunted replace sensor through new part	B2063		E	2
D9F1FF	Winch turn sensor3: System error Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B2063		E	2
D9FC1B	Winch turn sensor3: Control data transfer LSB-A digital shut off defective Operation conditional switch off, may not be shunted replace sensor through new part	B2063.X1:3		E	2
D9FCFF	Winch turn sensor3: Control data transfer LSB-A Synchronization channel A,B did not work Operation conditional switch off, may not be shunted replace sensor through new part	B2063.X1:3		E	2
E0000F	Master switch1: Inputs different information on other processor Module reset Replace module	A301		E	2
E00704	Master switch1: System voltage CPU/Logic / CPU0 level exceeded error report Inform Service of all error parameters and replace module	A301		E	0
E00705	Master switch1: System voltage CPU/Logic / CPU0 below minimum level error report Inform Service of all error parameters and replace module	A301		E	2
E0070F	Master switch1: System voltage CPU/Logic / CPU0 different information on other processor error report Inform Service of all error parameters and replace module	A301		E	2
E00804	Master switch1: Supply voltage 24V.1-2 / CPU0 level exceeded error report Check supplies, replace module	A301.X1:1		E	0
E00805	Master switch1: Supply voltage 24V.1-2 / CPU0 below minimum level error report Check supplies, replace module	A301.X1:1		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E0080F	Master switch1: Supply voltage 24V.1-2 / CPU0 different information on other processor error report Check supplies, replace module	A301.X1:1		E	2
E00B02	Master switch1: Switching output A0 HS (X) sensor deficiency data short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B03	Master switch1: Switching output A0 HS (X) sensor deficiency data short circuit to ground Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B12	Master switch1: Switching output A0 HS (X) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B13	Master switch1: Switching output A0 HS (X) open signal circuits Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B1A	Master switch1: Switching output A0 HS (X) User incorrect or erroneous Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B1B	Master switch1: Switching output A0 HS (X) digital shut off defective Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B1C	Master switch1: Switching output A0 HS (X) Current regulator defective Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B1D	Master switch1: Switching output A0 HS (X) Initial current outside permissible range Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B54	Master switch1: Switching output A0 HS (X) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E00B57	Master switch1: Switching output A0 HS (X) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B59	Master switch1: Switching output A0 HS (X) supply voltage missing Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00B72	Master switch1: Switching output A0 HS (X) outside source feeding Entry in error stack Report all error parameters to Service	A301.X1:3		E	2
E00C02	Master switch1: Switching output A1 HS (Y) sensor deficiency data short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C03	Master switch1: Switching output A1 HS (Y) sensor deficiency data short circuit to ground Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C12	Master switch1: Switching output A1 HS (Y) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C13	Master switch1: Switching output A1 HS (Y) open signal circuits Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C1A	Master switch1: Switching output A1 HS (Y) User incorrect or erroneous Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C1B	Master switch1: Switching output A1 HS (Y) digital shut off defective Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C1C	Master switch1: Switching output A1 HS (Y) Current regulator defective Entry in error stack Report all error parameters to Service	A301.X1:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E00C1D	Master switch1: Switching output A1 HS (Y) Initial current outside permissible range Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C54	Master switch1: Switching output A1 HS (Y) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C57	Master switch1: Switching output A1 HS (Y) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C59	Master switch1: Switching output A1 HS (Y) supply voltage missing Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00C72	Master switch1: Switching output A1 HS (Y) outside source feeding Entry in error stack Report all error parameters to Service	A301.X1:5		E	2
E00D12	Master switch1: Switching output A2 HS (X) short circuit to ground Error display on display, shut off of outlets Check connection to user and user	A301.X1:2		E	2
E00D13	Master switch1: Switching output A2 HS (X) open signal circuits Error display on display, shut off of outlets Input voltage outside of permissible value range	A301.X1:2		E	2
E00D1A	Master switch1: Switching output A2 HS (X) User incorrect or erroneous Error display on display, shut off of outlets Check user resistance and line	A301.X1:2		E	2
E00D1B	Master switch1: Switching output A2 HS (X) digital shut off defective Error display on display, shut off of outlets Replace LSB_AMS	A301.X1:2		E	2
E00D54	Master switch1: Switching output A2 HS (X) short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A301.X1:2		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E00D57	Master switch1: Switching output A2 HS (X) open circuit or short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A301.X1:2		E	2
E00E12	Master switch1: Switching output A3 HS (Y) short circuit to ground Error display on display, shut off of outlets Check connection to user and user	A301.X1:4		E	2
E00E13	Master switch1: Switching output A3 HS (Y) open signal circuits Error display on display, shut off of outlets Input voltage outside of permissible value range	A301.X1:4		E	2
E00E1A	Master switch1: Switching output A3 HS (Y) User incorrect or erroneous Error display on display, shut off of outlets Check user resistance and line	A301.X1:4		E	2
E00E1B	Master switch1: Switching output A3 HS (Y) digital shut off defective Error display on display, shut off of outlets Replace LSB_AMS	A301.X1:4		E	2
E00E54	Master switch1: Switching output A3 HS (Y) short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A301.X1:4		E	2
E00E57	Master switch1: Switching output A3 HS (Y) open circuit or short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A301.X1:4		E	2
E01C0F	Master switch1: Hand part different information on other processor Entry in error stack Report all error parameters to Service	A301		E	2
E01D21	Master switch1: Adjustment values in EEPROM / CPU0 invalid data record Entry in error stack Report all error parameters to Service	A301		E	2
E01EA0	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 0) Error display on display, entry in error stack Replace module	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E01EA1	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 1) Error display on display, entry in error stack Replace module	A301		E	2
E01EA2	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 2) Error display on display, entry in error stack Replace module	A301		E	2
E01EA3	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 3) Error display on display, entry in error stack Replace module	A301		E	2
E01EA4	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 4) Error display on display, entry in error stack Replace module	A301		E	2
E01EA5	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 5) Error display on display, entry in error stack Replace module	A301		E	2
E01EA6	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 6) Error display on display, entry in error stack Replace module	A301		E	2
E01EA7	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 7) Error display on display, entry in error stack Replace module	A301		E	2
E01EA8	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 8) Error display on display, entry in error stack Replace module	A301		E	2
E01EA9	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 9) Error display on display, entry in error stack Replace module	A301		E	2
E01EAA	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 10) Error display on display, entry in error stack Replace module	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E01EAB	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 11) Error display on display, entry in error stack Replace module	A301		E	2
E01EAC	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 12) Error display on display, entry in error stack Replace module	A301		E	2
E01EAD	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 13) Error display on display, entry in error stack Replace module	A301		E	2
E01EAE	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 14) Error display on display, entry in error stack Replace module	A301		E	2
E01EAF	Master switch1: X/Y- deflection unit / CPU0 Test system is erroneous (Error 15) Error display on display, entry in error stack Replace module	A301		E	2
E02013	Master switch1: System error OS-CPU0 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A301		E	2
E02016	Master switch1: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A301		E	2
E02033	Master switch1: System error OS-CPU0 Different Signature error indication on display Report all error parameters to Service and replace module. Carry out download	A301		E	2
E02068	Master switch1: System error OS-CPU0 impermissible interrupt Module reset Replace module	A301		E	2
E02071	Master switch1: System error OS-CPU0 Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E02073	Master switch1: System error OS-CPU0 interpreter error error indication on display Inform Service of all error parameters and replace module	A301		E	2
E02075	Master switch1: System error OS-CPU0 SPI-error error indication on display Inform Service of all error parameters and replace module	A301		E	2
E02078	Master switch1: System error OS-CPU0 impermissible parameter Error display on display, entry in error stack Inform Service of all error parameters and replace module	A301		E	2
E02080	Master switch1: System error OS-CPU0 Fatal internal error Module reset Inform Service of all error parameters and replace module	A301		E	2
E02082	Master switch1: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A301		E	2
E020D0	Master switch1: System error OS-CPU0 Voltage drop Entry in error stack Report all error parameters to Service	A301		E	2
E020D1	Master switch1: System error OS-CPU0 Program stopped Entry in error memory, program is stopped (master switch not functional) Start crane again	A301		E	2
E02401	Master switch1: Control Data transfer LSB-A / CPU0 initialising error processor-register erroneous Entry in error stack Report all error parameters to Service	A301.X1:8		E	2
E03001	Master switch1: Control / CPU0 Operating mode (Inputs) has changed since turn on No crane movement (Outlet) via this master switch, error message Check Mode-Inputs	A301		E	2
E03002	Master switch1: Control / CPU0 Operating mode (Inputs) does not match configuration No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E03003	Master switch1: Control / CPU0 Operating mode does not match other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E03004	Master switch1: Control / CPU0 Operating mode does not match LSB-Parameter No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E03005	Master switch1: Control / CPU0 No valid operating mode (crane op. / emerg. operation) No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E03008	Master switch1: Control / CPU0 No / impermissible outlet switching configured No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E03009	Master switch1: Control / CPU0 Configured outlet switching differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E0300A	Master switch1: Control / CPU0 Configuration data differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E03010	Master switch1: Control / CPU0 CAN-communication with UEA-Module erroneous/missing No crane movement (Outlet) via this master switch, error message Check CAN-connection, load LSB-Parameter(CAN-Ids via LSB-Parameter)	A301		E	2
E03011	Master switch1: Control / CPU0 LSB-communication with LSB-Master erroneous/missing No crane movement (Outlet) via this master switch, error message Check LSB-connection	A301		E	2
E03012	Master switch1: Control / CPU0 Communication with other channel (SPI) erroneous/missing No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A301		E	2
E03020	Master switch1: Control / CPU0 Not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E03021	Master switch1: Control / CPU0 Other channel not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A301		E	2
E03022	Master switch1: Control / CPU0 Deflection has too high dynamics Entry in error stack Do not operate Master switch jerkily	A301		E	2
E03030	Master switch1: Control / CPU0 Shut off collective error No crane movement (Outlet) via this master switch, error message Observe error messages, start crane again (ignition OFF/ON), replace master switch	A301		E	2
E03040	Master switch1: Control / CPU0 No ground potential switched at active PWM-Outlet Y front No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E03041	Master switch1: Control / CPU0 No ground potential switched at active PWM-Outlet Y rear No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E03042	Master switch1: Control / CPU0 No ground potential switched at active Digital-Outlet Y Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E03043	Master switch1: Control / CPU0 No ground potential switched at active PWM-Outlet X left No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E03044	Master switch1: Control / CPU0 No ground potential switched at active PWM-Outlet X right No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E03045	Master switch1: Control / CPU0 No ground potential switched at active Digital-Outlet X Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E03050	Master switch1: Control / CPU0 Initial error No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E03051	Master switch1: Control / CPU0 Output error Output X-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E03052	Master switch1: Control / CPU0 Output error Output Y-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E08704	Master switch1: System voltage CPU/Logic / CPU1 level exceeded error report Inform Service of all error parameters and replace module	A301		E	0
E08705	Master switch1: System voltage CPU/Logic / CPU1 below minimum level error report Inform Service of all error parameters and replace module	A301		E	2
E0870F	Master switch1: System voltage CPU/Logic / CPU1 different information on other processor error report Inform Service of all error parameters and replace module	A301		E	2
E08804	Master switch1: Supply voltage 24V.1-2 / CPU1 level exceeded error report Check supplies, replace module	A301.X1:1		E	0
E08805	Master switch1: Supply voltage 24V.1-2 / CPU1 below minimum level error report Check supplies, replace module	A301.X1:1		E	0
E0880F	Master switch1: Supply voltage 24V.1-2 / CPU1 different information on other processor error indication on display Report all error parameters to Service	A301.X1:1		E	2
E08F12	Master switch1: Switching output A4 LS (X+/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X2:4		E	2
E08F54	Master switch1: Switching output A4 LS (X+/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E08F57	Master switch1: Switching output A4 LS (X+/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:4		E	2
E09012	Master switch1: Switching output A5 LS (X+/A2) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X2:3		E	2
E09054	Master switch1: Switching output A5 LS (X+/A2) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:3		E	2
E09057	Master switch1: Switching output A5 LS (X+/A2) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:3		E	2
E09112	Master switch1: Switching output A6 LS (X-/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X2:6		E	2
E09154	Master switch1: Switching output A6 LS (X-/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:6		E	2
E09157	Master switch1: Switching output A6 LS (X-/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:6		E	2
E09212	Master switch1: Switching output A7 LS (X-/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X2:5		E	2
E09254	Master switch1: Switching output A7 LS (X-/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:5		E	2
E09257	Master switch1: Switching output A7 LS (X-/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E09312	Master switch1: Switching output A8 LS (Y+/A1) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X2:10		E	2
E09354	Master switch1: Switching output A8 LS (Y+/A1) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:10		E	2
E09357	Master switch1: Switching output A8 LS (Y+/A1) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:10		E	2
E09412	Master switch1: Switching output A9 LS (Y+/A3) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X2:9		E	2
E09454	Master switch1: Switching output A9 LS (Y+/A3) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:9		E	2
E09457	Master switch1: Switching output A9 LS (Y+/A3) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:9		E	2
E09512	Master switch1: Switching output A10 LS (Y-/A1) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X2:12		E	2
E09554	Master switch1: Switching output A10 LS (Y-/A1) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:12		E	2
E09557	Master switch1: Switching output A10 LS (Y-/A1) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:12		E	2
E09612	Master switch1: Switching output A11 LS (Y-/A3) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X2:11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E09654	Master switch1: Switching output A11 LS (Y-/A3) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:11		E	2
E09657	Master switch1: Switching output A11 LS (Y-/A3) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X2:11		E	2
E09712	Master switch1: Switching output A12 LS (X) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X1:11		E	2
E09754	Master switch1: Switching output A12 LS (X) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:11		E	2
E09757	Master switch1: Switching output A12 LS (X) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:11		E	2
E09812	Master switch1: Switching output A13 LS (Y) short circuit to ground Entry in error stack Report all error parameters to Service	A301.X1:12		E	2
E09854	Master switch1: Switching output A13 LS (Y) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:12		E	2
E09857	Master switch1: Switching output A13 LS (Y) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A301.X1:12		E	2
E09918	Master switch1: Switching output A4, A5, A6, A7, A12 (X) excess temperature Entry in error stack Report all error parameters to Service	A301.X2:3/4/5/6		E	2
E09A18	Master switch1: Switching output A8, A9, A10, A11, A13 (Y) excess temperature Entry in error stack Report all error parameters to Service	A301.X2:9/10/11		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E09C0F	Master switch1: Hand part different information on other processor Entry in error stack Report all error parameters to Service	A301		E	2
E09D21	Master switch1: Adjustment values in EEPROM / CPU1 invalid data record error indication on display Inform Service of all error parameters and replace module	A301		E	2
E09EA0	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 0) Error display on display, entry in error stack Replace module	A301		E	2
E09EA1	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 1) Error display on display, entry in error stack Replace module	A301		E	2
E09EA2	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 2) Error display on display, entry in error stack Replace module	A301		E	2
E09EA3	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 3) Error display on display, entry in error stack Replace module	A301		E	2
E09EA4	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 4) Error display on display, entry in error stack Replace module	A301		E	2
E09EA5	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 5) Error display on display, entry in error stack Replace module	A301		E	2
E09EA6	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 6) Error display on display, entry in error stack Replace module	A301		E	2
E09EA7	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 7) Error display on display, entry in error stack Replace module	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E09EA8	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 8) Error display on display, entry in error stack Replace module	A301		E	2
E09EA9	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 9) Error display on display, entry in error stack Replace module	A301		E	2
E09EAA	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 10) Error display on display, entry in error stack Replace module	A301		E	2
E09EAB	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 11) Error display on display, entry in error stack Replace module	A301		E	2
E09EAC	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 12) Error display on display, entry in error stack Replace module	A301		E	2
E09EAD	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 13) Error display on display, entry in error stack Replace module	A301		E	2
E09EAE	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 14) Error display on display, entry in error stack Replace module	A301		E	2
E09EAF	Master switch1: X/Y- deflection unit / CPU1 Test system is erroneous (Error 15) Error display on display, entry in error stack Replace module	A301		E	2
E0A013	Master switch1: System error OS-CPU1 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A301		E	2
E0A016	Master switch1: System error OS-CPU1 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E0A033	Master switch1: System error OS-CPU1 Different Signature error indication on display Report all error parameters to Service and replace module. Carry out download	A301		E	2
E0A068	Master switch1: System error OS-CPU1 impermissible interrupt Module reset Replace module	A301		E	2
E0A071	Master switch1: System error OS-CPU1 Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module	A301		E	2
E0A073	Master switch1: System error OS-CPU1 interpreter error error indication on display Inform Service of all error parameters and replace module	A301		E	2
E0A075	Master switch1: System error OS-CPU1 SPI-error error indication on display Inform Service of all error parameters and replace module	A301		E	2
E0A078	Master switch1: System error OS-CPU1 impermissible parameter error indication on display Inform Service of all error parameters and replace module	A301		E	2
E0A080	Master switch1: System error OS-CPU1 Fatal internal error Module reset Inform Service of all error parameters and replace module	A301		E	2
E0A082	Master switch1: System error OS-CPU1 hardware-watchdog erroneous Module reset Replace module	A301		E	2
E0A0D0	Master switch1: System error OS-CPU1 Voltage drop Entry in error stack Report all error parameters to Service	A301		E	2
E0A0D1	Master switch1: System error OS-CPU1 Program stopped Entry in error memory, program is stopped (master switch not functional) Start crane again	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E0A401	Master switch1: Control Data transfer LSB-B / CPU1 initialising error processor-register erroneous Entry in error stack Report all error parameters to Service	A301.X2:8		E	2
E0B001	Master switch1: Control / CPU1 Operating mode (Inputs) has changed since turn on No crane movement (Outlet) via this master switch, error message Check Mode-Inputs	A301		E	2
E0B002	Master switch1: Control / CPU1 Operating mode (Inputs) does not match configuration No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E0B003	Master switch1: Control / CPU1 Operating mode does not match other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E0B004	Master switch1: Control / CPU1 Operating mode does not match LSB-Parameter No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E0B005	Master switch1: Control / CPU1 No valid operating mode (crane op. / emerg. operation) No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E0B008	Master switch1: Control / CPU1 No / impermissible outlet switching configured No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E0B009	Master switch1: Control / CPU1 Configured outlet switching differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E0B00A	Master switch1: Control / CPU1 Configuration data differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A301		E	2
E0B010	Master switch1: Control / CPU1 CAN-communication with UEA-Module erroneous/missing No crane movement (Outlet) via this master switch, error message Check CAN-connection, load LSB-Parameter(CAN-Ids via LSB-Parameter)	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E0B011	Master switch1: Control / CPU1 LSB-communication with LSB-Master erroneous/missing No crane movement (Outlet) via this master switch, error message Check LSB-connection	A301		E	2
E0B012	Master switch1: Control / CPU1 Communication with other channel (SPI) erroneous/missing No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A301		E	2
E0B020	Master switch1: Control / CPU1 Not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A301		E	2
E0B021	Master switch1: Control / CPU1 Other channel not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A301		E	2
E0B022	Master switch1: Control / CPU1 Deflection has too high dynamics Entry in error stack Do not operate Master switch jerkily	A301		E	2
E0B030	Master switch1: Control / CPU1 Shut off collective error No crane movement (Outlet) via this master switch, error message Observe error messages, start crane again (ignition OFF/ON), replace master switch	A301		E	2
E0B040	Master switch1: Control / CPU1 No ground potential switched at active PWM-Outlet Y front No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E0B041	Master switch1: Control / CPU1 No ground potential switched at active PWM-Outlet Y rear No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E0B042	Master switch1: Control / CPU1 No ground potential switched at active Digital-Outlet Y Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E0B043	Master switch1: Control / CPU1 No ground potential switched at active PWM-Outlet X left No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E0B044	Master switch1: Control / CPU1 No ground potential switched at active PWM-Outlet X right No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E0B045	Master switch1: Control / CPU1 No ground potential switched at active Digital-Outlet X Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E0B050	Master switch1: Control / CPU1 Initial error No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E0B051	Master switch1: Control / CPU1 Output error Output X-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E0B052	Master switch1: Control / CPU1 Output error Output Y-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A301		E	2
E1000F	Master switch2: Inputs different information on other processor Module reset Replace module	A302		E	2
E10704	Master switch2: System voltage CPU/Logic / CPU0 level exceeded error report Inform Service of all error parameters and replace module	A302		E	0
E10705	Master switch2: System voltage CPU/Logic / CPU0 below minimum level error report Inform Service of all error parameters and replace module	A302		E	2
E1070F	Master switch2: System voltage CPU/Logic / CPU0 different information on other processor error report Inform Service of all error parameters and replace module	A302		E	2
E10804	Master switch2: Supply voltage 24V.1-2 / CPU0 level exceeded error report Check supplies, replace module	A302.X1:1		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E10805	Master switch2: Supply voltage 24V.1-2 / CPU0 below minimum level error report Check supplies, replace module	A302.X1:1		E	0
E1080F	Master switch2: Supply voltage 24V.1-2 / CPU0 different information on other processor error report Check supplies, replace module	A302.X1:1		E	2
E10B02	Master switch2: Switching output A0 HS (X) sensor deficiency data short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B03	Master switch2: Switching output A0 HS (X) sensor deficiency data short circuit to ground Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B12	Master switch2: Switching output A0 HS (X) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B13	Master switch2: Switching output A0 HS (X) open signal circuits Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B1A	Master switch2: Switching output A0 HS (X) User incorrect or erroneous Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B1B	Master switch2: Switching output A0 HS (X) digital shut off defective Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B1C	Master switch2: Switching output A0 HS (X) Current regulator defective Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B1D	Master switch2: Switching output A0 HS (X) Initial current outside permissible range Entry in error stack Report all error parameters to Service	A302.X1:3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E10B54	Master switch2: Switching output A0 HS (X) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B57	Master switch2: Switching output A0 HS (X) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B59	Master switch2: Switching output A0 HS (X) supply voltage missing Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10B72	Master switch2: Switching output A0 HS (X) outside source feeding Entry in error stack Report all error parameters to Service	A302.X1:3		E	2
E10C02	Master switch2: Switching output A1 HS (Y) sensor deficiency data short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C03	Master switch2: Switching output A1 HS (Y) sensor deficiency data short circuit to ground Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C12	Master switch2: Switching output A1 HS (Y) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C13	Master switch2: Switching output A1 HS (Y) open signal circuits Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C1A	Master switch2: Switching output A1 HS (Y) User incorrect or erroneous Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C1B	Master switch2: Switching output A1 HS (Y) digital shut off defective Entry in error stack Report all error parameters to Service	A302.X1:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E10C1C	Master switch2: Switching output A1 HS (Y) Current regulator defective Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C1D	Master switch2: Switching output A1 HS (Y) Initial current outside permissible range Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C54	Master switch2: Switching output A1 HS (Y) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C57	Master switch2: Switching output A1 HS (Y) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C59	Master switch2: Switching output A1 HS (Y) supply voltage missing Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10C72	Master switch2: Switching output A1 HS (Y) outside source feeding Entry in error stack Report all error parameters to Service	A302.X1:5		E	2
E10D12	Master switch2: Switching output A2 HS (X) short circuit to ground Error display on display, shut off of outlets Check connection to user and user	A302.X1:2		E	2
E10D13	Master switch2: Switching output A2 HS (X) open signal circuits Error display on display, shut off of outlets Input voltage outside of permissible value range	A302.X1:2		E	2
E10D1A	Master switch2: Switching output A2 HS (X) User incorrect or erroneous Error display on display, shut off of outlets Check user resistance and line	A302.X1:2		E	2
E10D1B	Master switch2: Switching output A2 HS (X) digital shut off defective Error display on display, shut off of outlets Replace LSB_AMS	A302.X1:2		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E10D54	Master switch2: Switching output A2 HS (X) short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A302.X1:2		E	2
E10D57	Master switch2: Switching output A2 HS (X) open circuit or short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A302.X1:2		E	2
E10E12	Master switch2: Switching output A3 HS (Y) short circuit to ground Error display on display, shut off of outlets Check connection to user and user	A302.X1:4		E	2
E10E13	Master switch2: Switching output A3 HS (Y) open signal circuits Error display on display, shut off of outlets Input voltage outside of permissible value range	A302.X1:4		E	2
E10E1A	Master switch2: Switching output A3 HS (Y) User incorrect or erroneous Error display on display, shut off of outlets Check user resistance and line	A302.X1:4		E	2
E10E1B	Master switch2: Switching output A3 HS (Y) digital shut off defective Error display on display, shut off of outlets Replace LSB_AMS	A302.X1:4		E	2
E10E54	Master switch2: Switching output A3 HS (Y) short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A302.X1:4		E	2
E10E57	Master switch2: Switching output A3 HS (Y) open circuit or short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A302.X1:4		E	2
E11C0F	Master switch2: Hand part different information on other processor Entry in error stack Report all error parameters to Service	A302		E	2
E11D21	Master switch2: Adjustment values in EEPROM / CPU0 invalid data record Entry in error stack Report all error parameters to Service	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E11EA0	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 0) Error display on display, entry in error stack Replace module	A302		E	2
E11EA1	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 1) Error display on display, entry in error stack Replace module	A302		E	2
E11EA2	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 2) Error display on display, entry in error stack Replace module	A302		E	2
E11EA3	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 3) Error display on display, entry in error stack Replace module	A302		E	2
E11EA4	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 4) Error display on display, entry in error stack Replace module	A302		E	2
E11EA5	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 5) Error display on display, entry in error stack Replace module	A302		E	2
E11EA6	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 6) Error display on display, entry in error stack Replace module	A302		E	2
E11EA7	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 7) Error display on display, entry in error stack Replace module	A302		E	2
E11EA8	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 8) Error display on display, entry in error stack Replace module	A302		E	2
E11EA9	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 9) Error display on display, entry in error stack Replace module	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E11EAA	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 10) Error display on display, entry in error stack Replace module	A302		E	2
E11EAB	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 11) Error display on display, entry in error stack Replace module	A302		E	2
E11EAC	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 12) Error display on display, entry in error stack Replace module	A302		E	2
E11EAD	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 13) Error display on display, entry in error stack Replace module	A302		E	2
E11EAE	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 14) Error display on display, entry in error stack Replace module	A302		E	2
E11EAF	Master switch2: X/Y- deflection unit / CPU0 Test system is erroneous (Error 15) Error display on display, entry in error stack Replace module	A302		E	2
E12013	Master switch2: System error OS-CPU0 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A302		E	2
E12016	Master switch2: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A302		E	2
E12033	Master switch2: System error OS-CPU0 Different Signature error indication on display Report all error parameters to Service and replace module. Carry out download	A302		E	2
E12068	Master switch2: System error OS-CPU0 impermissible interrupt Module reset Replace module	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E12071	Master switch2: System error OS-CPU0 Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module	A302		E	2
E12073	Master switch2: System error OS-CPU0 interpreter error error indication on display Inform Service of all error parameters and replace module	A302		E	2
E12075	Master switch2: System error OS-CPU0 SPI-error error indication on display Inform Service of all error parameters and replace module	A302		E	2
E12078	Master switch2: System error OS-CPU0 impermissible parameter Error display on display, entry in error stack Inform Service of all error parameters and replace module	A302		E	2
E12080	Master switch2: System error OS-CPU0 Fatal internal error Module reset Inform Service of all error parameters and replace module	A302		E	2
E12082	Master switch2: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A302		E	2
E120D0	Master switch2: System error OS-CPU0 Voltage drop Entry in error stack Report all error parameters to Service	A302		E	2
E120D1	Master switch2: System error OS-CPU0 Program stopped Entry in error memory, program is stopped (master switch not functional) Start crane again	A302		E	2
E12401	Master switch2: Control Data transfer LSB-A / CPU0 initialising error processor-register erroneous Entry in error stack Report all error parameters to Service	A302.X1:8		E	2
E13001	Master switch2: Control / CPU0 Operating mode (Inputs) has changed since turn on No crane movement (Outlet) via this master switch, error message Check Mode-Inputs	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E13002	Master switch2: Control / CPU0 Operating mode (Inputs) does not match configuration No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E13003	Master switch2: Control / CPU0 Operating mode does not match other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E13004	Master switch2: Control / CPU0 Operating mode does not match LSB-Parameter No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E13005	Master switch2: Control / CPU0 No valid operating mode (crane op. / emerg. operation) No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E13008	Master switch2: Control / CPU0 No / impermissible outlet switching configured No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E13009	Master switch2: Control / CPU0 Configured outlet switching differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E1300A	Master switch2: Control / CPU0 Configuration data differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E13010	Master switch2: Control / CPU0 CAN-communication with UEA-Module erroneous/missing No crane movement (Outlet) via this master switch, error message Check CAN-connection, load LSB-Parameter(CAN-Ids via LSB-Parameter)	A302		E	2
E13011	Master switch2: Control / CPU0 LSB-communication with LSB-Master erroneous/missing No crane movement (Outlet) via this master switch, error message Check LSB-connection	A302		E	2
E13012	Master switch2: Control / CPU0 Communication with other channel (SPI) erroneous/missing No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E13020	Master switch2: Control / CPU0 Not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A302		E	2
E13021	Master switch2: Control / CPU0 Other channel not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A302		E	2
E13022	Master switch2: Control / CPU0 Deflection has too high dynamics Entry in error stack Do not operate Master switch jerkily	A302		E	2
E13030	Master switch2: Control / CPU0 Shut off collective error No crane movement (Outlet) via this master switch, error message Observe error messages, start crane again (ignition OFF/ON), replace master switch	A302		E	2
E13040	Master switch2: Control / CPU0 No ground potential switched at active PWM-Outlet Y front No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E13041	Master switch2: Control / CPU0 No ground potential switched at active PWM-Outlet Y rear No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E13042	Master switch2: Control / CPU0 No ground potential switched at active Digital-Outlet Y Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E13043	Master switch2: Control / CPU0 No ground potential switched at active PWM-Outlet X left No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E13044	Master switch2: Control / CPU0 No ground potential switched at active PWM-Outlet X right No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E13045	Master switch2: Control / CPU0 No ground potential switched at active Digital-Outlet X Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E13050	Master switch2: Control / CPU0 Initial error No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E13051	Master switch2: Control / CPU0 Output error Output X-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E13052	Master switch2: Control / CPU0 Output error Output Y-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E18704	Master switch2: System voltage CPU/Logic / CPU1 level exceeded error report Inform Service of all error parameters and replace module	A302		E	0
E18705	Master switch2: System voltage CPU/Logic / CPU1 below minimum level error report Inform Service of all error parameters and replace module	A302		E	2
E1870F	Master switch2: System voltage CPU/Logic / CPU1 different information on other processor error report Inform Service of all error parameters and replace module	A302		E	2
E18804	Master switch2: Supply voltage 24V.1-2 / CPU1 level exceeded error report Check supplies, replace module	A302.X1:1		E	0
E18805	Master switch2: Supply voltage 24V.1-2 / CPU1 below minimum level error report Check supplies, replace module	A302.X1:1		E	0
E1880F	Master switch2: Supply voltage 24V.1-2 / CPU1 different information on other processor error indication on display Report all error parameters to Service	A302.X1:1		E	2
E18F12	Master switch2: Switching output A4 LS (X+/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X2:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E18F54	Master switch2: Switching output A4 LS (X+/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:4		E	2
E18F57	Master switch2: Switching output A4 LS (X+/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:4		E	2
E19012	Master switch2: Switching output A5 LS (X+/A2) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X2:3		E	2
E19054	Master switch2: Switching output A5 LS (X+/A2) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:3		E	2
E19057	Master switch2: Switching output A5 LS (X+/A2) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:3		E	2
E19112	Master switch2: Switching output A6 LS (X-/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X2:6		E	2
E19154	Master switch2: Switching output A6 LS (X-/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:6		E	2
E19157	Master switch2: Switching output A6 LS (X-/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:6		E	2
E19212	Master switch2: Switching output A7 LS (X-/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X2:5		E	2
E19254	Master switch2: Switching output A7 LS (X-/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E19257	Master switch2: Switching output A7 LS (X-/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:5		E	2
E19312	Master switch2: Switching output A8 LS (Y+/A1) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X2:10		E	2
E19354	Master switch2: Switching output A8 LS (Y+/A1) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:10		E	2
E19357	Master switch2: Switching output A8 LS (Y+/A1) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:10		E	2
E19412	Master switch2: Switching output A9 LS (Y+/A3) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X2:9		E	2
E19454	Master switch2: Switching output A9 LS (Y+/A3) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:9		E	2
E19457	Master switch2: Switching output A9 LS (Y+/A3) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:9		E	2
E19512	Master switch2: Switching output A10 LS (Y-/A1) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X2:12		E	2
E19554	Master switch2: Switching output A10 LS (Y-/A1) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:12		E	2
E19557	Master switch2: Switching output A10 LS (Y-/A1) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E19612	Master switch2: Switching output A11 LS (Y-/A3) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X2:11		E	2
E19654	Master switch2: Switching output A11 LS (Y-/A3) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:11		E	2
E19657	Master switch2: Switching output A11 LS (Y-/A3) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X2:11		E	2
E19712	Master switch2: Switching output A12 LS (X) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X1:11		E	2
E19754	Master switch2: Switching output A12 LS (X) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:11		E	2
E19757	Master switch2: Switching output A12 LS (X) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:11		E	2
E19812	Master switch2: Switching output A13 LS (Y) short circuit to ground Entry in error stack Report all error parameters to Service	A302.X1:12		E	2
E19854	Master switch2: Switching output A13 LS (Y) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:12		E	2
E19857	Master switch2: Switching output A13 LS (Y) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A302.X1:12		E	2
E19918	Master switch2: Switching output A4, A5, A6, A7, A12 (X) excess temperature Entry in error stack Report all error parameters to Service	A302.X2:3/4/5/6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E19A18	Master switch2: Switching output A8, A9, A10, A11, A13 (Y) excess temperature Entry in error stack Report all error parameters to Service	A302.X2:9/10/11		E	2
E19C0F	Master switch2: Hand part different information on other processor Entry in error stack Report all error parameters to Service	A302		E	2
E19D21	Master switch2: Adjustment values in EEPROM / CPU1 invalid data record error indication on display Inform Service of all error parameters and replace module	A302		E	2
E19EA0	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 0) Error display on display, entry in error stack Replace module	A302		E	2
E19EA1	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 1) Error display on display, entry in error stack Replace module	A302		E	2
E19EA2	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 2) Error display on display, entry in error stack Replace module	A302		E	2
E19EA3	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 3) Error display on display, entry in error stack Replace module	A302		E	2
E19EA4	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 4) Error display on display, entry in error stack Replace module	A302		E	2
E19EA5	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 5) Error display on display, entry in error stack Replace module	A302		E	2
E19EA6	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 6) Error display on display, entry in error stack Replace module	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E19EA7	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 7) Error display on display, entry in error stack Replace module	A302		E	2
E19EA8	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 8) Error display on display, entry in error stack Replace module	A302		E	2
E19EA9	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 9) Error display on display, entry in error stack Replace module	A302		E	2
E19EAA	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 10) Error display on display, entry in error stack Replace module	A302		E	2
E19EAB	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 11) Error display on display, entry in error stack Replace module	A302		E	2
E19EAC	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 12) Error display on display, entry in error stack Replace module	A302		E	2
E19EAD	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 13) Error display on display, entry in error stack Replace module	A302		E	2
E19EAE	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 14) Error display on display, entry in error stack Replace module	A302		E	2
E19EAF	Master switch2: X/Y- deflection unit / CPU1 Test system is erroneous (Error 15) Error display on display, entry in error stack Replace module	A302		E	2
E1A013	Master switch2: System error OS-CPU1 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E1A016	Master switch2: System error OS-CPU1 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A302		E	2
E1A033	Master switch2: System error OS-CPU1 Different Signature error indication on display Report all error parameters to Service and replace module. Carry out download	A302		E	2
E1A068	Master switch2: System error OS-CPU1 impermissible interrupt Module reset Replace module	A302		E	2
E1A071	Master switch2: System error OS-CPU1 Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module	A302		E	2
E1A073	Master switch2: System error OS-CPU1 interpreter error error indication on display Inform Service of all error parameters and replace module	A302		E	2
E1A075	Master switch2: System error OS-CPU1 SPI-error error indication on display Inform Service of all error parameters and replace module	A302		E	2
E1A078	Master switch2: System error OS-CPU1 impermissible parameter error indication on display Inform Service of all error parameters and replace module	A302		E	2
E1A080	Master switch2: System error OS-CPU1 Fatal internal error Module reset Inform Service of all error parameters and replace module	A302		E	2
E1A082	Master switch2: System error OS-CPU1 hardware-watchdog erroneous Module reset Replace module	A302		E	2
E1A0D0	Master switch2: System error OS-CPU1 Voltage drop Entry in error stack Report all error parameters to Service	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E1A0D1	Master switch2: System error OS-CPU1 Program stopped Entry in error memory, program is stopped (master switch not functional) Start crane again	A302		E	2
E1A401	Master switch2: Control Data transfer LSB-B / CPU1 initialising error processor-register erroneous Entry in error stack Report all error parameters to Service	A302.X2:8		E	2
E1B001	Master switch2: Control / CPU1 Operating mode (Inputs) has changed since turn on No crane movement (Outlet) via this master switch, error message Check Mode-Inputs	A302		E	2
E1B002	Master switch2: Control / CPU1 Operating mode (Inputs) does not match configuration No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E1B003	Master switch2: Control / CPU1 Operating mode does not match other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E1B004	Master switch2: Control / CPU1 Operating mode does not match LSB-Parameter No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E1B005	Master switch2: Control / CPU1 No valid operating mode (crane op. / emerg. operation) No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E1B008	Master switch2: Control / CPU1 No / impermissible outlet switching configured No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E1B009	Master switch2: Control / CPU1 Configured outlet switching differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2
E1B00A	Master switch2: Control / CPU1 Configuration data differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E1B010	Master switch2: Control / CPU1 CAN-communication with UEA-Module erroneous/missing No crane movement (Outlet) via this master switch, error message Check CAN-connection, load LSB-Parameter(CAN-Ids via LSB-Parameter)	A302		E	2
E1B011	Master switch2: Control / CPU1 LSB-communication with LSB-Master erroneous/missing No crane movement (Outlet) via this master switch, error message Check LSB-connection	A302		E	2
E1B012	Master switch2: Control / CPU1 Communication with other channel (SPI) erroneous/missing No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A302		E	2
E1B020	Master switch2: Control / CPU1 Not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A302		E	2
E1B021	Master switch2: Control / CPU1 Other channel not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A302		E	2
E1B022	Master switch2: Control / CPU1 Deflection has too high dynamics Entry in error stack Do not operate Master switch jerkily	A302		E	2
E1B030	Master switch2: Control / CPU1 Shut off collective error No crane movement (Outlet) via this master switch, error message Observe error messages, start crane again (ignition OFF/ON), replace master switch	A302		E	2
E1B040	Master switch2: Control / CPU1 No ground potential switched at active PWM-Outlet Y front No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E1B041	Master switch2: Control / CPU1 No ground potential switched at active PWM-Outlet Y rear No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E1B042	Master switch2: Control / CPU1 No ground potential switched at active Digital-Outlet Y Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E1B043	Master switch2: Control / CPU1 No ground potential switched at active PWM-Outlet X left No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E1B044	Master switch2: Control / CPU1 No ground potential switched at active PWM-Outlet X right No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E1B045	Master switch2: Control / CPU1 No ground potential switched at active Digital-Outlet X Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E1B050	Master switch2: Control / CPU1 Initial error No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E1B051	Master switch2: Control / CPU1 Output error Output X-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E1B052	Master switch2: Control / CPU1 Output error Output Y-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A302		E	2
E2000F	Master switch3: Inputs different information on other processor Module reset Replace module	A303		E	2
E20704	Master switch3: System voltage CPU/Logic / CPU0 level exceeded error report Inform Service of all error parameters and replace module	A303		E	0
E20705	Master switch3: System voltage CPU/Logic / CPU0 below minimum level error report Inform Service of all error parameters and replace module	A303		E	2
E2070F	Master switch3: System voltage CPU/Logic / CPU0 different information on other processor error report Inform Service of all error parameters and replace module	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E20804	Master switch3: Supply voltage 24V.1-2 / CPU0 level exceeded error report Check supplies, replace module	A303.X1:1		E	0
E20805	Master switch3: Supply voltage 24V.1-2 / CPU0 below minimum level error report Check supplies, replace module	A303.X1:1		E	0
E2080F	Master switch3: Supply voltage 24V.1-2 / CPU0 different information on other processor error report Check supplies, replace module	A303.X1:1		E	2
E20B02	Master switch3: Switching output A0 HS (X) sensor deficiency data short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B03	Master switch3: Switching output A0 HS (X) sensor deficiency data short circuit to ground Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B12	Master switch3: Switching output A0 HS (X) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B13	Master switch3: Switching output A0 HS (X) open signal circuits Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B1A	Master switch3: Switching output A0 HS (X) User incorrect or erroneous Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B1B	Master switch3: Switching output A0 HS (X) digital shut off defective Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B1C	Master switch3: Switching output A0 HS (X) Current regulator defective Entry in error stack Report all error parameters to Service	A303.X1:3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E20B1D	Master switch3: Switching output A0 HS (X) Initial current outside permissible range Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B54	Master switch3: Switching output A0 HS (X) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B57	Master switch3: Switching output A0 HS (X) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B59	Master switch3: Switching output A0 HS (X) supply voltage missing Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20B72	Master switch3: Switching output A0 HS (X) outside source feeding Entry in error stack Report all error parameters to Service	A303.X1:3		E	2
E20C02	Master switch3: Switching output A1 HS (Y) sensor deficiency data short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C03	Master switch3: Switching output A1 HS (Y) sensor deficiency data short circuit to ground Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C12	Master switch3: Switching output A1 HS (Y) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C13	Master switch3: Switching output A1 HS (Y) open signal circuits Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C1A	Master switch3: Switching output A1 HS (Y) User incorrect or erroneous Entry in error stack Report all error parameters to Service	A303.X1:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E20C1B	Master switch3: Switching output A1 HS (Y) digital shut off defective Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C1C	Master switch3: Switching output A1 HS (Y) Current regulator defective Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C1D	Master switch3: Switching output A1 HS (Y) Initial current outside permissible range Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C54	Master switch3: Switching output A1 HS (Y) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C57	Master switch3: Switching output A1 HS (Y) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C59	Master switch3: Switching output A1 HS (Y) supply voltage missing Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20C72	Master switch3: Switching output A1 HS (Y) outside source feeding Entry in error stack Report all error parameters to Service	A303.X1:5		E	2
E20D12	Master switch3: Switching output A2 HS (X) short circuit to ground Error display on display, shut off of outlets Check connection to user and user	A303.X1:2		E	2
E20D13	Master switch3: Switching output A2 HS (X) open signal circuits Error display on display, shut off of outlets Input voltage outside of permissible value range	A303.X1:2		E	2
E20D1A	Master switch3: Switching output A2 HS (X) User incorrect or erroneous Error display on display, shut off of outlets Check user resistance and line	A303.X1:2		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E20D1B	Master switch3: Switching output A2 HS (X) digital shut off defective Error display on display, shut off of outlets Replace LSB_AMS	A303.X1:2		E	2
E20D54	Master switch3: Switching output A2 HS (X) short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A303.X1:2		E	2
E20D57	Master switch3: Switching output A2 HS (X) open circuit or short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A303.X1:2		E	2
E20E12	Master switch3: Switching output A3 HS (Y) short circuit to ground Error display on display, shut off of outlets Check connection to user and user	A303.X1:4		E	2
E20E13	Master switch3: Switching output A3 HS (Y) open signal circuits Error display on display, shut off of outlets Input voltage outside of permissible value range	A303.X1:4		E	2
E20E1A	Master switch3: Switching output A3 HS (Y) User incorrect or erroneous Error display on display, shut off of outlets Check user resistance and line	A303.X1:4		E	2
E20E1B	Master switch3: Switching output A3 HS (Y) digital shut off defective Error display on display, shut off of outlets Replace LSB_AMS	A303.X1:4		E	2
E20E54	Master switch3: Switching output A3 HS (Y) short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A303.X1:4		E	2
E20E57	Master switch3: Switching output A3 HS (Y) open circuit or short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A303.X1:4		E	2
E21C0F	Master switch3: Hand part different information on other processor Entry in error stack Report all error parameters to Service	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E21D21	Master switch3: Adjustment values in EEPROM / CPU0 invalid data record Entry in error stack Report all error parameters to Service	A303		E	2
E21EA0	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 0) Error display on display, entry in error stack Replace module	A303		E	2
E21EA1	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 1) Error display on display, entry in error stack Replace module	A303		E	2
E21EA2	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 2) Error display on display, entry in error stack Replace module	A303		E	2
E21EA3	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 3) Error display on display, entry in error stack Replace module	A303		E	2
E21EA4	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 4) Error display on display, entry in error stack Replace module	A303		E	2
E21EA5	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 5) Error display on display, entry in error stack Replace module	A303		E	2
E21EA6	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 6) Error display on display, entry in error stack Replace module	A303		E	2
E21EA7	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 7) Error display on display, entry in error stack Replace module	A303		E	2
E21EA8	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 8) Error display on display, entry in error stack Replace module	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E21EA9	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 9) Error display on display, entry in error stack Replace module	A303		E	2
E21EAA	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 10) Error display on display, entry in error stack Replace module	A303		E	2
E21EAB	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 11) Error display on display, entry in error stack Replace module	A303		E	2
E21EAC	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 12) Error display on display, entry in error stack Replace module	A303		E	2
E21EAD	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 13) Error display on display, entry in error stack Replace module	A303		E	2
E21EAE	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 14) Error display on display, entry in error stack Replace module	A303		E	2
E21EAF	Master switch3: X/Y- deflection unit / CPU0 Test system is erroneous (Error 15) Error display on display, entry in error stack Replace module	A303		E	2
E22013	Master switch3: System error OS-CPU0 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A303		E	2
E22016	Master switch3: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A303		E	2
E22033	Master switch3: System error OS-CPU0 Different Signature error indication on display Report all error parameters to Service and replace module. Carry out download	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E22068	Master switch3: System error OS-CPU0 impermissible interrupt Module reset Replace module	A303		E	2
E22071	Master switch3: System error OS-CPU0 Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module	A303		E	2
E22073	Master switch3: System error OS-CPU0 interpreter error error indication on display Inform Service of all error parameters and replace module	A303		E	2
E22075	Master switch3: System error OS-CPU0 SPI-error error indication on display Inform Service of all error parameters and replace module	A303		E	2
E22078	Master switch3: System error OS-CPU0 impermissible parameter Error display on display, entry in error stack Inform Service of all error parameters and replace module	A303		E	2
E22080	Master switch3: System error OS-CPU0 Fatal internal error Module reset Inform Service of all error parameters and replace module	A303		E	2
E22082	Master switch3: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A303		E	2
E220D0	Master switch3: System error OS-CPU0 Voltage drop Entry in error stack Report all error parameters to Service	A303		E	2
E220D1	Master switch3: System error OS-CPU0 Program stopped Entry in error memory, program is stopped (master switch not functional) Start crane again	A303		E	2
E22401	Master switch3: Control Data transfer LSB-A / CPU0 initialising error processor-register erroneous Entry in error stack Report all error parameters to Service	A303.X1:8		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E23001	Master switch3: Control / CPU0 Operating mode (Inputs) has changed since turn on No crane movement (Outlet) via this master switch, error message Check Mode-Inputs	A303		E	2
E23002	Master switch3: Control / CPU0 Operating mode (Inputs) does not match configuration No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E23003	Master switch3: Control / CPU0 Operating mode does not match other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E23004	Master switch3: Control / CPU0 Operating mode does not match LSB-Parameter No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E23005	Master switch3: Control / CPU0 No valid operating mode (crane op. / emerg. operation) No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E23008	Master switch3: Control / CPU0 No / impermissible outlet switching configured No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E23009	Master switch3: Control / CPU0 Configured outlet switching differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E2300A	Master switch3: Control / CPU0 Configuration data differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E23010	Master switch3: Control / CPU0 CAN-communication with UEA-Module erroneous/missing No crane movement (Outlet) via this master switch, error message Check CAN-connection, load LSB-Parameter(CAN-Ids via LSB-Parameter)	A303		E	2
E23011	Master switch3: Control / CPU0 LSB-communication with LSB-Master erroneous/missing No crane movement (Outlet) via this master switch, error message Check LSB-connection	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E23012	Master switch3: Control / CPU0 Communication with other channel (SPI) erroneous/missing No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A303		E	2
E23020	Master switch3: Control / CPU0 Not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A303		E	2
E23021	Master switch3: Control / CPU0 Other channel not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A303		E	2
E23022	Master switch3: Control / CPU0 Deflection has too high dynamics Entry in error stack Do not operate Master switch jerkily	A303		E	2
E23030	Master switch3: Control / CPU0 Shut off collective error No crane movement (Outlet) via this master switch, error message Observe error messages, start crane again (ignition OFF/ON), replace master switch	A303		E	2
E23040	Master switch3: Control / CPU0 No ground potential switched at active PWM-Outlet Y front No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E23041	Master switch3: Control / CPU0 No ground potential switched at active PWM-Outlet Y rear No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E23042	Master switch3: Control / CPU0 No ground potential switched at active Digital-Outlet Y Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E23043	Master switch3: Control / CPU0 No ground potential switched at active PWM-Outlet X left No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E23044	Master switch3: Control / CPU0 No ground potential switched at active PWM-Outlet X right No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E23045	Master switch3: Control / CPU0 No ground potential switched at active Digital-Outlet X Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E23050	Master switch3: Control / CPU0 Initial error No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E23051	Master switch3: Control / CPU0 Output error Output X-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E23052	Master switch3: Control / CPU0 Output error Output Y-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E28704	Master switch3: System voltage CPU/Logic / CPU1 level exceeded error report Inform Service of all error parameters and replace module	A303		E	0
E28705	Master switch3: System voltage CPU/Logic / CPU1 below minimum level error report Inform Service of all error parameters and replace module	A303		E	2
E2870F	Master switch3: System voltage CPU/Logic / CPU1 different information on other processor error report Inform Service of all error parameters and replace module	A303		E	2
E28804	Master switch3: Supply voltage 24V.1-2 / CPU1 level exceeded error report Check supplies, replace module	A303.X1:1		E	0
E28805	Master switch3: Supply voltage 24V.1-2 / CPU1 below minimum level error report Check supplies, replace module	A303.X1:1		E	0
E2880F	Master switch3: Supply voltage 24V.1-2 / CPU1 different information on other processor error indication on display Report all error parameters to Service	A303.X1:1		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E28F12	Master switch3: Switching output A4 LS (X+/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X2:4		E	2
E28F54	Master switch3: Switching output A4 LS (X+/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:4		E	2
E28F57	Master switch3: Switching output A4 LS (X+/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:4		E	2
E29012	Master switch3: Switching output A5 LS (X+/A2) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X2:3		E	2
E29054	Master switch3: Switching output A5 LS (X+/A2) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:3		E	2
E29057	Master switch3: Switching output A5 LS (X+/A2) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:3		E	2
E29112	Master switch3: Switching output A6 LS (X-/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X2:6		E	2
E29154	Master switch3: Switching output A6 LS (X-/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:6		E	2
E29157	Master switch3: Switching output A6 LS (X-/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:6		E	2
E29212	Master switch3: Switching output A7 LS (X-/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X2:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E29254	Master switch3: Switching output A7 LS (X-/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:5		E	2
E29257	Master switch3: Switching output A7 LS (X-/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:5		E	2
E29312	Master switch3: Switching output A8 LS (Y+/A1) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X2:10		E	2
E29354	Master switch3: Switching output A8 LS (Y+/A1) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:10		E	2
E29357	Master switch3: Switching output A8 LS (Y+/A1) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:10		E	2
E29412	Master switch3: Switching output A9 LS (Y+/A3) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X2:9		E	2
E29454	Master switch3: Switching output A9 LS (Y+/A3) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:9		E	2
E29457	Master switch3: Switching output A9 LS (Y+/A3) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:9		E	2
E29512	Master switch3: Switching output A10 LS (Y-/A1) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X2:12		E	2
E29554	Master switch3: Switching output A10 LS (Y-/A1) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E29557	Master switch3: Switching output A10 LS (Y-/A1) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:12		E	2
E29612	Master switch3: Switching output A11 LS (Y-/A3) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X2:11		E	2
E29654	Master switch3: Switching output A11 LS (Y-/A3) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:11		E	2
E29657	Master switch3: Switching output A11 LS (Y-/A3) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X2:11		E	2
E29712	Master switch3: Switching output A12 LS (X) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X1:11		E	2
E29754	Master switch3: Switching output A12 LS (X) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:11		E	2
E29757	Master switch3: Switching output A12 LS (X) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:11		E	2
E29812	Master switch3: Switching output A13 LS (Y) short circuit to ground Entry in error stack Report all error parameters to Service	A303.X1:12		E	2
E29854	Master switch3: Switching output A13 LS (Y) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:12		E	2
E29857	Master switch3: Switching output A13 LS (Y) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A303.X1:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E29918	Master switch3: Switching output A4, A5, A6, A7, A12 (X) excess temperature Entry in error stack Report all error parameters to Service	A303.X2:3/4/5/6		E	2
E29A18	Master switch3: Switching output A8, A9, A10, A11, A13 (Y) excess temperature Entry in error stack Report all error parameters to Service	A303.X2:9/10/11		E	2
E29C0F	Master switch3: Hand part different information on other processor Entry in error stack Report all error parameters to Service	A303		E	2
E29D21	Master switch3: Adjustment values in EEPROM / CPU1 invalid data record error indication on display Inform Service of all error parameters and replace module	A303		E	2
E29EA0	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 0) Error display on display, entry in error stack Replace module	A303		E	2
E29EA1	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 1) Error display on display, entry in error stack Replace module	A303		E	2
E29EA2	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 2) Error display on display, entry in error stack Replace module	A303		E	2
E29EA3	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 3) Error display on display, entry in error stack Replace module	A303		E	2
E29EA4	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 4) Error display on display, entry in error stack Replace module	A303		E	2
E29EA5	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 5) Error display on display, entry in error stack Replace module	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E29EA6	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 6) Error display on display, entry in error stack Replace module	A303		E	2
E29EA7	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 7) Error display on display, entry in error stack Replace module	A303		E	2
E29EA8	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 8) Error display on display, entry in error stack Replace module	A303		E	2
E29EA9	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 9) Error display on display, entry in error stack Replace module	A303		E	2
E29EAA	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 10) Error display on display, entry in error stack Replace module	A303		E	2
E29EAB	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 11) Error display on display, entry in error stack Replace module	A303		E	2
E29EAC	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 12) Error display on display, entry in error stack Replace module	A303		E	2
E29EAD	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 13) Error display on display, entry in error stack Replace module	A303		E	2
E29EAE	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 14) Error display on display, entry in error stack Replace module	A303		E	2
E29EAF	Master switch3: X/Y- deflection unit / CPU1 Test system is erroneous (Error 15) Error display on display, entry in error stack Replace module	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E2A013	Master switch3: System error OS-CPU1 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A303		E	2
E2A016	Master switch3: System error OS-CPU1 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A303		E	2
E2A033	Master switch3: System error OS-CPU1 Different Signature error indication on display Report all error parameters to Service and replace module. Carry out download	A303		E	2
E2A068	Master switch3: System error OS-CPU1 impermissible interrupt Module reset Replace module	A303		E	2
E2A071	Master switch3: System error OS-CPU1 Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module	A303		E	2
E2A073	Master switch3: System error OS-CPU1 interpreter error error indication on display Inform Service of all error parameters and replace module	A303		E	2
E2A075	Master switch3: System error OS-CPU1 SPI-error error indication on display Inform Service of all error parameters and replace module	A303		E	2
E2A078	Master switch3: System error OS-CPU1 impermissible parameter error indication on display Inform Service of all error parameters and replace module	A303		E	2
E2A080	Master switch3: System error OS-CPU1 Fatal internal error Module reset Inform Service of all error parameters and replace module	A303		E	2
E2A082	Master switch3: System error OS-CPU1 hardware-watchdog erroneous Module reset Replace module	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E2A0D0	Master switch3: System error OS-CPU1 Voltage drop Entry in error stack Report all error parameters to Service	A303		E	2
E2A0D1	Master switch3: System error OS-CPU1 Program stopped Entry in error memory, program is stopped (master switch not functional) Start crane again	A303		E	2
E2A401	Master switch3: Control Data transfer LSB-B / CPU1 initialising error processor-register erroneous Entry in error stack Report all error parameters to Service	A303.X2:8		E	2
E2B001	Master switch3: Control / CPU1 Operating mode (Inputs) has changed since turn on No crane movement (Outlet) via this master switch, error message Check Mode-Inputs	A303		E	2
E2B002	Master switch3: Control / CPU1 Operating mode (Inputs) does not match configuration No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E2B003	Master switch3: Control / CPU1 Operating mode does not match other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E2B004	Master switch3: Control / CPU1 Operating mode does not match LSB-Parameter No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E2B005	Master switch3: Control / CPU1 No valid operating mode (crane op. / emerg. operation) No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E2B008	Master switch3: Control / CPU1 No / impermissible outlet switching configured No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E2B009	Master switch3: Control / CPU1 Configured outlet switching differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E2B00A	Master switch3: Control / CPU1 Configuration data differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A303		E	2
E2B010	Master switch3: Control / CPU1 CAN-communication with UEA-Module erroneous/missing No crane movement (Outlet) via this master switch, error message Check CAN-connection, load LSB-Parameter(CAN-Ids via LSB-Parameter)	A303		E	2
E2B011	Master switch3: Control / CPU1 LSB-communication with LSB-Master erroneous/missing No crane movement (Outlet) via this master switch, error message Check LSB-connection	A303		E	2
E2B012	Master switch3: Control / CPU1 Communication with other channel (SPI) erroneous/missing No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A303		E	2
E2B020	Master switch3: Control / CPU1 Not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A303		E	2
E2B021	Master switch3: Control / CPU1 Other channel not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A303		E	2
E2B022	Master switch3: Control / CPU1 Deflection has too high dynamics Entry in error stack Do not operate Master switch jerkily	A303		E	2
E2B030	Master switch3: Control / CPU1 Shut off collective error No crane movement (Outlet) via this master switch, error message Observe error messages, start crane again (ignition OFF/ON), replace master switch	A303		E	2
E2B040	Master switch3: Control / CPU1 No ground potential switched at active PWM-Outlet Y front No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E2B041	Master switch3: Control / CPU1 No ground potential switched at active PWM-Outlet Y rear No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E2B042	Master switch3: Control / CPU1 No ground potential switched at active Digital-Outlet Y Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E2B043	Master switch3: Control / CPU1 No ground potential switched at active PWM-Outlet X left No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E2B044	Master switch3: Control / CPU1 No ground potential switched at active PWM-Outlet X right No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E2B045	Master switch3: Control / CPU1 No ground potential switched at active Digital-Outlet X Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E2B050	Master switch3: Control / CPU1 Initial error No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E2B051	Master switch3: Control / CPU1 Output error Output X-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E2B052	Master switch3: Control / CPU1 Output error Output Y-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A303		E	2
E3000F	Master switch4: Inputs different information on other processor Module reset Replace module	A304		E	2
E30704	Master switch4: System voltage CPU/Logic / CPU0 level exceeded error report Inform Service of all error parameters and replace module	A304		E	0
E30705	Master switch4: System voltage CPU/Logic / CPU0 below minimum level error report Inform Service of all error parameters and replace module	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E3070F	Master switch4: System voltage CPU/Logic / CPU0 different information on other processor error report Inform Service of all error parameters and replace module	A304		E	2
E30804	Master switch4: Supply voltage 24V.1-2 / CPU0 level exceeded error report Check supplies, replace module	A304.X1:1		E	0
E30805	Master switch4: Supply voltage 24V.1-2 / CPU0 below minimum level error report Check supplies, replace module	A304.X1:1		E	0
E3080F	Master switch4: Supply voltage 24V.1-2 / CPU0 different information on other processor error report Check supplies, replace module	A304.X1:1		E	2
E30B02	Master switch4: Switching output A0 HS (X) sensor deficiency data short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B03	Master switch4: Switching output A0 HS (X) sensor deficiency data short circuit to ground Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B12	Master switch4: Switching output A0 HS (X) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B13	Master switch4: Switching output A0 HS (X) open signal circuits Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B1A	Master switch4: Switching output A0 HS (X) User incorrect or erroneous Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B1B	Master switch4: Switching output A0 HS (X) digital shut off defective Entry in error stack Report all error parameters to Service	A304.X1:3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E30B1C	Master switch4: Switching output A0 HS (X) Current regulator defective Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B1D	Master switch4: Switching output A0 HS (X) Initial current outside permissible range Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B54	Master switch4: Switching output A0 HS (X) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B57	Master switch4: Switching output A0 HS (X) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B59	Master switch4: Switching output A0 HS (X) supply voltage missing Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30B72	Master switch4: Switching output A0 HS (X) outside source feeding Entry in error stack Report all error parameters to Service	A304.X1:3		E	2
E30C02	Master switch4: Switching output A1 HS (Y) sensor deficiency data short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C03	Master switch4: Switching output A1 HS (Y) sensor deficiency data short circuit to ground Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C12	Master switch4: Switching output A1 HS (Y) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C13	Master switch4: Switching output A1 HS (Y) open signal circuits Entry in error stack Report all error parameters to Service	A304.X1:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E30C1A	Master switch4: Switching output A1 HS (Y) User incorrect or erroneous Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C1B	Master switch4: Switching output A1 HS (Y) digital shut off defective Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C1C	Master switch4: Switching output A1 HS (Y) Current regulator defective Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C1D	Master switch4: Switching output A1 HS (Y) Initial current outside permissible range Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C54	Master switch4: Switching output A1 HS (Y) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C57	Master switch4: Switching output A1 HS (Y) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C59	Master switch4: Switching output A1 HS (Y) supply voltage missing Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30C72	Master switch4: Switching output A1 HS (Y) outside source feeding Entry in error stack Report all error parameters to Service	A304.X1:5		E	2
E30D12	Master switch4: Switching output A2 HS (X) short circuit to ground Error display on display, shut off of outlets Check connection to user and user	A304.X1:2		E	2
E30D13	Master switch4: Switching output A2 HS (X) open signal circuits Error display on display, shut off of outlets Input voltage outside of permissible value range	A304.X1:2		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E30D1A	Master switch4: Switching output A2 HS (X) User incorrect or erroneous Error display on display, shut off of outlets Check user resistance and line	A304.X1:2		E	2
E30D1B	Master switch4: Switching output A2 HS (X) digital shut off defective Error display on display, shut off of outlets Replace LSB_AMS	A304.X1:2		E	2
E30D54	Master switch4: Switching output A2 HS (X) short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A304.X1:2		E	2
E30D57	Master switch4: Switching output A2 HS (X) open circuit or short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A304.X1:2		E	2
E30E12	Master switch4: Switching output A3 HS (Y) short circuit to ground Error display on display, shut off of outlets Check connection to user and user	A304.X1:4		E	2
E30E13	Master switch4: Switching output A3 HS (Y) open signal circuits Error display on display, shut off of outlets Input voltage outside of permissible value range	A304.X1:4		E	2
E30E1A	Master switch4: Switching output A3 HS (Y) User incorrect or erroneous Error display on display, shut off of outlets Check user resistance and line	A304.X1:4		E	2
E30E1B	Master switch4: Switching output A3 HS (Y) digital shut off defective Error display on display, shut off of outlets Replace LSB_AMS	A304.X1:4		E	2
E30E54	Master switch4: Switching output A3 HS (Y) short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A304.X1:4		E	2
E30E57	Master switch4: Switching output A3 HS (Y) open circuit or short circuit to supply voltage Error display on display, shut off of outlets Check line connection and user	A304.X1:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E31C0F	Master switch4: Hand part different information on other processor Entry in error stack Report all error parameters to Service	A304		E	2
E31D21	Master switch4: Adjustment values in EEPROM / CPU0 invalid data record Entry in error stack Report all error parameters to Service	A304		E	2
E31EA0	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 0) Error display on display, entry in error stack Replace module	A304		E	2
E31EA1	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 1) Error display on display, entry in error stack Replace module	A304		E	2
E31EA2	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 2) Error display on display, entry in error stack Replace module	A304		E	2
E31EA3	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 3) Error display on display, entry in error stack Replace module	A304		E	2
E31EA4	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 4) Error display on display, entry in error stack Replace module	A304		E	2
E31EA5	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 5) Error display on display, entry in error stack Replace module	A304		E	2
E31EA6	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 6) Error display on display, entry in error stack Replace module	A304		E	2
E31EA7	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 7) Error display on display, entry in error stack Replace module	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E31EA8	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 8) Error display on display, entry in error stack Replace module	A304		E	2
E31EA9	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 9) Error display on display, entry in error stack Replace module	A304		E	2
E31EAA	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 10) Error display on display, entry in error stack Replace module	A304		E	2
E31EAB	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 11) Error display on display, entry in error stack Replace module	A304		E	2
E31EAC	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 12) Error display on display, entry in error stack Replace module	A304		E	2
E31EAD	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 13) Error display on display, entry in error stack Replace module	A304		E	2
E31EAE	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 14) Error display on display, entry in error stack Replace module	A304		E	2
E31EAF	Master switch4: X/Y- deflection unit / CPU0 Test system is erroneous (Error 15) Error display on display, entry in error stack Replace module	A304		E	2
E32013	Master switch4: System error OS-CPU0 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A304		E	2
E32016	Master switch4: System error OS-CPU0 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E32033	Master switch4: System error OS-CPU0 Different Signature error indication on display Report all error parameters to Service and replace module. Carry out download	A304		E	2
E32068	Master switch4: System error OS-CPU0 impermissible interrupt Module reset Replace module	A304		E	2
E32071	Master switch4: System error OS-CPU0 Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module	A304		E	2
E32073	Master switch4: System error OS-CPU0 interpreter error error indication on display Inform Service of all error parameters and replace module	A304		E	2
E32075	Master switch4: System error OS-CPU0 SPI-error error indication on display Inform Service of all error parameters and replace module	A304		E	2
E32078	Master switch4: System error OS-CPU0 impermissible parameter Error display on display, entry in error stack Inform Service of all error parameters and replace module	A304		E	2
E32080	Master switch4: System error OS-CPU0 Fatal internal error Module reset Inform Service of all error parameters and replace module	A304		E	2
E32082	Master switch4: System error OS-CPU0 hardware-watchdog erroneous Module reset Replace module	A304		E	2
E320D0	Master switch4: System error OS-CPU0 Voltage drop Entry in error stack Report all error parameters to Service	A304		E	2
E320D1	Master switch4: System error OS-CPU0 Program stopped Entry in error memory, program is stopped (master switch not functional) Start crane again	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E32401	Master switch4: Control Data transfer LSB-A / CPU0 initialising error processor-register erroneous Entry in error stack Report all error parameters to Service	A304.X1:8		E	2
E33001	Master switch4: Control / CPU0 Operating mode (Inputs) has changed since turn on No crane movement (Outlet) via this master switch, error message Check Mode-Inputs	A304		E	2
E33002	Master switch4: Control / CPU0 Operating mode (Inputs) does not match configuration No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E33003	Master switch4: Control / CPU0 Operating mode does not match other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E33004	Master switch4: Control / CPU0 Operating mode does not match LSB-Parameter No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E33005	Master switch4: Control / CPU0 No valid operating mode (crane op. / emerg. operation) No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E33008	Master switch4: Control / CPU0 No / impermissible outlet switching configured No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E33009	Master switch4: Control / CPU0 Configured outlet switching differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E3300A	Master switch4: Control / CPU0 Configuration data differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E33010	Master switch4: Control / CPU0 CAN-communication with UEA-Module erroneous/missing No crane movement (Outlet) via this master switch, error message Check CAN-connection, load LSB-Parameter(CAN-Ids via LSB-Parameter)	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E33011	Master switch4: Control / CPU0 LSB-communication with LSB-Master erroneous/missing No crane movement (Outlet) via this master switch, error message Check LSB-connection	A304		E	2
E33012	Master switch4: Control / CPU0 Communication with other channel (SPI) erroneous/missing No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A304		E	2
E33020	Master switch4: Control / CPU0 Not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A304		E	2
E33021	Master switch4: Control / CPU0 Other channel not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A304		E	2
E33022	Master switch4: Control / CPU0 Deflection has too high dynamics Entry in error stack Do not operate Master switch jerkily	A304		E	2
E33030	Master switch4: Control / CPU0 Shut off collective error No crane movement (Outlet) via this master switch, error message Observe error messages, start crane again (ignition OFF/ON), replace master switch	A304		E	2
E33040	Master switch4: Control / CPU0 No ground potential switched at active PWM-Outlet Y front No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E33041	Master switch4: Control / CPU0 No ground potential switched at active PWM-Outlet Y rear No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E33042	Master switch4: Control / CPU0 No ground potential switched at active Digital-Outlet Y Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E33043	Master switch4: Control / CPU0 No ground potential switched at active PWM-Outlet X left No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E33044	Master switch4: Control / CPU0 No ground potential switched at active PWM-Outlet X right No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E33045	Master switch4: Control / CPU0 No ground potential switched at active Digital-Outlet X Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E33050	Master switch4: Control / CPU0 Initial error No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E33051	Master switch4: Control / CPU0 Output error Output X-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E33052	Master switch4: Control / CPU0 Output error Output Y-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E38704	Master switch4: System voltage CPU/Logic / CPU1 level exceeded error report Inform Service of all error parameters and replace module	A304		E	0
E38705	Master switch4: System voltage CPU/Logic / CPU1 below minimum level error report Inform Service of all error parameters and replace module	A304		E	2
E3870F	Master switch4: System voltage CPU/Logic / CPU1 different information on other processor error report Inform Service of all error parameters and replace module	A304		E	2
E38804	Master switch4: Supply voltage 24V.1-2 / CPU1 level exceeded error report Check supplies, replace module	A304.X1:1		E	0
E38805	Master switch4: Supply voltage 24V.1-2 / CPU1 below minimum level error report Check supplies, replace module	A304.X1:1		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E3880F	Master switch4: Supply voltage 24V.1-2 / CPU1 different information on other processor error indication on display Report all error parameters to Service	A304.X1:1		E	2
E38F12	Master switch4: Switching output A4 LS (X+/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X2:4		E	2
E38F54	Master switch4: Switching output A4 LS (X+/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:4		E	2
E38F57	Master switch4: Switching output A4 LS (X+/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:4		E	2
E39012	Master switch4: Switching output A5 LS (X+/A2) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X2:3		E	2
E39054	Master switch4: Switching output A5 LS (X+/A2) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:3		E	2
E39057	Master switch4: Switching output A5 LS (X+/A2) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:3		E	2
E39112	Master switch4: Switching output A6 LS (X-/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X2:6		E	2
E39154	Master switch4: Switching output A6 LS (X-/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:6		E	2
E39157	Master switch4: Switching output A6 LS (X-/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E39212	Master switch4: Switching output A7 LS (X-/A0) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X2:5		E	2
E39254	Master switch4: Switching output A7 LS (X-/A0) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:5		E	2
E39257	Master switch4: Switching output A7 LS (X-/A0) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:5		E	2
E39312	Master switch4: Switching output A8 LS (Y+/A1) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X2:10		E	2
E39354	Master switch4: Switching output A8 LS (Y+/A1) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:10		E	2
E39357	Master switch4: Switching output A8 LS (Y+/A1) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:10		E	2
E39412	Master switch4: Switching output A9 LS (Y+/A3) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X2:9		E	2
E39454	Master switch4: Switching output A9 LS (Y+/A3) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:9		E	2
E39457	Master switch4: Switching output A9 LS (Y+/A3) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:9		E	2
E39512	Master switch4: Switching output A10 LS (Y-/A1) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X2:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E39554	Master switch4: Switching output A10 LS (Y-/A1) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:12		E	2
E39557	Master switch4: Switching output A10 LS (Y-/A1) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:12		E	2
E39612	Master switch4: Switching output A11 LS (Y-/A3) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X2:11		E	2
E39654	Master switch4: Switching output A11 LS (Y-/A3) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:11		E	2
E39657	Master switch4: Switching output A11 LS (Y-/A3) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X2:11		E	2
E39712	Master switch4: Switching output A12 LS (X) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X1:11		E	2
E39754	Master switch4: Switching output A12 LS (X) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:11		E	2
E39757	Master switch4: Switching output A12 LS (X) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:11		E	2
E39812	Master switch4: Switching output A13 LS (Y) short circuit to ground Entry in error stack Report all error parameters to Service	A304.X1:12		E	2
E39854	Master switch4: Switching output A13 LS (Y) short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E39857	Master switch4: Switching output A13 LS (Y) open circuit or short circuit to supply voltage Entry in error stack Report all error parameters to Service	A304.X1:12		E	2
E39918	Master switch4: Switching output A4, A5, A6, A7, A12 (X) excess temperature Entry in error stack Report all error parameters to Service	A304.X2:3/4/5/6		E	2
E39A18	Master switch4: Switching output A8, A9, A10, A11, A13 (Y) excess temperature Entry in error stack Report all error parameters to Service	A304.X2:9/10/11		E	2
E39C0F	Master switch4: Hand part different information on other processor Entry in error stack Report all error parameters to Service	A304		E	2
E39D21	Master switch4: Adjustment values in EEPROM / CPU1 invalid data record error indication on display Inform Service of all error parameters and replace module	A304		E	2
E39EA0	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 0) Error display on display, entry in error stack Replace module	A304		E	2
E39EA1	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 1) Error display on display, entry in error stack Replace module	A304		E	2
E39EA2	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 2) Error display on display, entry in error stack Replace module	A304		E	2
E39EA3	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 3) Error display on display, entry in error stack Replace module	A304		E	2
E39EA4	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 4) Error display on display, entry in error stack Replace module	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E39EA5	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 5) Error display on display, entry in error stack Replace module	A304		E	2
E39EA6	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 6) Error display on display, entry in error stack Replace module	A304		E	2
E39EA7	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 7) Error display on display, entry in error stack Replace module	A304		E	2
E39EA8	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 8) Error display on display, entry in error stack Replace module	A304		E	2
E39EA9	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 9) Error display on display, entry in error stack Replace module	A304		E	2
E39EAA	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 10) Error display on display, entry in error stack Replace module	A304		E	2
E39EAB	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 11) Error display on display, entry in error stack Replace module	A304		E	2
E39EAC	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 12) Error display on display, entry in error stack Replace module	A304		E	2
E39EAD	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 13) Error display on display, entry in error stack Replace module	A304		E	2
E39EAE	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 14) Error display on display, entry in error stack Replace module	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E39EAF	Master switch4: X/Y- deflection unit / CPU1 Test system is erroneous (Error 15) Error display on display, entry in error stack Replace module	A304		E	2
E3A013	Master switch4: System error OS-CPU1 Test sum in FLASH erroneous error indication on display Inform Service of all error parameters and replace module	A304		E	2
E3A016	Master switch4: System error OS-CPU1 system-, driver-watchdog expired error indication on display Inform Service of all error parameters and replace module	A304		E	2
E3A033	Master switch4: System error OS-CPU1 Different Signature error indication on display Report all error parameters to Service and replace module. Carry out download	A304		E	2
E3A068	Master switch4: System error OS-CPU1 impermissible interrupt Module reset Replace module	A304		E	2
E3A071	Master switch4: System error OS-CPU1 Structure file missing or faulty error indication on display Inform Service of all error parameters and replace module	A304		E	2
E3A073	Master switch4: System error OS-CPU1 interpreter error error indication on display Inform Service of all error parameters and replace module	A304		E	2
E3A075	Master switch4: System error OS-CPU1 SPI-error error indication on display Inform Service of all error parameters and replace module	A304		E	2
E3A078	Master switch4: System error OS-CPU1 impermissible parameter error indication on display Inform Service of all error parameters and replace module	A304		E	2
E3A080	Master switch4: System error OS-CPU1 Fatal internal error Module reset Inform Service of all error parameters and replace module	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E3A082	Master switch4: System error OS-CPU1 hardware-watchdog erroneous Module reset Replace module	A304		E	2
E3A0D0	Master switch4: System error OS-CPU1 Voltage drop Entry in error stack Report all error parameters to Service	A304		E	2
E3A0D1	Master switch4: System error OS-CPU1 Program stopped Entry in error memory, program is stopped (master switch not functional) Start crane again	A304		E	2
E3A401	Master switch4: Control Data transfer LSB-B / CPU1 initialising error processor-register erroneous Entry in error stack Report all error parameters to Service	A304.X2:8		E	2
E3B001	Master switch4: Control / CPU1 Operating mode (Inputs) has changed since turn on No crane movement (Outlet) via this master switch, error message Check Mode-Inputs	A304		E	2
E3B002	Master switch4: Control / CPU1 Operating mode (Inputs) does not match configuration No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E3B003	Master switch4: Control / CPU1 Operating mode does not match other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E3B004	Master switch4: Control / CPU1 Operating mode does not match LSB-Parameter No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E3B005	Master switch4: Control / CPU1 No valid operating mode (crane op. / emerg. operation) No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E3B008	Master switch4: Control / CPU1 No / impermissible outlet switching configured No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E3B009	Master switch4: Control / CPU1 Configured outlet switching differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E3B00A	Master switch4: Control / CPU1 Configuration data differs from other channel No crane movement (Outlet) via this master switch, error message Check Mode-Inputs, Download configuration, load LSB-Parameter	A304		E	2
E3B010	Master switch4: Control / CPU1 CAN-communication with UEA-Module erroneous/missing No crane movement (Outlet) via this master switch, error message Check CAN-connection, load LSB-Parameter(CAN-Ids via LSB-Parameter)	A304		E	2
E3B011	Master switch4: Control / CPU1 LSB-communication with LSB-Master erroneous/missing No crane movement (Outlet) via this master switch, error message Check LSB-connection	A304		E	2
E3B012	Master switch4: Control / CPU1 Communication with other channel (SPI) erroneous/missing No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A304		E	2
E3B020	Master switch4: Control / CPU1 Not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A304		E	2
E3B021	Master switch4: Control / CPU1 Other channel not operational No crane movement (Outlet) via this master switch, error message Start crane again (Ignition OFF/ON), replace master switch	A304		E	2
E3B022	Master switch4: Control / CPU1 Deflection has too high dynamics Entry in error stack Do not operate Master switch jerkily	A304		E	2
E3B030	Master switch4: Control / CPU1 Shut off collective error No crane movement (Outlet) via this master switch, error message Observe error messages, start crane again (ignition OFF/ON), replace master switch	A304		E	2
E3B040	Master switch4: Control / CPU1 No ground potential switched at active PWM-Outlet Y front No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E3B041	Master switch4: Control / CPU1 No ground potential switched at active PWM-Outlet Y rear No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E3B042	Master switch4: Control / CPU1 No ground potential switched at active Digital-Outlet Y Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E3B043	Master switch4: Control / CPU1 No ground potential switched at active PWM-Outlet X left No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E3B044	Master switch4: Control / CPU1 No ground potential switched at active PWM-Outlet X right No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E3B045	Master switch4: Control / CPU1 No ground potential switched at active Digital-Outlet X Axle No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E3B050	Master switch4: Control / CPU1 Initial error No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E3B051	Master switch4: Control / CPU1 Output error Output X-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E3B052	Master switch4: Control / CPU1 Output error Output Y-DIGITAL(GND) short circuit after ground No crane movement (Outlet) via this master switch, error message Check current circuit initial switching	A304		E	2
E7D017	Pedal sensor2: Supply voltage 24V.1 voltage below required value Entry in error stack Check power supply	B305.X:1		E	1
E7E110	Pedal sensor2: Switching output A0 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B305.X:5		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E7E112	Pedal sensor2: Switching output A0 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B305.X:5		E	1
E7E11D	Pedal sensor2: Switching output A0 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B305.X:5		E	1
E7E151	Pedal sensor2: Switching output A0 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B305.X:5		E	1
E7E156	Pedal sensor2: Switching output A0 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B305.X:5		E	1
E7E157	Pedal sensor2: Switching output A0 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B305.X:5		E	1
E7E181	Pedal sensor2: Switching output A0 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B305.X:5		E	1
E7E210	Pedal sensor2: Switching output A1 inadmissible signal difference Current outputs 0 mA Check pedal, wiring, load	B305.X:4		E	1
E7E212	Pedal sensor2: Switching output A1 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B305.X:4		E	1
E7E21D	Pedal sensor2: Switching output A1 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B305.X:4		E	1
E7E251	Pedal sensor2: Switching output A1 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B305.X:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E7E256	Pedal sensor2: Switching output A1 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B305.X:4		E	1
E7E257	Pedal sensor2: Switching output A1 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B305.X:4		E	1
E7E281	Pedal sensor2: Switching output A1 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B305.X:4		E	1
E7E310	Pedal sensor2: Switching output A2 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B305.X:2		E	1
E7E312	Pedal sensor2: Switching output A2 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B305.X:2		E	1
E7E31D	Pedal sensor2: Switching output A2 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B305.X:2		E	1
E7E351	Pedal sensor2: Switching output A2 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B305.X:2		E	1
E7E356	Pedal sensor2: Switching output A2 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B305.X:2		E	1
E7E357	Pedal sensor2: Switching output A2 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B305.X:2		E	1
E7E381	Pedal sensor2: Switching output A2 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B305.X:2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E7E410	Pedal sensor2: Switching output A3 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B305.X:3		E	1
E7E412	Pedal sensor2: Switching output A3 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B305.X:3		E	1
E7E41D	Pedal sensor2: Switching output A3 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B305.X:3		E	1
E7E451	Pedal sensor2: Switching output A3 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B305.X:3		E	1
E7E456	Pedal sensor2: Switching output A3 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B305.X:3		E	1
E7E457	Pedal sensor2: Switching output A3 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B305.X:3		E	1
E7E481	Pedal sensor2: Switching output A3 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B305.X:3		E	1
E7F102	Pedal sensor2: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1
E7F106	Pedal sensor2: System error OS-CPU0 initialising error RAM erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1
E7F113	Pedal sensor2: System error OS-CPU0 test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E7F175	Pedal sensor2: System error OS-CPU0 SPI -Error, data transfer erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1
E7F180	Pedal sensor2: System error OS-CPU0 fatal internal software error LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1
E7F188	Pedal sensor2: System error OS-CPU0 Configuration does not match software condition LSB sends 0%, current outputs 0 mA Check LSB-Parameter, Coding	B305		E	1
E7F1A0	Pedal sensor2: System error OS-CPU0 impermissible signal deviation LSB LSB sends 0%, current outputs 0 mA Check LSB, other controls	B305		E	1
E7F1A1	Pedal sensor2: System error OS-CPU0 Error in power supply 5V LSB sends 0%, current outputs 0 mA Check supplies, change pedal	B305		E	1
E7F202	Pedal sensor2: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1
E7F206	Pedal sensor2: System error OS-CPU1 initialising error RAM erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1
E7F213	Pedal sensor2: System error OS-CPU1 test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1
E7F280	Pedal sensor2: System error OS-CPU1 fatal internal software error LSB sends 0%, current outputs 0 mA Change Pedal	B305		E	1
E8D017	Pedal sensor3: Supply voltage 24V.1 voltage below required value Entry in error stack Check power supply	B306.X:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E8E110	Pedal sensor3: Switching output A0 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B306.X:5		E	1
E8E112	Pedal sensor3: Switching output A0 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B306.X:5		E	1
E8E11D	Pedal sensor3: Switching output A0 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B306.X:5		E	1
E8E151	Pedal sensor3: Switching output A0 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B306.X:5		E	1
E8E156	Pedal sensor3: Switching output A0 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B306.X:5		E	1
E8E157	Pedal sensor3: Switching output A0 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B306.X:5		E	1
E8E181	Pedal sensor3: Switching output A0 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B306.X:5		E	1
E8E210	Pedal sensor3: Switching output A1 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B306.X:4		E	1
E8E212	Pedal sensor3: Switching output A1 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B306.X:4		E	1
E8E21D	Pedal sensor3: Switching output A1 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B306.X:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E8E251	Pedal sensor3: Switching output A1 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B306.X:4		E	1
E8E256	Pedal sensor3: Switching output A1 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B306.X:4		E	1
E8E257	Pedal sensor3: Switching output A1 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B306.X:4		E	1
E8E281	Pedal sensor3: Switching output A1 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B306.X:4		E	1
E8E310	Pedal sensor3: Switching output A2 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B306.X:2		E	1
E8E312	Pedal sensor3: Switching output A2 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B306.X:2		E	1
E8E31D	Pedal sensor3: Switching output A2 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B306.X:2		E	1
E8E351	Pedal sensor3: Switching output A2 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B306.X:2		E	1
E8E356	Pedal sensor3: Switching output A2 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B306.X:2		E	1
E8E357	Pedal sensor3: Switching output A2 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B306.X:2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E8E381	Pedal sensor3: Switching output A2 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B306.X:2		E	1
E8E410	Pedal sensor3: Switching output A3 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B306.X:3		E	1
E8E412	Pedal sensor3: Switching output A3 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B306.X:3		E	1
E8E41D	Pedal sensor3: Switching output A3 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B306.X:3		E	1
E8E451	Pedal sensor3: Switching output A3 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B306.X:3		E	1
E8E456	Pedal sensor3: Switching output A3 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B306.X:3		E	1
E8E457	Pedal sensor3: Switching output A3 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B306.X:3		E	1
E8E481	Pedal sensor3: Switching output A3 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B306.X:3		E	1
E8F102	Pedal sensor3: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1
E8F106	Pedal sensor3: System error OS-CPU0 initialising error RAM erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
E8F113	Pedal sensor3: System error OS-CPU0 test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1
E8F175	Pedal sensor3: System error OS-CPU0 SPI -Error, data transfer erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1
E8F180	Pedal sensor3: System error OS-CPU0 fatal internal software error LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1
E8F188	Pedal sensor3: System error OS-CPU0 Configuration does not match software condition LSB sends 0%, current outputs 0 mA Check LSB-Parameter, Coding	B306		E	1
E8F1A0	Pedal sensor3: System error OS-CPU0 impermissible signal deviation LSB LSB sends 0%, current outputs 0 mA Check LSB, other controls	B306		E	1
E8F1A1	Pedal sensor3: System error OS-CPU0 Error in power supply 5V LSB sends 0%, current outputs 0 mA Check supplies, change pedal	B306		E	1
E8F202	Pedal sensor3: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1
E8F206	Pedal sensor3: System error OS-CPU1 initialising error RAM erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1
E8F213	Pedal sensor3: System error OS-CPU1 test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1
E8F280	Pedal sensor3: System error OS-CPU1 fatal internal software error LSB sends 0%, current outputs 0 mA Change Pedal	B306		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EAD017	Pedal sensor5: Supply voltage 24V.1 voltage below required value Entry in error stack Check power supply	B308.X:1		E	1
EAE110	Pedal sensor5: Switching output A0 inadmissible signal difference Current outputs 0 mA Check pedal, wiring, load	B308.X:5		E	1
EAE112	Pedal sensor5: Switching output A0 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B308.X:5		E	1
EAE11D	Pedal sensor5: Switching output A0 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B308.X:5		E	1
EAE151	Pedal sensor5: Switching output A0 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B308.X:5		E	1
EAE156	Pedal sensor5: Switching output A0 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B308.X:5		E	1
EAE157	Pedal sensor5: Switching output A0 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B308.X:5		E	1
EAE181	Pedal sensor5: Switching output A0 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B308.X:5		E	1
EAE210	Pedal sensor5: Switching output A1 inadmissible signal difference Current outputs 0 mA Check pedal, wiring, load	B308.X:4		E	1
EAE212	Pedal sensor5: Switching output A1 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B308.X:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EAE21D	Pedal sensor5: Switching output A1 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B308.X:4		E	1
EAE251	Pedal sensor5: Switching output A1 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B308.X:4		E	1
EAE256	Pedal sensor5: Switching output A1 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B308.X:4		E	1
EAE257	Pedal sensor5: Switching output A1 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B308.X:4		E	1
EAE281	Pedal sensor5: Switching output A1 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B308.X:4		E	1
EAE310	Pedal sensor5: Switching output A2 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B308.X:2		E	1
EAE312	Pedal sensor5: Switching output A2 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B308.X:2		E	1
EAE31D	Pedal sensor5: Switching output A2 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B308.X:2		E	1
EAE351	Pedal sensor5: Switching output A2 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B308.X:2		E	1
EAE356	Pedal sensor5: Switching output A2 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B308.X:2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EAE357	Pedal sensor5: Switching output A2 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B308.X:2		E	1
EAE381	Pedal sensor5: Switching output A2 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B308.X:2		E	1
EAE410	Pedal sensor5: Switching output A3 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B308.X:3		E	1
EAE412	Pedal sensor5: Switching output A3 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B308.X:3		E	1
EAE41D	Pedal sensor5: Switching output A3 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B308.X:3		E	1
EAE451	Pedal sensor5: Switching output A3 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B308.X:3		E	1
EAE456	Pedal sensor5: Switching output A3 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B308.X:3		E	1
EAE457	Pedal sensor5: Switching output A3 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B308.X:3		E	1
EAE481	Pedal sensor5: Switching output A3 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B308.X:3		E	1
EAF102	Pedal sensor5: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EAF106	Pedal sensor5: System error OS-CPU0 initialising error RAM erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1
EAF113	Pedal sensor5: System error OS-CPU0 test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1
EAF175	Pedal sensor5: System error OS-CPU0 SPI -Error, data transfer erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1
EAF180	Pedal sensor5: System error OS-CPU0 fatal internal software error LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1
EAF188	Pedal sensor5: System error OS-CPU0 Configuration does not match software condition LSB sends 0%, current outputs 0 mA Check LSB-Parameter, Coding	B308		E	1
EAF1A0	Pedal sensor5: System error OS-CPU0 impermissible signal deviation LSB LSB sends 0%, current outputs 0 mA Check LSB, other controls	B308		E	1
EAF1A1	Pedal sensor5: System error OS-CPU0 Error in power supply 5V LSB sends 0%, current outputs 0 mA Check supplies, change pedal	B308		E	1
EAF202	Pedal sensor5: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1
EAF206	Pedal sensor5: System error OS-CPU1 initialising error RAM erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1
EAF213	Pedal sensor5: System error OS-CPU1 test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EAF280	Pedal sensor5: System error OS-CPU1 fatal internal software error LSB sends 0%, current outputs 0 mA Change Pedal	B308		E	1
EBD017	Pedal sensor6: Supply voltage 24V.1 voltage below required value Entry in error stack Check power supply	B309.X:1		E	1
EBE110	Pedal sensor6: Switching output A0 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B309.X:5		E	1
EBE112	Pedal sensor6: Switching output A0 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B309.X:5		E	1
EBE11D	Pedal sensor6: Switching output A0 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B309.X:5		E	1
EBE151	Pedal sensor6: Switching output A0 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B309.X:5		E	1
EBE156	Pedal sensor6: Switching output A0 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B309.X:5		E	1
EBE157	Pedal sensor6: Switching output A0 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B309.X:5		E	1
EBE181	Pedal sensor6: Switching output A0 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B309.X:5		E	1
EBE210	Pedal sensor6: Switching output A1 inadmissable signal difference Current outputs 0 mA Check pedal, wiring, load	B309.X:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EBE212	Pedal sensor6: Switching output A1 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B309.X:4		E	1
EBE21D	Pedal sensor6: Switching output A1 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B309.X:4		E	1
EBE251	Pedal sensor6: Switching output A1 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B309.X:4		E	1
EBE256	Pedal sensor6: Switching output A1 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B309.X:4		E	1
EBE257	Pedal sensor6: Switching output A1 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B309.X:4		E	1
EBE281	Pedal sensor6: Switching output A1 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B309.X:4		E	1
EBE310	Pedal sensor6: Switching output A2 inadmissible signal difference Current outputs 0 mA Check pedal, wiring, load	B309.X:2		E	1
EBE312	Pedal sensor6: Switching output A2 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B309.X:2		E	1
EBE31D	Pedal sensor6: Switching output A2 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B309.X:2		E	1
EBE351	Pedal sensor6: Switching output A2 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B309.X:2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EBE356	Pedal sensor6: Switching output A2 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B309.X:2		E	1
EBE357	Pedal sensor6: Switching output A2 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B309.X:2		E	1
EBE381	Pedal sensor6: Switching output A2 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B309.X:2		E	1
EBE410	Pedal sensor6: Switching output A3 inadmissible signal difference Current outputs 0 mA Check pedal, wiring, load	B309.X:3		E	1
EBE412	Pedal sensor6: Switching output A3 short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B309.X:3		E	1
EBE41D	Pedal sensor6: Switching output A3 Initial current outside permissible range Current outputs 0 mA Check pedal, wiring, load	B309.X:3		E	1
EBE451	Pedal sensor6: Switching output A3 short circuit to supply voltage, excessive temperature Current outputs 0 mA Check pedal, wiring, load	B309.X:3		E	1
EBE456	Pedal sensor6: Switching output A3 open circuit or short circuit to ground Current outputs 0 mA Check pedal, wiring, load	B309.X:3		E	1
EBE457	Pedal sensor6: Switching output A3 open circuit or short circuit to supply voltage Current outputs 0 mA Check pedal, wiring, load	B309.X:3		E	1
EBE481	Pedal sensor6: Switching output A3 short circuit to supply voltage, open line Current outputs 0 mA Check pedal, wiring, load	B309.X:3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EBF102	Pedal sensor6: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1
EBF106	Pedal sensor6: System error OS-CPU0 initialising error RAM erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1
EBF113	Pedal sensor6: System error OS-CPU0 test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1
EBF175	Pedal sensor6: System error OS-CPU0 SPI -Error, data transfer erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1
EBF180	Pedal sensor6: System error OS-CPU0 fatal internal software error LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1
EBF188	Pedal sensor6: System error OS-CPU0 Configuration does not match software condition LSB sends 0%, current outputs 0 mA Check LSB-Parameter, Coding	B309		E	1
EBF1A0	Pedal sensor6: System error OS-CPU0 impermissible signal deviation LSB LSB sends 0%, current outputs 0 mA Check LSB, other controls	B309		E	1
EBF1A1	Pedal sensor6: System error OS-CPU0 Error in power supply 5V LSB sends 0%, current outputs 0 mA Check supplies, change pedal	B309		E	1
EBF202	Pedal sensor6: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1
EBF206	Pedal sensor6: System error OS-CPU1 initialising error RAM erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EBF213	Pedal sensor6: System error OS-CPU1 test total in EPROM/FLASH erroneous LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1
EBF280	Pedal sensor6: System error OS-CPU1 fatal internal software error LSB sends 0%, current outputs 0 mA Change Pedal	B309		E	1
EC5BB4	LSB-BTB16: Operation ballasting / counterweight carriage Key switch coasting actuated after start or is stuck No release of coasting check wiring	A836		E	
EC5CD0	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1133 defect Output of error check wiring	A836		E	
EC5CD1	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1135 defect Output of error check wiring	A836		E	
EC5CD2	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1137 defect Output of error check wiring	A836		E	
EC5CD3	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1139 defect Output of error check wiring	A836		E	
EC5CD4	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1141 defect Output of error check wiring	A836		E	
EC5CD5	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1143 defect Output of error check wiring	A836		E	
EC5CD6	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1145 defect Output of error check wiring	A836		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EC5CD7	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1147 defect Output of error check wiring	A836		E	
EC5CD8	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1132 defect Output of error check wiring	A836		E	
EC5CD9	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1134 defect Output of error check wiring	A836		E	
EC5CDA	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1136 defect Output of error check wiring	A836		E	
EC5CDB	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1138 defect Output of error check wiring	A836		E	
EC5CDC	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1140 defect Output of error check wiring	A836		E	
EC5CDD	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1142 defect Output of error check wiring	A836		E	
EC5CDE	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1144 defect Output of error check wiring	A836		E	
EC5CDF	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1146 defect Output of error check wiring	A836		E	
EC5CE0	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force relay -K1101 defect Output of error check wiring	A836		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EC5CE1	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force relay -K1103 defect Output of error check wiring	A836		E	
EC5CE2	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force relay -K1102 defect Output of error check wiring	A836		E	
EC5CE3	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1147 defect Output of error check wiring	A836		E	
EC5CE4	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1148 defect Output of error check wiring	A836		E	
EC5CE5	LSB-BTB16: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1149 defect Output of error check wiring	A836		E	
EC5CF0	LSB-BTB16: Control ballasting / counterweight carriage Ground switch safety control unit has short circuit after Plus No release of emerg. stop chain Crane and SPMT check wiring	A836		E	
EC5CF1	LSB-BTB16: Control ballasting / counterweight carriage Ground switch safety control unit has short circuit after ground No release of emerg. stop chain Crane and SPMT check wiring	A836		E	
EC5CF2	LSB-BTB16: Control ballasting / counterweight carriage Open line report circuit ground switch safety control unit No release of emerg. stop chain Crane and SPMT check wiring	A836		E	
ED016A	LSB-BTB15: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED016C	LSB-BTB15: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED026A	LSB-BTB15: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED026C	LSB-BTB15: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED036A	LSB-BTB15: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED036C	LSB-BTB15: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED076A	LSB-BTB15: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED076C	LSB-BTB15: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED086A	LSB-BTB15: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED086C	LSB-BTB15: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED096A	LSB-BTB15: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED096C	LSB-BTB15: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED0B6A	LSB-BTB15: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED0B6C	LSB-BTB15: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED0F6A	LSB-BTB15: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED0F6C	LSB-BTB15: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED136A	LSB-BTB15: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED136C	LSB-BTB15: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED146A	LSB-BTB15: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED146C	LSB-BTB15: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED176A	LSB-BTB15: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED176C	LSB-BTB15: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED186A	LSB-BTB15: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED186C	LSB-BTB15: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED196A	LSB-BTB15: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED196C	LSB-BTB15: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED1A6A	LSB-BTB15: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED1A6C	LSB-BTB15: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED1C6A	LSB-BTB15: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:12		E	2
ED1C6C	LSB-BTB15: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:12		E	2
ED205B	LSB-BTB15: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A835.X4:12		E	2
ED316A	LSB-BTB15: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED316C	LSB-BTB15: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED326A	LSB-BTB15: LSBB Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED326C	LSB-BTB15: LSBB Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED396A	LSB-BTB15: LSBB Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED396C	LSB-BTB15: LSBB Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED3A6A	LSB-BTB15: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED3A6C	LSB-BTB15: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED3B6A	LSB-BTB15: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED3B6C	LSB-BTB15: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED3C6A	LSB-BTB15: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED3C6C	LSB-BTB15: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED416A	LSB-BTB15: LSBB Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED416C	LSB-BTB15: LSBB Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED426A	LSB-BTB15: LSBB Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED426C	LSB-BTB15: LSBB Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED436A	LSB-BTB15: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED436C	LSB-BTB15: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED446A	LSB-BTB15: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED446C	LSB-BTB15: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED476A	LSB-BTB15: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED476C	LSB-BTB15: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED4B6A	LSB-BTB15: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED4B6C	LSB-BTB15: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED4C6A	LSB-BTB15: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED4C6C	LSB-BTB15: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED4D6A	LSB-BTB15: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED4D6C	LSB-BTB15: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED4E6A	LSB-BTB15: LSBB Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A835.X4:9		E	2
ED4E6C	LSB-BTB15: LSBB Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A835.X4:9		E	2
ED505B	LSB-BTB15: Control data transfer LSBB Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A835.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED5CB0	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1101 defect Output of error check wiring	A835		E	
ED5CB1	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1103 defect Output of error check wiring	A835		E	
ED5CB2	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1105 defect Output of error check wiring	A835		E	
ED5CB3	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1107 defect Output of error check wiring	A835		E	
ED5CB4	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1109 defect Output of error check wiring	A835		E	
ED5CB5	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1111 defect Output of error check wiring	A835		E	
ED5CB6	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1113 defect Output of error check wiring	A835		E	
ED5CB7	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1115 defect Output of error check wiring	A835		E	
ED5CB8	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1100 defect Output of error check wiring	A835		E	
ED5CB9	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1102 defect Output of error check wiring	A835		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED5CBA	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1104 defect Output of error check wiring	A835		E	
ED5CBB	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1106 defect Output of error check wiring	A835		E	
ED5CBC	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1108 defect Output of error check wiring	A835		E	
ED5CBD	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1110 defect Output of error check wiring	A835		E	
ED5CBE	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1112 defect Output of error check wiring	A835		E	
ED5CBF	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1114 defect Output of error check wiring	A835		E	
ED5CC0	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1117 defect Output of error check wiring	A835		E	
ED5CC1	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1119 defect Output of error check wiring	A835		E	
ED5CC2	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1121 defect Output of error check wiring	A835		E	
ED5CC3	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1123 defect Output of error check wiring	A835		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED5CC4	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1125 defect Output of error check wiring	A835		E	
ED5CC5	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1127 defect Output of error check wiring	A835		E	
ED5CC6	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1129 defect Output of error check wiring	A835		E	
ED5CC7	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1131 defect Output of error check wiring	A835		E	
ED5CC8	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1116 defect Output of error check wiring	A835		E	
ED5CC9	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1118 defect Output of error check wiring	A835		E	
ED5CCA	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1120 defect Output of error check wiring	A835		E	
ED5CCB	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1122 defect Output of error check wiring	A835		E	
ED5CCC	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1124 defect Output of error check wiring	A835		E	
ED5CCD	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1126 defect Output of error check wiring	A835		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED5CCE	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1128 defect Output of error check wiring	A835		E	
ED5CCF	LSB-BTB15: Control ballasting / counterweight carriage Display ballast trailer swing/lateral force light -E1130 defect Output of error check wiring	A835		E	
ED5D51	LSB-BTB15: control auxiliary equipment Button Ladder UP after Start/op. error actuated or stuck	A835		E	1
ED5D52	LSB-BTB15: control auxiliary equipment Button Ladder DOWN after Start/op. error actuated or stuck	A835		E	1
ED5D53	LSB-BTB15: control auxiliary equipment Forced zero position double control of latter (button and BTT)	A835		E	1
ED5D54	LSB-BTB15: control auxiliary equipment Control panel Support Button act. after start or stuck	A835		E	1
ED5D55	LSB-BTB15: control auxiliary equipment Control panel Pinning Button act. after start or stuck	A835		E	1
ED5D60	LSB-BTB15: control auxiliary equipment Key button release vibrator operation at start actuated/sticks Error message no switching to external operation possible check wiring	A835		E	1
ED5D61	LSB-BTB15: control auxiliary equipment No release for vibrator operation external watchdog not OK Error message no switching to external operation possible Check system communication between BTB15 and Tiefenbacher	A835		B	1
ED5D62	LSB-BTB15: control auxiliary equipment No release for vibrator operation radio operation is active Error message no switching to external operation possible End radio operation	A835		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED5E4A	LSB-BTB15: crane control Pressure supply HV short circuit after ground or interruption	A835		E	1
ED5E4D	LSB-BTB15: crane control Monitoring Release Pinning, Short circuit after Plus	A835		E	1
ED5E4E	LSB-BTB15: crane control Monitoring Release Pinning, interruption/Short circuit after ground	A835		E	1
ED5E7E	LSB-BTB15: crane control Warning pressure supply HV < pmin with actuation	A835		E	1
ED5E7F	LSB-BTB15: crane control Warning pressure supply HV > pmin without actuation	A835		E	1
ED613A	LSB-BTB15: Operation crane control Selection Assembly winch from several op. positions simultaneous	A835		E	1
ED613B	LSB-BTB15: Operation crane control Selection Assembly winch spool up and out simultaneous	A835		E	1
ED613C	LSB-BTB15: Operation crane control Notice! Unplug control panel during crane operation!	A835		E	1
ED62BE	LSB-BTB15: Control hydraulic Remeasure BKE, output error Function tilt cab	A835		E	1
ED62BF	LSB-BTB15: Control hydraulic Remeasure BKE, output error Function swing cab	A835		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED62C5	LSB-BTB15: Control hydraulic Valve assembly cylinder up/down stuck	A835		E	1
ED62C6	LSB-BTB15: Control hydraulic Pressure supply turntable has leakage	A835		E	1
ED62C7	LSB-BTB15: Control hydraulic Valve assembly winch up/down stuck	A835		E	1
ED62C8	LSB-BTB15: Control hydraulic Valve swing cab in / out stuck	A835		E	1
ED62C9	LSB-BTB15: Control hydraulic Valve tilt cab up / down stuck	A835		E	1
ED62CA	LSB-BTB15: Control hydraulic Valve ladder up / down stuck	A835		E	1
ED62CB	LSB-BTB15: Control hydraulic Valve support center section up / down stuck	A835		E	1
ED62CD	LSB-BTB15: Control hydraulic Flow switch Support does not switch at movement selection	A835		E	1
ED62CE	LSB-BTB15: Control hydraulic Flow switch Assembly cyl. does not switch at movement sel.	A835		E	1
ED62CF	LSB-BTB15: Control hydraulic Flow switch Cab function does not switch at movement sel.	A835		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED7007	LSB-BTB15: remote control Zero position compulsion on radio MS	A835		E	1
ED7019	LSB-BTB15: remote control No radio release (electrical signal not available)	A835		E	1
ED7090	LSB-BTB15: remote control Short circuit after supply voltage on radio input UEA	A835		E	1
ED9900	LSB-BTB15: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A835		E	2
ED9901	LSB-BTB15: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A835		E	2
ED9902	LSB-BTB15: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A835		E	1
ED9904	LSB-BTB15: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A835		E	1
ED9905	LSB-BTB15: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A835		E	1
ED9906	LSB-BTB15: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A835		E	2
ED9907	LSB-BTB15: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A835		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
ED9911	LSB-BTB15: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A835		E	2
EDC218	LSB-BTB15: Hardware excess temperature Entry in error stack Replace LSB-Module	A835		E	2
EDC21B	LSB-BTB15: Hardware digital shut off defective Entry in error stack Report all error parameters to Service	A835		E	2
EDC21F	LSB-BTB15: Hardware After run logic defective Entry in error stack Report all error parameters to Service	A835		E	2
EDC226	LSB-BTB15: Hardware Under temperature Entry in error stack Replace LSB-Module	A835		E	2
EDC261	LSB-BTB15: Hardware measuring system defect Entry in error stack Replace LSB-Module	A835		E	2
EDC504	LSB-BTB15: System voltage Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A835		E	2
EDC505	LSB-BTB15: System voltage Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A835		E	2
EDC50F	LSB-BTB15: System voltage Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A835		E	2
EDC604	LSB-BTB15: System voltage CPU/Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A835		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDC605	LSB-BTB15: System voltage CPU/Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A835		E	2
EDC60F	LSB-BTB15: System voltage CPU/Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A835		E	2
EDC704	LSB-BTB15: Supply voltage 30 (A0-7) / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A835.X1:2/3		E	2
EDC705	LSB-BTB15: Supply voltage 30 (A0-7) / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A835.X1:2/3		E	2
EDC804	LSB-BTB15: Supply voltage 15.1 / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A835.X1:1		E	2
EDC805	LSB-BTB15: Supply voltage 15.1 / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A835.X1:1		E	2
EDC80F	LSB-BTB15: Supply voltage 15.1 / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A835.X1:1		E	2
EDCC04	LSB-BTB15: System voltage Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A835		E	2
EDCC05	LSB-BTB15: System voltage Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A835		E	2
EDCC0F	LSB-BTB15: System voltage Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A835		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDCD04	LSB-BTB15: System voltage CPU/Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A835		E	2
EDCD05	LSB-BTB15: System voltage CPU/Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A835		E	2
EDCD0F	LSB-BTB15: System voltage CPU/Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A835		E	2
EDCE04	LSB-BTB15: Supply voltage 30 (A8-15) / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A835.X2:2/3		E	2
EDCE05	LSB-BTB15: Supply voltage 30 (A8-15) / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A835.X2:2/3		E	2
EDCF04	LSB-BTB15: Supply voltage 15.1 / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A835.X2:1		E	2
EDCF05	LSB-BTB15: Supply voltage 15.1 / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A835.X2:1		E	2
EDCF0F	LSB-BTB15: Supply voltage 15.1 / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A835.X2:1		E	2
EDD004	LSB-BTB15: Digital input E0 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:4		E	2
EDD005	LSB-BTB15: Digital input E0 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDD104	LSB-BTB15: Digital input E1 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:5		E	2
EDD105	LSB-BTB15: Digital input E1 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:5		E	2
EDD204	LSB-BTB15: Digital input E2 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:6		E	2
EDD205	LSB-BTB15: Digital input E2 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:6		E	2
EDD304	LSB-BTB15: Digital input E3 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:7		E	2
EDD305	LSB-BTB15: Digital input E3 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:7		E	2
EDD403	LSB-BTB15: Digital input E4 sensor deficiency data short circuit to ground	A835.X1:8		E	1
EDD503	LSB-BTB15: Digital input E5 sensor deficiency data short circuit to ground	A835.X1:9		E	1
EDD603	LSB-BTB15: Digital input E6 sensor deficiency data short circuit to ground	A835.X1:10		E	1
EDD804	LSB-BTB15: Digital input E8 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDD805	LSB-BTB15: Digital input E8 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:4		E	2
EDD904	LSB-BTB15: Digital input E9 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:5		E	2
EDD905	LSB-BTB15: Digital input E9 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:5		E	2
EDD956	LSB-BTB15: Digital input E9 open circuit or short circuit to ground	A835.X2:5		E	1
EDDA04	LSB-BTB15: Digital input E10 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:6		E	2
EDDA05	LSB-BTB15: Digital input E10 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:6		E	2
EDDA56	LSB-BTB15: Digital input E10 open circuit or short circuit to ground	A835.X2:6		E	1
EDDB04	LSB-BTB15: Digital input E11 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:7		E	2
EDDB05	LSB-BTB15: Digital input E11 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:7		E	2
EDE012	LSB-BTB15: Switching output A0 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDE015	LSB-BTB15: Switching output A0 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:12		E	2
EDE01D	LSB-BTB15: Switching output A0 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X1:12		E	2
EDE054	LSB-BTB15: Switching output A0 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:12		E	2
EDE072	LSB-BTB15: Switching output A0 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:12		E	2
EDE112	LSB-BTB15: Switching output A1 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:13		E	2
EDE115	LSB-BTB15: Switching output A1 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:13		E	2
EDE11D	LSB-BTB15: Switching output A1 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X1:13		E	2
EDE154	LSB-BTB15: Switching output A1 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:13		E	2
EDE172	LSB-BTB15: Switching output A1 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:13		E	2
EDE212	LSB-BTB15: Switching output A2 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:14		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDE215	LSB-BTB15: Switching output A2 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:14		E	2
EDE21D	LSB-BTB15: Switching output A2 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X1:14		E	2
EDE254	LSB-BTB15: Switching output A2 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:14		E	2
EDE272	LSB-BTB15: Switching output A2 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:14		E	2
EDE312	LSB-BTB15: Switching output A3 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:15		E	2
EDE315	LSB-BTB15: Switching output A3 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:15		E	2
EDE31D	LSB-BTB15: Switching output A3 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X1:15		E	2
EDE354	LSB-BTB15: Switching output A3 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:15		E	2
EDE372	LSB-BTB15: Switching output A3 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:15		E	2
EDE412	LSB-BTB15: Switching output A4 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDE415	LSB-BTB15: Switching output A4 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:16		E	2
EDE41D	LSB-BTB15: Switching output A4 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X1:16		E	2
EDE454	LSB-BTB15: Switching output A4 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:16		E	2
EDE472	LSB-BTB15: Switching output A4 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:16		E	2
EDE512	LSB-BTB15: Switching output A5 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:17		E	2
EDE515	LSB-BTB15: Switching output A5 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:17		E	2
EDE51D	LSB-BTB15: Switching output A5 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X1:17		E	2
EDE554	LSB-BTB15: Switching output A5 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:17		E	2
EDE572	LSB-BTB15: Switching output A5 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:17		E	2
EDE612	LSB-BTB15: Switching output A6 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:18		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDE615	LSB-BTB15: Switching output A6 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:18		E	2
EDE61D	LSB-BTB15: Switching output A6 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X1:18		E	2
EDE654	LSB-BTB15: Switching output A6 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:18		E	2
EDE672	LSB-BTB15: Switching output A6 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:18		E	2
EDE712	LSB-BTB15: Switching output A7 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:19		E	2
EDE715	LSB-BTB15: Switching output A7 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:19		E	2
EDE71D	LSB-BTB15: Switching output A7 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X1:19		E	2
EDE754	LSB-BTB15: Switching output A7 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:19		E	2
EDE772	LSB-BTB15: Switching output A7 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X1:19		E	2
EDE812	LSB-BTB15: Switching output A8 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDE815	LSB-BTB15: Switching output A8 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:12		E	2
EDE81D	LSB-BTB15: Switching output A8 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X2:12		E	2
EDE854	LSB-BTB15: Switching output A8 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:12		E	2
EDE872	LSB-BTB15: Switching output A8 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:12		E	2
EDE912	LSB-BTB15: Switching output A9 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:13		E	2
EDE915	LSB-BTB15: Switching output A9 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:13		E	2
EDE91D	LSB-BTB15: Switching output A9 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X2:13		E	2
EDE954	LSB-BTB15: Switching output A9 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:13		E	2
EDE972	LSB-BTB15: Switching output A9 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:13		E	2
EDEA12	LSB-BTB15: Switching output A10 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:14		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDEA15	LSB-BTB15: Switching output A10 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:14		E	2
EDEA1D	LSB-BTB15: Switching output A10 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X2:14		E	2
EDEA54	LSB-BTB15: Switching output A10 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:14		E	2
EDEA72	LSB-BTB15: Switching output A10 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:14		E	2
EDEB12	LSB-BTB15: Switching output A11 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:15		E	2
EDEB15	LSB-BTB15: Switching output A11 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:15		E	2
EDEB1D	LSB-BTB15: Switching output A11 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X2:15		E	2
EDEB54	LSB-BTB15: Switching output A11 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:15		E	2
EDEB72	LSB-BTB15: Switching output A11 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:15		E	2
EDEC12	LSB-BTB15: Switching output A12 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDEC15	LSB-BTB15: Switching output A12 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:16		E	2
EDEC1D	LSB-BTB15: Switching output A12 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X2:16		E	2
EDEC54	LSB-BTB15: Switching output A12 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:16		E	2
EDEC72	LSB-BTB15: Switching output A12 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:16		E	2
EDED12	LSB-BTB15: Switching output A13 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:17		E	2
EDED15	LSB-BTB15: Switching output A13 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:17		E	2
EDED1D	LSB-BTB15: Switching output A13 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X2:17		E	2
EDED54	LSB-BTB15: Switching output A13 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:17		E	2
EDED72	LSB-BTB15: Switching output A13 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:17		E	2
EDEE12	LSB-BTB15: Switching output A14 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:18		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDEE15	LSB-BTB15: Switching output A14 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:18		E	2
EDEE1D	LSB-BTB15: Switching output A14 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X2:18		E	2
EDEE54	LSB-BTB15: Switching output A14 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:18		E	2
EDEE72	LSB-BTB15: Switching output A14 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:18		E	2
EDEF12	LSB-BTB15: Switching output A15 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:19		E	2
EDEF15	LSB-BTB15: Switching output A15 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:19		E	2
EDEF1D	LSB-BTB15: Switching output A15 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A835.X2:19		E	2
EDEF54	LSB-BTB15: Switching output A15 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:19		E	2
EDEF72	LSB-BTB15: Switching output A15 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A835.X2:19		E	2
EDF002	LSB-BTB15: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A835		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDF013	LSB-BTB15: System error OS-CPU0 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A835		E	1
EDF016	LSB-BTB15: System error OS-CPU0 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A835		E	1
EDF050	LSB-BTB15: System error OS-CPU0 file not available error report Reload application software	A835		E	2
EDF068	LSB-BTB15: System error OS-CPU0 impermissible interrupt Entry in error stack Report all error parameters to Service	A835		E	1
EDF070	LSB-BTB15: System error OS-CPU0 various structure versions Entry in error stack Report all error parameters to Service	A835		E	1
EDF073	LSB-BTB15: System error OS-CPU0 interpreter error Entry in error stack At P0=00000013 carry out download	A835		E	1
EDF075	LSB-BTB15: System error OS-CPU0 SPI-error Entry in error stack Report all error parameters to Service	A835		E	1
EDF078	LSB-BTB15: System error OS-CPU0 impermissible parameter Entry in error stack Report all error parameters to Service	A835		E	1
EDF07A	LSB-BTB15: System error OS-CPU0 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A835		E	2
EDF080	LSB-BTB15: System error OS-CPU0 Fatal internal error Entry in error stack Report all error parameters to Service	A835		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDF082	LSB-BTB15: System error OS-CPU0 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A835		E	1
EDF0AC	LSB-BTB15: System error OS-CPU0 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A835		E	1
EDF0C1	LSB-BTB15: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A835		E	1
EDF0D2	LSB-BTB15: System error OS-CPU0 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A835		E	2
EDF102	LSB-BTB15: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A835		E	1
EDF113	LSB-BTB15: System error OS-CPU1 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A835		E	1
EDF116	LSB-BTB15: System error OS-CPU1 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A835		E	1
EDF150	LSB-BTB15: System error OS-CPU1 file not available error report Reload application software	A835		E	2
EDF168	LSB-BTB15: System error OS-CPU1 impermissible interrupt Entry in error stack Report all error parameters to Service	A835		E	1
EDF170	LSB-BTB15: System error OS-CPU1 various structure versions Entry in error stack Report all error parameters to Service	A835		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDF173	LSB-BTB15: System error OS-CPU1 interpreter error Entry in error stack At P0=00000013 carry out download	A835		E	1
EDF175	LSB-BTB15: System error OS-CPU1 SPI-error Entry in error stack Report all error parameters to Service	A835		E	1
EDF178	LSB-BTB15: System error OS-CPU1 impermissible parameter Entry in error stack Report all error parameters to Service	A835		E	1
EDF17A	LSB-BTB15: System error OS-CPU1 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A835		E	2
EDF180	LSB-BTB15: System error OS-CPU1 Fatal internal error Entry in error stack Report all error parameters to Service	A835		E	1
EDF182	LSB-BTB15: System error OS-CPU1 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A835		E	1
EDF1AC	LSB-BTB15: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A835		E	1
EDF1C1	LSB-BTB15: System error OS-CPU1 Incorrect or wrong system version for application error report Reload matching system version	A835		E	1
EDF1D2	LSB-BTB15: System error OS-CPU1 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A835		E	2
EDF800	LSB-BTB15: Control data transfer CAN EP0 internal error at Register-check Controller CAN-transfer is not started replace control device	A835.X3:7/8/3/3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDF801	LSB-BTB15: Control data transfer CAN EP0 internal error at RAM-check Controller CAN-transfer is not started replace control device	A835.X3:7/8/3/3		E	2
EDF802	LSB-BTB15: Control data transfer CAN EP0 Configuration error Software Error message, CAN report is not configured Check software	A835.X3:7/8/3/3		E	1
EDF804	LSB-BTB15: Control data transfer CAN EP0 Configuration error time synchronization Time synchronization already active or is not configured Check software	A835.X3:7/8/3/3		E	1
EDF805	LSB-BTB15: Control data transfer CAN EP0 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A835.X3:7/8/3/3		E	1
EDF806	LSB-BTB15: Control data transfer CAN EP0 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A835.X3:7/8/3/3		E	2
EDF807	LSB-BTB15: Control data transfer CAN EP0 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A835.X3:7/8/3/3		E	1
EDF811	LSB-BTB15: Control data transfer CAN EP0 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A835.X3:7/8/3/3		E	2
EDF900	LSB-BTB15: Control data transfer CAN EP1 internal error at Register-check Controller CAN-transfer is not started replace control device	A835.X4:1/2/14/ 13		E	2
EDF901	LSB-BTB15: Control data transfer CAN EP1 internal error at RAM-check Controller CAN-transfer is not started replace control device	A835.X4:1/2/14/ 13		E	2
EDF902	LSB-BTB15: Control data transfer CAN EP1 Configuration error Software Error message, CAN report is not configured Check software	A835.X4:1/2/14/ 13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDF904	LSB-BTB15: Control data transfer CAN EP1 Configuration error time synchronization Time synchronization already active or is not configured Check software	A835.X4:1/2/14/ 13		E	1
EDF905	LSB-BTB15: Control data transfer CAN EP1 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A835.X4:1/2/14/ 13		E	1
EDF906	LSB-BTB15: Control data transfer CAN EP1 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A835.X4:1/2/14/ 13		E	2
EDF907	LSB-BTB15: Control data transfer CAN EP1 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A835.X4:1/2/14/ 13		E	1
EDF911	LSB-BTB15: Control data transfer CAN EP1 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A835.X4:1/2/14/ 13		E	2
EDFA00	LSB-BTB15: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A835.X3:7/8		E	1
EDFA01	LSB-BTB15: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A835.X3:7/8		E	1
EDFA02	LSB-BTB15: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A835.X3:7/8		E	1
EDFA04	LSB-BTB15: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A835.X3:7/8		E	1
EDFA05	LSB-BTB15: Control data transfer CAN-A Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A835.X3:7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDFA06	LSB-BTB15: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A835.X3:7/8		E	2
EDFA11	LSB-BTB15: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A835.X3:7/8		E	1
EDFA32	LSB-BTB15: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A835.X3:7/8		E	1
EDFA40	LSB-BTB15: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A835.X3:7/8		E	1
EDFA41	LSB-BTB15: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A835.X3:7/8		E	1
EDFB00	LSB-BTB15: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A835.X3:3/4		E	1
EDFB01	LSB-BTB15: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A835.X3:3/4		E	1
EDFB02	LSB-BTB15: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A835.X3:3/4		E	1
EDFB04	LSB-BTB15: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A835.X3:3/4		E	1
EDFB05	LSB-BTB15: Control data transfer CAN-B Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A835.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDFB06	LSB-BTB15: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A835.X3:3/4		E	2
EDFB11	LSB-BTB15: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A835.X3:3/4		E	1
EDFB32	LSB-BTB15: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A835.X3:3/4		E	1
EDFB40	LSB-BTB15: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A835.X3:3/4		E	1
EDFB41	LSB-BTB15: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A835.X3:3/4		E	1
EDFC00	LSB-BTB15: Control data transfer CAN-C internal error at Register-check Controller CAN-transfer is not started replace control device	A835.X4:1/2		E	1
EDFC01	LSB-BTB15: Control data transfer CAN-C internal error at RAM-check Controller CAN-transfer is not started replace control device	A835.X4:1/2		E	1
EDFC02	LSB-BTB15: Control data transfer CAN-C Configuration error Software Error message, CAN report is not configured Check software	A835.X4:1/2		E	1
EDFC04	LSB-BTB15: Control data transfer CAN-C Configuration error time synchronization Time synchronization already active or is not configured Check software	A835.X4:1/2		E	1
EDFC05	LSB-BTB15: Control data transfer CAN-C Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A835.X4:1/2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDFC06	LSB-BTB15: Control data transfer CAN-C fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A835.X4:1/2		E	2
EDFC11	LSB-BTB15: Control data transfer CAN-C permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A835.X4:1/2		E	1
EDFC32	LSB-BTB15: Control data transfer CAN-C Data transfer erroneous/missing check wiring	A835.X4:1/2		E	1
EDFC40	LSB-BTB15: Control data transfer CAN-C Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A835.X4:1/2		E	1
EDFC41	LSB-BTB15: Control data transfer CAN-C Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A835.X4:1/2		E	1
EDFD00	LSB-BTB15: Control data transfer CAN-D internal error at Register-check Controller CAN-transfer is not started replace control device	A835.X4:14/13		E	1
EDFD01	LSB-BTB15: Control data transfer CAN-D internal error at RAM-check Controller CAN-transfer is not started replace control device	A835.X4:14/13		E	1
EDFD02	LSB-BTB15: Control data transfer CAN-D Configuration error Software Error message, CAN report is not configured Check software	A835.X4:14/13		E	1
EDFD04	LSB-BTB15: Control data transfer CAN-D Configuration error time synchronization Time synchronization already active or is not configured Check software	A835.X4:14/13		E	1
EDFD05	LSB-BTB15: Control data transfer CAN-D Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A835.X4:14/13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EDFD06	LSB-BTB15: Control data transfer CAN-D fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A835.X4:14/13		E	2
EDFD11	LSB-BTB15: Control data transfer CAN-D permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A835.X4:14/13		E	1
EDFD32	LSB-BTB15: Control data transfer CAN-D Data transfer erroneous/missing check wiring	A835.X4:14/13		E	1
EDFD40	LSB-BTB15: Control data transfer CAN-D Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A835.X4:14/13		E	1
EDFD41	LSB-BTB15: Control data transfer CAN-D Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A835.X4:14/13		E	1
EFF001	LSB-BTT: System error Data comm. Infrared or cable defect (charge impulse recognized) Fatal system error BTT, Data transfer interrupted Clean cover glass for infrared interface, replace BTT or payload bay			E	1
EFF002	LSB-BTT: System error Data communication via Infrared or cables without charge impulse Fatal system error BTT, Data transfer interrupted Clean charge contacts, replace BTT or payload bay			E	1
EFF003	LSB-BTT: System error General internal error Fatal system error BTT, Data transfer interrupted Reset, replace BTT			E	2
EFF004	LSB-BTT: System error Data transfer erroneous, Packet size incorrect Fatal system error BTT, Data transfer interrupted Reset, BTT or replace BTB			E	2
EFF005	LSB-BTT: System error Data transfer erroneous, Packet content incorrect Fatal system error BTT, Data transfer interrupted Reset, BTT or replace BTB			E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
EFF006	LSB-BTT: System error Data transfer pictograms to BTT-E defective Fatal system error BTT, Data transfer interrupted Clean cover glass for infrared interface, replace BTT or BTT-E			E	2
EFF007	LSB-BTT: System error File system Fatal system error BTT, Data transfer interrupted After software change, load BTT, replace BTT			E	2
EFF008	LSB-BTT: System error Comm-driver Fatal system error BTT, Data transfer interrupted Reset, after software replacement load BTT, replace BTT			E	2
EFF009	LSB-BTT: System error Synchronization internal software processes (thread) erroneous Fatal system error BTT, Data transfer interrupted Reset, after software replacement load BTT, replace BTT			E	2
EFF010	LSB-BTT: System error Data format of a pictogram invalid Fatal system error BTT, Data transfer interrupted Replace software			E	2
EFF011	LSB-BTT: System error Maximum number of pictograms exceeded Fatal system error BTT, Data transfer interrupted BTT-E tauschen			E	2
F00000	LSB-BKE1: Central lubrication system defective Indicator light red, entry in error stack Check central greasing system, change module if nec.	A371.X2:11		E	1
F00110	LSB-BKE1: Tele control Pin condition Tele/tong erroneous/implausible Entry in error stack Check limit switch and electr. connections, change module if nec.	A371		E	1
F01000	LSB-BKE1: Central lubrication 1 defective Indicator light red, entry in error stack Check electr. connections and central lubr. system, replace module, if nec.	A371.X2:11		E	1
F01100	LSB-BKE1: Central lubrication 2 defective Indicator light red, entry in error stack Check electr. connections and central lubr. system, replace module, if nec.	A371.X2:17		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F01200	LSB-BKE1: Central lubrication 3 defective Indicator light red, entry in error stack Check electr. connections and central lubr. system, replace module, if nec.	A371.X2:5		E	1
F02000	LSB-BKE1: Airplane warning light defective Entry in error stack Check electr. connections and airplane warning light, replace module, if nec.	A371.X2:16		E	1
F02001	LSB-BKE1: Airplane warning light Erroneous - emerg. light source active Entry in error stack When emerg. Light (under LED-block) replace active lamp, otherwise check wiring	A371.X2:16		E	1
F0605D	LSB-BKE1: Module temperature too high / prewarning Entry in error stack Check power users(headlights)+ electr. connections, replace module if nec.	A371		E	2
F0605E	LSB-BKE1: Module temperature too high / shut off of users Headlights are turned off step by step, entry in error stack Check power users(headlights)+ electr. connections, replace module if nec.	A371		E	2
F07090	LSB-BKE1: Keyboard Button actuated/erroneous Entry in error stack Replace module	A371		E	1
F08781	LSB-BKE1: Digital input E0.7 short circuit to supply voltage, open line Error display per blinking LED, Entry in error stack Test electr. connections and windshield wiper motor, change module if nec.	A371.X2:3		E	1
F08881	LSB-BKE1: Digital input E0.8 short circuit to supply voltage, open line Error display per blinking LED, Entry in error stack Test electr. connections and windshield wiper motor, change module if nec.	A371.X2:1		E	1
F08981	LSB-BKE1: Digital input E0.9 short circuit to supply voltage, open line Error display per blinking LED, Entry in error stack Test electr. connections and windshield wiper motor, change module if nec.	A371.X2:2		E	1
F0B05C	LSB-BKE1: Supply voltage 30.4 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X4:2/3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F0B15C	LSB-BKE1: Supply voltage 30.1 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X3:2		E	2
F0B25C	LSB-BKE1: Supply voltage 30.2 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X3:3		E	2
F0B35C	LSB-BKE1: Supply voltage 30.3 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X3:6		E	2
F0B45C	LSB-BKE1: Supply voltage 15.2 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X4:6		E	2
F0B55C	LSB-BKE1: Supply voltage 15.1 missing or too low Entry in error stack Test current, electr. connections and fuse, change module if nec.	A371.X1:2		E	2
F0C05B	LSB-BKE1: Switch outlet A0.0 open, insufficient load, short circuit, overload or excess temp. Entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:10		E	1
F0C25B	LSB-BKE1: Switching output A0.2 open, insufficient load, short circuit, overload or excess temp. Entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:7		E	1
F0C45B	LSB-BKE1: Switching output A0.4 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:8		E	1
F0C55B	LSB-BKE1: Switching output A0.5 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:11		E	1
F0C65B	LSB-BKE1: Switching output A0.6 open, insufficient load, short circuit, overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:15		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F0C75B	LSB-BKE1: Switching output A0.7 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:8		E	1
F0C85B	LSB-BKE1: Switching output A0.8 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:9		E	1
F0C95B	LSB-BKE1: Switching output A0.9 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X4:12		E	1
F0CA5B	LSB-BKE1: Switching output A0.10 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:9		E	1
F0CB5B	LSB-BKE1: Switching output A0.11 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:12		E	1
F0CC5B	LSB-BKE1: Switching output A0.12 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:15		E	1
F0CE5B	LSB-BKE1: Switching output A0.14 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW4 Check outlet supply, user, change module if nec.	A371.X3:14		E	1
F0D15B	LSB-BKE1: Switching output A2.1 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:16		E	1
F0D25B	LSB-BKE1: Switching output A2.2 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:5		E	1
F0D35B	LSB-BKE1: Switching output A2.3 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:1		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F0D45B	LSB-BKE1: Switching output A2.4 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:4		E	1
F0D55B	LSB-BKE1: Switching output A2.5 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:7		E	1
F0D65B	LSB-BKE1: Switching output A2.6 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:10		E	1
F0D75B	LSB-BKE1: Switching output A2.7 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X3:13		E	1
F0D85B	LSB-BKE1: Switching output A2.8 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:14		E	1
F0D95B	LSB-BKE1: Switching output A2.9 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:11		E	1
F0DA5B	LSB-BKE1: Switching output A2.10 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:17		E	1
F0DB5B	LSB-BKE1: Switching output A2.11 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:13		E	1
F0DC5B	LSB-BKE1: Switching output A2.12 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:1		E	1
F0DD5B	LSB-BKE1: Switching output A2.13 open, insufficient load, short circuit,overload or excess temp. Error display per blinking LED, entry in error stack, set error status bit in EW5 Check outlet supply, user, change module if nec.	A371.X4:4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F0E05B	LSB-BKE1: Switching output A2.15 open, insufficient load, short circuit, overload or excess temp. Entry in error stack, set error status bit EW5 Check outlet supply, user, change module if nec.	A371.X1:3		E	1
F0F0A0	LSB-BKE1: Control Funktion blocked: button actuation without release Entry in error stack Carry out the manual buttons release	A371		B	1
F0F0A1	LSB-BKE1: Control Funktion locked: sequence of key actuation not observed Entry in error stack Carry out the manual buttons release	A371		B	1
F0F0A2	LSB-BKE1: Control Funktion blocked: button actuation impermissible Entry in error stack Press only one function key	A371		B	1
F0F108	LSB-BKE1: System error OS-CPU EEPROM erroneous Blinker code on internal LED, entry in error stack, no reaction Replace module	A371		E	1
F0F120	LSB-BKE1: System error OS-CPU task-watchdog expired Blinker code on internal LED, entry in error stack, no reaction Replace module	A371		E	2
F0F1C0	LSB-BKE1: System error OS-CPU Hardware / Software erroneous Blinker code on internal LED, entry in error stack, no reaction Replace module	A371		E	2
F0FC5A	LSB-BKE1: Control data transfer LSB Parameter block has erroneous test sum Entry in error stack Replace module	A371		E	1
F0FC5B	LSB-BKE1: Control data transfer LSB Short circuit on 2nd LSB-Transistor Entry in error stack Replace module	A371		E	1
F10050	LSB-BTB1: LSBA Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10051	LSB-BTB1: LSBA Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F10053	LSB-BTB1: LSBA Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F10054	LSB-BTB1: LSBA Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10064	LSB-BTB1: LSBA Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F10065	LSB-BTB1: LSBA Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F10066	LSB-BTB1: LSBA Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F10067	LSB-BTB1: LSBA Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F10068	LSB-BTB1: LSBA Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F10069	LSB-BTB1: LSBA Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1006A	LSB-BTB1: LSBA Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1006B	LSB-BTB1: LSBA Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1006C	LSB-BTB1: LSBA Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F10150	LSB-BTB1: LSBA Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F10151	LSB-BTB1: LSBA Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F10153	LSB-BTB1: LSBA Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F10154	LSB-BTB1: LSBA Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10164	LSB-BTB1: LSBA Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F10165	LSB-BTB1: LSBA Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F10166	LSB-BTB1: LSBA Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F10167	LSB-BTB1: LSBA Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10168	LSB-BTB1: LSBA Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F10169	LSB-BTB1: LSBA Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1016A	LSB-BTB1: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1016B	LSB-BTB1: LSBA Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1016C	LSB-BTB1: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F10250	LSB-BTB1: LSBA Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F10251	LSB-BTB1: LSBA Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F10253	LSB-BTB1: LSBA Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F10254	LSB-BTB1: LSBA Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10264	LSB-BTB1: LSBA Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10265	LSB-BTB1: LSBA Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F10266	LSB-BTB1: LSBA Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F10267	LSB-BTB1: LSBA Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F10268	LSB-BTB1: LSBA Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F10269	LSB-BTB1: LSBA Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1026A	LSB-BTB1: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1026B	LSB-BTB1: LSBA Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1026C	LSB-BTB1: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F10350	LSB-BTB1: LSBA Participant Adr. 3 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F10351	LSB-BTB1: LSBA Participant Adr. 3 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10353	LSB-BTB1: LSBA Participant Adr. 3 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F10354	LSB-BTB1: LSBA Participant Adr. 3 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10364	LSB-BTB1: LSBA Participant Adr. 3 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F10365	LSB-BTB1: LSBA Participant Adr. 3 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F10366	LSB-BTB1: LSBA Participant Adr. 3 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F10367	LSB-BTB1: LSBA Participant Adr. 3 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F10368	LSB-BTB1: LSBA Participant Adr. 3 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F10369	LSB-BTB1: LSBA Participant Adr. 3 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1036A	LSB-BTB1: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1036B	LSB-BTB1: LSBA Participant Adr. 3 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1036C	LSB-BTB1: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F10750	LSB-BTB1: LSBA Participant Adr. 7 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F10751	LSB-BTB1: LSBA Participant Adr. 7 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F10753	LSB-BTB1: LSBA Participant Adr. 7 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F10754	LSB-BTB1: LSBA Participant Adr. 7 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10764	LSB-BTB1: LSBA Participant Adr. 7 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F10765	LSB-BTB1: LSBA Participant Adr. 7 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F10766	LSB-BTB1: LSBA Participant Adr. 7 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F10767	LSB-BTB1: LSBA Participant Adr. 7 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F10768	LSB-BTB1: LSBA Participant Adr. 7 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10769	LSB-BTB1: LSBA Participant Adr. 7 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1076A	LSB-BTB1: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1076B	LSB-BTB1: LSBA Participant Adr. 7 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1076C	LSB-BTB1: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F10850	LSB-BTB1: LSBA Participant Adr. 8 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F10851	LSB-BTB1: LSBA Participant Adr. 8 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F10853	LSB-BTB1: LSBA Participant Adr. 8 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F10854	LSB-BTB1: LSBA Participant Adr. 8 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10864	LSB-BTB1: LSBA Participant Adr. 8 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F10865	LSB-BTB1: LSBA Participant Adr. 8 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10866	LSB-BTB1: LSBA Participant Adr. 8 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F10867	LSB-BTB1: LSBA Participant Adr. 8 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F10868	LSB-BTB1: LSBA Participant Adr. 8 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F10869	LSB-BTB1: LSBA Participant Adr. 8 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1086A	LSB-BTB1: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1086B	LSB-BTB1: LSBA Participant Adr. 8 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1086C	LSB-BTB1: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F10950	LSB-BTB1: LSBA Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F10951	LSB-BTB1: LSBA Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F10953	LSB-BTB1: LSBA Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10954	LSB-BTB1: LSBA Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10964	LSB-BTB1: LSBA Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F10965	LSB-BTB1: LSBA Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F10966	LSB-BTB1: LSBA Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F10967	LSB-BTB1: LSBA Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F10968	LSB-BTB1: LSBA Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F10969	LSB-BTB1: LSBA Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1096A	LSB-BTB1: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1096B	LSB-BTB1: LSBA Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1096C	LSB-BTB1: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10B50	LSB-BTB1: LSBA Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F10B51	LSB-BTB1: LSBA Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F10B53	LSB-BTB1: LSBA Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F10B54	LSB-BTB1: LSBA Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10B64	LSB-BTB1: LSBA Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F10B65	LSB-BTB1: LSBA Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F10B66	LSB-BTB1: LSBA Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F10B67	LSB-BTB1: LSBA Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F10B68	LSB-BTB1: LSBA Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F10B69	LSB-BTB1: LSBA Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10B6A	LSB-BTB1: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F10B6B	LSB-BTB1: LSBA Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F10B6C	LSB-BTB1: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F10F50	LSB-BTB1: LSBA Participant Adr. 15 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F10F51	LSB-BTB1: LSBA Participant Adr. 15 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F10F53	LSB-BTB1: LSBA Participant Adr. 15 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F10F54	LSB-BTB1: LSBA Participant Adr. 15 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F10F64	LSB-BTB1: LSBA Participant Adr. 15 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F10F65	LSB-BTB1: LSBA Participant Adr. 15 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F10F66	LSB-BTB1: LSBA Participant Adr. 15 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F10F67	LSB-BTB1: LSBA Participant Adr. 15 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F10F68	LSB-BTB1: LSBA Participant Adr. 15 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F10F69	LSB-BTB1: LSBA Participant Adr. 15 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F10F6A	LSB-BTB1: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F10F6B	LSB-BTB1: LSBA Participant Adr. 15 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F10F6C	LSB-BTB1: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F11350	LSB-BTB1: LSBA Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F11351	LSB-BTB1: LSBA Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F11353	LSB-BTB1: LSBA Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F11354	LSB-BTB1: LSBA Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F11364	LSB-BTB1: LSBA Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F11365	LSB-BTB1: LSBA Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F11366	LSB-BTB1: LSBA Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F11367	LSB-BTB1: LSBA Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F11368	LSB-BTB1: LSBA Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F11369	LSB-BTB1: LSBA Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1136A	LSB-BTB1: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1136B	LSB-BTB1: LSBA Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1136C	LSB-BTB1: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F11450	LSB-BTB1: LSBA Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F11451	LSB-BTB1: LSBA Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F11453	LSB-BTB1: LSBA Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F11454	LSB-BTB1: LSBA Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F11464	LSB-BTB1: LSBA Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F11465	LSB-BTB1: LSBA Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F11466	LSB-BTB1: LSBA Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F11467	LSB-BTB1: LSBA Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F11468	LSB-BTB1: LSBA Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F11469	LSB-BTB1: LSBA Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1146A	LSB-BTB1: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1146B	LSB-BTB1: LSBA Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1146C	LSB-BTB1: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F11750	LSB-BTB1: LSBA Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F11751	LSB-BTB1: LSBA Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F11753	LSB-BTB1: LSBA Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F11754	LSB-BTB1: LSBA Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F11764	LSB-BTB1: LSBA Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F11765	LSB-BTB1: LSBA Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F11766	LSB-BTB1: LSBA Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F11767	LSB-BTB1: LSBA Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F11768	LSB-BTB1: LSBA Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F11769	LSB-BTB1: LSBA Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1176A	LSB-BTB1: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1176B	LSB-BTB1: LSBA Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1176C	LSB-BTB1: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F11850	LSB-BTB1: LSBA Participant Adr. 24 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F11851	LSB-BTB1: LSBA Participant Adr. 24 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F11853	LSB-BTB1: LSBA Participant Adr. 24 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F11854	LSB-BTB1: LSBA Participant Adr. 24 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F11864	LSB-BTB1: LSBA Participant Adr. 24 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F11865	LSB-BTB1: LSBA Participant Adr. 24 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F11866	LSB-BTB1: LSBA Participant Adr. 24 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F11867	LSB-BTB1: LSBA Participant Adr. 24 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F11868	LSB-BTB1: LSBA Participant Adr. 24 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F11869	LSB-BTB1: LSBA Participant Adr. 24 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1186A	LSB-BTB1: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1186B	LSB-BTB1: LSBA Participant Adr. 24 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F1186C	LSB-BTB1: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F11950	LSB-BTB1: LSBA Participant Adr. 25 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F11951	LSB-BTB1: LSBA Participant Adr. 25 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F11953	LSB-BTB1: LSBA Participant Adr. 25 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F11954	LSB-BTB1: LSBA Participant Adr. 25 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F11964	LSB-BTB1: LSBA Participant Adr. 25 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F11965	LSB-BTB1: LSBA Participant Adr. 25 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F11966	LSB-BTB1: LSBA Participant Adr. 25 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F11967	LSB-BTB1: LSBA Participant Adr. 25 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F11968	LSB-BTB1: LSBA Participant Adr. 25 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F11969	LSB-BTB1: LSBA Participant Adr. 25 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F1196A	LSB-BTB1: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F1196B	LSB-BTB1: LSBA Participant Adr. 25 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1196C	LSB-BTB1: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F11A50	LSB-BTB1: LSBA Participant Adr. 26 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F11A51	LSB-BTB1: LSBA Participant Adr. 26 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F11A53	LSB-BTB1: LSBA Participant Adr. 26 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F11A54	LSB-BTB1: LSBA Participant Adr. 26 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F11A64	LSB-BTB1: LSBA Participant Adr. 26 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F11A65	LSB-BTB1: LSBA Participant Adr. 26 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2
F11A66	LSB-BTB1: LSBA Participant Adr. 26 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F11A67	LSB-BTB1: LSBA Participant Adr. 26 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F11A68	LSB-BTB1: LSBA Participant Adr. 26 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F11A69	LSB-BTB1: LSBA Participant Adr. 26 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F11A6A	LSB-BTB1: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F11A6B	LSB-BTB1: LSBA Participant Adr. 26 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F11A6C	LSB-BTB1: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F11C50	LSB-BTB1: LSBA Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:12		E	2
F11C51	LSB-BTB1: LSBA Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:12		E	2
F11C53	LSB-BTB1: LSBA Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:12		E	1
F11C54	LSB-BTB1: LSBA Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:12		E	2
F11C64	LSB-BTB1: LSBA Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:12		E	1
F11C65	LSB-BTB1: LSBA Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F11C66	LSB-BTB1: LSBA Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:12		E	2
F11C67	LSB-BTB1: LSBA Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:12		E	1
F11C68	LSB-BTB1: LSBA Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:12		E	1
F11C69	LSB-BTB1: LSBA Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:12		E	1
F11C6A	LSB-BTB1: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:12		E	2
F11C6B	LSB-BTB1: LSBA Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:12		E	2
F11C6C	LSB-BTB1: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:12		E	2
F12052	LSB-BTB1: Control data transfer LSBA has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A31.X4:12		E	0
F12055	LSB-BTB1: Control data transfer LSBA Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A31.X4:12		E	2
F12056	LSB-BTB1: Control data transfer LSBA Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A31.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F12057	LSB-BTB1: Control data transfer LSBA has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A31.X4:12		E	1
F12058	LSB-BTB1: Control data transfer LSBA recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A31.X4:12		E	0
F12059	LSB-BTB1: Control data transfer LSBA recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A31.X4:12		E	0
F1205B	LSB-BTB1: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A31.X4:12		E	2
F12060	LSB-BTB1: Control data transfer LSBA driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A31.X4:12		E	2
F12061	LSB-BTB1: Control data transfer LSBA driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A31.X4:12		E	2
F12062	LSB-BTB1: Control data transfer LSBA Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A31.X4:12		E	2
F13050	LSB-BTB1: LSBB Participant Adr. 0 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F13051	LSB-BTB1: LSBB Participant Adr. 0 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F13053	LSB-BTB1: LSBB Participant Adr. 0 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F13054	LSB-BTB1: LSBB Participant Adr. 0 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F13064	LSB-BTB1: LSBB Participant Adr. 0 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F13065	LSB-BTB1: LSBB Participant Adr. 0 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F13066	LSB-BTB1: LSBB Participant Adr. 0 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F13067	LSB-BTB1: LSBB Participant Adr. 0 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F13068	LSB-BTB1: LSBB Participant Adr. 0 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F13069	LSB-BTB1: LSBB Participant Adr. 0 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F1306A	LSB-BTB1: LSBB Participant Adr. 0 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1306B	LSB-BTB1: LSBB Participant Adr. 0 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F1306C	LSB-BTB1: LSBB Participant Adr. 0 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F13150	LSB-BTB1: LSBB Participant Adr. 1 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F13151	LSB-BTB1: LSBB Participant Adr. 1 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F13153	LSB-BTB1: LSBB Participant Adr. 1 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F13154	LSB-BTB1: LSBB Participant Adr. 1 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F13164	LSB-BTB1: LSBB Participant Adr. 1 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F13165	LSB-BTB1: LSBB Participant Adr. 1 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F13166	LSB-BTB1: LSBB Participant Adr. 1 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F13167	LSB-BTB1: LSBB Participant Adr. 1 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F13168	LSB-BTB1: LSBB Participant Adr. 1 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F13169	LSB-BTB1: LSBB Participant Adr. 1 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1316A	LSB-BTB1: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1316B	LSB-BTB1: LSBB Participant Adr. 1 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F1316C	LSB-BTB1: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F13250	LSB-BTB1: LSBB Participant Adr. 2 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F13251	LSB-BTB1: LSBB Participant Adr. 2 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F13253	LSB-BTB1: LSBB Participant Adr. 2 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F13254	LSB-BTB1: LSBB Participant Adr. 2 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F13264	LSB-BTB1: LSBB Participant Adr. 2 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F13265	LSB-BTB1: LSBB Participant Adr. 2 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F13266	LSB-BTB1: LSBB Participant Adr. 2 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F13267	LSB-BTB1: LSBB Participant Adr. 2 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F13268	LSB-BTB1: LSBB Participant Adr. 2 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F13269	LSB-BTB1: LSBB Participant Adr. 2 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F1326A	LSB-BTB1: LSBB Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1326B	LSB-BTB1: LSBB Participant Adr. 2 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F1326C	LSB-BTB1: LSBB Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F13950	LSB-BTB1: LSBB Participant Adr. 9 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F13951	LSB-BTB1: LSBB Participant Adr. 9 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F13953	LSB-BTB1: LSBB Participant Adr. 9 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F13954	LSB-BTB1: LSBB Participant Adr. 9 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F13964	LSB-BTB1: LSBB Participant Adr. 9 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F13965	LSB-BTB1: LSBB Participant Adr. 9 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F13966	LSB-BTB1: LSBB Participant Adr. 9 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F13967	LSB-BTB1: LSBB Participant Adr. 9 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F13968	LSB-BTB1: LSBB Participant Adr. 9 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F13969	LSB-BTB1: LSBB Participant Adr. 9 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F1396A	LSB-BTB1: LSBB Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1396B	LSB-BTB1: LSBB Participant Adr. 9 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F1396C	LSB-BTB1: LSBB Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F13A50	LSB-BTB1: LSBB Participant Adr. 10 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F13A51	LSB-BTB1: LSBB Participant Adr. 10 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F13A53	LSB-BTB1: LSBB Participant Adr. 10 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F13A54	LSB-BTB1: LSBB Participant Adr. 10 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F13A64	LSB-BTB1: LSBB Participant Adr. 10 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F13A65	LSB-BTB1: LSBB Participant Adr. 10 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F13A66	LSB-BTB1: LSBB Participant Adr. 10 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F13A67	LSB-BTB1: LSBB Participant Adr. 10 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F13A68	LSB-BTB1: LSBB Participant Adr. 10 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F13A69	LSB-BTB1: LSBB Participant Adr. 10 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F13A6A	LSB-BTB1: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F13A6B	LSB-BTB1: LSBB Participant Adr. 10 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F13A6C	LSB-BTB1: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F13B50	LSB-BTB1: LSBB Participant Adr. 11 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F13B51	LSB-BTB1: LSBB Participant Adr. 11 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F13B53	LSB-BTB1: LSBB Participant Adr. 11 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F13B54	LSB-BTB1: LSBB Participant Adr. 11 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F13B64	LSB-BTB1: LSBB Participant Adr. 11 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F13B65	LSB-BTB1: LSBB Participant Adr. 11 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F13B66	LSB-BTB1: LSBB Participant Adr. 11 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F13B67	LSB-BTB1: LSBB Participant Adr. 11 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F13B68	LSB-BTB1: LSBB Participant Adr. 11 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F13B69	LSB-BTB1: LSBB Participant Adr. 11 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F13B6A	LSB-BTB1: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F13B6B	LSB-BTB1: LSBB Participant Adr. 11 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F13B6C	LSB-BTB1: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F13C50	LSB-BTB1: LSBB Participant Adr. 12 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F13C51	LSB-BTB1: LSBB Participant Adr. 12 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F13C53	LSB-BTB1: LSBB Participant Adr. 12 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F13C54	LSB-BTB1: LSBB Participant Adr. 12 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F13C64	LSB-BTB1: LSBB Participant Adr. 12 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F13C65	LSB-BTB1: LSBB Participant Adr. 12 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F13C66	LSB-BTB1: LSBB Participant Adr. 12 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F13C67	LSB-BTB1: LSBB Participant Adr. 12 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F13C68	LSB-BTB1: LSBB Participant Adr. 12 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F13C69	LSB-BTB1: LSBB Participant Adr. 12 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F13C6A	LSB-BTB1: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F13C6B	LSB-BTB1: LSBB Participant Adr. 12 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F13C6C	LSB-BTB1: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F14150	LSB-BTB1: LSBB Participant Adr. 17 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F14151	LSB-BTB1: LSBB Participant Adr. 17 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14153	LSB-BTB1: LSBB Participant Adr. 17 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F14154	LSB-BTB1: LSBB Participant Adr. 17 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F14164	LSB-BTB1: LSBB Participant Adr. 17 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14165	LSB-BTB1: LSBB Participant Adr. 17 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F14166	LSB-BTB1: LSBB Participant Adr. 17 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F14167	LSB-BTB1: LSBB Participant Adr. 17 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F14168	LSB-BTB1: LSBB Participant Adr. 17 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F14169	LSB-BTB1: LSBB Participant Adr. 17 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F1416A	LSB-BTB1: LSBB Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1416B	LSB-BTB1: LSBB Participant Adr. 17 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1416C	LSB-BTB1: LSBB Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F14250	LSB-BTB1: LSBB Participant Adr. 18 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F14251	LSB-BTB1: LSBB Participant Adr. 18 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F14253	LSB-BTB1: LSBB Participant Adr. 18 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F14254	LSB-BTB1: LSBB Participant Adr. 18 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F14264	LSB-BTB1: LSBB Participant Adr. 18 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14265	LSB-BTB1: LSBB Participant Adr. 18 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F14266	LSB-BTB1: LSBB Participant Adr. 18 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F14267	LSB-BTB1: LSBB Participant Adr. 18 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F14268	LSB-BTB1: LSBB Participant Adr. 18 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14269	LSB-BTB1: LSBB Participant Adr. 18 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F1426A	LSB-BTB1: LSBB Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1426B	LSB-BTB1: LSBB Participant Adr. 18 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F1426C	LSB-BTB1: LSBB Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F14350	LSB-BTB1: LSBB Participant Adr. 19 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F14351	LSB-BTB1: LSBB Participant Adr. 19 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F14353	LSB-BTB1: LSBB Participant Adr. 19 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F14354	LSB-BTB1: LSBB Participant Adr. 19 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F14364	LSB-BTB1: LSBB Participant Adr. 19 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14365	LSB-BTB1: LSBB Participant Adr. 19 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14366	LSB-BTB1: LSBB Participant Adr. 19 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F14367	LSB-BTB1: LSBB Participant Adr. 19 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F14368	LSB-BTB1: LSBB Participant Adr. 19 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F14369	LSB-BTB1: LSBB Participant Adr. 19 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F1436A	LSB-BTB1: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1436B	LSB-BTB1: LSBB Participant Adr. 19 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F1436C	LSB-BTB1: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F14450	LSB-BTB1: LSBB Participant Adr. 20 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F14451	LSB-BTB1: LSBB Participant Adr. 20 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F14453	LSB-BTB1: LSBB Participant Adr. 20 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14454	LSB-BTB1: LSBB Participant Adr. 20 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F14464	LSB-BTB1: LSBB Participant Adr. 20 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14465	LSB-BTB1: LSBB Participant Adr. 20 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F14466	LSB-BTB1: LSBB Participant Adr. 20 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F14467	LSB-BTB1: LSBB Participant Adr. 20 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F14468	LSB-BTB1: LSBB Participant Adr. 20 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F14469	LSB-BTB1: LSBB Participant Adr. 20 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F1446A	LSB-BTB1: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1446B	LSB-BTB1: LSBB Participant Adr. 20 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F1446C	LSB-BTB1: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14750	LSB-BTB1: LSBB Participant Adr. 23 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F14751	LSB-BTB1: LSBB Participant Adr. 23 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F14753	LSB-BTB1: LSBB Participant Adr. 23 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F14754	LSB-BTB1: LSBB Participant Adr. 23 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F14764	LSB-BTB1: LSBB Participant Adr. 23 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14765	LSB-BTB1: LSBB Participant Adr. 23 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F14766	LSB-BTB1: LSBB Participant Adr. 23 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F14767	LSB-BTB1: LSBB Participant Adr. 23 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F14768	LSB-BTB1: LSBB Participant Adr. 23 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F14769	LSB-BTB1: LSBB Participant Adr. 23 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1476A	LSB-BTB1: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F1476B	LSB-BTB1: LSBB Participant Adr. 23 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F1476C	LSB-BTB1: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F14B50	LSB-BTB1: LSBB Participant Adr. 27 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F14B51	LSB-BTB1: LSBB Participant Adr. 27 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F14B53	LSB-BTB1: LSBB Participant Adr. 27 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F14B54	LSB-BTB1: LSBB Participant Adr. 27 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F14B64	LSB-BTB1: LSBB Participant Adr. 27 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14B65	LSB-BTB1: LSBB Participant Adr. 27 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F14B66	LSB-BTB1: LSBB Participant Adr. 27 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14B67	LSB-BTB1: LSBB Participant Adr. 27 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F14B68	LSB-BTB1: LSBB Participant Adr. 27 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F14B69	LSB-BTB1: LSBB Participant Adr. 27 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F14B6A	LSB-BTB1: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F14B6B	LSB-BTB1: LSBB Participant Adr. 27 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F14B6C	LSB-BTB1: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F14C50	LSB-BTB1: LSBB Participant Adr. 28 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F14C51	LSB-BTB1: LSBB Participant Adr. 28 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F14C53	LSB-BTB1: LSBB Participant Adr. 28 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F14C54	LSB-BTB1: LSBB Participant Adr. 28 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14C64	LSB-BTB1: LSBB Participant Adr. 28 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14C65	LSB-BTB1: LSBB Participant Adr. 28 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F14C66	LSB-BTB1: LSBB Participant Adr. 28 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F14C67	LSB-BTB1: LSBB Participant Adr. 28 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F14C68	LSB-BTB1: LSBB Participant Adr. 28 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F14C69	LSB-BTB1: LSBB Participant Adr. 28 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F14C6A	LSB-BTB1: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F14C6B	LSB-BTB1: LSBB Participant Adr. 28 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F14C6C	LSB-BTB1: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F14D50	LSB-BTB1: LSBB Participant Adr. 29 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14D51	LSB-BTB1: LSBB Participant Adr. 29 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F14D53	LSB-BTB1: LSBB Participant Adr. 29 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F14D54	LSB-BTB1: LSBB Participant Adr. 29 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F14D64	LSB-BTB1: LSBB Participant Adr. 29 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14D65	LSB-BTB1: LSBB Participant Adr. 29 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F14D66	LSB-BTB1: LSBB Participant Adr. 29 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F14D67	LSB-BTB1: LSBB Participant Adr. 29 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1
F14D68	LSB-BTB1: LSBB Participant Adr. 29 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F14D69	LSB-BTB1: LSBB Participant Adr. 29 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F14D6A	LSB-BTB1: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14D6B	LSB-BTB1: LSBB Participant Adr. 29 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F14D6C	LSB-BTB1: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F14E50	LSB-BTB1: LSBB Participant Adr. 30 reports an incorrect sensor type Entry in error stack, otherwise no reaction. The answer is interpreted acc. to nominal type recognition check address assignment over test system (LSB-screen), install correct sensor	A31.X4:9		E	2
F14E51	LSB-BTB1: LSBB Participant Adr. 30 was not configured for the block transfer Entry in error stack, otherwise no reaction. No block transfer is made configuration problem, load new Software	A31.X4:9		E	2
F14E53	LSB-BTB1: LSBB Participant Adr. 30 no longer reports or withdrawn during running period Entry in error stack, participant is deactivated. Data buffers for application are set to 0 check connection, if connection OK then replace sensor	A31.X4:9		E	1
F14E54	LSB-BTB1: LSBB Participant Adr. 30 Features other settings (parameters) as pre-entered set values entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config check parameter set/real value through test system (LSB-screen), set sensor to default value	A31.X4:9		E	2
F14E64	LSB-BTB1: LSBB Participant Adr. 30 reports tolerable error in self-test Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction check sensor, clean if necessary, with repeated occurrence replace sensor	A31.X4:9		E	1
F14E65	LSB-BTB1: LSBB Participant Adr. 30 reports intolerable error in self-test Entry in error stack otherwise no reaction. Error free operation is no longer ensured replace sensor immediately	A31.X4:9		E	2
F14E66	LSB-BTB1: LSBB Participant Adr. 30 with software version, that is no longer compatible Entry in error stack otherwise no reaction. It is tried, if possible, to work with the sensor replace sensor through new part	A31.X4:9		E	2
F14E67	LSB-BTB1: LSBB Participant Adr. 30 supports no download function Entry in error stack, otherwise no reaction. No download is made Carry out no Download	A31.X4:9		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F14E68	LSB-BTB1: LSBB Participant Adr. 30 may not be installed in this operating condition Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remove participant from Bus	A31.X4:9		E	1
F14E69	LSB-BTB1: LSBB Participant Adr. 30 two participants are active on this address Entry in error stack otherwise no reaction. Error free operation is no longer ensured Remedy address conflict by removing one participant. Assign correct addresses via test system	A31.X4:9		E	1
F14E6A	LSB-BTB1: LSBB Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A31.X4:9		E	2
F14E6B	LSB-BTB1: LSBB Participant Adr. 30 May not be configured on this bus for strobe mode entry in error memory, or no reaction, the sensor data could be incorrect, due to incorrect sensor config Check config. sensor parameterization. Sensor and bus must be configured for strobe mode	A31.X4:9		E	2
F14E6C	LSB-BTB1: LSBB Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A31.X4:9		E	2
F15052	LSB-BTB1: Control data transfer LSBB has recognised Bus collisions, communication interrupted entry in error memory, driver draws itself back from bus, possible release of reset and re-booting of network with temporary malfunctions error will be eliminated from system itself, otherwise check address assignment of sensor	A31.X4:9		E	0
F15055	LSB-BTB1: Control data transfer LSBB Bus connection faulty/defect, short circuit to supply voltage Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A31.X4:9		E	2
F15056	LSB-BTB1: Control data transfer LSBB Bus connection faulty/defect, no supply/short circuit to earth Entry in error stack, driver tries to restart the bus. As soon as error is remedied, bus will start check bus line, sensor (withdraw) and bus circuit board for shorts, check bus fuse on bus circuit board	A31.X4:9		E	2
F15057	LSB-BTB1: Control data transfer LSBB has recognised network re-set (data transfer starts again) Entry in error stack, driver restarts and carried out new initialization of network Check bus line, pull successive sensors from bus until source of problem is found. Replace defective part	A31.X4:9		E	1
F15058	LSB-BTB1: Control data transfer LSBB recognised participant with incorrect baud rate in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by system. Check address assignment of sensors	A31.X4:9		E	0

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F15059	LSB-BTB1: Control data transfer LSBB recognised communication breakdown in bus Entry in error stack, driver restarts and carried out new initialization of network Will be remedied by driver when restarting the network	A31.X4:9		E	0
F1505B	LSB-BTB1: Control data transfer LSBB Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A31.X4:9		E	2
F15060	LSB-BTB1: Control data transfer LSBB driver error: no order to carry out entry in error memory, driver runs on normally and waits for bus connection of participant period problems, error will be fixed by system. If incorrectly configured, new software required	A31.X4:9		E	2
F15061	LSB-BTB1: Control data transfer LSBB driver error: undefined message appears Entry in error stack, driver restarts and carried out new initialization of network For period problems, error will be fixed by system otherwise new software required to fix error	A31.X4:9		E	2
F15062	LSB-BTB1: Control data transfer LSBB Driver error: Initialization error Entry in error stack, driver restarts and carried out new initialization of network New Software necessary to remedy error	A31.X4:9		E	2
F15D51	LSB-BTB1: control auxiliary equipment Button Ladder UP after Start/op. error actuated or stuck Movement is not actuated check wiring	A31		E	
F15D52	LSB-BTB1: control auxiliary equipment Button Ladder DOWN after Start/op. error actuated or stuck Movement is not actuated check wiring	A31		E	
F15D53	LSB-BTB1: control auxiliary equipment Forced zero position double control of latter (button and BTT) Movement is not actuated Actuate only from one op. location	A31		E	
F15E18	LSB-BTB1: crane control Signals ignition switch implausible	A31		E	1
F15F50	LSB-BTB1: Control Radio remote control Terminal Expansion reports System error Reset, check / replace hardware LSB-BTT-E	A31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F15F51	LSB-BTB1: Control Radio remote control Terminal Expansion reports error an master switch 1 Reset, check / replace hardware LSB-BTT-E	A31		E	1
F15F52	LSB-BTB1: Control Radio remote control Terminal Expansion reports error an master switch 2 Reset, check / replace hardware LSB-BTT-E	A31		E	1
F15F53	LSB-BTB1: Control Radio remote control Signale von master switch 1 not plausible Check / replace hardware LSB-BTT-E	A31		E	1
F15F54	LSB-BTB1: Control Radio remote control Signale von master switch 2 not plausible Check / replace hardware LSB-BTT-E	A31		E	1
F15F55	LSB-BTB1: Control Radio remote control Radio data transfer BTT-E faulty/erroneous (MS1+2, Channel 0) No radio control Data transfer to BTT-E erroneous or interrupted	A31		E	1
F15F56	LSB-BTB1: Control Radio remote control Radio data transfer BTT-E faulty/erroneous (MS1+2, Channel 1) No radio control Data transfer to BTT-E erroneous or interrupted	A31		E	1
F15FFD	LSB-BTB1: Control Radio remote control Crane control reports error, request on crane monitor in crane cab No radio control Call up errors on crane monitor in crane cab	A31		E	1
F16000	LSB-BTB1: Control Radio remote control Locked, Operating mode superstr. not recognized No menu change over possible on BTT Turn ignition on in Superstructure	A31		B	
F16001	LSB-BTB1: Control Radio remote control Locked, no release from Crane control Channel 1 No radio mode crane control Check control units and LSB-connections	A31		B	
F16002	LSB-BTB1: Control Radio remote control Locked, no release from Crane control Channel 2 No radio mode crane control Check control units and LSB-connections	A31		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F16003	LSB-BTB1: Control Radio remote control Locked, too many buttons on terminal actuated All buttons are zeroed out, all movements stop	A31		B	
F16004	LSB-BTB1: Control Radio remote control blocked, master switch 1 deflected after menu change or error All buttons are zeroed out, all movements stop	A31		B	
F16005	LSB-BTB1: Control Radio remote control blocked, master switch 2 deflected after menu change or error All buttons are zeroed out, all movements stop	A31		B	
F16006	LSB-BTB1: Control Radio remote control Master switch left Y-direction locked No movements possible via radio control Unlock radio master switch via menu	A31		B	
F16007	LSB-BTB1: Control Radio remote control Master switch left X-direction locked No movements possible via radio control Unlock radio master switch via menu	A31		B	
F16008	LSB-BTB1: Control Radio remote control Master switch right Y-direction locked No movements possible via radio control Unlock radio master switch via menu	A31		B	
F16009	LSB-BTB1: Control Radio remote control Master switch right X-direction locked No movements possible via radio control Unlock radio master switch via menu	A31		B	
F16010	LSB-BTB1: Control Radio remote control No release of crane control for hook inst. No movements possible via radio control Check releases for functions, error messages, crane control	A31		B	
F16011	LSB-BTB1: Control Radio remote control No release of crane control for assembly function folding jib No movements possible via radio control Check releases for functions, error messages, crane control	A31		B	
F16012	LSB-BTB1: Control Radio remote control No release of crane control for assembly function hose drum No movements possible via radio control Check releases for functions, error messages, crane control	A31		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F16013	LSB-BTB1: Control Radio remote control No release of crane control for assembly function accessories No movements possible via radio control Check releases for functions, error messages, crane control	A31		B	
F16014	LSB-BTB1: Control Radio remote control No release for assembly function, since configuration incorrect	A31		E	1
F160FE	LSB-BTB1: Control Radio remote control Function BTT-E prevented, Option not available No radio control Take BTT from BTT-E	A31		B	
F16110	LSB-BTB1: Operation crane control Blocked, release 2-Hand missing	A31		B	
F16138	LSB-BTB1: Operation crane control No release for ballasting function Movement is not actuated Turn actuation of other aux. users off or remedy system error	A31		B	
F17018	LSB-BTB1: remote control Operating mode not configured all movements are blocked Press OK first on monitor and then on radio remote control	A31		B	
F17E01	LSB-BTB1: Boot up phase crane control / emerg.off Emerg. off active, button actuated or line interruption (E1/E10) Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E02	LSB-BTB1: Boot up phase crane control / emerg.off Emerg. off active, button actuated or line interruption (E1/E10) Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E03	LSB-BTB1: Boot up phase crane control / emerg.off Emerg. off active, motor control unit reports button actuated Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E04	LSB-BTB1: Boot up phase crane control / emerg.off Cross comparison emergency off recognizes error Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F17E05	LSB-BTB1: Boot up phase crane control / emerg.off Cross comparison emergency off recognizes error Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E06	LSB-BTB1: Boot up phase crane control / emerg.off Reports input signals emergency off to Init invalid Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E07	LSB-BTB1: Boot up phase crane control / emerg.off Input E1 Short circuit after VCC Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E08	LSB-BTB1: Boot up phase crane control / emerg.off Input E10 Short circuit after VCC Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E09	LSB-BTB1: Boot up phase crane control / emerg.off Report emerg. off engine control unit invalid Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E0A	LSB-BTB1: Boot up phase crane control / emerg.off Input E9 Short circuit after VCC Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E0B	LSB-BTB1: Boot up phase crane control / emerg.off Input E2 Short circuit after VCC Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E0C	LSB-BTB1: Boot up phase crane control / emerg.off Input E9 open line or Battery master switch off Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E0D	LSB-BTB1: Boot up phase crane control / emerg.off Input E2 open line or Battery master switch off Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E0E	LSB-BTB1: Boot up phase crane control / emerg.off Time exceeded request flank emerg. off from superstructure error report on display Contact Service	A31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F17E0F	LSB-BTB1: Boot up phase crane control / emerg.off Output power supply engine control unit short circuit after VCC Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E10	LSB-BTB1: Boot up phase crane control / emerg.off Output power supply engine control unit short circuit after ground Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17E11	LSB-BTB1: Boot up phase crane control / emerg.off Report cond. Emerg. off bypassed from engine control unit error report on display Contact Service	A31		E	1
F17E12	LSB-BTB1: Boot up phase crane control / emerg.off Emerg. off active, conn. interruption at active radio remote contr. Em. Off reaction is initiated Emerg. off open, reestablish connection	A31		E	1
F17E13	LSB-BTB1: Boot up phase crane control / emerg.off Emerg. off active, conn. interruption at active radio remote contr. Em. Off reaction is initiated Emerg. off open, reestablish connection	A31		E	1
F17E14	LSB-BTB1: Boot up phase crane control / emerg.off Report emerg. off motor control unit reports short circuit after VCC Em. Off reaction is initiated All ignition starter switch off, check em. Off, ignition starter switch on	A31		E	1
F17F36	LSB-BTB1: Signals speed recordation Travel speed Tachograph <> Gear output RPM not plausible Error message, larger of two signals is used as travel speed Check tachograph, Gear output RPM, reports from distributor gear	A31		E	1
F17F3A	LSB-BTB1: Signals speed recordation Tachograph/trip recorder reports Error error report Read error on tachograph, check tacho plate / chip card	A31		E	1
F17F3B	LSB-BTB1: Signals speed recordation Unit speed display/distances initialized	A31		E	1
F180FA	LSB-BTB1: control engine Configuration Engine type missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F180FB	LSB-BTB1: control engine Configuration Exhaust stage missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A31		E	1
F180FC	LSB-BTB1: control engine Configuration Engine type implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A31		E	1
F180FD	LSB-BTB1: control engine Configuration Exhaust stage implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A31		E	1
F18519	LSB-BTB1: control axle suspension/level Signal sensor axle suspension faulty/implausible/incorrect allocation	A31		E	1
F1851B	LSB-BTB1: control axle suspension/level Oil supply axle suspension not added Filling not possible Note other error codes	A31		E	1
F1851C	LSB-BTB1: control axle suspension/level Oil supply axle suspension not turned off Steering is hard to move Note other error codes	A31		E	1
F1851D	LSB-BTB1: control axle suspension/level Ground for valve down is not added Relief not possible Note other error codes	A31		E	1
F1851E	LSB-BTB1: control axle suspension/level Ground for valve down is not turned off No Note other error codes	A31		E	1
F1851F	LSB-BTB1: control axle suspension/level Ground switch valves down or cable to valve down left front defective No Check wiring to relieve valves, if wiring ok, replace LSB-EA1	A31		E	1
F18520	LSB-BTB1: control axle suspension/level Cable to valve down left front defective Relief not possible Check wiring valves	A31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F18521	LSB-BTB1: control axle suspension/level Cable to valve down right front defective Relief not possible Check wiring valves	A31		E	1
F18522	LSB-BTB1: control axle suspension/level Cable to valve down left rear defective Relief not possible Check wiring valves	A31		E	1
F18523	LSB-BTB1: control axle suspension/level Cable to valve down right rear defective Relief not possible Check wiring valves	A31		E	1
F18524	LSB-BTB1: control axle suspension/level Signal sensor axle suspension cylinder front right missing/implausible	A31		E	1
F18525	LSB-BTB1: control axle suspension/level Signal sensor axle suspension cylinder front left missing/implausible	A31		E	1
F18526	LSB-BTB1: control axle suspension/level Signal sensor axle suspension cylinder rear right missing/implausible	A31		E	1
F18527	LSB-BTB1: control axle suspension/level Signal sensor axle suspension cylinder rear left missing/implausible	A31		E	1
F18A1B	LSB-BTB1: Operation crawler Rapid gear crawler is not possible suspended ballast is installed	A31		B	
F18A29	LSB-BTB1: Operation crawler Fast speed of crawler not possible - LMB utilisation > 80 percent	A31		B	
F19900	LSB-BTB1: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A31		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F19901	LSB-BTB1: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A31		E	2
F19902	LSB-BTB1: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A31		E	1
F19904	LSB-BTB1: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A31		E	1
F19905	LSB-BTB1: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A31		E	1
F19906	LSB-BTB1: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A31		E	2
F19907	LSB-BTB1: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A31		E	1
F19911	LSB-BTB1: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31		E	2
F19E01	LSB-BTB1: operation engine operation of 2-hand-function without activation of 2-hand-key	A31		E	1
F19E55	LSB-BTB1: operation engine STOP, ignition operators cab in upper-carriage operation mode Check ignition starter switch in chassis/superstructure	A31		B	
F19E56	LSB-BTB1: operation engine STOP, ignition operators cab in under-carriage operation mode Check ignition starter switch in chassis/superstructure	A31		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F19E62	LSB-BTB1: operation engine no start, ignition upper/under-carriage switched on Check ignition starter switch in chassis/superstructure	A31		B	
F1A301	LSB-BTB1: operation axle suspension operation of 2-hand-function without activation of 2-hand-key function is not carried out Press 2-Hand key (or deadman)	A31		B	
F1A302	LSB-BTB1: operation axle suspension operation from upper-carriage without operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A31		B	
F1A303	LSB-BTB1: operation axle suspension operation from under-carriage without operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A31		B	
F1A30C	LSB-BTB1: operation axle suspension Simultaneous from different control locations	A31		B	
F1A30F	LSB-BTB1: operation axle suspension Function prevented, deadman not actuated	A31		B	
F1A325	LSB-BTB1: operation axle suspension function with actual travel speed blocked	A31		B	
F1A33F	LSB-BTB1: operation axle suspension Function locked at blocked axle suspension function is not carried out Press 2-Hand key (or deadman)	A31		B	
F1AC01	LSB-BTB1: operation supports operation of 2-hand-function without activation of 2-hand-key function is not carried out Press 2-Hand key (or deadman)	A31		B	
F1AC02	LSB-BTB1: operation supports operation from upper-carriage without operation mode function is not carried out switch over uppercarriage/undercarriage-change-switch to undercarriage operation mode	A31		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1AC0C	LSB-BTB1: operation supports Simultaneous from different control locations	A31		B	
F1AC0F	LSB-BTB1: operation supports Function prevented, deadman not actuated	A31		B	
F1AC25	LSB-BTB1: operation supports function with actual travel speed blocked	A31		B	
F1C02F	LSB-BTB1: Diagnostics syst. band end/adj. program Test program stop because incorrect steering program placed Test program is not started or aborted	A31		B	
F1C03E	LSB-BTB1: Diagnostics syst. band end/adj. program Function locked at blocked axle suspension Test program is not started or aborted	A31		B	
F1C03F	LSB-BTB1: Diagnostics syst. band end/adj. program Test program not executable since brake pedal actuated Test program is not started or aborted	A31		B	
F1C041	LSB-BTB1: Diagnostics syst. band end/adj. program Test program not executable since gear not in N Test program is not started or aborted	A31		B	
F1C043	LSB-BTB1: Diagnostics syst. band end/adj. program Test program not executable at current travel speed Test program is not started or aborted	A31		B	
F1C045	LSB-BTB1: Diagnostics syst. band end/adj. program Test program not executable since motor not on Test program is not started or aborted	A31		B	
F1C04D	LSB-BTB1: Diagnostics syst. band end/adj. program Test program not executable since travel pedal actuated Test program is not started or aborted	A31		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1C073	LSB-BTB1: Diagnostics syst. band end/adj. program Vehicle is not in travel mode Test program is not started or aborted	A31		B	
F1C086	LSB-BTB1: Diagnostics syst. band end/adj. program Test program axle suspension not yet carried out error report Carry out test program until error free end	A31		E	1
F1C0FE	LSB-BTB1: Diagnostics syst. band end/adj. program Program or option not available	A31		B	
F1C218	LSB-BTB1: Hardware excess temperature Entry in error stack Replace LSB-Module	A31		E	2
F1C21B	LSB-BTB1: Hardware digital shut off defective Entry in error stack Report all error parameters to Service	A31		E	2
F1C21F	LSB-BTB1: Hardware After run logic defective Entry in error stack Report all error parameters to Service	A31		E	2
F1C226	LSB-BTB1: Hardware Under temperature Entry in error stack Replace LSB-Module	A31		E	2
F1C261	LSB-BTB1: Hardware measuring system defect Entry in error stack Replace LSB-Module	A31		E	2
F1C504	LSB-BTB1: System voltage Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A31		E	2
F1C505	LSB-BTB1: System voltage Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A31		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1C50F	LSB-BTB1: System voltage Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A31		E	2
F1C604	LSB-BTB1: System voltage CPU/Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A31		E	2
F1C605	LSB-BTB1: System voltage CPU/Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A31		E	2
F1C60F	LSB-BTB1: System voltage CPU/Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A31		E	2
F1C704	LSB-BTB1: Supply voltage 30 (A0-7) / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A31.X1:2/3		E	2
F1C705	LSB-BTB1: Supply voltage 30 (A0-7) / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A31.X1:2/3		E	2
F1C804	LSB-BTB1: Supply voltage 15.1 / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A31.X1:1		E	2
F1C805	LSB-BTB1: Supply voltage 15.1 / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A31.X1:1		E	2
F1C80F	LSB-BTB1: Supply voltage 15.1 / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A31.X1:1		E	2
F1CC04	LSB-BTB1: System voltage Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A31		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1CC05	LSB-BTB1: System voltage Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A31		E	2
F1CC0F	LSB-BTB1: System voltage Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A31		E	2
F1CD04	LSB-BTB1: System voltage CPU/Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A31		E	2
F1CD05	LSB-BTB1: System voltage CPU/Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A31		E	2
F1CD0F	LSB-BTB1: System voltage CPU/Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A31		E	2
F1CE04	LSB-BTB1: Supply voltage 30 (A8-15) / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A31.X2:2/3		E	2
F1CE05	LSB-BTB1: Supply voltage 30 (A8-15) / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A31.X2:2/3		E	2
F1CF04	LSB-BTB1: Supply voltage 15.1 / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A31.X2:1		E	2
F1CF05	LSB-BTB1: Supply voltage 15.1 / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A31.X2:1		E	2
F1CF0F	LSB-BTB1: Supply voltage 15.1 / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A31.X2:1		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1D004	LSB-BTB1: Digital input E0 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:4		E	2
F1D005	LSB-BTB1: Digital input E0 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:4		E	2
F1D104	LSB-BTB1: Digital input E1 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:5		E	2
F1D105	LSB-BTB1: Digital input E1 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:5		E	2
F1D204	LSB-BTB1: Digital input E2 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:6		E	2
F1D205	LSB-BTB1: Digital input E2 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:6		E	2
F1D304	LSB-BTB1: Digital input E3 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:7		E	2
F1D305	LSB-BTB1: Digital input E3 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:7		E	2
F1D804	LSB-BTB1: Digital input E8 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:4		E	2
F1D805	LSB-BTB1: Digital input E8 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1D904	LSB-BTB1: Digital input E9 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:5		E	2
F1D905	LSB-BTB1: Digital input E9 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:5		E	2
F1DA04	LSB-BTB1: Digital input E10 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:6		E	2
F1DA05	LSB-BTB1: Digital input E10 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:6		E	2
F1DB04	LSB-BTB1: Digital input E11 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:7		E	2
F1DB05	LSB-BTB1: Digital input E11 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:7		E	2
F1E012	LSB-BTB1: Switching output A0 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:12		E	2
F1E015	LSB-BTB1: Switching output A0 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:12		E	2
F1E01D	LSB-BTB1: Switching output A0 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X1:12		E	2
F1E054	LSB-BTB1: Switching output A0 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1E072	LSB-BTB1: Switching output A0 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:12		E	2
F1E112	LSB-BTB1: Switching output A1 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:13		E	2
F1E115	LSB-BTB1: Switching output A1 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:13		E	2
F1E11D	LSB-BTB1: Switching output A1 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X1:13		E	2
F1E154	LSB-BTB1: Switching output A1 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:13		E	2
F1E172	LSB-BTB1: Switching output A1 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:13		E	2
F1E212	LSB-BTB1: Switching output A2 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:14		E	2
F1E215	LSB-BTB1: Switching output A2 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:14		E	2
F1E21D	LSB-BTB1: Switching output A2 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X1:14		E	2
F1E254	LSB-BTB1: Switching output A2 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:14		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1E272	LSB-BTB1: Switching output A2 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:14		E	2
F1E312	LSB-BTB1: Switching output A3 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:15		E	2
F1E315	LSB-BTB1: Switching output A3 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:15		E	2
F1E31D	LSB-BTB1: Switching output A3 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X1:15		E	2
F1E354	LSB-BTB1: Switching output A3 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:15		E	2
F1E372	LSB-BTB1: Switching output A3 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:15		E	2
F1E412	LSB-BTB1: Switching output A4 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:16		E	2
F1E415	LSB-BTB1: Switching output A4 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:16		E	2
F1E41D	LSB-BTB1: Switching output A4 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X1:16		E	2
F1E454	LSB-BTB1: Switching output A4 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1E472	LSB-BTB1: Switching output A4 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:16		E	2
F1E512	LSB-BTB1: Switching output A5 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:17		E	2
F1E515	LSB-BTB1: Switching output A5 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:17		E	2
F1E51D	LSB-BTB1: Switching output A5 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X1:17		E	2
F1E554	LSB-BTB1: Switching output A5 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:17		E	2
F1E572	LSB-BTB1: Switching output A5 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:17		E	2
F1E612	LSB-BTB1: Switching output A6 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:18		E	2
F1E615	LSB-BTB1: Switching output A6 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:18		E	2
F1E61D	LSB-BTB1: Switching output A6 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X1:18		E	2
F1E654	LSB-BTB1: Switching output A6 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:18		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1E672	LSB-BTB1: Switching output A6 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:18		E	2
F1E712	LSB-BTB1: Switching output A7 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:19		E	2
F1E715	LSB-BTB1: Switching output A7 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:19		E	2
F1E71D	LSB-BTB1: Switching output A7 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X1:19		E	2
F1E754	LSB-BTB1: Switching output A7 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:19		E	2
F1E772	LSB-BTB1: Switching output A7 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X1:19		E	2
F1E812	LSB-BTB1: Switching output A8 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:12		E	2
F1E815	LSB-BTB1: Switching output A8 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:12		E	2
F1E81D	LSB-BTB1: Switching output A8 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X2:12		E	2
F1E854	LSB-BTB1: Switching output A8 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1E872	LSB-BTB1: Switching output A8 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:12		E	2
F1E912	LSB-BTB1: Switching output A9 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:13		E	2
F1E915	LSB-BTB1: Switching output A9 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:13		E	2
F1E91D	LSB-BTB1: Switching output A9 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X2:13		E	2
F1E954	LSB-BTB1: Switching output A9 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:13		E	2
F1E972	LSB-BTB1: Switching output A9 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:13		E	2
F1EA12	LSB-BTB1: Switching output A10 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:14		E	2
F1EA15	LSB-BTB1: Switching output A10 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:14		E	2
F1EA1D	LSB-BTB1: Switching output A10 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X2:14		E	2
F1EA54	LSB-BTB1: Switching output A10 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:14		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1EA72	LSB-BTB1: Switching output A10 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:14		E	2
F1EB12	LSB-BTB1: Switching output A11 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:15		E	2
F1EB15	LSB-BTB1: Switching output A11 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:15		E	2
F1EB1D	LSB-BTB1: Switching output A11 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X2:15		E	2
F1EB54	LSB-BTB1: Switching output A11 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:15		E	2
F1EB72	LSB-BTB1: Switching output A11 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:15		E	2
F1EC12	LSB-BTB1: Switching output A12 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:16		E	2
F1EC15	LSB-BTB1: Switching output A12 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:16		E	2
F1EC1D	LSB-BTB1: Switching output A12 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X2:16		E	2
F1EC54	LSB-BTB1: Switching output A12 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1EC72	LSB-BTB1: Switching output A12 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:16		E	2
F1ED12	LSB-BTB1: Switching output A13 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:17		E	2
F1ED15	LSB-BTB1: Switching output A13 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:17		E	2
F1ED1D	LSB-BTB1: Switching output A13 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X2:17		E	2
F1ED54	LSB-BTB1: Switching output A13 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:17		E	2
F1ED72	LSB-BTB1: Switching output A13 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:17		E	2
F1EE12	LSB-BTB1: Switching output A14 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:18		E	2
F1EE15	LSB-BTB1: Switching output A14 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:18		E	2
F1EE1D	LSB-BTB1: Switching output A14 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X2:18		E	2
F1EE54	LSB-BTB1: Switching output A14 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:18		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1EE72	LSB-BTB1: Switching output A14 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:18		E	2
F1EF12	LSB-BTB1: Switching output A15 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:19		E	2
F1EF15	LSB-BTB1: Switching output A15 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:19		E	2
F1EF1D	LSB-BTB1: Switching output A15 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A31.X2:19		E	2
F1EF54	LSB-BTB1: Switching output A15 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:19		E	2
F1EF72	LSB-BTB1: Switching output A15 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A31.X2:19		E	2
F1F002	LSB-BTB1: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A31		E	1
F1F013	LSB-BTB1: System error OS-CPU0 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A31		E	1
F1F016	LSB-BTB1: System error OS-CPU0 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A31		E	1
F1F050	LSB-BTB1: System error OS-CPU0 file not available error report Reload application software	A31		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1F068	LSB-BTB1: System error OS-CPU0 impermissible interrupt Entry in error stack Report all error parameters to Service	A31		E	1
F1F070	LSB-BTB1: System error OS-CPU0 various structure versions Entry in error stack Report all error parameters to Service	A31		E	1
F1F073	LSB-BTB1: System error OS-CPU0 interpreter error Entry in error stack At P0=00000013 carry out download	A31		E	1
F1F075	LSB-BTB1: System error OS-CPU0 SPI-error Entry in error stack Report all error parameters to Service	A31		E	1
F1F078	LSB-BTB1: System error OS-CPU0 impermissible parameter Entry in error stack Report all error parameters to Service	A31		E	1
F1F07A	LSB-BTB1: System error OS-CPU0 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A31		E	2
F1F080	LSB-BTB1: System error OS-CPU0 Fatal internal error Entry in error stack Report all error parameters to Service	A31		E	1
F1F082	LSB-BTB1: System error OS-CPU0 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A31		E	1
F1F0AC	LSB-BTB1: System error OS-CPU0 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A31		E	1
F1F0C1	LSB-BTB1: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1F0D2	LSB-BTB1: System error OS-CPU0 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A31		E	2
F1F102	LSB-BTB1: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A31		E	1
F1F113	LSB-BTB1: System error OS-CPU1 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A31		E	1
F1F116	LSB-BTB1: System error OS-CPU1 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A31		E	1
F1F150	LSB-BTB1: System error OS-CPU1 file not available error report Reload application software	A31		E	2
F1F168	LSB-BTB1: System error OS-CPU1 impermissible interrupt Entry in error stack Report all error parameters to Service	A31		E	1
F1F170	LSB-BTB1: System error OS-CPU1 various structure versions Entry in error stack Report all error parameters to Service	A31		E	1
F1F173	LSB-BTB1: System error OS-CPU1 interpreter error Entry in error stack At P0=00000013 carry out download	A31		E	1
F1F175	LSB-BTB1: System error OS-CPU1 SPI-error Entry in error stack Report all error parameters to Service	A31		E	1
F1F178	LSB-BTB1: System error OS-CPU1 impermissible parameter Entry in error stack Report all error parameters to Service	A31		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1F17A	LSB-BTB1: System error OS-CPU1 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A31		E	2
F1F180	LSB-BTB1: System error OS-CPU1 Fatal internal error Entry in error stack Report all error parameters to Service	A31		E	1
F1F182	LSB-BTB1: System error OS-CPU1 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A31		E	1
F1F1AC	LSB-BTB1: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A31		E	1
F1F1C1	LSB-BTB1: System error OS-CPU1 Incorrect or wrong system version for application error report Reload matching system version	A31		E	1
F1F1D2	LSB-BTB1: System error OS-CPU1 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A31		E	2
F1F800	LSB-BTB1: Control data transfer CAN EP0 internal error at Register-check Controller CAN-transfer is not started replace control device	A31.X3:7/8/3/3		E	2
F1F801	LSB-BTB1: Control data transfer CAN EP0 internal error at RAM-check Controller CAN-transfer is not started replace control device	A31.X3:7/8/3/3		E	2
F1F802	LSB-BTB1: Control data transfer CAN EP0 Configuration error Software Error message, CAN report is not configured Check software	A31.X3:7/8/3/3		E	1
F1F804	LSB-BTB1: Control data transfer CAN EP0 Configuration error time synchronization Time synchronization already active or is not configured Check software	A31.X3:7/8/3/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1F805	LSB-BTB1: Control data transfer CAN EP0 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A31.X3:7/8/3/3		E	1
F1F806	LSB-BTB1: Control data transfer CAN EP0 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A31.X3:7/8/3/3		E	2
F1F807	LSB-BTB1: Control data transfer CAN EP0 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A31.X3:7/8/3/3		E	1
F1F811	LSB-BTB1: Control data transfer CAN EP0 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8/3/3		E	2
F1F900	LSB-BTB1: Control data transfer CAN EP1 internal error at Register-check Controller CAN-transfer is not started replace control device	A31.X4:1/2/14/1 3		E	2
F1F901	LSB-BTB1: Control data transfer CAN EP1 internal error at RAM-check Controller CAN-transfer is not started replace control device	A31.X4:1/2/14/1 3		E	2
F1F902	LSB-BTB1: Control data transfer CAN EP1 Configuration error Software Error message, CAN report is not configured Check software	A31.X4:1/2/14/1 3		E	1
F1F904	LSB-BTB1: Control data transfer CAN EP1 Configuration error time synchronization Time synchronization already active or is not configured Check software	A31.X4:1/2/14/1 3		E	1
F1F905	LSB-BTB1: Control data transfer CAN EP1 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A31.X4:1/2/14/1 3		E	1
F1F906	LSB-BTB1: Control data transfer CAN EP1 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A31.X4:1/2/14/1 3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1F907	LSB-BTB1: Control data transfer CAN EP1 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A31.X4:1/2/14/1 3		E	1
F1F911	LSB-BTB1: Control data transfer CAN EP1 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X4:1/2/14/1 3		E	2
F1FA00	LSB-BTB1: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A31.X3:7/8		E	1
F1FA01	LSB-BTB1: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A31.X3:7/8		E	1
F1FA02	LSB-BTB1: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A31.X3:7/8		E	1
F1FA04	LSB-BTB1: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A31.X3:7/8		E	1
F1FA05	LSB-BTB1: Control data transfer CAN-A Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A31.X3:7/8		E	1
F1FA06	LSB-BTB1: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A31.X3:7/8		E	2
F1FA11	LSB-BTB1: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8		E	1
F1FA40	LSB-BTB1: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A31.X3:7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1FA41	LSB-BTB1: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A31.X3:7/8		E	1
F1FA5F	LSB-BTB1: Control data transfer CAN-A Malfunction, all participants missing Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8		E	1
F1FA68	LSB-BTB1: Control data transfer CAN-A Travel recorder / Tachograph erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8		E	1
F1FAA0	LSB-BTB1: Control data transfer CAN-A LSB-EA1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8		E	1
F1FAA1	LSB-BTB1: Control data transfer CAN-A LSB-EA2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8		E	1
F1FAA2	LSB-BTB1: Control data transfer CAN-A LSB-EA3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8		E	1
F1FAA3	LSB-BTB1: Control data transfer CAN-A LSB-EA4 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8		E	1
F1FAAA	LSB-BTB1: Control data transfer CAN-A LSB-BTB1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:7/8		E	1
F1FB00	LSB-BTB1: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A31.X3:3/4		E	1
F1FB01	LSB-BTB1: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A31.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1FB02	LSB-BTB1: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A31.X3:3/4		E	1
F1FB04	LSB-BTB1: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A31.X3:3/4		E	1
F1FB05	LSB-BTB1: Control data transfer CAN-B Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A31.X3:3/4		E	1
F1FB06	LSB-BTB1: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A31.X3:3/4		E	2
F1FB11	LSB-BTB1: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:3/4		E	1
F1FB40	LSB-BTB1: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A31.X3:3/4		E	1
F1FB41	LSB-BTB1: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A31.X3:3/4		E	1
F1FB5F	LSB-BTB1: Control data transfer CAN-B Malfunction, all participants missing Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:3/4		E	1
F1FB68	LSB-BTB1: Control data transfer CAN-B Travel recorder / Tachograph erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:3/4		E	1
F1FBA0	LSB-BTB1: Control data transfer CAN-B LSB-EA1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1FBA1	LSB-BTB1: Control data transfer CAN-B LSB-EA2 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:3/4		E	1
F1FBA2	LSB-BTB1: Control data transfer CAN-B LSB-EA3 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:3/4		E	1
F1FBA3	LSB-BTB1: Control data transfer CAN-B LSB-EA4 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:3/4		E	1
F1FBAA	LSB-BTB1: Control data transfer CAN-B LSB-BTB1 erroneous Error message participant, input data is allocated with standard values (s.n.v.) CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X3:3/4		E	1
F1FC00	LSB-BTB1: Control data transfer CAN-C internal error at Register-check Controller CAN-transfer is not started replace control device	A31.X4:1/2		E	1
F1FC01	LSB-BTB1: Control data transfer CAN-C internal error at RAM-check Controller CAN-transfer is not started replace control device	A31.X4:1/2		E	1
F1FC02	LSB-BTB1: Control data transfer CAN-C Configuration error Software Error message, CAN report is not configured Check software	A31.X4:1/2		E	1
F1FC04	LSB-BTB1: Control data transfer CAN-C Configuration error time synchronization Time synchronization already active or is not configured Check software	A31.X4:1/2		E	1
F1FC05	LSB-BTB1: Control data transfer CAN-C Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A31.X4:1/2		E	1
F1FC06	LSB-BTB1: Control data transfer CAN-C fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A31.X4:1/2		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1FC11	LSB-BTB1: Control data transfer CAN-C permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X4:1/2		E	1
F1FC40	LSB-BTB1: Control data transfer CAN-C Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A31.X4:1/2		E	1
F1FC41	LSB-BTB1: Control data transfer CAN-C Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A31.X4:1/2		E	1
F1FD00	LSB-BTB1: Control data transfer CAN-D internal error at Register-check Controller CAN-transfer is not started replace control device	A31.X4:14/13		E	1
F1FD01	LSB-BTB1: Control data transfer CAN-D internal error at RAM-check Controller CAN-transfer is not started replace control device	A31.X4:14/13		E	1
F1FD02	LSB-BTB1: Control data transfer CAN-D Configuration error Software Error message, CAN report is not configured Check software	A31.X4:14/13		E	1
F1FD04	LSB-BTB1: Control data transfer CAN-D Configuration error time synchronization Time synchronization already active or is not configured Check software	A31.X4:14/13		E	1
F1FD05	LSB-BTB1: Control data transfer CAN-D Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A31.X4:14/13		E	1
F1FD06	LSB-BTB1: Control data transfer CAN-D fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A31.X4:14/13		E	2
F1FD11	LSB-BTB1: Control data transfer CAN-D permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A31.X4:14/13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F1FD40	LSB-BTB1: Control data transfer CAN-D Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A31.X4:14/13		E	1
F1FD41	LSB-BTB1: Control data transfer CAN-D Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A31.X4:14/13		E	1
F2016A	LSB-BTB2: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2016C	LSB-BTB2: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2026A	LSB-BTB2: LSBA Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2026C	LSB-BTB2: LSBA Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2036A	LSB-BTB2: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2036C	LSB-BTB2: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2046A	LSB-BTB2: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2046C	LSB-BTB2: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2056A	LSB-BTB2: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2056C	LSB-BTB2: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2066A	LSB-BTB2: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2066C	LSB-BTB2: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2076A	LSB-BTB2: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2076C	LSB-BTB2: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F20B6A	LSB-BTB2: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F20B6C	LSB-BTB2: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F20C6A	LSB-BTB2: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F20C6C	LSB-BTB2: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F20D6A	LSB-BTB2: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F20D6C	LSB-BTB2: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F20E6A	LSB-BTB2: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F20E6C	LSB-BTB2: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F20F6A	LSB-BTB2: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F20F6C	LSB-BTB2: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2106A	LSB-BTB2: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2106C	LSB-BTB2: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2116A	LSB-BTB2: LSBA Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2116C	LSB-BTB2: LSBA Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2126A	LSB-BTB2: LSBA Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2126C	LSB-BTB2: LSBA Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2136A	LSB-BTB2: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2136C	LSB-BTB2: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2146A	LSB-BTB2: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2146C	LSB-BTB2: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2166A	LSB-BTB2: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2166C	LSB-BTB2: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2176A	LSB-BTB2: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F2176C	LSB-BTB2: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F21A6A	LSB-BTB2: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F21A6C	LSB-BTB2: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F21B6A	LSB-BTB2: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F21B6C	LSB-BTB2: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F21C6A	LSB-BTB2: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F21C6C	LSB-BTB2: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F21D6A	LSB-BTB2: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:12		E	2
F21D6C	LSB-BTB2: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:12		E	2
F2205B	LSB-BTB2: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A32.X4:12		E	2
F2316A	LSB-BTB2: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2316C	LSB-BTB2: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2326A	LSB-BTB2: LSBB Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2326C	LSB-BTB2: LSBB Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2346A	LSB-BTB2: LSBB Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2346C	LSB-BTB2: LSBB Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2356A	LSB-BTB2: LSBB Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2356C	LSB-BTB2: LSBB Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2366A	LSB-BTB2: LSBB Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2366C	LSB-BTB2: LSBB Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2376A	LSB-BTB2: LSBB Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2376C	LSB-BTB2: LSBB Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2386A	LSB-BTB2: LSBB Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2386C	LSB-BTB2: LSBB Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2396A	LSB-BTB2: LSBB Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2396C	LSB-BTB2: LSBB Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F23A6A	LSB-BTB2: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F23A6C	LSB-BTB2: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F23B6A	LSB-BTB2: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F23B6C	LSB-BTB2: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F23C6A	LSB-BTB2: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F23C6C	LSB-BTB2: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F23D6A	LSB-BTB2: LSBB Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F23D6C	LSB-BTB2: LSBB Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F23E6A	LSB-BTB2: LSBB Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F23E6C	LSB-BTB2: LSBB Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F23F6A	LSB-BTB2: LSBB Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F23F6C	LSB-BTB2: LSBB Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2406A	LSB-BTB2: LSBB Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2406C	LSB-BTB2: LSBB Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2416A	LSB-BTB2: LSBB Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2416C	LSB-BTB2: LSBB Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2426A	LSB-BTB2: LSBB Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2426C	LSB-BTB2: LSBB Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2436A	LSB-BTB2: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2436C	LSB-BTB2: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2446A	LSB-BTB2: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2446C	LSB-BTB2: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2456A	LSB-BTB2: LSBB Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2456C	LSB-BTB2: LSBB Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2466A	LSB-BTB2: LSBB Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2466C	LSB-BTB2: LSBB Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2476A	LSB-BTB2: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2476C	LSB-BTB2: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2486A	LSB-BTB2: LSBB Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2486C	LSB-BTB2: LSBB Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2496A	LSB-BTB2: LSBB Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F2496C	LSB-BTB2: LSBB Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F24A6A	LSB-BTB2: LSBB Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F24A6C	LSB-BTB2: LSBB Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F24B6A	LSB-BTB2: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F24B6C	LSB-BTB2: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F24C6A	LSB-BTB2: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F24C6C	LSB-BTB2: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F24D6A	LSB-BTB2: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F24D6C	LSB-BTB2: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F24E6A	LSB-BTB2: LSBB Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A32.X4:9		E	2
F24E6C	LSB-BTB2: LSBB Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A32.X4:9		E	2
F2505B	LSB-BTB2: Control data transfer LSBB Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A32.X4:9		E	2
F25B05	LSB-BTB2: Operation ballasting / counterweight carriage Shut-down keys counterweight "Up" / "Down" actuated simultaneously	A32		B	
F25B06	LSB-BTB2: Operation ballasting / counterweight carriage Shut-down keys counterweight "In" / "Out" actuated simultaneously	A32		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F25BAD	LSB-BTB2: Operation ballasting / counterweight carriage Button Ballast UP/DOWN after Start/op. error actuated or stuck Function blocked Release all buttons; check buttons, wiring	A32		B	
F25BB0	LSB-BTB2: Operation ballasting / counterweight carriage Button Ballast UP/DOWN blocked actuated after start or stuck	A32		B	
F25BCD	LSB-BTB2: Operation ballasting / counterweight carriage Button Ballast OUT/IN after start/op. error actuated or stuck	A32		B	
F25D50	LSB-BTB2: control auxiliary equipment Button Assembly winch after Start/op. error actuated or stuck Function blocked Release all buttons; check buttons, wiring	A32		B	
F26108	LSB-BTB2: Operation crane control Caution adjustment program is active error report End test program	A32		B	2
F26132	LSB-BTB2: Operation crane control Rpm Motor 1 too low no brake power assignment possible No additional brake power is provided Check engine control	A32		E	
F26133	LSB-BTB2: Operation crane control Rpm Motor 2 too low no brake power assignment possible No additional brake power is provided Check engine control	A32		E	
F26137	LSB-BTB2: Operation crane control Outputs assembly winch erroneous Function blocked Observe initial error	A32		B	
F2613B	LSB-BTB2: Operation crane control Selection Assembly winch spool up and out simultaneous Issue of error / winch is not actuated Select only one direction	A32		B	
F2613F	LSB-BTB2: Operation crane control Selection of several aux. users error report Remove all selections aux. user	A32		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F27007	LSB-BTB2: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A32		B	
F27019	LSB-BTB2: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A32		E	
F27090	LSB-BTB2: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A32		E	
F280FA	LSB-BTB2: control engine Configuration Engine type missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A32		E	1
F280FB	LSB-BTB2: control engine Configuration Exhaust stage missing Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A32		E	1
F280FC	LSB-BTB2: control engine Configuration Engine type implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A32		E	1
F280FD	LSB-BTB2: control engine Configuration Exhaust stage implausible for system recognition engine Options or markers from BAAN erroneous. Check links in xml, BAAN-line	A32		E	1
F29900	LSB-BTB2: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A32		E	2
F29901	LSB-BTB2: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A32		E	2
F29902	LSB-BTB2: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A32		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F29904	LSB-BTB2: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A32		E	1
F29905	LSB-BTB2: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A32		E	1
F29906	LSB-BTB2: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A32		E	2
F29907	LSB-BTB2: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A32		E	1
F29911	LSB-BTB2: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A32		E	2
F29C02	LSB-BTB2: control diagnosis system error in diagnosis requirement CAN-participant ABS	A32		E	1
F29E6A	LSB-BTB2: operation engine Start/Stop op. panel after Start/op. error actuated or stuck Function blocked Release all buttons; check buttons, wiring	A32		B	
F2C044	LSB-BTB2: Diagnostics syst. band end/adj. program Test program not executable since motor not off	A32		E	1
F2C090	LSB-BTB2: Diagnostics syst. band end/adj. program Band end parameter in engine control unit programmed Note that band end parameters were writing. After op. of control unit reported once	A32		E	1
F2C0C3	LSB-BTB2: Diagnostics syst. band end/adj. program F1: Engine RPM too low Test program is not started or aborted Check Bus connection	A32		B	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2C0C4	LSB-BTB2: Diagnostics syst. band end/adj. program F2: Engine RPM too high Test program is not started or aborted Check Bus connection	A32		B	2
F2C218	LSB-BTB2: Hardware excess temperature Entry in error stack Replace LSB-Module	A32		E	2
F2C21B	LSB-BTB2: Hardware digital shut off defective Entry in error stack Report all error parameters to Service	A32		E	2
F2C21F	LSB-BTB2: Hardware After run logic defective Entry in error stack Report all error parameters to Service	A32		E	2
F2C226	LSB-BTB2: Hardware Under temperature Entry in error stack Replace LSB-Module	A32		E	2
F2C261	LSB-BTB2: Hardware measuring system defect Entry in error stack Replace LSB-Module	A32		E	2
F2C504	LSB-BTB2: System voltage Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A32		E	2
F2C505	LSB-BTB2: System voltage Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A32		E	2
F2C50F	LSB-BTB2: System voltage Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A32		E	2
F2C604	LSB-BTB2: System voltage CPU/Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A32		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2C605	LSB-BTB2: System voltage CPU/Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A32		E	2
F2C60F	LSB-BTB2: System voltage CPU/Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A32		E	2
F2C704	LSB-BTB2: Supply voltage 30 (A0-7) / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A32.X1:2/3		E	2
F2C705	LSB-BTB2: Supply voltage 30 (A0-7) / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A32.X1:2/3		E	2
F2C804	LSB-BTB2: Supply voltage 15.1 / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A32.X1:1		E	2
F2C805	LSB-BTB2: Supply voltage 15.1 / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A32.X1:1		E	2
F2C80F	LSB-BTB2: Supply voltage 15.1 / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A32.X1:1		E	2
F2CC04	LSB-BTB2: System voltage Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A32		E	2
F2CC05	LSB-BTB2: System voltage Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A32		E	2
F2CC0F	LSB-BTB2: System voltage Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A32		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2CD04	LSB-BTB2: System voltage CPU/Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A32		E	2
F2CD05	LSB-BTB2: System voltage CPU/Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A32		E	2
F2CD0F	LSB-BTB2: System voltage CPU/Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A32		E	2
F2CE04	LSB-BTB2: Supply voltage 30 (A8-15) / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A32.X2:2/3		E	2
F2CE05	LSB-BTB2: Supply voltage 30 (A8-15) / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A32.X2:2/3		E	2
F2CF04	LSB-BTB2: Supply voltage 15.1 / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A32.X2:1		E	2
F2CF05	LSB-BTB2: Supply voltage 15.1 / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A32.X2:1		E	2
F2CF0F	LSB-BTB2: Supply voltage 15.1 / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A32.X2:1		E	2
F2D004	LSB-BTB2: Digital input E0 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:4		E	2
F2D005	LSB-BTB2: Digital input E0 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2D104	LSB-BTB2: Digital input E1 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:5		E	2
F2D105	LSB-BTB2: Digital input E1 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:5		E	2
F2D204	LSB-BTB2: Digital input E2 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:6		E	2
F2D205	LSB-BTB2: Digital input E2 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:6		E	2
F2D304	LSB-BTB2: Digital input E3 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:7		E	2
F2D305	LSB-BTB2: Digital input E3 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:7		E	2
F2D804	LSB-BTB2: Digital input E8 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:4		E	2
F2D805	LSB-BTB2: Digital input E8 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:4		E	2
F2D904	LSB-BTB2: Digital input E9 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:5		E	2
F2D905	LSB-BTB2: Digital input E9 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2DA04	LSB-BTB2: Digital input E10 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:6		E	2
F2DA05	LSB-BTB2: Digital input E10 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:6		E	2
F2DB04	LSB-BTB2: Digital input E11 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:7		E	2
F2DB05	LSB-BTB2: Digital input E11 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:7		E	2
F2E012	LSB-BTB2: Switching output A0 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:12		E	2
F2E015	LSB-BTB2: Switching output A0 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:12		E	2
F2E01D	LSB-BTB2: Switching output A0 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X1:12		E	2
F2E054	LSB-BTB2: Switching output A0 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:12		E	2
F2E072	LSB-BTB2: Switching output A0 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:12		E	2
F2E112	LSB-BTB2: Switching output A1 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2E115	LSB-BTB2: Switching output A1 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:13		E	2
F2E11D	LSB-BTB2: Switching output A1 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X1:13		E	2
F2E154	LSB-BTB2: Switching output A1 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:13		E	2
F2E172	LSB-BTB2: Switching output A1 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:13		E	2
F2E212	LSB-BTB2: Switching output A2 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:14		E	2
F2E215	LSB-BTB2: Switching output A2 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:14		E	2
F2E21D	LSB-BTB2: Switching output A2 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X1:14		E	2
F2E254	LSB-BTB2: Switching output A2 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:14		E	2
F2E272	LSB-BTB2: Switching output A2 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:14		E	2
F2E312	LSB-BTB2: Switching output A3 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2E315	LSB-BTB2: Switching output A3 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:15		E	2
F2E31D	LSB-BTB2: Switching output A3 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X1:15		E	2
F2E354	LSB-BTB2: Switching output A3 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:15		E	2
F2E372	LSB-BTB2: Switching output A3 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:15		E	2
F2E412	LSB-BTB2: Switching output A4 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:16		E	2
F2E415	LSB-BTB2: Switching output A4 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:16		E	2
F2E41D	LSB-BTB2: Switching output A4 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X1:16		E	2
F2E454	LSB-BTB2: Switching output A4 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:16		E	2
F2E472	LSB-BTB2: Switching output A4 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:16		E	2
F2E512	LSB-BTB2: Switching output A5 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:17		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2E515	LSB-BTB2: Switching output A5 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:17		E	2
F2E51D	LSB-BTB2: Switching output A5 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X1:17		E	2
F2E554	LSB-BTB2: Switching output A5 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:17		E	2
F2E572	LSB-BTB2: Switching output A5 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:17		E	2
F2E612	LSB-BTB2: Switching output A6 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:18		E	2
F2E615	LSB-BTB2: Switching output A6 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:18		E	2
F2E61D	LSB-BTB2: Switching output A6 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X1:18		E	2
F2E654	LSB-BTB2: Switching output A6 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:18		E	2
F2E672	LSB-BTB2: Switching output A6 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:18		E	2
F2E712	LSB-BTB2: Switching output A7 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:19		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2E715	LSB-BTB2: Switching output A7 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:19		E	2
F2E71D	LSB-BTB2: Switching output A7 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X1:19		E	2
F2E754	LSB-BTB2: Switching output A7 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:19		E	2
F2E772	LSB-BTB2: Switching output A7 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X1:19		E	2
F2E812	LSB-BTB2: Switching output A8 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:12		E	2
F2E815	LSB-BTB2: Switching output A8 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:12		E	2
F2E81D	LSB-BTB2: Switching output A8 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X2:12		E	2
F2E854	LSB-BTB2: Switching output A8 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:12		E	2
F2E872	LSB-BTB2: Switching output A8 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:12		E	2
F2E912	LSB-BTB2: Switching output A9 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2E915	LSB-BTB2: Switching output A9 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:13		E	2
F2E91D	LSB-BTB2: Switching output A9 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X2:13		E	2
F2E954	LSB-BTB2: Switching output A9 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:13		E	2
F2E972	LSB-BTB2: Switching output A9 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:13		E	2
F2EA12	LSB-BTB2: Switching output A10 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:14		E	2
F2EA15	LSB-BTB2: Switching output A10 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:14		E	2
F2EA1D	LSB-BTB2: Switching output A10 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X2:14		E	2
F2EA54	LSB-BTB2: Switching output A10 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:14		E	2
F2EA72	LSB-BTB2: Switching output A10 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:14		E	2
F2EB12	LSB-BTB2: Switching output A11 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2EB15	LSB-BTB2: Switching output A11 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:15		E	2
F2EB1D	LSB-BTB2: Switching output A11 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X2:15		E	2
F2EB54	LSB-BTB2: Switching output A11 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:15		E	2
F2EB72	LSB-BTB2: Switching output A11 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:15		E	2
F2EC12	LSB-BTB2: Switching output A12 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:16		E	2
F2EC15	LSB-BTB2: Switching output A12 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:16		E	2
F2EC1D	LSB-BTB2: Switching output A12 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X2:16		E	2
F2EC54	LSB-BTB2: Switching output A12 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:16		E	2
F2EC72	LSB-BTB2: Switching output A12 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:16		E	2
F2ED12	LSB-BTB2: Switching output A13 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:17		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2ED15	LSB-BTB2: Switching output A13 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:17		E	2
F2ED1D	LSB-BTB2: Switching output A13 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X2:17		E	2
F2ED54	LSB-BTB2: Switching output A13 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:17		E	2
F2ED72	LSB-BTB2: Switching output A13 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:17		E	2
F2EE12	LSB-BTB2: Switching output A14 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:18		E	2
F2EE15	LSB-BTB2: Switching output A14 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:18		E	2
F2EE1D	LSB-BTB2: Switching output A14 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X2:18		E	2
F2EE54	LSB-BTB2: Switching output A14 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:18		E	2
F2EE72	LSB-BTB2: Switching output A14 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:18		E	2
F2EF12	LSB-BTB2: Switching output A15 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:19		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2EF15	LSB-BTB2: Switching output A15 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:19		E	2
F2EF1D	LSB-BTB2: Switching output A15 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A32.X2:19		E	2
F2EF54	LSB-BTB2: Switching output A15 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:19		E	2
F2EF72	LSB-BTB2: Switching output A15 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A32.X2:19		E	2
F2F002	LSB-BTB2: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A32		E	1
F2F013	LSB-BTB2: System error OS-CPU0 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A32		E	1
F2F016	LSB-BTB2: System error OS-CPU0 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A32		E	1
F2F050	LSB-BTB2: System error OS-CPU0 file not available error report Reload application software	A32		E	2
F2F068	LSB-BTB2: System error OS-CPU0 impermissible interrupt Entry in error stack Report all error parameters to Service	A32		E	1
F2F070	LSB-BTB2: System error OS-CPU0 various structure versions Entry in error stack Report all error parameters to Service	A32		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2F073	LSB-BTB2: System error OS-CPU0 interpreter error Entry in error stack At P0=00000013 carry out download	A32		E	1
F2F075	LSB-BTB2: System error OS-CPU0 SPI-error Entry in error stack Report all error parameters to Service	A32		E	1
F2F078	LSB-BTB2: System error OS-CPU0 impermissible parameter Entry in error stack Report all error parameters to Service	A32		E	1
F2F07A	LSB-BTB2: System error OS-CPU0 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A32		E	2
F2F080	LSB-BTB2: System error OS-CPU0 Fatal internal error Entry in error stack Report all error parameters to Service	A32		E	1
F2F082	LSB-BTB2: System error OS-CPU0 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A32		E	1
F2F0AC	LSB-BTB2: System error OS-CPU0 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A32		E	1
F2F0C1	LSB-BTB2: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A32		E	1
F2F0D2	LSB-BTB2: System error OS-CPU0 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A32		E	2
F2F102	LSB-BTB2: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A32		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2F113	LSB-BTB2: System error OS-CPU1 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A32		E	1
F2F116	LSB-BTB2: System error OS-CPU1 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A32		E	1
F2F150	LSB-BTB2: System error OS-CPU1 file not available error report Reload application software	A32		E	2
F2F168	LSB-BTB2: System error OS-CPU1 impermissible interrupt Entry in error stack Report all error parameters to Service	A32		E	1
F2F170	LSB-BTB2: System error OS-CPU1 various structure versions Entry in error stack Report all error parameters to Service	A32		E	1
F2F173	LSB-BTB2: System error OS-CPU1 interpreter error Entry in error stack At P0=00000013 carry out download	A32		E	1
F2F175	LSB-BTB2: System error OS-CPU1 SPI-error Entry in error stack Report all error parameters to Service	A32		E	1
F2F178	LSB-BTB2: System error OS-CPU1 impermissible parameter Entry in error stack Report all error parameters to Service	A32		E	1
F2F17A	LSB-BTB2: System error OS-CPU1 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A32		E	2
F2F180	LSB-BTB2: System error OS-CPU1 Fatal internal error Entry in error stack Report all error parameters to Service	A32		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2F182	LSB-BTB2: System error OS-CPU1 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A32		E	1
F2F1AC	LSB-BTB2: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A32		E	1
F2F1C1	LSB-BTB2: System error OS-CPU1 Incorrect or wrong system version for application error report Reload matching system version	A32		E	1
F2F1D2	LSB-BTB2: System error OS-CPU1 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A32		E	2
F2F800	LSB-BTB2: Control data transfer CAN EP0 internal error at Register-check Controller CAN-transfer is not started replace control device	A32.X3:7/8/3/3		E	2
F2F801	LSB-BTB2: Control data transfer CAN EP0 internal error at RAM-check Controller CAN-transfer is not started replace control device	A32.X3:7/8/3/3		E	2
F2F802	LSB-BTB2: Control data transfer CAN EP0 Configuration error Software Error message, CAN report is not configured Check software	A32.X3:7/8/3/3		E	1
F2F804	LSB-BTB2: Control data transfer CAN EP0 Configuration error time synchronization Time synchronization already active or is not configured Check software	A32.X3:7/8/3/3		E	1
F2F805	LSB-BTB2: Control data transfer CAN EP0 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A32.X3:7/8/3/3		E	1
F2F806	LSB-BTB2: Control data transfer CAN EP0 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A32.X3:7/8/3/3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2F807	LSB-BTB2: Control data transfer CAN EP0 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A32.X3:7/8/3/3		E	1
F2F811	LSB-BTB2: Control data transfer CAN EP0 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A32.X3:7/8/3/3		E	2
F2F900	LSB-BTB2: Control data transfer CAN EP1 internal error at Register-check Controller CAN-transfer is not started replace control device	A32.X4:1/2/14/1 3		E	2
F2F901	LSB-BTB2: Control data transfer CAN EP1 internal error at RAM-check Controller CAN-transfer is not started replace control device	A32.X4:1/2/14/1 3		E	2
F2F902	LSB-BTB2: Control data transfer CAN EP1 Configuration error Software Error message, CAN report is not configured Check software	A32.X4:1/2/14/1 3		E	1
F2F904	LSB-BTB2: Control data transfer CAN EP1 Configuration error time synchronization Time synchronization already active or is not configured Check software	A32.X4:1/2/14/1 3		E	1
F2F905	LSB-BTB2: Control data transfer CAN EP1 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A32.X4:1/2/14/1 3		E	1
F2F906	LSB-BTB2: Control data transfer CAN EP1 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A32.X4:1/2/14/1 3		E	2
F2F907	LSB-BTB2: Control data transfer CAN EP1 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A32.X4:1/2/14/1 3		E	1
F2F911	LSB-BTB2: Control data transfer CAN EP1 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A32.X4:1/2/14/1 3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2FA00	LSB-BTB2: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A32.X3:7/8		E	1
F2FA01	LSB-BTB2: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A32.X3:7/8		E	1
F2FA02	LSB-BTB2: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A32.X3:7/8		E	1
F2FA04	LSB-BTB2: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A32.X3:7/8		E	1
F2FA05	LSB-BTB2: Control data transfer CAN-A Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A32.X3:7/8		E	1
F2FA06	LSB-BTB2: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A32.X3:7/8		E	2
F2FA11	LSB-BTB2: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A32.X3:7/8		E	1
F2FA32	LSB-BTB2: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A32.X3:7/8		E	1
F2FA40	LSB-BTB2: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A32.X3:7/8		E	1
F2FA41	LSB-BTB2: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A32.X3:7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2FA80	LSB-BTB2: Control data transfer CAN-A LSB-UEA1 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FA81	LSB-BTB2: Control data transfer CAN-A LSB-UEA2 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FA83	LSB-BTB2: Control data transfer CAN-A LSB-UEA4 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FA86	LSB-BTB2: Control data transfer CAN-A LSB-UEA7 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FA87	LSB-BTB2: Control data transfer CAN-A LSB-UEA8 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FA88	LSB-BTB2: Control data transfer CAN-A LSB-UEA9 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FA89	LSB-BTB2: Control data transfer CAN-A LSB-UEA10 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FAAC	LSB-BTB2: Control data transfer CAN-A LSB-BTB3 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FAB0	LSB-BTB2: Control data transfer CAN-A LSB-AMS1 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1
F2FAB1	LSB-BTB2: Control data transfer CAN-A LSB-AMS2 erroneous error report Check CAN-Network, control units	A32.X3:7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2FB00	LSB-BTB2: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A32.X3:3/4		E	1
F2FB01	LSB-BTB2: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A32.X3:3/4		E	1
F2FB02	LSB-BTB2: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A32.X3:3/4		E	1
F2FB04	LSB-BTB2: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A32.X3:3/4		E	1
F2FB05	LSB-BTB2: Control data transfer CAN-B Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A32.X3:3/4		E	1
F2FB06	LSB-BTB2: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A32.X3:3/4		E	2
F2FB11	LSB-BTB2: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A32.X3:3/4		E	1
F2FB40	LSB-BTB2: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A32.X3:3/4		E	1
F2FB41	LSB-BTB2: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A32.X3:3/4		E	1
F2FB60	LSB-BTB2: Control data transfer CAN-B Motor erroneous error report Check CAN-Network, control units	A32.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2FC00	LSB-BTB2: Control data transfer CAN-C internal error at Register-check Controller CAN-transfer is not started replace control device	A32.X4:1/2		E	1
F2FC01	LSB-BTB2: Control data transfer CAN-C internal error at RAM-check Controller CAN-transfer is not started replace control device	A32.X4:1/2		E	1
F2FC02	LSB-BTB2: Control data transfer CAN-C Configuration error Software Error message, CAN report is not configured Check software	A32.X4:1/2		E	1
F2FC04	LSB-BTB2: Control data transfer CAN-C Configuration error time synchronization Time synchronization already active or is not configured Check software	A32.X4:1/2		E	1
F2FC05	LSB-BTB2: Control data transfer CAN-C Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A32.X4:1/2		E	1
F2FC06	LSB-BTB2: Control data transfer CAN-C fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A32.X4:1/2		E	2
F2FC11	LSB-BTB2: Control data transfer CAN-C permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A32.X4:1/2		E	1
F2FC32	LSB-BTB2: Control data transfer CAN-C Data transfer erroneous/missing check wiring	A32.X4:1/2		E	1
F2FC40	LSB-BTB2: Control data transfer CAN-C Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A32.X4:1/2		E	1
F2FC41	LSB-BTB2: Control data transfer CAN-C Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A32.X4:1/2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2FC8A	LSB-BTB2: Control data transfer CAN-C LSB-UEA11 erroneous error report Check CAN-Network, control units	A32.X4:1/2		E	1
F2FC90	LSB-BTB2: Control data transfer CAN-C LSB-TE1 erroneous error report Check CAN-Network, control units	A32.X4:1/2		E	1
F2FC91	LSB-BTB2: Control data transfer CAN-C LSB-TE2 erroneous error report Check CAN-Network, control units	A32.X4:1/2		E	1
F2FC92	LSB-BTB2: Control data transfer CAN-C LSB-TE3 erroneous error report Check CAN-Network, control units	A32.X4:1/2		E	1
F2FCB0	LSB-BTB2: Control data transfer CAN-C LSB-AMS1 erroneous error report Check CAN-Network, control units	A32.X4:1/2		E	1
F2FCB1	LSB-BTB2: Control data transfer CAN-C LSB-AMS2 erroneous error report Check CAN-Network, control units	A32.X4:1/2		E	1
F2FD00	LSB-BTB2: Control data transfer CAN-D internal error at Register-check Controller CAN-transfer is not started replace control device	A32.X4:14/13		E	1
F2FD01	LSB-BTB2: Control data transfer CAN-D internal error at RAM-check Controller CAN-transfer is not started replace control device	A32.X4:14/13		E	1
F2FD02	LSB-BTB2: Control data transfer CAN-D Configuration error Software Error message, CAN report is not configured Check software	A32.X4:14/13		E	1
F2FD04	LSB-BTB2: Control data transfer CAN-D Configuration error time synchronization Time synchronization already active or is not configured Check software	A32.X4:14/13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F2FD05	LSB-BTB2: Control data transfer CAN-D Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A32.X4:14/13		E	1
F2FD06	LSB-BTB2: Control data transfer CAN-D fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A32.X4:14/13		E	2
F2FD11	LSB-BTB2: Control data transfer CAN-D permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A32.X4:14/13		E	1
F2FD40	LSB-BTB2: Control data transfer CAN-D Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A32.X4:14/13		E	1
F2FD41	LSB-BTB2: Control data transfer CAN-D Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A32.X4:14/13		E	1
F2FD60	LSB-BTB2: Control data transfer CAN-D Motor erroneous error report Check CAN-Network, control units	A32.X4:14/13		E	1
F36212	LSB-BTB3: Control hydraulic Pressure stage p2 - pressure too high - warning warning Check pressure stages luffing/tele	A33		E	
F36213	LSB-BTB3: Control hydraulic Pressure stage p3 - pressure too high - warning warning Check pressure stages luffing/tele	A33		E	
F36214	LSB-BTB3: Control hydraulic Pressure stage p4 - pressure too high - warning warning Check pressure stages luffing/tele	A33		E	
F36215	LSB-BTB3: Control hydraulic Pressure stage p5 - pressure too high- warning warning Check pressure stages luffing/tele	A33		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F36216	LSB-BTB3: Control hydraulic Pressure stage p6 - pressure too high- warning Shut off Luffing and telescoping Check pressure stages luffing/tele	A33		E	
F36217	LSB-BTB3: Control hydraulic Pressure stage p7 - pressure too high- warning Shut off Luffing and telescoping Check pressure stages luffing/tele	A33		E	
F36222	LSB-BTB3: Control hydraulic Pressure stage p2 - pressure too high - Shut off Shut off Luffing and telescoping Check pressure stages luffing/tele	A33		E	
F36223	LSB-BTB3: Control hydraulic Pressure stage p3 - pressure too high - Shut off Shut off Luffing and telescoping Check pressure stages luffing/tele	A33		E	
F36224	LSB-BTB3: Control hydraulic Pressure stage p4 - pressure too high - Shut off Shut off Luffing and telescoping Check pressure stages luffing/tele	A33		E	
F36225	LSB-BTB3: Control hydraulic Pressure stage p5 - pressure too high- Shut off Shut off Luffing and telescoping Check pressure stages luffing/tele	A33		E	
F36226	LSB-BTB3: Control hydraulic Pressure stage p6 - pressure too high- Shut off	A33		E	
F36227	LSB-BTB3: Control hydraulic Pressure stage p7 - pressure too high- Shut off No crane movement which is controlled via Master switch -1 (right) or Master switch -2 (left) Check CAN-connection	A33		E	
F37007	LSB-BTB3: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A33		B	
F37019	LSB-BTB3: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A33		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F37090	LSB-BTB3: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A33		E	
F6016A	LSB-BTB6: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6016C	LSB-BTB6: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6036A	LSB-BTB6: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6036C	LSB-BTB6: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6046A	LSB-BTB6: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6046C	LSB-BTB6: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6056A	LSB-BTB6: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6056C	LSB-BTB6: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6066A	LSB-BTB6: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6066C	LSB-BTB6: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6076A	LSB-BTB6: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6076C	LSB-BTB6: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6086A	LSB-BTB6: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6086C	LSB-BTB6: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6096A	LSB-BTB6: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6096C	LSB-BTB6: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F60A6A	LSB-BTB6: LSBA Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F60A6C	LSB-BTB6: LSBA Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F60B6A	LSB-BTB6: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F60B6C	LSB-BTB6: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F60C6A	LSB-BTB6: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F60C6C	LSB-BTB6: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F60D6A	LSB-BTB6: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F60D6C	LSB-BTB6: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F60E6A	LSB-BTB6: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F60E6C	LSB-BTB6: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6106A	LSB-BTB6: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6106C	LSB-BTB6: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6136A	LSB-BTB6: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6136C	LSB-BTB6: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6146A	LSB-BTB6: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6146C	LSB-BTB6: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6156A	LSB-BTB6: LSBA Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6156C	LSB-BTB6: LSBA Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6166A	LSB-BTB6: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6166C	LSB-BTB6: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6176A	LSB-BTB6: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6176C	LSB-BTB6: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6186A	LSB-BTB6: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6186C	LSB-BTB6: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6196A	LSB-BTB6: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F6196C	LSB-BTB6: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F61A6A	LSB-BTB6: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F61A6C	LSB-BTB6: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F61B6A	LSB-BTB6: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F61B6C	LSB-BTB6: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F61C6A	LSB-BTB6: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F61C6C	LSB-BTB6: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F61D6A	LSB-BTB6: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F61D6C	LSB-BTB6: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F61E6A	LSB-BTB6: LSBA Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:12		E	2
F61E6C	LSB-BTB6: LSBA Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:12		E	2
F6205B	LSB-BTB6: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A36.X4:12		E	2
F6316A	LSB-BTB6: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6316C	LSB-BTB6: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6326A	LSB-BTB6: LSBB Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6326C	LSB-BTB6: LSBB Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6336A	LSB-BTB6: LSBB Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6336C	LSB-BTB6: LSBB Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6346A	LSB-BTB6: LSBB Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6346C	LSB-BTB6: LSBB Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6356A	LSB-BTB6: LSBB Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6356C	LSB-BTB6: LSBB Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6366A	LSB-BTB6: LSBB Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6366C	LSB-BTB6: LSBB Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6376A	LSB-BTB6: LSBB Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6376C	LSB-BTB6: LSBB Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6386A	LSB-BTB6: LSBB Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6386C	LSB-BTB6: LSBB Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6396A	LSB-BTB6: LSBB Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6396C	LSB-BTB6: LSBB Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F63A6A	LSB-BTB6: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F63A6C	LSB-BTB6: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F63B6A	LSB-BTB6: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F63B6C	LSB-BTB6: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F63C6A	LSB-BTB6: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F63C6C	LSB-BTB6: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F63D6A	LSB-BTB6: LSBB Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F63D6C	LSB-BTB6: LSBB Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F63E6A	LSB-BTB6: LSBB Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F63E6C	LSB-BTB6: LSBB Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6486A	LSB-BTB6: LSBB Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6486C	LSB-BTB6: LSBB Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6496A	LSB-BTB6: LSBB Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F6496C	LSB-BTB6: LSBB Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F64A6A	LSB-BTB6: LSBB Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F64A6C	LSB-BTB6: LSBB Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F64B6A	LSB-BTB6: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F64B6C	LSB-BTB6: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F64C6A	LSB-BTB6: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F64C6C	LSB-BTB6: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F64D6A	LSB-BTB6: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F64D6C	LSB-BTB6: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F64E6A	LSB-BTB6: LSBB Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A36.X4:9		E	2
F64E6C	LSB-BTB6: LSBB Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A36.X4:9		E	2
F6505B	LSB-BTB6: Control data transfer LSBB Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A36.X4:9		E	2
F65E59	LSB-BTB6: crane control Pilot contacts winch loc. winch 1 / winch 2 invalid combination Error message winch turn sensor A (W1) is assigned winch location 1, winch turn sensor (W2) is assigned winch location 2 Check pilot contacts and winch turn sensor on LSB-Bus	A36		E	
F67007	LSB-BTB6: remote control Zero position compulsion on radio MS No movements possible via radio control Bring radio control master switch to neutral position	A36		E	1
F67019	LSB-BTB6: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A36		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F67090	LSB-BTB6: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A36		E	1
F68B02	LSB-BTB6: Control crawler Pedal sensor crawler left, elect. not in zero pos. Operational shut off. Crawler cannot be controlled with this pedal Check: voltage on analog input must be >5.5V and <6.5V, then pedal in zero pos., check wiring	A36		E	1
F68B03	LSB-BTB6: Control crawler Pedal sensor crawler right, elect. not in zero pos. Operational shut off. Crawler cannot be controlled with this pedal Check: voltage on analog input must be >5.5V and <6.5V, then pedal in zero pos., check wiring	A36		E	1
F68B1C	LSB-BTB6: Control crawler Interruption bus connection(s)Actuation / release, zero force Output of error, crane function is not selected. Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A36		E	1
F69900	LSB-BTB6: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A36		E	2
F69901	LSB-BTB6: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A36		E	2
F69902	LSB-BTB6: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A36		E	1
F69904	LSB-BTB6: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A36		E	1
F69905	LSB-BTB6: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A36		E	1
F69906	LSB-BTB6: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A36		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F69907	LSB-BTB6: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A36		E	1
F69911	LSB-BTB6: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A36		E	2
F6C218	LSB-BTB6: Hardware excess temperature Entry in error stack Replace LSB-Module	A36		E	2
F6C21B	LSB-BTB6: Hardware digital shut off defective Entry in error stack Report all error parameters to Service	A36		E	2
F6C21F	LSB-BTB6: Hardware After run logic defective Entry in error stack Report all error parameters to Service	A36		E	2
F6C226	LSB-BTB6: Hardware Under temperature Entry in error stack Replace LSB-Module	A36		E	2
F6C261	LSB-BTB6: Hardware measuring system defect Entry in error stack Replace LSB-Module	A36		E	2
F6C504	LSB-BTB6: System voltage Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A36		E	2
F6C505	LSB-BTB6: System voltage Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A36		E	2
F6C50F	LSB-BTB6: System voltage Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A36		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6C604	LSB-BTB6: System voltage CPU/Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A36		E	2
F6C605	LSB-BTB6: System voltage CPU/Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A36		E	2
F6C60F	LSB-BTB6: System voltage CPU/Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A36		E	2
F6C704	LSB-BTB6: Supply voltage 30 (A0-7) / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A36.X1:2/3		E	2
F6C705	LSB-BTB6: Supply voltage 30 (A0-7) / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A36.X1:2/3		E	2
F6C804	LSB-BTB6: Supply voltage 15.1 / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A36.X1:1		E	2
F6C805	LSB-BTB6: Supply voltage 15.1 / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A36.X1:1		E	2
F6C80F	LSB-BTB6: Supply voltage 15.1 / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A36.X1:1		E	2
F6CC04	LSB-BTB6: System voltage Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A36		E	2
F6CC05	LSB-BTB6: System voltage Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A36		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6CC0F	LSB-BTB6: System voltage Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A36		E	2
F6CD04	LSB-BTB6: System voltage CPU/Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A36		E	2
F6CD05	LSB-BTB6: System voltage CPU/Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A36		E	2
F6CD0F	LSB-BTB6: System voltage CPU/Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A36		E	2
F6CE04	LSB-BTB6: Supply voltage 30 (A8-15) / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A36.X2:2/3		E	2
F6CE05	LSB-BTB6: Supply voltage 30 (A8-15) / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A36.X2:2/3		E	2
F6CF04	LSB-BTB6: Supply voltage 15.1 / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A36.X2:1		E	2
F6CF05	LSB-BTB6: Supply voltage 15.1 / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A36.X2:1		E	2
F6CF0F	LSB-BTB6: Supply voltage 15.1 / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A36.X2:1		E	2
F6D004	LSB-BTB6: Digital input E0 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6D005	LSB-BTB6: Digital input E0 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:4		E	2
F6D073	LSB-BTB6: Digital input E0 open circuit or short circuit to supply voltage/ground Operational shut off. No actuation possible with connected pedal Check: voltage an analog input, approx.2V at deflection to rear,approx. 10V at deflection to front, check wiring	A36.X1:4		E	1
F6D104	LSB-BTB6: Digital input E1 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:5		E	2
F6D105	LSB-BTB6: Digital input E1 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:5		E	2
F6D173	LSB-BTB6: Digital input E1 open circuit or short circuit to supply voltage/ground Operational shut off. No actuation possible with connected pedal Check: voltage an analog input, approx.2V at deflection to rear,approx. 10V at deflection to front, check wiring	A36.X1:5		E	1
F6D204	LSB-BTB6: Digital input E2 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:6		E	2
F6D205	LSB-BTB6: Digital input E2 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:6		E	2
F6D304	LSB-BTB6: Digital input E3 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:7		E	2
F6D305	LSB-BTB6: Digital input E3 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:7		E	2
F6D804	LSB-BTB6: Digital input E8 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6D805	LSB-BTB6: Digital input E8 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:4		E	2
F6D904	LSB-BTB6: Digital input E9 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:5		E	2
F6D905	LSB-BTB6: Digital input E9 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:5		E	2
F6DA04	LSB-BTB6: Digital input E10 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:6		E	2
F6DA05	LSB-BTB6: Digital input E10 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:6		E	2
F6DB04	LSB-BTB6: Digital input E11 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:7		E	2
F6DB05	LSB-BTB6: Digital input E11 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:7		E	2
F6E012	LSB-BTB6: Switching output A0 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:12		E	2
F6E015	LSB-BTB6: Switching output A0 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:12		E	2
F6E01D	LSB-BTB6: Switching output A0 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X1:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6E054	LSB-BTB6: Switching output A0 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:12		E	2
F6E072	LSB-BTB6: Switching output A0 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:12		E	2
F6E112	LSB-BTB6: Switching output A1 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:13		E	2
F6E115	LSB-BTB6: Switching output A1 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:13		E	2
F6E11D	LSB-BTB6: Switching output A1 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X1:13		E	2
F6E154	LSB-BTB6: Switching output A1 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:13		E	2
F6E172	LSB-BTB6: Switching output A1 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:13		E	2
F6E212	LSB-BTB6: Switching output A2 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:14		E	2
F6E215	LSB-BTB6: Switching output A2 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:14		E	2
F6E21D	LSB-BTB6: Switching output A2 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X1:14		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6E254	LSB-BTB6: Switching output A2 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:14		E	2
F6E272	LSB-BTB6: Switching output A2 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:14		E	2
F6E312	LSB-BTB6: Switching output A3 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:15		E	2
F6E315	LSB-BTB6: Switching output A3 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:15		E	2
F6E31D	LSB-BTB6: Switching output A3 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X1:15		E	2
F6E354	LSB-BTB6: Switching output A3 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:15		E	2
F6E372	LSB-BTB6: Switching output A3 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:15		E	2
F6E412	LSB-BTB6: Switching output A4 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:16		E	2
F6E415	LSB-BTB6: Switching output A4 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:16		E	2
F6E41D	LSB-BTB6: Switching output A4 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X1:16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6E454	LSB-BTB6: Switching output A4 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:16		E	2
F6E472	LSB-BTB6: Switching output A4 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:16		E	2
F6E512	LSB-BTB6: Switching output A5 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:17		E	2
F6E515	LSB-BTB6: Switching output A5 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:17		E	2
F6E51D	LSB-BTB6: Switching output A5 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X1:17		E	2
F6E554	LSB-BTB6: Switching output A5 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:17		E	2
F6E572	LSB-BTB6: Switching output A5 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:17		E	2
F6E612	LSB-BTB6: Switching output A6 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:18		E	2
F6E615	LSB-BTB6: Switching output A6 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:18		E	2
F6E61D	LSB-BTB6: Switching output A6 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X1:18		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6E654	LSB-BTB6: Switching output A6 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:18		E	2
F6E672	LSB-BTB6: Switching output A6 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:18		E	2
F6E712	LSB-BTB6: Switching output A7 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:19		E	2
F6E715	LSB-BTB6: Switching output A7 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:19		E	2
F6E71D	LSB-BTB6: Switching output A7 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X1:19		E	2
F6E754	LSB-BTB6: Switching output A7 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:19		E	2
F6E772	LSB-BTB6: Switching output A7 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X1:19		E	2
F6E812	LSB-BTB6: Switching output A8 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:12		E	2
F6E815	LSB-BTB6: Switching output A8 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:12		E	2
F6E81D	LSB-BTB6: Switching output A8 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X2:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6E854	LSB-BTB6: Switching output A8 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:12		E	2
F6E872	LSB-BTB6: Switching output A8 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:12		E	2
F6E912	LSB-BTB6: Switching output A9 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:13		E	2
F6E915	LSB-BTB6: Switching output A9 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:13		E	2
F6E91D	LSB-BTB6: Switching output A9 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X2:13		E	2
F6E954	LSB-BTB6: Switching output A9 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:13		E	2
F6E972	LSB-BTB6: Switching output A9 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:13		E	2
F6EA12	LSB-BTB6: Switching output A10 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:14		E	2
F6EA15	LSB-BTB6: Switching output A10 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:14		E	2
F6EA1D	LSB-BTB6: Switching output A10 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X2:14		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6EA54	LSB-BTB6: Switching output A10 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:14		E	2
F6EA72	LSB-BTB6: Switching output A10 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:14		E	2
F6EB12	LSB-BTB6: Switching output A11 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:15		E	2
F6EB15	LSB-BTB6: Switching output A11 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:15		E	2
F6EB1D	LSB-BTB6: Switching output A11 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X2:15		E	2
F6EB54	LSB-BTB6: Switching output A11 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:15		E	2
F6EB72	LSB-BTB6: Switching output A11 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:15		E	2
F6EC12	LSB-BTB6: Switching output A12 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:16		E	2
F6EC15	LSB-BTB6: Switching output A12 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:16		E	2
F6EC1D	LSB-BTB6: Switching output A12 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X2:16		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6EC54	LSB-BTB6: Switching output A12 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:16		E	2
F6EC72	LSB-BTB6: Switching output A12 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:16		E	2
F6ED12	LSB-BTB6: Switching output A13 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:17		E	2
F6ED15	LSB-BTB6: Switching output A13 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:17		E	2
F6ED1D	LSB-BTB6: Switching output A13 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X2:17		E	2
F6ED54	LSB-BTB6: Switching output A13 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:17		E	2
F6ED72	LSB-BTB6: Switching output A13 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:17		E	2
F6EE12	LSB-BTB6: Switching output A14 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:18		E	2
F6EE15	LSB-BTB6: Switching output A14 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:18		E	2
F6EE1D	LSB-BTB6: Switching output A14 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X2:18		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6EE54	LSB-BTB6: Switching output A14 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:18		E	2
F6EE72	LSB-BTB6: Switching output A14 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:18		E	2
F6EF12	LSB-BTB6: Switching output A15 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:19		E	2
F6EF15	LSB-BTB6: Switching output A15 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:19		E	2
F6EF1D	LSB-BTB6: Switching output A15 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A36.X2:19		E	2
F6EF54	LSB-BTB6: Switching output A15 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:19		E	2
F6EF72	LSB-BTB6: Switching output A15 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A36.X2:19		E	2
F6F002	LSB-BTB6: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A36		E	1
F6F013	LSB-BTB6: System error OS-CPU0 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A36		E	1
F6F016	LSB-BTB6: System error OS-CPU0 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A36		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6F050	LSB-BTB6: System error OS-CPU0 file not available error report Reload application software	A36		E	2
F6F068	LSB-BTB6: System error OS-CPU0 impermissible interrupt Entry in error stack Report all error parameters to Service	A36		E	1
F6F070	LSB-BTB6: System error OS-CPU0 various structure versions Entry in error stack Report all error parameters to Service	A36		E	1
F6F073	LSB-BTB6: System error OS-CPU0 interpreter error Entry in error stack At P0=00000013 carry out download	A36		E	1
F6F075	LSB-BTB6: System error OS-CPU0 SPI-error Entry in error stack Report all error parameters to Service	A36		E	1
F6F078	LSB-BTB6: System error OS-CPU0 impermissible parameter Entry in error stack Report all error parameters to Service	A36		E	1
F6F07A	LSB-BTB6: System error OS-CPU0 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A36		E	2
F6F080	LSB-BTB6: System error OS-CPU0 Fatal internal error Entry in error stack Report all error parameters to Service	A36		E	1
F6F082	LSB-BTB6: System error OS-CPU0 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A36		E	1
F6F0AC	LSB-BTB6: System error OS-CPU0 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A36		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6F0C1	LSB-BTB6: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A36		E	1
F6F0D2	LSB-BTB6: System error OS-CPU0 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A36		E	2
F6F102	LSB-BTB6: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A36		E	1
F6F113	LSB-BTB6: System error OS-CPU1 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A36		E	1
F6F116	LSB-BTB6: System error OS-CPU1 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A36		E	1
F6F150	LSB-BTB6: System error OS-CPU1 file not available error report Reload application software	A36		E	2
F6F168	LSB-BTB6: System error OS-CPU1 impermissible interrupt Entry in error stack Report all error parameters to Service	A36		E	1
F6F170	LSB-BTB6: System error OS-CPU1 various structure versions Entry in error stack Report all error parameters to Service	A36		E	1
F6F173	LSB-BTB6: System error OS-CPU1 interpreter error Entry in error stack At P0=00000013 carry out download	A36		E	1
F6F175	LSB-BTB6: System error OS-CPU1 SPI-error Entry in error stack Report all error parameters to Service	A36		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6F178	LSB-BTB6: System error OS-CPU1 impermissible parameter Entry in error stack Report all error parameters to Service	A36		E	1
F6F17A	LSB-BTB6: System error OS-CPU1 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A36		E	2
F6F180	LSB-BTB6: System error OS-CPU1 Fatal internal error Entry in error stack Report all error parameters to Service	A36		E	1
F6F182	LSB-BTB6: System error OS-CPU1 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A36		E	1
F6F1AC	LSB-BTB6: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A36		E	1
F6F1C1	LSB-BTB6: System error OS-CPU1 Incorrect or wrong system version for application error report Reload matching system version	A36		E	1
F6F1D2	LSB-BTB6: System error OS-CPU1 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A36		E	2
F6F800	LSB-BTB6: Control data transfer CAN EP0 internal error at Register-check Controller CAN-transfer is not started replace control device	A36.X3:7/8/3/3		E	2
F6F801	LSB-BTB6: Control data transfer CAN EP0 internal error at RAM-check Controller CAN-transfer is not started replace control device	A36.X3:7/8/3/3		E	2
F6F802	LSB-BTB6: Control data transfer CAN EP0 Configuration error Software Error message, CAN report is not configured Check software	A36.X3:7/8/3/3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6F804	LSB-BTB6: Control data transfer CAN EP0 Configuration error time synchronization Time synchronization already active or is not configured Check software	A36.X3:7/8/3/3		E	1
F6F805	LSB-BTB6: Control data transfer CAN EP0 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A36.X3:7/8/3/3		E	1
F6F806	LSB-BTB6: Control data transfer CAN EP0 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A36.X3:7/8/3/3		E	2
F6F807	LSB-BTB6: Control data transfer CAN EP0 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A36.X3:7/8/3/3		E	1
F6F811	LSB-BTB6: Control data transfer CAN EP0 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A36.X3:7/8/3/3		E	2
F6F900	LSB-BTB6: Control data transfer CAN EP1 internal error at Register-check Controller CAN-transfer is not started replace control device	A36.X4:1/2/14/1 3		E	2
F6F901	LSB-BTB6: Control data transfer CAN EP1 internal error at RAM-check Controller CAN-transfer is not started replace control device	A36.X4:1/2/14/1 3		E	2
F6F902	LSB-BTB6: Control data transfer CAN EP1 Configuration error Software Error message, CAN report is not configured Check software	A36.X4:1/2/14/1 3		E	1
F6F904	LSB-BTB6: Control data transfer CAN EP1 Configuration error time synchronization Time synchronization already active or is not configured Check software	A36.X4:1/2/14/1 3		E	1
F6F905	LSB-BTB6: Control data transfer CAN EP1 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A36.X4:1/2/14/1 3		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6F906	LSB-BTB6: Control data transfer CAN EP1 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A36.X4:1/2/14/1 3		E	2
F6F907	LSB-BTB6: Control data transfer CAN EP1 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A36.X4:1/2/14/1 3		E	1
F6F911	LSB-BTB6: Control data transfer CAN EP1 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A36.X4:1/2/14/1 3		E	2
F6FA00	LSB-BTB6: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A36.X3:7/8		E	1
F6FA01	LSB-BTB6: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A36.X3:7/8		E	1
F6FA02	LSB-BTB6: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A36.X3:7/8		E	1
F6FA04	LSB-BTB6: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A36.X3:7/8		E	1
F6FA05	LSB-BTB6: Control data transfer CAN-A Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A36.X3:7/8		E	1
F6FA06	LSB-BTB6: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A36.X3:7/8		E	2
F6FA11	LSB-BTB6: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A36.X3:7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6FA32	LSB-BTB6: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A36.X3:7/8		E	1
F6FA40	LSB-BTB6: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A36.X3:7/8		E	1
F6FA41	LSB-BTB6: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A36.X3:7/8		E	1
F6FB00	LSB-BTB6: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A36.X3:3/4		E	1
F6FB01	LSB-BTB6: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A36.X3:3/4		E	1
F6FB02	LSB-BTB6: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A36.X3:3/4		E	1
F6FB04	LSB-BTB6: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A36.X3:3/4		E	1
F6FB05	LSB-BTB6: Control data transfer CAN-B Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A36.X3:3/4		E	1
F6FB06	LSB-BTB6: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A36.X3:3/4		E	2
F6FB11	LSB-BTB6: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A36.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6FB32	LSB-BTB6: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A36.X3:3/4		E	1
F6FB40	LSB-BTB6: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A36.X3:3/4		E	1
F6FB41	LSB-BTB6: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A36.X3:3/4		E	1
F6FC00	LSB-BTB6: Control data transfer CAN-C internal error at Register-check Controller CAN-transfer is not started replace control device	A36.X4:1/2		E	1
F6FC01	LSB-BTB6: Control data transfer CAN-C internal error at RAM-check Controller CAN-transfer is not started replace control device	A36.X4:1/2		E	1
F6FC02	LSB-BTB6: Control data transfer CAN-C Configuration error Software Error message, CAN report is not configured Check software	A36.X4:1/2		E	1
F6FC04	LSB-BTB6: Control data transfer CAN-C Configuration error time synchronization Time synchronization already active or is not configured Check software	A36.X4:1/2		E	1
F6FC05	LSB-BTB6: Control data transfer CAN-C Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A36.X4:1/2		E	1
F6FC06	LSB-BTB6: Control data transfer CAN-C fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A36.X4:1/2		E	2
F6FC11	LSB-BTB6: Control data transfer CAN-C permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A36.X4:1/2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6FC32	LSB-BTB6: Control data transfer CAN-C Data transfer erroneous/missing check wiring	A36.X4:1/2		E	1
F6FC40	LSB-BTB6: Control data transfer CAN-C Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A36.X4:1/2		E	1
F6FC41	LSB-BTB6: Control data transfer CAN-C Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A36.X4:1/2		E	1
F6FD00	LSB-BTB6: Control data transfer CAN-D internal error at Register-check Controller CAN-transfer is not started replace control device	A36.X4:14/13		E	1
F6FD01	LSB-BTB6: Control data transfer CAN-D internal error at RAM-check Controller CAN-transfer is not started replace control device	A36.X4:14/13		E	1
F6FD02	LSB-BTB6: Control data transfer CAN-D Configuration error Software Error message, CAN report is not configured Check software	A36.X4:14/13		E	1
F6FD04	LSB-BTB6: Control data transfer CAN-D Configuration error time synchronization Time synchronization already active or is not configured Check software	A36.X4:14/13		E	1
F6FD05	LSB-BTB6: Control data transfer CAN-D Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A36.X4:14/13		E	1
F6FD06	LSB-BTB6: Control data transfer CAN-D fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A36.X4:14/13		E	2
F6FD11	LSB-BTB6: Control data transfer CAN-D permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A36.X4:14/13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F6FD32	LSB-BTB6: Control data transfer CAN-D Data transfer erroneous/missing check wiring	A36.X4:14/13		E	1
F6FD40	LSB-BTB6: Control data transfer CAN-D Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A36.X4:14/13		E	1
F6FD41	LSB-BTB6: Control data transfer CAN-D Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A36.X4:14/13		E	1
F7016A	LSB-BTB7: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7016C	LSB-BTB7: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7036A	LSB-BTB7: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7036C	LSB-BTB7: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7046A	LSB-BTB7: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7046C	LSB-BTB7: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7056A	LSB-BTB7: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7056C	LSB-BTB7: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7066A	LSB-BTB7: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7066C	LSB-BTB7: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7076A	LSB-BTB7: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7076C	LSB-BTB7: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7086A	LSB-BTB7: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7086C	LSB-BTB7: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7096A	LSB-BTB7: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7096C	LSB-BTB7: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F70A6A	LSB-BTB7: LSBA Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F70A6C	LSB-BTB7: LSBA Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F70B6A	LSB-BTB7: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F70B6C	LSB-BTB7: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F70C6A	LSB-BTB7: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F70C6C	LSB-BTB7: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F70D6A	LSB-BTB7: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F70D6C	LSB-BTB7: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F70E6A	LSB-BTB7: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F70E6C	LSB-BTB7: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7106A	LSB-BTB7: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7106C	LSB-BTB7: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7136A	LSB-BTB7: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7136C	LSB-BTB7: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7146A	LSB-BTB7: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7146C	LSB-BTB7: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7156A	LSB-BTB7: LSBA Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7156C	LSB-BTB7: LSBA Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7166A	LSB-BTB7: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7166C	LSB-BTB7: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7176A	LSB-BTB7: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7176C	LSB-BTB7: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7186A	LSB-BTB7: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7186C	LSB-BTB7: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7196A	LSB-BTB7: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F7196C	LSB-BTB7: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F71A6A	LSB-BTB7: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F71A6C	LSB-BTB7: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F71B6A	LSB-BTB7: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F71B6C	LSB-BTB7: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F71C6A	LSB-BTB7: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F71C6C	LSB-BTB7: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F71D6A	LSB-BTB7: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F71D6C	LSB-BTB7: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F71E6A	LSB-BTB7: LSBA Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:12		E	2
F71E6C	LSB-BTB7: LSBA Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:12		E	2
F7205B	LSB-BTB7: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A37.X4:12		E	2
F7316A	LSB-BTB7: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7316C	LSB-BTB7: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7336A	LSB-BTB7: LSBB Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7336C	LSB-BTB7: LSBB Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7346A	LSB-BTB7: LSBB Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7346C	LSB-BTB7: LSBB Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7356A	LSB-BTB7: LSBB Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7356C	LSB-BTB7: LSBB Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7366A	LSB-BTB7: LSBB Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7366C	LSB-BTB7: LSBB Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7376A	LSB-BTB7: LSBB Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7376C	LSB-BTB7: LSBB Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7386A	LSB-BTB7: LSBB Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7386C	LSB-BTB7: LSBB Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7396A	LSB-BTB7: LSBB Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7396C	LSB-BTB7: LSBB Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F73A6A	LSB-BTB7: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F73A6C	LSB-BTB7: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F73B6A	LSB-BTB7: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F73B6C	LSB-BTB7: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F73C6A	LSB-BTB7: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F73C6C	LSB-BTB7: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F73D6A	LSB-BTB7: LSBB Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F73D6C	LSB-BTB7: LSBB Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F73E6A	LSB-BTB7: LSBB Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F73E6C	LSB-BTB7: LSBB Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F73F6A	LSB-BTB7: LSBB Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F73F6C	LSB-BTB7: LSBB Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7406A	LSB-BTB7: LSBB Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7406C	LSB-BTB7: LSBB Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7416A	LSB-BTB7: LSBB Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7416C	LSB-BTB7: LSBB Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7426A	LSB-BTB7: LSBB Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7426C	LSB-BTB7: LSBB Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7436A	LSB-BTB7: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7436C	LSB-BTB7: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7446A	LSB-BTB7: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7446C	LSB-BTB7: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7456A	LSB-BTB7: LSBB Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7456C	LSB-BTB7: LSBB Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7466A	LSB-BTB7: LSBB Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7466C	LSB-BTB7: LSBB Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7476A	LSB-BTB7: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7476C	LSB-BTB7: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7486A	LSB-BTB7: LSBB Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7486C	LSB-BTB7: LSBB Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7496A	LSB-BTB7: LSBB Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F7496C	LSB-BTB7: LSBB Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F74A6A	LSB-BTB7: LSBB Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F74A6C	LSB-BTB7: LSBB Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F74B6A	LSB-BTB7: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F74B6C	LSB-BTB7: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F74C6A	LSB-BTB7: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F74C6C	LSB-BTB7: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F74D6A	LSB-BTB7: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A37.X4:9		E	2
F74D6C	LSB-BTB7: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A37.X4:9		E	2
F7505B	LSB-BTB7: Control data transfer LSBB Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A37.X4:9		E	2
F75B07	LSB-BTB7: Operation ballasting / counterweight carriage Shut-down keys support BW "Up" / "Down" actuated simultaneously Function blocked Release all buttons; check buttons, wiring	A37		E	1
F75B34	LSB-BTB7: Operation ballasting / counterweight carriage Switch-off key support "Up" clamping or actuated with start	A37		E	1
F75B35	LSB-BTB7: Operation ballasting / counterweight carriage Switch-off key support "Down" clamping or actuated with start	A37		E	1
F75BAF	LSB-BTB7: Operation ballasting / counterweight carriage Simultaneous actuation in crane cab and extern Error output Operate only from one op. location	A37		E	1
F75BCE	LSB-BTB7: Operation ballasting / counterweight carriage Button pressure supply ballast hoist cyl. actuated at start or stuck Function blocked Release all buttons; check buttons, wiring	A37		B	
F75BCF	LSB-BTB7: Operation ballasting / counterweight carriage Button pressure supply BW/push out cyl. actuated at start or stuck Function blocked Release all buttons; check buttons, wiring	A37		B	
F75BDA	LSB-BTB7: Operation ballasting / counterweight carriage Button pressure supply wheel sets BT actuated at start or stuck Function blocked Release all buttons; check buttons, wiring	A37		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F75BDB	LSB-BTB7: Operation ballasting / counterweight carriage Button pressure supply support BT actuated at start or stuck Function blocked Release all buttons; check buttons, wiring	A37		E	1
F75BDC	LSB-BTB7: Operation ballasting / counterweight carriage Button towing BT actuated at start or stuck Function blocked Release all buttons; check buttons, wiring	A37		E	1
F75BDD	LSB-BTB7: Operation ballasting / counterweight carriage Button turning with BT actuated at start or stuck Function blocked Release all buttons; check buttons, wiring	A37		E	1
F75BDE	LSB-BTB7: Operation ballasting / counterweight carriage Button parallel travel BT actuated at start or stuck Error issue function blocked Operate only from one op. location	A37		E	1
F75BE0	LSB-BTB7: Operation ballasting / counterweight carriage Shut off button signal on inputs not two-channel Function blocked Release all buttons; check buttons, wiring	A37		E	1
F75BE3	LSB-BTB7: Operation ballasting / counterweight carriage Key switch BT lifted off at start actuated or stuck Output of error, crane function is not selected. Key switch in zero pos.	A37		B	
F75BE4	LSB-BTB7: Operation ballasting / counterweight carriage Button Driving free with BT emerg. Op. at start actuated or stuck Output of error, crane function is not selected. Button in zero pos.	A37		B	
F75BE5	LSB-BTB7: Operation ballasting / counterweight carriage Taster Turning free with BT emerg. Op. at start actuated or stuck Output of error, crane function is not selected. Button in zero pos.	A37		B	
F75C36	LSB-BTB7: Control ballasting / counterweight carriage Shut off pressure supply at movement without actuation Operational shut off of pressure supply Check valves, wiring, if short circuit after Plus on valve or valve terminal	A37		E	
F75E4D	LSB-BTB7: crane control Monitoring Release Pinning, Short circuit after Plus error report Check signal line for short circuit. Check wiring, switch on valve	A37		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F75E4E	LSB-BTB7: crane control Monitoring Release Pinning, interruption/Short circuit after ground error report Check signal line for interruption, check wiring, switch on valve. Replace valve	A37		E	
F762C5	LSB-BTB7: Control hydraulic Valve assembly cylinder up/down stuck error report Replace valve Assembly cylinder up/ down	A37		E	
F762C6	LSB-BTB7: Control hydraulic Pressure supply turntable has leakage error report Leckage suchen	A37		E	
F762C7	LSB-BTB7: Control hydraulic Valve assembly winch up/down stuck error report Replace valve assembly winch up / down	A37		E	
F762C8	LSB-BTB7: Control hydraulic Valve swing cab in / out stuck error report Valve swing cab ein / aus tauschen	A37		E	
F762C9	LSB-BTB7: Control hydraulic Valve tilt cab up / down stuck error report Valve tilt cab auf / ab tauschen	A37		E	
F762CA	LSB-BTB7: Control hydraulic Valve ladder up / down stuck error report Replace valve Ladder up / down	A37		E	
F762CB	LSB-BTB7: Control hydraulic Valve support center section up / down stuck error report Replace valve Support center section up / down	A37		E	
F762CC	LSB-BTB7: Control hydraulic Valve pinning / unpinning stuck error report Replace valve pin / unpin	A37		E	
F77007	LSB-BTB7: remote control Zero position compulsion on radio MS	A37		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F77019	LSB-BTB7: remote control No radio release (electrical signal not available) No movements possible via radio control Check electr.line	A37		E	1
F77090	LSB-BTB7: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A37		E	1
F79900	LSB-BTB7: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A37		E	2
F79901	LSB-BTB7: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A37		E	2
F79902	LSB-BTB7: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A37		E	1
F79904	LSB-BTB7: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A37		E	1
F79905	LSB-BTB7: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A37		E	1
F79906	LSB-BTB7: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A37		E	2
F79907	LSB-BTB7: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A37		E	1
F79911	LSB-BTB7: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A37		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7C218	LSB-BTB7: Hardware excess temperature Entry in error stack Replace LSB-Module	A37		E	2
F7C21B	LSB-BTB7: Hardware digital shut off defective Entry in error stack Report all error parameters to Service	A37		E	2
F7C21F	LSB-BTB7: Hardware After run logic defective Entry in error stack Report all error parameters to Service	A37		E	2
F7C226	LSB-BTB7: Hardware Under temperature Entry in error stack Replace LSB-Module	A37		E	2
F7C261	LSB-BTB7: Hardware measuring system defect Entry in error stack Replace LSB-Module	A37		E	2
F7C504	LSB-BTB7: System voltage Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A37		E	2
F7C505	LSB-BTB7: System voltage Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A37		E	2
F7C50F	LSB-BTB7: System voltage Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A37		E	2
F7C604	LSB-BTB7: System voltage CPU/Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A37		E	2
F7C605	LSB-BTB7: System voltage CPU/Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A37		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7C60F	LSB-BTB7: System voltage CPU/Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A37		E	2
F7C704	LSB-BTB7: Supply voltage 30 (A0-7) / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A37.X1:2/3		E	2
F7C705	LSB-BTB7: Supply voltage 30 (A0-7) / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A37.X1:2/3		E	2
F7C804	LSB-BTB7: Supply voltage 15.1 / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A37.X1:1		E	2
F7C805	LSB-BTB7: Supply voltage 15.1 / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A37.X1:1		E	2
F7C80F	LSB-BTB7: Supply voltage 15.1 / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A37.X1:1		E	2
F7CC04	LSB-BTB7: System voltage Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A37		E	2
F7CC05	LSB-BTB7: System voltage Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A37		E	2
F7CC0F	LSB-BTB7: System voltage Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A37		E	2
F7CD04	LSB-BTB7: System voltage CPU/Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A37		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7CD05	LSB-BTB7: System voltage CPU/Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A37		E	2
F7CD0F	LSB-BTB7: System voltage CPU/Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A37		E	2
F7CE04	LSB-BTB7: Supply voltage 30 (A8-15) / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A37.X2:2/3		E	2
F7CE05	LSB-BTB7: Supply voltage 30 (A8-15) / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A37.X2:2/3		E	2
F7CF04	LSB-BTB7: Supply voltage 15.1 / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A37.X2:1		E	2
F7CF05	LSB-BTB7: Supply voltage 15.1 / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A37.X2:1		E	2
F7CF0F	LSB-BTB7: Supply voltage 15.1 / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A37.X2:1		E	2
F7D004	LSB-BTB7: Digital input E0 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:4		E	2
F7D005	LSB-BTB7: Digital input E0 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:4		E	2
F7D104	LSB-BTB7: Digital input E1 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:5		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7D105	LSB-BTB7: Digital input E1 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:5		E	2
F7D204	LSB-BTB7: Digital input E2 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:6		E	2
F7D205	LSB-BTB7: Digital input E2 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:6		E	2
F7D304	LSB-BTB7: Digital input E3 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:7		E	2
F7D305	LSB-BTB7: Digital input E3 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:7		E	2
F7D354	LSB-BTB7: Digital input E3 short circuit to supply voltage	A37.X1:7		E	1
F7D356	LSB-BTB7: Digital input E3 open circuit or short circuit to ground	A37.X1:7		E	1
F7D454	LSB-BTB7: Digital input E4 short circuit to supply voltage	A37.X1:8		E	1
F7D456	LSB-BTB7: Digital input E4 open circuit or short circuit to ground	A37.X1:8		E	1
F7D804	LSB-BTB7: Digital input E8 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:4		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7D805	LSB-BTB7: Digital input E8 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:4		E	2
F7D904	LSB-BTB7: Digital input E9 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:5		E	2
F7D905	LSB-BTB7: Digital input E9 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:5		E	2
F7DA04	LSB-BTB7: Digital input E10 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:6		E	2
F7DA05	LSB-BTB7: Digital input E10 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:6		E	2
F7DB04	LSB-BTB7: Digital input E11 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:7		E	2
F7DB05	LSB-BTB7: Digital input E11 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:7		E	2
F7DB54	LSB-BTB7: Digital input E11 short circuit to supply voltage	A37.X2:7		E	1
F7DB56	LSB-BTB7: Digital input E11 open circuit or short circuit to ground	A37.X2:7		E	1
F7DC54	LSB-BTB7: Digital input E12 short circuit to supply voltage	A37.X2:8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7DC56	LSB-BTB7: Digital input E12 open circuit or short circuit to ground	A37.X2:8		E	1
F7E012	LSB-BTB7: Switching output A0 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:12		E	2
F7E015	LSB-BTB7: Switching output A0 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:12		E	2
F7E01D	LSB-BTB7: Switching output A0 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X1:12		E	2
F7E054	LSB-BTB7: Switching output A0 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:12		E	2
F7E072	LSB-BTB7: Switching output A0 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:12		E	2
F7E112	LSB-BTB7: Switching output A1 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:13		E	2
F7E115	LSB-BTB7: Switching output A1 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:13		E	2
F7E11D	LSB-BTB7: Switching output A1 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X1:13		E	2
F7E154	LSB-BTB7: Switching output A1 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7E172	LSB-BTB7: Switching output A1 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:13		E	2
F7E212	LSB-BTB7: Switching output A2 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:14		E	2
F7E215	LSB-BTB7: Switching output A2 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:14		E	2
F7E21D	LSB-BTB7: Switching output A2 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X1:14		E	2
F7E254	LSB-BTB7: Switching output A2 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:14		E	2
F7E272	LSB-BTB7: Switching output A2 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:14		E	2
F7E312	LSB-BTB7: Switching output A3 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:15		E	2
F7E315	LSB-BTB7: Switching output A3 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:15		E	2
F7E31D	LSB-BTB7: Switching output A3 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X1:15		E	2
F7E354	LSB-BTB7: Switching output A3 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7E372	LSB-BTB7: Switching output A3 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:15		E	2
F7E412	LSB-BTB7: Switching output A4 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:16		E	2
F7E415	LSB-BTB7: Switching output A4 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:16		E	2
F7E41D	LSB-BTB7: Switching output A4 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X1:16		E	2
F7E454	LSB-BTB7: Switching output A4 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:16		E	2
F7E472	LSB-BTB7: Switching output A4 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:16		E	2
F7E512	LSB-BTB7: Switching output A5 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:17		E	2
F7E515	LSB-BTB7: Switching output A5 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:17		E	2
F7E51D	LSB-BTB7: Switching output A5 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X1:17		E	2
F7E554	LSB-BTB7: Switching output A5 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:17		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7E572	LSB-BTB7: Switching output A5 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:17		E	2
F7E612	LSB-BTB7: Switching output A6 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:18		E	2
F7E615	LSB-BTB7: Switching output A6 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:18		E	2
F7E61D	LSB-BTB7: Switching output A6 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X1:18		E	2
F7E654	LSB-BTB7: Switching output A6 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:18		E	2
F7E672	LSB-BTB7: Switching output A6 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:18		E	2
F7E712	LSB-BTB7: Switching output A7 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:19		E	2
F7E715	LSB-BTB7: Switching output A7 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:19		E	2
F7E71D	LSB-BTB7: Switching output A7 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X1:19		E	2
F7E754	LSB-BTB7: Switching output A7 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:19		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7E772	LSB-BTB7: Switching output A7 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X1:19		E	2
F7E812	LSB-BTB7: Switching output A8 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:12		E	2
F7E815	LSB-BTB7: Switching output A8 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:12		E	2
F7E81D	LSB-BTB7: Switching output A8 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X2:12		E	2
F7E854	LSB-BTB7: Switching output A8 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:12		E	2
F7E872	LSB-BTB7: Switching output A8 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:12		E	2
F7E912	LSB-BTB7: Switching output A9 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:13		E	2
F7E915	LSB-BTB7: Switching output A9 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:13		E	2
F7E91D	LSB-BTB7: Switching output A9 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X2:13		E	2
F7E954	LSB-BTB7: Switching output A9 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7E972	LSB-BTB7: Switching output A9 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:13		E	2
F7EA12	LSB-BTB7: Switching output A10 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:14		E	2
F7EA15	LSB-BTB7: Switching output A10 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:14		E	2
F7EA1D	LSB-BTB7: Switching output A10 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X2:14		E	2
F7EA54	LSB-BTB7: Switching output A10 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:14		E	2
F7EA72	LSB-BTB7: Switching output A10 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:14		E	2
F7EB12	LSB-BTB7: Switching output A11 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:15		E	2
F7EB15	LSB-BTB7: Switching output A11 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:15		E	2
F7EB1D	LSB-BTB7: Switching output A11 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X2:15		E	2
F7EB54	LSB-BTB7: Switching output A11 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7EB72	LSB-BTB7: Switching output A11 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:15		E	2
F7EC12	LSB-BTB7: Switching output A12 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:16		E	2
F7EC15	LSB-BTB7: Switching output A12 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:16		E	2
F7EC1D	LSB-BTB7: Switching output A12 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X2:16		E	2
F7EC54	LSB-BTB7: Switching output A12 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:16		E	2
F7EC72	LSB-BTB7: Switching output A12 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:16		E	2
F7ED12	LSB-BTB7: Switching output A13 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:17		E	2
F7ED15	LSB-BTB7: Switching output A13 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:17		E	2
F7ED1D	LSB-BTB7: Switching output A13 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X2:17		E	2
F7ED54	LSB-BTB7: Switching output A13 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:17		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7ED72	LSB-BTB7: Switching output A13 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:17		E	2
F7EE12	LSB-BTB7: Switching output A14 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:18		E	2
F7EE15	LSB-BTB7: Switching output A14 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:18		E	2
F7EE1D	LSB-BTB7: Switching output A14 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X2:18		E	2
F7EE54	LSB-BTB7: Switching output A14 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:18		E	2
F7EE72	LSB-BTB7: Switching output A14 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:18		E	2
F7EF12	LSB-BTB7: Switching output A15 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:19		E	2
F7EF15	LSB-BTB7: Switching output A15 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:19		E	2
F7EF1D	LSB-BTB7: Switching output A15 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A37.X2:19		E	2
F7EF54	LSB-BTB7: Switching output A15 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:19		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7EF72	LSB-BTB7: Switching output A15 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A37.X2:19		E	2
F7F002	LSB-BTB7: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A37		E	1
F7F013	LSB-BTB7: System error OS-CPU0 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A37		E	1
F7F016	LSB-BTB7: System error OS-CPU0 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A37		E	1
F7F050	LSB-BTB7: System error OS-CPU0 file not available error report Reload application software	A37		E	2
F7F068	LSB-BTB7: System error OS-CPU0 impermissible interrupt Entry in error stack Report all error parameters to Service	A37		E	1
F7F070	LSB-BTB7: System error OS-CPU0 various structure versions Entry in error stack Report all error parameters to Service	A37		E	1
F7F073	LSB-BTB7: System error OS-CPU0 interpreter error Entry in error stack At P0=00000013 carry out download	A37		E	1
F7F075	LSB-BTB7: System error OS-CPU0 SPI-error Entry in error stack Report all error parameters to Service	A37		E	1
F7F078	LSB-BTB7: System error OS-CPU0 impermissible parameter Entry in error stack Report all error parameters to Service	A37		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7F07A	LSB-BTB7: System error OS-CPU0 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A37		E	2
F7F080	LSB-BTB7: System error OS-CPU0 Fatal internal error Entry in error stack Report all error parameters to Service	A37		E	1
F7F082	LSB-BTB7: System error OS-CPU0 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A37		E	1
F7F0AC	LSB-BTB7: System error OS-CPU0 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A37		E	1
F7F0C1	LSB-BTB7: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A37		E	1
F7F0D2	LSB-BTB7: System error OS-CPU0 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A37		E	2
F7F102	LSB-BTB7: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A37		E	1
F7F113	LSB-BTB7: System error OS-CPU1 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A37		E	1
F7F116	LSB-BTB7: System error OS-CPU1 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A37		E	1
F7F150	LSB-BTB7: System error OS-CPU1 file not available error report Reload application software	A37		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7F168	LSB-BTB7: System error OS-CPU1 impermissible interrupt Entry in error stack Report all error parameters to Service	A37		E	1
F7F170	LSB-BTB7: System error OS-CPU1 various structure versions Entry in error stack Report all error parameters to Service	A37		E	1
F7F173	LSB-BTB7: System error OS-CPU1 interpreter error Entry in error stack At P0=00000013 carry out download	A37		E	1
F7F175	LSB-BTB7: System error OS-CPU1 SPI-error Entry in error stack Report all error parameters to Service	A37		E	1
F7F178	LSB-BTB7: System error OS-CPU1 impermissible parameter Entry in error stack Report all error parameters to Service	A37		E	1
F7F17A	LSB-BTB7: System error OS-CPU1 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A37		E	2
F7F180	LSB-BTB7: System error OS-CPU1 Fatal internal error Entry in error stack Report all error parameters to Service	A37		E	1
F7F182	LSB-BTB7: System error OS-CPU1 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A37		E	1
F7F1AC	LSB-BTB7: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A37		E	1
F7F1C1	LSB-BTB7: System error OS-CPU1 Incorrect or wrong system version for application error report Reload matching system version	A37		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7F1D2	LSB-BTB7: System error OS-CPU1 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A37		E	2
F7F800	LSB-BTB7: Control data transfer CAN EP0 internal error at Register-check Controller CAN-transfer is not started replace control device	A37.X3:7/8/3/3		E	2
F7F801	LSB-BTB7: Control data transfer CAN EP0 internal error at RAM-check Controller CAN-transfer is not started replace control device	A37.X3:7/8/3/3		E	2
F7F802	LSB-BTB7: Control data transfer CAN EP0 Configuration error Software Error message, CAN report is not configured Check software	A37.X3:7/8/3/3		E	1
F7F804	LSB-BTB7: Control data transfer CAN EP0 Configuration error time synchronization Time synchronization already active or is not configured Check software	A37.X3:7/8/3/3		E	1
F7F805	LSB-BTB7: Control data transfer CAN EP0 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A37.X3:7/8/3/3		E	1
F7F806	LSB-BTB7: Control data transfer CAN EP0 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A37.X3:7/8/3/3		E	2
F7F807	LSB-BTB7: Control data transfer CAN EP0 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A37.X3:7/8/3/3		E	1
F7F811	LSB-BTB7: Control data transfer CAN EP0 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A37.X3:7/8/3/3		E	2
F7F900	LSB-BTB7: Control data transfer CAN EP1 internal error at Register-check Controller CAN-transfer is not started replace control device	A37.X4:1/2/14/1 3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7F901	LSB-BTB7: Control data transfer CAN EP1 internal error at RAM-check Controller CAN-transfer is not started replace control device	A37.X4:1/2/14/1 3		E	2
F7F902	LSB-BTB7: Control data transfer CAN EP1 Configuration error Software Error message, CAN report is not configured Check software	A37.X4:1/2/14/1 3		E	1
F7F904	LSB-BTB7: Control data transfer CAN EP1 Configuration error time synchronization Time synchronization already active or is not configured Check software	A37.X4:1/2/14/1 3		E	1
F7F905	LSB-BTB7: Control data transfer CAN EP1 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A37.X4:1/2/14/1 3		E	1
F7F906	LSB-BTB7: Control data transfer CAN EP1 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A37.X4:1/2/14/1 3		E	2
F7F907	LSB-BTB7: Control data transfer CAN EP1 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A37.X4:1/2/14/1 3		E	1
F7F911	LSB-BTB7: Control data transfer CAN EP1 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A37.X4:1/2/14/1 3		E	2
F7FA00	LSB-BTB7: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A37.X3:7/8		E	1
F7FA01	LSB-BTB7: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A37.X3:7/8		E	1
F7FA02	LSB-BTB7: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A37.X3:7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7FA04	LSB-BTB7: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A37.X3:7/8		E	1
F7FA05	LSB-BTB7: Control data transfer CAN-A Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A37.X3:7/8		E	1
F7FA06	LSB-BTB7: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A37.X3:7/8		E	2
F7FA11	LSB-BTB7: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A37.X3:7/8		E	1
F7FA32	LSB-BTB7: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A37.X3:7/8		E	1
F7FA40	LSB-BTB7: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A37.X3:7/8		E	1
F7FA41	LSB-BTB7: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A37.X3:7/8		E	1
F7FB00	LSB-BTB7: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A37.X3:3/4		E	1
F7FB01	LSB-BTB7: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A37.X3:3/4		E	1
F7FB02	LSB-BTB7: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A37.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7FB04	LSB-BTB7: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A37.X3:3/4		E	1
F7FB05	LSB-BTB7: Control data transfer CAN-B Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A37.X3:3/4		E	1
F7FB06	LSB-BTB7: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A37.X3:3/4		E	2
F7FB11	LSB-BTB7: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A37.X3:3/4		E	1
F7FB32	LSB-BTB7: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A37.X3:3/4		E	1
F7FB40	LSB-BTB7: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A37.X3:3/4		E	1
F7FB41	LSB-BTB7: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A37.X3:3/4		E	1
F7FC00	LSB-BTB7: Control data transfer CAN-C internal error at Register-check Controller CAN-transfer is not started replace control device	A37.X4:1/2		E	1
F7FC01	LSB-BTB7: Control data transfer CAN-C internal error at RAM-check Controller CAN-transfer is not started replace control device	A37.X4:1/2		E	1
F7FC02	LSB-BTB7: Control data transfer CAN-C Configuration error Software Error message, CAN report is not configured Check software	A37.X4:1/2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7FC04	LSB-BTB7: Control data transfer CAN-C Configuration error time synchronization Time synchronization already active or is not configured Check software	A37.X4:1/2		E	1
F7FC05	LSB-BTB7: Control data transfer CAN-C Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A37.X4:1/2		E	1
F7FC06	LSB-BTB7: Control data transfer CAN-C fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A37.X4:1/2		E	2
F7FC11	LSB-BTB7: Control data transfer CAN-C permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A37.X4:1/2		E	1
F7FC32	LSB-BTB7: Control data transfer CAN-C Data transfer erroneous/missing check wiring	A37.X4:1/2		E	1
F7FC40	LSB-BTB7: Control data transfer CAN-C Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A37.X4:1/2		E	1
F7FC41	LSB-BTB7: Control data transfer CAN-C Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A37.X4:1/2		E	1
F7FD00	LSB-BTB7: Control data transfer CAN-D internal error at Register-check Controller CAN-transfer is not started replace control device	A37.X4:14/13		E	1
F7FD01	LSB-BTB7: Control data transfer CAN-D internal error at RAM-check Controller CAN-transfer is not started replace control device	A37.X4:14/13		E	1
F7FD02	LSB-BTB7: Control data transfer CAN-D Configuration error Software Error message, CAN report is not configured Check software	A37.X4:14/13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F7FD04	LSB-BTB7: Control data transfer CAN-D Configuration error time synchronization Time synchronization already active or is not configured Check software	A37.X4:14/13		E	1
F7FD05	LSB-BTB7: Control data transfer CAN-D Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A37.X4:14/13		E	1
F7FD06	LSB-BTB7: Control data transfer CAN-D fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A37.X4:14/13		E	2
F7FD11	LSB-BTB7: Control data transfer CAN-D permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A37.X4:14/13		E	1
F7FD32	LSB-BTB7: Control data transfer CAN-D Data transfer erroneous/missing check wiring	A37.X4:14/13		E	1
F7FD40	LSB-BTB7: Control data transfer CAN-D Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A37.X4:14/13		E	1
F7FD41	LSB-BTB7: Control data transfer CAN-D Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A37.X4:14/13		E	1
F8016A	LSB-BTB8: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F8016C	LSB-BTB8: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8056A	LSB-BTB8: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8056C	LSB-BTB8: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8066A	LSB-BTB8: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F8066C	LSB-BTB8: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F80B6A	LSB-BTB8: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F80B6C	LSB-BTB8: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F80C6A	LSB-BTB8: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F80C6C	LSB-BTB8: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F80D6A	LSB-BTB8: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F80D6C	LSB-BTB8: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F80E6A	LSB-BTB8: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F80E6C	LSB-BTB8: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F80F6A	LSB-BTB8: LSBA Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F80F6C	LSB-BTB8: LSBA Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8106A	LSB-BTB8: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F8106C	LSB-BTB8: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8116A	LSB-BTB8: LSBA Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F8116C	LSB-BTB8: LSBA Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8126A	LSB-BTB8: LSBA Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F8126C	LSB-BTB8: LSBA Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8166A	LSB-BTB8: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8166C	LSB-BTB8: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8176A	LSB-BTB8: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F8176C	LSB-BTB8: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8186A	LSB-BTB8: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F8186C	LSB-BTB8: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8196A	LSB-BTB8: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F8196C	LSB-BTB8: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F81A6A	LSB-BTB8: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F81A6C	LSB-BTB8: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F81B6A	LSB-BTB8: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F81B6C	LSB-BTB8: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F81C6A	LSB-BTB8: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F81C6C	LSB-BTB8: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F81D6A	LSB-BTB8: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F81D6C	LSB-BTB8: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F81E6A	LSB-BTB8: LSBA Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:12		E	2
F81E6C	LSB-BTB8: LSBA Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:12		E	2
F8205B	LSB-BTB8: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A38.X4:12		E	2
F8316A	LSB-BTB8: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8316C	LSB-BTB8: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8326A	LSB-BTB8: LSBB Participant Adr. 2 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8326C	LSB-BTB8: LSBB Participant Adr. 2 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8356A	LSB-BTB8: LSBB Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8356C	LSB-BTB8: LSBB Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8366A	LSB-BTB8: LSBB Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8366C	LSB-BTB8: LSBB Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8386A	LSB-BTB8: LSBB Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8386C	LSB-BTB8: LSBB Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F83A6A	LSB-BTB8: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F83A6C	LSB-BTB8: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F83B10	LSB-BTB8: LSBB Participant Adr. 11 inadmissible signal difference/plausability control defective	A38.X4:9		E	1
F83B11	LSB-BTB8: LSBB Participant Adr. 11 excess current recognition	A38.X4:9		E	1
F83B6A	LSB-BTB8: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F83B6C	LSB-BTB8: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F83C6A	LSB-BTB8: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F83C6C	LSB-BTB8: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F83D6A	LSB-BTB8: LSBB Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F83D6C	LSB-BTB8: LSBB Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F83E6A	LSB-BTB8: LSBB Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F83E6C	LSB-BTB8: LSBB Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F83F6A	LSB-BTB8: LSBB Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F83F6C	LSB-BTB8: LSBB Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8406A	LSB-BTB8: LSBB Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8406C	LSB-BTB8: LSBB Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8416A	LSB-BTB8: LSBB Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8416C	LSB-BTB8: LSBB Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8426A	LSB-BTB8: LSBB Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8426C	LSB-BTB8: LSBB Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8436A	LSB-BTB8: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8436C	LSB-BTB8: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8446A	LSB-BTB8: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8446C	LSB-BTB8: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8456A	LSB-BTB8: LSBB Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8456C	LSB-BTB8: LSBB Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8466A	LSB-BTB8: LSBB Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8466C	LSB-BTB8: LSBB Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8476A	LSB-BTB8: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8476C	LSB-BTB8: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F8496A	LSB-BTB8: LSBB Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F8496C	LSB-BTB8: LSBB Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F84A6A	LSB-BTB8: LSBB Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F84A6C	LSB-BTB8: LSBB Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F84B6A	LSB-BTB8: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F84B6C	LSB-BTB8: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F84C6A	LSB-BTB8: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F84C6C	LSB-BTB8: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F84D6A	LSB-BTB8: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F84D6C	LSB-BTB8: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2
F84E6A	LSB-BTB8: LSBB Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A38.X4:9		E	2
F84E6C	LSB-BTB8: LSBB Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A38.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8505B	LSB-BTB8: Control data transfer LSBB Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A38.X4:9		E	2
F85B05	LSB-BTB8: Operation ballasting / counterweight carriage Shut-down keys counterweight "Up" / "Down" actuated simultaneously	A38		E	1
F85B06	LSB-BTB8: Operation ballasting / counterweight carriage Shut-down keys counterweight "In" / "Out" actuated simultaneously	A38		E	1
F85B07	LSB-BTB8: Operation ballasting / counterweight carriage Shut-down keys support BW "Up" / "Down" actuated simultaneously Function blocked Release all buttons; check buttons, wiring	A38		E	1
F85B0A	LSB-BTB8: Operation ballasting / counterweight carriage Shut off button steering corr. BW left /right act. same time Error issue function blocked check wiring	A38		B	1
F85B34	LSB-BTB8: Operation ballasting / counterweight carriage Switch-off key support "Up" clamping or actuated with start Error issue function blocked check wiring	A38		B	1
F85B35	LSB-BTB8: Operation ballasting / counterweight carriage Switch-off key support "Down" clamping or actuated with start Error issue function blocked check wiring	A38		E	1
F85B36	LSB-BTB8: Operation ballasting / counterweight carriage Switch-off key BW steering system clamping or actuated with start Error issue function blocked check wiring	A38		E	1
F85BAD	LSB-BTB8: Operation ballasting / counterweight carriage Button Ballast UP/DOWN after Start/op. error actuated or stuck	A38		E	1
F85BB0	LSB-BTB8: Operation ballasting / counterweight carriage Button Ballast UP/DOWN blocked actuated after start or stuck	A38		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F85BCD	LSB-BTB8: Operation ballasting / counterweight carriage Button Ballast OUT/IN after start/op. error actuated or stuck Error issue function blocked check wiring	A38		B	1
F85BCE	LSB-BTB8: Operation ballasting / counterweight carriage Button pressure supply ballast hoist cyl. actuated at start or stuck Error issue function blocked check wiring	A38		B	1
F85BCF	LSB-BTB8: Operation ballasting / counterweight carriage Button pressure supply BW/push out cyl. actuated at start or stuck Error issue function blocked check wiring	A38		B	1
F85BDA	LSB-BTB8: Operation ballasting / counterweight carriage Button pressure supply wheel sets BT actuated at start or stuck	A38		E	1
F85BDB	LSB-BTB8: Operation ballasting / counterweight carriage Button pressure supply support BT actuated at start or stuck Function blocked Release all buttons; check buttons, wiring	A38		E	1
F85BE0	LSB-BTB8: Operation ballasting / counterweight carriage Shut off button signal on inputs not two-channel Function blocked Release all buttons; check buttons, wiring	A38		E	1
F85BE1	LSB-BTB8: Operation ballasting / counterweight carriage Button steering correction BW turn left actuated at start or stuck Error issue function blocked check wiring	A38		B	1
F85BE2	LSB-BTB8: Operation ballasting / counterweight carriage Button steering correction BW turn right actuated at start or klebt Error issue function blocked check wiring	A38		B	1
F85C10	LSB-BTB8: Control ballasting / counterweight carriage Module software not compatible to crane -> module needs update Error output and ballast trailer function locked Perform software update (update application) on the module BTB8.	A38		E	1
F85C1C	LSB-BTB8: Control ballasting / counterweight carriage Interruption bus connection(s)Actuation / release, zero force No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A38		B	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F89900	LSB-BTB8: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A38		E	2
F89901	LSB-BTB8: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A38		E	2
F89902	LSB-BTB8: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A38		E	1
F89904	LSB-BTB8: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A38		E	1
F89905	LSB-BTB8: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A38		E	1
F89906	LSB-BTB8: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A38		E	2
F89907	LSB-BTB8: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A38		E	1
F89911	LSB-BTB8: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A38		E	2
F8C218	LSB-BTB8: Hardware excess temperature Entry in error stack Replace LSB-Module	A38		E	2
F8C21B	LSB-BTB8: Hardware digital shut off defective Entry in error stack Report all error parameters to Service	A38		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8C21F	LSB-BTB8: Hardware After run logic defective Entry in error stack Report all error parameters to Service	A38		E	2
F8C226	LSB-BTB8: Hardware Under temperature Entry in error stack Replace LSB-Module	A38		E	2
F8C261	LSB-BTB8: Hardware measuring system defect Entry in error stack Replace LSB-Module	A38		E	2
F8C504	LSB-BTB8: System voltage Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A38		E	2
F8C505	LSB-BTB8: System voltage Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A38		E	2
F8C50F	LSB-BTB8: System voltage Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A38		E	2
F8C604	LSB-BTB8: System voltage CPU/Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A38		E	2
F8C605	LSB-BTB8: System voltage CPU/Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A38		E	2
F8C60F	LSB-BTB8: System voltage CPU/Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A38		E	2
F8C704	LSB-BTB8: Supply voltage 30 (A0-7) / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A38.X1:2/3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8C705	LSB-BTB8: Supply voltage 30 (A0-7) / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A38.X1:2/3		E	2
F8C804	LSB-BTB8: Supply voltage 15.1 / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A38.X1:1		E	2
F8C805	LSB-BTB8: Supply voltage 15.1 / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A38.X1:1		E	2
F8C80F	LSB-BTB8: Supply voltage 15.1 / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A38.X1:1		E	2
F8CC04	LSB-BTB8: System voltage Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A38		E	2
F8CC05	LSB-BTB8: System voltage Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A38		E	2
F8CC0F	LSB-BTB8: System voltage Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A38		E	2
F8CD04	LSB-BTB8: System voltage CPU/Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A38		E	2
F8CD05	LSB-BTB8: System voltage CPU/Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A38		E	2
F8CD0F	LSB-BTB8: System voltage CPU/Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A38		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8CE04	LSB-BTB8: Supply voltage 30 (A8-15) / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A38.X2:2/3		E	2
F8CE05	LSB-BTB8: Supply voltage 30 (A8-15) / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A38.X2:2/3		E	2
F8CF04	LSB-BTB8: Supply voltage 15.1 / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A38.X2:1		E	2
F8CF05	LSB-BTB8: Supply voltage 15.1 / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A38.X2:1		E	2
F8CF0F	LSB-BTB8: Supply voltage 15.1 / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A38.X2:1		E	2
F8D004	LSB-BTB8: Digital input E0 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:4		E	2
F8D005	LSB-BTB8: Digital input E0 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:4		E	2
F8D104	LSB-BTB8: Digital input E1 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:5		E	2
F8D105	LSB-BTB8: Digital input E1 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:5		E	2
F8D204	LSB-BTB8: Digital input E2 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8D205	LSB-BTB8: Digital input E2 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:6		E	2
F8D304	LSB-BTB8: Digital input E3 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:7		E	2
F8D305	LSB-BTB8: Digital input E3 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:7		E	2
F8D804	LSB-BTB8: Digital input E8 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:4		E	2
F8D805	LSB-BTB8: Digital input E8 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:4		E	2
F8D904	LSB-BTB8: Digital input E9 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:5		E	2
F8D905	LSB-BTB8: Digital input E9 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:5		E	2
F8DA04	LSB-BTB8: Digital input E10 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:6		E	2
F8DA05	LSB-BTB8: Digital input E10 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:6		E	2
F8DB04	LSB-BTB8: Digital input E11 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:7		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8DB05	LSB-BTB8: Digital input E11 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:7		E	2
F8E012	LSB-BTB8: Switching output A0 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:12		E	2
F8E015	LSB-BTB8: Switching output A0 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:12		E	2
F8E01D	LSB-BTB8: Switching output A0 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X1:12		E	2
F8E054	LSB-BTB8: Switching output A0 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:12		E	2
F8E072	LSB-BTB8: Switching output A0 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:12		E	2
F8E112	LSB-BTB8: Switching output A1 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:13		E	2
F8E115	LSB-BTB8: Switching output A1 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:13		E	2
F8E11D	LSB-BTB8: Switching output A1 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X1:13		E	2
F8E154	LSB-BTB8: Switching output A1 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8E172	LSB-BTB8: Switching output A1 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:13		E	2
F8E212	LSB-BTB8: Switching output A2 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:14		E	2
F8E215	LSB-BTB8: Switching output A2 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:14		E	2
F8E21D	LSB-BTB8: Switching output A2 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X1:14		E	2
F8E254	LSB-BTB8: Switching output A2 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:14		E	2
F8E272	LSB-BTB8: Switching output A2 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:14		E	2
F8E312	LSB-BTB8: Switching output A3 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:15		E	2
F8E315	LSB-BTB8: Switching output A3 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:15		E	2
F8E31D	LSB-BTB8: Switching output A3 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X1:15		E	2
F8E354	LSB-BTB8: Switching output A3 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8E372	LSB-BTB8: Switching output A3 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:15		E	2
F8E412	LSB-BTB8: Switching output A4 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:16		E	2
F8E415	LSB-BTB8: Switching output A4 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:16		E	2
F8E41D	LSB-BTB8: Switching output A4 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X1:16		E	2
F8E454	LSB-BTB8: Switching output A4 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:16		E	2
F8E472	LSB-BTB8: Switching output A4 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:16		E	2
F8E512	LSB-BTB8: Switching output A5 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:17		E	2
F8E515	LSB-BTB8: Switching output A5 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:17		E	2
F8E51D	LSB-BTB8: Switching output A5 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X1:17		E	2
F8E554	LSB-BTB8: Switching output A5 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:17		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8E572	LSB-BTB8: Switching output A5 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:17		E	2
F8E612	LSB-BTB8: Switching output A6 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:18		E	2
F8E615	LSB-BTB8: Switching output A6 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:18		E	2
F8E61D	LSB-BTB8: Switching output A6 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X1:18		E	2
F8E654	LSB-BTB8: Switching output A6 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:18		E	2
F8E672	LSB-BTB8: Switching output A6 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:18		E	2
F8E712	LSB-BTB8: Switching output A7 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:19		E	2
F8E715	LSB-BTB8: Switching output A7 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:19		E	2
F8E71D	LSB-BTB8: Switching output A7 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X1:19		E	2
F8E754	LSB-BTB8: Switching output A7 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:19		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8E772	LSB-BTB8: Switching output A7 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X1:19		E	2
F8E812	LSB-BTB8: Switching output A8 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:12		E	2
F8E815	LSB-BTB8: Switching output A8 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:12		E	2
F8E81D	LSB-BTB8: Switching output A8 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X2:12		E	2
F8E854	LSB-BTB8: Switching output A8 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:12		E	2
F8E872	LSB-BTB8: Switching output A8 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:12		E	2
F8E912	LSB-BTB8: Switching output A9 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:13		E	2
F8E915	LSB-BTB8: Switching output A9 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:13		E	2
F8E91D	LSB-BTB8: Switching output A9 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X2:13		E	2
F8E954	LSB-BTB8: Switching output A9 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8E972	LSB-BTB8: Switching output A9 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:13		E	2
F8EA12	LSB-BTB8: Switching output A10 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:14		E	2
F8EA15	LSB-BTB8: Switching output A10 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:14		E	2
F8EA1D	LSB-BTB8: Switching output A10 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X2:14		E	2
F8EA54	LSB-BTB8: Switching output A10 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:14		E	2
F8EA72	LSB-BTB8: Switching output A10 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:14		E	2
F8EB12	LSB-BTB8: Switching output A11 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:15		E	2
F8EB15	LSB-BTB8: Switching output A11 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:15		E	2
F8EB1D	LSB-BTB8: Switching output A11 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X2:15		E	2
F8EB54	LSB-BTB8: Switching output A11 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8EB72	LSB-BTB8: Switching output A11 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:15		E	2
F8EC12	LSB-BTB8: Switching output A12 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:16		E	2
F8EC15	LSB-BTB8: Switching output A12 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:16		E	2
F8EC1D	LSB-BTB8: Switching output A12 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X2:16		E	2
F8EC54	LSB-BTB8: Switching output A12 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:16		E	2
F8EC72	LSB-BTB8: Switching output A12 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:16		E	2
F8ED12	LSB-BTB8: Switching output A13 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:17		E	2
F8ED15	LSB-BTB8: Switching output A13 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:17		E	2
F8ED1D	LSB-BTB8: Switching output A13 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X2:17		E	2
F8ED54	LSB-BTB8: Switching output A13 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:17		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8ED72	LSB-BTB8: Switching output A13 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:17		E	2
F8EE12	LSB-BTB8: Switching output A14 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:18		E	2
F8EE15	LSB-BTB8: Switching output A14 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:18		E	2
F8EE1D	LSB-BTB8: Switching output A14 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X2:18		E	2
F8EE54	LSB-BTB8: Switching output A14 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:18		E	2
F8EE72	LSB-BTB8: Switching output A14 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:18		E	2
F8EF12	LSB-BTB8: Switching output A15 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:19		E	2
F8EF15	LSB-BTB8: Switching output A15 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:19		E	2
F8EF1D	LSB-BTB8: Switching output A15 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A38.X2:19		E	2
F8EF54	LSB-BTB8: Switching output A15 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:19		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8EF72	LSB-BTB8: Switching output A15 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A38.X2:19		E	2
F8F002	LSB-BTB8: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A38		E	1
F8F013	LSB-BTB8: System error OS-CPU0 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A38		E	1
F8F016	LSB-BTB8: System error OS-CPU0 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A38		E	1
F8F050	LSB-BTB8: System error OS-CPU0 file not available error report Reload application software	A38		E	2
F8F068	LSB-BTB8: System error OS-CPU0 impermissible interrupt Entry in error stack Report all error parameters to Service	A38		E	1
F8F070	LSB-BTB8: System error OS-CPU0 various structure versions Entry in error stack Report all error parameters to Service	A38		E	1
F8F073	LSB-BTB8: System error OS-CPU0 interpreter error Entry in error stack At P0=00000013 carry out download	A38		E	1
F8F075	LSB-BTB8: System error OS-CPU0 SPI-error Entry in error stack Report all error parameters to Service	A38		E	1
F8F078	LSB-BTB8: System error OS-CPU0 impermissible parameter Entry in error stack Report all error parameters to Service	A38		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8F07A	LSB-BTB8: System error OS-CPU0 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A38		E	2
F8F080	LSB-BTB8: System error OS-CPU0 Fatal internal error Entry in error stack Report all error parameters to Service	A38		E	1
F8F082	LSB-BTB8: System error OS-CPU0 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A38		E	1
F8F0AC	LSB-BTB8: System error OS-CPU0 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A38		E	1
F8F0C1	LSB-BTB8: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A38		E	1
F8F0D2	LSB-BTB8: System error OS-CPU0 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A38		E	2
F8F102	LSB-BTB8: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A38		E	1
F8F113	LSB-BTB8: System error OS-CPU1 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A38		E	1
F8F116	LSB-BTB8: System error OS-CPU1 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A38		E	1
F8F150	LSB-BTB8: System error OS-CPU1 file not available error report Reload application software	A38		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8F168	LSB-BTB8: System error OS-CPU1 impermissible interrupt Entry in error stack Report all error parameters to Service	A38		E	1
F8F170	LSB-BTB8: System error OS-CPU1 various structure versions Entry in error stack Report all error parameters to Service	A38		E	1
F8F173	LSB-BTB8: System error OS-CPU1 interpreter error Entry in error stack At P0=00000013 carry out download	A38		E	1
F8F175	LSB-BTB8: System error OS-CPU1 SPI-error Entry in error stack Report all error parameters to Service	A38		E	1
F8F178	LSB-BTB8: System error OS-CPU1 impermissible parameter Entry in error stack Report all error parameters to Service	A38		E	1
F8F17A	LSB-BTB8: System error OS-CPU1 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A38		E	2
F8F180	LSB-BTB8: System error OS-CPU1 Fatal internal error Entry in error stack Report all error parameters to Service	A38		E	1
F8F182	LSB-BTB8: System error OS-CPU1 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A38		E	1
F8F1AC	LSB-BTB8: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A38		E	1
F8F1C1	LSB-BTB8: System error OS-CPU1 Incorrect or wrong system version for application error report Reload matching system version	A38		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8F1D2	LSB-BTB8: System error OS-CPU1 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A38		E	2
F8F800	LSB-BTB8: Control data transfer CAN EP0 internal error at Register-check Controller CAN-transfer is not started replace control device	A38.X3:7/8/3/3		E	2
F8F801	LSB-BTB8: Control data transfer CAN EP0 internal error at RAM-check Controller CAN-transfer is not started replace control device	A38.X3:7/8/3/3		E	2
F8F802	LSB-BTB8: Control data transfer CAN EP0 Configuration error Software Error message, CAN report is not configured Check software	A38.X3:7/8/3/3		E	1
F8F804	LSB-BTB8: Control data transfer CAN EP0 Configuration error time synchronization Time synchronization already active or is not configured Check software	A38.X3:7/8/3/3		E	1
F8F805	LSB-BTB8: Control data transfer CAN EP0 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A38.X3:7/8/3/3		E	1
F8F806	LSB-BTB8: Control data transfer CAN EP0 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A38.X3:7/8/3/3		E	2
F8F807	LSB-BTB8: Control data transfer CAN EP0 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A38.X3:7/8/3/3		E	1
F8F811	LSB-BTB8: Control data transfer CAN EP0 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A38.X3:7/8/3/3		E	2
F8F900	LSB-BTB8: Control data transfer CAN EP1 internal error at Register-check Controller CAN-transfer is not started replace control device	A38.X4:1/2/14/1 3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8F901	LSB-BTB8: Control data transfer CAN EP1 internal error at RAM-check Controller CAN-transfer is not started replace control device	A38.X4:1/2/14/1 3		E	2
F8F902	LSB-BTB8: Control data transfer CAN EP1 Configuration error Software Error message, CAN report is not configured Check software	A38.X4:1/2/14/1 3		E	1
F8F904	LSB-BTB8: Control data transfer CAN EP1 Configuration error time synchronization Time synchronization already active or is not configured Check software	A38.X4:1/2/14/1 3		E	1
F8F905	LSB-BTB8: Control data transfer CAN EP1 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A38.X4:1/2/14/1 3		E	1
F8F906	LSB-BTB8: Control data transfer CAN EP1 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A38.X4:1/2/14/1 3		E	2
F8F907	LSB-BTB8: Control data transfer CAN EP1 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A38.X4:1/2/14/1 3		E	1
F8F911	LSB-BTB8: Control data transfer CAN EP1 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A38.X4:1/2/14/1 3		E	2
F8FA00	LSB-BTB8: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A38.X3:7/8		E	1
F8FA01	LSB-BTB8: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A38.X3:7/8		E	1
F8FA02	LSB-BTB8: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A38.X3:7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8FA04	LSB-BTB8: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A38.X3:7/8		E	1
F8FA05	LSB-BTB8: Control data transfer CAN-A Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A38.X3:7/8		E	1
F8FA06	LSB-BTB8: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A38.X3:7/8		E	2
F8FA11	LSB-BTB8: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A38.X3:7/8		E	1
F8FA32	LSB-BTB8: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A38.X3:7/8		E	1
F8FA40	LSB-BTB8: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A38.X3:7/8		E	1
F8FA41	LSB-BTB8: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A38.X3:7/8		E	1
F8FB00	LSB-BTB8: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A38.X3:3/4		E	1
F8FB01	LSB-BTB8: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A38.X3:3/4		E	1
F8FB02	LSB-BTB8: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A38.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8FB04	LSB-BTB8: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A38.X3:3/4		E	1
F8FB05	LSB-BTB8: Control data transfer CAN-B Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A38.X3:3/4		E	1
F8FB06	LSB-BTB8: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A38.X3:3/4		E	2
F8FB11	LSB-BTB8: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A38.X3:3/4		E	1
F8FB32	LSB-BTB8: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A38.X3:3/4		E	1
F8FB40	LSB-BTB8: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A38.X3:3/4		E	1
F8FB41	LSB-BTB8: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A38.X3:3/4		E	1
F8FC00	LSB-BTB8: Control data transfer CAN-C internal error at Register-check Controller CAN-transfer is not started replace control device	A38.X4:1/2		E	1
F8FC01	LSB-BTB8: Control data transfer CAN-C internal error at RAM-check Controller CAN-transfer is not started replace control device	A38.X4:1/2		E	1
F8FC02	LSB-BTB8: Control data transfer CAN-C Configuration error Software Error message, CAN report is not configured Check software	A38.X4:1/2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8FC04	LSB-BTB8: Control data transfer CAN-C Configuration error time synchronization Time synchronization already active or is not configured Check software	A38.X4:1/2		E	1
F8FC05	LSB-BTB8: Control data transfer CAN-C Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A38.X4:1/2		E	1
F8FC06	LSB-BTB8: Control data transfer CAN-C fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A38.X4:1/2		E	2
F8FC11	LSB-BTB8: Control data transfer CAN-C permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A38.X4:1/2		E	1
F8FC32	LSB-BTB8: Control data transfer CAN-C Data transfer erroneous/missing check wiring	A38.X4:1/2		E	1
F8FC40	LSB-BTB8: Control data transfer CAN-C Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A38.X4:1/2		E	1
F8FC41	LSB-BTB8: Control data transfer CAN-C Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A38.X4:1/2		E	1
F8FD00	LSB-BTB8: Control data transfer CAN-D internal error at Register-check Controller CAN-transfer is not started replace control device	A38.X4:14/13		E	1
F8FD01	LSB-BTB8: Control data transfer CAN-D internal error at RAM-check Controller CAN-transfer is not started replace control device	A38.X4:14/13		E	1
F8FD02	LSB-BTB8: Control data transfer CAN-D Configuration error Software Error message, CAN report is not configured Check software	A38.X4:14/13		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
F8FD04	LSB-BTB8: Control data transfer CAN-D Configuration error time synchronization Time synchronization already active or is not configured Check software	A38.X4:14/13		E	1
F8FD05	LSB-BTB8: Control data transfer CAN-D Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A38.X4:14/13		E	1
F8FD06	LSB-BTB8: Control data transfer CAN-D fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A38.X4:14/13		E	2
F8FD11	LSB-BTB8: Control data transfer CAN-D permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A38.X4:14/13		E	1
F8FD32	LSB-BTB8: Control data transfer CAN-D Data transfer erroneous/missing check wiring	A38.X4:14/13		E	1
F8FD40	LSB-BTB8: Control data transfer CAN-D Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A38.X4:14/13		E	1
F8FD41	LSB-BTB8: Control data transfer CAN-D Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A38.X4:14/13		E	1
FB016A	LSB-BTB11: LSBA Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB016C	LSB-BTB11: LSBA Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB036A	LSB-BTB11: LSBA Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB036C	LSB-BTB11: LSBA Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB046A	LSB-BTB11: LSBA Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB046C	LSB-BTB11: LSBA Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB056A	LSB-BTB11: LSBA Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB056C	LSB-BTB11: LSBA Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB066A	LSB-BTB11: LSBA Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB066C	LSB-BTB11: LSBA Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB076A	LSB-BTB11: LSBA Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB076C	LSB-BTB11: LSBA Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB086A	LSB-BTB11: LSBA Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB086C	LSB-BTB11: LSBA Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB096A	LSB-BTB11: LSBA Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB096C	LSB-BTB11: LSBA Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB0A6A	LSB-BTB11: LSBA Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB0A6C	LSB-BTB11: LSBA Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB0B6A	LSB-BTB11: LSBA Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB0B6C	LSB-BTB11: LSBA Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB0C6A	LSB-BTB11: LSBA Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB0C6C	LSB-BTB11: LSBA Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB0D6A	LSB-BTB11: LSBA Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB0D6C	LSB-BTB11: LSBA Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB0E6A	LSB-BTB11: LSBA Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB0E6C	LSB-BTB11: LSBA Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB106A	LSB-BTB11: LSBA Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB106C	LSB-BTB11: LSBA Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB136A	LSB-BTB11: LSBA Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB136C	LSB-BTB11: LSBA Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB146A	LSB-BTB11: LSBA Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB146C	LSB-BTB11: LSBA Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB156A	LSB-BTB11: LSBA Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB156C	LSB-BTB11: LSBA Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB166A	LSB-BTB11: LSBA Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB166C	LSB-BTB11: LSBA Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB176A	LSB-BTB11: LSBA Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB176C	LSB-BTB11: LSBA Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB186A	LSB-BTB11: LSBA Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB186C	LSB-BTB11: LSBA Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB196A	LSB-BTB11: LSBA Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB196C	LSB-BTB11: LSBA Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB1A6A	LSB-BTB11: LSBA Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB1A6C	LSB-BTB11: LSBA Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB1B6A	LSB-BTB11: LSBA Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB1B6C	LSB-BTB11: LSBA Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB1C6A	LSB-BTB11: LSBA Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB1C6C	LSB-BTB11: LSBA Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB1D6A	LSB-BTB11: LSBA Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB1D6C	LSB-BTB11: LSBA Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB1E6A	LSB-BTB11: LSBA Participant Adr. 30 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:12		E	2
FB1E6C	LSB-BTB11: LSBA Participant Adr. 30 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:12		E	2
FB205B	LSB-BTB11: Control data transfer LSBA Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A831.X4:12		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB316A	LSB-BTB11: LSBB Participant Adr. 1 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB316C	LSB-BTB11: LSBB Participant Adr. 1 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB336A	LSB-BTB11: LSBB Participant Adr. 3 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB336C	LSB-BTB11: LSBB Participant Adr. 3 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB346A	LSB-BTB11: LSBB Participant Adr. 4 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB346C	LSB-BTB11: LSBB Participant Adr. 4 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB356A	LSB-BTB11: LSBB Participant Adr. 5 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB356C	LSB-BTB11: LSBB Participant Adr. 5 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB366A	LSB-BTB11: LSBB Participant Adr. 6 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB366C	LSB-BTB11: LSBB Participant Adr. 6 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB376A	LSB-BTB11: LSBB Participant Adr. 7 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB376C	LSB-BTB11: LSBB Participant Adr. 7 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB386A	LSB-BTB11: LSBB Participant Adr. 8 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB386C	LSB-BTB11: LSBB Participant Adr. 8 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB396A	LSB-BTB11: LSBB Participant Adr. 9 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB396C	LSB-BTB11: LSBB Participant Adr. 9 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB3A6A	LSB-BTB11: LSBB Participant Adr. 10 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB3A6C	LSB-BTB11: LSBB Participant Adr. 10 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB3B6A	LSB-BTB11: LSBB Participant Adr. 11 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB3B6C	LSB-BTB11: LSBB Participant Adr. 11 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB3C6A	LSB-BTB11: LSBB Participant Adr. 12 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB3C6C	LSB-BTB11: LSBB Participant Adr. 12 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB3D6A	LSB-BTB11: LSBB Participant Adr. 13 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB3D6C	LSB-BTB11: LSBB Participant Adr. 13 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB3E6A	LSB-BTB11: LSBB Participant Adr. 14 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB3E6C	LSB-BTB11: LSBB Participant Adr. 14 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB3F6A	LSB-BTB11: LSBB Participant Adr. 15 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB3F6C	LSB-BTB11: LSBB Participant Adr. 15 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB406A	LSB-BTB11: LSBB Participant Adr. 16 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB406C	LSB-BTB11: LSBB Participant Adr. 16 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB416A	LSB-BTB11: LSBB Participant Adr. 17 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB416C	LSB-BTB11: LSBB Participant Adr. 17 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB426A	LSB-BTB11: LSBB Participant Adr. 18 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB426C	LSB-BTB11: LSBB Participant Adr. 18 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB436A	LSB-BTB11: LSBB Participant Adr. 19 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB436C	LSB-BTB11: LSBB Participant Adr. 19 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB446A	LSB-BTB11: LSBB Participant Adr. 20 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB446C	LSB-BTB11: LSBB Participant Adr. 20 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB456A	LSB-BTB11: LSBB Participant Adr. 21 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB456C	LSB-BTB11: LSBB Participant Adr. 21 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB466A	LSB-BTB11: LSBB Participant Adr. 22 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB466C	LSB-BTB11: LSBB Participant Adr. 22 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB476A	LSB-BTB11: LSBB Participant Adr. 23 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB476C	LSB-BTB11: LSBB Participant Adr. 23 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB486A	LSB-BTB11: LSBB Participant Adr. 24 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB486C	LSB-BTB11: LSBB Participant Adr. 24 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB496A	LSB-BTB11: LSBB Participant Adr. 25 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB496C	LSB-BTB11: LSBB Participant Adr. 25 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB4A6A	LSB-BTB11: LSBB Participant Adr. 26 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB4A6C	LSB-BTB11: LSBB Participant Adr. 26 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB4B6A	LSB-BTB11: LSBB Participant Adr. 27 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB4B6C	LSB-BTB11: LSBB Participant Adr. 27 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB4C6A	LSB-BTB11: LSBB Participant Adr. 28 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB4C6C	LSB-BTB11: LSBB Participant Adr. 28 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB4D6A	LSB-BTB11: LSBB Participant Adr. 29 Expanded safety info (time stamp or CRC8) is erroneous Entry in error stack otherwise no reaction. Error free operation is no longer ensured Check config. sensor parameterization. Sensor does not support this operating mode	A831.X4:9		E	2
FB4D6C	LSB-BTB11: LSBB Participant Adr. 29 Reports sometime still on bus Entry in error stack otherwise no reaction. Error free operation is no longer ensured check connection, if connection ok then replace sensor	A831.X4:9		E	2
FB505B	LSB-BTB11: Control data transfer LSBB Short circuit on 2nd LSB-Transistor Entry in error stack otherwise no reaction. Only note, the sensor still functions without restriction Driver incorrectly configured. Check parameterization. Otherwise hardware defect. Replace module	A831.X4:9		E	2
FB5D51	LSB-BTB11: control auxiliary equipment Button Ladder UP after Start/op. error actuated or stuck Movement is not actuated check wiring	A831		B	
FB5D52	LSB-BTB11: control auxiliary equipment Button Ladder DOWN after Start/op. error actuated or stuck Movement is not actuated check wiring	A831		B	
FB5D53	LSB-BTB11: control auxiliary equipment Forced zero position double control of latter (button and BTT) Movement is not actuated Actuate only from one op. location	A831		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB5D54	LSB-BTB11: control auxiliary equipment Control panel Support Button act. after start or stuck Error message aux. user functions are blocked Check wiring or unplug op. panel to be able to use other aux. users	A831		E	
FB5D55	LSB-BTB11: control auxiliary equipment Control panel Pinning Button act. after start or stuck Error message aux. user functions are blocked Check wiring or unplug op. panel to be able to use other aux. users	A831		E	
FB5E4A	LSB-BTB11: crane control Pressure supply HV short circuit after ground or interruption	A831		E	
FB5E4D	LSB-BTB11: crane control Monitoring Release Pinning, Short circuit after Plus error report Check signal line for short circuit. Check wiring, switch on valve	A831		B	
FB5E4E	LSB-BTB11: crane control Monitoring Release Pinning, interruption/Short circuit after ground error report Check signal line for interruption, check wiring, switch on valve. Replace valve	A831		B	
FB5E7E	LSB-BTB11: crane control Warning pressure supply HV < pmin with actuation Error issue function blocked Check sensor, wiring, hydr. cartridge	A831		E	
FB5E7F	LSB-BTB11: crane control Warning pressure supply HV > pmin without actuation Error issue function blocked Check sensor, wiring, hydr. cartridge	A831		E	
FB611C	LSB-BTB11: Operation crane control Mandatory zero after interruption bus conn.(s) actuation / release No act. of winch. NO act. of winch brake Reset master switch (zero force). Error always occurs in con. with a shut off or system error	A831		B	
FB613A	LSB-BTB11: Operation crane control Selection Assembly winch from several op. positions simultaneous Function blocked Actuate only from one op. location	A831		B	
FB613B	LSB-BTB11: Operation crane control Selection Assembly winch spool up and out simultaneous Issue of error / winch is not actuated Select only one direction	A831		B	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB613C	LSB-BTB11: Operation crane control Notice! Unplug control panel during crane operation! error report Unplug control panel, plug in dummy plug or check wiring	A831		B	
FB6156	LSB-BTB11: Operation crane control Selection aux. user without release from crane control Pressure supply valve open, no issuance of Error message not simultaneously ballasting or lowering winch when aux. brake system active	A831		B	
FB62BE	LSB-BTB11: Control hydraulic Remeasure BKE, output error Function tilt cab Error message aux. user functions are blocked Check wiring	A831		E	
FB62BF	LSB-BTB11: Control hydraulic Remeasure BKE, output error Function swing cab Error message aux. user functions are blocked Check wiring	A831		E	
FB62C5	LSB-BTB11: Control hydraulic Valve assembly cylinder up/down stuck error report Replace valve Assembly cylinder up/ down	A831		E	
FB62C6	LSB-BTB11: Control hydraulic Pressure supply turntable has leakage error report Leckage suchen	A831		E	
FB62C7	LSB-BTB11: Control hydraulic Valve assembly winch up/down stuck error report Replace valve assembly winch up / down	A831		E	
FB62C8	LSB-BTB11: Control hydraulic Valve swing cab in / out stuck error report Valve swing cab ein / aus tauschen	A831		E	
FB62C9	LSB-BTB11: Control hydraulic Valve tilt cab up / down stuck error report Valve tilt cabauf / ab tauschen	A831		E	
FB62CA	LSB-BTB11: Control hydraulic Valve ladder up / down stuck error report Replace valve Ladder up / down	A831		E	

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB62CB	LSB-BTB11: Control hydraulic Valve support center section up / down stuck error report Replace valve support center part up / down. Check if ball valve support is closed if not support	A831		E	
FB62CC	LSB-BTB11: Control hydraulic Valve pinning / unpinning stuck error report Replace valve pin / unpin	A831		E	
FB62CD	LSB-BTB11: Control hydraulic Flow switch Support does not switch at movement selection Error message aux. user functions are blocked Check wiring	A831		E	
FB62CE	LSB-BTB11: Control hydraulic Flow switch Assembly cyl. does not switch at movement sel. Error message aux. user functions are blocked Check wiring	A831		E	
FB62CF	LSB-BTB11: Control hydraulic Flow switch Cab function does not switch at movement sel. Error message aux. user functions are blocked Check wiring	A831		E	
FB7007	LSB-BTB11: remote control Zero position compulsion on radio MS	A831		E	1
FB7019	LSB-BTB11: remote control No radio release (electrical signal not available) No movements possible via radio control	A831		E	
FB7090	LSB-BTB11: remote control Short circuit after supply voltage on radio input UEA No movements possible via radio control Check electr.line	A831		E	1
FB9900	LSB-BTB11: Control data transfer CAN internal error at Register-check Controller CAN-transfer is not started replace control device	A831		E	2
FB9901	LSB-BTB11: Control data transfer CAN internal error at RAM-check Controller CAN-transfer is not started replace control device	A831		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FB9902	LSB-BTB11: Control data transfer CAN Configuration error Software Error message, CAN report is not configured Check software	A831		E	1
FB9904	LSB-BTB11: Control data transfer CAN Configuration error time synchronization Time synchronization already active or is not configured Check software	A831		E	1
FB9905	LSB-BTB11: Control data transfer CAN Configuration error IOX-gateway AEW-gateway already active or not configured Check software	A831		E	1
FB9906	LSB-BTB11: Control data transfer CAN fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A831		E	2
FB9907	LSB-BTB11: Control data transfer CAN J1939-Diagnostics: LEC conversion file not found Error message, CAN report is not configured Check software, report all error parameters to customer service	A831		E	1
FB9911	LSB-BTB11: Control data transfer CAN permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A831		E	2
FBC218	LSB-BTB11: Hardware excess temperature Entry in error stack Replace LSB-Module	A831		E	2
FBC21B	LSB-BTB11: Hardware digital shut off defective Entry in error stack Report all error parameters to Service	A831		E	2
FBC21F	LSB-BTB11: Hardware After run logic defective Entry in error stack Report all error parameters to Service	A831		E	2
FBC226	LSB-BTB11: Hardware Under temperature Entry in error stack Replace LSB-Module	A831		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBC261	LSB-BTB11: Hardware measuring system defect Entry in error stack Replace LSB-Module	A831		E	2
FBC504	LSB-BTB11: System voltage Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A831		E	2
FBC505	LSB-BTB11: System voltage Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A831		E	2
FBC50F	LSB-BTB11: System voltage Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A831		E	2
FBC604	LSB-BTB11: System voltage CPU/Logic / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A831		E	2
FBC605	LSB-BTB11: System voltage CPU/Logic / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A831		E	2
FBC60F	LSB-BTB11: System voltage CPU/Logic / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A831		E	2
FBC704	LSB-BTB11: Supply voltage 30 (A0-7) / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A831.X1:2/3		E	2
FBC705	LSB-BTB11: Supply voltage 30 (A0-7) / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A831.X1:2/3		E	2
FBC804	LSB-BTB11: Supply voltage 15.1 / CPU0 level exceeded Entry in error stack Report all error parameters to Service	A831.X1:1		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBC805	LSB-BTB11: Supply voltage 15.1 / CPU0 below minimum level Entry in error stack Report all error parameters to Service	A831.X1:1		E	2
FBC80F	LSB-BTB11: Supply voltage 15.1 / CPU0 different information on other processor Entry in error stack Report all error parameters to Service	A831.X1:1		E	2
FBCC04	LSB-BTB11: System voltage Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A831		E	2
FBCC05	LSB-BTB11: System voltage Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A831		E	2
FBCC0F	LSB-BTB11: System voltage Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A831		E	2
FBCE04	LSB-BTB11: System voltage CPU/Logic / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A831		E	2
FBCE05	LSB-BTB11: System voltage CPU/Logic / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A831		E	2
FBCE0F	LSB-BTB11: System voltage CPU/Logic / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A831		E	2
FBCE04	LSB-BTB11: Supply voltage 30 (A8-15) / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A831.X2:2/3		E	2
FBCE05	LSB-BTB11: Supply voltage 30 (A8-15) / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A831.X2:2/3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBCF04	LSB-BTB11: Supply voltage 15.1 / CPU1 level exceeded Entry in error stack Report all error parameters to Service	A831.X2:1		E	2
FBCF05	LSB-BTB11: Supply voltage 15.1 / CPU1 below minimum level Entry in error stack Report all error parameters to Service	A831.X2:1		E	2
FBCF0F	LSB-BTB11: Supply voltage 15.1 / CPU1 different information on other processor Entry in error stack Report all error parameters to Service	A831.X2:1		E	2
FBD004	LSB-BTB11: Digital input E0 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:4		E	2
FBD005	LSB-BTB11: Digital input E0 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:4		E	2
FBD104	LSB-BTB11: Digital input E1 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:5		E	2
FBD105	LSB-BTB11: Digital input E1 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:5		E	2
FBD204	LSB-BTB11: Digital input E2 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:6		E	2
FBD205	LSB-BTB11: Digital input E2 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:6		E	2
FBD304	LSB-BTB11: Digital input E3 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:7		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBD305	LSB-BTB11: Digital input E3 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:7		E	2
FBD403	LSB-BTB11: Digital input E4 sensor deficiency data short circuit to ground error report Check wiring	A831.X1:8		E	
FBD503	LSB-BTB11: Digital input E5 sensor deficiency data short circuit to ground error report Check wiring	A831.X1:9		E	
FBD603	LSB-BTB11: Digital input E6 sensor deficiency data short circuit to ground error report Check wiring	A831.X1:10		E	
FBD804	LSB-BTB11: Digital input E8 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:4		E	2
FBD805	LSB-BTB11: Digital input E8 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:4		E	2
FBD904	LSB-BTB11: Digital input E9 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:5		E	2
FBD905	LSB-BTB11: Digital input E9 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:5		E	2
FBD956	LSB-BTB11: Digital input E9 open circuit or short circuit to ground error report Check wiring	A831.X2:5		E	
FBDA04	LSB-BTB11: Digital input E10 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:6		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBDA05	LSB-BTB11: Digital input E10 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:6		E	2
FBDA56	LSB-BTB11: Digital input E10 open circuit or short circuit to ground error report Check wiring	A831.X2:6		E	
FBDB04	LSB-BTB11: Digital input E11 level exceeded Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:7		E	2
FBDB05	LSB-BTB11: Digital input E11 below minimum level Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:7		E	2
FBE012	LSB-BTB11: Switching output A0 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:12		E	2
FBE015	LSB-BTB11: Switching output A0 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:12		E	2
FBE01D	LSB-BTB11: Switching output A0 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X1:12		E	2
FBE054	LSB-BTB11: Switching output A0 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:12		E	2
FBE072	LSB-BTB11: Switching output A0 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:12		E	2
FBE112	LSB-BTB11: Switching output A1 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBE115	LSB-BTB11: Switching output A1 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:13		E	2
FBE11D	LSB-BTB11: Switching output A1 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X1:13		E	2
FBE154	LSB-BTB11: Switching output A1 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:13		E	2
FBE172	LSB-BTB11: Switching output A1 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:13		E	2
FBE212	LSB-BTB11: Switching output A2 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:14		E	2
FBE215	LSB-BTB11: Switching output A2 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:14		E	2
FBE21D	LSB-BTB11: Switching output A2 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X1:14		E	2
FBE254	LSB-BTB11: Switching output A2 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:14		E	2
FBE272	LSB-BTB11: Switching output A2 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:14		E	2
FBE312	LSB-BTB11: Switching output A3 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBE315	LSB-BTB11: Switching output A3 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:15		E	2
FBE31D	LSB-BTB11: Switching output A3 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X1:15		E	2
FBE354	LSB-BTB11: Switching output A3 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:15		E	2
FBE372	LSB-BTB11: Switching output A3 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:15		E	2
FBE412	LSB-BTB11: Switching output A4 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:16		E	2
FBE415	LSB-BTB11: Switching output A4 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:16		E	2
FBE41D	LSB-BTB11: Switching output A4 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X1:16		E	2
FBE454	LSB-BTB11: Switching output A4 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:16		E	2
FBE472	LSB-BTB11: Switching output A4 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:16		E	2
FBE512	LSB-BTB11: Switching output A5 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:17		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBE515	LSB-BTB11: Switching output A5 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:17		E	2
FBE51D	LSB-BTB11: Switching output A5 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X1:17		E	2
FBE554	LSB-BTB11: Switching output A5 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:17		E	2
FBE572	LSB-BTB11: Switching output A5 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:17		E	2
FBE612	LSB-BTB11: Switching output A6 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:18		E	2
FBE615	LSB-BTB11: Switching output A6 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:18		E	2
FBE61D	LSB-BTB11: Switching output A6 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X1:18		E	2
FBE654	LSB-BTB11: Switching output A6 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:18		E	2
FBE672	LSB-BTB11: Switching output A6 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:18		E	2
FBE712	LSB-BTB11: Switching output A7 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:19		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBE715	LSB-BTB11: Switching output A7 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:19		E	2
FBE71D	LSB-BTB11: Switching output A7 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X1:19		E	2
FBE754	LSB-BTB11: Switching output A7 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:19		E	2
FBE772	LSB-BTB11: Switching output A7 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X1:19		E	2
FBE812	LSB-BTB11: Switching output A8 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:12		E	2
FBE815	LSB-BTB11: Switching output A8 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:12		E	2
FBE81D	LSB-BTB11: Switching output A8 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X2:12		E	2
FBE854	LSB-BTB11: Switching output A8 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:12		E	2
FBE872	LSB-BTB11: Switching output A8 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:12		E	2
FBE912	LSB-BTB11: Switching output A9 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBE915	LSB-BTB11: Switching output A9 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:13		E	2
FBE91D	LSB-BTB11: Switching output A9 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X2:13		E	2
FBE954	LSB-BTB11: Switching output A9 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:13		E	2
FBE972	LSB-BTB11: Switching output A9 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:13		E	2
FBEA12	LSB-BTB11: Switching output A10 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:14		E	2
FBEA15	LSB-BTB11: Switching output A10 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:14		E	2
FBEA1D	LSB-BTB11: Switching output A10 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X2:14		E	2
FBEA54	LSB-BTB11: Switching output A10 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:14		E	2
FBEA72	LSB-BTB11: Switching output A10 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:14		E	2
FBEB12	LSB-BTB11: Switching output A11 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:15		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBEB15	LSB-BTB11: Switching output A11 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:15		E	2
FBEB1D	LSB-BTB11: Switching output A11 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X2:15		E	2
FBEB54	LSB-BTB11: Switching output A11 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:15		E	2
FBEB72	LSB-BTB11: Switching output A11 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:15		E	2
FBEC12	LSB-BTB11: Switching output A12 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:16		E	2
FBEC15	LSB-BTB11: Switching output A12 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:16		E	2
FBEC1D	LSB-BTB11: Switching output A12 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X2:16		E	2
FBEC54	LSB-BTB11: Switching output A12 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:16		E	2
FBEC72	LSB-BTB11: Switching output A12 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:16		E	2
FBED12	LSB-BTB11: Switching output A13 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:17		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBED15	LSB-BTB11: Switching output A13 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:17		E	2
FBED1D	LSB-BTB11: Switching output A13 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X2:17		E	2
FBED54	LSB-BTB11: Switching output A13 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:17		E	2
FBED72	LSB-BTB11: Switching output A13 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:17		E	2
FBEE12	LSB-BTB11: Switching output A14 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:18		E	2
FBEE15	LSB-BTB11: Switching output A14 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:18		E	2
FBEE1D	LSB-BTB11: Switching output A14 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X2:18		E	2
FBEE54	LSB-BTB11: Switching output A14 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:18		E	2
FBEE72	LSB-BTB11: Switching output A14 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:18		E	2
FBEF12	LSB-BTB11: Switching output A15 short circuit to ground Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:19		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBEF15	LSB-BTB11: Switching output A15 open electric circuit Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:19		E	2
FBEF1D	LSB-BTB11: Switching output A15 Initial current outside permissible range Entry in error stack Report all error parameters to Service	A831.X2:19		E	2
FBEF54	LSB-BTB11: Switching output A15 short circuit to supply voltage Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:19		E	2
FBEF72	LSB-BTB11: Switching output A15 outside source feeding Entry in error stack Check signal, replace LSB-Module if nec.	A831.X2:19		E	2
FBF002	LSB-BTB11: System error OS-CPU0 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A831		E	1
FBF013	LSB-BTB11: System error OS-CPU0 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A831		E	1
FBF016	LSB-BTB11: System error OS-CPU0 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A831		E	1
FBF050	LSB-BTB11: System error OS-CPU0 file not available error report Reload application software	A831		E	2
FBF068	LSB-BTB11: System error OS-CPU0 impermissible interrupt Entry in error stack Report all error parameters to Service	A831		E	1
FBF070	LSB-BTB11: System error OS-CPU0 various structure versions Entry in error stack Report all error parameters to Service	A831		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBF073	LSB-BTB11: System error OS-CPU0 interpreter error Entry in error stack At P0=00000013 carry out download	A831		E	1
FBF075	LSB-BTB11: System error OS-CPU0 SPI-error Entry in error stack Report all error parameters to Service	A831		E	1
FBF078	LSB-BTB11: System error OS-CPU0 impermissible parameter Entry in error stack Report all error parameters to Service	A831		E	1
FBF07A	LSB-BTB11: System error OS-CPU0 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A831		E	2
FBF080	LSB-BTB11: System error OS-CPU0 Fatal internal error Entry in error stack Report all error parameters to Service	A831		E	1
FBF082	LSB-BTB11: System error OS-CPU0 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A831		E	1
FBF0AC	LSB-BTB11: System error OS-CPU0 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A831		E	1
FBF0C1	LSB-BTB11: System error OS-CPU0 Incorrect or wrong system version for application error report Reload matching system version	A831		E	1
FBF0D2	LSB-BTB11: System error OS-CPU0 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A831		E	2
FBF102	LSB-BTB11: System error OS-CPU1 initialising error test total in EPROM/FLASH erroneous Entry in error stack Report all error parameters to Service	A831		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBF113	LSB-BTB11: System error OS-CPU1 Test sum in FLASH erroneous Entry in error stack Report all error parameters to Service	A831		E	1
FBF116	LSB-BTB11: System error OS-CPU1 system-, driver-watchdog expired Entry in error stack Report all error parameters to Service	A831		E	1
FBF150	LSB-BTB11: System error OS-CPU1 file not available error report Reload application software	A831		E	2
FBF168	LSB-BTB11: System error OS-CPU1 impermissible interrupt Entry in error stack Report all error parameters to Service	A831		E	1
FBF170	LSB-BTB11: System error OS-CPU1 various structure versions Entry in error stack Report all error parameters to Service	A831		E	1
FBF173	LSB-BTB11: System error OS-CPU1 interpreter error Entry in error stack At P0=00000013 carry out download	A831		E	1
FBF175	LSB-BTB11: System error OS-CPU1 SPI-error Entry in error stack Report all error parameters to Service	A831		E	1
FBF178	LSB-BTB11: System error OS-CPU1 impermissible parameter Entry in error stack Report all error parameters to Service	A831		E	1
FBF17A	LSB-BTB11: System error OS-CPU1 Configuration file missing or faulty Entry in error stack Report all error parameters to Service	A831		E	2
FBF180	LSB-BTB11: System error OS-CPU1 Fatal internal error Entry in error stack Report all error parameters to Service	A831		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBF182	LSB-BTB11: System error OS-CPU1 hardware-watchdog erroneous Entry in error stack Report all error parameters to Service	A831		E	1
FBF1AC	LSB-BTB11: System error OS-CPU1 Restoration of CW-operandi failed Entry in error stack Report all error parameters to Service	A831		E	1
FBF1C1	LSB-BTB11: System error OS-CPU1 Incorrect or wrong system version for application error report Reload matching system version	A831		E	1
FBF1D2	LSB-BTB11: System error OS-CPU1 No program release after fatal error Entry in error memory, program is stopped If error repeated, repl. comp. group, report error param. to Service	A831		E	2
FBF800	LSB-BTB11: Control data transfer CAN EP0 internal error at Register-check Controller CAN-transfer is not started replace control device	A831.X3:7/8/3/3		E	2
FBF801	LSB-BTB11: Control data transfer CAN EP0 internal error at RAM-check Controller CAN-transfer is not started replace control device	A831.X3:7/8/3/3		E	2
FBF802	LSB-BTB11: Control data transfer CAN EP0 Configuration error Software Error message, CAN report is not configured Check software	A831.X3:7/8/3/3		E	1
FBF804	LSB-BTB11: Control data transfer CAN EP0 Configuration error time synchronization Time synchronization already active or is not configured Check software	A831.X3:7/8/3/3		E	1
FBF805	LSB-BTB11: Control data transfer CAN EP0 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A831.X3:7/8/3/3		E	1
FBF806	LSB-BTB11: Control data transfer CAN EP0 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A831.X3:7/8/3/3		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBF807	LSB-BTB11: Control data transfer CAN EP0 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A831.X3:7/8/3/3		E	1
FBF811	LSB-BTB11: Control data transfer CAN EP0 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A831.X3:7/8/3/3		E	2
FBF900	LSB-BTB11: Control data transfer CAN EP1 internal error at Register-check Controller CAN-transfer is not started replace control device	A831.X4:1/2/14/ 13		E	2
FBF901	LSB-BTB11: Control data transfer CAN EP1 internal error at RAM-check Controller CAN-transfer is not started replace control device	A831.X4:1/2/14/ 13		E	2
FBF902	LSB-BTB11: Control data transfer CAN EP1 Configuration error Software Error message, CAN report is not configured Check software	A831.X4:1/2/14/ 13		E	1
FBF904	LSB-BTB11: Control data transfer CAN EP1 Configuration error time synchronization Time synchronization already active or is not configured Check software	A831.X4:1/2/14/ 13		E	1
FBF905	LSB-BTB11: Control data transfer CAN EP1 Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A831.X4:1/2/14/ 13		E	1
FBF906	LSB-BTB11: Control data transfer CAN EP1 fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A831.X4:1/2/14/ 13		E	2
FBF907	LSB-BTB11: Control data transfer CAN EP1 J1939-Diagnostics: LEC conversion file not found Associated error text cannot be called up Report all error parameters to Service	A831.X4:1/2/14/ 13		E	1
FBF911	LSB-BTB11: Control data transfer CAN EP1 permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A831.X4:1/2/14/ 13		E	2

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBFA00	LSB-BTB11: Control data transfer CAN-A internal error at Register-check Controller CAN-transfer is not started replace control device	A831.X3:7/8		E	1
FBFA01	LSB-BTB11: Control data transfer CAN-A internal error at RAM-check Controller CAN-transfer is not started replace control device	A831.X3:7/8		E	1
FBFA02	LSB-BTB11: Control data transfer CAN-A Configuration error Software Error message, CAN report is not configured Check software	A831.X3:7/8		E	1
FBFA04	LSB-BTB11: Control data transfer CAN-A Configuration error time synchronization Time synchronization already active or is not configured Check software	A831.X3:7/8		E	1
FBFA05	LSB-BTB11: Control data transfer CAN-A Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A831.X3:7/8		E	1
FBFA06	LSB-BTB11: Control data transfer CAN-A fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A831.X3:7/8		E	2
FBFA11	LSB-BTB11: Control data transfer CAN-A permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A831.X3:7/8		E	1
FBFA32	LSB-BTB11: Control data transfer CAN-A Data transfer erroneous/missing check wiring	A831.X3:7/8		E	1
FBFA40	LSB-BTB11: Control data transfer CAN-A Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A831.X3:7/8		E	1
FBFA41	LSB-BTB11: Control data transfer CAN-A Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A831.X3:7/8		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBFB00	LSB-BTB11: Control data transfer CAN-B internal error at Register-check Controller CAN-transfer is not started replace control device	A831.X3:3/4		E	1
FBFB01	LSB-BTB11: Control data transfer CAN-B internal error at RAM-check Controller CAN-transfer is not started replace control device	A831.X3:3/4		E	1
FBFB02	LSB-BTB11: Control data transfer CAN-B Configuration error Software Error message, CAN report is not configured Check software	A831.X3:3/4		E	1
FBFB04	LSB-BTB11: Control data transfer CAN-B Configuration error time synchronization Time synchronization already active or is not configured Check software	A831.X3:3/4		E	1
FBFB05	LSB-BTB11: Control data transfer CAN-B Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A831.X3:3/4		E	1
FBFB06	LSB-BTB11: Control data transfer CAN-B fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A831.X3:3/4		E	2
FBFB11	LSB-BTB11: Control data transfer CAN-B permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A831.X3:3/4		E	1
FBFB32	LSB-BTB11: Control data transfer CAN-B Data transfer erroneous/missing check wiring	A831.X3:3/4		E	1
FBFB40	LSB-BTB11: Control data transfer CAN-B Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A831.X3:3/4		E	1
FBFB41	LSB-BTB11: Control data transfer CAN-B Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A831.X3:3/4		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBFC00	LSB-BTB11: Control data transfer CAN-C internal error at Register-check Controller CAN-transfer is not started replace control device	A831.X4:1/2		E	1
FBFC01	LSB-BTB11: Control data transfer CAN-C internal error at RAM-check Controller CAN-transfer is not started replace control device	A831.X4:1/2		E	1
FBFC02	LSB-BTB11: Control data transfer CAN-C Configuration error Software Error message, CAN report is not configured Check software	A831.X4:1/2		E	1
FBFC04	LSB-BTB11: Control data transfer CAN-C Configuration error time synchronization Time synchronization already active or is not configured Check software	A831.X4:1/2		E	1
FBFC05	LSB-BTB11: Control data transfer CAN-C Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A831.X4:1/2		E	1
FBFC06	LSB-BTB11: Control data transfer CAN-C fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A831.X4:1/2		E	2
FBFC11	LSB-BTB11: Control data transfer CAN-C permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A831.X4:1/2		E	1
FBFC32	LSB-BTB11: Control data transfer CAN-C Data transfer erroneous/missing check wiring	A831.X4:1/2		E	1
FBFC40	LSB-BTB11: Control data transfer CAN-C Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A831.X4:1/2		E	1
FBFC41	LSB-BTB11: Control data transfer CAN-C Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A831.X4:1/2		E	1

Fehler-Nr.	Fehlertext / Reaktion / Behebung	Stecker	Blatt	K	W
FBFD00	LSB-BTB11: Control data transfer CAN-D internal error at Register-check Controller CAN-transfer is not started replace control device	A831.X4:14/13		E	1
FBFD01	LSB-BTB11: Control data transfer CAN-D internal error at RAM-check Controller CAN-transfer is not started replace control device	A831.X4:14/13		E	1
FBFD02	LSB-BTB11: Control data transfer CAN-D Configuration error Software Error message, CAN report is not configured Check software	A831.X4:14/13		E	1
FBFD04	LSB-BTB11: Control data transfer CAN-D Configuration error time synchronization Time synchronization already active or is not configured Check software	A831.X4:14/13		E	1
FBFD05	LSB-BTB11: Control data transfer CAN-D Configuration error IOX-gateway AEW-Gateway already active or is not configured Check software	A831.X4:14/13		E	1
FBFD06	LSB-BTB11: Control data transfer CAN-D fatal run time error at RAM-check Controller Error message, CAN-driver is stopped replace control device	A831.X4:14/13		E	2
FBFD11	LSB-BTB11: Control data transfer CAN-D permanent error bus connection timeout for CAN-reports, parametric default values are used CAN-Bus lines, end resistors (2x120 Ohm parallel = 60 Ohm), check control units on bus	A831.X4:14/13		E	1
FBFD32	LSB-BTB11: Control data transfer CAN-D Data transfer erroneous/missing check wiring	A831.X4:14/13		E	1
FBFD40	LSB-BTB11: Control data transfer CAN-D Undefined error code (J1939, SPN) Entry in error stack Report all error parameters to Service	A831.X4:14/13		E	1
FBFD41	LSB-BTB11: Control data transfer CAN-D Diagnostics message J1939 DMx with incorrect conversion method (CM) Associated error text cannot be called up Report all error parameters to Service	A831.X4:14/13		E	1

